

1935-36
MODELS.
117 AND 214
(GENERAL
ELECTRIC.
M-50 AND M-55a)

I-F Tuning Adjustments


- (a) Short circuit the antenna and ground terminals and tune the receiver so that no signal is received. Set the volume control to its maximum position. Ground the receiver.
- (b) Connect the output of the test oscillator between the first detector control grid and chassis ground. Attach an indicating meter, such as is illustrated on page 2, to the speaker circuit.
- (c) Place the external oscillator into operation at 460 kc. Adjust the output so that a slight registration occurs on the output indicator. The output should be set at as low a value as will give a convenient indication during adjustment; this requirement is important in that the a.v.c. action is voided by such a method. Adjust the secondary and primary trimmers (C18 and C17) of the first i-f transformer for maximum receiver output.

- a minimum during the adjustments. The trimmers C44 and C45 should then be tuned to the point giving peak receiver output.
- (c) Retune the test oscillator, setting its frequency to 600 kc. Turn the receiver selector control to the point where the incoming oscillator signal is received best. *This point will not always be exactly at 600 on the dial*. Then adjust the low-frequency trimmer C40, simultaneously rocking the tuning capacitor slowly through the signal until maximum receiver output results from these combined operations. This adjustment must be made irrespective of dial calibration. It is advisable to repeat the 1720 kc. adjustment of the oscillator trimmer C44 in order to correct for any change caused by the tuning of C40.

I.F. = 460 K.C.

R-F and Oscillator Adjustments

- (a) Connect the output of the modulated Full Range Oscillator to the antenna and ground terminals of the receiver. Check the position of the dial pointer. It should set exactly on the radial line, adjacent to the dial reading of 540 when the tuning capacitor plates are at full mesh. After correcting the dial pointer, place the receiver in operation and set the selector at 1720 kc., advance the volume control to maximum and turn the range switch to its broadcast position.
- (b) Adjust the frequency of the external oscillator to 1720 kc. and regulate its output until a perceptible indication appears on the output indicator. This indication should be held at



Trimmer Locations and Radiatron Socket Voltages
 (Measured at 115 volts line supply—Maximum Volume Control—No Signal)

DATA SHEET

PRINTED IN CANADA

COURTESY—R.C.A.

VICTOR-45