

DENON

Hi-Fi Component

SERVICE MANUAL STEREO CASSETTE TAPE DECK MODEL DRM-800




TABLE OF CONTENTS

OPERATING INSTRUCTIONS.....	2 ~ 11
SPECIFICATIONS.....	11
BLOCK DIAGRAM	12
LEVEL DIAGRAM.....	13
DISASSEMBLY INSTRUCTIONS.....	14 ~ 15
ADJUSTING AND CHECKING THE MECHANISM SECTION	15 ~ 17
ADJUSTING THE ELECTRICAL SECTIONS.....	17 ~ 19
PARTS LIST OF EXPLODED VIEW.....	20
EXPLODED VIEW OF CABINET AND CHASSIS GROUP.....	21
PARTS LIST OF 4U-1817/4U-1823/MECHANISM EXPLODED VIEW.....	22
EXPLODED VIEW OF MECHANISM.....	23
PARTS LIST OF 4U-1816	24
WIRING DIAGRAM	25
SCHEMATIC DIAGRAM.....	26 ~ 27
P.W.BOARD OF 4U-1816	28
P.W.BOARD OF 4U-1817/4U-1823	29
SEMICONDUCTORS	30

NIPPON COLUMBIA CO., LTD.

IMPORTANT TO SAFETY

WARNING:

TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.

CAUTION:

1. Handle the power supply cord carefully

Do not damage or deform the power supply cord. If it is damaged or deformed, it may cause electric shock or malfunction when used. When removing from wall outlet, be sure to remove by holding the plug attachment and not by pulling the cord.

2. Do not open back plate

In order to prevent electric shock, do not open the back plate. If problems occur, contact your DENON dealer.

3. Do not place anything inside

Do not place metal objects or spill liquid inside the cassette deck. Electric shock or malfunction may result.

Please, record and retain the Model name and serial number of your set shown on the rating label.

Model No. DRM-800

Serial No. _____

SAFETY INSTRUCTIONS FOR AUDIO SET

■ INSTALLATION

- Operate the set only from a power source which is indicated on the rating label (indication) at the back of the set.
- Frayed cords and broken plugs may cause a fire or shock hazard. Do not damage the power cord.
 - Do not cut and splice the power cord.
 - When removing the power cord from wall outlet, be sure to unplug by holding the plug attachment and not by pulling the cord. Do not hot the plug by wet hand.
 - Call your service technician for replacement of damaged cords and plugs.




Check voltage



Do not pinch power cord.




Do not splice power cord.



Avoid heat.

■ USE

- Do not expose the set to rain or water (liquid). Do not spill liquid or insert metal objects inside the set. Rain, water or liquid such as cosmetics as well as metal may cause electric shorts which can result in fire or shock hazard. If any thing gets inside, unplug the power cord and have a DENON service technician check your set before further use.
- Never leave your set switched on when leaving the house. For added protection of your audio system during lightning storm or when the set is to be left unused for a long period of time be sure to unplug the power cord from the wall outlet.
- Take care so that the set is not dropped to avoid damaging the cabinet which defeats safeguards or injuring yourself. If the set has been dropped or the cabinet has been damaged, unplug the set and have it checked by a DENON service technician to restore the safeguards.



Remove power in your absence.

■ SERVICING

- The servicing of set must not be attempted by yourself beyond that described in the operating instructions. In case of problems that cannot be settled by referring to your operating instructions, unplug the power cord and contact your DENON dealer. No user-serviceable parts are inside the set. Only qualified service inside your set.
- Refer to the operating instructions for maintenance and cleaning.



Do not drop.



No user-serviceable parts inside.

— TABLE OF CONTENTS —

FEATURES	3
CONNECTION	3
FRONT PANEL SWITCHES AND CONTROLS	4~5
PLAYBACK	5
RECORDING	6
PROPER RECORDING LEVEL	6
RECORDING BIAS ADJUSTMENT	7
REC/REC MUTE KEY	7
AUTO TAPE SELECT FEATURE	7
MUSIC SEARCH SYSTEM	8
TAPE COUNTER AND MEMORY STOP	8
MONITOR BUTTON	9
DOLBY C NOISE REDUCTION SYSTEM	9
DOLBY HX-PRO HEADROOM EXTENTION SYSTEM	9
MAINTENANCE	10
CASSETTE TAPE	10
SYMPTOMS OFTEN MISTAKEN AS BREAKDOWNS	11
SPECIFICATIONS	11

Thank you very much for purchasing the DENON component DRM-800.

THE DENON DRM-800 is a top-line stereo cassette tape deck, capable of outstanding performance in combination with high grade hi-fi systems.


DENON proudly presents this advanced tape deck to audiophiles and music lovers as a further proof of DENON's non-compromising pursuit of the ultimate in sound quality. The high quality performance and easy operation are certain to provide you with many hours of outstanding listening pleasure.

FEATURES

- Computer-controlled servo technology.
 - Closed-loop dual-capstan tape transport.
 - Silent, soft-touch controls provide maximum ease-of-use.
 - Computer-controlled, full-logic tape controls enable fool-proof operation.
 - Automatic eliminating the slack of the tape.
- Three-head design utilizes the SF Amorphous record/playback combination head assembly.
- Dolby HX PRO headroom extension.
- Dolby C noise reduction systems (Double Dolby System).
- Computing linear tape counter with 4-digit readout and memory stop.
- Wide-range FL peak level meters.
- Auto tape selector.
- Recording Bias adjustment control.
- Cassette stabilizer.

CONNECTION

- Leave your entire system (including this cassette deck) turned off until all connections between the deck and other components have been made.



■ Connecting the deck to an amplifier

- Before connecting the deck to your amplifier, it is a good practice to review your amplifier's instruction manual.
- Use the white plugs for the left channel, and the red plugs for the right channel.

■ Connecting the deck to CD player (CD DIRECT)

Use the separately sold pin cord to connect the CD DIRECT IN terminal of the cassette deck to the LINE OUT (ANALOG) FIX terminal of the CD player.

■ Systems remote control

When you use our company's receiver and the cassette deck having the REMOTE CONTROL (TAPE) terminal, connect their REMOTE CONTROL terminals with the attached mini-plug cable. ("PLAY, FF, REW, STOP, REC/REC MUTE AND REC PAUSE" can be operated by the wireless remote controller attached to the receiver.)

■ Tape dubbing

- Many stereo amplifiers and receivers have tape dubbing circuitry so that tape duplication can be performed between two or more tape decks. Review your amplifier's instruction manual for a full explanation of this mode of operation.


■ Connecting Headphones

To listen through headphones, plug your headphones into the PHONES jack.

■ Installation Precautions

If the deck is placed on or too near an amplifier or tuner, noise (induced hum) or beat interference may result (especially during AM reception). If this occurs, separate the deck from other components or reorient its position.

FRONT PANEL SWITCHES AND CONTROLS



① POWER switch

Controls the supply of AC power to the deck. One push turns the deck on, a second push turns it off. The deck remains in a stand-by (non-operative) mode for approximately 2 seconds after it is switched on.

② EJECT button

Press this button to eject the cassette. When the deck is operating (tape is running), press the stop (■) key first to stop the tape transport; then press the EJECT button.

③ Cassette compartment cover

If this compartment cover is not closed completely, the deck's transport controls will remain inoperative.

④ COUNTER RESET button

Operation of the button resets the counter to all zero.

⑤ MEMORY button

During rewinding operations, the tape will stop at the "0000" counter point automatically when this button is pressed in.

⑥ TAPE SIZE button

You can know accurate elapsed time of the tape by adjusting the TAPE SIZE button to the tape size used. When the TAPE SIZE button is pressed, the current tape size is displayed for 1 sec in the 4-figures counter. If you further press the button during the display, the tape size will change in the following cycle.
C-90 C-75 C-60 C-100

⑦ DOLBY NR button

Immediately after the power source is turned off, DOLBY NR becomes the "OFF" state. When the left-side DOLBY NR button is pressed once with DOLBY NR being at the "OFF" state, DOLBY NR B-TYPE is preferred and turned on. Every time when the right-side B/C button is pressed, B-TYPE and C-TYPE are selected alternatively.

⑧ MPX FILTER button

The MPX FILTER button should be used to prevent interference with the Dolby NR circuit when making Dolby NR encoded recordings of FM stereo programs. When making Dolby NR encoded recordings from any program source other than FM stereo, leave this button in the "OFF" position.

⑨ CD DIRECT button

If you connect the CD player as the CONNECTION (CD DIRECT) shown on page 3, the signals are directly input without passing through the stereo amplifier, and thus the signal route can be shortened improving the sound quality. Press this button for the CD DIRECT recording.

⑩ MONITOR button

The SOURCE position of this button allows you to monitor the source program before it is recorded. The TAPE position of this button is used for tape playback monitoring or simultaneous monitoring during recording.

⑪ BIAS FINE control

(for NORMAL, CrO₂ and METAL tape)
Adjust the bias according to the tape characteristics. Standard biasing is obtained at the center click-stop position.

⑫ BALANCE control

This is the knob to adjust the recording level balance between the left and right channels. Turn it counter-clockwise to reduce the right channel's level and clockwise to reduce the left channel's. Usually, put the knob at the center click position.

⑬ PHONES jack

For private music enjoyment without disturbing others, or for monitoring a recording, a set of headphones may be plugged in. Impedance should be from 8 to 1200 ohms.

⑭ OUTPUT LEVEL control

This control adjusts playback, recording monitor, and headphones output levels for the both channels simultaneously.

⑮ INPUT LEVEL control

The recording input level is adjusted by this knob. The levels in the left and right channels can be changed simultaneously.

⑯ DISPLAY

The indicators with an encircled number light up by pressing the corresponding button.

FLUORESCENT PEAK METER
These meters indicate recording or playback peak levels for each channel. For peak levels exceeding +7 dB, the Auto Peak Hold Feature holds the peak level reading for approximately 2 seconds.

DOLBY NR Indicator I INPUT Indicator 3

TAPE SELECT Indicator
This indicator light is interlocked with the Auto Tape Select feature which automatically adjusts the deck to the type of tape in use.

L -40 -30 -20 -10 -5 -3 -2 -1 0 0 +1 +2 +3 +5 +7 +10
R -40 -30 -20 -10 -5 -3 -2 -1 0 0 +1 +2 +3 +5 +7 +10

PEAK HOLD

INPUT DOLBY NR LINE CD DIRECT C-TYPE FILTER
MEMORY FILTER TAPE TYPE-I TYPE-IV

>PLAY PAUSE REC
MONITOR TAPE SOURCE

MONITOR Indicator 6

TAPE TRANSPORT Indicator 5

4-DIGIT READOUT Indicator

-LINEAR TAPE COUNTER (3)
Tape passage is indicated digitally in minutes and seconds.
-TAPE SIZE (4)

The tape size selected by the TAPE SIZE button is displayed for 1 second.

MEMORY Indicator 2

FILTER Indicator 2

④ REC RETURN Button

When this key is pressed at the recording state, the tape is rewound to the starting point. When the starting point is


automatically reached, the record standby mode (rec pause state) comes.

⑤ Tape transport controls

▶ PLAY	PLAY KEY	Press to playback tape.
■ STOP	STOP KEY	Press to stop tape in any mode.
◀◀	REW KEY	Press for fast rewind.
▶▶	FF KEY	Press for fast forward tape winding.
● REC/REC MUTE	RECORD/MUTE KEY	To begin recording, press the RECORD and PLAY keys simultaneously. If only the RECORD key is pressed, the deck is placed in the REC PAUSE (record standby) mode. When this key is pressed under the REC PAUSE state, the mode shifts to the Auto Rec Mute. When this key is pressed for making a non-recorded part between two melodies, about 5 sec of non-recorded part can automatically be created.
■ REC PAUSE	REC PAUSE KEY	Press this key if you want to change from the rec mute or recording state into the rec pause state. "Pause" is effective during "RECORDING" only.

PLAYBACK

- Switch on your amplifier or receiver.
- Set the TAPE MONITOR switch on your amplifier or receiver to the TAPE position.
- Operate the deck in numerical order as illustrated below:



① PHONES

Playback sound is fed into the headphone set.

② POWER

Push the switch to turn "ON" (▲) the power.

③ EJECT

Press the EJECT button to open the cassette compartment.

④ Cassette Compartment Cover

When a cassette tape is inserted and the door is closed, the tape is automatically wound up for about 0.2 sec. to eliminate the slack.

⑤ DOLBY NR

For recordings made without Dolby NR, set to "OFF". For recordings made with Dolby B NR, set to "ON" and "B". (The B-TYPE indicator will light up.)

For recordings made with Dolby C NR, set to "ON" and "C". (The C-TYPE indicator will light up.)

⑥ ▶PLAY

Push the PLAY KEY (The ▶ PLAY and TAPE indicators will light up).

⑦ OUTPUT

Check to make sure the OUTPUT LEVEL.


- When playback is finished, press the stop (■STOP) key.
- To restart the tape, press the PLAY (▶PLAY) key.
- If different types of Dolby Noise Reduction are used for record and playback, playback response will be adversely effected.

Note:

If the power switch is turned OFF in either the recording or playback mode, the cassette cannot be removed, even if the EJECT button is pressed. Please turn the power switch ON again, and then in stop mode, press the EJECT button to remove the cassette tape.

RECORDING

- Switch on the source component (tuner, amplifier, etc.).
- Set the TAPE MONITER switch on your amplifier or receiver to the SOURCE position.



① POWER

Push the switch to turn "ON" (—) the power.

② EJECT

Press the EJECT button to open the cassette compartment.

③ Cassette Compartment Cover

When a cassette tape is inserted and the door is closed, the tape is automatically wound up for about 0.2 sec. to eliminate the slack. (Confirm that the claw of the cassette half is not broken.)

④ DOLBY NR

Set, in accordance with the recording to be made. For recordings without Dolby NR, set to "OFF". For recordings with Dolby B NR, set to "ON" and "B" (The B-TYPE indicator will light up). For recordings with Dolby C NR, set to "ON" and "C" (The C-TYPE indicator will light up). Future mistakes during playback can be avoided if the cassette is so marked for Dolby NR encoded recordings.

⑤ MPX FILTER

Button it "ON" for the DOLBY NR recording of FM broadcasts (The FILTER indicator will light up).

⑥ REC/REC MUTE

When pressed, the deck goes into the record standby mode. The REC and PAUSE indicators will light up, and both recording/playback and erase heads will come into contact with the tape. Initial setting of recording levels should be made in the record standby mode. (The source monitor mode comes automatically.)

⑦ INPUT LEVEL

Used to set the recording level.

⑧ BALANCE

Adjust the recording level balance between the left and right channels.

⑨ ▶PLAY

When pressed, the recording will start. The ▶PLAY and REC indicators will light up. (The tape monitor mode comes automatically.)

• When recording is finished, press the STOP (■STOP) key.

PROPER RECORDING LEVEL

A too high recording level can saturate the tape and cause distortion. On the other hand, if recording levels are set too low, soft passages will be marked by residual noise. Proper recording level is the single most important factor for making well balanced recordings.

Guideline for maximum recording level

Normal tape (TYPE I)	+1 dB levels on peaks
CrO ₂ tape (TYPE II)	-3 dB levels on peaks
Metal tape (TYPE IV)	+5 dB levels on peaks

Note: Optimum recording levels can differ depending on program sources or the type of tape used. Make trial recordings using the simultaneous monitoring. Refer to the description under "MONITOR BUTTON".

■ Meter reading difference between L and R channels

The left and right channels readings of the PEAK METER can differ due to variations in input signal levels. In such cases, adjust the individual channels of the BALANCE control until identical meter readings are obtained for both channels.



RECORDING BIAS ADJUSTMENT

For best recording results, monitoring during the recording process and comparing various recordings using your own judgement are essential.

The DRM-800 is equipped with a bias adjustment control to assist you in setting the proper bias for different types and brands of recording tape. At the center stop position, the deck is set for a reference bias level for NORMAL, CrO₂ and METAL tapes. If the resulting recording in this position has too much or too little high frequency

content, varying the bias adjustment control can be useful to achieve better results.

If the high frequencies (treble sounds) are to be boosted, turn the bias control counterclockwise to decrease bias current. If distortion is of more concern than high frequency response, turn the control clockwise to increase bias current. By the use of this control, you can record tapes with response that matches your personal listening tastes.



REC/REC MUTE KEY

REC/REC MUTE is the DENON's unique and convenient function. By using this key, it is easily possible to insert a suitable space (the non-recorded part) between two melodies.

1. When you want to make about 5 sec of non-recorded part after the recording state:
Press the REC/REC MUTE key. The recorder will automatically create about 5 sec of non-recorded part and will stay in the recording standby state.
2. To create about 5 sec of non-recorded part after the standby state:

Press the REC/REC MUTE key, and the recorder will enter the non-recording state, automatically create about 5 sec of non-recorded part and stay in the standby state.

3. To cancel the non-recording state (the REC MUTE state): Press the REC PAUSE key, and the recorder will cancel the non-recording state and will stay in the standby state.
4. To extend the non-recording state (the REC MUTE state) for further 5 sec or more:
Press the REC/REC MUTE key, and the non-recorded part will automatically be extended for another 5 sec.

AUTO TAPE SELECT FEATURE

This Stereo Cassette Deck contains an Auto Tape Select feature which automatically selects the optimum bias and equalization for the tape in use. This is accomplished by detection of tape type detection holes in the cassette housing. The Tape type (TYPE-I, TYPE-II or TYPE-III) is indicated by the TAPE SELECT indicator.

- If a tape without tape type detection holes is used, the TAPE SELECT indicator will not indicate the correct tape type and the deck will automatically adjust itself for normal tapes.



MUSIC SEARCH SYSTEM

This device is a convenient system which detects the non-recorded part of more than 4 seconds between melodies, cues the next melody while the present melody is being reproduced or automatically detects the beginning of the melody now being reproduced and makes it into the reproducible state.

1. For cueing the next melody while the present melody is being reproduced:

At PLAY mode, depress the PLAY key and the FF key simultaneously. This device will detect the interval between melodies with the CUE state on, automatically become the PLAY mode and begin performing the next melody.

2. For hearing again the melody now being reproduced:


At PLAY mode, depress the PLAY key and the REW key simultaneously. This device will detect the interval between melodies with the REVIEW state on, automatically become the PLAY mode, detect the beginning of the melody now being performed and play it from the first again.

Note: Note about MUSIC SEARCH action:

MUSIC SEARCH is a function which operates by detecting a comparatively long non-recorded part on the tape. Therefore, MUSIC SEARCH may not operate normally in the following cases.

- Sound on the tape is interrupted by speech or conversation.
- Long periods of pianissimo (softly played music) or non-recorded intervals occur on the tape
- The tape has picked up noise in a non-recorded interval.
- Non-recorded intervals on the tape are less than 4 seconds in length.
- Noise-emitting electrical appliances are in operation nearby. i.e.; Electric razors, drills, refrigerators, etc.

TAPE COUNTER AND MEMORY STOP



1) Operation of the Linear Tape Counter




- (1) Press the RESET button to reset the counter to "0000".
- (2) By using the PLAY, FF, or REW function, the reading of the counter indicate in minutes and seconds.
 - During recording and playback operations, the counter is useful for noting the location of existing programs or positions where recording is to be started.
 - The reading of this counter does not correspond with that of any other deck.
 - The linear counter of this machine is designed to be suitable for the cassette tape with a small hub. Therefore if a cassette tape with a large hub is used in this machine, some error will occur in the display on the counter.

2) Operation of MEMORY STOP

1. During recording or playback operations, MEMORY STOP can be used to locate a particular point on the tape. At the desired point, reset the counter to "0000". With the MEMORY STOP button in the "ON" position, the deck will stop at the "0000" point (actually "5955" and "0000") during REWIND operations.
2. The MEMORY indication will light when this function is activated.
3. Notes:
 - When the power is turned "OFF", this function is automatically deactivated.
 - The MEMORY STOP is accurate to ± 5 on the counter, and will stop between "5955" and "0000".
 - The MEMORY STOP is released by pressing the EJECT button.
 - The MEMORY STOP does not operate during the REC RETURN.

MONITOR BUTTON

This Stereo cassette deck uses a three-head system which permits simultaneous "off-the-tape monitoring" during recording. Use the MONITOR button to select monitoring sources. Incidentally, as this Stereo Cassette Deck adopts an automonitor system, **TAPE** or **SOURCE** can automatically be activated according to the operation conditions. These modes can also be activated manually. The MONITOR indicator shows the selected monitoring source, **TAPE** or **SOURCE**.

Recording		The signal recorded on the tape is monitored simultaneously "off-the-tape". This monitoring mode enables you easy check for optimum recording levels. In the TAPE mode, the FL PEAK METER indicates the signal levels played back off-the-tape.
		The SOURCE position enables you to monitor the input source signal before it is recorded on the tape. Using the FL PEAK METER, this mode is convenient for setting recording levels or input level monitoring during recording.
Playback		During playback, the MONITOR button must be placed in the TAPE position. If it is set in the SOURCE position, the signal from the tape won't be heard.

DOLBY C NOISE REDUCTION SYSTEM

- The Dolby noise reduction system substantially reduces the tape background noise (hiss) inherent in the cassette medium. Dolby B NR is most widely in use. However, Dolby C NR is a much more recent development and represents a significantly improvements over Dolby B NR.
- Tape background noise consists primarily of high frequency information which is particularly annoying during soft passages. The Dolby NR system increase the level of low volume mid and high frequency signal during recording and reduces the level of these signals by an identical amount during playback. As a result, the playback signal is identical to the original source signal, but the level of background noise generated by the tape is greatly reduced.

- The operating principle of Dolby C NR is similar to that of B except for the encoding/decoding response curves. The noise reduction effect obtained by Dolby C NR is up to 20dB, compared to 10dB with Dolby B NR. In addition, Dolby C NR uses an antisaturation network and spectral skewing circuit, and significantly improves the dynamic range in the mid to high frequencies.

DOLBY HX-PRO HEADROOM EXTENSION SYSTEM

This deck is equipped with the DOLBY HX-PRO headroom extension system. Since the system functions automatically during recording, no switching operation or adjustment is required. The system is effective with any type of Normal, CrO₂ or Metal tapes.

The Dolby HX-PRO headroom extention system functions during recording to lift up the saturation level in the treble range. Therefore, most of the treble range components distorted or lost during recording on conventional cassette decks are more faithfully recorded on the new DRM-800 cassette deck.

Features of the DOLBY HX-PRO headroom extension system

- (1) Performance of Normal and CrO₂ tapes can be upgraded closer to that of Metal tapes.
- (2) The dynamic range in the treble is improved significantly.
- (3) Since no decoding in playback is necessary, the improvement can be obviously heard on any hi-fi playback system including portable components and car systems.
- (4) The system functions whether the Dolby B/C NR is engaged or not.

MAINTENANCE


■ Removing the cassette compartment cover

It will be more convenient if the cassette compartment cover is removed during the cleaning of the pinchroller and heads, or during demagnetizing of heads.

Follow these procedures:


1. Press the EJECT button to open the cassette compartment.
2. Hold only the cover of the cassette compartment and pull it up. The compartment cover is removed from the front.

When attaching the cassette compartment cover, reverse the above procedure.



■ Head Cleaning

After long usage, tape coating or dust may adhere to the heads causing deterioration of sound. Clean them regularly. Use a cotton swab moistened with cleaning solution (such as alcohol).




Note:

1. Some cleaning cassettes on the market have a strong abrasive effect and scratch the heads. Use cotton swabs instead of cleaning cassettes.
2. Since the use of metal tapes is apt to collect more dust on the heads, clean the heads more often to enjoy optimum sound.

■ Cleaning the pinchroller and the capstan

If the pinchroller or the capstan accumulate dust, tape transport may become unstable resulting from slippage during recording or playback. The tape can also be damaged by being rolled up around the capstan.

Clean them with a cotton swab or a soft cloth moistened with cleaning solution (such as alcohol).



■ Demagnetizing the heads

The heads may become magnetized after long usage or by having a strongly magnetized object brought near them. The result is a generation of noise, loss of the high frequency range, or erasing the treble components of pre-recorded tapes and adding noise.

Demagnetize the heads on a regular basis.

■ Procedure

1. Be sure to turn "off" the power supply.
2. Turn the demagnetizer "on" while it is more than 30cm away from the heads. Bring the demagnetizer near the heads and slowly move it in a small circle four or five times.
3. Slowly move the demagnetizer away from the heads and turn "off" the power of the demagnetizer when it is about 30cm away from the heads.

CASSETTE TAPE


■ Handling Precautions

• C120 cassettes

C120 cassettes are not recommended as they use a very thin tape base which may become tangled around the capstan or pinchroller.

• Tape slack

This cassette deck incorporates an automatic tape slackness preventive mechanism, but it can not prevent such a slackness as shown below. Remove it with a pencil or the like prior to use.




■ Storage Precautions

- Do not store cassette tapes in a place where they will be subject to:
 - Extremely high temperature or excessive moisture
 - Excessive dust
 - Magnetic fields (near TV set or speakers)
 - Direct sunlight
- To eliminate tape slack, store your cassettes in cassette cases with hub stops.

■ Accidental Erasure Prevention

- Every cassette has erasure prevention tabs for each side. To protect your valuable recorded tapes from accidental or inadvertent erasure, remove the tab for the appropriate side with a screwdriver or other tools.
- To record on a tape with the erasure prevention tabs removed, cover the tab holes with plastic tape.



SYMPTOMS OFTEN MISTAKEN AS BREAKDOWNS

Make sure of the followings before you consider as any malfunctions:

1. Are all the connections correct?
2. Is the set being operated correctly in accordance with the operating instructions?
3. Are the speakers and amplifiers functioning correctly?

If the tape deck still does not function properly, check it again, using the check list below. If the symptom does not correspond to the check list, please contact your DENON dealer.

Symptom	Cause	Remedy
Tape does not run	Power cord is off. Tape is completely wound up. Tape is loose. Cassette is not loaded properly. Defective cassette.	Check power cord. Rewind tape. Tighten tape with pencil, etc. Load cassette properly. Replace cassette.
Tape is not recorded when recording button is pressed.	No cassette is loaded. Erase prevention tab is broken off.	Load cassette. Cover hole with plastic tape.
Sound is warbled or distorted.	Heads, capstan or pinchroller are contaminated. Tape is wound too tight. Recording input level is too high. Tape is worn out and has "drop-outs".	Clean them. Fast forward or rewind to loosen tape winding. Adjust recording input level. Replace tape.
Excessive noise.	Tape is worn. Heads, capstan or pinchroller are contaminated. Heads are magnetized. Recording input level is too low.	Replace tape. Clean them. Demagnetize heads. Adjust recording input level.
High frequency (treble) is emphasized.	Dolby NR button is set improperly.	Set Dolby NR button properly.
High frequency (treble) is lost.	Heads are contaminated. Tape is worn.	Clean them. Replace tape.
When a CrO ₂ or metal tape is placed in the deck, a different tape indicator comes on.	The cassette housing is of an older design without tape type detection holes.	Use the latest cassettes with tape type detection holes.
The cassette tape cannot be removed.	If the power switch is turned off in either the recording or playback mode, and the unit is stopped, there may be cases when the cassette cannot be removed, even if the EJECT button is pressed.	Turn the power switch ON again, and then press the stop (■) key. Then, in the stop mode, press the EJECT button to remove the cassette tape.

SPECIFICATIONS

- Type Vertical tape loading 4-track 2-channel stereo cassette deck
- Heads SF Record/Playback Combination head × 1
Erase head (Double gap ferrite) × 1
- Motors Capstan (DC servo motor) × 1
Reel (DC motor) × 1
Actuator (DC motor) × 1
- Tape Speed 4.8 cm/sec.
- Fast forward, rewind time Approx. 90 sec. with a C-60 cassette
- Recording bias Approx. 105 kHz
- Overall S/N ratio (at 3% THD level) Dolby C NR on ... more than 75 dB (CCIR/ARM)
- Overall frequency response 20~21,000 Hz ±3 dB (at -20 dB METAL tape)
- Channel separation more than 40 dB (at 1 kHz)
- Crosstalk more than 65 dB (at 1 kHz)
- Wow & flutter 0.038% wrms (JIS method)
- Inputs
line 80 mV (-20 dBm) input level at maximum
input impedance : 50 kohm unbalanced


- Outputs
line 620 mV (0 dB) output level at maximum (with 47 kohm load, recorded level of 200 pwb/mm)
headphone 1.2 mW output level at maximum (optimum load impedance 8 ohm~1.2 kohm)
- Accessories Parallel pin cord × 2
Mini-plug cable × 1
- Power supply 50 Hz/60 Hz compatible, voltage is shown on rating label
- Power consumption 18 W
- Dimensions 434 (W) × 135 (H) × 303 (D) mm
- Weight 4.6 kg

■ Above specifications and design styling are subject to change for improvement.

■ Dolby noise reduction and HX PRO headroom extension manufactured under license from Dolby Laboratories Licensing Corporation. HX PRO originated by Bang and Olufsen. "Dolby", the double-D symbol and "HX PRO" are trademarks of Dolby Laboratories Licensing Corporation.

Best results will be obtained with use of DENON DX and HD Series cassette tapes.


BLOCK DIAGRAM



LEVEL DIAGRAM


PLAYBACK SYSTEM

TCC-130 DOLBY B-TYPE
400 Hz 200 mwb/m



RECORDING SYSTEM


INPUT FREQUENCY
400 Hz



DISASSEMBLY INSTRUCTIONS

1. How to Remove the Front Panel


- (1) Remove the two screws (3×10 CBTS-P) (30) in the top side of the top cover (27). Move the top cover to the rear and rise it to remove it.
- (2) Press the eject knob (14), open the cassette window (23) and remove the mechanism as shown in the figure.
Note: Handle the cassette window with care because it can be scratched easily.
- (3) Remove the four screws (3×10 CBTS-P) (30) and the two screws (3×6 CBTS-S) (35) on top of the front panel (16), the five hooks on the top, the three hooks on the bottom and pull the unit forward to detach it.



5 hooks on the top of the front panel



3 hooks on the bottom of the front panel



2. How to Remove the Mechanism

- (1) Remove the top cover (27) and front panel (16). (Refer to Step 1.)
- (2) Remove the screw (3×10 CBTS-P) (30) on the shield bracket (18) and the screws (3×8 CBTS-S) (31) and detach the shield bracket. (Refer to the disassembly figure.)
- (3) Remove the two securing screws (3×10 CBTS-P) (30) for the mechanism.

- (4) Remove the connectors attached to the leads from the mechanism that are attached to the audio board and the power supply board. Remove the style pins that secure the wires.


Mechanism

W891 → (8P) → CN891 (WHITE)	Power supply circuit board
W892 → (7P) → CN892 (WHITE)	
W171 → (6P) → CN171	Audio circuit board
W172 → (4P) → CN172	

Note: Be sure to check that the connectors are reconnected correctly when the unit is reassembled.

- (5) Lift the unit up to remove it.


Note: When the reassembly is performed make sure that the stays at the bottom of the unit enter the slots in the chassis and that no wires are pinched between the unit and the chassis.



3. How to Remove the Front Esc. Assembly

- (1) Remove the top cover (27) and the front panel (16). (Refer to Step 1.)
 - (2) Remove the wires from the front esc. assembly (9) that are connected to the audio board and power supply board.
Front Esc. Assembly
- | | |
|-----------------------------|----------------------------|
| W141 → (13P) → CN141 | |
| W151 → (3P) → CN151 | Audio circuit board |
| W121 → (3P) → CN121 (Blue) | |
| W291 → (25P) → CN291 | Power supply circuit board |

- (3) Remove the two front esc. hooks from the bottom of the chassis and the front esc. assembly can be removed towards the front.



4. How to Remove the Meter Circuit Board


- (1) Remove the top cover (27) and front panel (16). (Refer to Step 1.)
- (2) Remove the front esc. assembly (9). (Refer to Step 3.)
- (3) Remove the three screws (3×10 CBTS-P) (30) that secure the unit board, the seven hooks and remove the meter board.

Note: When replacing the (tactile-takuto) switch (X) insert it so it is not raised after assembly.



5. How to Remove the Audio Circuit Board

- (1) Remove the top cover (27) and the front panel. (Refer to Step 1.)
- (2) Remove the two cushions (26) attached to the chassis and the shield bracket (18).
- (3) Remove the front esc. assembly. (Refer to Step 3.)
- (4) Remove the shield bracket (18).
- (5) Remove the wires from the power supply board that are connected to the unit.
- (6) Remove the two screws (3×10 CBTS-P) that press the 4-pin jack and 2-pin jack, the three screws (3×10 CBTS-P) that secure the circuit board and the two hooks that secure the board to the chassis and the board can pulled out of the assembly.




Note: Most service operations for the audio board can be performed by removing the bottom plate from the rear of the chassis. Refer to the previously described disassembly procedures if it is necessary to remove the entire unit.

Assembly is the reverse of disassembly. Each part must be mounted in the correct position or the unit may not be able to be installed. Make sure that each part is mounted correctly during assembly.

6. How to Remove the Power Supply Board

- (1) Remove the top cover and front panel. (Refer to Step 1.)
- (2) Pull out the power switch lever (13) from the power switch.
- (3) Remove the wires from the unit that are attached to the audio board or power supply board.
- (4) Remove the three screws (3×10 CBTS-P) (30) that secure the power supply circuit board and raise the board to remove it.



ADJUSTING AND CHECKING THE MECHANISM SECTION

1. Exchanging pinch roller


Before exchanging the pinch roller, clean the tape contact surfaces of the pinch roller and of the capstan shaft.

Defects on tape playing are primarily caused by a dirty pinch roller or capstan shaft.


The right pinch roller arm (23) can be detached by removing the spring (24) and the slit washer (317). The left pinch roller arm (104) can be taken out by removing (106), the nylon nut (315) and washers (107) and (108).

After exchanging the pinch roller, run a tape without a C-90 butt and verify that no tape curling occurs at the tape guide (103) and the tape guide part on the record/playback head.

Normal condition




Defective running condition



2. Verifying pinch roller crimping

In the playback condition, hook a stick type spring balance to the bracket on the central axis of the pinch roller. After pulling the pinch roller away from the capstan shaft, let the pinch roller contact the capstan shaft as it is and verify that the readings on the stick type spring balance are 350 to 450 g on the right side and 150 to 250 g on the left when the pinch roller starts turning. If the readings exceed the standard values, replace spring (24) or (106).



3. Exchanging recording/playback head (9)


Detach the front panel first.

3-1 Dismounting recording/playback head

- (1) Detach the recording/playback head locking screw (311) and the azimuth adjusting nut (10).
- (2) Remove soldering on the head wire and separate the mechanical unit to dismount the recording/playback head.

3-2 Recording/playback head installation

Assembly is the reverse of the installation procedure described in section 3-1. The soldering for the head wire is performed as shown in Figure 3-1.



4. Recording/playback head Adjustment

4-1 Height adjustment (adjust with head adjustment jig THG-801)

- (1) Set THG-801 (jig board) on the mechanical unit and perform the adjustment by turning the special height adjustment nut (10) so the 3.8 mm part on THG-801 (jig shaft) can move without touching the tape guide on the recording/playback head (9).
- (2) Turn the azimuth adjusting nut (311) so that the recording/playback head does not tilt while adjusting the height, and make a rough visual adjustment.


4-2 Adjustment of tilt angle

- (1) Set THG-801 (jig board) in the mechanical unit and place THG-801 (jig shaft) on the recording head to inspect the gap between the jig board. If the jig shaft is tilted forward, the tilt screw (311) is too tight. Loosen it slightly and adjust the tilt screw (311) until the jig stick is parallel to the jig board and the gap is completely eliminated.
- (2) Readjusting the tilt may cause the height adjustment to slip. After adjusting the tilt, be sure to verify the height. If the height is misaligned, turn the special height adjustment nut (10) and the tilt screw (311) to the same angle to shift the recording/playback head so it is parallel to the jig board for height readjustment. After the adjustment is completed, tighten the lock nuts.

4-3 Azimuth Adjustment

Playback test tape A-BEX TCC-153 and perform the adjustment by turning the azimuth adjustment nut (311) until A and B in the Lissajous wave figure are at the maximum and the minimum positions respectively. After azimuth adjustment is completed, check again to make sure there is no dislocation on the head height with the readjusting jig THG-801. After the adjustment is completed, secure the lock nuts on the adjusted parts.

Figure 4-2.1 Forward tilt case Figure 4-2.2 Backward tilt case



Note: Be sure to mount the head adjust spacer

5. Erasure Head Exchange

5-1 Remove the locking screw (171) for the erasure head.

- 5-2 Remove the solder on the head wire, and separate the mechanical unit to dismount the erasure head.

6. Tape guide height verification

Set the jig board THG-801 on the mechanical unit. Adjust it by turning the verification adjustment nut (315) so that the 3.8 mm part on the jig stick THG-801 jig shaft move without contacting the tape guide part of the tape guide (103).

7. Verifying fast-forwarding torque

Load a cassette-type torque meter and verify that the reading on the torque meter at the median value is 30—80 g·cm during playback.

If the reading is outside the standard, verify the voltage of the reel motor ($3.3 \text{ V} \pm 0.3 \text{ V}$). If the voltage is low the torque is weak and when the voltage is high the torque is strong.

Also verify the reel thrusting gutter in Item 8.

8. Verification Reel Driver Thrust Movement

Verify that the thrust movement is 3.0 to 4.0 mm.

9. FF and REW Torque Verification

○ When using cassette-type torque meter:

Verify that the readings at the end of the fast-forward and rewind is 80—160 g·cm.

○ Load the cassette half-modified jig and hook the tip of a dial tension meter (full scale 100—300 g) on the triangle part. Switch to the FF (REW) position and feed a tape at a somewhat slower pace than the speed of the tape that is rolled in. Verify that the value on the dial tension meter at that time is more than 80 g·cm.

10. Back tension torque verification for recording/playback

Load a cassette-type torque meter to verify that the reading on the torque meter for recording/playback is 6 to 15 g·cm and there is no unevenness.

If the reading is outside the standard values, verify the reel thrust gutter or replace the spring (7).

11. FF and REW Time Verification


Load a DENON HD-7E/60 cassette tape and verify that the FF and REW time is 80 to 110 seconds. If the reading is outside the standard values, verify Items 8 and 10.

12. Accidental erasure prevention, metal and chrome switch function verification

Verify that switch (83) is functioning normally depending on whether the hole is present or not.

13. Pulse detection LED and reel table clearance verification

Verify that the gap between the surface of the shutter part of the reel table and LED is approximately 1 mm.



ADJUSTING THE ELECTRICAL SECTIONS

ELECTRICAL SYSTEM ADJUSTMENT

● Gauges necessary for adjustment

- (1) Low frequency oscillator (2) Variable resistance attenuator
- (3) Electronic voltmeter (4) Oscilloscope (5) Frequency counter (6) Adjustment driver (7) Trap coil adjustment square regulation shaft
- (8) Test tape (SONY TY224)
(A-BEX TCC-153, TCC-130, TCC-262B/162B)
(DENON HD-7E/60)
- (9) Mirror cassette for playing (A-BEX TCC-902)

● Adjustment Notes


- (1) Clean the head surface, capstan axis, pinch roller, etc. with gauze or cotton swabs soaked with alcohol before adjusting.
- (2) Demagnetize the recording head and erasure head with the head eraser.
- (3) Completely demagnetize the adjusting driver.
- (4) Set function switches as follows unless specifically indicated.
 - MONITOR switch: TAPE
 - INPUT volume: Maximum (right side)
 - DOLBY NR switch: OFF
 - BIAS volume: Center (clicking detent in center)
 - OUT PUT volume: Maximum (right side)
 - BALANCE volume: Center (clicking detent in center)

1. Tape playing check

Load a mirror cassette for playing and examine the area around the fixed guide of the recording/playback head at playing condition with lighting and verify that the tape edge is not contacting the tape guide part. The tape playing is the most important element that determines the capacity of the entire cassette deck. Make every effort to avoid moving the adjusting part. Also, refer to "Adjustment and verification of mechanical system" for exchanging and adjusting the recording/playback head.

2. Azimuth adjustment



- 2-1 After verifying the tape playback, load the test tape (A-BEX TCC-153).
- 2-2 Playback the test tape and make any necessary adjustment by turning the azimuth adjustment nut so that A and B in the Lissajous wave figure are at the maximum and minimum levels respectively.



A-BEX TCC-153

3. Tape Speed Verification and Adjustment



- 3-1 Connect the frequency counter to the LINE OUT terminal and load a test tape (SONY TY-224)
- 3-2 Playback the test tape. When the test tape playback stabilizes at the center part of the tape, adjust the regulator on the back side of the capstan motor so that the frequency counter reading is set within the range of $3000\text{ Hz} \pm 6\text{ Hz}$.



4. Playback System Adjustment

4-1 Playback level


Playback a test tape for Dolby standard level (A-BEX TCC-130). Adjust RT101 (Lch) and RT201 (Rch) so that the LINE OUT terminal level is at -2 dB (0.620 V).



4-2 Verifying playback frequency characteristics


Playback the test tape (A-BEX TCC-262B/162B) and verify that the frequency characteristics conform to the specified standard.

Note: Before checking the playback frequency response, first adjust the azimuth using the 8 kHz signal at the beginning of the test tape (A-BEX TCC-262B). Also, after checking the playback frequency, make sure to readjust the azimuth with the test tape (A-BEX TCC-153) and then lock the adjustment screw.




5 Recording System Adjustment

- 5-1 Adjusting recording/playback comprehensive frequency characteristics
- (1) Load a test tape DENON HD-7E/80. Record with a -38 dB 1 kHz input level signal into the LINE IN terminal and playback.
 - (2) Make a sample recording using a 10-kHz input signal and playback this recording. Adjust RT103 (left channel) and RT203 (right channel) so that they conform to the following specified characteristics.



Record/Playback Overall Frequency Response




5-2 Recording/Playback Level Adjustment

- (1) Load the test tape DENON HD-7E/60. Make a sample recording with the 1 kHz (-38 dB) signal and play this section back.
- (2) Adjust RT-102 (Lch) and RT-202 (Rch) so that the output from LINE OUT terminal is the same as the output at recording monitoring time.

5-3 Dolby C recording and playback comprehensive frequency characteristics verification

- (1) Set the Dolby NR switch at "C" position.
- (2) Use a test tape DENON HD-7E/60 and record and playback as in Item 5-1 to verify that they satisfy the characteristics standards.

Dolby C Record/Playback Overall Frequency Response




PARTS LIST OF EXPLODED VIEW

Ref. No.	Part No	Part Name	Remarks	Ref. No.	Part No.	Part Name	Remarks	
1	411 0857 356	CHASSIS	Europe, U.K. Australia	35	473 7002 005	3×6 CBTS(S)-Z		
	411 0857 372	CHASSIS	Europe (Gold)	40	009 0027 006	25P FFC CABLE		
	411 0857 369	CHASSIS	U.S.A., Canada	41	009 0028 005	17P FFC CABLE		
	411 0857 385	CHASSIS	Asia	42	001 0038 075	VINYL WIRE		
②	2	414 0525 001	EARTH BRACKET		45	441 1128 001	HOOK PROTECTOR	
③	3	105 0828 105	BOTTOM COVER		50	205 0499 025	25P FFC CON.	CN291
④	4	104 0183 119	FOOT ASS'Y		51	205 0514 049	BASE(S)	CN291
	104 0183 122	FOOT ASS'Y	U.S.A. only	52	205 0514 010	25P FFC CON.	CN191	
6	412 2782 008	SHIELD PLATE		⑤	60	4U- 1817 Z81	BASE(S)	
7	461 0178 001	RUBBER SHEET		61	204 8260 004	PWR LOGIC PWB	JK002	
8	VM864	CASSETTE MECHA		⑥	62	4U- 1817 Z82	MINI JACK	
9	103 1224 249	FRONT ESC ASS'Y		63	204 8260 004	MTR CONTROL PWB		
	103 1224 265	FRONT ESC ASS'Y	Europe (Gold)	64	212 4388 907	ASS'Y		
	103 1224 252	FRONT ESC ASS'Y	U.S.A., Canada	⑦	65	4U- 1817 Z84	TACT SWITCH	
10	103 1225 235	FRONT ESC		66	211 0597 003	VOLUME PWB ASS'Y		
	103 1225 251	FRONT ESC	Europe (Gold)	67	211 0595 005	V1620P30FA104	VR302	
	103 1225 248	FRONT ESC	U.S.A., Canada	⑧	68	4U- 1817 Z85	V1103P25C	VR301
⑨	11	143 0615 200	WINDOW		69	204 8264 026	H.P. JACK	
	143 0615 213	WINDOW	U.S.A., Canada	⑩	70	4U- 1823 Z8	P. SUPPLY UNIT	JK001
12	113 1190 134	PUSH KNOB (A)			71	4U- 1823 U8	P. SUPPLY UNIT	Europe
	113 1190 147	PUSH KNOB (A)	Europe (Gold)		72	4U- 1823 K8	P. SUPPLY UNIT	U.S.A., Canada
	113 1190 150	PUSH KNOB (A)	U.S.A. only		73	4U- 1823 M8	P. SUPPLY UNIT	U.K., Australia
13	113 1188 104	P.S. LEVER ASS'Y			74	212 0286 003	POWER TRANS.	Asia
	113 1188 117	P.S. LEVER ASS'Y	Europe (Gold)		75	4U- 1816 Z8	AUDIO PWB UNIT	
	113 1188 120	P.S. LEVER ASS'Y	U.S.A. only		76	204 8310 006	4P PIN JACK	JK301
14	113 1187 202	EJECT KNOB			77	4U- 1861 Z	4P PIN JACK	
	113 1187 215	EJECT KNOB	Europe (Gold)		78	204 8311 018	AUTO STOP PWB	
	113 1187 228	EJECT KNOB	U.S.A. only		79	204 8294 000	UNIT	
15	463 0617 005	SPRING			80	212 0286 003	AC CORD	
16	144 1844 235	FRONT PANEL			81	204 8310 001	AC CORD	Europe, U.K.
	144 1844 248	FRONT PANEL	Europe (Gold)		82	204 8310 006	AC CORD	U.S.A.
17	103 1223 240	ESC BAR			83	204 8310 005	AC CORD	Canada
	103 1223 253	ESC BAR	Europe (Gold)		84	204 8310 028	AC CORD	Asia
	103 1223 266	ESC BAR	U.S.A., Canada		85	204 8311 018	2P PIN JACK	
18	414 0527 106	SHIELD BRACKET			86	513 8294 000	VDE LABEL	Europe only
19	445 0048 016	CORD HOLDER			87	515 8253 025	APPROVAL MARK	Europe only
20	477 0210 003	PUSH RIVET			88	513 8266 009	DANGEROUS MARK	U.S.A. only
21	112 0515 131	VOL KNOB			89	513 1222 008	DATE LABEL	U.S.A., Canada
	112 0515 144	VOL KNOB	Europe (Gold)		90	513 0772 009	UL LABEL	U.S.A. only
	112 0515 128	VOL KNOB	U.S.A. only		91	515 0439 102	SAFETY	U.S.A. only
22	112 0555 007	VOL KNOB (B)			92	515 0418 107	INSTRUCTION	
	112 0555 010	VOL KNOB (B)	Europe (Gold)		93	515 0388 004	DAI WARRANTY	U.S.A. only
23	103 1226 137	C. WINDOW			94	212 4698 008	HOME	
	103 1226 140	C. WINDOW	Europe (Gold)		95	515 0388 004	DCI WARRANTY	Canada only
	103 1226 153	C. WINDOW	U.S.A. only		96	515 8030 008	VOLTAGE SELECTOR	Asia only
24	445 0056 008	CORD BUSH			97	515 8030 008	PRESET LABEL	Asia only
25	412 2008 012	BUSHING PLATE						
26	461 0502 004	CUSHION						
	461 0502 017	CUSHION	U.S.A. only					
27	102 0385 225	TOP COVER						
	102 0385 238	TOP COVER	(Gold)					
30	473 7508 017	3×10 CBTS(P)-B						
	473 7510 005	3×10 CBTS(P)-N	Europe (Gold)					
31	473 7002 018	3×8 CBTS(S)-Z						
32	473 7502 013	4×10 CBTS(P)-Z						
33	477 0262 006	SPECIAL SCREW						


(Gold) in the Remarks column refers to models with Gold front panels.

1 1 2 1 3 4 1 5 1 6 1 7 1 8


EXPLODED VIEW OF CABINET AND CHASSIS GROUP

1 1 2 3 4 5 6 1 7 1 8


EXPLODED VIEW OF MECHANISM UNIT




WIRING DIAGRAM




SCHEMATIC DIAGRAM OF AUDIO SECTION



SCHEMATIC DIAGRAM OF POWER & LOGIC SECTION




P.W. BOARD OF 4U-1816




P.W. BOARD


4U-1817



4U-1823



4U-1823













4U-1861



1 2 3 4 5 6 7 8

SEMICONDUCTORS


④ IC




④ IC



④ Transistors



2SK381




2SC1740
2SC2603




2SB794




2SD985



DTA124XS
DTA143ES
DTA143XS
DTA144ES



DTC124XS
DTC143XS
DTC144ES



1SR35
1SS270A
HZ4A-1
HZ6C-3
HZ7C-2
HZ9C-1
HZ9C-2
HZ30-2