

DENON

Ver. 5

Please refer to the
MODIFICATION NOTICE.

SERVICE MANUAL

MODEL	JP	E3	E2	EK	EA	E1C	E1K	CI
PMA-720AE			✓			✓		
PMA-520AE			✓			✓		

INTEGRATED STEREO AMPLIFIER

• For purposes of improvement, specifications and design are subject to change without notice.

• Please use this service manual with referring to the operating instructions without fail.

• Some illustrations using in this service manual are slightly different from the actual set.

DENON

D&M Holdings Inc.

CONTENTS

ABOUT THIS MANUAL	3
What you can do with this manual	3
Using Adobe Reader (Windows version)	4
SAFETY PRECAUTIONS	6
NOTE FOR SCHEMATIC DIAGRAM	7
NOTE FOR PARTS LIST	7
TECHNICAL SPECIFICATIONS	8
DIMENSION	8
DISASSEMBLY	9
1. FRONT PANEL ASSY	10
3. MAIN PCB ASSY.....	11
4. POWER TRANSFORMER	11
ADJUSTMENT	12
TROUBLE SHOOTING	13
1. The power can not be turned on. (Power indication LED does not light.)	13
2. The power turned on, but a sound does not output normally. (Both channels).....	13
BLOCK AND LEVEL DIAGRAM	15
WIRING DIAGRAM	16
PRINTED WIRING BOARDS	17
MAIN	17
FRONT.....	19
HEADPHONE	19
POWER (PMA-720AE)	20
POWER (PMA-520AE)	20
REMOTE CONTROL	21
FUNCTION.....	21
POWER SW.....	21
VOLUME.....	21
SCHEMATIC DIAGRAMS (1/2)	22
TONE PART	22
POWER PART	22
FUNCTION SW PART.....	22
VOLUME PART.....	22
POWER SW PART.....	22
FLASHER INOUT PART	22
MAIN PART	23
EXPLODED VIEW (PMA-720AE)	24
PARTS LIST OF EXPLODED VIEW (PMA-720AE)	25
PACKING VIEW (PMA-720AE)	26
PARTS LIST OF PACKING & ACCESSORIES (PMA-720AE)	26
EXPLODED VIEW (PMA-520AE)	27
PARTS LIST OF EXPLODED VIEW (PMA-520AE)	28
PACKING VIEW (PMA-520AE)	29
PARTS LIST OF PACKING & ACCESSORIES (PMA-520AE)	29
SEMICONDUCTORS	31
1. IC's	31
PARTS LIST OF P.C.B. UNIT	35
FRONT PCB ASSY (PMA-720AE).....	35
FRONT PCB ASSY (PMA-520AE).....	38
MAIN PCB ASSY (PMA-720AE)	40
MAIN PCB ASSY (PMA-520AE)	46

ABOUT THIS MANUAL

Read the following information before using the service manual.


What you can do with this manual

Search for a Ref. No. (phrase) (Ctrl+Shift+F)

You can use the search function in Acrobat Reader to search for a Ref. No. in schematic diagrams, printed wiring board diagrams, block diagrams, and parts lists.

1. Press **Ctrl+Shift+F** on the keyboard.

- The Search window appears.



2. Enter the Ref. No. you want to search for in the Search window, and then click the **Search** button.

- A list of search results appears.



3. Click an item on the list.

- The screen jumps to the page for that item, and the search phrase is displayed.

Using Adobe Reader (Windows version)

Add notes to this data (Sign)


The Sign function lets you add notes to the data in this manual.

Save the file once you have finished adding notes.

[Example using Adobe Reader X]

On the "View" menu, click "Sign".

- The Sign pane appears.



[Example using Adobe Reader 9]


On the "Document" menu, click "Sign".

Magnify schematic / printed wiring board diagrams - 1

(Ctrl+Space, mouse operation)

Press **Ctrl+Space** on the keyboard and drag the mouse to select the area you want to view.

- The selected area is magnified.




- When you want to move the area shown, hold down **Space** and drag the mouse.

- When you want to show a full page view, press **Ctrl+0** on the keyboard.

Print a magnified part of the manual

The Properties dialog box and functions will vary depending on your printer.

1. Drag the mouse to magnify the part you want to print.
2. On the "File" menu, click "Print".
3. Configure the following settings in the Print dialog box.



Properties

Click this button and check that the printer is set to a suitable paper size.

Page to print

Select the following checkbox.

"More Options" : "Current View"

Page Sizing & Handling

Select the following checkbox.

"Size" / "Size Options" : "Fit"


4. Click the **Print** button to start printing.

Magnify schematic / printed wiring board diagrams - 2 (Pan & Zoom function)


The Pan & Zoom function lets you see which part of a magnified diagram is being shown in a separate window.

[Example using Adobe Reader X]

On the "View" menu, point to "Zoom", and then click "Pan & Zoom".



- The Pan & Zoom window appears on the screen.



[Example using Adobe Reader 9]


On the "Tools" menu, point to "Select & Zoom", and then click "Pan & Zoom Window".

Magnify schematic / printed wiring board diagrams - 3 (Loupe Tool function)


The Loupe Tool function lets you magnify a specific part of a diagram in a separate window.

[Example using Adobe Reader X]

On the "View" menu, point to "Zoom", and then click "Loupe Tool".



- The Loupe Tool window appears on the screen.



[Example using Adobe Reader 9]

On the "Tools" menu, point to "Select & Zoom", and then click "Loupe Tool Window".

NOTE FOR SCHEMATIC DIAGRAM

WARNING:

Parts indicated by the  mark have critical characteristics. Use ONLY replacement parts recommended by the manufacturer.

CAUTION:

Before returning the set to the customer, be sure to carry out either (1) a leakage current check or (2) a line to chassis resistance check. If the leakage current exceeds 0.5 millamps, or if the resistance from chassis to either side of the power cord is less than 460 kohms, the set is defective.

WARNING:

DO NOT return the set to the customer unless the problem is identified and remedied.

NOTICE:

ALL RESISTANCE VALUES IN OHM. K=1,000 OHM / M=1,000,000 OHM

ALL CAPACITANCE VALUES ARE EXPRESSED IN MICRO FARAD, UNLESS OTHERWISE INDICATED. P INDICATES MICRO-MICRO FARAD. EACH VOLTAGE AND CURRENT ARE MEASURED AT NO SIGNAL INPUT CONDITION. CIRCUIT AND PARTS ARE SUBJECT TO CHANGE WITHOUT PRIOR NOTICE.


NOTE FOR PARTS LIST

1. Parts indicated by "nsp" on this table cannot be supplied.
2. When ordering a part, make a clear distinction between "1" and "I" (i) to avoid mis-supplying.
3. A part ordered without specifying its part number can not be supplied.
4. Part indicated by "★" mark is not illustrated in the exploded view.
5. General-purpose Carbon Film Resistor in the P.W.Board parts list. (Refer to the Schematic Diagram for those parts.)
6. General-purpose Carbon Chip Resistors are not included are not included in the P.W.Board parts list.
(Refer to the Schematic Diagram for those parts.)

WARNING: Parts indicated by the  mark have critical characteristics. Use ONLY replacement parts recommended by the manufacturer.

DISASSEMBLY


- Disassemble in order of the arrow in the following figure.
- In the case of the re-assembling, assemble it in order of the reverse of the following flow.
- In the case of the reassembling, observe "Caution concerning disassembly and assembly!".
- If wire bundles are untied or moved to perform adjustment or replace parts etc., be sure to rearrange them neatly as they were originally bundled or placed afterward.
Otherwise, incorrect arrangement can be a cause of noise generation.



About the photos used for "descriptions of the DISASSEMBLY" section

- The shooting direction of each photograph used herein is indicated on the left side of the respective photograph as "Shooting direction: ***". (** : A,B,C,D)
- Refer to the diagram below about the shooting direction of each photograph.
- Photographs with no shooting direction indicated were taken from the top of the set.
- The photograph is PMA-520AEE2 model.


The viewpoint of each photograph
(Shooting direction)




1. FRONT PANEL ASSY

Proceeding : **TOP CABINET** → **FRONT PANEL ASSY**


- (1) Remove the screws.



- (2) Cut the wire clamp bands.



- (3) Disconnect the connector wires, then remove the screws.



Please refer to "EXPLODED VIEW" for the disassembly method of each PCB included in FRONT PANEL ASSY.

2. POWER PCB

Proceeding : **TOP CABINET** → **POWER PCB**

Please refer to "EXPLODED VIEW" for the disassembly method of POWER PCB.

3. MAIN PCB ASSY

Proceeding : **TOP CABINET** → **MAIN PCB ASSY**

Please refer to "EXPLODED VIEW" for the disassembly method of MAIN PCB ASSY.

4. POWER TRANSFORMER

Proceeding : **TOP CABINET** → **POWER TRANSFORMER**

Please refer to "EXPLODED VIEW" for the disassembly method of POWER TRANSFORMER.

ADJUSTMENT

Adjusting Idling Current


Required measurement equipment: DC Voltmeter

1. Preparation

- (1) Avoid direct blow from an air conditioner or an electric fan and humidity should be moderate, and place the set at normal usage environment.
Temperature should be at 15 °C ~ 30 °C (59 °F ~ 86 °F).
- (2) Presetting
 - POWER (Power source switch) OFF
 - VOLUME (Volume control) \odot min.
 - SPEAKER (Speaker terminal) No load
(Do not connect speaker, dummy resistor, etc.)


2. Adjustment

- (1) Remove top cover. And then connect DC Voltmeter to the test points CN31 and CN32 of CUP12196B Main PCB.
- (2) Connect power cord to AC wall outlet, and turn POWER switch "ON".
- (3) Right after power on, adjust VR31 and VR32 so that the DC voltmeter reads $10 \pm 1\text{mV}$.
- (4) Then after 2 minutes warm up adjust VR31 and VR32 so that the DC voltmeter reads $10 \pm 1\text{mV}$.
- (5) And after 10 minutes warm up adjust VR31 and VR32 so that the DC voltmeter reads $10 \pm 0.5\text{mV}$.




TROUBLE SHOOTING

1. The power can not be turned on. (Power indication LED does not light.)




2. The power turned on, but a sound does not output normally. (Both channels)


2.1. Set remains in standby mode.



2.2. Power indicator LED remains flashing red and muting mode is not canceled (protection mode is set).




2.3. Set operates, but then power indicator LED flashes red (protection mode is set).




Personal notes:

BLOCK AND LEVEL DIAGRAM




WIRING DIAGRAM





1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18

MAIN
(FOIL SIDE)




鉛フリー半田
半田付けには、鉛フリー半田 (Sn-Ag-Cu) を使用してください。
Lead-free Solder
When soldering, use the Lead-free Solder (Sn-Ag-Cu).






1 2 3 4 5 6 7 8

FRONT SCHEMATIC DIAGRAM




SCHEMATIC DIAGRAMS (1/2)
TONE PART
POWER PART
FUNCTION SW PART
VOLUME PART
POWER SW PART
FLASHER INOUT PART

GND_A — POWER +_A — POWER -_A — GND_D — POWER +_D — STBY POWER




EXPLODED VIEW (PMA-720AE)



WARNING:
Parts marked with this symbol have critical characteristics.
Use ONLY replacement parts recommended by the manufacturer.

PACKING VIEW (PMA-720AE)



PARTS LIST OF PACKING & ACCESSORIES (PMA-720AE)


*Parts indicated by "nsp" on this table cannot be supplied.
*Parts indicated by the "★" mark are not illustrated in the exploded view.

*The parts listed below are only for maintenance. Therefore they might differ from the parts used in the unit in appearances or dimensions.

Note: The symbols in the column "Remarks" indicate the following destinations.
E2 : Europe model E1C : China model
BK : Black model SP : Premium Silver model


Ref. No.	Part No.	Part Name	Remarks	Q'ty	New
1	943531102590D	BOX , OUT CARTON		CPG2A818R	1 *
2	nsp	BAG , POLY		CPB1A013Y	1
3	943533101210D	PAD , SNOW		CPS3A747	2
4	-	INSTRUCTIONMANUAL ASS'Y		-	1
4-1	943307101180D	REMOCON TRANSMITTER ASS'Y (RC-1173)		CARTDCD720A1	1 *
4-2	nsp	BATTERY , AAA 2PCS IN PACK		CABR03PPB	2
4-3	35251013500AD	CD ROM MANUAL ASS'Y (PMA-720/520AE E2)	E2	CFT1A070ZA	1 *
4-4	54111087900AD	GETTING STARTED _IM (E2)	E2	CQX1A1687Z	1 *
4-4	54111086500AD	INST.MANUAL (PMA-720AE E1C)	E1C	CQX1A1691Z	1 *
4-5	nsp	LIST , S.S		CQE1A226P	1
6	nsp	BAG , POLY		CPB1061W	1
7	nsp	CONTROL, LABEL		CQB1A993Z	1
8	nsp	LABEL , COLOR LABEL(WHITE)	SP	CQB1A676	1

EXPLODED VIEW (PMA-520AE)



WARNING:
Parts marked with this symbol have critical characteristics.
Use ONLY replacement parts recommended by the manufacturer.

PACKING VIEW (PMA-520AE)



PARTS LIST OF PACKING & ACCESSORIES (PMA-520AE)

*Parts indicated by "nsp" on this table cannot be supplied.

*Parts indicated by the "★" mark are not illustrated in the exploded view.

*The parts listed below are only for maintenance. Therefore they might differ from the parts used in the unit in appearances or dimensions.

Note: The symbols in the column "Remarks" indicate the following destinations.
 E2 : Europe model
 E1C : China model
 BK : Black model
 SP : Premium Silver model

Ref. No.	Part No.	Part Name	Remarks	Q'ty	New
1	943531102450D	BOX , OUT CARTON		CPG2A818P	1 *
2	nsp	BAG , POLY		CPB1A013Y	1
3	943533101210D	PAD , SNOW		CPS3A747	2
4	-	INSTRUCTIONMANUAL ASS'Y		-	1
4-1	943307101180D	REMOCON TRANSMITTER ASS'Y (RC-1173)		CARTDCD720A1	1 *
4-2	nsp	BATTERY , AAA 2PCS IN PACK		CABR03PPB	2
4-3	35251013500AD	CD ROM MANUAL ASS'Y (PMA-720/520AE E2)	E2	CFT1A070ZA	1 *
4-4	54111087900AD	GETTING STARTED _IM (E2)	E2	CCX1A1687Z	1 *
4-4	54111086500AD	INST.MANUAL (PMA-720AE E1C)	E1C	CCX1A1691Z	1 *
4-5	nsp	LIST , S.S		CQE1A226P	1
4-6	nsp	WARRANTY CARD, CHINA	E1C	CQE1A473Y	1
4-7	nsp	CARD FOR CHINA IDENTIFICAT	E1C	CQE1A450Z	1
6	nsp	BAG , POLY		CPB1061W	1
7	nsp	CONTROL, LABEL		CQB1A993Z	1
8	nsp	LABEL , COLOR LABEL(WHITE)	SP	CQB1A676	1

Personal notes:


Personal notes:

SEMICONDUCTORS

Only major semiconductors are shown. General semiconductors etc. are omitted from list.
The semiconductors which have a detailed drawing in a schematic diagram are omitted from list.

1. IC's

TMP86FH47BUG (MAIN :IC41)




TMP86FH47BUG Terminal Functions

pin	port	I/O	function	active	normal
1	VSS		to GND		
2	XIN	I	x'tal		
3	XOUT	O	x'tal		
4	TEST		to VSS/VDD		
5	VDD		to 3.3v		
6	P21(XTIN)	O	LED RED	H	L
7	P22(XTOUT)	O	LED GREEN	H	L
8	REST	I	reset		
9	P20(STOP/INT5)	I	Stop mode cancellation	HIGH eddge	L
10	P00(INT0)	I	ASO/DC protector	LOW eddge	H
11	P01(TC4)	O	NC	-	Fixed L
12	P02(RXD)	I	RXD(prom)	L	H
13	P03(TXD)	O	TXD(prom)	L	H
14	P04(SO)	O	analog sw data	H	L
15	P05(SI)	O	analog sw strobe	H	L
16	P06(SCK)	O	analog sw clock	H	L
17	P07(INT4)	O	NC	-	Fixed L
18	P17	I	NC	-	Fixed L
19	P16	I	NC	-	Fixed L
20	P15(INT3)	O	ac power relay	H	L


21	P14(PPG)	O	volume up	H	L
22	P13(DVO)	O	volume down	H	L
23	P12(INT2)	I	remocon input	L	H
24	P11(INT1)	I	Power off (power failure)	H	L
25	P10(TC3)	O	timer reset	L	H
26	P30(AIN0)	I	Model switch	AD	AD
27	P31(AIN1)	I	NC	-	Fixed L
28	P32(AIN2)	I	NC	-	Fixed L
29	P33(AIN3)	I	function selector	edge/AD	
30	P34(AIN4/STOP2)	O	head phone/muting	H	L
31	P35(AIN5/STOP3)	O	NC	-	Fixed L
32	P36(AIN6/STOP4)	O	NC	-	Fixed L
33	P37(AIN7/STOP5)	I	THERMAL protector	LOW edge	H
34	VAREF		to VDD		
35	AVDD		to VDD		
36	AVSS		to VSS		
37	P40	O	PHONO LED/relay drive	H	L
38	P41	O	CD LED/relay drive	H	L
39	P42	O	TUNER LED	H	L
40	P43	O	AUX LED	H	L
41	P44	O	NETWORK LED	H	L
42	P45	O	RECODER LED	H	L
43	P46	I	SIG. Timer	L	H
44	P47	I	NC	-	Fixed H

LC78212 (MAIN : IC21)





Top View

LC78212 Block diagram



ILC7812 Terminal Functions

Pin	I/O	Internal equivalent circuit	Pin function																																											
V_{DD} , V_{SS} , V_{EE}			Power supply																																											
L1 to L8, R1 to R8, LCOM1 to LCOM4, RCOM1 to RCOM4		See the block diagram.	Analog switch input and output																																											
CL, DI, CE	I		Serial data input (Schmitt buffer) CL.....Clock input DI.....Data input CE.....Chip enable																																											
S	I		Selection of one of two chips The address is set to the values shown in the table below according to the level input to the S pin. <table border="1" data-bbox="737 631 1239 848"> <thead> <tr> <th rowspan="2">Product</th> <th rowspan="2">S pin level</th> <th colspan="4">Address</th> </tr> <tr> <th>A₀</th> <th>A₁</th> <th>A₂</th> <th>A₃</th> </tr> </thead> <tbody> <tr> <td rowspan="2">LC78211</td> <td>L</td> <td>0</td> <td>1</td> <td>0</td> <td>1</td> </tr> <tr> <td>H</td> <td>1</td> <td>1</td> <td>0</td> <td>1</td> </tr> <tr> <td rowspan="2">LC78212</td> <td>L</td> <td>0</td> <td>0</td> <td>1</td> <td>1</td> </tr> <tr> <td>H</td> <td>1</td> <td>0</td> <td>1</td> <td>1</td> </tr> <tr> <td rowspan="2">LC78213</td> <td>L</td> <td>0</td> <td>1</td> <td>1</td> <td>1</td> </tr> <tr> <td>H</td> <td>1</td> <td>1</td> <td>1</td> <td>1</td> </tr> </tbody> </table>	Product	S pin level	Address				A ₀	A ₁	A ₂	A ₃	LC78211	L	0	1	0	1	H	1	1	0	1	LC78212	L	0	0	1	1	H	1	0	1	1	LC78213	L	0	1	1	1	H	1	1	1	1
Product	S pin level	Address																																												
		A ₀	A ₁	A ₂	A ₃																																									
LC78211	L	0	1	0	1																																									
	H	1	1	0	1																																									
LC78212	L	0	0	1	1																																									
	H	1	0	1	1																																									
LC78213	L	0	1	1	1																																									
	H	1	1	1	1																																									
RES	I		Reset input The states of the analog switches are undefined when power is first applied. Setting this pin low will force all switches the off state.																																											

Ref. No.	Part No.	Part Name	Remarks	Q'ty	New
OL92	943641005850S	JACK , AC OUTLET (230V , 3P)	CJJ7A031Z		
RC51	943262010290S	SENSOR , REMOTE/U	CRVKS603TH5B		
RY92	00D9430194900	RELAY,G5PA-1,DC6V,1C1P	CSL1E002ZE		
SW51	00D9430194803	SW , PUSH (VERTICAL)	CSH2D013Z		
SW52-54	00D9430199400	SW , PUSH(VERTICAL) CN	KSH2B003Z		
SW91	00D9430140609	EOL item CSH1A010ZV(SDL1P-B)	CSH1A010ZV		
⚠ T901	00D9430193203	TRANSFORMER , SUB	E2	CLT5I008ZE	
⚠ T901	943101005870S	TRANSFORMER , SUB	E1C	CLT5I008ZH	

Ref. No.	Part No.	Part Name	Remarks	Q'ty	New
	00D2631100018	I.C,REGULATOR(+6V,T0220IS)	HVIKIA7806API		
	00D9430194609	POSISTOR	CRTPTFM04BB222Q		

