


# The Harman Kardon Model CD91C

Manual No. 57A

## ULTRAWIDEBAND LINEAR PHASE CASSETTE DECK

# Technical Manual



**harman/kardon**

240 CROSSWAYS PARK WEST, WOODBURY, N.Y. 11797  
1112-H15257A4 P-08833 400 PRINTED IN JAPAN

CD91C

**CONTENTS**

LEAKAGE TEST .....	2	CIRCUIT DESCRIPTION .....	14
COMPONENTS AND THEIR FUNCTIONS .....	2, 3	GENERAL UNIT EXPLODED VIEW .....	15
SPECIFICATIONS .....	4	GENERAL UNIT PARTS LIST .....	16
INTERNAL VIEW .....	4	CASSETTE MECHANISM EXPLODED VIEW .....	17
DISASSEMBLY PROCEDURES .....	5-7	CASSETTE MECHANISM PARTS LIST .....	18
AC LINE CORD REPLACEMENT .....	7	ELECTRICAL PARTS LIST .....	19-21
ALIGNMENT PROCEDURES .....	8-10	PACKAGE .....	22
TIMING CHART .....	11, 12	SCHEMATIC DIAGRAM .....	23
BLOCK DIAGRAM .....	13	WIRING DIAGRAM .....	24



**LEAKAGE TEST (FOR SERVICE ENGINEERS IN THE U.S.A.)**

Before returning the unit to the user, perform the following safety checks:


1. Inspect all lead dress to make certain that leads are not pinched or that hardware is not lodged between the chassis and other metal parts in the unit.
2. Replace all protective devices such as nonmetallic control knobs, insulating fishpapers, cabinet backs, adjustment and compartment covers or shields, isolation resistor-capacity networks, mechanical insulators, etc.
3. Be sure that no shock hazard exists; check for leakage current using Simpson Model 229 Leakage Tester, standard equipment item No. 21641, RCA Model WT540A or use alternate method as follows:

Plug the AC line cord directly into a 120-volt AC receptacle (do not use an Isolation Transformer for this test). Using two clip leads, connect a 1500 ohm, 10-watt resistor paralleled by a 0.15mf capacitor, in series with all exposed metal cabinet parts and a known earth ground, such as a water pipe or conduit. Use a VTVM or VOM with 1000 ohms per volt, or higher, sensitivity to measure the AC voltage drop across the resistor. (See Diagram.) Move the resistor connection to each exposed metal part having a return path to the chassis (antenna, metal, cabinet, screw heads, knobs and control shafts, escutcheon, etc.) and measure the AC voltage drop across the resistor. (This test should be performed with the power switch in both the On and Off positions.) A reading of 0.35 volt RMS or more is excessive and indicates a potential shock hazard which must be corrected before returning the unit to the owner.

SIMPSON MODEL 229 ETC. FOR LEAKAGE TEST



**COMPONENTS AND THEIR FUNCTIONS**



CD91C

**1 EJECT BUTTON (EJECT)**

For opening the cassette compartment door. The soft eject mechanism opens the door slowly when this button is pressed.

**Caution:** Never press this button while the tape is running. Be sure to press the STOP button before pressing the EJECT button.

**2 CASSETTE COMPARTMENT****3 RESET BUTTON (reset)**

For resetting the tape counter to "000". Press this button to reset the TAPE COUNTER to "000" when starting to record.

**4 TAPE COUNTER**

For a digital indication of the position on a cassette tape. The figure changes as the tape runs. Cueing for the start of a melody is facilitated by making a note of the counter reading.

**5 STOP BUTTON ( ■ STOP)**

For stopping each operation.

Pressing this button stops playback, recording, fast forwarding or rewinding of a tape. It also cancels the standby state of the PAUSE button operation.

**6 POWER INDICATOR (POWER)****7 RECORD INDICATOR (REC)**

To indicate that the tape is being recorded.

**8 PAUSE INDICATOR (PAUSE)**

For indication that the "PAUSE" function has been activated.

**9 PLAY BUTTON (PLAY ► )**

For playback of a tape.

Press this button to start playback.

**10 DOLBY\* NR SYSTEM SELECTORS (DOLBY B-C NR)****NR ON/OFF Selector:**

For recording or playback using the Dolby NR (Noise Reduction) system.

Depress this switch to use the Dolby NR system. The green DOLBY NR INDICATOR (for B-type) or the yellow one (for C-type) illuminates according to the NR TYPE selector position. Release this switch to turn off the Dolby NR system.

**NR TYPE Selector:**

For selection of Dolby B- or C-type NR system.

Depress this switch to select the Dolby C-type NR system. Release it and the B-type is selected.

**11 LED LEVEL DISPLAY**

For an accurate indication of the recording or playback level.

**12 MPX FILTER SWITCH (mpx filter)**

The MPX filter is a high frequency filter that has very little effect below 16kHz, but has 30dB attenuation at 19kHz, the frequency of the FM Stereo pilot signal. This filter should be engaged (button out position) when recording from an FM Stereo tuner or receiver. However, to appreciate the ultrawideband frequency response of all Harman Kardon cassette decks, the MPX filter should be disengaged (button in position) when recording all other sources, such as phono, tape, microphone, etc.

**13 DOLBY NR INDICATORS (Dolby NR B, C)**

For indication that the Dolby B or C noise reduction is activated.

**14 POWER SWITCH (POWER)**

For turning power on and off.

When this switch is pressed with the power line cord plugged to an AC outlet, the POWER indicator illuminates.

**15 HEADPHONES JACK (HEADPHONES)**

For connection of stereo headphones.

**16 REWIND BUTTON (◀◀REW)**

For rewinding of a tape at a high speed.

Rewind time is about 90 sec. with C-60 tape.

**17 FAST FORWARD BUTTON (F.FWD▶▶)**

For fast forwarding of a tape.

Fast forward time is about 90 sec. with C-60 tape.

**18 TAPE SELECTORS (BIAS/EQUALIZATION)**

For selection of the record and playback circuitry that provides the lowest distortion and flattest frequency response for METAL, CrO<sub>2</sub> or LN tape.

**19 RECORD BUTTON (REC●)**

To record a tape, press this button and the PLAY button at the same time. The red RECORD INDICATOR illuminates to indicate that a recording is being made.

A RECORD STANDBY mode can be activated by pressing the RECORD button and the PAUSE button at the same time. The red RECORD and yellow PAUSE INDICATORS illuminate. This mode is useful for making input level adjustments prior to recording. To change from the RECORD STANDBY mode to the RECORD mode, press the PLAY button. To cancel the RECORD STANDBY mode, press the STOP button.

**20 PAUSE BUTTON (PAUSE■)**

For temporarily stopping playback or recording. Also, press this button with the RECORD button to activate the RECORD STANDBY mode.

**21 BIAS FINE TRIM KNOB (bias fine trim)**

For precise adjustment of the bias used during recording.

**22 BALANCE CONTROL (input balance)**

For control of input level balance between the right and left channels.

Set the knob at the 12 o'clock position for normal operation. Use this feature to restore the input level balance when the levels of the right and left channels are extremely different or to deliberately upset the input level balance as you like. Turn this knob clockwise, and the recording level of left channel is decreased.

Turn counterclockwise, and the recording level of right channel is decreased.

**23 INPUT LEVEL CONTROL (INPUT LEVEL)**

For input level control during recording. The LED LEVEL DISPLAY shows the input level.

\* Noise reduction manufactured under license from Dolby Laboratories Licensing Corporation. "Dolby" and the double-D symbol are trademarks of Dolby Laboratories Licensing Corporation.

## SPECIFICATIONS

Track Configuration 4-track 2 channel Stereo  
Cassette Deck

### ● MECHANICAL SECTION

	Nominal	Limit
Tape Speed	4.75cm/sec.	± 1.5%
Wow and Flutter	0.05%	≤ 0.08%
F.F./REW Time for C-60 Cassette	90 sec.	≤ 100 sec.
Motor	DC Servomotor	
Take Up Torque	50 gr. cm	35 ~ 70 gr. cm
F.F Torque	100 gr. cm	70 ~ 150 gr. cm
REW Torque	100 gr. cm	70 ~ 150 gr. cm

### ● HEAD SECTION

Recording/Playback Fe-Al-Si Alloy Core  
Erase Ferrite Core

### ● AMPLIFIRE SECTION

Input Sensitivity 55mV 40 (min) ~ 100 (max) mV  
Input Impedance 22k $\Omega$  15 (min) ~ 30 (max) k $\Omega$

	Nominal	Limit
Signal-to-Noise Ratio (DOLBY B to ON)		
at MIC input	52dB	≥ 48dB
	(Input 1kHz, 1.5mV for normal tape)	
at LINE input	61dB	≥ 56dB
	(Input 1kHz, 100mV for normal tape)	
Erase Ratio	65dB	≥ 60dB
	(Input 80Hz for metal tape)	
Channel Separation	45dB	≥ 35dB
	(Input 1kHz)	
Crosstalk	72dB	≥ 60dB
	(Input 1kHz)	

● DIMENSIONS (W x H x D) 17-7/16" x 4-13/16" x 13-9/16"  
(443 x 123 x 345 mm)

● WEIGHT 13 lbs. 4 oz. (6 kg)


### ● POWER SUPPLIES

U.S. & Canadian models AC 120V, 60Hz  
General model AC 100/120/220/240V, 50/60Hz

● POWER CONSUMPTION 27W

Specifications and components subject to change without notice.  
Overall performance will be maintained or improved.

## INTERNAL VIEW



- ① VOLTAGE SELECTOR  
(General model only)
- ② POWER TRANSFORMER
- ③ MAIN P.C. BOARD (PCB-1)
- ④ JACK P.C. BOARD (PCB-7)
- ⑤ POWER SWITCH
- ⑥ CASSETTE TAPE RECORDER  
MECHANICAL ASSEMBLY
- ⑦ CONTROL SWITCHES P.C.  
BOARD (PCB-2)

## DISASSEMBLY PROCEDURES

### 1 CABINET TOP REMOVAL

Remove the screws ① to ⑥ in Fig. 1 and then remove the cabinet top.




Fig. 1

### 2 CABINET BOTTOM REMOVAL

Remove the screws ① to ⑩ in Fig. 2 and then remove the cabinet bottom.





Fig. 2

### 3 FRONT PANEL ASSEMBLY REMOVAL

1. Remove the cabinet top (Refer to step 1).
2. Pull out the input level knob.
3. Remove the cassette door assembly.
4. Remove the screws ① to ⑬ in Fig. 2 and ① to ③ in Fig. 3 and then remove the front panel assembly.



CASSETTE DOOR ASSEMBLY

Fig. 3

### 4 CONTROL SWITCHES P.C. BOARD REMOVAL

1. Remove the screw ① in Fig. 4 and then remove the dolby NR indicators P.C. board.
2. Disconnect connector with lead and jumper leads from connectors on the main P.C. board.
3. Remove screws ② and ③ in Fig. 4 and then remove the control switches P.C. board.




Fig. 4

### 5 MAIN P.C. BOARD REMOVAL

1. Remove the front panel assembly (Refer to step 3).
2. Pull out the bias fine trim and input balance knobs.
3. Unsolder the lead wires and disconnect the connectors which are connected to main P.C. board.
4. Remove screws ① and ②, and hexagonal nut ④ to ⑥ in Fig. 5.
5. Remove screws ① to ④ in Fig. 6 and then pull out main P.C. board backward.




Fig. 5




Fig. 6

### 6 PLATE ASSEMBLY REMOVAL

1. Remove the front panel assembly and control switches P.C. board (Refer to steps 3 and 4).
2. Remove screw ④ in Fig. 4 and then remove the power, rec. and pause indicators P.C. board.
3. Disconnect connector with lead from connector on the LED level display assembly.
4. Unsolder the lead wires which are connected to reed switch P.C. board.
5. Remove the belt of the counter.
6. Remove the screws ⑦ to ⑨ in Fig. 5 and then remove the plate assembly.

### 7 CASSETTE TAPE RECORDER MECHANICAL ASSEMBLY REMOVAL

1. Remove the cabinet bottom and front panel assembly (Refer to step 2 and 3).
2. Unsolder the lead wires and disconnect the connector which are connected to the cassette tape recorder mechanical assembly.
3. Remove the belt of the counter.
4. Remove the screws 5 and 6 in Fig. 6 and the screws 1 and 2 in Fig. 7 and then remove the cassette tape recorder mechanical assembly backward.




Fig. 7

### 8 PLATE REMOVAL

1. Remove the cassette tape mechanical assembly (Refer to step 7).
2. Remove the screws 1 and 2 in Fig. 8 and then remove the plate.




Fig. 8

### 9 EJECT LOCK ARM REMOVAL

1. Remove the plate (Refer to step 8).
2. Remove the springs 1 and 2 in Fig. 9 and remove the screw 3 in Fig. 9 and then remove the eject lock arm.




Fig. 9

### 10 MICRO SWITCH REMOVAL

1. Remove the eject lock arm (Refer to step 9).
2. Unsolder the lead wires which are connected to the micro switch.
3. Remove the screws 2 and 3 in Fig. 10 and then remove the micro switch.




Fig. 10

### 11 CASSETTE SUPPORT REMOVAL

1. Remove the eject lock arm (Refer to step 9).
2. Remove the spring 4 in Fig. 9 and remove the joint of damper 1 in Fig. 10 from cassette support.
3. Remove the screws 1 to 3 in Fig. 11 and remove the bracket and then remove the cassette support.




Fig. 11

**12 PINCH ROLLER AND HEADS REMOVAL**

1. Remove the cassette support (Refer to step 11 ).
2. Remove the lock washer ① in Fig. 12 and pull out the pinch roller by pushing the pinch roller spring ⑥ in Fig. 12 with tweezers.
3. Remove the screws ② and ③ in Fig. 12 and then remove the erase head.
4. Remove the screws ④ and ⑤ in Fig. 12 and then remove the record/playback head.

\* Be careful not to lose the spring which are attached to the screws ② and ④ in Fig. 12.

Always adjust the azimuth after replacing the record/playback head (Refer to alignment procedures).




Fig. 12

**13 MOTOR AND BELT REMOVAL**

1. Remove the cassette tape recorder mechanical assembly (Refer to step 7 ).
2. Unsolder the lead wires which are connected to the motor.
3. Remove the screw ① in Fig. 13 and remove actuators ② and ③ when pulling down the motor bracket and then remove the motor bracket and remove main and sub belts.
4. Remove the screws ① and ② in Fig. 14 and then remove the motor.




Fig. 13





Fig. 14

**AC LINE CORD REPLACEMENT (FOR SERVICE ENGINEERS IN OTHER THAN NORTH AMERICA)**

In order to prevent fire or shock hazard when replacing the AC line cord, follow the steps below to replace the parts with the standard supply parts.



# ALIGNMENT PROCEDURES

## ELECTRICAL ADJUSTMENT AND CONFIRMATION

General conditions (unless otherwise noted)

CONTROLS AND SWITCHES	SETTINGS
Dolby NR	off
MPX Filter	off
Bias Fine Trim	center
Input Balance	center
Input Level	max




Fig. 1




Fig. 3




Fig. 5




Fig. 4




Fig. 6




**\*Azimuth adjustment**

When the maximum level point of R channel does not equal that of L channel, connect the oscilloscope as shown in Fig. 2 and proceed with azimuth adjustment so that L and R channels are in phase.

a) Connect L channel tape out to "X(or V)" and R channel to "Y(or H)". Observe the lissajous waveform.

b) Set L and R channels to monaural. Adjust vertical and horizontal gain so that the waveform becomes 45 degree.

c) Adjust azimuth so that the measurement of "a" becomes maximum and the measurement of "b" becomes minimum against 45 degree line.



STEP	ADJUSTMENT ITEM	INSTRUMENT REQUIRED	MODE	INPUT SIGNAL	POINTS TO BE CONNECTED	ADJUSTMENT PART	RATING	REMARKS
1	Tape speed	Frequency counter Test tape (MTT-111D)	PB		TP501 or TP502	VR built in motor	3kHz ±10Hz	
2	Wow flutter confirmation	Wow flutter meter Test tape (MTT-111D)	PB				Confirm that wow flutter is within the specification.	
3	Azimuth	VTVM Test tape (MTT-114)	PB		TP501 or TP502	Azimuth screw	Maximum output	Refer to *Azimuth adjustment.
4	Playback amp. level	VTVM Test tape (MTT-150)	PB		TP501 TP502	VR101 VR102	580 mV	
5	Playback frequency characteristic confirmation	VTVM Test tape (TCC-162 or MTT-256μ and TCC-262 or MTT-356μ)	PB		TAPE OUT		Confirm that frequency response is within the range as shown in Fig. 5.	
6	Bias trap	VTVM	REC-PAUSE		TP253 TP254	L203 L204	Minimum output	Tape selector is metal position.
7	Bias level (Pre-adjustment)	VTVM	REC-PAUSE		TP101, 103 TP102, 104	VR251 VR252	100 mV	Tape selector is metal position.
					TP102, TP104	VR254	52 mV	Tape selector is CrO <sub>2</sub> position.
					TP102, TP104	VR253	32 mV	Tape selector is LN position.
8	Bias frequency confirmation	Frequency counter	REC-PAUSE		R251 and TP251		105kHz ± 5kHz	Tape selector is metal position.
9	Record level (Pre-adjustment)	VTVM Blank tape (AC-512)	REC/PB	Apply 400Hz signal to LINE INPUT. Set INPUT LEVEL knob so that TP501 and TP502 voltage is 580 mV when REC-PAUSE mode.	TP501 TP502	VR201 VR202	580 mV	Tape selector is CrO <sub>2</sub> position.
10	Peaking coil (Pre-adjustment)	VTVM	REC	Apply 20kHz signal to LINE INPUT. Set INPUT LEVEL knob so that TP101 and TP102 voltage is 580mV -25dB when REC-PAUSE mode.	TP101 TP102	L201 L202	Maximum output.	Short the TP251 and TP252. Tape selector is metal position.
11	Record/playback equalizer frequency characteristic (Pre-adjustment)	VTVM Blank tape (AC-711)	REC/PB	Apply 400Hz signal to LINE INPUT. Set INPUT LEVEL knob so that TP501 and TP502 voltage is 580 mV -25dB when REC-PAUSE mode. Then, adjust with a 20Hz to 30kHz sweep signal.	TAPE OUT	VR251 VR252	So that the record/playback frequency response is flat.	Tape selector is metal position.
12	Record/playback equalizer frequency characteristic	VTVM Blank tapes (LN XL-1) (CrO <sub>2</sub> AC-512) (metal AC-711)	REC/PB	Apply 400Hz signal to LINE INPUT. Set INPUT LEVEL knob so that TP501 and TP502 voltage is 580 mV -25dB when REC-PAUSE mode. Then, adjust with a 20Hz to 30kHz sweep signal.	TAPE OUT	VR254 L202	So that the record/playback frequency response is flat (at least within the range in Fig. 4).	Tape selector is CrO <sub>2</sub> position.
					TAPE OUT	VR251 L201		Tape selector is LN position.
					TAPE OUT	VR253	Confirm record/playback frequency response. If the frequency response is not within the range in Fig. 4, do the adjustment, over starting with step 11.	Tape selector is metal position.
					TAPE OUT	VR251	Confirm record/playback frequency response. If frequency response is not the same as for step 12-4, adjust while watching the balance of the two.	Tape selector is LN position.
					TAPE OUT			
13	Record level	VTVM Blank tape (AC-512)	REC/PB	Apply 400Hz signal to LINE INPUT. Set INPUT LEVEL knob so that TP501 and TP502 voltage is 580 mV when REC-PAUSE mode.	TP501 TP502	VR201 VR202	580 mV	Tape selector is CrO <sub>2</sub> position.
14	Record level confirmation	VTVM Blank tapes (metal AC-711) (LN XL-1)	REC/PB	Apply 400Hz signal to LINE INPUT. Set INPUT LEVEL knob so that TP501 and TP502 voltage is 580 mV when REC-PAUSE mode.	TP501 TP502		580 mV ± 1dB	This confirmation should be done at each tape selector position.
15	Record/playback equalizer frequency characteristic confirmation	VTVM Blank tapes (LN XL-1) (CrO <sub>2</sub> AC-512) (metal AC-711)	REC/PB	Apply 400Hz signal to LINE INPUT. Set INPUT LEVEL knob so that TP501 and TP502 voltage is 580 mV -25dB when REC-PAUSE mode. Then, adjust with a 20Hz to 30kHz sweep signal.	TAPE OUT		Confirm that record/playback frequency response is within the range in Fig. 5 and 6. If it is not within the range in Fig. 5 and 6, redo the adjustments on steps 11 and 12.	This confirmation should be done at each tape selector position under each of the following conditions, Dolby B and Dolby C on.
16	Meter level	VTVM	REC-PAUSE	Apply 400Hz signal to LINE INPUT. Set INPUT LEVEL knob so that TP501 and TP502 voltage is 580 mV -0.5dB when REC-PAUSE mode.		VR401 VR402	0 VU LED lights up.	

**\*Azimuth adjustment**

When the maximum level point of R channel does not equal that of L channel, connect the oscilloscope as shown in Fig. 2 and proceed with azimuth adjustment so that L and R channels are in phase.

a) Connect L channel tape out to "X(or V)" and R channel to "Y(or H)". Observe the lissajous waveform.

b) Set L and R channels to monaural. Adjust vertical and horizontal gain so that the waveform becomes 45 degree.

c) Adjust azimuth so that the measurement of "a" becomes maximum and the measurement of "b" becomes minimum against 45 degree line.

STEP	ADJUSTMENT ITEM	INSTRUMENT REQUIRED	MODE	INPUT SIGNAL	POINT CONF.
1	Tape speed	Frequency counter Test tape (MTT-111D)	PB		TP1 TP2
2	Wow flutter confirmation	Wow flutter meter Test tape (MTT-111D)	PB		
3	Azimuth	VTVM Test tape (MTT-114)	PB		TP1 TP2
4	Playback amp. level	VTVM Test tape (MTT-150)	PB		TP1 TP2
5	Playback frequency characteristic confirmation	VTVM Test tape (TCC-162 or MTT-256 $\mu$ and TCC-262 or MTT-356 $\mu$ )	PB		TA
6	Bias trap	VTVM	REC-PAUSE		TP1 TP2
7	Bias level (Pre-adjustment)	VTVM	REC-PAUSE		TP1
					TP2
					TP3
8	Bias frequency confirmation	Frequency counter	REC-PAUSE		R2 TP
9	Record level (Pre-adjustment)	VTVM Blank tape (AC-512)	REC/PB	Apply 400Hz signal to LINE INPUT. Set INPUT LEVEL knob so that TP501 and TP502 voltage is 580 mV when REC-PAUSE mode.	TP1 TP2
10	Peaking coil (Pre-adjustment)	VTVM	REC	Apply 20kHz signal to LINE INPUT. Set INPUT LEVEL knob so that TP101 and TP102 voltage is 580mV -25dB when REC-PAUSE mode.	TP1 TP2
11	Record/playback equalizer frequency characteristic (Pre-adjustment)	VTVM Blank tape (AC-711)	REC/PB	Apply 400Hz signal to LINE INPUT. Set INPUT LEVEL knob so that TP501 and TP502 voltage is 580 mV -25dB when REC-PAUSE mode. Then, adjust with a 20Hz to 30kHz sweep signal.	TA
12	Record/playback equalizer frequency characteristic	VTVM Blank tapes (LN XL-1) (CrO <sub>2</sub> AC-512) (metal AC-711)	REC/PB	Apply 400Hz signal to LINE INPUT. Set INPUT LEVEL knob so that TP501 and TP502 voltage is 580 mV -25dB when REC-PAUSE mode. Then, adjust with a 20Hz to 30kHz sweep signal.	TA
					TA
					TA
					TA
					TA
13	Record level	VTVM Blank tape (AC-512)	REC/PB	Apply 400Hz signal to LINE INPUT. Set INPUT LEVEL knob so that TP501 and TP502 voltage is 580 mV when REC-PAUSE mode.	TP1 TP2
14	Record level confirmation	VTVM Blank tapes (metal AC-711) (LN XL-1)	REC/PB	Apply 400Hz signal to LINE INPUT. Set INPUT LEVEL knob so that TP501 and TP502 voltage is 580 mV when REC-PAUSE mode.	TP1 TP2
15	Record/playback equalizer frequency characteristic confirmation	VTVM Blank tapes (LN XL-1) (CrO <sub>2</sub> AC-512) (metal AC-711)	REC/PB	Apply 400Hz signal to LINE INPUT. Set INPUT LEVEL knob so that TP501 and TP502 voltage is 580 mV -25dB when REC-PAUSE mode. Then, adjust with a 20Hz to 30kHz sweep signal.	TA
16	Meter level	VTVM	REC-PAUSE	Apply 400Hz signal to LINE INPUT. Set INPUT LEVEL knob so that TP501 and TP502 voltage is 580 mV -0.5dB when REC-PAUSE mode.	

Lch  
output

Vertical  
comes  
f "a"  
f "b"





Fig. 2

	POINTS TO BE CONNECTED	ADJUSTMENT PART	RATING	REMARKS
	TP501 or TP502	VR built in motor	3kHz $\pm$ 10Hz	
			Confirm that wow flutter is within the specification.	
	TP501 or TP502	Azimuth screw	Maximum output	Refer to *Azimuth adjustment.
	TP501 TP502	VR101 VR102	580 mV	
	TAPE OUT		Confirm that frequency response is within the range as shown in Fig. 5.	
	TP253 TP254	L203 L204	Minimum output	Tape selector is metal position.
	TP101, 103 TP102, 104	VR251 VR252	100 mV	Tape selector is metal position.
	TP102, TP104	VR254	52 mV	Tape selector is CrO <sub>2</sub> position.
	TP102, TP104	VR253	32 mV	Tape selector is LN position.
	R251 and TP251		105kHz $\pm$ 5kHz	Tape selector is metal position.
INPUT. at TP501 when	TP501 TP502	VR201 VR202	580 mV	Tape selector is CrO <sub>2</sub> position.
INPUT. at TP101 25dB when	TP101 TP102	L201 L202	Maximum output.	Short the TP251 and TP252. Tape selector is metal position.
INPUT. at TP501 25dB when st with a	TAPE OUT	VR251 VR252	So that the record/playback frequency response is flat.	Tape selector is metal position.
INPUT. at TP501 25dB when st with a	TAPE OUT	VR254 L202	So that the record/playback frequency response is flat (at least within the range in Fig. 4).	Tape selector is CrO <sub>2</sub> position.
		VR251 L201		Tape selector is LN position.
	TAPE OUT	VR253	Confirm record/playback frequency response. If the frequency response is not within the range in Fig. 4, do the adjustment, over starting with step 11.	Tape selector is metal position.
	TAPE OUT	VR251	Confirm record/playback frequency response. If frequency response is not the same as for step 12.4, adjust while watching the balance of the two.	Tape selector is LN position.
INPUT. at TP501 and REC-PAUSE	TP501 TP502	VR201 VR202	580 mV	Tape selector is CrO <sub>2</sub> position.
INPUT. at TP501 and REC-PAUSE	TP501 TP502		580 mV $\pm$ 1dB	This confirmation should be done at each tape selector position.
INPUT. at TP501 and B when REC- h a 20Hz to	TAPE OUT		Confirm that record/playback frequency response is within the range in Fig. 5 and 6. If it is not within the range in Fig. 5 and 6, redo the adjustments on steps 11 and 12.	This confirmation should be done at each tape selector position under each of the following conditions, Dolby B and Dolby C on.
INPUT. at TP501 and B when REC-		VR401 VR402	0 VU LED lights up.	

**MECHANISM ADJUSTMENT AND CONFIRMATION**


**HEAD HEIGHT**

- a) Attach the M-300 head gauge plate.
- b) Inspect the height of the head with a adjustment chip attached to the gauge plate at playback mode.
- c) The adjustment chip attached to the gauge plate should not hit the tape guide of record/playback and erase heads.



**FRONT AND REAR POSITION**

- a) Attach the M-300 head gauge plate.
- b) Attach the adjustment chip attached to the gauge plate to the center of the head and read the scale on the plate.
- c) The scale should be within MIN and MAX of the M-300 head gauge at both record/playback and erase heads.
- d) If the scale is not within the specified range, adjust it by loosening the screw fixing each head.
- e) After adjustment, apply screw lock paint.




**PINCH ROLLER TAPE RUNNING**

- a) Insert a mirror cassette tape and set to the playback mode.
- b) The tape should not be curled at the tape guide of the record/playback and erase heads.

NOTES: Confirm that grease or foreign substance adhere to the rubber of the pinch roller, and that no flaw is on the pinch roller.


**PINCH ROLLER PRESSURE**

- a) With unit in playback mode, put a tension gauge as shown in the illustration and add the load to arrow direction and measure the value at which the rotation of the pinch roller stops.
- b) Confirm that the load is between 250g and 350g when the pinch roller leaves the capstan.



**CLUTCH ASSEMBLY**

- a) Confirm that clutch assembly operates smoothly after replacing.
- b) Insert the C-60 tape and when stop button is depressed at fast forward/rewind, clutch assembly return to the neutral position.




**MICRO SWITCH CASSETTE PACK DETECT SWITCH**

- a) Confirm that the switch operates when the cassette pack (the cassette pack is measurement 63.5 mm or a MAZ-0184-C gauge) is set to the right position.
- b) Confirm that the switch changes to off when you return the switch (SW. ARM) at on position slowly.


**MIS-ERASE PROTECT SWITCH**

- a) Confirm that the switch operates with a cassette tape which has an actuator for mis-erase protect (a tape which is measurement 62.9 mm or MAZ-0184-C gauge.)
- b) Confirm that the switch changes to off when you return the switch (REC. ARM) at on position.



**AIR DAMPER**

- a) Confirm that cassette lid opens smoothly and that no unusual sound is heard while opening or closing the cassette lid when the eject button is depressed.
- b) Confirm that the eject lever does not touch the chassis or the damper, etc. and it operates smoothly.
- c) Confirm that the eject button can't be depressed during playback.
- d) Adjust the screw of the damper with a screw driver so that the speed which is necessary for the cassette support to fully open with the eject lock arm becomes more than one second.



**BELT**

- Confirm that the belt does not fall off when you force the fly wheel to stop with your hand while it is rotating.

**TIMING CHART**




Fig. 1




Fig. 2





Fig. 3

## MECHANISM ADJUSTMENT AND CONFIRMATION


### ■ HEAD ● HEIGHT

- Attach the M-300 head gauge plate.
- Inspect the height of the head with an adjustment chip attached to the gauge plate at playback mode.
- The adjustment chip attached to the gauge plate should not hit the tape guide of record/playback and erase heads.



### ● FRONT AND REAR POSITION

- Attach the M-300 head gauge plate.
- Attach the adjustment chip attached to the gauge plate to the center of the head and read the scale on the plate.
- The scale should be within MIN and MAX of the M-300 head gauge at both record/playback and erase heads.
- If the scale is not within the specified range, adjust it by loosening the screw fixing each head.
- After adjustment, apply screw lock paint.




### ■ PINCH ROLLER ● TAPE RUNNING

- Insert a mirror cassette tape and set to the playback mode.
- The tape should not be curled at the tape guide of the record/playback and erase heads.

NOTES: Confirm that grease or foreign substance adhere to the rubber of the pinch roller, and that no flaw is on the pinch roller.


### ● PINCH ROLLER PRESSURE

- With unit in playback mode, put a tension gauge as shown in the illustration and add the load to arrow direction and measure the value at which the rotation of the pinch roller stops.
- Confirm that the load is between 250g and 350g when the pinch roller leaves the capstan.



### ■ CLUTCH ASSEMBLY

- Confirm that clutch assembly operates smoothly after replacing.
- Insert the C-60 tape and when stop button is depressed at fast forward/rewind, clutch assembly return to the neutral position.




### ■ MICRO SWITCH

#### ● CASSETTE PACK DETECT SWITCH

- Confirm that the switch operates when the cassette pack (the cassette pack is measurement 63.5 mm or a MAZ-0184-C gauge) is set to the right position.
- Confirm that the switch changes to off when you return the switch (SW. ARM) at on position slowly.


#### ● MIS-ERASE PROTECT SWITCH

- Confirm that the switch operates with a cassette tape which has an actuator for mis-erase protect (a tape which is measurement 62.9 mm or MAZ-0184-C gauge.)
- Confirm that the switch changes to off when you return the switch (REC. ARM) at on position.



### ■ AIR DAMPER

- Confirm that cassette lid opens smoothly and that no unusual sound is heard while opening or closing the cassette lid when the eject button is depressed.
- Confirm that the eject lever does not touch the chassis or the damper, etc. and it operates smoothly.
- Confirm that the eject button can't be depressed during playback.
- Adjust the screw of the damper with a ⊕ screw driver so that the speed which is necessary for the cassette support to fully open with the eject lock arm becomes more than one second.



### ■ BELT

- Confirm that the belt does not fall off when you force the fly wheel to stop with your hand while it is rotating.

# TIMING CHART




Fig. 1




Fig. 2




Fig. 3




Fig. 4





Fig. 5

**NOTE**  
 After the power switch is pushed on, the unit remains in stop mode for about 1.6 second. After that, it operates according to each input key as shown figure. During this 1.6 second all input keys are ineffective.

$T_1 = 61$  (msec)  
 $T_2 = 400$  (msec)

BLOCK DIAGRAM





## CIRCUIT DESCRIPTION

### ● PLAYBACK MODE (Rch)

The signal from the playback head is amplified by the playback amplifier (Q102, Q104, Q106, Q108 and Q110), input to pin 4 of the MPX/dolby NR IC (IC502), then split into two parts after passing through the MPX/dolby NR circuit and being output from pin 24. One part is output from the output terminal, while the other is amplified by the headphones amplifier and output to the headphone jack. During playback, the bias/equalization selector is switched to equalization for the playback amplifier.

### ● RECORDING MODE (Lch)

The line input signal is adjusted by the input level and input balance controls, then input to pin 1 of the MPX/dolby NR IC (IC501). The signals are output from pin 14 after passing through the MPX/dolby NR circuit, then passed through the equalizer and the record amplifier (IC201). Finally, the signals modulate the bias current which is applied to the record head by the bias oscillator.

### ● MPX/DOLBY NR CIRCUIT

The MPX filter circuit is turned on and off by the MPX filter switch. When it is off, the signals bypass the circuit. The dolby circuit is turned on and off by the dolby NR switch, and selected B and C types by the dolby NR type selector. When the circuit is on and type selector is B position, B-type dolby equalization is applied so that the signal is compressed during recording and expanded during playback.

### ● MUTING

In the playback and record modes, the muting control signals are output from pins 9 (MUT) and 15 (REC) of the deck control IC (IC801) and applied to Q55 and Q713, which produce the muting signals for the playback and recording modes.

The line muting signal for the stop mode and for cutting out shock noise when the power is turned on or off is output by Q51.

#### 1. RECORDING MUTE (PLAYBACK MODE)

When the play button is pressed, the muting signal for the playback mode (which cuts the recording signal) is output. This turns on Q714, which turns on Q711 (for the left channel) and Q712 (for the right channel) to mute the recording signal.

#### 2. PLAYBACK MUTE (RECORDING MODE)


When the rec. button is pressed, the muting signal for the record mode (which cuts the playback signal) is output. This turns on Q715, causing Q701, Q703, Q705 and Q707 to go on to mute the playback signal on the left channel; and causing Q702, Q704, Q706, and Q708 to go on to mute the playback signal on the right channel.

At the same time, Q716 goes on to cut the bias current.

#### 3. LINE MUTE (STOP MODE)

The line muting signal is output when the stop button is pressed or the power turned on or off. This signal causes Q53 (left channel) and Q54 (right channel) to go on, muting the line signal.


# GENERAL UNIT EXPLODED VIEW



## GENERAL UNIT PARTS LIST

Ref. No.	Part No.	Description
101	A423-CD91CA	Cabinet Bottom Assembly
102	A443-CD91CA	Front Panel Assembly (Includes: Cassette Control Buttons)
103	A452-CD91CA	Cassette Door Assembly
104	A514-CD91CA	Plate Assembly, LED Level Display
105	A630-CD91CA	Knob Assembly, Input Level
106	A662-CD91CB	Push Button Assembly, Power
107	A662-CD91CC	Push Button Assembly, Tape Selectors, Dolby NR System Selectors, MPX Filter
108	B211-CD91CA	Chassis Assembly, Front
109	3112-10802	Cassette Tape Recorder Mechanical Assembly
119	1319-0139	Foot
121	1414-01202	Cabinet Top
124	1424-07011	Cabinet Back (U.S. & Canadian models)
124	1424-07008	Cabinet Back (General model)
134	1514-08802	Dressing Plate
145	1634-02701	Knob, Bias Fine Trim, Input Balance
147	1662-05501VN	Push Button, Eject
151	1662-05401VN	Push Button, Reset
157	2111-1356	Felt, Headphones
161	2114-415027	Bushing, AC Line Cord
162	2114-72167	Bushing, Headphones
166	2218-7001	Holding Bracket, Lead Wires
168	2219-7091	Bracket, Power Transformer
169	2219-7655	Bracket, Left
170	2219-7813	Bracket, Right
171	2219-7809	Bracket, Headphones
172	2219-7810	Bracket, Eject
173	2219-7811	Bracket, Power Switch
174	2219-7812	Bracket, Power Transformer
177	2219-7821	Bracket, PCB-1 Mounting
178	2219-7899	Bracket, PCB-1 Mounting
181	2222-7146	Heat Sink, PCB-1
182	2222-7067	Heat Sink, PCB-1
184	2240-7120	Holder, Lead Wires
195	2601-7113	Shaft, Rew., F.FWD, Rec., Pause
196	2601-7112	Shaft, Stop, Play
198	2651-2101705	Spring, Tape Selectors, Dolby NR System Selectors, MPX Filter
203	2642-01444	Belt, Counter
209	2440-61	Special Nut, Headphones
212	3131-445001	Tape Counter
213	2459-3003511	Rivet, Holding Bracket
214	2320-7004	Special Screw, Transistors

CASSETTE MECHANISM EXPLODED VIEW



## CASSETTE MECHANISM PARTS LIST

Ref. No.	Part No.	Description
1	FP467-12	Flywheel Assembly
2	FP469-12	Idler Assembly
3	FP470-11	Clutch Assembly
4	FR12N-11	Take-up Reel Assembly
5	FP472-11	Damper Assembly
6	FR12P-11	Supply Reel Assembly
7	F011-132	Chassis
8	F014-053	Pinch Roller
9	PKA16108	Solenoid
10	F064-093	Motor
11	F029-137	Head, Record/Playback
12	F030-059	Head, Erase
13	F214-015	Bracket, Solenoid
14	FP11N-11	Connector Panel
15	FR345-14	Head Base
16	FR346-11	Assist Base
17	FR347-13	Bracket, Motor
18	FR349-17	Bracket, Damper
19	FR350-15	Bracket, Door
20	FR352-11	Safety Lever
21	FC11H-14	Eject Lock Arm
22	FR355-14	FF Solenoid Arm
23	FR356-14	Switch Arm
24	FD17T-13	Record Arm
25	FR358-13	Reference Guide
26	FR359-12	Play Solenoid Arm
27	FR360-12	Cassette Guide
28	FK572-12	Spring, Azimuth
29	FK551-13	Spring, Cassette
30	FK568-11	Spring, Door
31	FK569-13	Spring, Pinch Roller
32	FK570-12	Spring, Solenoid Bracket
33	FK572-11	Spring, Azimuth
34	FK573-11	Spring, Eject Lock Arm
35	FK574-12	Spring, Assist Base
36	FK575-11	Spring, Play Idler
37	FK576-12	Spring, Play Solenoid Arm
38	FK577-12	Spring, Assist Base
39	FK578-13	Spring, Head Base Hold
40	FK579-14	Spring, Back Tension
41	FM281-12	Spacer, Flywheel
42	FM283-14	Spacer, Head
43	FM296-11	Spacer
44	FN153-11	Play Gear
45	FN154-14	Idler Gear
46	FP462-11	Main Belt
47	FP463-11	Sub Belt
48	FP464-11	Cushion
49	FE173-11	Micro Switch
50	PKA16106	Solenoid
51	FK11C-19	Spring, Eject Lock Arm
52	F027-054	Cassette Support
53	F028-025	Brake
54	FD12W-12	Brake Arm
55	FK11Y-13	Rod, Brake Arm
56	FK12A-12	Spring, Brake
57	FC25D-11	Belt Guide
58	FH126-11	Holder
59	KY130-11	Connector

## ELECTRICAL PARTS LIST


Ref. No.	Part No.	Description
<b>CHASSIS MISCELLANEOUS</b>		
P1	4161-0487	AC Line Cord (U.S. & Canadian models)
P1	4161-7256	AC Line Cord (General model)
T1	5584-701376	Power Transformer (U.S. & Canadian models)
T1	5584-702392	Power Transformer (General model)
SW2	4411-104736	Rotary Switch, Voltage Selector (General model only)
F1, 2	5732-10202	Fuse, T1A, 250V (General model only)
D401	5623-LT1087	LED Display Assembly, Level Meter
D403	5637-SLF301C	L.E.D., SLF301C, Yellow, Cassette Illuminator
J401	4163-71065	Connector with Lead Wire, 8-Pin
J801	4163-103502	Connector with Lead Wire, 10-Pin
J802	4163-082002	Connector with Lead Wire, 8-Pin
JM151	4242-034602	Jumper Lead, 3-Wire
JM152, 501	4242-031307	Jumper Lead, 3-Wire
JM301	4242-035502	Jumper Lead, 3-Wire
JM502	4242-033007	Jumper Lead, 3-Wire
JM503	4242-031802	Jumper Lead, 3-Wire
JM803	4242-053507	Jumper Lead, 5-Wire
LUG1	4211-4	Lug Terminal
<b>PCB-1 MAIN P.C. BOARD</b>		
<b>RESISTORS</b>		
R13, 14, 16, 264	5102-4R74715	4.7 $\Omega$ , $\pm$ 2%, 1/4W, Fuse
R17	5102-2205114	22 $\Omega$ , $\pm$ 5%, 1/2W, Fuse
R117, 118, 119, 120	5174-822381	8.2k $\Omega$ , $\pm$ 1%, 1/4W, Metal
R121, 122	5174-133381	13k $\Omega$ , $\pm$ 1%, 1/4W, Metal
R317, 318, 319, 320, 839	5102-1004715	10 $\Omega$ , $\pm$ 2%, 1/4W, Fuse
R523, 524	5174-512381	5.1k $\Omega$ , $\pm$ 1%, 1/4W, Metal
R525, 526	5174-153381	15k $\Omega$ , $\pm$ 1%, 1/4W, Metal
R555, 556	5174-563381	56k $\Omega$ , $\pm$ 1%, 1/4W, Metal
R733	5102-2204715	22 $\Omega$ , $\pm$ 2%, 1/4W, Fuse
<b>CONTROLS</b>		
VR101, 102	5101-20371920	20k $\Omega$ B
VR151, 152	5113-50380122	50k $\Omega$ A, Input Level
VR153, 154	5113-10489122	100k $\Omega$ MN, Input Balance
VR201, 202	5101-20271920	2k $\Omega$ B
VR251, 252	5101-6838474	68k $\Omega$ B
VR253, 254	5101-10371920	10k $\Omega$ B
VR255	5113-1027921	1k $\Omega$ B, Bias Fine Trim
VR401, 402	5101-30371920	30k $\Omega$ B
<b>CAPACITORS</b>		
C2, 3	5361-473ZF	0.047 $\mu$ F, +80% -20%, 50V, Ceramic
C4, 5	5345-228D041	2200 $\mu$ F, $\pm$ 20%, 25V, Electrolytic
C6, 7, 10, 301, 302, 303, 304, 565, 566	5345-226C041	22 $\mu$ F, $\pm$ 20%, 16V, Electrolytic
C8, 9	5345-108C041	1000 $\mu$ F, $\pm$ 20%, 16V, Electrolytic
C51	5345-226F041	22 $\mu$ F, $\pm$ 20%, 50V, Electrolytic
C52	5345-226D041	22 $\mu$ F, $\pm$ 20%, 25V, Electrolytic
C53	5345-337D041	330 $\mu$ F, $\pm$ 20%, 25V, Electrolytic
C54	5345-225F041	2.2 $\mu$ F, $\pm$ 20%, 50V, Electrolytic
C55	5345-335F0951	3.3 $\mu$ F, $\pm$ 20%, 50V, Electrolytic
C101, 102	5353-101534	100pF, $\pm$ 5%, 500V, Mica
C103, 104	5345-226C0226	22 $\mu$ F, $\pm$ 20%, 16V, Electrolytic
C105, 106	5345-227A0951	220 $\mu$ F, $\pm$ 20%, 6.3V, Electrolytic
C107, 108, 109, 110	5359-3627851	3600pF, $\pm$ 2%, 100V, Polypropylene
C111, 112	5345-106C0226	10 $\mu$ F, $\pm$ 20%, 16V, Electrolytic
C113, 114, 225, 226, 515, 516, 567, 568, 702, 807	5345-107C041	100 $\mu$ F, $\pm$ 20%, 16V, Electrolytic
C115, 116	5359-1815851	180pF, $\pm$ 5%, 100V, Polypropylene
C117, 118	5359-3315851	330pF, $\pm$ 5%, 100V, Polypropylene
C119, 120	5359-8215851	820pF, $\pm$ 5%, 100V, Polypropylene

Ref. No.	Part No.	Description
C165, 166, 215, 216	5345-476C041	47 $\mu$ F, $\pm$ 20%, 16V, Electrolytic
C201, 202	5359-3915851	390pF, $\pm$ 5%, 100V, Polypropylene
C207, 208	5359-4315851	430pF, $\pm$ 5%, 100V, Polypropylene
C211, 212, 213, 214, 501, 502	5345-105F0951	1 $\mu$ F, $\pm$ 20%, 50V, Electrolytic
C219, 220	5342-225D0951	2.2 $\mu$ F, $\pm$ 20%, 25V, Electrolytic
C221, 222	5359-2215851	220pF, $\pm$ 5%, 100V, Polypropylene
C229, 230	5359-6815851	680pF, $\pm$ 5%, 100V, Polypropylene
C251	5345-227D041	220 $\mu$ F, $\pm$ 20%, 25V, Electrolytic
C253, 254	5353-680534	68pF, $\pm$ 5%, 500V, Mica
C401, 402	5345-105-50	1 $\mu$ F, +75% -10%, 50V, Electrolytic
C503, 504, 511, 512, 513, 514, 539, 540, 561, 562	5345-106C0951	10 $\mu$ F, $\pm$ 20%, 16V, Electrolytic
C507, 508	5359-1027851	1000pF, $\pm$ 2%, 100V, Polypropylene
C509, 510	5359-4727851	4700pF, $\pm$ 2%, 100V, Polypropylene
C517, 518, 701	5345-227C041	220 $\mu$ F, $\pm$ 20%, 16V, Electrolytic
C519, 520, 521, 522	5359-153771	0.015 $\mu$ F, $\pm$ 2%, 50V, Polypropylene
C523, 524, 551, 552, 563, 564	5345-L106M16	10 $\mu$ F, $\pm$ 20%, 16V, Electrolytic
C529, 530, 555, 556, 801	5345-475D041	4.7 $\mu$ F, $\pm$ 20%, 25V, Electrolytic
C531, 532, 533, 534, 557, 558	5345-L154M50	0.15 $\mu$ F, $\pm$ 20%, 50V, Electrolytic
C535, 536, 537, 538, 559, 560	5345-L474M50	0.47 $\mu$ F, $\pm$ 20%, 50V, Electrolytic
C547, 548	5359-3327851	3300pF, $\pm$ 2%, 100V, Polypropylene
C549, 550	5359-3927851	3900pF, $\pm$ 2%, 100V, Polypropylene
C704	5345-225F041	2.2 $\mu$ F, $\pm$ 20%, 50V, Electrolytic
C802	5345-336C041	33 $\mu$ F, $\pm$ 20%, 16V, Electrolytic
C806	5345-474F041	0.47 $\mu$ F, $\pm$ 20%, 50V, Electrolytic
C815	5345-337C041	330 $\mu$ F, $\pm$ 20%, 16V, Electrolytic
<b>INTEGRATED CIRCUITS</b>		
IC201	5652- $\mu$ PC4558C	$\mu$ PC4558C
IC501, 502	5652-HA12038	HA12038
IC801	5654-M54886P	M54886P
<b>TRANSISTORS</b>		
Q1	5611-473(Y)	2SA473(Y) (w/Insulator)
Q2	5613-1173(Y)	2SC1173(Y) (w/Insulator)
Q3, 52, 705, 706, 707, 708, 711, 712, 713, 718, 801, 803, 806, 807, 808, 813	5613-2603(F)	2SC2603(F)
Q4, 51, 55, 717	5611-1115(F)	2SA1115(F)
Q5, 251, 307, 308	5613-2236(Y)	2SC2236(Y)
Q53, 54	5613-2878(B)	2SC2878(B)
Q101, 102	5613-2855(E)	2SC2855(E) or 2SC2855(D)
Q103, 104	5611-1190(E)	2SA1190(E) or 2SA1190(D)
Q105, 106, 301, 302, 501, 502	5613-2320(F)	2SC2320(F)
Q107, 108, 303, 304	5611-999(F)	2SA999(F)
Q109, 110, 503, 504, 505, 506	5613-2603(F)	2SC2603(F) or 2SC2603(E)
Q305, 306	5611-966(Y)	2SA966(Y)
Q701, 702, 703, 704	5613-1845(E)	2SC1845(E)
Q714, 715	5611-970(BL)	2SA970(BL)
Q716	5614-667(C)	2SD667(C)
Q802, 804, 805, 814	5611-1115(F)	2SA1115(F) or 2SA1115(E)
Q809, 810, 811	5612-561(C)	2SB561(C)
<b>DIODES</b>		
D1	5685-1F	Bridge Silicon, S1RBA10
D2, 3, 7, 51, 52, 53, 54, 55, 56, 57, 251, 252, 253, 254, 255, 701, 702, 703, 704, 706, 707, 801, 802, 803, 808, 813	5636-1SS53	1SS53
D4, 5	5635-RD9R1EB2	Zener, RD9.1EB2
D6	5635-RD11EB2	Zener, RD11EB2


Ref. No.	Part No.	Description
D58	5635-RD12EB2	Zener, RD12EB2
D101, 102	5641-KB265	Varistor, KB265
D501	5635-RD5R6EB2	Zener, RD5.6EB2
D705	5636-1S2471	1S2471
D804, 805, 806, 807	5632-DS135E	DS135E
D809, 812	5635-RD5R1EB2	Zener, RD5.1EB2
<b>COILS</b>		
L201, 202	5932-70122	3.3mH
L203, 204	5932-70117	
L251	5995-101325	100 $\mu$ H
L501, 502	5932-70217	
<b>MISCELLANEOUS</b>		
LC501, 502	5214-46	LC Components
OS101	6171-1201	Complex, Osc.
SW201, 202, 203	4431-03107151	Push Switch, Tape Selectors
P10	4443-027114	Connector, 2-Pin
P152, 501, 502	4443-030185	Connector, 3-Pin
P401, 402	4443-037114	Connector, 3-Pin
P801	4443-107114	Connector, 10-Pin
P803	4443-050185	Connector, 5-Pin
JM701	4242-031302	Jumper Lead, 3-Wire
	2132-7048	Spacer, D6
	2132-7049	Spacer, R17
	4472-414	Fuse Holder (x4) (General model only)
<b>PCB-2 CONTROL SWITCHES P.C. BOARD</b>		
<b>CAPACITORS</b>		
C403, 404	5345-475D041	4.7 $\mu$ F, $\pm$ 20%, 25V, Electrolytic
C571, 572	5345-227C041	220 $\mu$ F, $\pm$ 20%, 16V, Electrolytic
<b>MISCELLANEOUS</b>		
SW501, 502, 503	4431-A027136	Push Switch, NR ON/OFF, NR Type, MPX Filter
SW801, 802, 803, 804, 805, 806	4431-01010170	Push Switch, Rew., Stop, F.FWD, Rec., Play, Pause
<b>PCB-3 POWER SWITCH P.C. BOARD</b>		
C1	5361-1030419	Capacitor, 0.01 $\mu$ F, +100% -0%, AC125V, Ceramic (U.S. & Canadian models)
C1	5352-1030958	Capacitor, 0.01 $\mu$ F, $\pm$ 20%, AC250V, Metalized Polyester (General model)
SW1	4431-A01056	Push Switch, Power
<b>PCB-4 DOLBY B-C NR INDICATORS P.C. BOARD</b>		
D404	5637-GL9HY9	L.E.D., GL9HY9, Yellow, Dolby C
D405	5637-GL9PG19	L.E.D., GL9PG19, Green, Dolby B
<b>PCB-5 HEADPHONE JACK P.C. BOARD</b>		
J301	4451-00141	Jack, Headphones
<b>PCB-6 POWER, REC AND PAUSE INDICATORS P.C. BOARD</b>		
D402, 811	5637-GL9PR6	L.E.D., GL9PR6, Red, Power, Rec.
D810	5637-GL9HY6	L.E.D., GL9HY6, Yellow, Pause
<b>PCB-7 JACK P.C. BOARD</b>		
J1, 2, 3, 4	4484-31	4-Pin Jack, Line Input, Line Output
<b>PCB-8 REED SWITCH P.C. BOARD</b>		
SW807	4466-713	Reed Switch, Auto Stop



**PACKAGE**




SCHEMATIC DIAGRAM




- ..... RECORDING SIGNAL (Lch)  
 ..... PLAYBACK SIGNAL (Rch)
- ALL RESISTANCE VALUES ARE IN  $\Omega$ .  
 $k\Omega = 1000\Omega$ ,  $M\Omega = 1000k\Omega$
  - THE WATTAGE OF RESISTORS IS 1/4W UNLESS OTHERWISE NOTED.
  - ALL CAPACITANCE VALUES ARE IN  $\mu F$  UNLESS OTHERWISE NOTED.  $P = \mu mF$
  - V: DC VOLTAGE AT NO SIGNAL.
  - STOP MODE  
 (...) PLAYBACK MODE  
 (...) RECORDING MODE
  - SAFETY REQUIREMENTS COMPONENTS IN ACCORDANCE WITH PRESENT SAFETY REGULATIONS. THESE COMPONENTS MUST ONLY BE REPLACED BY ORIGINAL PARTS.

# SCHEMATIC DIAGRAM



# DOLBY NR SECTION



DOLBY NR OFF	4.7V
DOLBY B	6.6V
DOLBY C	8.2V

DOLBY NR OFF	4.7V
DOLBY B	6.6V
DOLBY C	8.2V


G

H

I

J

# RECORDING AMP.



Lch  
MON. OUT  
+ 10/16 (775mV)  
(L,L)  
METER OUT

Lch  
REC. OUT  
+ 5.6V C539  
10/16 (580mV)  
(L,L)

Rch  
MON. OUT  
+ 10/16 (775mV)  
(L,L)  
METER OUT

Rch  
REC. OUT  
+ 10/16 (580mV)  
(L,L)

MPX FILTER  
ON / OFF

+Vcc

56m

IC201 (1/2)

M5219P

R233 180

R237 180

R238 2.2K

C215 2.2K

C216 47/16

C217 47/16

C218 47/16

C219 47/16

C220 47/16

C221 47/16

C222 47/16

C223 47/16

C224 47/16

C225 47/16

C226 47/16

C227 47/16

C228 47/16

C229 47/16

C230 47/16

C231 47/16

C232 47/16

C233 47/16

C234 47/16

C235 47/16

C236 47/16

C237 47/16

C238 47/16

C239 47/16

C240 47/16

C241 47/16

C242 47/16

C243 47/16

Q717  
2SA1115(F)


5V  
11.9V  
12.6V

K

L

M

N




### HEADPHONE AMP.

LEFT OUTPUT  
J3

RIGHT OUTPUT  
J4


HEADPHONES  
J301(1/2)

HEADPHONES  
J301(2/2)



### PEAK LEVEL METER

### POWER SUPPLY



POWER INDICATOR  
D402 GL9PR6

5


6

7

8





9

10





..... RECORDING SIGNAL (Lch)  
 ..... PLAYBACK SIGNAL (Rch)

1. ALL RESISTANCES VALUES ARE IN  $\Omega$ .  
 $k\Omega = 1000\Omega$ ,  $M\Omega = 1000 k\Omega$
2. THE WATTAGE OF RESISTORS IS 1/4W UNLESS OTHERWISE NOTED.
3. ALL CAPACITANCES VALUES ARE IN  $\mu F$  UNLESS OTHERWISE NOTED.  $P = \mu\mu F$
4. V: DC VOLTAGE AT NO SIGNAL.  
 ... V STOP MODE  
 (... V) PLAYBACK MODE  
 (... V) RECORDING MODE
5.  $\Delta$  SAFETY REQUIREMENTS COMPONENTS IN ACCORDANCE WITH PRESENT SAFETY REGULATIONS. THESE COMPONENTS MUST ONLY BE REPLACED BY ORIGINAL PARTS.









.....V..... When set a cassette tape.  
 .....V..... When without a cassette tape.

### LOGIC CONTROL



WIRING DIAGRAM




**PIN CONNECTION DIAGRAM OF TRANSISTORS, DIODES AND ICs.**

Q1: 2SA473 (Y) Q2: 2SC1173 (Y)	Q5: 2S1, 307, 308 : 2SC2236 (Y) Q714, 715 : 2SA970 (BL) Q716: 2SD667 (C)
Q3, 52, 705 ~ 708, 711 ~ 713, 718, 801, 803, 806 ~ 808, 813: 2SC2603 (F) Q4: 51, 55, 717: 2SA1115 (F) Q109, 110, 503 ~ 506: 2SC2603 (F) or (E) Q802, 804, 805, 814: 2SA1115 (F) or (E)	
Q53, 54: 2SC2878 (B) Q101, 102: 2SC2855 (E) or (D) Q103, 104: 2SA1190 (E) or (D) Q105, 106, 301, 302, 501, 502: 2SC2320 (F) Q107, 108, 303, 304: 2SA999 (F) Q305, 306: 2SA966 (Y) Q701 ~ 704: 2SC1845 (E) Q809 ~ 811: 2SB661 (C)	
D1: 1SRBA10	D101, 102: K8265
D2, 3, 7, 51 ~ 57, 251 ~ 255, 701 ~ 704, 706, 707, 801 ~ 803, 808, 813 : 1S553	
D4, 5: RD9.1EB2 D6: RD11EB2 D8: RD12EB2 D501: RD5.6EB2 D705: 1S2471 D809, 812: RD5.1EB2	Anode Cathode
D804 ~ 807: DS135E	D404: GL9HY9 D405: GL9PG19
D402, 811: GL9PR6 D810: GL9HY6	D403: SLF301C IC501, 502 : HA12038
IC 201 : $\mu$ PC4558C	IC801: M54866P

**WIRE COLOR ABBREVIATIONS**  
 RED : Red    BLK : Black  
 ORG : Orange    YEL : Yellow  
 BLU : Blue    PUP : Purple  
 WHT : White    PIK : Pink  
 GRN : Green    BRN : Brown

WIRING DIAGRAM






H I J K L


OUTPUT INPUT

J3 LEFT J1  
J4 RIGHT J2

PCB-7



JM 301



K

L



M

N

OUTPUT INPUT

J3 LEFT J1  
J4 RIGHT J2

PCB-7



**PIN CONNECTION DIAGRAM OF TRANSISTORS, DIODES AND ICs.**

<p>Q1: 2SA473 (Y) Q2: 2SC1173 (Y)</p>	<p>Q5, 251, 307, 308 : 2SC2236 (Y) Q714, 715 : 2SA970 (BL) Q716: 2SD667 (C)</p>
<p>Q3, 52, 705 ~ 708, 711 ~ 713, 718, 801, 803, 806 ~ 808, 813: 2SC2603 (F) Q4, 51, 55, 717, : 2SA1115 (F) Q109, 110, 503 ~ 506: 2SC2603 (F) or (E) Q802, 804, 805, 814: 2SA1115 (F) or (E)</p>	
<p>Q53, 54: 2SC2878 (B) Q101, 102: 2SC2855 (E) or (D) Q103, 104: 2SA1190 (E) or (D) Q105, 106, 301, 302, 501, 502: 2SC2320 (F) Q107, 108, 303, 304: 2SA999 (F) Q305, 306: 2SA966 (Y) Q701 ~ 704: 2SC1845 (E) Q809 ~ 811: 2SB561 (C)</p>	
<p>D1: S1RBA10</p>	<p>D101, 102: KB265</p>

5


6

7





8

9



10





CASSETTE TAPE RECORDER MECHANICAL ASSEMBLY








CASSETTE  
ILLUMINATOR




DC SOLENOID

PLAY



PCB-6

POWER REC PAUSE



PCB-2

SW802  
STOP

SW805  
PLAY

SW501  
DOLBY NR  
off on

SW801  
REW


SW803  
F.FWD

SW804  
REC

SW806  
PAUSE

JM301


JM603



PCB-8

PCB-1

SW203  
70µsec  
METAL



SW203  
70µsec  
METAL

SW202  
70µsec  
CrO2

SW201  
120µsec  
LN

BIAS / EQUALIZATION

bias  
fine trim


input  
balance

INPUT LEVEL

JM501

JM502

JM503




SW501 SW502 SW503  
DOLBY B-C NR  
mpx filter


NR  off  on

B  C

on  off





D401  
LED LEVEL DISPLAY ASSEMBLY










Q3, 52, 705 ~ 708, 711 ~ 713, 718, 801, 803, 806 ~ 808, 813: 2SC2603 (F)  
 Q4, 51, 55, 717, : 2SA1115 (F)  
 Q109, 110, 503 ~ 506: 2SC2603 (F) or (E)  
 Q802, 804, 805, 814: 2SA1115 (F) or (E)

Q53, 54: 2SC2878 (B)  
 Q101, 102: 2SC2855 (E) or (D)  
 Q103, 104: 2SA1190 (E) or (D)  
 Q105, 106, 301, 302, 501, 502: 2SC2320 (F)  
 Q107, 108, 303, 304: 2SA999 (F)  
 Q305, 306: 2SA966 (Y)  
 Q701 ~ 704: 2SC1845 (E)  
 Q809 ~ 811: 2SB561 (C)



D2, 3, 7, 51 ~ 57, 251 ~ 255, 701 ~ 704, 706, 707, 801 ~ 803, 808, 813 : 1SS53  
 D4, 5: RD9.1EB2  
 D6: RD11EB2  
 D58: RD12EB2  
 D501: RD5.6EB2  
 D705: 1S2471  
 D809, 812: RD5.1EB2



D401 LED LEVEL DISPLAY ASSEMBLY

Dolby NR B C

PCB-4

- WIRE COLOR ABBREVIATIONS
- |              |              |
|--------------|--------------|
| RED : Red    | BLK : Black  |
| ORG : Orange | YEL : Yellow |
| BLU : Blue   | PUP : Purple |
| WHT : White  | PIK : Pink   |
| GRN : Green  | BRN : Brown  |