


HITACHI

SERVICE MANUAL

SM0512

DV-RV8500E
DV-RV8500E(UK)



DO NOT RESELL OR DIVERT IMPROPERLY.

SPECIFICATIONS AND PARTS ARE SUBJECT TO CHANGE FOR IMPROVEMENT

DVD VIDEO RECORDER with VIDEO CASSETTE RECORDER

July

2005

Digital Media Division, Yokohama

Table of Contents

1 Safety Precaution for Repair	1-1	(8) DVD multi-drive	4-6
1-1 Cautions	1-1	(9) VDR, JACK and KEY P.C.Bs	4-6
1-2 Electrostatic Protection Measures	1-2	4-3 Deck Mechanism Parts Locations	4-7
1-3 Cautions When Handling DVD Drive	1-2	4-4 Deck Mechanism Disassembly	4-8
1-4 Lead-Free Solder	1-3	(1) Drum assembly	4-8
1-5 Notes When Using Service Manual	1-4	(2) Top plate	4-9
2 General Description	2-1	(3) CST holder assembly	4-9
2-1 Overview	2-1	(4) F/L rack gear assembly	4-9
2-1-1 Service method	2-1	(5) Door opener	4-9
2-1-2 Disc information	2-2	(6) F/L arm assembly	4-9
2-2 Features	2-4	(7) S/W lever assembly	4-9
2-3 Specifications	2-5	(8) L/D motor assembly	4-11
2-4 Major Differences from Previous Model ..	2-6	(9) Wheel gear	4-11
2-5 Function Differences from		(10) F/E head	4-11
Previous Model	2-7	(11) A/C head assembly	4-11
2-6 Names of Parts	2-8	(12) T brake assembly	4-12
2-7 List of Abbreviations and Terms for DVD		(13) Tension arm assembly	4-12
Recorder	2-12	(14) S reel and T reel	4-12
3 Details of Servicing and		(15) P4 base assembly	4-13
Troubleshooting	3-1	(16) Lid opener	4-13
3-1 Details of Servicing	3-1	(17) Pressure arm assembly	4-13
3-1-1 Removing Disc from Faulty Recorder ...	3-1	(18) Take-up arm	4-13
3-1-2 Removing Video Cassette from Faulty		(19) Capstan supporter	4-14
Recorder	3-1	(20) Capstan belt and capstan motor	4-14
3-1-3 Firmware	3-2	(21) F/R lever	4-14
3-1-4 Setting to defaults at the factory	3-3	(22) D37 clutch assembly	4-14
3-2 Troubleshooting	3-4	(23) Driver gear and cam gear	4-15
3-2-1 Troubleshooting electronic system	3-4	(24) Sector gear	4-15
3-2-2 Troubleshooting mechanical block	3-14	(25) Capstan brake assembly	4-15
4 Disassembly and Reassembly	4-1	(26) Slider plate	4-15
4-1 Order of Disassembly	4-1	(27) Tension lever	4-15
4-2 Cabinet Disassembly	4-1	(28) Spring lever	4-15
(1) Top Cover	4-1	(29) Brake lever	4-15
(2) Front Panel	4-2	(30) P2 gear assembly and	
(3) FAN Motor	4-2	P3 gear assembly	4-16
(4) SMPS P.C.B	4-3	(31) P2 base assembly and	
(5) Deck mechanism	4-4	P3 base assembly	4-16
(6) TIMER P.C.B	4-5	(32) Loading base	4-16
(7) VCR P.C.B	4-5	(33) Tension base	4-17
		(34) Jog idler arm assembly	4-17
		4-5 Checking Mode after Reassembling Deck	
		Mechanism	4-18

5 Adjustment / Maintenance 5-1

5-1 Set-up for Adjustment 5-1

5-2 VCR Electrical Adjustment 5-2

5-2-1 Head switching adjustment 5-2

5-3 Deck Mechanism Tape Transport System
Adjustment 5-3

5-3-1 Guide roller height adjustment 5-3

5-3-2 A/C head adjustment 5-4

5-3-3 X-value adjustment 5-5

5-3-4 Adjustments after replacing
drum assembly 5-5

5-3-5 Check after adjustment 5-6

5-3-6 Method of setting the mechanism to
loading status without inserting tape 5-6

5-3-7 Reel torques 5-7

5-4 Maintenance 5-8

5-4-1 Maintenance and inspection 5-8

5-4-2 Lubricating oil and greasing 5-10

6 Exploded View and Parts List 6-1

6-1 Exploded Views 6-1

6-1-1 Cabinet Section 6-1

6-1-2 F / L Mechanism 6-2

6-1-3 Deck Mechanism Section - Top view ... 6-3

6-1-4 Deck Mechanism Section - Bottom view 6-4

6-2 Parts List 6-5

6-2-1 Mechanical Parts List 6-5

6-2-2 Electrical Parts List 6-6

S Schematic, Wiring Diagrams S-1

S-1 Wiring Diagram S-1

S-2 S.M.P.S Schematic Diagram S-2

S-3 SYSTEM Schematic Diagram(VCR P.C.B) S-3

S-4 TUNER Schematic Diagram(VCR P.C.B) .. S-4

S-5 A/V Schematic Diagram(VCR P.C.B) S-5

S-6 Hi-Fi Schematic Diagram(VCR P.C.B) S-6

S-7 REAR JACK Schematic Diagram
(VCR P.C.B) S-7

S-8 TIMER,KEY Schematic Diagrams S-8

S-9 JACK Schematic Diagram S-9

S-10 A/V,SYSTEM Circuit Waveforms S-10

S-11 CIRCUIT VOLTAGE CHART S-11

C Circuit Board Diagrams C-1

C-1 VCR Circuit Board Diagram C-1

C-2 S.M.P.S Circuit Board Diagram C-3

C-3 JACK Circuit Board Diagram C-4

C-4 TIMER Circuit Board Diagram C-4

C-5 KEY Circuit Board Diagram C-4

B Block Diagrams B-1

B-1 S.M.P.S Circuit Block Diagram B-1

B-2 VIDEO Circuit Block Diagram B-2

B-3 AUDIO Circuit Block Diagram B-3


B-4 SYSTEM Circuit Block Diagram B-4

B-5 VIDEO I/O Circuit Block Diagram B-5

1-1 Cautions

PRODUCT SAFETY NOTICE

Many electrical and mechanical parts have special safety-related characteristics. These are often not evident from visual inspection nor can the protection afforded by them necessarily be obtained by using replacement components rated for a higher voltage, wattage, etc. Replacement parts which have these special safety characteristics are identified in this Service Manual. Electrical components having such features are identified by marking with a \triangle on the schematics and the parts list in this Service Manual. The use of a substitute replacement component which does not have the same safety characteristics as the HITACHI recommended replacement one, shown in the parts list in this Service Manual, may create shock, fire, or other hazards. Product safety is continuously under review and new instructions are issued from time to time. For the latest information, always consult the current HITACHI Service Manual. A subscription to, or additional copies for, HITACHI Service Manual may be obtained at a nominal charge from HITACHI SALES CORPORATION.



CAUTION

This product contains a laser diode of higher class than 1. To ensure continued safety, do not remove any covers or attempt to gain access to the inside of the product. Refer all servicing to qualified personnel.

CAUTION


There is a high-voltage section inside the DVD video recorder. When repairing or inspecting it, take great care to prevent electric shock: Use an isolating transformer, wear gloves, etc.

1-2 Electrostatic Protection Measures

Semiconductor components can be damaged by static electricity charged on clothes, human body, etc. Take great care when handling components to avoid electrostatic damage, and perform servicing in an environment where grounding is complete.


(1) Grounding work bench

Lay out an antistatic mat on work bench, and then use the ground plate to ground the work bench.



(2) Grounding human body


Use an antistatic wrist strap to discharge any static electricity charged on the body. Also, use a tester for wrist strap to make sure that the wrist strap is working normally. Note, however, that static electricity charged on clothes will not be discharged by wrist strap: Therefore do not allow your clothes to touch the semiconductor components.



1-3 Cautions When Handling DVD Drive

The optical pickup in DVD drive has a high precision structure: Be sure to observe the following cautions.

- 1) Do not subject optical pickups to any severe vibrations or impact during movement, installation or disassembly.
- 2) When performing repair work, do not perform disassembly any further than that described in this manual.
- 3) Never turn the semi-variable resistors for adjustment in optical pickup or DVD drive.
- 4) NEVER look into the objective lens in optical pickup or directly view the laser light: You could lose your eyesight.



Do not directly look at laser light from pickup.

1-4 Lead-Free Solder

The printed circuit board that uses lead-free solder is adopted. To protect the global environment, use the recommended lead-free solder also during servicing.

Read and observe the following before soldering:

Caution

ALWAYS wear protective goggles during soldering so that no solder smoke or scattered solder enters the eye. Lead-free solder may scatter at high temperatures of 600°C.

(1) Characteristics of lead-free solder

The melting point of lead-free solder is 30-40°C higher than that of lead based solder.

(2) Lead-free solder for servicing

Use the following lead-free solder for servicing:

Recommended lead-free solder and composition of alloy (wt%): Sn-3.0Ag-0.5Cu or equivalent

Information:

For composition of alloy, Sn is tin; Ag is silver; Cu is copper; Bi is bismuth; Pb is lead.

(3) Soldering iron for servicing

The temperature of soldering iron tip must be adjusted according to the points to be soldered: Use an antistatic soldering iron with thermal control function.

When removing components, take care not to damage any surrounding component or pattern. When attaching components, observe the heating time in the following table so that the components are not destroyed by heat.

Tip temperatures for different soldering points:

Point to be soldered	Tip temperature
Surface-mounted (chip) parts [other than those shown below]	320 ± 30°C [heating time: less than 5 seconds]
Surface-mounted (chip) parts [for DVD cameras, cellular phones only]	350 ± 10°C [heating time: less than 3 seconds]
Discrete parts	380 ± 30°C
Chassis, metal shield, etc.	420 ± 30°C

(4) Cautions when using lead based solder

It is recommended that you use lead-free solder when servicing, but it is also possible to service using lead based solder. However, if lead based solder is used for servicing, take care with the following:

- 1) Before using lead based solder, remove the lead-free solder completely from the point to be soldered.
- 2) For additional soldering for repair, set the soldering iron tip temperature for lead-free solder, mix lead based solder and lead-free solder sufficiently. Do not perform any repair using the bare soldering iron tip without adding solder, since it will cause secondary failure due to lack of strength.

1-5 Notes When Using Service Manual

(1) Value units used in parts list

Certain symbols are indicated as shown below for value units of resistors, capacitors and coils in parts list. When you read them, note the following regular indications:

Parts	Indication in list	Regular indication
Resistor	KOHM	k Ω
Capacitor	UF	μ F
	PF	pF
Coil	UH	μ H
	MH	mH

(2) Values in schematic diagrams

The values, dielectric strength (power capacitance) and tolerances of the resistors (excluding variable resistors) and capacitors are indicated in the schematic diagrams using abbreviations. Certain symbols are indicated for value units: When you read them note the regular indications in tables below:

[Resistors]

Item	Indication
Value	No indication Ω
	K k Ω
	M M Ω
Tolerance	No indication $\pm 5\%$ (All tolerances other than $\pm 5\%$ are indicated in schematic diagrams)
Power capacitance	No indication 1/8W (1/16 W for leadless resistors with no indication) All capacitances other than the above are indicated in schematic diagrams.

[Capacitors]

Item	Indication
Value	No indication μ F
	P pF
Dielectric strength	No indication 50V (All dielectric strengths other than 50 V are indicated in schematic diagrams)

[Coils]

Item	Indication
Value	μ μ H
	m mH

2 General Description

2-1 Overview

The DV-RV8500E is a DVD recorder with VHS VCR that incorporates a DVD super multi-drive: It allows user to record and play back on +RW and +R, as well as on DVD-RAM, DVD-RW, DVD-R and VHS videotape.

It can be used without any concern about the type of media.

2-1-1 Service method

Basically, components are replaced when servicing the DV-RV8500E. However, the service method is different for high-density packaging PCBs and precision components.

Refer to the following table and perform the designated, appropriate servicing. Any changes that occur in the service method will be published using service bulletin, etc.

Do not perform any servicing other than that described in this manual.

Component	Service method
Exterior component	Component replacement
DVD Multi Drive	Unit replacement
VDR P.C.B	Circuit board assembly replacement
VCR P.C.B	Component replacement
TIMER P.C.B	Component replacement
JACK P.C.B	Component replacement
KEY P.C.B	Component replacement
SMPS P.C.B	Component replacement
Deck mechanism	Component replacement




Fig. 2-1-1 Component Location

2-1-2 Disc information

Recordable Discs



DVD-RW (Digital Video Disc - ReWritable):

These Discs can be recorded on repeatedly. Recordings can be erased, then you can record again on the same Disc. When a brand-new DVD-RW disc is inserted, the screen for formatting the disc will appear: Choose the VR mode or Video mode, and then format the disc before use.



DVD-R (Digital Video Disc - Recordable):

These Discs can be recorded only once. After you finalize a DVD-R, you cannot record on it or edit it any more.



DVD+ReWritable

DVD+RW (Digital Video Disc + ReWritable):

These Discs can be recorded on repeatedly. Recordings can be erased, then you can record again on the same Disc. When a brand-new DVD+RW disc is inserted, the screen for formatting the disc will appear: Format the disc before use. When a DVD+RW disc recorded on this recorder is removed, it will automatically be finalized, but if you enter a title after finalization, you will need to manually finalize it.



DVD+R

DVD+R (Digital Video Disc + Recordable):

These Discs can be recorded only once. After you finalize a DVD+R, you cannot record on it or edit it any more.



DVD VIDEO RAM/RW

DVD-RAM (DVD - Random Access Memory)

DVD-RAM discs can be formatted for VR mode recording. These Discs can be recorded on repeatedly. Recordings can be erased, then you can record again on the same Disc. Playable on DVD-RAM compatible players. Recordings can be extensively edited. Only DVD-RAM standard Version 2.0, 2.1 and 2.2 discs can be used in this unit. You cannot use the cartridge-type DVD-RAM disc in this unit. When a brand-new DVD-RAM disc is inserted, the screen for formatting the disc will appear: Format the disc before use. In the case of an 8-cm DVD-RAM on which photos were recorded on a Hitachi DVD video camera/recorder, no editing of Disc Navigation or play list can be performed on this recorder (recording on it and creating a play list are possible).

Notes

- This recorder cannot record CD-R or CD-RW discs.
- DVD-R/RW, DVD+R/RW and CD-R/RW discs recorded using a personal computer or a DVD or CD recorder may not play if the disc is damaged or dirty, or if there is dirt or condensation on the recorder's lens.
- If you record a disc using a personal computer, even if it is recorded in a compatible format, there are cases in which it may not play because of the settings of the application software used to create the disc. (Check with the software publisher for more detailed information.)
- The company does not hold any responsibility to compensate the contents which should have been recorded, and any losses or damages (e.g. losses of business profit, or business intermission) that may arise from malfunction of this recorder (not recording/editing as intended). Problems arising in the following situations are included.
 - When a DVD disc recorded on this recorder is used in a DVD recorder of another manufacturer, or used (insertion, playback, recording or editing) in a personal computer DVD drive.
 - When a DVD that has been used as above is used again in this recorder.
 - When a DVD disc recorded in a DVD recorder of another manufacturer, or in a personal computer DVD drive is used.

Playable Discs

	DVD (8 cm/12 cm disc)
	Video CD (VCD) (8 cm / 12 cm disc)
	Audio CD (8 cm/12 cm disc)

In addition, this unit can play DVD-R/DVD-RW discs; DVD+R/DVD+RW discs; CD-R/CD-RW discs that contain audio titles, MP3 files, WMA files, or JPEG files; and VCD.

Notes

- Depending on the conditions of the recording equipment or the CD-R/RW (or DVD±R/±RW) disc itself, some CD-R/RW (or DVD±R/±RW) discs cannot be played on the unit.
- Do not attach any seal or label to either side (the labelled side or the recorded side) of a disc.
- Do not use irregularly shaped CDs (e.g., heart-shaped or octagonal). Doing so may result in malfunctions.

About DVD-R and DVD-RW disc

How are DVD-R and DVD-RW discs different?

The essential difference between DVD-R and DVD-RW is that DVD-R is a record-once medium, while DVD-RW is a re-recordable/erasable medium. You can re-record/erase a DVD-RW disc approximately 1,000 times.

Can I play my recordable discs in a regular DVD player?

Generally, DVD-R discs and DVD-RW discs recorded in Video mode are playable in a regular DVD player, but they must be 'finalized' first. This process fixes the contents of the disc to make them readable to other DVD players as DVD-Video discs. DVD-RW discs recorded in VR (Video Recording) mode are playable in some players.



This indicates a product feature that is capable of playing DVD-RW discs recorded with Video Recording format.

What are 'recording modes'?

There are two recording modes available using this recorder: VR mode and Video mode. When recording to a DVD-R disc, recordings are always in Video mode. DVD-RW discs can be formatted for VR mode recording or Video mode recording.

VR mode recording

- 4 different picture quality/recording time settings available (XP, SP, LP, EP)
- Not playable on regular DVD players
- Recordings can be extensively edited

Video mode recording

- 4 different picture quality/recording time settings available (XP, SP, LP, EP)
- Playable on regular DVD players (after finalizing)
- Limited editing features

Note

DVD-Video Format (Video mode) is a new format for recording on DVD-R/RW and DVD+R/RW discs that was approved by the DVD Forum in 2000. You may therefore experience problems playing recordable DVD discs in some players. Symptoms include video artifacts, audio and/or video dropouts and playback suddenly stopping.

Our company cannot take responsibility for problems playing discs recorded on this recorder in other players.

Is editing a DVD like editing a video tape?

No. When you edit a video tape you need one video deck to play the original tape and another to record the edits. With DVD, you edit by making a 'Playlist' of what to play and when to play it. On playback, the recorder plays the disc according to the Playlist.

About word 'Original' and 'Playlist'

Throughout this manual, you will often see the words Original and Playlist to refer to the actual content and the edited version.

- **Original:** content refers to what's actually recorded on the disc.
- **Playlist:** content refers to the edited version of the disc — how the Original content is to be played.

About DVD+R and DVD+RW disc

How are DVD+R and DVD+RW discs different?

The essential difference between DVD+R and DVD+RW is that DVD+R is a record-once medium, while DVD+RW is a re-recordable/erasable medium. You can re-record/erase a DVD+RW disc approximately 1,000 times.

DVD+RW mode recording

- 4 different picture quality/recording time settings available (XP, SP, LP, EP)
- Playable on regular DVD players
- The edited contents is playable on regular DVD players only after finalizing
- Recordings can be edited the title/chapter

DVD+R mode recording

- 4 different picture quality/recording time settings available (XP, SP, LP, EP)
- Playable on regular DVD players (after finalizing)
- Any edited contents are not be compatible on regular DVD players. (Hide, chapter combine, added chapter mark, etc.)
- Limited title/chapter editing features

2-2 Features

1. DVD super multi-drive incorporated

- 1) This drive is newly compatible with recording/playback on +R and +RW, in addition to DVD-RAM, DVD-RW and DVD-R. DVD-RW is compatible with recording/playback in both Video mode and VR (Video Recording) mode: DVD media can be selected to match the application.
- 2) The drive can play back 8 cm DVD-R recorded on a Hitachi DVD video camera/recorder and not finalized.
- 3) The drive is widely compatible with reading of original CD-R/RW recorded in MP3, WMA (Windows Media Player) and JPEG formats, as well as music CDs.

2. The Dubbing button easily dubs VHS images to create a DVD.

Simply pressing the button allows user to dub precious material recorded on VHS videotapes onto DVD. And images edited on DVD can be dubbed onto VHS videotape.

3. High-quality image design

- 1) VBR (Variable Bit Rate control) format ensures both high image quality and long-time recording: This DVD recorder uses a VBR recording format that increases the compression ratio with simple images and decreases it with complex images of larger amounts of data, thus variably controlling to the optimum compression ratio: It reduces deterioration in image quality and effectively records on DVD.
- 2) Progressive playback makes possible the playback of generally available DVD movies, with natural images and reduced flickering: This DVD recorder plays back clear images even on a large screen with reduced jaggging on diagonal lines or characters, and reduced flickering.

4. Enhanced functions

- 1) DV input port enables digital dubbing from a digital camcorder to DVD.
- 2) Zoom-up function allows you to enlarge DVD images.

2-3 Specifications

General

Power requirements	AC 220-240V, 50/60Hz
Power consumption	35W
Dimensions (approx.)	432 X 81.5 X 367 mm (w x h x d)
Mass (approx.)	6.6 kg
Operating temperature	5°C to 35°C
Operating humidity	5 % to 90 %
Television system	PAL B/G, SECAM L/L' colour system [For E] PAL I colour system [For E (UK)]
Recording format	VCR : PAL, SECAM [SECAM : E only] DVD : PAL

System

Laser	Semiconductor laser, wavelength 650 nm
Video head system	Double azimuth 4 heads, helical scanning
Signal system	VCR : PAL, SECAM [SECAM : E only] DVD : PAL

Recording

Recording format	DVD VideoRecording, DVD-VIDEO
Recordable discs	DVD-ReWritable, DVD-Recordable, DVD+ReWritable, DVD+Recordable, DVD-Random Access Memory
Recordable time	DVD (4.7GB) : Approx. 1 hour (XP mode), 2 hours (SP mode), 4 hours (LP mode), 6 hours (EP mode)
Video recording format	
Sampling frequency	27MHz
Compression format	MPEG 2
Audio recording format	
Sampling frequency	48kHz
Compression format	Dolby Digital

Playback

Frequency response	DVD (PCM 48 kHz): 8 Hz to 22 kHz, CD: 8 Hz to 20 kHz DVD (PCM 96 kHz): 8 Hz to 44 kHz
Signal-to-noise ratio	More than 100 dB (AUDIO OUT connector)
Harmonic distortion	Less than 0.008% (AUDIO OUT connector)
Dynamic range	More than 95 dB (AUDIO OUT connector)

Inputs

AERIAL IN	Aerial input, 75 ohms
VIDEO IN	1.0 Vp-p 75 ohms, sync negative, RCA jack x 1 / SCART x 2
AUDIO IN	0 dBm more than 47 kohms, RCA jack (L, R) x 1 / SCART x 2
DV IN	4 pin (i.LINK/IEEE 1394 standard)
S-VIDEO IN	(Y) 1.0 V (p-p), 75 Ω, negative sync, Mini DIN 4-pin x 1 (C) 0.3 V (p-p) 75 Ω



Outputs

VIDEO OUT	1.0 Vp-p 75 ohms, sync negative, SCART x 2
S-VIDEO OUT	(Y) 1.0 V (p-p), 75 Ω, negative sync, Mini DIN 4-pin x 1 (C) 0.3 V (p-p) 75 Ω
COMPONENT VIDEO OUT	(Y) 1.0 V (p-p), 75 Ω, negative sync, RCA jack x 1 (Cb/Pb)/(Cr/Pr) 0.7 V (p-p), 75 Ω, RCA jack x 2
Audio output (digital audio)	0.5 V (p-p), 75 Ω, RCA jack x 1
Audio output (optical audio)	3 V (p-p), 75 Ω, Optical connector x 1
Audio output (analogue audio)	2.0 Vrms (1 KHz, 0 dB), 600 Ω, RCA jack (L, R) x 1 / SCART

- Design and specifications are subject to change without notice.
- Manufactured under licence from Dolby Laboratories. "Dolby" and the double-D symbol are trademarks of Dolby Laboratories.
- DTS and DTS Digital Out are registered trademarks of Digital Theater Systems, Inc.

2-4 Major Differences from Previous Model

← : Same as on left

Item	DV-RV8500E	DV-RX7000E
Appearance		
Dimensions	432(W) x 367(D) x 81.5(H)mm	430(W) x 279(D) x 69(H)mm
Power consumption	Approx. 35 W	Approx.35 W
CPRM	Yes	←
Recordable media	12 cm (5") 4.7 GB DVD-RAM	←
	12 cm (5") 9.4 GB DVD-RAM	←
	8 cm (3") 1.4 GB DVD-RAM	←
	8 cm (3") 2.8 GB DVD-RAM	←
	12 cm (5") 4.7 GB DVD-RW	←
	8 cm (3") 1.4 GB DVD-RW	---
	12 cm (5") 4.7 GB DVD-R	←
	8 cm (3") 1.4 GB DVD-R	←
	12 cm (5") 4.7 GB DVD-R (4x-SPEED)	←
	12 cm (5") 4.7 GB DVD+RW	---
	12 cm (5") 4.7 GB DVD+R	---
Playable media	VHS	---
	DVD-RAM	←
	DVD-RW	←
	DVD-R	←
	DVD+RW	---
	DVD+R	---
	DVD-VIDEO	←
	Video CD (VCD)	←
	Audio CD (CD-DA)	←
	CD-R/CD-RW (CD-DA, MP3,WMA,JPEG,VCD formatted discs)	CD-R/CD-RW (CD-DA, MP3,JPEG formatted discs)
VHS/S-VHS (SQPB)	---	
Remote control	DV-RM8500E	DV-RM7000E
DV input terminal	1 (IEEE 1394/i.LINK)	←
S-VIDEO input terminal	1 (Mini DIN 4pin)	2 (Mini DIN 4pin: 2)
VIDEO/AUDIO input terminals	3 (RCA: 1, SCART: 2)	4 (RCA: 2, SCART: 2)
COMPONENT VIDEO output terminal	1 (RCA)	---
S-VIDEO output terminal	1 (Mini DIN 4pin)	←
VIDEO output terminal	2 (SCART: 2)	3 (RCA: 1, SCART: 2)
Analog AUDIO output terminals	3 (RCA: 1, SCART: 2)	4 (RCA: 2, SCART: 2)
Digital AUDIO output terminals	2 (Optical: 1, Coaxial: 1)	←
Video output switch	Yes (COMPONENT-RGB)	Yes (SETUP screen)


2-5 Function Differences from Previous Model

← : Same as on left

		Item	DV-RV8500E	DV-RX7000E
DVD section	Recording	Digital Recording (DV to DVD)	Yes	No
		Dubbing (VCR to DVD)	Yes	No
		Time Slip (PIP)	Yes	←
		Instant Timer Recording	Yes	One Touch Recording (OTR)
		Flexible Recording Mode	No	Yes (Timer Recording Only)
		Recording Mode	XP, SP, LP, EP	XP, SP, LP, EP, FR
	Playback	Title List Playback	Yes	←
		CM Skip	No	Yes (15, 30, 60 sec)
		Manual Skip	Yes	←
		Marker Search	Yes	←
		Zoom	Yes	←
		Photo CD Playback (JPEG)	Yes	←
		MP3 Playback	Yes	←
		P in P	No	Yes
		Repeat Play	Yes	←
		Repeat A-B Play	Yes	←
		Camera Angle	Yes	←
		3D Surround	Yes	No
		Slow Motion Play	Yes	←
		Random Play	Yes (Karaoke, VCD)	Yes
		Time Search	Yes	←
		DivX Movie Disc Playback	Yes	No
		WMA Playback	Yes	No
		Intro Play	No	Yes
		Other	Disk Menu	Yes
	Title List		Yes	←
	Chapter List		Yes	←
Edit Title List	Yes		←	
Edit Chapter List	Yes		←	
Playlist	Yes		←	
Divide Program	Yes		No	
Hide Program	Yes		No	
VCR section	Recording	Digital Recording (DV to VCR)	Yes	---
		Dubbing (DVD to VCR)	Yes	---
		Title List Dubbing (DVD to VCR)	Yes	---
		Instant Timer Recording	Yes	---
	Playback	Picture Search	Yes	---
		Slow Motion	Yes	---
		Counter [0:00:00] Stop	Yes	---

2-6 Names of Parts

Front Panel




- ① **STANDBY/ON**
Switches the Recorder ON and OFF.
Press to turn the power on and off. (As to the indication of the Operate switch, "I" shows ON and "⏻" shows electrical power stand-by.)
- ② **Disc Tray (DVD deck)**
Insert a disc here.
- ③ **▲ OPEN/CLOSE**
Opens or closes the disc tray.
- ④ **Cassette Compartment (VCR deck)**
Insert a video cassette here.
- ⑤ **▲ EJECT**
Ejects the tape in the VCR deck.
- ⑥ **AV 3 IN**
- **VIDEO /AUDIO (Left/Right)**
Connect the audio/video output of an external source
(Audio system, TV/ Monitor, VCR, Camcorder, etc.).
- **S-VIDEO IN**
Connect the S-Video output of an external source
(TV/ Monitor, VCR, Camcorder, etc.).
- ⑦ **DV IN**
Connect the DV output of a digital camcorder.
- ⑧ **DVD/VCR indicator**
Indicates the active DVD or VCR deck.
- ⑨ **DVD/VCR**
Toggles control between the DVD deck and the VCR deck.
- ⑩ **DUBBING**
Press to copy DVD to VCR (or VCR to DVD).
- ⑪ **● (REC)**
Starts recording.
Press repeatedly to set the recording time.
- ⑫ **■ (STOP)**
Stops playback.
- ⑬ **▶ (PLAY)**
To play back a disc or tape.
- ⑭ **SEARCH**
Press ◀◀ for fast back.
Press ▶▶ for fast forward.

Note

Holding down the POWER button on the front of this recorder in the stop mode will allow you to reset the recorder. Do not perform this during recording: Doing so will result in flawed recording.

Function Display Window



Remote Control Overview

POWER
Switches the recorder ON or OFF.

DVD
Select the Recorder's function mode to DVD.

VCR
Select the Recorder's function mode to VCR.

INPUT
Changes the input to use for recording (Tuner, AV1-3, or DV IN).

0-9 numerical buttons
Selects numbered options in a menu.

CLEAR
- Removes a track number on the Program List or a mark on the Marker Search menu.
- Reset tape counter to zero.

DISPLAY
Accesses On-Screen Display.

TIME SLIP
To play the title being recorded and also currently being recorded appears as PIP.

TIMER REC
Displays Timer Record menu.

REC (●)
Starts recording. Press repeatedly to set the recording time.

REC MODE
Selects the recording mode: XP, SP, LP, or EP.

MANUAL SKIP
Pressing this button during playback will skip to a scene 30 seconds forward.

TV/DVD
To view channels selected by the recorder's tuner or by the TV tuner.

CHP ADD
Inserts a chapter marker when playing/recording a VR mode DVD-RW (and DVD+RW+R) disc.

VIDEO Plus +
Pressing this button and input VIDEO Plus + number to preset the timer for recording.

DUBBING
Press to copy DVD to VCR (or VCR to DVD).

AUDIO
Selects an audio language (DVD) or an audio channel (CD).

SUBTITLE
Selects a subtitle language.

ANGLE
Selects a DVD camera angle, if available.

ZOOM
Enlarges DVD video image.

MARKER
Marks any point during playback.


SEARCH
Displays Marker Search menu.

EJECT, OPEN/CLOSE
- Opens and closes the disc tray.
- Ejects the tape in the VCR deck.

TV Control Buttons

POWER: Turns the TV on or off.
INPUT: Selects the TV's source.
PROG: Selects TV's channel.
VOL: Adjusts TV's volume.
MUTE: Temporarily turns TV sound OFF, press again to restore.
BACKWARD / FORWARD (◀/▶)
- DVD: Search backward or forward.
- VCR: Rewinds the tape during the STOP mode, for fast reverse picture search and Advances the tape during the STOP mode, fast forward picture search.
SKIP (◀◀/▶▶)
Go to next chapter or track. Returns to beginning of current chapter or track or go to previous chapter or track.
PAUSE/STEP (⏸)
Pause playback temporarily / press repeatedly for frame-by-frame playback.
PLAY (▶)
Starts playback.
STOP (■)
Stops playback or recording.
DISC MENU / LIST
Accesses menu on a DVD disc, Title List or Playlist menu.
◀/▶/▲/▼ (left/right/up/down)
Selects an option in the menu.
PROG/TRK(+/-)
- Select channel program of the recorder.
- To adjust tracking.
- To control vertical tremble during picture still.
ENTER
- Acknowledges menu selection.
- Displays information while viewing a TV program.
SETUP
Accesses or removes the Setup menu.
TITLE MENU
Displays the disc's Title menu, if available.
RETURN (↶)
- Removes the menu.
- Displays the menu of a video CD with PBC.
REPEAT
Repeat chapter, track, title, all.
A-B
Repeat sequence.
RANDOM
Plays tracks in random order.
THUMBNAIL
Selects a thumbnail picture for the current title and chapter for use in the Original and Playlist menu.

Rear Panel



2-7 List of Abbreviations and Terms for DVD Recorder

Index	Abbreviation/Term	Explanation
A	AC3	See Dolby AC3.
B	Black Level	Function to correct the gradations on dark portions to make dark scenes easier-to-see.
C	CPRM	Content Protection for Recordable Media: Copyright protection function that is suitable for online distribution of music.
	CD-R	One type of DVD standard disc, to which writing once is possible (recordable type)
	CD-RW	One type of CD standard disc, to which writing up to 1000 times is possible
	Component video output terminals	Used for outputs of HDTV video signal format. Since signals for brightness and colors are independently handled for components signals (Y: luminance signal; PR/PB: chrominance signals), degrading of image will be reduced.
D	Decoder	A device that decodes the data coded and recorded on DVD Video and restores it to video and audio signals. This processing is referred to as decoding.
	Dynamic Range	A difference between maximum and minimum levels of audio recorded on disc: Measured in decibel (dB) units. If the dynamic range is compressed (audio DRC), the minimum signal level will increase and the maximum signal level will decrease: This will reduce the higher audio signal - such as burst sound - so that the low-level audio signal - such as human voice - can be heard more clearly.
	Dolby AC3	Audio coding format developed by Dolby Laboratories in U.S, also simply referred as AC3 format: Supports 5-channel full-range sound and one channel for sub-woofer sound playback.
	DRC	Dynamic Range Control: Adjusting the audio range of maximum and minimum levels (dynamic range) will improve audio signal when, for example, dialog is hard to hear or user is watching movies late at night.
	DTS	Digital Theater System: Sound system as for movie theaters developed by US Digital Theater Systems, Inc. The number of channels provided by DTS is the same for Dolby AC3.
	DVD	Digital Versatile Disc. A huge amount of digital data for video (movie) and audio can be recorded on this disc, whose size is the same as CD.
	DVD-Audio	One type of DVD standard disc, on which high-quality audio can be recorded
	DVD-R	One type of DVD standard disc, to which writing once is possible (recordable type)
	DVD-RAM	One type of DVD standard disc, to which writing up to 100,000 times is possible
	DVD-RW	One type of DVD standard disc, to which writing up to 1000 times is possible
	DVD-Video	One type of DVD standard disc, on which high-quality video and audio can be recorded
	DVD Video Format	Video recording/playback standard that applies to DVD-Video, DVD-R and DVD-RW
DVD Video Recording Format	Video recording/playback standard that applies to DVD-RAM and DVD-RW: This allows versatile editing functions, differing from the DVD Video Format.	
I	I/P/B	DVD recorders normally use data that is common between images, and individually record different data for each image. I-picture: Images recorded independently for the reference of commonly used data. P-picture: Images created from past I-picture or P-picture B-picture: Images created from both I and P pictures, which interact between both types Since I-picture delivers the highest image quality, selecting I-picture is recommended when adjusting image quality.

Index	Abbreviation/Term	Explanation
J	JPEG	Joint Photographic Expert Group: International standard format for compressing still images.
M	MPEG	Moving Picture Experts Group: Standard related to compression of digital video and audio. MPEG2 is a higher standard of MPEG and is applied to video (movie) requiring higher quality.
	MPEG Audio Layer 2	One of three audio compression standards (layers 1-3) defined by MPEG
	MP3	MPEG1 Audio Layer-3: Audio data digital compression technology.
O	Optical digital audio output	Audio is usually converted to an electrical signal and transmitted from DVD to a device such as amp: When audio is converted to a digital signal, this optical digital audio output can be transmitted on optical fiber.
P	Pan & Scan/ Letterbox	Most DVD videos are produced assuming that they will be displayed on wide TV screen (aspect ratio of 16:9): If they are displayed on TV screens with 4:3 aspect ratio, 16:9 images will not quite fit on 4:3 screens. There are two ways of displaying 16:9 images on 4:3 TV: <ul style="list-style-type: none"> · Pan & Scan: Cuts out the left and right ends of images and displays them on whole screen. · Letterbox: Reproduces 16:9 images on 4:3 screens with black bands across the top and bottom of screen.
	Playback Control (PBC)	One format to play Video CD: User can select desired screens and data while watching the displayed menu screen.
	Progressive playback function	This function converts interlaced images to non-interlaced images and displays them. It can play back 24-frame/second images included in DVD movie software, etc.
S	S-Video Output	The video signal is separated into chrominance (C) and luminance (L) signals and transmitted to TV: This delivers clearer images.
	Sampling Frequency	Sampling slices audio waves (analog signal) at a specified time interval, and digitizes the levels of the sliced waves. The slicing number per second is referred to as the sampling frequency: The higher the number, the closer the sound to the original.
	SDMI	Secure Digital Music Initiative: This conference was established by hardware makers, the Recording Industry Association of America (RIAA) and music industry companies, to protect copyrights of musical compositions.
T	Tracking	To make adjustment for clearer playback image, by reducing noise that appears on screen during videotape playback.
V	Virtual surround	This technology localizes sound at any position using only two front speakers, by subjecting the L and R signals to matrix operation. It uses the four transfer functions from L/R speakers located at specified positions to both ears of listener located in a specified position, taking into account the shape of head and the effect of earlobes, and the two transfer functions from any position to both ears.
W	WMA	Windows Media Audio: Codec that was developed by Microsoft Corporation in USA.

3 Details of Servicing and Troubleshooting

3-1 Details of Servicing

3-1-1 Removing Disc from Faulty Recorder

If disc cannot be removed due to fault, disassemble the recorder and remove the disc by the following procedure:

- 1) Remove the top cover.
[See 4-2 (1) for removal procedure.]
- 2) Remove the front panel.
[See 4-2 (2) for removal procedure.]
- 3) Push the white component portion under the disc tray strongly, and the tray will come slightly forward.

Remove the disc tray in the direction of arrow B. Perform this work carefully, making sure that the disc is not scratched.




Fig. 3-1-1 Removing Disc

3-1-2 Removing Video Cassette from Faulty Recorder

If video cassette cannot be removed due to fault, disassemble the recorder and remove the video cassette by the following procedure:

- 1) Remove the top cover. [See 4-2 (1) for removal procedure.]
- 2) Remove the front panel. [See 4-2 (2) for removal procedure.]
- 3) Remove the deck mechanism. [See 4-2 (5) for removal procedure.]
- 4) Turn the worm gear of L/D motor assembly in the direction of arrow A: Unloading will start.

When the tape starts to slacken, turn the D37 clutch assembly on the front of deck mechanism in the direction of arrow B to remove the slack tape.

- 5) When unloading is complete, the deck mechanism will begin EJECT operation: Completely turn the worm gear of L/D motor assembly in the direction of arrow A.




Fig. 3-1-2 Removing Video Cassette

3-1-3 Firmware

The firmware is occasionally updated to improve performance.

Check whether a customer complaint can be solved by updating of firmware: If the complaint can be solved, update the firmware.

Information:

- 1) If any corrections in firmware are made at the factory, information on how to obtain the firmware data and create a disc containing upgraded firmware will be reported in technical bulletin, etc.
- 2) The main and drive firmware programs in this DVD recorder can be written to one CD-R and updated at the same time. It is also possible to write one firmware program to a CD-R and update it individually. Note that some parts of on-screen display will be different depending on the contents to be written to CD-R.

(1) Version check procedure

- 1) With the recorder turned on, make sure that no disc or tape is inserted.
- 2) Connect a monitor TV to the video output terminals on this DVD recorder.
- 3) Simultaneously hold down the REC ● and PLAY ► buttons on the front of this DVD recorder for approx. 10 seconds.
- 4) The firmware version screen will appear on the monitor TV.
- 5) Turn the recorder off to switch off the display.




Fig. 3-1-3

(2) Main/drive firmware simultaneous updating procedure

- 1) Write the main firmware data and drive firmware data to a CD-R.
- 2) Insert the firmware disc: The screen for verifying update will appear (Fig. 3-1-3).
- 3) Press the REC ● button on this DVD recorder three times: The Firmware Update screen will appear (Fig. 3-1-4).
- 4) Use the cursor buttons on remote control to choose "ALL", and then press the ENTER ● button.
- 5) The current version of drive firmware and the version of firmware on the disc will both appear on the screen. Pressing the REC ● button on this DVD recorder will start writing (Fig. 3-1-5).




Fig. 3-1-4

To cancel writing, press the OPEN/CLOSE ▲ button and remove the disc.

- 6) The main firmware version will then appear on the screen. Pressing the REC ● button on this DVD recorder will start writing (Fig. 3-1-6). To cancel writing, press the OPEN/CLOSE ▲ button and remove the disc.
- 7) When updating is complete, the tray will open automatically: Remove the disc.




Fig. 3-1-5

- 8) Turn the DVD recorder off and then on: The firmware is now updated.




Fig. 3-1-6

(3) Main firmware updating procedure

- 1) Write the main firmware data to a CD-R.
- 2) Insert the firmware disc: The screen for verifying update will appear (Fig. 3-1-7).
- 3) Press the REC ● button on this DVD recorder three times: Both the current version of main firmware and the version of main firmware on the disc will appear on the screen (Fig. 3-1-8).
- 4) Pressing the REC ● button on this DVD recorder will start writing (Fig. 3-1-8).

To cancel writing, press the OPEN/CLOSE ▲ button and remove the disc.

- 5) When updating is complete, the tray will open automatically: Remove the disc.
- 6) Turn the DVD recorder off and then on: The firmware is now updated.




Fig. 3-1-7




Fig. 3-1-8

(4) Drive firmware updating procedure

- 1) Write the drive firmware data to a CD-R.
- 2) Insert the firmware disc: The screen for verifying update will appear (Fig. 3-1-7).
- 3) Press the REC ● button on this DVD recorder three times: The data on disc will be read, the Firmware Update screen will appear, and the drive firmware version along with the version of drive firmware on the disc, will appear on the screen (Fig. 3-1-9).

When reading the data on disc is complete, the disc tray will open automatically: Remove the disc.

- 4) Press the REC ● button on this DVD recorder.
To cancel writing, press the OPEN/CLOSE ▲ button.
- 5) Turn the DVD recorder off and then on: The firmware is now updated.




Fig. 3-1-9

3-1-4 Setting to defaults at the factory


Perform the following procedure to reset this DVD recorder to the initial status when it was shipped from the factory (defaults):






- 1) Press the SETUP button on remote control and use the cursor ▲▼ buttons to choose the GENERAL menu.
- 2) Press the cursor ► button to move to the second level.
- 3) Use the cursor ▲▼ buttons to choose “Factory Set”, choose the SET icon, and then press the ENTER ● button.

3-2 Troubleshooting


3-2-1 Troubleshooting electronic system

(1) SMPS Circuit









(2) SYSTEM Circuit




Supplement: Automatic stop may occur when grease or oil in the mechanism block has dried up.





(3) Servo circuit







(4) VIDEO circuit







(5) AUDIO circuit









(6) TUNER circuit




3-2-2 Troubleshooting mechanical block

(1) Deck mechanism





(2) Front loading mechanism



4-1 Order of Disassembly

Refer to the Disassembly Flowchart in Fig. 4-1-1 for the order of removing components. When reassembling components, use the reverse order to removal unless otherwise specified.

Reading Disassembly Flowchart:

After locating the target component in the flowchart, remove all components of the target in sequence, following the arrows (routes) from the top of flowchart. If multiple routes exist to the target component from the top of flowchart, remove all the components on all the routes.




Fig. 4-1-1 Disassembly Flowchart

4-2 Cabinet Disassembly

Information:

Numbers in figures are step numbers in disassembly procedure, and letters in brackets [] show the types of screw.

(1) Top Cover

- 1) Remove the seven screws [A].
- 2) Slightly open both ends on the front side of top cover and lift the top cover in the direction of the arrow.




Fig. 4-2-1 Top cover

(2) Front Panel

- 1) Release three tabs (A), two tabs (B) and two tabs (C) in this order. (The tab (A) and the tab (C) should be released at the same time, respectively.)
- 2) Slowly move the front panel forward to remove it.

■ Caution when reassembling front panel:

Reattach the front panel while pushing the cassette door so that the cassette door open/close lever is positioned outside the door.




Fig. 4-2-2 Front Panel

(3) FAN Motor

- 1) Unplug the connector on SMPS P.C.B.
- 2) Remove two screws [B] from the rear panel.

■ Caution when reinstalling FAN motor:

Wind the cord of FAN motor around the cords on VDR P.C.B, as shown in the figure, to secure them.




Fig. 4-2-3 FAN Motor

(4) SMPS P.C.B

- 1) Remove the power cable form rear panel.
- 2) Unplug the five connectors on SMPS P.C.B.
- 3) Remove screw [C] on rear panel, three screws [D] and screw [E] on the SMPS P.C.B, and then lift the SMPS P.C.B block.
- 4) Remove four screws [F] that secure the heat sink, and then separate the SMPS P.C.B.

■ **Caution when reinstalling heat sink:**

Secure the heat sink, identified [Caution] in the figure, on the back of P.C.B, and make sure that a cushion is attached between the heat sink and P.C.B.




Fig. 4-2-4 SMPS P.C.B (1)




Fig. 4-2-5 SMPS P.C.B (2)

(5) Deck mechanism

- 1) Unplug the connector from A/C head.
- 2) Remove four screws [D] and two screws [E].
- 3) While unplugging the three direct connectors that connect the deck mechanism and VCR P.C.B, lift the entire deck mechanism straight up.




Fig. 4-2-6 Deck Mechanism

■ Caution when reinstalling deck mechanism:

Make sure of the following when reinstalling the deck mechanism:

- The mode switch (MS501) on VCR P.C.B is positioned as in the figure shown below.
- The drive gear on the back of deck mechanism is positioned as in the figure shown below.

While keeping the two positioning poles and guide LEDs aligned, assemble the deck mechanism at right angles: The boss of mode switch will fit into the hole in drive gear.




Fig. 4-2-7 Reassembling Deck Mechanism

(6) TIMER P.C.B

- 1) Remove the front holder.
- 2) Unplug the direct connectors from the VCR P.C.B.
- 3) Unplug the connector.

Information

Release the four stoppers of front holder: The TIMER P.C.B can be detached without removing the deck mechanism.




Fig. 4-2-8 TIMER P.C.B

(7) VCR P.C.B

- 1) Disconnect the two FFCs.
- 2) Remove four screws [C] from the rear panel.
- 3) Remove four screws [F] on the P.C.B.
- 4) Release the stopper.
- 5) Lift the entire VCR P.C.B, and then remove it in the direction of the arrow.

■ Caution when reinstalling VCR P.C.B:

Position the VCR P.C.B according to the positioning boss.




Fig. 4-2-9 VCR P.C.B

(8) DVD multi-drive

- 1) Unplug the connector on SMPS P.C.B.
- 2) Disconnect the FFC on the VDR P.C.B: Lift both sides of the connector up (a), tilt it in the direction of arrow (b) to release the stoppers, and then disconnect the FFC.
- 3) Remove four screws [G], and then slowly lift the DVD multi-drive.
- 4) Release the screws on both sides of the drive holder, and then remove the DVD multi-drive.




Fig. 4-2-10 DVD Multi Drive

(9) VDR, JACK and KEY P.C.Bs

■ VDR P.C.B

- 1) Unplug the connector and disconnect the two FFCs on the VDR P.C.B.
- 2) Remove five screws [F], and then remove the VDR P.C.B.

■ JACK P.C.B

- 3) Unplug the connector on JACK P.C.B.
- 4) Remove two screws [F], and then remove the JACK P.C.B.

■ KEY P.C.B

- 5) Remove screw [D], and then remove the KEY P.C.B.




Fig. 4-2-11 VDR P.C.B, JACK P.C.B, KEY P.C.B

4-3 Deck Mechanism Parts Locations




Fig. 4-3-1 Top View of Mechanism-1




Fig. 4-3-2 Top View of Mechanism-2




Fig. 4-3-3 Bottom View of Mechanism

Disassembly start no.	Item no.	Part name	Disassembly reference diagram
	1	Drum assembly	A-1
	2	Top plate	A-2
2	3	CST holder assembly	A-2
2,3	4	F/L rack gear assembly	A-2
2,3,4	5	Door opener	A-2
2,3,4,5	6	F/L arm assembly	A-2
	7	S/W lever assembly	A-2
	8	L/D motor assembly	A-3
	9	Wheel gear	A-3
	10	F/E head	A-3
	11	A/C head assembly	A-3
2,3	12	T brake assembly	A-4
2,3	13	Tension arm assembly	A-4
2,3,12,13	14	S reel/T reel	A-4
	15	P4 base assembly	A-5
	16	Lid opener	A-5
16	17	Pressure arm assembly	A-5
16	18	Take-up arm	A-5
	19	Capstan supporter	A-6
16,17	20	Capstan belt, Capstan motor	A-6
	21	F/R lever	A-6
20,21	22	D37 clutch assembly	A-6
	23	Drive gear/cam gear	A-7
	24	Sector gear	A-7
20	25	Capstan brake assembly	A-7
20,21,22, 23,24,25	26	Slider plate	A-7
20,21,22, 23,24,25,26	27	Tension lever	A-7
20,21,22, 23,24,25,26	28	Spring lever	A-7
20,21,22, 23,24,25,26	29	Brake lever	A-7
24	30	P2 gear assembly/ P3 gear assembly	A-8
2,3,13, 24,30	31	P2 base assembly/ P3 base assembly	A-8
24,30	32	Loading base	A-8
2,3,13	33	Tension base	A-9
	34	Jog idler arm assembly	A-9

Information

Use the reverse procedure to removal when reinstalling components.

4-4 Deck Mechanism Disassembly

(1) Drum assembly (Fig. A-1)

- 1) Disconnect the flat cable between the drum assembly and capstan motor.
- 2) Remove three screws (S1), and then remove the drum assembly upward.
- 3) Release hooks (H1, H2) only if necessary, and then separate the FPC holder and FPC cap.





Fig. A-1 Drum Ass'y

(2) Top plate (Fig. A-2-1)

- 1) Use a flat-bladed screwdriver, etc. to release portion (B) at the right of top plate in the direction of the arrow.
- 2) Use the same procedure to release portion (B') at the left of top plate in the direction of the arrow.

Note:

When reinstalling the top plate, align portions (C) and (C').




(3) CST holder assembly (Fig. A-2-2)

- 1) Move the CST holder assembly in the direction of arrow (D) to release the CST holder assembly from the slit in chassis.
- 2) Also release the CST holder assembly from the right slit in chassis.

Note:

When reinstalling, first insert portion (E) of the CST holder assembly into the slit in chassis, and then fit the remaining bosses into the slits in chassis in sequence.




(4) F/L rack gear assembly (Fig. A-2-3)

- 1) Release hook (H3), and then slide the F/L rack gear assembly in the direction of arrow (A) to remove it.

Note:

When reinstalling the F/L rack gear assembly, assemble the drive gear and F/L rack gear as shown in the figure.



(5) Door opener (Fig. A-2-4)

- 1) Turn the door opener clockwise to release it from the guide hole in chassis.

(6) F/L arm assembly (Fig. A-2-5)


- 1) Turn the left side of F/L arm assembly in the direction of the arrow to release it from the slit in chassis.

(7) S/W lever assembly (Fig. A-2-6)

- 1) Release hook (H4) and push it in the direction of the arrow to remove the S/W lever.

Note:

Take care not to lose the spring attached to the S/W lever assembly.






Fig. A-2 Top Plate, CST Holder Ass'y, F/L Rack Gear Ass'y, Door Opener, F/L Arm Ass'y, S/W Lever Ass'y

(8) L/D motor assembly (Fig. A-3-1)

- 1) Unplug connector (C1).
- 2) Remove screw (S4), and then remove the L/D motor assembly.

(10) F/E head (Fig. A-3-3)

- 1) Turn the entire E/F head in the direction of arrow (A) to release its engagement with chassis.

(9) Wheel gear (Fig. A-3-2)

- 1) Release hook (H5) of wheel gear shaft, and then lift the wheel gear.

(11) A/C head assembly (Fig. A-3-4)

- 1) Remove screw (S5), and then lift the A/C head assembly.




Fig. A-3 L/D Motor Ass'y, Wheel Gear, F/E Head, A/C Head Ass'y

(12) T brake assembly (Fig. A-4-1)

- 1) Release the tension spring from hook (H6) of chassis.
- 2) Turn the T brake arm counterclockwise to release its engagement with chassis, and then lift it.

(13) Tension arm assembly (Fig. A-4-2)

- 1) Release the tension spring from hook (H7) of spring lever.
- 2) Release hook (H8) of tension base, and then lift the tension arm assembly.

(14) S reel and T reel (Fig. A-4-3)

- 1) Lift the S reel and T reel.
Take care during reassembly that the S reel and T reel are not reversed.





Fig. A-4 T Brake Ass'y, Tension Arm Ass'y, S reel, T reel

(15) P4 base assembly (Fig. A-5-1)

- 1) Release portion (A) of the P4 base assembly from the boss of chassis.
- 2) Turn the P4 base assembly in the direction of the arrow to release its engagement with chassis.

(16) Lid opener (Fig. A-5-2)

- 1) Release portion (B) of the lid opener from the boss of chassis.
- 2) Turn the lid opener in the direction of the arrow to release its engagement with chassis.

(17) Pressure arm assembly (Fig. A-5-3)

- 1) Lift the pressure arm assembly.

Note:

A spring is attached between the pressure arm assembly and chassis: Take care not to lose it. When reinstalling the pressure arm assembly, make sure that you insert the boss at portion (C) of pressure arm assembly into the slit in cam gear at the back of chassis.

(18) Take-up arm (Fig. A-5-4)

- 1) Lift the take-up arm to release it from hook (H9) of chassis.

Note:

When reinstalling the take-up arm, make sure that you insert the boss at portion (D) of take-up arm into the slit in cam gear at the back of chassis.




Fig. A-5 P4 Base Ass'y, Lid Opener, Pressure Arm Ass'y, Take-up Arm

(19) Capstan supporter (Fig. A-6-1)

- 1) Use a Philips (+) screwdriver to turn the capstan supporter 90° clockwise and release it from the chassis.

(20) Capstan belt (Fig. A-6-2) and capstan motor (Fig. A-6-3)

- 1) Remove the capstan belt.
- 2) Remove three screws (S6), and then lift the capstan motor.

(21) F/R lever (Fig. A-6-4)

- 1) Release lock tab (L1) in the direction of the arrow, and then lift the F/R lever.

(22) D37 clutch assembly (Fig. A-6-5)

- 1) Remove washer (W1), and then lift the D37 clutch assembly.




Fig. A-6 Capstan Supporter, Capstan Belt, Capstan Motor, F/R Lever, D37 Clutch Ass'y

(23) Driver gear (Fig. A-7-1) and cam gear (Fig. A-7-2)

- 1) Remove washer (W2), and then lift the drive gear.
- 2) Release hook (H10) of the cam gear shaft, and then lift the cam gear.

Note:

Align these positions of gears during reassembly:

- 1) Align hole (A) in drive gear and hole (B) in cam gear.
- 2) Align hole (C) in cam gear and the hole in chassis.

(24) Sector gear (Fig. A-7-3)

- 1) Release hook (H11) of sector gear, and then lift the sector gear.

(25) Capstan brake assembly (Fig. A-7-4)

- 1) Release lock tab (L2) from the surface of chassis, and then lift the capstan brake.

(26) Slider plate (Fig. A-7-5)

- 1) Release the engagement with chassis, and then lift the slider plate.

(27) Tension lever (Fig. A-7-6)

- 1) Turn the tension lever counterclockwise to release it from guide (A) of chassis.

(28) Spring lever (Fig. A-7-7)

- 1) Turn the spring lever in the direction of the arrow to release portion (B) from the guide of chassis.

(29) Brake lever (Fig. A-7-8)

- 1) Lift the brake lever.

Note:

When reinstalling the sector gear and slider plate, perform the position alignment shown in the figure on next page.




Fig. A-7 Drive Gear, Cam Gear, Sector Gear, Capstan Brake Ass'y, Slider Plate, Tension Lever, Spring Lever, Brake Lever

(30) P2 gear assembly (Fig. A-8-1) and P3 gear assembly (Fig. A-8-2)

- 1) Lift the P3 gear assembly.
- 2) Lift the P2 gear assembly.

Note:

When reinstalling the P2 and P3 gear assemblies, be sure to align the holes in them.

(31) P2 base assembly (Fig. A-8-3) and P3 base assembly (Fig. A-8-4)

- 1) Slide the P2 base assembly in the direction of arrow (A) to release it from the guide hole in chassis.
- 2) Slide the P3 base assembly in the direction of arrow (B) to release it from the guide hole in chassis.

(32) Loading base (Fig. A-8-5)

- 1) Release three hooks (H12, H13, H14), and then lift the loading base.




Fig. A-8 P2 Gear Ass'y, P3 Gear Ass'y, P2 Base Ass'y, P3 Base Ass'y, Loading Base

(33) Tension base (Fig. A-9-1)

- 1) Release portion (A) of tension base from the boss of chassis.
- 2) Turn the tension base in the direction of the arrow to release its engagement with chassis.

(34) Jog idler arm assembly (Fig. A-9-2)

- 1) Hold portions (B) and (C) of jog idler arm assembly on both sides, and then remove the arm assembly.

Note:

Take care that portion (D) does not strike the chassis during disassembly.




Fig. A-9 Tension Base, Jog Idler Arm Ass'y

4-5 Checking Mode after Reassembling Deck Mechanism

After disassembling the deck mechanism, check the positions of the following gears when reassembling it: If the positions of gears drift, the deck mechanism will not operate normally. Turn the cam gear with the L/D motor assembly removed, and make sure that loading and unloading are performed normally.

- 1) Make sure that hole (A') in chassis on the surface of deck mechanism is aligned with hole (A) in cam gear: If they are not aligned, remove the L/D motor assembly, and then turn the cam gear until the holes are aligned.
- 2) Make sure that the small hole in cam gear on the back of deck mechanism is aligned with hole (B) in drive gear: If they are not aligned, remove the drive gear, align their positions, and then reassemble the gears.




Fig. 4-5-1 Cam Gear Position Alignment




Fig. 4-5-2 Drive Gear Position Alignment

5-1 Set-up for Adjustment

(1) Test equipment necessary for adjustment

- 1) Dual-trace oscilloscope
- 2) Color bar generator
- 3) Monitor TV
- 4) Blank tape (VHS)

(2) Connections of test equipment







Connect the equipment as follows when otherwise not specified.

- 1) Connect a color bar generator to the video input jack.
- 2) Connect a monitor TV to the EURO AV1 AUDIO/VIDEO jack.

(3) Cautions on adjustment

- 1) The following conditions apply when otherwise not specified.
 Probe of oscilloscope: 10:1
 Synchronization of oscilloscope: Internal sync
- 2) When performing more than one adjustment, follow the specified order.

(4) List of Adjustment jigs

<p>Alignment tape</p> 	<p>Cassett Torque Meter (SRK-VHT-303)</p> 	<p>Torque Gauge (600 g/cm)</p> 
<p>Torque Gauge Adaptor</p> 	<p>Guide roller screwdriver Parts No. 7069064</p> 	<p>Philips (+) screwdriver</p> 

5-2 VCR Electrical Adjustment

5-2-1 Head switching adjustment

(1) Supplement

- If the SYSTEM microprocessor (IC501) or EEPROM (IC503) on VCR P.C.B is replaced, be sure to perform the head switching adjustment.
- If the drum assembly is replaced, be sure to perform the X-value adjustment and head switching adjustment.

(2) Adjustment method

- 1) Connect oscilloscope CH-1 to the H/SW terminal on VCR P.C.B, and CH-2 to the VCR VIDEO terminal on VDR P.C.B.
- 2) Use CH-1 (H/SW) to trigger the oscilloscope.
- 3) Play back the alignment tape.
- 4) Play back the tape for approx. 3 seconds, while simultaneously holding down the REC ● and PLAY ► buttons on recorder for several seconds (FL display: --).
- 5) Simultaneously hold down the REC ● and PLAY ► buttons on recorder for several seconds again: The adjustment will automatically start.
When the adjustment is complete, "PG" will appear in the FL display.
- 6) Observe the waveforms on oscilloscope, and make sure that the phase from the vertical sync signal to the leading edge (trigger position) of H/SW pulse is $6.5H \pm 0.5H$.




Fig. 5-2-1 Connection Diagram




Fig. 5-2-2 Waveform Diagram

5-3 Deck Mechanism Tape Transport System Adjustment

The tape transport components were precisely adjusted before the recorder was shipped from the factory. They do not need to be adjusted except for the following cases:

- 1) Noise appears on the screen during playback.
- 2) Tape is damaged.
- 3) Any of the tape transport components is replaced

If any of the above occurs, or if any of the tape transport components is replaced, first run a E-240 tape and make sure that excessive tape wrinkling does not occur at the P2/P3 guide rollers, tape run guideline on lower drum, A/C head or P4 guide post.

- ◆ If tape wrinkling occurs at the P2/P3 guide rollers or tape run guideline on lower drum assembly, turn the height adjustment screws of P2/P3 guide rollers until wrinkling is eliminated
See “5-3-1 Guide roller height adjustment”.
- ◆ If tape wrinkling occurs at the post of P4 base assembly, perform the A/C head height and tilt adjustments.
See “5-3-2 A/C head adjustment”.

5-3-1 Guide roller height adjustment

(1) Rough adjustment

- 1) Run a E-240 blank tape, and check the tape run guideline on lower drum.
- 2) If the tape rides under the tape run guideline, turn the guide roller height adjustment screw to the left to adjust.
- 3) If the tape is above the tape run guideline, turn the guide roller height adjustment screw to the right to adjust.

(2) Fine adjustment

- 1) Connect oscilloscope CH-1 to the H/SW terminal on VCR P.C.B, and CH-2 to the RF terminal.
- 2) Use CH-1 (H/SW) to trigger the oscilloscope.
- 3) Play back the alignment tape.
(If the drum assembly is replaced, adjust the tracking so that the FM output is maximal.)
- 4) Finely adjust the guide roller height adjustment screw so that the supply and take-up portions of RF envelope are flat.
- 5) Move the tracking in both directions, and make sure that the FM envelope waveform drops evenly.




Fig. 5-3-1 P2/P3 Guide Roller Height Adjustment Screws




Fig. 5-3-2 Guide Roller Fine Adjustment

5-3-2 A/C head adjustment

(1) Rough adjustment (height adjustment and tilt adjustment)

(Play back the alignment tape: Perform this adjustment only if no audio signal is output.)

- 1) Make sure that the A/C head base assembly satisfies the specifications in Fig. 5-3-3(a).
- 2) Run a E-240 blank tape and make sure that no curling or wrinkling of tape occurs at the lower flange of P4 guide post [see Fig. 5-3-3(c)].
- 3) If curling or wrinkling occurs, slowly turn tilt adjustment screw (C) to precisely adjust [see Fig. 5-3-3(b)].
- 4) Finely adjust height adjustment screw (B) and tilt adjustment screw (C) so that the lower edge of tape is positioned at the bottom of control head as shown in Fig. 5-3-3(c).





Fig. 5-3-3 A/C Head Rough Adjustment

(2) Tape transport check between P4 guide post and pressure roller

- 1) Play back a tape recorded in SP mode.
- 2) Set to the reverse playback mode, and make sure that no curling or wrinkling of tape occurs between the P4 guide post and pressure roller.

If curling or wrinkling occurs, slowly turn tilt adjustment screw (C) to precisely adjust [see Fig. 5-3-3(b)].

(3) Fine adjustment (azimuth adjustment)

- 1) Play back the alignment tape.
- 2) Observe the audio output waveform on oscilloscope.
- 3) Finely adjust azimuth adjustment screw (A) so that the audio output level is maximal at the 1 kHz and 7 kHz audio signals of alignment tape.




Fig. 5-3-4 A/C Head Fine Adjustment

5-3-3 X-value adjustment

- 1) Connect oscilloscope CH-1 to the H/SW terminal on VCR P.C.B, and CH-2 to the RF terminal.
- 2) Use CH-1 (H/SW) to trigger the oscilloscope.
- 3) Play back the color-bar portion of alignment tape, and activate auto tracking.
- 4) Slightly loosen the screw that secures the A/C head (do not loosen excessively).
- 5) Insert a ϕ 3-4 Philips (+) screwdriver into the hole in chassis of X-value adjustment mechanical block, tilt the screwdriver to the left and right until the CH-2 FM ENV output is maximal.
- 6) Tighten the securing screw.




Fig. 5-3-5 X-Value Adjustment

5-3-4 Adjustments after replacing drum assembly

After replacing the drum assembly, check and adjust the following:

- 1) Guide roller height adjustment
- 2) X-value adjustment
- 3) Head switching adjustment

5-3-5 Check after adjustment

(1) FM output check when switching from VCR search to playback

Press the playback button during VCR search, and make sure that the appropriate amplitudes of FM envelope and audio outputs can be obtained within the specified time.

- 1) Connect oscilloscope CH-1 to the FM ENV terminal on VCR P.C.B, and CH-2 to the audio output terminal.
- 2) Play back the alignment tape.
- 3) Observe the waveforms on oscilloscope: Measure the times until the appropriate amplitudes are obtained when the playback button is pressed during reverse search.

Specifications: FM envelope within 5 seconds; audio output within 10 seconds

- 4) Press the playback button during forward search, and measure the times in the same way.
- 5) If the specifications are not satisfied, perform the following adjustments again:
 - A/C head adjustment
 - X-value adjustment

(2) Tape curling/wrinkling check

- 1) Run an E-240 tape, and make sure that no curling or wrinkling occurs at the start, middle or end of tape.
- 2) If curling or wrinkling occurs, perform the following adjustments again:
 - Guide roller height adjustment
 - A/C head adjustment

5-3-6 Method of setting the mechanism to loading status without inserting tape

- 1) Unplug the power cord from AC outlet.
- 2) Remove the top cover and front panel.
- 3) Use black masking tape, etc. to shield light from the end sensors on both sides.
- 4) Plug the power cord into AC outlet to power the recorder.
- 5) While pressing the stop lever of CST holder assembly, load the CST holder assembly (it will automatically load midway).
- 6) When the CST holder assembly descends to chassis, the cylinder will rotate, and the P2/P3 base assemblies will operate in the loading status to go to stand by.


This status will allow you to input each mode. However, when rewind is performed, the power will turn off in a few seconds, since the take-up reel is in the stop status and no reel pulse can be detected.

Therefore, for rewind operation, manually rotate the take-up reel.

5-3-7 Reel torques

(1) Preparations when using a torque gauge

- 1) Set the recorder to the loading status, referring to “5-3-6 Method of setting the mechanism to loading status without inserting tape”.
- 2) Assemble the torque gauge adaptor and torque gauge, and place them on reel.



- 3) Check the torque values in the following operation modes:

Item	Operation mode	Gauge	Measured reel	Torque value
Fast forward torque	Fast forward	Torque gauge	Take-up	At least 400 g/cm
Rewind torque	Rewind	Torque gauge	Supply	At least 400 g/cm
Playback torque	Playback	Torque meter	Take-up	40-100 g/cm
Reverse search torque	Reverse search	Torque meter	Supply	120-210 g/cm

5-4 Maintenance

5-4-1 Maintenance and inspection

The deck mechanism uses very precise components to ensure the compatibility between VCR models: If any of the mechanical components are dirty or the performance is degraded, the symptoms will be similar to those when the mechanism is faulty.

For clear images, it is necessary to periodically clean and lubricate the mechanism and replace any faulty components.

(1) Reference for maintenance and inspection

The time for maintenance and inspection depends on the environment and the way the VCR is used: For ordinary home use, maintenance and inspection every 1,000 hours will ensure clear images.

Time used per day	Period for reaching 1,000 hours
Approx. 1 hour	Approx. 3 years
Approx. 2 hours	Approx. 1.5 years
Approx. 3 hours	Approx. 1 year

(2) Items necessary for maintenance and inspection

- 1) Head cleaning kit
- 2) Oil and grease for maintenance
- 3) Alcohol
- 4) Cleaning cloth

(3) Cleaning video heads

It is recommended that you use a generally available cleaning tape to clean the heads.

If noise cannot be removed completely with a cleaning tape, use a cleaning cloth to clean the heads and transport system.

[Cleaning method using cleaning tape]

Play back the cleaning tape in the same way as an ordinary tape for approx. 30 seconds.

[Cleaning method using cleaning cloth]

- 1) Lightly fit the cleaning cloth to the head, and turn the rotating cylinder gently to the left and right. Turn the rotating cylinder one turn to also clean its outer circumference. (Cleaning with cleaning cloth moistened with alcohol is more effective.)
- 2) Do not use a cleaning cloth to which oil adheres or a dirty one.




Fig. 5-4-1 Cleaning Method using Cleaning Cloth

(4) Problem guide

If the time of using the VCR exceeds approx. 1,000 hours, the phenomena shown in Table 5-4-1 may appear on playback images. These phenomena may disappear when the mechanical components are cleaned or lubricated. Check the use time, etc., and if judged that it is time for maintenance and inspection, inspect the portions to be checked according to Table 5-4-1.

Note:

If normal operation is not restored after cleaning, the components marked ○ in component replacement column probably need to be replaced, since their performance may be degraded.

Table 5-4-1 List of phenomena

Phenomenon	Cause	Portions to be checked	Component replacement	Component
Color beats	Dirt on F/E head	Clean part of F/E head where tape is in contact	○	(a)
Poor S/N, no color	Dirt on video heads	Clean video heads	○	(b)
Vertical jitter, horizontal jitter	Dirt on video heads (drum), tape transport system	Clean video heads (drum) and tape transport system.	○	(b)
Low volume, sound distortion	Dirt on A/C head	Clean part of A/C head where tape is in contact	○	(c)
Tape twisted	Dirt on pressure roller, capstan belt	Clean pressure roller and capstan shaft. Check capstan belt.	○	(d)
				(e)
No tape run, slack tape	Insufficient torque of D37 clutch assembly	Check torque of D37 clutch assembly	○	(f)
	Dirt on video heads (drum), tape transport system	Clean and check tape transport system.	○	




Fig. 5-4-2 Locations of Components to Be Checked

5-4-2 Lubricating oil and greasing

(1) Greasing procedure

Coat components with an appropriate amount of grease applied to a rod or brush. Take care that excessive grease does not adhere to tape transport system or drive system. If there is too much grease on them, use gauze moistened with alcohol to wipe it off. Periodically grease components with a reference of 500-hour use.

(2) Greases to be used

- KG-684G (green)
- PL-433 (yellow)

(3) Lubricating/coating locations

P2/P3 guide tape run portions




Fig. 5-4-3 Chassis




Fig. 5-4-4 Mechanical Components


6

Exploded View and Parts List


6-1 Exploded Views

6-1-1 Cabinet Section


Note: Components without any numbers in exploded views were not assigned as service parts as of the date of issue of this manual.




6-1-2 F / L Mechanism Section



6-1-3 Deck Mechanism Section - Top view



6-1-4 Deck Mechanism Section - Bottom view



**THE UPDATED PARTS LIST
FOR THIS MODEL IS
AVAILABLE ON ESTA**

S Schematic, Wiring Diagrams


S-1 Wiring Diagram

For schematic diagram
- Resistors are in ohms, 1/8W unless otherwise noted.


Special note :
Most semiconductor devices are electrostatically sensitive and therefore require the special handling techniques described under the "Electrostatic Protection Measures" section of this service manual.

Note :
Do not use the part number shown on this drawing for ordering. The correct part number is shown in the parts list (may be slightly different or amended since this drawing was prepared).


Important safety notices :
Components identified with the mark \triangle have the special characteristics for safety. When replacing any of these components. Use only the same type.




S-2 S.M.P.S Schematic Diagram




S-3 SYSTEM Schematic Diagram (VCR P.C.B)




S-4 TUNER Schematic Diagram (VCR P.C.B)




S-5 A/V Schematic Diagram (VCR P.C.B)



S-6 Hi-Fi Schematic Diagram (VCR P.C.B)





S-7 REAR JACK Schematic Diagram (VCR P.C.B)



- SCART Pin connection
1. Audio Output2(R)
 2. Audio Input2(R)
 3. Audio Output1(L)
 4. Audio Earth
 5. Blue Earth
 6. Audio Input1(L)
 7. Blue Signal
 8. Red Earth
 9. Green Earth
 10. Data 2
 11. Green Signal
 12. Data 1
 13. Red Earth
 14. Data Earth
 15. Red Signal
 16. Blanking Signal
 17. Video Earth
 18. Blanking Signal Earth
 19. Video Output
 20. Video Input
 21. Plug Screen Earth

S-8 TIMER Schematic Diagram, KEY Schematic Diagram









To VDR PN302

TPB-	15
TPB+	14
D_GND	13
TPA-	12
TPA+	11
D_GND	10
Y_IN	9
C_IN	8
A_GND	7
A3_R_IN	6
A3_L_IN	5
A_GND	4
S_JACK_DET	3
V3_IN	2
A_GND	1
PN7605	

JK765	
1	TPB-
2	TPA-
3	TPA+
4	TPB+
5	GND
6	GND
7	GND
8	GND


DV IN




AV3

S-10 A/V, SYSTEM Circuit Waveforms

IC301 (A/V)




IC501 (SYSTEM)



CONDUCTOR SIDE


LOCATION GUIDE

IC301	I8
IC501	M10



C-2 S.M.P.S Circuit Board Diagram


CONDUCTOR SIDE




LOCATION GUIDE

BC101	E4	C152	K2	L101	B2	R135	J4
BC102	E2	C153	L4	L102	B3	R136	I4
BC103	D6	C154	K2	L121	H5	R137	K4
BC104	E1	C155	J1	L122	H4	R138	K4
BD101	C3	C156	L4	L123	H3	R139	I5
C101	B4	C157	K4	L125	G3	R140	I4
C102	B2	D101	E4	L127	I1	R141	K4
C103	C4	D102	D5	P101	J5	R142	J4
C105	D4	D103	D2	P102	L3	R143	J4
C106	E4	D104	E3	P103	K1	R144	J4
C108	D5	D121	G5	P104	K1	R145	J4
C110	A2	D122	G3	PW101	B5	R146	G5
C111	C5	D123	G2	Q120	I4	R147	H4
C112	D5	D124	G2	Q121	J4	R148	G4
C114	D3	D125	G1	Q122	J4	R149	L3
C115	D2	D126	G4	Q123	J4	R150	L4
C116	E2	D127	F3	Q124	I4	R151	I2
C117	D3	D128	G3	Q125	K3	R154	J3
C119	C2	D129	G4	Q126	L4	R155	K1
C120	C4	D130	F5	R100	B4	R156	J2
C121	E6	D132	K4	R103	D3	R157	J2
C122	G5	D133	K4	R105	E5	R159	I2
C123	G3	D134	J4	R107	G3	R160	I3
C124	H5	D151	H3	R109	D5	R161	H3
C125	I3	D153	J2	R112	D2	R162	G3
C126	H2	D155	K4	R113	E2	R163	G3
C128	H4	FH01	A5	R114	D3	R167	I2
C129	G2	FH02	A4	R115	D2	R168	J2
C130	H4	IC101	D4	R121	E5	R169	J3
C131	G3	IC102	E6	R122	E5	T101	E4
C132	H4	IC103	E6	R123	E6	T102	E2
C133	K3	IC104	D2	R124	E5	TH01	C3
C134	J4	IC105	F3	R125	E5	V101	B5
C135	I4	IC106	G3	R126	F6	ZD101	C4
C136	G4	IC151	H2	R127	I5	ZD102	C2
C137	G4	IC152	K2	R128	K3	ZD103	L3
C139	H1	IC154	I3	R129	K3	ZD104	C5
C140	I1	IC157	J1	R130	I3	ZD105	C3
C141	F3	IC160	I2	R131	H3	ZD151	G3
C142	F4	J101	B3	R132	F3	ZD152	L4
C150	L2	J102	B2	R133	F3	ZD153	I4
C151	K2	J103	J2	R134	J4		


C-3 JACK Circuit Board Diagram, C-4 TIMER Circuit Board Diagram, C-5 KEY Circuit Board Diagram



C-3 JACK Circuit Board Diagram




C-5 KEY Circuit Board Diagram




C-4 TIMER Circuit Board Diagram

COMPONENT SIDE




CONDUCTOR SIDE




B Block Diagrams

B-1 S.M.P.S Circuit Block Diagram




B-2 VIDEO Circuit Block Diagram

1) PB MODE




2) REC MODE




B-3 AUDIO Circuit Block Diagram


F 1) LINEAR AUDIO PB MOD




3) Hi-Fi AUDIO PB MODE




C 2) LINEAR AUDIO REC MOD




4) Hi-Fi AUDIO REC MODE



B-4 SYSTEM Circuit Block Diagram



B-5 VIDEO I/O Circuit Block Diagram



HITACHI

Hitachi, Ltd. Tokyo, Japan
International Sales Division
THE HITACHI ATAGO BUILDING,
No. 15-12 Nishi Shinbashi, 2 - Chome,
Minato - Ku, Tokyo 105-8430, Japan.
Tel: 03 35022111

HITACHI EUROPE LTD,

Whitebrook Park
Lower Cookham Road
Maidenhead
Berkshire
SL6 8YA

UNITED KINGDOM

Tel: 01628 643000
Fax: 01628 643400
Email: consumer-service@hitachi-eu.com

HITACHI EUROPE S.A.

364 Kifissias Ave. & 1, Delfon Str.
152 33 Chalandri
Athens

GREECE

Tel: 1-6837200
Fax: 1-6835964
Email: service.hellas@hitachi-eu.com

HITACHI EUROPE GmbH

Munich Office
Dornacher Strasse 3
D-85622 Feldkirchen bei München

GERMANY

Tel: +49-89-991 80-0
Fax: +49-89-991 80-224
Hotline: +49-180-551 25 51 (12ct/min)
Email: HSE-DUS.service@hitachi-eu.com

HITACHI EUROPE S.A.

Gran Via Carlos III, 86, planta 5
Edificios Trade - Torre Este
08028 Barcelona

SPAIN

Tel: +34 93 409 2550
Fax: +34 93 491 3513
Email: atencion.cliente@hitachi-eu.com

HITACHI EUROPE srl

Via Tommaso Gulli N.39, 20147
Milano, Italia

ITALY

Tel: +39 02 487861
Tel: +39 02 38073415 Servizio Clienti
Fax: +39 02 48786381/2
Email: customerservice.italy@hitachi-eu.com

HITACHI Europe AB

Box 77 S-164 94 Kista

SWEDEN

Tel: +46 (0) 8 562 711 00
Fax: +46 (0) 8 562 711 13
Email: csgswe@hitachi-eu.com

HITACHI EUROPE S.A.S

Lyon Office
B.P. 45, 69671 BRON CEDEX

FRANCE

Tel: +33 04 72 14 29 70
Fax: +33 04 72 14 29 99
Email: france.consommateur@hitachi-eu.com

HITACHI EUROPE LTD (Norway) AB

STRANDVEIEN 18

1366 Lysaker

NORWAY

Tel: 67 5190 30
Fax: 67 5190 32
Email: csgnor@hitachi-eu.com

HITACH EUROPE AB

Egebækgård
Egebækvej 98
DK-2850 Nærum

DENMARK

Tel: +45 43 43 6050
Fax: +45 43 60 51
Email: csgnor@hitachi-eu.com

HITACHI EUROPE AB

Neopoli / Niemenkatu 73
FIN-15140 Lahti

FINLAND

Tel : +358 3 8858 271
Fax: +358 3 8858 272
Email: csgnor@hitachi-eu.com

Hitachi Europe Ltd

Bergensesteenweg 421
1600 Sint-Pieters-Leeuw

BELGIUM

Tel: +32 2 363 99 01
Fax: +32 2 363 99 00
Email: sofie.van.bom@hitachi-eu.com

HITACHI EUROPE LTD

Na Sychrove 975/8
101 27 Praha 10 - Bohdalec

CZECH REPUBLIC

Tel: +420 267 212 383
Fax: +420 267 212 385
Email: csgnor@hitachi-eu.com