


JVC

SERVICE MANUAL

COMPACT COMPONENT SYSTEM

CA-D701T

PICK UP	OPT-150S
LSI	MN35510



Area Suffix

A	Australia
BS	The U.K.
EF	Continental Europe Except Germany & Italy
EN	Nordic Countries
G	Germany
VX	Eastern Europe
UB	Hong Kong
UP	Korea
US	Singapore
UT	Taiwan
U	Universal Except All of Above

Contents

Safety Precautions	1-2	Flow of Functional Operation	
Important for Laser Products	1-3	Until TOC is Read	2-45
Instruction Book	1-4	Maintenance of Laser Pickup	2-46
Description of Major LSIs	2-1	Replacement of Laser Pickup	2-46
Internal Connection of FL Display Tube	2-20	Block Diagrams	2-47
Disassembly Procedures	2-22	Schematic Diagrams	2-49
Adjustment Procedures	2-41	Printed Circuit Boards	2-59
		Parts List	3-1

COMPACT
disc
DIGITAL AUDIO

Safety Precautions

1. The design of this product contains special hardware and many circuits and components specially for safety purposes. For continued protection, no changes should be made to the original design unless authorized in writing by the manufacturer. Replacement parts must be identical to those used in the original circuits. Services should be performed by qualified personnel only.
2. Alterations of the design or circuitry of the product should not be made. Any design alterations of the product should not be made. Any design alterations or additions will void the manufacturer's warranty and will further relieve the manufacture of responsibility for personal injury or property damage resulting therefrom.
3. Many electrical and mechanical parts in the products have special safety-related characteristics. These characteristics are often not evident from visual inspection nor can the protection afforded by them necessarily be obtained by using replacement components rated for higher voltage, wattage, etc. Replacement parts which have these special safety characteristics are identified in the Parts List of Service Manual. Electrical components having such features are identified by shading on the schematics and by (Δ) on the Parts List in the Service Manual. The use of a substitute replacement which does not have the same safety characteristics as the recommended replacement parts shown in the Parts List of Service Manual may create shock, fire, or other hazards.
4. The leads in the products are routed and dressed with ties, clamps, tubings, barriers and the like to be separated from live parts, high temperature parts, moving parts and/or sharp edges for the prevention of electric shock and fire hazard. When service is required, the original lead routing and dress should be observed, and it should be confirmed that they have been returned to normal, after re-assembling.
5. Leakage current check (Electrical shock hazard testing)
After re-assembling the product, always perform an isolation check on the exposed metal parts of the product (antenna terminals, knobs, metal cabinet, screw heads, headphone jack, control shafts, etc.) to be sure the product is safe to operate without danger of electrical shock.
Do not use a line isolation transformer during this check.

- Plug the AC line cord directly into the AC outlet. Using a "Leakage Current Tester", measure the leakage current from each exposed metal parts of the cabinet, particularly any exposed metal part having a return path to the chassis, to a known good earth ground. Any leakage current must not exceed 0.5mA AC (r.m.s.).


- Alternate check method

Plug the AC line cord directly into the AC outlet. Use an AC voltmeter having, 1,000 ohms per volt or more sensitivity in the following manner. Connect a 1,500 Ω 10 W resistor paralleled by a 0.15 μ F AC-type capacitor between an exposed metal part and a known good earth ground.

Measure the AC voltage across the resistor with the AC voltmeter.

Move the resistor connection to each exposed metal part, particularly any exposed metal part having a return path to the chassis, and measure the AC voltage across the resistor.

Now, reverse the plug in the AC outlet and repeat each measurement. Any voltage measured must not exceed 0.75 V AC (r.m.s.). This corresponds to 0.5 mA AC (r.m.s.).



Warning

1. This equipment has been designed and manufactured to meet international safety standards.
2. It is the legal responsibility of the repairer to ensure that these safety standards are maintained.
3. Repairs must be made in accordance with the relevant safety standards.
4. It is essential that safety critical components are replaced by approved parts.
5. If mains voltage selector is provided, check setting for local voltage.

Important for Laser Products

1. **CLASS 1 LASER PRODUCT**
2. **DANGER** : Invisible laser radiation when open and interlock failed or defeated. Avoid direct exposure to beam.
3. **CAUTION** : There are no serviceable parts inside the Laser Unit. Do not disassemble the Laser Unit. Replace the complete Laser Unit if it malfunctions.
4. **CAUTION** : The compact disc player uses invisible laser radiation and is equipped with safety switches which prevent emission of radiation when the drawer is open and the safety interlocks have failed or are defeated. It is dangerous to defeat the safety switches.
5. **CAUTION** : If safety switches malfunction, the laser is able to function.
6. **CAUTION** : Use of controls, adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

VARNING : Osynlig laserstrålning när denna del är öppnad och spärren är urkopplad. Betrakta ej strålen.

VARO : Avattaessa ja suojalukitus ohitettaessa olet alttiina näkymättömälle lasersäteilylle. Älä katso säteeseen.


ADVARSEL : Usynlig laserstrålning ved åbning, når sikkerhedsafbrydere er ude af funktion. Undgå udsættelse for stråling.

ADVARSEL : Usynlig laserstrålning ved åbning, når sikkerhedsbryteren er avslott. unngå utsettelse for stråling.


REPRODUCTION AND POSITION OF LABELS

WARNING LABEL

DANGER : Invisible laser radiation when open and interlock failed or defeated. AVOID DIRECT EXPOSURE TO BEAM. (e)	VARNING : Osynlig laserstrålning när denna del är öppnad och spärren är urkopplad. Betrakta ej strålen. (s)	ADVARSEL : Usynlig laserstrålning ved åbning, når sikkerhedsafbrydere er ude af funktion. Undgå udsættelse for stråling. (d)	VARO : Avattaessa ja suojalukitus ohitettaessa olet alttiina näkymättömälle lasersäteilylle. Älä katso säteeseen. (f)
--	--	---	--



CLASSIFICATION LABEL



Insstruction Book

Table of Contents

Features	1	Basics of Using the CD Player —	
How This Manual Is Organized	1	Continuous Play	21
IMPORTANT CAUTIONS	1	To Insert Discs	21
		To Play a Disc	22
Getting Started	3	RESUME	22
Accessories	3	To Change Discs While Playing	22
How To Put Batteries In the Remote Control	3	To Select a Disc, Track or Passage Within a Track	23
Using the Remote Control	3	To Select a Track	23
Connecting the FM Antenna	4	To Select a Passage Within a Track	23
Connecting the Speakers	5	Locating a Track With the Remote Control Directly	23
Connecting the AM (MW/LW) Antenna	4	Programming the Playing Order of the Tracks	23
Connecting the SUB WOOFER	5	To Check the Program	25
Connecting a VCR	5	To Modify the Program	25
Connecting the Optional Speakers	6	Random Play	25
DEMO Mode	6	Repeating a Selection or the Discs	26
COMPU PLAY	6	Tray Lock Function	26
		Locking the Electronic Lock	26
		Unlocking the Electronic Lock	26
Using the Amplifier	7	Using the Cassette Deck (Listening to a Tape)	27
Turning the Power On and Off	7	One Touch Play	28
Turning the CA-D701T On	7	Regular Play	28
Turning the CA-D701T Off	7	Fast Left and Fast Right	28
Adjusting the Volume	8	Music Scan	29
FADE MUTING Function	8	To Find the Beginning of the Current Selection	29
Balance adjustment	8	To Find the Beginning of the Next Selection	29
Reinforcing the Bass Sound	8	Other Useful Features of the Cassette Deck	29
Sound Modes	9	Using the Cassette Deck (Recording)	30
Selecting a Sound Mode	9	Things To Know Before You Start Recording	30
Customizing a Sound Mode	10	Standard Recording	31
When a Rear Speaker is Connected	11	To Record Any Sound Source To Tape	31
Adjusting the Rear Speaker Level	11	CD Direct Recording	32
Using a VCR	12	Auto Edit Recording	33
Listening to a VCR	12	Tape to Tape Recording (Dubbing)	34
Recording to a VCR	12	How to Use the DUBBING Button	34
		Using the Timers	35
Dolby Surround	13	Setting the Clock	35
Preparing the Dolby Surround	14	Adjusting the Brightness of the Display	36
Getting Ready To Use Dolby Pro Logic	15	Setting the DAILY Timer	36
Speaker Arrangements for Dolby Pro Logic	15	Turning the DAILY Timer On and Off	38
Setting-up Dolby Pro Logic	15	Setting the REC (Recording) Timer	39
Getting Ready To Use Dolby 3 Channel Logic	16	Turning the REC Timer On and Off	40
Speaker Arrangements for Dolby 3 Channel Logic	16	Setting the SLEEP Timer	40
Setting-up Dolby 3ch Logic	16	Timer Priority	41
Using Dolby Surround	17	Care And Maintenance	42
Using the Tuner	18	Troubleshooting	43
One Touch Radio	18	Specifications	44
Tuning In a Station	18		
Switching between Frequency Bands	18		
Selecting a radio station	19		
Presetting Stations	19		
To Change the FM Reception Mode	19		
		Using the CD Player	20
		The Quickest Way To Start a CD Is With the One Touch Operation	21

English

English

Thank you for purchasing the JVC Compact Component System. We hope it will be a valued addition to your home, giving you years of enjoyment. Be sure to read this instruction manual carefully before operating your new stereo system. Here you will find all the information you need to set up and use the system. For questions that are not answered in the manual, please contact your dealer.

Features

- Here are some of the things that make your CA-D701T powerful and easy to use.
 - The controls and operations have been redesigned to make them very easy to use so you can spend your time listening to music.
 - With the One Touch Operation feature of JVC's **COMPU PLAY** you can turn on the CA-D701T and start the radio, the Cassette Deck, or the CD Player with a single touch.
 - You can use the MULTI CONTROL stick to set the CD Player, Tuner, Timer, and Sound Mode operations.
 - To get such great sound from such a compact package the CA-D701T has:
 - Built-in **Dolby Pro Logic** and **Dolby 3ch Logic** effects. Combined with the optional center and rear speakers, this allows you to enjoy the dynamic, pulsating sound effects of a cinema.
 - Programmed sound mode includes live surround effects **D. CLUB, HALL, and STADIUM**. It also includes S.E.A (Sound Effect Amplifier) effects **ROCK, POP, and CLASSIC**. You can also register up to three customized settings.
 - CD changer function can operate 3 discs.
 - Continuous, random or program play of 3 discs.
 - Discs can be changed during play using the **TRIPLE TRAY**.
 - The three timers, **DAILY Timer, REC (Recording) Timer, and SLEEP Timer**, are extremely easy to set. The Displays are large and clear. They are organized so you can tell at a glance what's happening because functions light up as you use them, and blink to tell you they are ready. They provide some important messages like "NO DISC", and other informations.

How This Manual Is Organized

- In this manual we have incorporated some special features:
 - Basic information that is the same for many different functions is grouped in one place, and not repeated in each procedure. For instance, in the section on playing a CD, we do not repeat the information about setting the volume and the sound conditions, which are discussed in the Using the Amplifier section.
 - Name of buttons and controls are written in all capital letters like this: **SOUND MODE**.
 - When we are talking about the Function, rather than the **BUTTON** or **DISPLAY**, only the first letter is capitalized.
- The manual has a table of contents to help you quickly look up what you want to know. We've enjoyed making this manual for you, and hope you will use it to enjoy the sound and many features built into your CA-D701T.

IMPORTANT CAUTIONS

- 1. Installation of the Unit**
 - Select a place which is level, dry and neither too hot nor too cold. (Between 5°C and 35°C or 41°F and 95°F)
 - Leave sufficient distance between the Unit and a TV.
 - Do not use the Unit in a place subject to vibrations.
- 2. Power cord**
 - Do not handle the power cord with wet hands!
 - Some power (20 watts) is always consumed as long as the power cord is connected to the wall outlet.
 - When unplugging the Unit from the wall outlet, always pull the plug, not the power cord.
- 3. Malfunctions, etc.**
 - There are no user serviceable parts inside. If anything goes wrong, unplug the power cord and consult your dealer.
 - Do not insert any metallic object into the Unit.

Getting Started

Accessories

Check that you have all of the following items, which are supplied with the CA-D701T.


- AM (MW/LW) Loop Antenna (1)
- Remote Control (1)
- Batteries (2)
- FM Wire Antenna (1)

If any of these items is missing, contact your dealer immediately.

How To Put Batteries In the Remote Control

Match the polarity (+ and -) on the batteries with the + and - markings in the battery compartment.

R6P (SUM-3)/AA (15F)




CAUTION: Handle batteries properly.

To avoid battery leakage or explosion:

- Remove batteries when the Remote Control will not be used for a long time.
- When you need to replace the batteries, replace both batteries at the same time with new ones.
- Don't use an old battery with a new one.
- Don't use different types of batteries together.

Using the Remote Control

The Remote Control makes it easy to use many of the functions of the CA-D701T from a distance of up to 7m (23 feet) away. You need to point the Remote Control at the remote sensor on the CA-D701T's front panel.



Remote sensor


3

English

English

CAUTION: Make all connections before plugging the Unit into an AC power outlet.

Connecting the FM Antenna




A. Using the Supplied Wire Antenna

The FM Wire Antenna provided can be connected to a FM 75-ohm COAXIAL as temporary measure. Extend the supplied wire antenna horizontally.

B. Using the Coaxial Type Connector (Not Supplied)

A 75-ohm antenna with coaxial type connector (DIN 45 325) should be connected to the FM 75-ohm COAXIAL terminal.




Before attaching a 75 ohm coaxial lead (the kind with a round wire going to an outside antenna), disconnect the supplied FM Wire Antenna.


CAUTION: To avoid noise, keep antennas away from metallic parts of the CA-D701T, connecting cord and the AC power cord.

Connecting the AM (MW/LW) Antenna

AM antenna wire (Not Supplied) If reception is poor, connect the outside antenna.



Note: Even when connecting an outside AM antenna, keep the indoor AM loop connected.



Turn the loop until you have the best reception

Snap the tabs on the loop into the slots of the base to attach the AM Loop.


4

CAUTION: Make all connections before plugging the Unit into an AC power outlet.

Connecting the Speakers (Please refer to instructions for speakers as will when you connect speakers.)

For each speaker, connect one end of the speaker wire to the speaker terminals on the back of the CA-D701T and the other end to the speaker.

1. Open each of the terminals and insert the speaker wires firmly (be sure to remove the insulation at the end of each wire first), then close the terminals.
2. Connect the red (+) and black (-) terminals of the right side speaker to the red (+) and black (-) terminals marked RIGHT on the CA-D701T.
Connect the red (+) and black (-) terminals of the left side speaker to the red (+) and black (-) terminals marked LEFT on the CA-D701T.




IMPORTANT: Use speakers with the correct impedance only. The correct impedance is indicated on the back panel.

CAUTION: If a TV is installed near speakers, the TV may display irregular colours. In this case, set the speakers away from the TV.


Connecting the SUB WOOFER

Connect the Sub-Woofier to the SUBWOOFER OUT terminal.




Connecting a VCR

Connect the VCR to the VCR terminal.



Connecting the Optional Speakers

Connect the optional center speaker and rear speakers.



Now you can plug the AC power cord into the wall outlet, and your CA-D701T is at your command!

DEMO Mode

When the CA-D701T is connected to an AC power outlet, a DEMO mode displaying some of the system's features automatically starts.

The DEMO display cycles through the following items repeatedly.

- Scrolling display of "DEMO MODE START".
- Demo of MULTI CONTROL.
- Demo of Dolby Surround.
- Demo of Sound Modes.
- Demo of continuous play from DISC-1 to DISC-3.
- Scrolling display of "TUNER RANDOM 40CH PRESET".

To turn the DEMO display off, press any of the operation buttons. "DEMO OFF" appears on the display and the DEMO display automatically stops.

DEMO OFF



To turn the DEMO display on, press the DEMO button.

Notes:

- The DEMO display automatically starts when the power cord is inserted into a wall outlet.
- The DEMO display will not start if VCR is selected as a music source.

COMPU PLAY

COMPU PLAY is JVC's feature that lets you control the most frequently used functions of the CA-D701T with a single touch.

One Touch Operation starts playing a CD, turns on the radio, plays a tape, etc. with a single press of the play button for that function. What One Touch Operation does for you is to turn the power on, then start the function you have specified. If the Unit is not ready, such as no CD or tape in place, the Unit still powers on so you can insert a CD or tape.

How One Touch Operation works in each case is explained in the section dealing with that function. The COMPU PLAY buttons are:


On the Unit

- CD button
- CD Player \Rightarrow button
- CD Player DISC-1 to DISC-3 buttons
- FM/AM button
- TAPE button
- DECK CONTROL \leftarrow , \rightarrow buttons
- VCR button

On the Remote Control

- TUNER button
- VCR button
- CD control \blacktriangle button
- CD control DISC 1 to DISC 3 buttons
- CD control Open/Close \blacktriangle buttons
- Deck control \blacktriangle buttons

Using the Amplifier



MULTI CONTROL stick and indicator. The indicators, light for directions the MULTI CONTROL stick can be used, and blink, during operation.

When the CA-D701T is being used, the display shows other items as well. However, we have only shown the items described in this section.

FADE MUTING

Turning the Power On and Off

Turning the CA-D701T On

Press the **POWER** button.

The display comes on and the STANDBY indicator goes out.

- The CA-D701T comes on ready to continue in the mode it was in when the power was last turned off.
- If the last thing you were doing was listening to a tape in Deck B, you are now ready to listen to a tape again in Deck B, or you can change to another source.
- If you were listening to the Tuner last, the Tuner comes on playing the station it was last set to.

Turning the CA-D701T Off

Press the **POWER** button again.

The STANDBY indicator lights up and the display is blank, except for the clock display.

- Some power (20 watts) is always consumed even though power is turned off (called Standby Mode).
- To switch off the Unit completely, unplug the AC power cord from the AC outlet. When you unplug the AC power cord, the clock will be reset to 0:00 immediately, and preset Tuner stations will be erased after a few days.



Adjusting the Volume



OR



Turn the VOLUME control clockwise to increase the volume or anticlockwise to decrease it. Turning the VOLUME control quickly also adjusts the volume level quickly. When using the Remote Control, press the **VOLUME +** button to increase the volume or press the **VOLUME -** button to decrease it. You can adjust the volume level between 0 and 50.

- When the CA-D701T is turned on from Standby mode, the volume is set to 0 and automatically increases to the previous volume level. To stop this automatic volume adjustment, turn the VOLUME control slightly or press the **VOLUME** button on the Remote Control.

For private listening

Connect a pair of headphones to the PHONES jack. No sound comes out of the speakers. Be sure to turn down the volume before connecting or putting on headphones.

FADE MUTING Function

Set the Volume Level to 0 by pressing the **FADE MUTING** button on the Remote Control. Press this button again to restore the Volume Level to its previous level.



Balance adjustment

You can use the Remote Control to adjust the left and right balance of the speakers.

- Press the **SHIFT** button.
- Press the **L BALANCE R** buttons (0 or +10). The display changes to show the balance adjustment.



L - - - * - - R

Pressing the L button (10) moves the pointer to the left, pressing the R button (+10) moves the pointer to the right.

L - - - * - - R

Display when set for no sound from the right speaker.

Display at the center position.

- The balance is normally set to the center position.

Note: If no adjustments are made for 5 seconds in balance adjustment mode, the display reverts to the previous display.

Reinforcing the Bass Sound

S.A. (Signal Adaptive) BASS adjusts low tones at low volume to enhance their effect. When the volume level is low, this enhances low tones that are normally difficult to hear and adjusts low tones to a fixed level to reduce low tone distortion.


The display changes with each press of the S.A. (Signal Adaptive) BASS button as shown below.

- SA BASS1 → SA BASS2 → OFF → (back to the beginning)
- SA BASS2 enhances low tones more than SA BASS1.

To get the effect, press the SA BASS button and select SA BASS1 or SA BASS2. "SA BASS1" or "SA BASS2" appears in the display and the button indicator lights up.

- When listening to recording with low volume low tones, the difference between SA BASS1 and SA BASS2 is clear. When listening to recording with louder low tones, however, the difference between SA BASS1 and SA BASS2 may not be so clear.

Indicator



To cancel the effect, press the S.A. BASS button until "OFF" appears on the display. The indicator light goes out.

Sound Modes

The CA-D701T has some preset sound effects that give you control of the way your music sounds, so you can tailor it for your room and for the quality of the source. We can give you some idea of how each one affects the music, but the only way to really tell is to try them yourself. You can also create up to three of your own customized S.E.A. (Sound Effect Amplifier) settings and store them in the unit's memory.

- The preset sound modes include modes using surround effects and modes using S.E.A. effects.
- Sound Mode effects cannot be recorded.

Surround effect modes


- D. CLUB (Dance Club)** Increases resonance and bass.
- HALL** Adds depth and brilliance to the sound, like in a concert hall.
- STADIUM** Adds clarity and spreads the sound, like in an outdoor stadium.

S.E.A. effect modes


- ROCK** Boosts low and high frequencies.
- POP** Good for vocal music.
- CLASSIC** Set for wide and dynamic sound stereo systems.

Selecting a Sound Mode

Using the Unit




- 1. Press the SOUND MODE button.**
The currently selected Sound mode appears on the display.
The MULTI CONTROL indicators light up to indicate the directions in which you can use the controller.



Note: If no adjustments are made for 5 seconds in Sound mode after the SOUND MODE button is pressed, the display reverts to the previous display.

- 2. Press the MULTI CONTROL stick to the left or right to select a Sound mode.**
Use the MULTI CONTROL stick to select a Sound mode while sound mode is displayed. If the display reverts to the previous display, press the SOUND MODE button again and use the MULTI CONTROL stick to select a mode.



- The display also displays the frequency for the selected mode.

Moving the MULTI CONTROL stick to the right →
 ↔ D. CLUB ↔ HALL ↔ STADIUM ↔ ROCK ↔ POP ↔ CLASSIC ↔ MANUAL 1 ↔ MANUAL 2 ↔
 MANUAL 3 ↔ OFF ↔
 ← Moving the MULTI CONTROL stick to the left

To cancel Sound mode, select "OFF".



Unless sound mode "OFF" is selected, the red perimeter line around the SOUND MODE indicator is lit. If "OFF" is selected, the perimeter line goes out.



Using the Remote Control


Press the SOUND MODE button.
The display changes with each press of the button as shown below.

→ D. CLUB → HALL → STADIUM → ROCK → POP → CLASSIC → MANUAL 1 → MANUAL 2 →
 MANUAL 3 → OFF → (back to the beginning)

Customizing a Sound Mode

You can change an existing sound mode to suit your own preferences. These changed settings can be stored in the CA-D701T's sound mode memory.

- 1. Select the sound mode you want to change.**
If you select D. CLUB, HALL, or STADIUM, the surround effect remains unchanged, but you can adjust the S.E.A. effect.
- 2. Press the SEA CONTROL button.**
"SEA CONT" appears in the display, then the low tone section of the tone equalizer is displayed and the MULTI CONTROL indicators light up to indicate the directions in which you can use the controller.



Note: If no adjustments are made for 5 seconds after the SEA CONTROL button is pressed, Sound mode appears on the display then reverts to the previous display.


- 3. Adjust the settings using the MULTI CONTROL stick.**
 Adjust the level by adjusting the MULTI CONTROL stick up and down.
The level can be set between +3 and -3 in seven steps.



- Select the tone range by adjusting the MULTI CONTROL stick left and right.
You can select LOW, MID, or HIGH tones.



- 4. Press the SET button.**
"MANUAL 1" appears on the display.



- 5. Select the memory number by adjusting the MULTI CONTROL stick left and right.**
You can choose from "MANUAL 1" to "MANUAL 3".






- Press the **SET** button again. "MEMORY" appears on the display and the settings are stored in the memory number selected.
 - The sound mode is set to the settings you have stored.
 - If you store new settings to a memory number that has already been used, the new settings replace the existing setting.



When a Rear Speaker is Connected

If the optional rear speaker is connected, you can use the rear speaker to enjoy Surround effects when a Surround effect (D. CLUB, HALL, STADIUM, or a MANUAL setting based on one of these) Sound Mode is selected.

- The rear speaker cannot be used when an S.E.A. effect (ROCK, POP, CLASSIC) is selected.



Adjusting the Rear Speaker Level

You can use the steps below to adjust the rear speaker level.

- Select a Surround effect Sound Mode.
- Start playback from the desired source.
- Press the **SHIFT** button on the remote control.
 - The level changes one step with each press of the buttons.
 - You can set the level between -10 and +10 in 21 steps.
 - The rear speaker level changes equally for both left and right. You cannot adjust the left and right balance for the rear speaker independently.
 - You can adjust the rear speaker level for each of the Surround effect modes.



Using a VCR

Listening to a VCR

By playing the sound from VCR through the CA-D701T, you can gain control over how the music or program sounds. Once the connected equipment is playing through the CA-D701T, you can apply the sound effects.

- First make sure that the optional equipment is properly connected to the CA-D701T. (See page 5).

- Set the **VOLUME** control to 0.

- Press the **VCR** button.

When CA-D701T is in Standby mode, the Unit is automatically turned on and "VCR" appears on the display.



- Start playing the equipment.

- Adjust the **VOLUME** control to the desired listening level.

- Select a sound effect mode, if you wish.

To Cancel the Setting

Change the source by starting any one of the CA-D701T's built-in sound sources, such as the Tuner or CD Player.

Recording to a VCR


To record to a VCR, start playback of the recording source of the CA-D701T and start recording on your VCR. (Refer to the VCR's instruction manual for details on the recording procedure for your VCR.)

- You cannot record using Sound mode effects.


English

English


Dolby Surround



Operation keys



Display




Dolby Surround indicator

When the CA-D701T is being used, the display shows other items as well. However, we have only shown the items described in this section.

Accessing the Dolby Surround Functions

Press the operation keys with green labels on the Remote Control to use the Dolby Surround functions. To use the function marked in green, press the SHIFT button first, then press the desired operation key.

The Dolby Surround has been also developed to reproduce the important elements of the acoustic surround at home. To watch the sound tracks of video software bearing the mark  which includes the same encoded surround information as found in Dolby Stereo film, the CA-D701T can provide you with two Dolby Surround programs (Dolby Pro Logic and Dolby 3ch Logic).

Dolby Pro Logic: Select this mode when the optional rear speakers are connected.

Dolby 3ch Logic: Select this mode when no rear speakers are connected.

Manufactured under license from Dolby Laboratories Licensing Corporation. "Dolby", "Pro Logic" and the double-D symbol are trademarks of Dolby Laboratories Licensing Corporation.

- You need to connect the optional center speaker and rear speakers to use the Dolby Surround functions.

Preparing the Dolby Surround

To use the Dolby Surround effects, you need to prepare the various settings. These settings are set using the Remote Control. The Dolby Surround settings are:

Center Speaker Mode

Center Speaker mode contains the following four settings.

PHANTOM: Select this setting if you have not connected a center speaker. The left and right front speakers project the sound to give the effect of a center speaker.

NORMAL: Select this setting if you are using a small center speaker. Since the center speaker cannot boost the low tones effectively, this setting uses the front speakers to boost the low tones from the center speaker.

WIDE: Select this setting if you are using a center speaker that is similar in power to the front speakers.

OFF: Select this setting to turn off the output for the center speaker.

Delay Time Mode

Delay Time mode contains the following four settings.

DELAY 1: Select this setting if the rear speakers are further away from your listening position than the front speakers. (Delay time: 15 msec.)

DELAY 2: Select this setting if the rear speakers and front speakers are about the same distance way from your listening position. (Delay time: 20 msec.)

DELAY 3: Select this setting if the rear speakers are nearer to your listening position than the front speakers. (Delay time: 25 msec.)

DELAY 4: Select this setting if the rear speakers are very close to your listening position compared to the front speakers. (Delay time: 30 msec.)

Adjusting the level of the Center Speaker

Adjust the level of the center speaker between +10 and -10. Set the level so that it is about the same as the level from the front speakers.

Adjusting the level of the Rear Speakers


Adjust the level of the rear speakers between +10 and -10. Set the level so that it is about the same as the level from the front speakers.

- You cannot adjust the levels of the left and right rear speakers independently.

Getting Ready To Use Dolby Pro Logic

Speaker Arrangements for Dolby Pro Logic

Layout when using the center speaker and rear speakers




Setting-up Dolby Pro Logic

1. Press the **PRO LOGIC/3CH LOGIC** button to select **PRO LOGIC**.

The PRO LOGIC/3CH LOGIC button indicator lights up.
The display changes with each press of the PRO LOGIC/3CH LOGIC button as shown below.
→ **PRO LOGIC** → **3CH LOGIC** → Off (button not lit) → (back to the beginning)

The PRO LOGIC/3CH LOGIC button lights up and "PRO LOGIC" appears on the display.



When using the Remote Control, press the **SHIFT** button then press the **PRO LOGIC** button.

- Perform the steps below using the buttons on the Remote Control.

2. Select the desired **Center Speaker mode**.

Press the **SHIFT** button on the Remote Control then press the **CENTER MODE** button.

The display changes with each press of the button, as shown below.

- **NORMAL** → **WIDE** → **OFF** → **PHANTOM** → (back to the beginning)

3. Select the **Delay time**.

Press the **DELAY TIME** button. The display changes with each press of the button, as shown below.

- **DELAY 2** → **DELAY 3** → **DELAY 4** → **DELAY 1** → (back to the beginning)

4. Set the volume to the level you normally use.

Press the **TEST TONE** button.

A test tone is emitted in the order shown below.

- **LEFT** → **CENTER** → **RIGHT** → **REAR** → (back to the beginning)


- When "PHANTOM" is selected for Center Speaker mode, the test tone for the center speaker is projected by the front speakers.

- When "OFF" is selected for Center Speaker mode, no test tone is output from the center speaker.

6. Adjust the level for the center speaker.

Press the **CENTER LEVEL +** or **-** button. Set the level so that it is about the same as the level from the front speakers.

You cannot adjust the level for the center speaker if "PHANTOM" or "OFF" is selected for Center Speaker mode.



7. Adjust the level for the rear speakers.

Press the **REAR LEVEL +** or **-** button. Set the level so that it is about the same as the level from the front speakers.



8. To cancel Test Tone mode.

Press the **TEST TONE** button again.
This completes the preparations required for using Dolby Pro Logic.



Getting Ready To Use Dolby 3 Channel Logic

Speaker Arrangements for Dolby 3 Channel Logic



Setting-up Dolby 3ch Logic

1. Press the **PRO LOGIC/3CH LOGIC** button to select **3CH LOGIC**.

The PRO LOGIC/3CH LOGIC button indicator lights up.
The display changes with each press of the PRO LOGIC/3CH LOGIC button as shown below.
→ **PRO LOGIC** → **3CH LOGIC** → Off (button not lit) → (back to the beginning)

The PRO LOGIC/3CH LOGIC button lights up and "3CH LOGIC" appears on the display.



When using the Remote Control, press the **SHIFT** button then press the **3CH LOGIC** button.

- Perform the steps below using the buttons on the Remote Control.

2. Select the desired **Center Speaker mode**.

Press the **SHIFT** button on the Remote Control then press the **CENTER MODE** button. The display changes with each press of the button, as shown below.

- **NORMAL** → **WIDE** → **OFF** → (back to the beginning)

3. Set the volume to the level you normally use.

Press the **TEST TONE** button.

A test tone is emitted in the order shown below.

- **LEFT** → **CENTER** → **RIGHT** → (back to the beginning)

- When "OFF" is selected for Center Speaker mode, no test tone is output from the center speaker.


- When "OFF" is selected for Center Speaker mode, no test tone is output from the center speaker.

5. Adjust the level for the center speaker.

Press the **CENTER LEVEL +** or **-** button. Set the level so that it is about the same as the level from the front speakers.

You cannot adjust the level for the center speaker if "OFF" is selected for Center Speaker mode.


You cannot adjust the level for the center speaker if "OFF" is selected for Center Speaker mode.



6. **To cancel Test Tone mode.**
Press the TEST TONE button again. This completes the preparations required for using Dolby 3 Channel Logic.
 You cannot adjust the Delay Time or rear speaker levels in Dolby 3 Channel Logic mode.




Using Dolby Surround

1. **Press the PRO LOGIC/3CH LOGIC button and select the desired mode.**
If you are using the remote control, press the PRO LOGIC or 3CH LOGIC button after pressing the SHIFT button.
Make sure that the center speakers and rear speaker have been setup correctly, as described on pages 14 to 17.
2. **Playback as source with the  mark.**
Enjoy the great sound achieved through Dolby Surround.


To Cancel Dolby Surround Effects

Press the PRO LOGIC/3CH LOGIC button until the indicator light goes out. If you are using the Remote Control, press the Dolby Surround buttons (PRO LOGIC or 3CH LOGIC) after pressing the SHIFT button.

Using the Tuner



MULTI CONTROL stick and indicator
The indicators light for directions the MULTI CONTROL stick can be used, and blink during operation.



When the CA-D701T is being used, the display shows other items as well. However, we have only shown the items described in this section.

You can listen to both FM and AM (MW/LW) stations. Stations can be tuned in manually, automatically, or from preset memory storage.

- Before listening to the radio:
- Check that both the FM and AM (MW/LW) antennas are firmly connected. (See page 4).

One Touch Radio

Just press the FM/AM button (or the TUNER button on the Remote Control) to turn on the Unit and start playing the most recent station tuned in.

- You can switch from any other sound source to the radio by pressing the FM/AM button (or the TUNER button on the Remote Control).




Tuning In a Station


Press the FM/AM button (or the TUNER button on the Remote Control) to turn on the radio. The Frequency of the previously selected channel appears on the display.

Switching between Frequency Bands


Press the FM/AM button.
Each time you press the button, the band alternates between FM and AM (MW/LW).



Using the CD Player



MULTI CONTROL stick and indicator
The indicators light for directions the MULTI CONTROL stick can be used, and blink during operation.



When the CA-D701T is being used, the display shows other items as well. However, we have only shown the items described in this section.

DISC indicator

Each of the Disc buttons acts as an indicator. This indicator is off when the CD Player is checking that there is no disc in the disc tray for the corresponding disc number.

Pressing the **▲** button turns the indicator on. During playback, the disc indicator for the disc being played flashes.



Disc marker

Disc display

A red marker lights on the disc display for the disc number you have selected. This disc display blinks while a CD is being played. The center of the disc display is not lit while CD Player is checking that there is no disc in the disc tray for the corresponding disc number.

English

English

Selecting a radio station

- Select a frequency by adjusting the MULTI CONTROL stick up or down. The frequency changes in one step increments. "TUNED" appears on the display when a signal is found. This is called Manual Tuning.
- The frequency increases when MULTI CONTROL stick is pressed upwards, and decreases when the MULTI CONTROL stick is pressed downwards.
- If the MULTI CONTROL stick is pressed up or down continuously for a few seconds, the frequency changes continuously until a signal is found, then "TUNED" appears on the display. This is called Auto Tuning.
- Possible only after presetting stations.

Using the Unit

Select a preset channel by adjusting the MULTI CONTROL stick left or right.

Using the Remote Control

1. Press the TUNER button so that you can receive the most recent station tuned in.
2. Select the station by entering the preset number in the number keys of the Remote Control.
 - Example: for channel 5, press 5. For channel 15, press +10 then 5. For channel 20, press +10, then 10. For channel 32, press +10 three times, then 2.

Presetting Stations

You can store up to 40 of your favourite radio stations (FM and AM (MW/LW)) in memory, giving you quick, easy access to the stations.

Note: In some cases, test frequencies have been already memorized for the tuner since the factory examined the tuner preset function before shipment. This is not a malfunction. You can preset the stations you want into memory by following the presetting method.

1. Select a frequency band by pressing the FM/AM button.
2. Tune to a station by adjusting the MULTI CONTROL stick up or down.
3. Press the SET button.
 - On the display, "SET" will blink for 5 seconds.
 - During these 5 seconds while "SET" is blinking, you can assign a channel number to the station and enter it into the memory.
4. Select a preset number by adjusting the MULTI CONTROL stick left or right.
5. Press the SET button and the station will be assigned to the channel number showing on the display. "MEMORY" appears in the display.
- If a station has been previously stored using the same channel number, this will be erased and the newly selected station will be stored.
- If "SET" in the display goes off, start again from step 3.
6. Repeat steps 1 - 5 for each station you want to store in memory with a preset number.

CAUTION: If the Unit is unplugged or if a power failure occurs, the preset stations will be erased after a few days. If this happens, preset the station again.

To Change the FM Reception Mode




When an FM stereo broadcast is hard to receive or noisy, press the FM MODE button on the Remote Control so that the "AUTO" indicator goes off in the display. Reception improves, but there are no stereo effects. In this monaural mode, noise comes out while tuning in stations (since muting is also cancelled).



To restore the stereo effect, press the FM MODE button on the Remote Control so that the "AUTO" indicator lights up. In this stereo mode, no noise comes out while tuning in stations, and you can hear stereo sounds when a program is broadcast in stereo.

The CA-D701T's CD Player has an Automatic Changer with 3 disc trays. You can use Continuous, Random, Program or Repeat Play for the discs in DISC-1, DISC-2 and DISC-3. Repeat Play can repeat all the tracks on all the CD's, the tracks on one of the CD's or one track on one CD. There is also the Tray Lock function, which safely keeps discs in the trays.

Here are the basic things you need to know to play a CD and locate the different selections on it. Each selection is called a track, so when we are talking about locating a track, we are also talking about how you find a certain song or performance.

The Quickest Way To Start a CD Is With the One Touch Operation
The power comes on, and operations are done automatically.

- Press the CD or  button (or the  button on the Remote Control).
- If there is a CD in the disc tray of the selected (lit) disc number, playback continues from the track where it was interrupted.
- If there is no CD in any of the disc trays, the message "OPEN" appears in the display after a few seconds and the disc tray for the marked disc opens.
- Press a DISC button (1 to 3).
- If there is a CD in the disc tray for the disc number you have selected, playback begins from the first track of that disc. If there is no CD in the disc tray, the message "OPEN" appears in the display after a few seconds and the disc tray opens.
- Press the  button.
- The power turns on, and the tray opens automatically.



To Play a Disc
 This function plays the disc in the Unit continuously.

1. Prepare the discs.
2. Press the DISC button (1-3) of the disc you want to play.
 The first track of the selected disc will begin playing.
 When the selected disc finishes playing, the next disc will begin playing automatically.
 When the last disc has finished playing, the Unit will stop automatically.

□ When a DISC button is pressed while a tray is open, the open tray will close automatically and Continuous Play playback begins from the first track of the disc.


To use Continuous Play from the first track of the disc selected by the disc marker, you do not need to press a DISC button (1-3), just press the  or  button on the Remote Control).


Playing order of discs

- When playback starts from DISC-1, the playing order is DISC-1 → DISC-2 → DISC-3. When DISC-3 has finished, the CD Player selects DISC-1 (the disc marker is on) and stops.
- When playback starts from DISC-2, the playing order is DISC-2 → DISC-3 → DISC-1. When DISC-1 has finished, the CD Player selects DISC-2 (the disc marker is on) and stops.
- When playback starts from DISC-3, the playing order is DISC-3 → DISC-1 → DISC-2. When DISC-2 has finished, the CD Player selects DISC-3 (the disc marker is on) and stops.
- If any of the disc trays are empty, the CD Player skips that disc tray and continues through the remaining disc trays in the order shown above.


Basics of Using the CD Player — Continuous Play



You can play the discs continuously in the DISC 1 to DISC 3 trays.







1. Press the  button on the left of the Disc button you want to insert the disc into.
 The disc tray slides out automatically.
2. Place a CD, with its label side up, onto the tray.







ATTENTION: To avoid malfunctions when you play a CD, please set the CD in the right place at the center of the tray.







3. Press the  button to close the tray.
4. Repeat steps 1 to 3 to insert other discs into other trays.
 To continue putting discs into other trays, even if a tray is open, by pressing the  button of another disc tray, the open tray will close automatically, and the new disc tray will slide out.
- To put an 8 cm CD into a tray, insert it so that it is aligned with the groove in the tray's center.
- "OPEN" appears in the display when a tray opens, and "CLOSE" when a tray closes.
- If a tray is open when the CA-D701T switches to Standby mode, the tray is closed automatically.

Note: When the CD Player is reading a disc, "....." appears in the display. While this is being displayed, the  button or DISC button cannot be used. Once the display changes from "....." to another display, the  button and DISC button can be used.

Note: If there is no CD in disc tray for the DISC button you pressed, the message "OPEN" appears in the display and the disc tray automatically opens. If there is no disc in the disc tray for the selected disc number, when the  or  button on the Remote Control) is pressed, playback begins from the next disc.



To stop play the disc, press the  button.
To stop play and remove the disc, press the  button for the disc being played.
To pause, press the  button. The Disc display will blink. (The Pause function cannot be used with the  button on the Remote Control.)
To cancel pause, press the  button again (or press the  button on the Remote Control). Play continues from the point where it was paused.

RESUME

When the  button is pressed during playback, and the source is changed, the track number is memorized even when the power is turned off. The next time the  or  button (or the  button on the Remote Control) is pressed, play resumes from the track where it was interrupted.
 □ To start playback from the first track, press the DISC button.

To Change Discs While Playing

You can replace a CD in a tray not being used, while another CD is playing.

1. Press the  button of the tray not being used.
 The tray opens.
2. Replace the disc in the tray.
3. Press the  button to close the tray.

To Select a Disc, Track or Passage Within a Track
 Press the **DISC** button (1-3) for the disc tray containing the track you want to listen to. Playback starts from the first track of the disc you selected.
 Example: for the third disc, press 3.

To Select a Track
 Using the Unit
Select a track by adjusting the MULTI CONTROL stick left or right.
 The MULTI CONTROL stick adjustments step through the tracks on the CD one track at a time.
 Moving the MULTI CONTROL stick to the right selects the next track.
 Moving the MULTI CONTROL stick to the left selects the previous track.
 If the MULTI CONTROL stick is held down continuously, the CD Player skips through the tracks on the CD continuously in the selected direction.



Using the Remote Control
 Press the **◀** or **▶** button to select the track.
 Each time you briefly press and release the **◀** or **▶** button, the track changes by one.
 Press and release the **▶** button to go ahead one track at a time.
 Press and release the **◀** button to go back one track at a time.
 Holding down the **◀** or **▶** button allows you to change tracks continuously.



To Select a Passage Within a Track
 While a CD is playing, press the **MULTI CONTROL** stick up or downwards continuously. If the MULTI CONTROL stick is pressed upwards the CD is played forwards quickly, if the controller is pressed downwards the CD is played backwards quickly. Release the controller when the CD reaches the passage you want to hear.
Note: You cannot perform these fast forwards or fast backwards operation with the remote control.



Locating a Track With the Remote Control Directly
 Using the number keys on the Remote Control allows you to go directly to the beginning of any track.


1. Press the **DISC** button (1-3) for the disc tray containing the track you want to listen to.
 Example: for the third disc, press 3.
2. Enter the number of the track you want to listen to with the number keys.
 The selected track starts playing.
 Example: for track 5, press 5. For track 15, press +10 then 5. For track 20, press +10, then 10. For track 32, press +10 three times, then 2.

Programming the Playing Order of the Tracks

You can change the order in which the discs and tracks play, and select only the discs and tracks you want from among those loaded in the CD Player.
 You can program up to 32 steps in any desired order from among the discs in the player.
 You can only make or change a program when the CD Player is stopped.

Using the Unit

1. Press the **PROGRAM/RANDOM** button.
 The message "PROGRAM" appears on the display and the **PROGRAM** indicator comes on. If you have already created a program, the last step of the previous program is displayed.



- The display changes with each press of the **PROGRAM/RANDOM** button, as shown below.
 → **PROGRAM** → **RANDOM** → **Off** (Continuous Play) → (back to the beginning)

2. Select a disc with the **DISC** buttons (1 to 3).
 The display changes to the Program Entry display and the disc number and track number sections blink for a few seconds.

Disc number Step number



- While the display is blinking, perform the operations in steps 3 to 4. When the blinking display changes to the "PROGRAM" display, repeat the operations in steps 2 to 4.

3. Select a track for the program by adjusting the **MULTI CONTROL** stick left or right.
 The track number appears on the display.



4. Press the **SET** button.
 The blinking disc number and track number changes to a steady light, and the step number is displayed.



5. Repeat steps 2 to 4 to select the other tracks for the program.
 To select another track from the same disc, repeat the procedure from step 3.
6. Press the **▶/IT** or **CD** button.
 The Unit plays the tracks in the order you have programmed them.

Using the Remote Control

1. Press the **PROGRAM/RANDOM** button on the Unit.
 The message "PROGRAM" appears in the display and the **PROGRAM** indicator comes on. If you have already created a program, the last step of the previous program is displayed.



- The display changes with each press of the **PROGRAM/RANDOM** button, as shown below.
 → **PROGRAM** → **RANDOM** → **Off** (Continuous Play) → (back to the beginning)

2. Select a disc with the **DISC** buttons (1-3).
 The display changes to the Program Entry display and the disc number and track number sections blink for a few seconds.

Disc number Step number



- While the display is blinking, perform the operations in step 3. When the blinking display changes to the "PROGRAM" display, repeat the operations in steps 2 to 3.

- Note:** Press the DISC buttons (1-3), or the number keys, to cancel Random play and begin playback in Continuous Play mode.
- Press the REPEAT button before or during random play to instruct the CA-D701T to continue with a different random track selection after the last selection is played.
- To cancel random play,** press the ■ button, then press the PROGRAM/RANDOM button to select another mode.

Repeating a Selection or the Discs

You can have all the discs, the program or the individual selection currently playing repeat as many times as you like.



- Press the REPEAT button on the CA-D701T.**
The display changes with each press of the button, as shown below.
→ REPEAT ALL → REPEAT 1 CD → REPEAT 1 → blank display → (back to the beginning)
- REPEAT ALL:** Repeats all the tracks on the CD's in the CD Player, or all the tracks in the program.
REPEAT 1 CD: Repeats all the tracks on one CD.
REPEAT 1: Repeats one track on a CD.
- "REPEAT ALL" and "REPEAT 1" remain on the display even when you change the play mode.
 - The three Repeat Modes above can be selected during Continuous Play, however, during Program Play and Random Play, you can only select REPEAT ALL or REPEAT 1.

To exit Repeat Mode, press the REPEAT button until the Repeat mode indicator on the display goes out.

Tray Lock Function

In order to safely keep the discs in the CD Player, the three trays can be electronically locked in a single operation.
When the electronic lock is on, the trays cannot be opened even if the ▲ button is pressed.
This function can only be accessed by using the buttons on the Unit itself.

Locking the Electronic Lock

1. Put the CA-D701T's power into STANDBY mode.
 2. While pressing the ■ button, press the ▲ button for DISC 1's tray on the Unit.
- "LOCKED" appears on the display to let you know that the trays have been locked.

LOCKED

When the CD Player trays are locked, pressing the ▲ buttons displays the message "LOCKED" on the display and the trays do not open. But, the ▲ button can be used to automatically turn on the power.

Unlocking the Electronic Lock

1. Put the CA-D701T's power into STANDBY mode.
 2. While pressing the ■ button, press the ▲ button for DISC 1's tray on the Unit.
- When the unlock operation is done, "UNLOCKED" appears in the display to show that the lock has been taken off.

UNLOCKED

The trays can now be opened by pressing the ▲ buttons.
The ▲ button can also be used to automatically turn on the power.

3. Press the number keys (1 to 10 and *10) to select the track to program.
□ Example: For track 5, press 5. For track 15, press +10 then 5. For track 20, press +10 then 10. For track 32, press +10 three times, then 2.
- The blinking disc number and track number changes to a steady light, and the step number is displayed.



4. Repeat steps 2 to 3 to select the other tracks for the program.

5. Press the ► button.

The Unit plays the tracks in the order you have programmed them.

- If you try to program a 33rd step, the CA-D701T lets you know that the program is full by displaying the message "FULL" on the display.
- If you try to program an disc tray that is empty, or a track number that does not exist on a disc (for example, selecting track 14 on a disc that only has 12 tracks), the selected disc or track are skipped when the program is played.
- You can skip to a particular program step during program play. To do this from the unit, move the MULTI CONTROL stick left or right, to do so from the remote control press the ◀ or ▶ buttons.
- To play the programmed tracks over and over, press the REPEAT button. The Repeat mode indicators light up in sequence with each press of the REPEAT button.

To stop playing, press the ■ button.
To delete all the tracks in a program, keep pressing the CANCEL button on the Unit until all the tracks in the program have been deleted, or press the ▲ button for each disc in the program.
To exit Program Mode, press the PROGRAM/RANDOM button twice to change to Continuous Play mode.

To Check the Program

While the CD Player is stopped, use the ◀ or ▶ buttons on the remote control to check the contents of the program.
Each time you press the ▶ button, the program contents are shown on the display in the programmed order. Pressing the ◀ button displays the previous step in the program.

To Modify the Program

Modify the contents of a program while the CD Player is stopped.
Press the CANCEL button on the Unit, the last track in the program is deleted.
Each time you press the button, the last track listed in the program is deleted from the program.
To add a track to the program, follow the procedure above (on either the Unit or the Remote Control). The news tracks are added to the end of the program.

Random Play





- The tracks will play in no special order when you use this mode.
1. Press the PROGRAM/RANDOM button while the CD Player is stopped to change to the Random Mode display.



- The display changes with each press of the PROGRAM/RANDOM button, as shown below.
→ PROGRAM → RANDOM → Off (Continuous Play) → (back to the beginning)
2. Press the ▷/◀ or CD button (or the ► button on the Remote Control)
- The tracks are played in random order.
When all of the tracks have been played, the CD Player stops.

Using the Cassette Deck (Listening to a Tape)



◀▶ : Tape Direction indicator
 ◻◻ : Reverse Mode indicator
 DD : DOLBY B NR indicator

Tape Direction Indicator on the Display

The Tape Direction indicator tells you which direction the selected tape deck will use for playback. During playback, the direction indicator blinks slowly. During fast left or fast right, the indicator blinks quickly. During Music Scan mode, the direction indicator alternates between blinking slowly and quickly repeatedly.

When the CA-D701T is being used, the display shows other items as well. However, we have only shown the items described in this section.

Cassette Deck control buttons

The Cassette Deck allows you to play, record and dub audio tapes.

- ❑ Most tapes are now recorded with the Dolby NR system, so first check which type of the Dolby NR system has been used on the tape. Only Dolby B NR is incorporated into the CA-D701T.
- ❑ With Automatic Tape Detection, you can listen to type I or II tapes without changing any settings.

The use of tapes longer than 120 minutes is not recommended, since characteristic deterioration may occur and these tapes easily jam in the pinch-rollers and the capstans.

English

COMPUTER PLAY

One Touch Play

- ❑ Press the TAPE button. The power comes on and "TAPE" lights up on the display. If there is a tape in the deck corresponding to the Deck Indicator DECK A/B, that tape starts to playback. If there is no tape in the deck corresponding to the Deck Indicator, the CA-D701T automatically turns on the power and displays "TAPE" then the message "NO TAPE" and waits for you to insert a tape or select another function.
- ❑ Press the ◀ or ▶ button (or the ◀ or ▶ button on the Remote Control). The power comes on and "TAPE" appears in the display. When a tape is already in the tape deck, the tape is played in the direction of the button pressed. If there is no tape in the deck corresponding to the Deck Indicator, the CA-D701T automatically turns on the power and displays "TAPE" then the message "NO TAPE" and waits for you to insert a tape or select another function.

Regular Play

If the power is already on, you can use this basic procedure:

1. Press the ▲ button for the deck you want to use.
2. When the cassette holder opens, put the cassette in, with the exposed part of the tape down, toward the base of the CA-D701T.
 - ❑ If the cassette holder does not open, turn the Unit off, then back on and press the ▲ button again.
3. Close the holder gently. When both Deck A and Deck B contain a tape, the last deck to have a tape inserted is selected. To change the selected deck, press the DECK A/B button. When using the Remote Control, press the A or B button.
4. Press the ◀ or ▶ button (or ◀ or ▶ button on the Remote Control). The tape is played in the direction of the button pressed for the selected deck.
 - ❑ The Cassette Deck automatically stops when one side of a tape has finished playing.

To stop playing, press the ■ button.

To remove the tape, stop the tape, and press the ▲ button.

To change deck while playing a tape, press the ◀ or ▶ button after pressing the DECK A/B button on the Unit or press the ◀ or ▶ button after pressing the A or B button on the Remote Control.


Fast Left and Fast Right

- ❑ While the tape is stopped, press the ◀ button and the tape will wind rapidly onto the left side of the cassette without playing.
- ❑ While the tape is stopped, press the ▶ button and the tape will wind rapidly onto the right side of the cassette without playing.

Note: Deck A and Deck B cannot be used for playback at the same time.



Using the Cassette Deck (Recording)



MULTI CONTROL stick and indicator
The indicators light for directions the MULTI CONTROL stick can be used, and blink during operation.

Recording onto a cassette from any of the sound sources is simple. Just place a tape in Deck B, have the source ready, make one or two settings, and you're ready to record. For each source the procedure is a little different and now we'll explain just what to do for each one. If you forget, just come back to the section which has the specific procedures you need. But first, here are a few things to make your recordings better.

Things To Know Before You Start Recording

- ❑ It may be unlawful to record or play back copyrighted material without the consent of the copyright owner.
- ❑ Press the DOLBY B NR button — the indicator lights up — to reduce tape hiss, except when dubbing tapes, since Dolby NR is inactive in Dubbing Mode regardless of the setting of DOLBY B NR. The dubbed tape automatically contains the same processing as the source tape.
- ❑ When you want to record onto both sides of a tape, you can set Reverse mode on to do so. However, recording automatically stops after recording in the ◀ direction in Reverse mode. Therefore, make sure that the tape direction is ▶ when recording with Reverse mode on.
- ❑ The recording level, which is the volume at which the new tape is being made, is automatically set correctly, so it is not affected by the VOLUME control on the CA-D701T. Thus, during recording you can adjust the sound you are actually listening to without affecting the recording level.
- ❑ Two small tabs on the back of the cassette tape, one for side A and one for side B, can be removed to prevent accidental erasure or re-recording. To record on a cassette with the tabs removed, you must cover the holes with adhesive tape first. However, when a type II tape is used, only cover part of the hole as shown, since the other part of the hole is used to detect the tape type.
- ❑ When recording, you can hear Sound Mode effects through the speakers or headphones.
- ❑ However, the sound is recorded without Sound Mode effects.
- ❑ Type I and Type II tapes can be used for recording.



Note: At the start and end of cassette tapes, there is leader tape which cannot be recorded onto. Depending on the recording source, the first part of the recording may be missing because of the leader. When recording CDs or radio broadcasts, to get the beginning of the recording on the tape, first wind on the leader before beginning recording.

CAUTION: If recordings you have made have excessive noise or static, the Unit may be too close to a TV which was on during the recording. Either turn off the TV or increase the distance between the TV and the CA-D701T.

English

English

Music Scan

To find the beginning of a music track during play, use the Music Scan function. Music Scan searches for blank portions that usually separate selections, then plays the next selection.

To Find the Beginning of the Current Selection

- Press the ◀◀ or ▶▶ button during play.
- ❑ Make sure that you press the ◀◀ or ▶▶ button in the opposite direction to that in which the tape is playing. Searching stops at the beginning of the current selection, and the current selection starts automatically.

To Find the Beginning of the Next Selection

- Press the ◀◀ or ▶▶ button during play.
- ❑ Make sure that you press the ◀◀ or ▶▶ button in the same direction as that in which the tape is playing. Searching stops at the beginning of the next selection, and the next selection starts automatically.

Music Scan works by detecting a 4-second long blank at the beginning of each selection, so it won't work well if your tape has:

- No blank at the beginning of a selection.
- Noise (often caused by much use or poor quality dubbing) which fills the blank with noise.
- Long, very soft passages or pauses in a selection. The scan will detect these as 4-second long blanks. If this happens, just scan again until you reach the selection you want.

Other Useful Features of the Cassette Deck

- ❑ Use **Reverse Mode** to make the tape automatically reverse at the end of a side and start playing the other side. Press the REVERSE MODE button to change from Reverse Mode on to Reverse Mode off, or from off to on.



Reverse Mode ON Reverse Mode OFF

- ❑ **Continuous Play:** With the Reverse Mode indicator on, when tape playback in the ◀ direction finishes, the Unit always checks to see if a tape is in the other deck. If there is, it automatically starts playing. This Continuous Play function works regardless of which deck starts first.

- ❑ Press the DOLBY B NR button to switch Dolby B Noise Reduction on (the indicator lights up) or off (the indicator goes off). If a tape is recorded with the Dolby B NR system, playing it back with the Dolby NR on will reduce tape noise and improve the clarity of the sound.



Dolby noise reduction manufactured under license from Dolby Laboratories Licensing Corporation.
"DOLBY" and the double-D symbol are trademarks of Dolby Laboratories Licensing Corporation.


Standard Recording

This is the basic method for recording any source. The CA-D701T also has special ways for recording CD to tape, and tape to tape, which save you time and effort, as well as give you some special effects. However, when you need to add a selection to a tape you have made, or are combining selections from several sources on one tape, use the method described below; just substitute the source you want into this procedure, such as a tape in Deck A, a CD, or the Tuner. You can also record from VCR with this procedure.

To Record Any Sound Source To Tape _____
Follow these steps to record from any sound source onto a tape in Deck B.

Using the Unit

- 1. Insert a blank or erasable tape into Deck B.**
Reverse Mode comes on.
 - When using Reverse Mode, insert the tape so that it will be recorded in the forwards direction.
- 2. Press the REVERSE MODE button if you want to record on both sides of the tape.**
Reverse Mode comes on.
 - When using Reverse Mode, insert the tape so that it will be recorded in the forwards direction.
- 3. Check the recording direction for the tape.**
Check that the Tape Direction indicator is the same as that for the tape in the tape deck. If the directions are different, press the button to set the tape direction.
 - When using Reverse Mode to record both sides of a tape, check that the Tape Direction indicator is in the forwards direction. If the direction indicator is not in the forwards direction, press the button then press the button.
- 4. Prepare the source by, for example, tuning in a radio station, loading CDs, or turning on connected equipment.**
- 5. Press the REC START/STOP button.**
The Recording indicator light comes on and the CA-D701T begins recording.



If you are recording an AM (MW/LW) broadcast and you hear interference, move BEAT CUT switch on the back panel from position 1 (the normal mode) to position 2.

English

English

Notes for using Reverse Mode for recording

When recording in Reverse Mode, the CA-D701T automatically stops when it reaches the end of the reverse direction. To record on both sides of a tape, make sure that the recording direction for the tape inserted into Deck B is forwards , and that the Tape Direction indicator is also forwards before you start recording.

To Pause at Any Time During the Recording Process

Press the REC PAUSE button on the Remote Control. Then press either the or button on the Remote Control or REC START/STOP button on the Unit to restart recording.


To Stop at Any Time During the Recording Process

Press the REC START/STOP button on the Unit again, or press the button.

CD Direct Recording

Everything on the CD goes onto the tape in the order it is on the CD, or according to the order you have set in a program.

- 1. Prepare CDs. (See page 21.)**
Check that the CD Player is not playing a CD.
- 2. Insert a cassette in Deck B to record on.**
 - When you want to record on both sides of a tape, press the REVERSE MODE to turn Reverse Mode on. Check that the recording direction for the tape and the Tape Direction indicator are correct. (See "Notes for using Reverse Mode for recording" earlier on this page.)
- 3. Press the CD REC START button.**
"CD REC" is displayed on the display then the Unit plays the CD and starts recording.



At the end of the tape, the CA-D701T automatically goes back to the beginning of the last selection and re-records it, this time gently fading out at the end. If you selected Reverse Mode, "TAPE SIDE-B STANDBY" scrolls through the display then the reverse side starts with the last selection of the first side. The last selection of the first side will fade out at the end. (A 10 second blank is created at the beginning of the reverse side.)

When the recording is finished, the message "CD REC FINISHED" scrolls by on the display. The CD Player and Cassette Deck stop.

To Stop at Any Time During the Recording Process

Press the REC START/STOP button or the button on the Cassette Deck or CD Player (or the button on the Remote Control).

Note: When making SLEEP timer settings while doing CD Direct recording, set the time so that there is enough leeway to finish the recording before the power goes off. If the time is set to about the length of the CD, the power may go off before recording finishes.

For CD Direct Recording using more than one disc, use a blank tape. If you use a prerecorded tape, prerecorded material may not be erased between newly-recorded tracks.

Auto Edit Recording

Using Auto Edit, you can record the CD tracks to fit the tape, so a selection isn't cut off. Auto Edit is one of the best ways to copy all of a CD onto a tape. Auto Edit programs the CD tracks in numerical order. To prevent the end of the last track on the front side from being cut off, the last track on the front side is selected to fit on the remaining tape length.


1. Prepare CDs. (See page 21.)

2. Press the EDIT button on the Unit. "DISC" appears in the display.



3. Press the DISC button for the disc you want to record.

After "TAPE C" appears on the display, the optimum tape length for the disc you want to record is displayed.



You can select a different length of tape, depending on the actual size of the tape you are using, from eleven possibilities programmed into the CA-D701T: 40, 46, 50, 54, 60, 64, 70, 74, 80, 84, 90. Select the tape length that corresponds to the length of tape you are using, or the nearest length to it, by adjusting the MULTI CONTROL stick left or right.

- If you pick a tape length shorter than the total playing time of the CD, the last tracks on both sides of the tape will be faded out as the tape ends.

4. Press the SET button.

The tracks to be recorded on side B of the tape appear on the display.



To display the tracks that will be recorded on side A of the tape, press the SET button again. The Unit switches between side A and side B with each press of the SET button.


- To check the tracks that will be recorded, press the ◀ or ▶ buttons on the Remote Control.

5. Insert a cassette in Deck B to record on.

When you want to record on both sides of a tape, press the REVERSE MODE button to turn Reverse mode on.

6. Press the CD REC START button.

The Unit plays the CD and starts recording. If the tape has not been rewound, the Unit rewinds the tape before starting to record the CD.



When the tape is ready, to prevent the start of a track being cut, the CA-D701T creates a blank period of 10 seconds before it starts to record the CD. While a blank period is being created, "TAPE SIDE-A STANDBY" scrolls through the display. (The CA-D701T also creates a 10 second blank period at the start of side B of the tape. While a blank period is being created, "TAPE SIDE-B STANDBY" scrolls through the display.)

When the recording is finished, the message "CD REC FINISHED" scrolls by on the display. The CD Player and Cassette Deck stop.

To stop at any time while recording, press the ■ button (CD control or Cassette Deck control) or the REC START/STOP button. If you press the CD control ■ button, the Cassette Deck creates a four second blank space after the CD Player stops. If you press any other button to stop the recording, the CD Player and Cassette Deck stop at the same time.

To cancel Auto Edit, press the ▲ button for disc number being recorded, or press the PROGRAM/RANDOM button while the CD Player is stopped.

Note: When making SLEEP timer settings while doing Auto Edit recording, set the time so that there is enough leeway to finish the recording before the power goes off. If the time is set to about the length of the CD, the power may go off before recording finishes.

Tape to Tape Recording (Dubbing)

Recording from one tape to another is called dubbing.

You can dub tapes simply, with just a single button.

- When dubbing tapes, make sure that the playback direction of Deck A and Deck B are the same.
- When you want to record both sides of a tape, press the REVERSE MODE button to turn Reverse mode on.
- It is preferable that the type of tape (Type I or Type II) you record from be the same as the type you record onto.

How to Use the DUBBING Button


1. Insert the source cassette you want to copy from into Deck A for playback.

2. Insert the blank or erasable cassette you want to copy onto in to Deck B for recording.

3. Press the DUBBING button.

Deck A and Deck B will start simultaneously.

To stop dubbing, press the ■ button or REC START/STOP button.




Dolby NR is inactive in dubbing mode regardless of the setting of DOLBY B NR. The dubbed tape automatically contains the same processing as the source tape.

- When doing dubbing with the DUBBING button, you can hear Sound Mode effects through the speakers or headphones. However, the sound is dubbed without Sound Mode effects.

Using the Timers

MULTI CONTROL stick and indicator
The indicators light for directions the MULTI CONTROL stick can be used, and blink during operation.



When the CA-D701T is being used, the display shows other items as well. However, we have only shown the items described in this section.

The timers lets you control recording and listening functions automatically.

- Three types of timers are available:
 - DAILY Timer** — Use this timer to set wake up to music from any source, instead of an alarm clock.
 - REC (Recording) Timer** — Unattended recording of radio broadcasts. You can set the starting time and length of the recording.
 - SLEEP Timer** — Fall asleep and have your CA-D701T turn off automatically after a certain length of time.

Setting the Clock

1. **Press the TIMER/CLOCK button.**
The "CLOCK" indicator and the hour digits blink on the display.
You can set the clock, the clock must be right for the timers to work as you expect.
Note that the clock must be set, or the timers cannot be set.
2. **Set the hour by adjusting the MULTI CONTROL stick left or right.**
Adjust the MULTI CONTROL stick to the right to advance the hour setting, adjust it to the left to decrease the setting. Press the MULTI CONTROL stick continuously to increase or decrease the hour setting rapidly.
3. **Press the SET button.**
The minute digits blink on the display.
4. **Set the minute by adjusting the MULTI CONTROL stick left or right.**
Adjust the MULTI CONTROL stick to the right to advance the minute setting, adjust it to the left to decrease the setting. Press the MULTI CONTROL stick continuously to increase or decrease the minute setting rapidly in 10 minute steps.
5. **Press the SET button.**
"CLOCK OK" appears on the display, and the clock starts at zero seconds from the set time.

CAUTION: If there is a power failure, the clock loses its setting. The display shows "0:00", and the clock must be reset.

Adjusting the Brightness of the Display




In Standby mode, you can adjust the brightness of the clock display. Pressing the MULTI CONTROL stick in the upwards direction makes the display brighter. Pressing the MULTI CONTROL stick in the downwards direction makes the display darker.

Setting the DAILY Timer

With this timer, you can wake up to music from a CD, tape, your favourite radio program, or other source.

- You can set the DAILY Timer whether the Unit is on or off.




1. **Press the TIMER/CLOCK button so that "DAILY Timer" appears in the display.**
The message "DAILY" blinks, and the DAILY indicator light blinks on the display.



- The display changes with each press of the button, as shown below.
DAILY (blinks) → **ON TIME** (blinks) → **REC** (blinks) → **ON TIME** (blinks) → **CLOCK** (blinks) (Clock setting mode) → original display before the TIMER/CLOCK button was pressed → (back to the beginning)

Note: If the clock has not been set, even if the TIMER/CLOCK button is pressed you cannot select the DAILY Timer.

2. **Press the TIMER/CLOCK button again.**
The display changes to the On Time display.



3. **Set the time you want the Unit to turn on.**
Set the time by adjusting the MULTI CONTROL stick left or right in the same way you set the time for the clock. Press the SET button to set the on time.



The "OFF time" hour setting starts to blink after the "ON time" minute setting is set.

4. **Set the time you want the Unit to turn off.**

Set the time by adjusting the MULTI CONTROL stick left or right in the same way you set the time for the clock. Press the SET button to set the off time.

- When the off time has been set, the display changes to the source selection display.





5. Select the source you want to listen to. To use the Tuner as the source:
 1. Adjust the MULTI CONTROL stick left or right until "TUNER" blinks in the display.



2. Adjust the MULTI CONTROL stick up or down to select the preset channel you want to listen to. (Possible only after presetting stations.)



3. Press the SET button.



To use a CD as the source:
 1. Adjust the MULTI CONTROL stick left or right until "CD - - -" blinks in the display.



2. Adjust the MULTI CONTROL stick up or down to select the disc tray containing the CD you want to play.



3. Press the SET button. If you press the SET button without selecting a disc, the last disc played by the CA-D701T will be used.



4. Adjust the MULTI CONTROL stick up or down to select the starting track of the CD. You can only select up to 20 tracks.



5. Press the SET button. If you press the SET button without selecting a track, playback will start from the first track on the CD.



To use a Cassette Deck as the source:
 1. Adjust the MULTI CONTROL stick left or right until "TAPE" blinks in the display.



2. Press the SET button.



To use another source:
 Use this to select a radio station that has not been preset.


1. Adjust the MULTI CONTROL stick left or right until " - - - - -" blinks in the display.



2. Press the SET button. The last source used is selected.



6. Setting the Volume Level.
 Adjust the MULTI CONTROL stick left or right to set the volume level.



VOLUME - A: Sets the volume level to 10.

VOLUME - B: Sets the volume level to 15.

VOLUME - C: Sets the volume level to 20.

VOLUME - - -: Sets the volume to the last volume setting used.

7. Press the SET button.

The "DAILY" indicator changes from a blinking display to a steady display. The ON TIME, OFF TIME, PLAYBACK SOURCE (including the disc number and track number, if a CD source is selected) are displayed then the display reverts to the previous display, before the Timer was set.

Turn the power off if you made the timer settings with the power turned on.

- A few seconds before the start for the timer, the CA-D701T automatically turns on the power, and the "DAILY TIMER" blinks on the display. When the set time is reached, playback starts using the selected source. A few seconds before the end of the timer, "TIMER" blinks on the display. With the coming of the timer end time, the power is automatically turned off again.
- If a button is pressed when the DAILY Timer is operating, playback continues but the timer is cancelled.

Before Turning Off the Unit

- If the source is a CD, make sure that there is a CD in the selected disc number.
- If the source is a tape:
 - The tape in the deck corresponding to the Deck Indicator mark is played. Make sure that there is a tape in the selected Cassette Deck.
 - Check that the tape direction is correct. This is important especially when Reverse Mode is off.
 - Set Reverse Mode on if you want to play both sides of the tape.
- Select the Sound Mode if you want to listen using a Sound Mode effect.

To change the DAILY Timer setting

To change the settings for the DAILY Timer, repeat the setting procedure from the beginning.

Turning the DAILY Timer On and Off

Once the DAILY Timer has been set it will be activated at the same time every day until the setting is turned off.

To turn the DAILY Timer off, press the TIMER/CLOCK button until "DAILY" appears in the display. Press the CANCEL button. "OFF" appears in the display and the DAILY indicator goes out.

To turn the DAILY TIMER on again, press the TIMER/CLOCK button until "DAILY" appears in the display, then press the SET button. The Timer ON TIME, OFF TIME, PLAYBACK SOURCE (including the disc number and track number if a CD source is selected) are displayed on the display.

CAUTION: If the CA-D701T is unplugged, or a power failure occurs, the timer setting will be erased in a few days. If the settings are erased in this way, reset the timer settings.


Setting the REC (Recording) Timer

With the Recording Timer you can make a tape of a radio broadcast automatically whether or not you are home. For the timer to work correctly, you need to make sure of the following in addition to setting the time for the Tuner and Cassette Deck to come on:


- You can set the REC Timer whether the Unit is on or off.
- The tape you want to record onto must be in Deck B.

Procedure for Setting the REC Timer

1. Press the **TIMER/CLOCK** button so that "REC Timer" appears in the display. The message "REC" blinks and the REC indicator light blinks on the display.




- The display changes with each press of the button, as shown below.
DAILY (blinks) → **ON TIME** (blinks) → **REC** (blinks) → **ON TIME** (blinks) → **CLOCK** (blinks) (Clock setting mode) → original display before the **TIMER/CLOCK** button was pressed → (back to the beginning)



Note: If the clock has not been set, even if the **TIMER/CLOCK** button is pressed you cannot select the REC Timer.

2. Press the **TIMER/CLOCK** button again.

The display changes to the On Time display.



3. Set the time you want the Unit to be turned on.

Set the time by adjusting the **MULTI CONTROL** stick left or right in the same way you set the time for the clock. Press the **SET** button to set the on time.

4. Set the time you want the Unit to be turned off.

Set the time by adjusting the **MULTI CONTROL** stick left or right in the same way you set the time for the clock. Press the **SET** button to set the off time.

5. Select the radio station you want to record.

Set the radio station you want to record by adjusting the **MULTI CONTROL** stick up or down.

6. Press the **SET** button.

The "REC" indicator changes from a blinking display to a steady display. The **ON TIME**, **OFF TIME**, and preset channel number are displayed then the display reverts to the previous display, before the Timer was set. Turn the power off if you made the timer settings with the power turned on.



- A few seconds before the start time for the recording, the CA-D701T automatically turns on the power, and "REC TIMER" blinks on the display. When the start time is reached, recording starts using the selected source. A few seconds before the end of the timer, "TIMER" blinks on the display. With the coming of the timer end time, the power is automatically turned off again.
- If a button is pressed when the REC Timer is operating, recording continues but the timer is cancelled.

Before the Timer Starts

- Check that tape direction is correct. This is important especially when Reverse Mode is off.
- Set Reverse Mode on if you want to record on both sides of the tape.
- The **VOLUME** control is automatically set to 0 when REC Timer is recording.

It is very easy, and can be very disappointing, to forget to put in a tape, or to accidentally leave a tape in Deck B you don't want recorded over. Although this happens to almost everyone at one time or another, we hope it won't happen to you!

To Change the Recording Timer Setting

To change the settings for the REC Timer, repeat the setting procedure from the beginning.

Turning the REC Timer On and Off

Once the REC Timer has been used to record a source, the setting is maintained but the Timer is set to OFF.

To turn the REC Timer off before the timer starts, press the **TIMER/CLOCK** button until "REC" appears in the display, then press the **CANCEL** button. "OFF" appears in the display and the REC indicator goes out.

To record at the same time again, press the **TIMER/CLOCK** button until "REC" appears in the display, then press the **SET** button. The **ON TIME**, **OFF TIME**, channel frequency, and preset channel number are displayed then the display reverts to the previous display, before the Timer was set.

CAUTION: If the CA-D701T is unplugged, or a power failure occurs, the timer setting will be erased in a few days. If the settings are erased in this way, reset the timer settings.

Setting the SLEEP Timer


Use the Sleep Timer to turn the Unit off after a certain number of minutes when it is playing. By setting this timer, you can fall asleep to music and know your Unit will turn off by itself rather than play all night.

- You can only set the Sleep Timer when the Unit is on and a source is playing.

To set the SLEEP Timer, follow this procedure:

1. With the CA-D701T on and a source playing, press the **SLEEP** button on the Remote Control.

The message "SLEEP" appears on the display.



2. Set the length of time you want the source to play before shutting off.

- Each time you press this button while the "SLEEP" indicator is blinking, it changes the number of minutes shown on the display in this sequence:

→ 10 → 20 → 30 → 60 → 90 → 120 → Cancelled → (back to the beginning)

When the number of minutes you want shows on the display, just wait 5 seconds until the indicator stops blinking, and is lighted steadily.

The Unit is now set to turn off after the number of minutes you set.

To Change the SLEEP Timer Setting

Press the **SLEEP** button until the number of minutes you want appears on the display.

To Cancel the SLEEP Timer Setting

Press the **SLEEP** button until the "SLEEP" indicator goes off on the display.

Turning off the Unit also cancels the SLEEP Timer.

Care And Maintenance


English

English


Timer Priority

- Since each timer can be set independently, you may wonder what happens if the settings overlap. Here are the priorities for each timer:
- ☐ The REC Timer always has priority. This means that:
 - If another timer is set to come on during a time when the REC Timer is operating, the other timer just won't come on at all, so you will always get the entire program on tape.
 - If the REC Timer is set to come on while another timer is operating, the other timer will shut off 10 seconds before the REC Timer is set to turn on, and the REC Timer will then take over.
 - ☐ The SLEEP Timer has the least priority. This means that if the SLEEP Timer is set while the DAILY Timer is operating, the DAILY Timer settings are cancelled. However, if the DAILY Timer is set to come while the SLEEP Timer is operating, the SLEEP Timer setting will be cancelled and the Unit will use the settings from the DAILY Timer.

Example 1



Example 2



Compact Discs

Handle your compact discs, cassette tapes, and Cassette Deck carefully, and they will last a long time.

- Remove the CD from the case by holding it at the edges while pressing the center hole lightly.
- Do not touch the shiny surface of the CD, or bend the CD.
- Put the CD back in its case after use to prevent warping.
- Be careful not to scratch the surface of the CD when placing it back in the case.
- Avoid exposure to direct sunlight, temperature extremes, and moisture.
- A dirty CD may not play correctly. If a CD does become dirty, wipe it with a soft cloth in a straight line, from center to edge.



Cassette Tapes


- If the tape is loose in its cassette, take up the slack by inserting a pencil in one of the reels and rotating.
- If the tape is loose, it may get stretched, cut, or caught in the cassette.
- Do not touch the tape surface.



- Do not store the tape:
 - In dusty places
 - In direct sunlight or heat
 - In moist areas
 - On a TV or speaker
 - Near a magnet

Cassette Deck

- If the heads, capstans, and pinch-rollers of the Cassette Deck become dirty, the following will occur:
 - Loss of sound quality
 - Fading
 - Discontinuous sound
 - Incomplete erasure
 - Difficulty recording
- Clean the heads, capstans, and pinch-rollers using a cotton swab moistened with alcohol.



- If the heads become magnetized, the Unit will produce noise or lose high frequencies.
- To demagnetize the heads, turn off the Unit, and use a head demagnetizer (available at electronics and record shops).

CAUTION: Do not use any solvent (for example, conventional record cleaner, spray thinner, benzine, etc.) to clean a CD.

Moisture Condensation

Moisture may condense on the lens inside the Unit in the following cases:

- After starting the heating in the room.
 - In a damp room.
 - If the unit is brought directly from a cold to a warm place.
- Should this occur, the Unit may malfunction. In this case, leave the unit turned on for a few hours until the moisture evaporates, unplug the AC power cord, and then plug it in again.





General Notes

- In general, you will have the best performance by keeping your tapes, CDs, and the mechanism clean.
- Store tapes and CDs in their cases, and keep them in cabinets or on shelves.
 - Keep the Cassette Deck's tape holder and the CD trays closed when not in use.

Troubleshooting

- If you are having a problem with your CA-D701T, check this list for a possible solution before calling for service.
- If you cannot solve the problem from the hints given here, or the Unit has been physically damaged, call a qualified person, such as your dealer, for service.

Symptom	Possible Cause	Action
No sound is heard.	Connections are incorrect, or loose.	Check all connections and make corrections. (See pages 4 - 6.)
Unable to record.	Cassette record protect tabs are removed.	Cover holes on back edge of cassette with tape.
Poor radio reception	<ul style="list-style-type: none"> • The antenna is disconnected. • The AM Loop Antenna is too close to the Unit. • The FM Wire Antenna is not properly extended and positioned. 	<ul style="list-style-type: none"> • Re-connect the antenna securely. • Change the position and direction of the AM Loop Antenna. • Extend FM Wire Antenna to the best reception position.
The CD skips.	The CD is dirty or scratched.	Clean or replace the CD.
Unable to operate the Remote Control.	<ul style="list-style-type: none"> • The path between the Remote Control and the sensor on the Unit is blocked. • The batteries have lost their charge. 	<ul style="list-style-type: none"> • Remove the obstruction. • Replace the batteries.
The CD tray cannot be opened.	The main AC power cord is not plugged in.	Plug in the AC power plug.
The CD does not play.	The CD is upside down.	Put the CD in with the label side up.
Operations are disabled.	The built-in microprocessor has malfunctioned due to external electrical interference.	Unplug the Unit then plug it back in.
The cassette door cannot be opened.	During tape playing, the power cord was unplugged.	Plug in the power cord, press the  button, and then the  button.

43

Specifications

Amplifier Section

Output Power (IEC 268-3/DIN) From speakers
45 watts per channel, min. RMS, both channels driven, into 6 ohms at 1 kHz with no more than 0.9% total harmonic distortion.

Center speaker (At surround operation)
25 watts, min RMS, driven, into 8 ohms at 1 kHz, with no more than 0.9% total harmonic distortion.

Rear speakers (At surround operation)
12.5 watts per channel, min RMS, both driven, into 16 ohms at 1 kHz, with no more than 0.9% total harmonic distortion.

Input Sensitivity/Impedance (1 kHz)
VCR 300 mV/45 kohms

Cassette Deck Section

Frequency Response
Type II (CO₂) : 30 - 16,000 Hz
Type I (NORMAL) : 30 - 15,000 Hz
Wow And Flutter 0.15% (WRMS)

CD Automatic Changer Section

CD Capacity 3 discs
Dynamic Range 93 dB
Signal-To-Noise Ratio 98 dB
Wow And Flutter Unmeasurable

Tuner Section

FM Tuner
Tuning Range 87.5 - 108.0 MHz
AM Tuner
Tuning Range
MW 522 - 1,629 kHz
LW 144-288 kHz

Dimensions 245 x 345 x 350.2 mm (W/H/D)
(9-11/16 x 13-5/8 x 13-13/16 inches)
Mass 8.5 kg (18.8 lbs)

Accessories

AM (MW/LW) Loop Antenna (1)
Remote Control (1)
Batteries R6P (SUM-3)/AA (15F) (2)
FM Wire Antenna (1)

Power Specifications

Power Requirements AC 230 V[~], 50 Hz
Power Consumption 160 watts
20 watts (in standby mode)

Design and specifications are subject to change without notice.

English

English


44

MEMO

Description of ICs

■ MN172412K8L1(IC902) : TUNER / DISPLAY Controller

1. Terminal layout



2. Terminal Function

Pin No.	Symbol	I/O	Functions and Operations	Pin No.	Symbol	I/O	Functions and Operations
1	7G	O	FL grid control	49	RDS RST	I	Reset signal from IC191
2	8G	O	FL grid control	50	/TUNED	I	TUNED indication control
3~15	P1~P13	O	FL anode control	51	/STEREO	I	STEREO indication control
16	P14	O	FL anode control	52	MUTE	O	Muting of tuner sound
17	P15	O	FL anode control	53	DCSOUT	O	Compulink signal output
18	P16	O	FL anode control	54	DCSIN	I	Compulink signal input
19	P20	O	FL anode control	55	CS2	I	chip select terminal input
20	P19	O	FL anode control	56	KI1	I	Key matrix input
21	P18	O	FL anode control	57	KI2	I	Key matrix input
22	P17	O	FL anode control	58	KI3	I	Key matrix input
23	-BP	--	Power supply for FL display	59	KI4	I	Key matrix input
24	P36	O	FL anode control	60	IFDATA	I	Data from PLL synthesizer
25	P35	O	FL anode control	61	CE	O	Chip enable signal for PLL synthesizer
26	P34	O	FL anode control	62	CK	O	Clock for PLL synthesizer
27	P33	O	FL anode control	63	TUDATA	O	Data for PLL synthesizer
28	P32	O	FL anode control	64	CS1	I	chip select terminal input
29	P31	O	FL anode control	65	C-REQ	I	Communication request data to IC301
30	P30	O	FL anode control	66	C-CLK	O	Communication data clock to IC301
31	P29	O	FL anode control	67	C-DATA	O	Communication data to IC301
32	P28	O	FL anode control	68	/RESET	I	RESET signal input
33	P27	O	FL anode control	69	GND	--	Connected to GND
34	P26	O	FL anode control	70	X1	--	Non connection
35	P25	O	FL anode control	71	X2	--	Connected to GND
36	P24	O	FL anode control	72	OSC2	I/O	Clock oscillation terminal
37	P23	O	FL anode control	73	OSC1	I/O	Clock oscillation terminal
38	P22	O	FL anode control	74	VDD	---	Power supply (+ B5V)
39	P21	O	FL anode control	75	T-REQ	I	Request signal to IC901
40	FOUT	O	Clock frequency	76	T-CLK	O	Clock signal to IC901
41	SPISTB	O	Strobe signal for IC903	77	T-DATA	O	Data for IC901
42	SPIDT1	O	Data input from IC903	78	NC	--	Non connection
43	SPIDTO	O	Data output for IC903	79	1G	O	FL grid control
44	SPICSB	O	Chip select output for IC903	80	2G	O	FL grid control
45	RDS CK	O	Clock input from IC191	81	3G	O	FL grid control
46	RDS DATA	O	Data signal from IC191	82	4G	O	FL grid control
47	RDS RST	O	Reset signal for IC191	83	5G	O	FL grid control
48	/TUINH	I	Inhibit signal Input	84	6G	O	FL grid control

■ MN17P3222JAAX1(IC301) : DECK/CD Controller

1. Terminal layout


42	~	22
43		21
}		}
63		1
64	~	84

3. Terminal Function

Pin No.	Symbol	I/O	Functions and Operations	Pin No.	Symbol	I/O	Functions and Operations
1	/APACK	I	APACKswitch detect input	49	/RESTSW	I	Traverse REST sw input
2	AEQ	O	It is "L" when CrO2 tape is in deck A	50		--	Connected to GND
3	DECKAI	O	DECKA indicator control	51		--	Connected to GND
4	DECKBI	O	DECKB indicator control	52	/RST	O	CD Lsi reset signal output
5		--	Non connection	53	MLD	O	Command load signal output to CD Lsi
6		--	Non connection	54	MDATA	O	Command data output to CD Lsi
7	RECI	O	Indication control	55	MLCK	O	Command clock signal output to CD Lsi
8	PON IND	O	Power indicator control	56	DATA	O	Communication data to changer μ -com
9	DISC1IND	O	DISC1 indicator control	57	SCK	O	Communication clock signal to changer μ -com
10	DISC2IND	O	DISC2 indicator control	58	CHST	I	Strobe signal to changer μ -com
11	DISC3IND	O	DISC3 indicator control	59	REQ1	I	Request signal to changer μ -com
12	PBEQ	O	Play back	60		--	Connected to GND
13	MSIN	I	music scan signal input	61		--	Connected to GND
14	NR	O	NR control signal	62		--	Connected to GND
15	/CAPN	O	Capstan (ON/OFF) control	63	CS	--	Connected to GND
16	BPLZ	O	B mecha. solenoid control	64		--	Connected to GND
17	APLZ	O	A mecha. solenoid control	65		--	Connected to GND
18		--	Connected to GND	66		--	Connected to GND
19		--	Non connection	67		--	Connected to GND
20	BMT	O	It is 'H' when Deck B is not playing	68	/RESET	I	CD reset signal input
21	OMT	O	Deck PB Mute control signal	69	GND	--	Connected to GND
22	RMT	O	Recording mute signal output	70	NC	--	Non connection
23		--	Non connection	71	GND	--	Connected to GND
24	/PB/REC	O	Rec. P.B select signal output	72	OSC	I	Osialtion terminal
25	REC	O	It is "H" when recording	73	OSC	--	Osialtion terminal
26	BIAS	O	REC bias ON/OFF control	74	VDD	--	+5V
27~39		--	Connected to GND	75	DCS IN	I	DCS signal input
40	C-REQ	O	Communication request data output to IC902	76	DCS OUT	O	DCS signal output
41	C-CLK	I	Clock signal input from IC902	77	APLS	I	A mech. reel pulse input
42		--	Non connection	78	BEQ	O	Play equalizer control
43	C-DATA	I	Command data output to IC902	79	/PSWB	I	B mech. play switch input
44		--	Connected to GND	80	BPLS	I	B mech. pranger control output
45	SQCK	O	Outside lock for sub-code Q register output	81	/FREC	I	FREC switch detect input
46	SUBQ	I	Sub code and Q register signal input	82	/RREC	I	RREC switch detect input
47	LSION	O	CD Lsi on signal output	83	/BPACK	I	BPACKswitch detect input
48	STAT	O	STATUS signal (CRC,CUE,CLVS,TTSTOP,ECLV,SQOK)	84	/PSWA	O	A mech. play switch input

■ HD404719A71FS(IC901) : AMP Controller

1. Terminal layout




2. Terminal Function

Pin No.	Symbol	I/O	Functions and Operations	Pin No.	Symbol	I/O	Functions and Operations
1	IN6	I	Key input (A/D convert)	40		--	Not use
2	/INH	I	Inhibit signal input	41	CDI	O	CD indication control
3	/PRT	I	Protector signal input	42	TUI	O	TUNED indication control
4	AD GND	--	Connected to GND	43	TAPEI	O	TAPE indication control
5	RESET	I	Reset signal input	44	VCRI	O	VCR indication control
6	OSC1	I/O	Clock oscillation terminal	45		--	Not use
7	OSC2	I/O	Clock oscillation terminal	46	APOI	O	APO indication control
8	GND	--	Connected to GND	47	BASSI	O	BASS indication control
9		--	Connected to GND	48	STUNDBYI	O	STNDBY indication control
10		--	Not use	49		--	Connected to GND
11	/TEST	O	Pull up	50~57		--	Not use
12	VCC	--	Power supply	58	SCK	O	Clock for IC401
13	RDS	O	Chip select terminal	59	SDA1	O	Data for IC401
14	PROLOGIC	O	Chip select terminal	60		--	Not use
15	KARAOKE	O	Chip select terminal	61	/RMIN	I	Remote control signal input
16	ECHO	O	Chip select terminal	62		--	Not use
17	SABASS	O	Chip select terminal	63	T-DATA	I	Communication data from IC302
18	HPIN	I	Head phone detect	64	T-REQ	O	Communication request data to IC302
19	CDRESET	O	CD servo Lsi reset signal output	65	T-CLK	O	Communication data clock from IC302
20	/TUINH	O	Tuner Inhibit signal output	66~68		--	Not use
21	TURESET	O	Tuner reset signal output	69	JOG2	I	Input 2 Jog pulse
22	DCSIN	I	Compulink signal data input	70	JOG1	I	Input 1 Jog pulse
23	DCSOUT	O	Compulink signal data output	71		--	Not use
24	ACO	O	Power supply control signal	72	SMUTE	O	Source Mute control signal
25	CONT.A	O	KARAOKE on/off control signal	73	ECHO2	O	Echo2 signal output
26,27		--	Not use	74	ECHO1	O	Echo1 signal output
28	RERAY1	O	Speaker relay on/off signal output	75	AD Vcc	---	Power supply (+B5V)
29		--	Not use	76	IN1	I	Key input (A/D convert)
30	SURR	O	Surrund ON/OFF control signal	77	IN2	I	Key input (A/D convert)
31		--	Not use	78	IN3	I	Key input (A/D convert)
32~38		--	Not use	79	IN4	I	Key input (A/D convert)
39		--	Not use	80	IN5	I	Key input (A/D convert)

■ UPD65612GB-165(IC801) : Changer Controller

1. Terminal Layout



2. Pin Functions

Pin No.	Symbol	I/O	Function	Pin No.	Symbol	I/O	Function
1	NC	--	Non connection	23	2SSW	I	TRAY2 switch input signal
2	NC	--	Non connection	24	1SSW	I	TRAY1 switch input signal
3	NC	--	Non connection	25	NC	--	Non connection
4	OS1I	I	Oscillation terminal	26	CAM0	I	Cam switch input signal for LCAM
5	OS1O	O	Oscillation terminal	27	CAM1	I	Cam switch input signal for LCAM
6	OS2I	I	Oscillation terminal	28	CAM2	I	Cam switch input signal for LCAM
7	OS2O	O	Oscillation terminal	29	CAM3	I	Cam switch input signal for LCAM
8	NC	--	Non connection	30	CAM4	I	Cam switch input signal for RCAM
9	C25IN	I	Connected to C25OUT	31	CAM5	I	Cam switch input signal for RCAM
10	C25OUT	O	Connected to C25IN	32	CAM6	I	Cam switch input signal for RCAM
11	RESET	I	Reset signal input	33	CAM7	I	Cam switch input signal for RCAM
12	REQ	O	Output the "mecha. data request"	34	FIT	O	Connected to C50
13	DATA	I/O	Control,Status data I/O	35	C50	I	Connected to FIT
14	ST	I	Strobe signal input	36	LMUP	O	L motor control signal
15	CKS	I	Clock input	37	LMDWN	O	L motor control signal
16	SELECT	--	Connected to GND	38	C25	--	Non connection
17	GND	--	GND	39	VDD	--	Power supply terminal
18	CK	--	Connected to GND	40	C100	--	Non connection
19	1MSW	I	TRAY1 switch input signal	41	RMUP	O	R motor control signal
20	2MSW	I	TRAY2 switch input signal	42	RMDWN	O	R motor control signal
21	3MSW	I	TRAY3 switch input signal	43	NC	--	Non connection
22	3SSW	I	TRAY3 switch input signal	44	NC	--	Non connection


CA-D701T

■ LC72131 (IC121) : PLL Synthesizer

1. Terminal Layout

XIN	1	22	XOUT
	2	21	VSS
PLLCE	3	20	LPF OUT
PLLDA	4	19	LPF IN
PLLCK	5	18	PD
IFDATA	6	17	VDD
<u>FM</u>	7	16	FM OSC
<u>AM</u>	8	15	AM OSC
<u>LW</u>	9	14	
<u>AUTO/MONO</u>	10	13	IF REQ
<u>FM-LOW</u>	11	12	FM/AM IF

2. Block Diagram




3. Pin Functions


Pin No.	Symbol	I/O	Functions	Pin No.	Symbol	I/O	Functions
1	X in	I	Crystal oscillator (7.2MHz).	12	FM/AM IF	I	Universal counter input
2		--	Not use	13	IF REQ	O	Output the "IF-signal request" to IC102
3	PLLCE	I	Fix the chip enable to "H" when inputting(DI) and outputting (DO) the serial data	14		I	Not use
4	PLLDA	I	Receive the control data from the controller (IC201).	15	AMOSC	I	Input the local oscillator signal of AM.
5	PLLCK	I	This clock is used to synchronize data when transmitting the data of DI and DO.	16	FM OSC	I	Input the local oscillator signal of FM.
6	IFDATA	O	Transmit the data from LC72131 to the controller which is synchronized with CK.	17	VDD	O	This is a terminal of power supply.
7	<u>FM</u>	O	It is "L" on FM mode.	18	PD	O	PLL charge pump output : When the local oscillator signal frequency is higher than the reference frequency high level signals will output. When it is lower than the reference frequency, low level signals will output. When it is same as reference frequency signals, it will be floating.
8	<u>AM</u>	O	It is "L" on MW mode.	19	LPF IN	I	Transistor used for the PLL active low-pass filter
9	<u>LW</u>	O	It is "L" on LW mode.	20	LPF OUT	O	Transistor used for the PLL active low-pass filter
10	<u>AUTO/MONO</u>	O	It is "L" on monaural, "H" on auto.	21	VSS	--	Connected to GND
11	<u>POWER</u>	O	Regulator control signal PON "H", STANDBY "L"	22	X out	O	Crystal oscillator (7.2MHz).

■ IR3R42 (IC104) : POLAR STEREO DETECTOR (Only used for VX version)

1. Terminal Layout




2. Block Diagram




■ MN35510 (IC603) : DIGITAL SERVO & DIGITAL SIGNAL PROCESSER

1. Terminal Layout



2. Block Diagram



Description


Pin No.	symbol	I/O	Description	Pin No.	symbol	I/O	Description
1	BCLK	O	Bit clock output pin SRDATA	41	TES	O	Tracking error shunt signal output (H;shunt)
2	LRCK	O	L/R distinction signal output	42	PLAY	—	Not used
3	SRDATA	O	Serial data output	43	WVEL	—	Not used
4	DVDD1	—	Power supply(Digital)	44	ARF	I	RF signal input
5	DVSS1	—	Connected to GND (Digital)	45	IREF	I	Reference current input pin
6	TX	O	Not use	46	DRF	—	Connected to GND
7	MCLK	I	μ-com command clock signal input (Data is latched at signal's rising point)	47	DSL F	I/O	Loop filter pin for DSL
8	MDATA	I	μ-com command data input	48	PLL F	I/O	Loop filter pin for PLL
9	MLD	I	μ-com command load signal input	49	VCOF	—	Connected to GND
10	SENSE	O	Not used	50	AVDD2	—	Power supply (Analog)
11	FLOCK	O	Not used	51	AVSS2	—	Connected to GND(Analog)
12	TLOCK	O	Not used	52	EFM	—	Not used
13	BLKCK	O	Subcode · block · clock signal output	53	PCK	—	Not used
14	SQCK	I	Outside lock for sub-code Q resister input	54	PDO	—	Not used
15	SUBQ	O	Sub-code Q-code output	55	SUBC	—	Not used
16	DMUTE	—	Connected to GND	56	SBCK	—	Not used
17	STATUS	O	Status signal (CRC,CUE,CLVS,TTSTOP,ECLV,SQOK)	57	VSS	—	Connected to GND(for X'tal cscillation circuit)
18	RST	I	Reset signal input (L :Reset)	58	X1	I	Input of 16.9344MHz X'tal oscillation circuit
19	SMCK	—	Not used	59	X2	O	Output of X'tal oscillation circuit
20	PMCK	—	Not used	60	VDD	—	Power supply(for X'tal cscillation circuit)
21	TRV	O	Traverse enforced output	61	BYTCK	—	Not used
22	TVD	O	Traverse drive output	62	CLDCK	—	Not used
23	PC	—	Not used	63	FCLK	—	Not used
24	ECM	O	Spindle motor drive signal (Enforced mode output) 3-State	64	IPPLAG	—	Not used
25	ECS	O	Spindle motor drive signal (Servo error signal output)	65	FLAG	—	Not used
26	KICK	O	Kick pulse output	66	CLVS	—	Not used
27	TRD	O	Tracking drive output	67	CRC	—	Not used
28	FOD	O	Focus drive output	68	DEMPH	—	Not used
29	VREF	I	Reference voltage input pin for D/A output block(TVD,FOD,FBAL,TBAL)	69	RESY	—	Not used
30	FBAL	O	Focus Balance adjust signal output	70	IOSEL	—	Pull up
31	TBAL	O	Tracking Balance adjust signal output	71	TEST	—	Pull up
32	FE	I	Focus error signal input(Analog input)	72	AVDD1	—	Power supply (Digital)
33	TE	I	Tracking error signal input(Analog input)	73	OUT L	O	Lch audio output
34	RF ENV	I	RF envelope signal input(Analog input)	74	AVSS1	—	Connected to GND
35	VDET	I	Vibration detect signal input(H : detect)	75	OUT R	O	Rch audio output
36	OFT	I	Off track signal input(H : off track)	76	RSEL	—	Pull up
37	TRCRS	I	Track cross signal input	77	CSEL	—	Connected to GND
38	RFDET	I	RF detect signal input(L : detect)	78	PSEL	—	Connected to GND
39	BDO	I	BDO input pin (H : drop out)	79	MSEL	—	Connected to GND
40	LDON	O	Laser ON signal output (H : on)	80	SSEL	—	Pull up (+5V)

■ AN8806SB (IC601) : RF & SERVO AMP

1. Terminal Layout

PD	1	36	PDAC
LD	2	35	PDBD
LDON	3	34	PDE
LDP	4	33	PDF
VCC	5	32	PDER
RF-	6	31	PDFR
RF OUT	7	30	TBAL
RF IN	8	29	FBAL
C.AGC	9	28	FE-
ARF	10	27	FE OUT
C.ENV	11	26	TE-
C.EA	12	25	TE OUT
CS BDO	13	24	CROSS
BDO	14	23	TE BPF
CS BRT	15	22	VDET
OFTR	16	21	LD OFF
/NRFDET	17	20	VREF
GND	18	19	ENV

2. Block Diagram




3. Functions


Pin No.	Symbol	I/O	Functions and operations
1	PD	I	APC amp input terminal
2	LD	O	APC amp output terminal
3	LD ON	I	APC ON/OFF control terminal
4	LDP	--	Connected to ground
5	VCC	--	Power supply
6	RF-	I	Inverse input pin for RF amp
7	RF OUT	O	RF amp output
8	RF IN	I	RF input
9	C.AGC	I/O	Connecting pin of AGC loop filter
10	ARF	O	RF output
11	C.ENV	I/O	A capacitor is connected to this terminal to detect the envelope of RF signal
12	C.EA	I/O	A capacitor is connected to this terminal to detect the envelope of RF signal
13	CS BDO	I/O	A capacitor is connected to detect the lower envelope of the RF signal
14	BDO	O	BDO output pin
15	CS BRT	I/O	A capacitor is connected to detect the lower envelope of the RF signal
16	OFTR	O	Of-track status signal output
17	/NRFDDET	O	RF detection signal output
18	GND	--	Ground
19	ENV	O	Envelope output
20	VREF	O	Reference voltage output
21	LD OFF	--	Connect to ground
22	VDET	O	Vibration detection signal output
23	TE BPF	I	Input pin of tracking error through BPF
24	CROSS	O	Tracking error cross output
25	TE OUT	O	Tracking error signal output
26	TE-	I	Inverse input pin for tracking error amp
27	FE OUT	O	Output pin of focus error
28	FE-	I	Inverse input pin for focus error amp
29	FBAL	I	Focus balance control
30	TBAL	I	Tracking balance control
31	PDFR	I/O	F I-V amp gain control
32	PDER	I/O	E I-V amp gain control
33	PDF	I	I-V amp input
34	PDE	I	I-V amp input
35	PD BD	I	I-V amp input
36	PD AC	I	I-V amp input

■ LV1016 (IC541) : Dolby Surround Passive Decoder

1. Terminal Layout



2. Block Diagram




3. Pin Functions

Pin No.	Symbol	I/O	Functions
1	DGND	--	Digital GND
2	CLK	I	Serial interface clock
3	DATA	I	Serial interface data input
4	STB	I	Strobe signal input
5	NR-DET	--	Capacitor for noise reduction detection
6	NR-IREF	--	Resistor for noise reduction reference current
7	VCC	--	Supply
8	L-IN	I	Left channel signal input
9	R-IN	I	Right channel signal input
10	S-IN	I	Surround signal input
11	DELAY-OUT	--	Not used
12	DC-CUT	--	Capacitor for DC-cut
13	S-OUT	O	Surround signal output
14	VREF	--	Analog reference voltage
15	R-MIX-OUT	--	Not used
16	L-MIX-OUT	--	Not used
17	ADND	--	Analog ground
18	DC-CUT	--	Capacitor for DC-cut
19	D/A	--	Capacitor for integrator
20	NOISE SHAPER	--	Capacitor for noise shaper
21	A/D	--	Capacitor for integrator
22	VDD	--	Supply for the digital section
23	OSC	--	Oscillation terminal
24	OSC	--	Oscillation terminal

■ LA2786 (IC501) : Dolby Pro Logic Surround Signal Processor

1. Terminal Layout




2. Pin Functions


Pin No	Symbol	I/O	Functions	Pin No	Symbol	I/O	Functions
1	NS-BPF1	--	Capacitor for spectrum filter in noise sequencer	22	VCS-1	--	Capacitor for time constant (in log differential area)
2	NS-BPF2	--	Capacitor for spectrum filter in noise sequencer	23	VCS-2	--	Capacitor for time constant (in log differential area)
3	VREF	--	Analog reference voltage	24	VCS-TH	--	Capacitor for time constant (in log differential area)
4	S-DC-OUT	--	Capacitor for DC-cut Sch	25	L+R RECT	--	Capacitor for Center channel detection
5	C-DC-OUT	--	Capacitor for DC-cut Cch	26	DC-CUT	--	Capacitor for DC-cut at detection circuit
6	L-DC-OUT	--	Capacitor for DC-cut Lch	27	L-R RECT	--	Capacitor for Surround channel detection
7	R-DC-OUT	--	Capacitor for DC-cut Rch	28	DC-CUT	--	Capacitor for DC-cut at detection circuit
8	VREF-BUFFER	--	VREF low impedance	29	R-BPF3	--	LPF,HPF for Right channel control circuit
9	L-IN	I	Left channel signal input	30	R-BPF2	--	LPF,HPF for Right channel control circuit
10	R-IN	I	Right channel signal input	31	R-BPF1	--	LPF,HPF for Right channel control circuit
11	GND	--	Ground	32	C-TRIM DC-CUT	--	Capacitor for DC-cut Center channel
12	L-BPF1	--	LPF,HPF for Lch control circuit	33	C-MODE-CAP	--	Capacitor for Center channel output low-pass filter
13	L-BPF2	--	LPF,HPF Left channel control circuit	34	C-OUT	O	Center signal output
14	L-BPF3	--	LPF,HPF Left channel control circuit	35	S-OUT	O	Surround signal output
15	DC-CUT	--	Capacitor for DC-cut at detection circuit	36	R-OUT	O	Right channel signal output
16	R RECT	--	Capacitor for Right channel detection	37	L-OUT	O	Left channel signal output
17	DC-CUT	--	Capacitor for DC-cut at detection circuit	38	VCC	--	power supply
18	L RECT	--	Capacitor for Left channel detection	39	OSC	--	Oscillation for noise sequencer and auto balance
19	VLR-TH	--	Capacitor for time constant (in log differential area)	40	STB	I	Strobe signal input
20	VLR-2	--	Capacitor for time constant (in log differential area)	41	DATA	I	Serial interface data input
21	VLR-1	--	Capacitor for time constant (in log differential area)	42	CLK	I	Serial interface clock

■ XR1099(IC903) : 7-channel graphic equalizer filter with A/D converter (Only used for universal type)

1. Internal Block Diagram




2. Terminal Layout




3. Terminal Description

Pin No	Symbol	I/O	Function	Pin No	Symbol	I/O	Function
1	CSB	I	Chip select	9	TEST	--	TEST Terminal
2	STB	I	Strobe signal	10	VSS	--	-5V
3	SPIDTO	I	Data input	11	RIN	I	Connected to GND
4	SPIDTI	O	Data output	12	LIN	I	Sound signal input
5		--	Non connection	13	GND	--	GND
6		I	Connected to GND	14		I	Connected to GND
7	L A/D	I	Connected to GND	15	CLK	I	A resister is connected
8	R A/D	I	Connected to GND	16	VCC	--	+5V

■ HA12136A(IC231) : NR amplifier




■ BA6897FP(IC602) : 4channel driver




T.S.D : sermal shat down
 D.BUF : Drive buffer

■ GP1U271X (IC904) : Receiver for remote controller




■ HA12206NT (IC305) : P.B & EQ/REC Amp.

Block Diagram




■ LA2650 (IC406) : SA BASS


Block Diagram



■ BA15218 (IC402,403,407,562,912) :
Dual OP Amp.



■ BA15218N (IC302,303) : Dual OP Amp.




■ BU9252S (IC915) : Delay Circuit (Only used For U,UB,UP,UT,US)

Terminal layout

S/H	1	18	VCC
IN	2	17	TST0
GND	3	16	TST1
OUT	4	15	TST2
VDD	5	14	TDIN
DCNT1	6	13	TDO0
DCNT2	7	12	TDO1
DCNT3	8	11	OSC
GND	9	10	OSC

Block Diagram



Description


Pin No	Symbol	Function	Pin No	Symbol	Function
1	S&H	A capacitor is connected for sample & hold	10	OSC0	Oscillation terminal
2	AIN	Analog input	11	OSC1	Oscillation terminal
3	GND	GND	12	TDO1	Not used
4	AOUT	Analog output	13	TDO0	Not used
5	VDD	Power supply	14	TDIN	Not used
6	DCNT0	Pull up (+5V)	15	TST2	Not used
7	DCNT1	Pull up (+5V)	16	TST1	Not used
8	DCNT2	Pull up (+5V)	17	TST0	Not used
9	GND	GND	18	VCC	Power supply

■ BA7725S (IC914) :Echo circuit Analog Compantor:(Only used For U,UB,UP,UT,US)

Terminal layout

LINE OUT	1	22	MICAMPIN
LINE IN	2	21	MICAMPOUT
NC	3	20	NC
ECHO LEV CTRL	4	19	VCC
GND	5	18	RIPPLE FILTER
LOOP GAIN CTRL	6	17	CMP DET
EXP DET	7	16	CMP DET CT
EXP DET CT	8	15	CMP OUT
EXP BF OUT	9	14	CMP BF IN
EXP BF IN	10	13	CMP BF OUT
DLY BF OUT	11	12	DLY BF OUT



Block Diagram





Terminal Description

Pin No.	Symbol	I/O	Function
1	LINE OUT	O	Line output
2	LINE IN	I	Line input
3	NC	--	Not used
4	ECHO LEV CTRL	I	Determines echo level. The echo circuit is off when 1 volt is added. The echo level varies according to the voltage from 2 volts to 9 volts.
5	GND	--	Analog GND
6	LOOP GAIN CTRL	I	Loop gain control terminal. The gain varies according to the voltage from 2 volts to 9 volts.
7	EXP DET	I	Detection terminal for expand circuit
8	EXP DET CT	I	Determines the attack and recovery time of expand circuit
9	EXP BF OUT	O	Buffer output for LPF (Expand circuit side)
10	EXP BF IN	I	Buffer input for LPF (Expand circuit side)
11	DLY BF OUT	O	Delay buffer output
12	DLY BF IN	I	Delay buffer input
13	CMP BF OUT	O	Buffer output (Compress circuit side)
14	CMP BF IN	I	Buffer input (Compress circuit side)
15	CMP OUT	O	Compress circuit output
16	CMP DET CT	I	Determines the attack and recovery time of compress circuit
17	CMP DET	I	Detection terminal for compress circuit
18	RIPPLE FILTER	I	A capacitor is connected for ripple elimination filter
19	VCC	--	Power supply
20	NC	--	Not used
21	MIC AMP OUT	O	Mic amp output
22	MIC AMP IN	I	Mic amp input

Main parts Layout






Disassembly Pocedures



(1) Removing the top cover

- 1.Remove 2 screws(Aí)fasteng both sides of top cover,and 6 screws(A) fasting the rear side.
- 2.Remove the top cover.





(2) Removing the changer mechanism ass'y

- 1.Remove 2 screws(B)fasteing up side(Fig.2).
- 2.Remove 2 screws(C)fasteing rear side.
- 3.Remove 2 screws(B) holding the PCB's.
- 4.Disconnect the CN811,CN614,CN613
- 5.Remove the changer mechanism ass'y(Fig.3).



(3) Removing the rear panel and Tuner PCB

- 1.Remove 11 screws(D)fasteing rear side and remove the heat sink cover(Fig.5).
(Remove 2 screws(Dí) only universal type)
- 2.Remove 3 screws(D)holding the heat sink.
- 3.Remove the rear panel and Tuner PCB.



(4) Removing the Front panel ass'y

- 1.Remove the CDchanger mechanism.
- 2.Disconnect the CN411,CN412 and CN915,CN322.
- 3.Remove 2 screws(D)hololding the Front panel ass'y.
- 4.Remove the 3 hooks fastening both sides of Front panel ass'y.




Fig.6

(5) Removing the Cassette deck control PCB.

- 1.Remove the Front panel Ass'y
- 2.Disconnect the CN331,CN332.
- 3.Remove 2 screws(D)holding the Cassette deck control PCB.




Fig.7

(6) Removing the Cassette deck mech. ass'y

- 1.Remove the Front panel Ass'y.
- 2.Remove the Cassette deck control PCB.
- 3.Remove 4 screws(E) and 4 screws(F) holding the Cassette mecanism ass'y.




Fig.8

(7) Removing the Amp /Speaker out/Source select PCB

- 1.Remove the CD changer mech. and rear panel.
- 2.Disconnect the CN411,CN412,CN701,and Take the Source select PCB on the Power supply PCB.
- 3.Disconnect the CN915,and Take the Power amp and




Fig.9

(8) Removing the Power supply PCB

- 1.Remove the CD changer mech. and rear panel, and take the Source select PCB,Amp PCB and Speaker out PCB.
- 2.Disconnect the CN009,CN111.
- 3.Remove the 3 screws(D) holding the Power supply PCB.
- 4.Remove the Power supply PCB.

(9) Removing the Power Trans.

- 1.Remove the CD changer mech.
- 2.Disconnect the CN009,CN111.
- 3.Remove the 4 screws(I)holding the Power Trans.
- 4.Remove the Power Trans..




Fig. 10

(10) Removing the Front PCB

- 1.Remove the Front panel Assy.
- 2.Remove the deck control PCB.
- 3.Remove the 4 screws(H)holding the Bracket. (Remove the 2 screws(Hi)holding the mic.P.C.B. Only universal type.)
- 4.Remove the 9 screws(H)holding the Front PCB.
- 5.Remove the 5 screws(H)holding the deck sw and main volume PCB.
- 6.Remove the Front PCB and deck sw PCB.




Fig. 11




Fig. 12

(11) Removing the Power IC

- 1.Remove the Amp PCB and Regulator PCB with the heatsink.
- 2.Remove 3 screws(G)holding the Amp PCB and Remove it.
- 3.Unsolder the Power IC terminals.
- 4.Remove the Power IC.




Fig. 14





Fig. 13

(12) Removing the Capstanmotor control PCB

- 1.Remove the cassettemechanism ass'y.
- 2.Remove the 2 screws (J)holding the capstanmotor control PCB.
- 3.Remove the capstanmotor control PCB.



Capstan motor control PCB

Fig.15

(13) Removing the Cassette door

- 1.Remove the cassettemechanism ass'y
- 2.Push the Cassette doorholder both side.
- 3.Remove the cassette door.(See Fig.16)




Fig.16

(14) Fix the Cassette Holder spring

- Fix holder spring before fix guide .
and cassette mech.(See Fig.17)





Fig.17



Cassette Mech. Ass'y removal

(15) Head assembly removal

1. Remove the Cassette mech. ass'y.
2. Remove the flexible wire from the cassette deck and remove the 3 screws $\text{\textcircled{K}}$ holding the head ass'y.




Fig.18 Cassette mechanism top view

(17) Pinch roller (FWD/REV) removal

1. Remove the cassette mech. assembly.
2. Remove the hook holding the pinch roller.
3. Remove the pinch roller ass'y.




Fig. 20 Cassette mechanism bottom view

(16) Head assembly

1. The direction of the head is changed with the direction lever. When servicing, install the direction lever according to the direction of the head assembly.




Fig.19-A Head ass'y side view




Fig.19-B A distance of between head older and azimuth screw

(18) Capstan motor removal.

1. Remove the cassette mechanism.
2. Remove the cassette deck control PCB.
3. Remove the 6 screws (L) holding the bracket.
4. Remove the hooks (■) of the bracket.
5. Put the cutting on the flywheel A together the bracket's pall as shown in fig. 22(Flywheel A) and check that the flywheel B is removed from the bracket's pall (fig. 22-Flywheel B).
6. Remove the capstan motor with the bracket.
7. Unsolder the broken flat wire of the capstan motor.
8. Remove the 2 screws fixing the motor and the bracket.

* To remove the bracket, it is easier to remove mech. "B" first.
Vice versa, assembling mech. "A" is easier for reassembly.

8.7 ± 0.05mm




Fig. 21 Capstan motor pulley installation

(19) Flywheel removal

1. Remove the cassette mechanism assembly.
2. Remove the cassette amp PCB.
3. Remove the 6 screws (L) and the bracket.
4. Remove the 4 hooks of the bracket.
5. Remove the bracket.
6. Remove the flywheels.

*The oil on the capstan must be wiped out after reassembling.




Fig. 22-A




Fig. 22-B

(20) How to install the belts

1. Install the flywheels and belts as shown in the figure below . (Fig. 23)

When putting the belts, put the long belt first.

2. Install the main reels to put the belts on the flywheels.




Fig. 23-A Install the Bracket and flywheels





Fig. 23-C Install the cassette mech.



REEL BELTS → After hooking reel belts, no twist .






Fig. 23-B Install the Belts

②Belt(Short)

①Belt (long)

(21) Switch PCB removal

1. Remove the flywheel .
2. Remove the 1 screw (M) .
3. Unsolder the broken solenoid.
4. Release the 4 hooks holding the Switch PCB.
5. Remove it.



When attach the FM bracket,
Install the reel belt on the stud
(See fig. 23)

Fig. 24

(22) Control cam removal

1. Remove the FM bracket and flywheel .
2. Pull out the main pulley .
3. Remove the trigger arm .
While opening the two tabs (a) under the trigger arm, pull out the trigger arm from the shaft.
4. Pull out the elevator ring .
5. Remove the FWD/REV arm assembly .
a. Remove the FWD/REV arm spring.
b. While opening the four FWD/REV arm retaining tabs (b) outwards, pull out the FWD/REV arm .
6. Pull out the control cam .
While pulling the shaft stopper section of the control cam in the central direction, pull out the control cam .

When attaching the control cam

While pressing the FWD/REV arm in the direction of the sorrow, pull the head the front.





Fig. 25-c

Moving area of the trigger arm.
Position of the hole and the stud after fixing the FR arm ass'y.



Position of the hole of cam and top of the arm after fixing the FR arm ass'y.

Fig. 25-a




Fig. 25-b

After performing the procedure shown above, the studs under the control cam move as shown.





Fig. 25-d

(23) How to assemble


1. Move the FWD/REV arm in the direction of the arrow .
2. In step 1 ,pull the head base forward .
3. In step 2 ,after inserting the cam into the shaft ,move the head base and FWD/REV arm slightly until the cam is fully inserted and it clicks to inform when it has been locked .
4. Rotate the cam counterclockwise to check if the cam rotates smoothly and the spring clicks according to the forward/backward movement of the head base .
5. After checking the rotation of the cam ,rotate the cam until the notch section comes to the right so that the FWD/REV arm assembly can be attached .
6. Attach the FWD/REV arm assembly while observing the positioning of:
 - the hole and stud
 - the cam hole and arm edge
 shown in the figure 25-a .
 After attachment ,move the FWD/REV arm in the direction of the arrow to check if it moves back to the original position .
7. Attach the elevator ring .
8. Attach the trigger arm .
 After attachment ,move the trigger arm in the direction of the arrow to check if it moves back to the original position .

Working confirmation:
 If the control cam rotates counterclockwise ,the assembly was successful: if it does not rotates . It must be reassembled .



Fit the control cam its notch located as shown . (Engage with the gear of the control cam while moving the FWD/REV arm and head base slightly .)

Fig. 26-a



Attach the FWD/REV arm with the control cam rotated up to the position shown .

Fig. 26-b

CD Changer mech. Ass'y removal

(24) CD Tray assembly removal

1. Disassemble the changer mech..
2. Remove the screw ③ holding the stopper bracket.(See Fig.27) ---- (U.S.A only)
3. Remove the rod from both ends' hooks which are secured on T.Bracket ② and clamber base ①. [See Fig. 27)
4. Remove 3 screws ④ securing T.Bracket.(See Fig. 29.)
5. Remove a screw ⑤ securing center of the clamber ass'y. (See Fig. 28)
6. Remove the clamber ass'y from ★ screw fixing side.
7. Remove a screw ⑥ which secures the return spring and lock levers from the chassis ass'y.(See Fig. 30.)
8. Remove 2 palls ⑦ which slightly secure the return spring to remove it.
9. Remove 3 lock levers.
10. Check that the lifter unit stopper is inserted into hole ⑧ located on CD tray ass'y. (See Fig. 31.)
11. Check that the driver unit elevator is seen from a hole (marked ⑨) on left side of the CD changer mech..(See Fig. 32 and 33.)
[NOTE] Set the elevator in correct position (Fig. 33) by rotating the pulley gear with finger if it is not positioned correctly (Fig. 34.).
12. Rotate the motor pulley clockwise with finger until the lifter unit's stopper is lowered from ⑧ hole located on the CD tray ass'y. (See Fig. 34.)
13. And, pull all 3 CD tray assemblies forward until they stop. (See Fig. 32.)
14. Press 2 pawls (f, f') located rear side of the CD tray ass'y according to an arrow ⑩ to remove the CD tray ass'y. (See Fig. 35.)
At first, removing the lowest tray is easier.




Fig. 27




Fig.28




Fig.29




Fig.30




Fig. 31




Fig. 32




Fig. 34




Fig. 33




Fig. 35

(25) CD mechanism removal

1. Remove the CD tray ass'y.
2. Rotate the Cam R1, R2 ass'y counterclockwise so that CD mech. ass'y's shaft ① is positioned as shown in Fig. 36.
3. Remove 4 screws ② securing CD mech. ass'y. (See Fig. 36.)

***How to replace pick-up unit**

1. If CD mech. is removed without disassembling CD mech. ass'y, rotate the Cam R1, R2 ass'y clockwise to set the CD mech. ass'y's shaft(L) as shown in Fig. 37.
2. Lift the CD mech. ass'y toward the direction ① to remove it from the lifter unit. (See Fig. 38.)




Fig. 36




Fig. 37




Fig. 38

(26) Actuator motor board removal

1. Unsolder 4 soldered point ① for both motors. (See Fig. 39.)
2. Remove a screw ③ securing the CD servo board. (See Fig. 39.)
3. Press the hook and release it to remove the CD servo board.
4. Remove 2 screws ④ securing the actuator motor board. (See Fig. 39.)
5. Remove 2 screws ⑤ securing the tray select switch board. (See Fig. 40.)




Fig. 40




Fig. 39

(27) Cam unit removal

1. Disassemble CD mech. ass'y.
2. Rotate the Cam gear L so that the drive unit's pole ⑫ is positioned as shown in Fig. 41.
3. Remove the drive unit and cylinder gear. (See Fig.42.)
4. Rotate the Cam gear L so that the select gear's ⑬ is positioned as shown in Fig.43.
5. Remove 4 screws ④ securing the cam unit which includes the cam gear L and Cam R1, R2 ass'y. (See Fig 43.)




Fig. 41




Fig. 42




Fig. 43

(28) Removal for actuator motor and belt

1. Remove 2 screws \textcircled{P} securing the gear bracket.
(See Fig. 44.)
2. Press the pawl \textcircled{M} securing the gear bracket to the arrow in the figure to remove the gear bracket. (See Fig. 44.)
3. Remove the gear bracket from the chassis ass'y's \textcircled{N} securing top of the gear bracket. (See Fig. 45.)
4. Remove each belts from the both actuator motor pulleys and the pulley gears. (See Fig.44.)
5. Reverse the chassis ass'y and widen 4 poles \textcircled{O} which secure both actuator motors to its arrows to remove the actuator motors. (See Fig.46.)

[NOTE] The pulley gears and other gears which consist the gear unit may drop separately if the chassis ass'y is reversed without gear bracket and belt. See Fig. 47 to assemble them again.




Fig. 44




Fig. 45




Fig. 46




Fig. 47

(29) Removal of cam R1,R2 ass'y and cam gear L

1. Remove the slit washer securing Cam R1, R2 ass'y.
(See Fig. 48.)
2. Remove 2 poles ⑤ securing Cam R1 to remove Cam R2 from Cam R1.
3. Remove the slit washer securing Cam gear L.
4. Remove Cam gear L from the C.G. base ass'y.




Fig. 48

(30) Removal of C.G. base ass'y

Remove 3 screws ④ securing the C.G. base ass'y. (See Fig. 48 and 49.)

[NOTE] Set the drive unit's pawl ⑥ so that it is positioned as shown in Fig. 49.
Confirm that the cam gear L engages with the gear unit by rotating the cam gear L.




Fig. 49

- (31) Removing the Pickup
1. Remove the CD mech. assembly.
 2. Release the shaft to remove the pickup .




Fig. 50

- (32) Spindle motor installation
1. Tighten the 2 screws to the same torque.
 2. Fasten the spindle and feed motor P.C. board with the screw and solder.
 3. Install the turntable. When installing, press straight down at the center of the turntable until the distance from the surface of the mech. base to the turntable is exactly $19.4 \pm 0.1\text{mm}$.




Fig. 51

- (33) Removing the Spindle motor
1. Remove the CD mech. assembly.
 2. Remove the turntable, and remove the 2 screws ⊗ retaining the spindle motor.
 3. Remove the screw retaining the spindle and feed motor circuit board and unsolder it.




Fig. 52

- (34) After inserting the turntable, bond the motor shaft and turntable together (at the section marked by an arrow in fig 53 on the left below).





Fig. 53

- (35) Use "LOCKTITE" #460 bonding agent, and apply as little as possible .
 Take care not to allow any excess bonding agent to get onto the turntable .
 Be extremely careful not to allow bonding agent to adhere to the motor bearing (the section marked by an allow in fig. 53 on the right).

Connected an extension cord

1. Remove the CD changer mechanism ass'y.
2. Disconnect the 7pin wire from the CN613 (Source selector & SEA P.C.B) and disconnect the 7pin wire.
3. Connected the extension cord CN603 to CN613.



Adjustment procedures

■ Tuner section




Fig.1

Clock Adjustment

1. After connecting B863 and B864 with some wire as shown in the figure below, connect the AC power cord into an AC outlet.
2. Confirm that the display is off and remove the wire.
3. Connect a frequency counter to TP303 B862 and B808.
4. Adjust TC902 for the frequency $50000 \pm 0.29\text{Hz}$.

(1) Tuning voltage

Confirm the voltages at TP101 is within the standard values shown in the table below. If the voltages are not satisfied, replace T111 for MW 5or FE101 for FM .

Tuning range & Tuning voltage (Unit : V)

Area	Range				
	LW (kHz)	MW (kHz)	FM (MHz)	FM TU.VOL	
				87.5MHz	108.0MHz
*	144~288	522~1629	87.5~108.0	1.6 ± 1.0	8.0 ± 2.0
the U.S.A,Canad	—	530~1710	87.5~108.0	1.6 ± 1.0	8.0 ± 2.0
Universal type(AM Channel space 9kHz)	—	531~1602	87.5~108.0	1.6 ± 1.0	8.0 ± 2.0
Universal type(AM Channel space 10kHz)	—	530~1600	87.5~108.0	1.6 ± 1.0	8.0 ± 2.0
Easern Europe	144~288	522~1629	65.0~74.0 87.5~108.0	65.0MHz > 1.3	108.0MHz < 11

* MARK:Australia,Continental Europe,Nordic Countries, the U.K,



AM Tuning voltage (Unit : V)

Area	Frequency (MW)							Frequency (LW)	
	522KHz	530KHz	531KHz	1600KHz	1602KHz	1629KHz	1710KHz	144kHz	288kHz
A,the U.K. , Europe	>0.7	—	—	—	—	<8.3	—	0.5 <1.0	5.0 <7.5
the U.S.A,Canad	—	>0.8	—	—	—	—	<8.8	—	—
Universal (Chanel space9kHz)	—	—	>0.8	—	<7.9	—	—	—	—
Universal (Chanel space10kHz)	—	>0.8	—	<7.9	—	—	—	—	—

(2) FM center meter

Receive a broadcast which understanding the frequency by using the function of 'MANUAL SEARCH'. Adjust T141 (detector coil) so that the voltage at TP102 becomes $0 \pm 1.5\text{mV}$.

■ Deck Adjust point



Deck section


1. Measuring instruments

- Audio frequency signal generator (0dbS output at the 600 ohm output terminal from 50Hz to 20KHz)
- Electronic voltmeter
- Frequency counter
- Wow & Flutter meter
- Distortion Meter with band pass filter
- Attenuator (600 ohm impedance)
- A resistor with 600Ω


Tape No.	Frequency	Level (Wow & Flutter)	Purpose
VTT-703L	10kHz	- 10dBs	Head azimuth , Frequency Response
VTT-712	3000Hz	0dBs 0.025% WRMS	Tape Speed , Wow & Flutter
VTT-724	1kHz	- 4dBs	Standard Level
TMT-6447	—	—	Blank Skip
TMT-6247 , TMT-6237	—	—	Music Scan
TMT-7088S	—	—	Recording standard Normal : UR
AC-712	—	—	Recording standard METAL : MA
AC-513	—	—	Recording standard CrO ₂ : SA
TW-2111, TW-2121	—	—	Forward / reverse play torque measuring
TW-2231	—	—	Feed forward / rewind torque measuring
C-120 Tape	—	—	Confirming the tape running

2.Adjustment and repairing the mechanism

Item	Adjustment method	Standard value	Remarks
Head azimuth	<p>Deck A</p> <ol style="list-style-type: none"> 1. Connect an electronic voltmeter to the NR TP901 (figure 2) to playback VTT-703L. 2. Adjust screw ① so that the indication of the voltmeter becomes maximum when PLAY (▶) is pressed. 3. Adjust screw ② so that the indication of the voltmeter becomes maximum when PLAY (◀) is pressed. <p>Deck B</p> <ol style="list-style-type: none"> 4. Adjust screw ③ so that the indication of the voltmeter becomes maximum when PLAY (▶) is pressed. 5. Adjust screw ④ so that the indication of the voltmeter becomes maximum when PLAY (◀) is pressed. 6. After making the adjustment, apply screw lock to prevent screws ①, ②, ③ and ④ coming loose. 	Maximum	<ol style="list-style-type: none"> 1. Refer to figure 3. 2. When the specified characteristic cannot be obtained because of head wear, excessive magnetization, etc., replace the head assembly and adjust the head azimuth. Also, perform the electric adjustment. 3. When there is the difference of more than 3 ~ 4 dB between left and right output levels, replace the head assembly to avoid complaints.
Playback torque	1. Measure the torque in the playback mode by the torque meter.	26 ~ 72 g-cm	When the standard torque cannot be obtained, replace the FR arm assembly or motor.
Fast forward torque	1. Measure the torque in the fast forward mode by the torque meter.	75 ~ 175 g-cm	When the standard torque cannot be obtained, replace the FR arm assembly or motor.
Rewind torque	1. Measure the torque in the rewind mode by the torque meter.	75 ~ 175 g-cm	When the standard torque cannot be obtained, replace the FR arm assembly or motor.
Wow & flutter	<ol style="list-style-type: none"> 1. Connect the wow & flutter meter to the DOLBY TP (figure 2) and play back VTT-712. 2. Its reading should be within 0.25% (WTD). 	Less than 0.25%	As a complaint may occur if the wow & flutter fluctuates by 0.1% even though it is allowed in the standard, repairing is required.



Deck A



Deck B

Fig.3

3. Electrical Adjustments (Make the following adjustments after adjusting the head azimuth.)

In principle, the adjustments should be made in the following sequence.

Set the NR switch to OFF and the BEAT CUT switch to "1".

Adjustments marked with an asterisk (*) should always be made after the head is replaced

0dBs=0.775V

Item	Adjustment Method	Adjustment Location	Standard Value	Remarks
Tape Speed	1. Connect a frequency counter to the NR TP 901 (figure 2) and play back VTT-712 . 2. Adjust the semi-fixed resistor VR901 on ENH-292 - 1 (figure 2).	VR233	3,000 Hz ±10Hz	Connect a wow & flutter meter with a built-in frequency counter to the speaker terminals.
* Standard level (Playback Level)	1. Connect an electronic voltmeter to the NR TP901 (figure 2) . Play back VTT-724 (1 kHz : -4dBs) to adjust the semi - fixed resistors.	Deck A L: VR301 R: VR302 Deck B L: VR303 R: VR304	488mV (-4dBs)	1) The playback level varies when the head is replaced so should be adjusted. Use an electronic voltmeter with an impedance of 100 kΩ or more.
* Playback Frequency Response	1. Connect an electronic voltmeter to the NR TP 901 (figure 2) . 2. Play VTT-703L (10kHz : -10dBs) and adjust semi-fixed resistors to obtain the standard values.	Deck A L: VR305 R: VR306 Deck B L: VR307 R: VR308	245mV (-10dBs)	—
* Recording Bias Frequency	1. Connect a frequency counter to the BIAS TP (figure 2) , and perform a recording to adjust bias frequency .	L301	105 kHz ±5 kHz	
* Record / Play Frequency Response (Bias current)	1. Supply 1kHz and 12.5kHz with 30mV signals to AUX terminals respectively to record them. 2. Connect an electronic voltmeter to the NR TP901 (figure 2) to confirm the recorded values. 3. If the values are not satisfied , adjust the semi-fixed resistors and record the signal again to confirm the recorded values.	L : VR309 R : VR310	0±2 dB with 1 kHz as the standard.	Refer to figure 4 below. 1) The recording and playback frequency response of a cassette deck are adjusted by adjusting the bias. 2) Perform the adjustment with normal tape and confirm that the values are within the range for metal tape.





Fig.4

Flow of Functional Operation Until TOC is Read



Maintenance of Laser Pickup


(1) *Cleaning the pick up lens*

Before you replace the pick up, please try to clean the lens with a alcohol soaked cotton swab.

(2) *Life of the laser diode (Fig.1)*

When the life of the laser diode has expired, the following symptoms will appear.

- (1) The level of RF output (EFM output: amplitude of eye pattern) will be low.



(Fig.1)


(3) *Semi-fixed resistor on the APC PC board*

The semi-fixed resistor on the APC printed circuit board which is attached to the pickup is used to adjust the laser power. Since this adjustment should be performed to match the characteristics of the whole optical block, do not touch the semi-fixed resistor.


If the laser power is lower than the specified value, the laser diode is almost worn out, and the laser pickup should be replaced.

If the semi-fixed resistor is adjusted while the pickup is functioning normally, the laser pickup may be damaged due to excessive current.

Replacement of Laser Pickup



Block Diagrams



Schematic Diagrams

Primary With Main Power Supply Section


EXPLANATION MODEL CA-

SHEET NUMBER	MODEL NUMBER TO BE APPLIED
1/11	CA-D701T/CA-D701TR/CA-D851TR
2/11	CA-D701T/CA-D701TR/CA-D851TR
3/11	CA-D701T/CA-D701TR/CA-D851TR
4/11	CA-D701T/CA-D701TR/CA-D851TR
5/11	CA-D701T/CA-D701TR/CA-D851TR
6/11	CA-D701T/CA-D701TR/CA-D851TR
7/11	CA-D701T
8/11	CA-D851TR
9/11	CA-D701T
10/11	CA-D701T/CA-D701TR/CA-D851TR
11/11	CA-D701T/CA-D701TR/CA-D851TR

VERSION CODES

J : U.S.A.
 C : CANADA
 EN : NORDIC COUNTRIES
 EF : CONTINENTAL EUROPE EXCEPT GERMANY
 G : GERMANY
 VX : EASTERN EUROPE
 BS : U.K.
 A : AUSTRALIA
 UP : KOREA
 UB : HONGKONG
 US : SINGAPORE
 UT : TAIWAN
 U : UNIVERSAL EXCEPT ALL OF ABOVE

NOTES:
 MARK (*) IS TO SHOW DEVIATION
 DETAILS ARE EXPLAINED NEARBY



A

B


C

D

EXPLANATION OF OVERALL OF SCHEMA.
MODEL CA-D701T/CA-D761T/CA-D851TR

MODEL NUMBERS TO BE APPLIED	CIRCUITS DESCRIPTION
CA-D701T/CA-D761T/CA-D851TR	· PRIMARY WITH MAINS TRANSFORMER
CA-D701T/CA-D761T/CA-D851TR	· DC REGULATORS/AUDIO OUTPUT
CA-D701T/CA-D761T/CA-D851TR	· EXTERNAL SIGNAL INPUT · SOURCE SELECTOR SWITCH · MIC AMPLIFIER
CA-D701T/CA-D761T/CA-D851TR	· TAPE DECK MECHANISMS CONTROL · MISCELLANEOUS CIRCUITS FOR TAPE DECK SUCH AS AMPLIFIER, SWITCH, BIAS AND OTHERS
CA-D701T/CA-D761T/CA-D851TR	· FL DISPLAY/USER CONTROL KEYS FOR TUNER SECTION AND AUDIO DISC/SYSTEM CONTROL LSI FOR TUNER SECTION
CA-D701T/CA-D761T	· (ONLY FOR J, C, U, UB, US, UT, UP, A) TUNER RF/IF/FM MULTIPLEX
CA-D701T	· (ONLY FOR EF, EN, BS, G) TUNER RF/IF/FM MULTIPLEX
CA-D851TR	· (ONLY FOR EF, EN, BS, G) TUNER RF/IF/FM MULTIPLEX/RDS SIGNAL PROCESSOR ICs
CA-D701T	· (ONLY FOR VX) TUNER RF/IF/FM MULTIPLEX
CA-D701T/CA-D761T/CA-D851TR	· AMPLIFIER FOR AUDIO DISC · SYSTEM CONTROL LSI FOR AUDIO DISC
CA-D701T/CA-D761T/CA-D851TR	· AUDIO DISC MECHANISMS CONTROL


TO SHOW DEVIATION IN VERSIONS.
 E EXPLAINED NEAR THE MARK.




Tuner Section: Only used for J,C,U,UB,US,UT,UP,A version)

FOR CA-D761T J, C
CA-D701T A, U, UB, US, UT, UP

ENA-178




FROM CN101 OF ENB-255-9 (SHEET 3/11)



* MARK

	CA-D761T J. C	CA-0701T U. UB. US. UT. UP. A
C137	680P	560P
C139, 140	0.033TF	0.022TF
CF101, 102	QAX0284 -001Z	QAX0285 -001Z
R130	68 UNF. C (1/4W)	68 UNF. F (1/4W)
R147	15k	27k

RF101
EAF2207-001



Notes:

1. indicates Main signal path.
2. indicates REC. signal path.
3. indicates CENTER & REAR signal path.
4. When replacing the parts in the darkened are () and those marked with , be sure to use the designated parts to ensure safety.
5. This is the standard circuit diagram.
The design and contents are subject to change without notice.

Tuner Section: Only used for EF,EN,BS,G version)

FOR CA-D701T EF, EN, G, BS (WITHOUT RDS)



5

4

3

2

1



A

B


C

D


Tuner Section: Only used for VX version)

FOR CA-D701 VX
ENA-178

□ FM 87.5MHz NO SIGNAL
() MM522 KHz NO SIGNAL
[] LW 144KHz NO SIGNAL
| | FM65.0MHz NO SIGNAL



RF101
EAF2302-002



5

4

3

2

1


2-52

A

B

C

D




FROM CN101 OF
ENG-25-9
(SHEET 3/11)

E

F

G

H




J

I

H

G

F



4

3

2

1

E

D

C

B

A


External Signal Input/Source Selector Section



7

6

5

4





* MARK

SYMBOL NO.	U, US, UP, UT, UB	D741		D851TR	D761T
		A	BS, EF, EN, G, VX	BF, EN, G	J, C
C453-455	USED	NONE	NONE	NONE	USED
R445-448	USED	NONE	NONE	NONE	USED
R478, 479	NONE	USED	USED	USED	USED
C457-462	USED	NONE	NONE	NONE	NONE
D401, 402	USED	NONE	NONE	NONE	NONE
IC403	USED	NONE	NONE	NONE	USED
IC404	USED	NONE	NONE	NONE	NONE
R423-425	USED	NONE	NONE	NONE	NONE
R426, 427	USED	NONE	NONE	NONE	SHORT
R428-430	USED	NONE	NONE	NONE	NONE
C451, 452	USED	NONE	NONE	NONE	NONE
R443, 444	USED	NONE	NONE	NONE	NONE
R455, 456	4.7K	3.9K	3.9K	3.9K	3.9K
R409, 410	4.7K	3.3K	3.3K	3.3K	4.7K
R457, 458	7.5K	7.5K	7.5K	7.5K	5.6K
R565, 566	1.6K	1.6K	1.6K	1.6K	1.3K
S490	NONE	NONE	USED	USED	NONE
R490	NONE	NONE	USED	USED	NONE
C484	NONE	NONE	NONE	NONE	USED


F


G

H

J

Tape Deck Mechanisms Control/Deck Amplifier Section





A MARK


	U, DR, U UT, UP	CA-D701T A	CP, EX, G ES, VU	CA-D701T J, C	CA-D854TB EX, EN, G, BE
C319	NONE	NONE	0.022	NONE	0.022
C317	NONE	NONE	880P	NONE	560P
C328	NONE	NONE	0.022	NONE	0.022
D343	NONE	NONE	480 178	NONE	380 173
U301	88V7148-083	NONE	NONE	NONE	NONE
U302	88V7148-084	NONE	NONE	NONE	NONE
K301-K303	SHORT	SHORT	88V81-007	SHORT	88V81-007
K321	SHORT	SHORT	88V81-007	SHORT	88V81-007
K322	SHORT	SHORT	88V81-007	SHORT	88V81-007
Q320	NONE	NONE	28V 1488L 80	NONE	28V 1488L 80
Q321	NONE	NONE	WRA1044	NONE	WRA1044
K308	NONE	NONE	580	NONE	560
D365, 366	SHORT	SHORT	.47	SHORT	.47
K308, 309	SHORT	SHORT	.47	SHORT	.47

7

6

5

4



J

I


H

G

F

Q320	DIODE	2N2134GR BR 50	DIODE	2N2134GR BR 50
Q321	DIODE	1N4001	DIODE	1N4001
R308	RESISTOR	500	RESISTOR	500
R375, R384	SHORT	SHORT	SHORT	SHORT
R382, R384	SHORT	SHORT	SHORT	SHORT

ENB-255-31



E

D

C

B

A

2-55


4

3


2

1

TO CN22 OF
BNC-139-2
(SHEET 2/11)




4
3
2
1



* MARK LIST

	D701T			VXC	D851TR		D761T
	U, UT, UP, US, UB	A	EP, EN, O, BS		EP, EN, O	J, C	
B401	USED	USED	NONE	NONE	NONE	NONE	NONE
B426	USED	USED	USED	USED	NONE	USED	USED
B428	NONE	USED	USED	USED	USED	USED	USED
B429	NONE	USED	USED	USED	USED	USED	USED
C921-923	USED	NONE	NONE	NONE	NONE	USED	USED
C9402	NONE	NONE	NONE	NONE	USED	NONE	NONE
D931	USED	NONE	NONE	USED	NONE	NONE	NONE
D932	NONE	NONE	NONE	USED	NONE	USED	USED
D933	USED	USED	NONE	NONE	NONE	USED	USED
D935	USED	NONE	NONE	NONE	NONE	USED	USED
D936	NONE	NONE	NONE	NONE	USED	NONE	NONE
D941	USED	NONE	NONE	NONE	NONE	USED	USED
IC903	USED	NONE	NONE	NONE	NONE	USED	USED
R980-986	USED	NONE	NONE	NONE	NONE	USED	USED
R991	NONE	NONE	NONE	NONE	USED	NONE	NONE
R992	USED	NONE	NONE	NONE	NONE	NONE	NONE
R994	USED	NONE	NONE	NONE	NONE	NONE	NONE
R940-943	NONE	NONE	NONE	NONE	USED	NONE	NONE
S927-930	NONE	NONE	NONE	NONE	USED	NONE	NONE
R315	USED	NONE	NONE	NONE	NONE	USED	USED
D431, 411	NONE	NONE	NONE	NONE	NONE	USED	USED



F


G


H


I

J

■ CD Section








M CN613 OF
ENC-136-1
HEET 3/11)

4
3
2
1

TO CN811 OF
FMH-005-1
(SHEET 2/8)



4
3
2
1





TABLE 1 CAM PATTERN LIST

CAM NO	LCAM				ON	RCAM				POSITION
	0	1	2	3		4	5	6	7	
MAIN TRAY1	0	1	1	1	0	1	1	1	0	EMERGENCY
SUB TRAY1	0	0	1	1	0	1	1	0	0	TRAY1 STANDBY
CAM1 1	0	1	0	1	0	1	0	1	0	TRAY1 CHECKING
MAIN TRAY2	1	0	0	1	0	1	0	0	1	TRAY2 STANDBY
SUB TRAY2	1	1	1	0	0	0	1	1	1	TRAY2 CHECKING
CAM1 2	1	0	1	0	0	0	1	0	1	TRAY3 STANDBY
MAIN TRAY3	1	1	0	0	0	0	0	1	1	TRAY3 CHECKING
SUB TRAY3	1	0	0	0	0					
OFF	1	1	1	1	0	1	1	1	1	OFF

0=0V
1=5V



VMW1377

F


G


H

I

J


Printed Circuit Boards
MAIN AMP P.C.BORD(ENH-308)








5 6 7 8 9 10

FRONT P.C.BORD(ENB-255)



TUNER P.C.BORD(ENA-178)






5


6

7

8


CD P.C.BORD(ENN-488)






CA-D701T

CD CANGER CONTROL P.C.BORD





PARTS LIST

* All printed circuit boards and its assemblies are not available as service parts.

The Marks for Designated Areas

A . . . Australia
 BS . . . the U.K.
 EF . . . Continental Europe
 EN . . . Scandinavia
 G . . . Germany
 UB . . . Hong Kong
 U . . . Universal Type
 UP . . . Korea
 US . . . Singapore
 UT . . . Taiwan
 VX . . . East Europe
 No marks indicates all areas.

- Contents -

General Exploded View and Parts List -----	3-2
Changer Mechanism Ass'y and Parts List-----	3-5
■ Grease Point -----	3-5
CD Mechanism Ass'y and Parts List -----	3-7
■ Grease Point -----	3-7
Chassette Mechanism Ass'y and Parts List -----	3-8
■ Grease Point -----	3-8
Electrical Parts List -----	3-10
(ENH-308) -----	3-10
(ENB-255) -----	3-13
(ENC-139) -----	3-16
(ENN-488) -----	3-20
(ENA-178CM) -----	3-21
(ENA-178DM) -----	3-22
(ENA-178EM) -----	3-23
(Changer Control P.C. Board) -----	3-24
Accessories List -----	3-25
Packing Materials and Part Numbers -----	3-26

■ Parts List

Block No. **M1M1M1**

△	Item	Parts Number	Parts Name	Q'ty	Description	Area
	1	EFP-CAD701TE(S)	FRONT PANEL ASSY	1		
		EFP-CAD701TJ(S)	FRONT PANEL ASSY	1		
		EFP-CAD701TU(S)	FRONT PANEL ASSY	1		
	1-1	E103259-014SM	FRONT PANEL	1		A BS EF EN G VX
		E103259-015SM	FRONT PANEL	1		U UB UP US UT
	1-2	E406971-221	JVC MARK	1		
	2	E75896-001	SPACER	2		
	3	E209142-017SM	WINDOW SCREEN	1		
	4	E209144-001SM	PUSH BUTTON	1	SOUND	A BS EF EN G VX
		E209144-003SM	PUSH BUTTON	1	SOUND	U UB UP US UT
	5	E310199-001SM	SELECT KNOB	1		
	6	E310192-001SM	PUSH BUTTON	1	DISC	
	7	E310189-003SM	INDICATOR LENS	1	JOY	
	8	E310194-001SM	PUSH BUTTON	1	SURR. ON/OFF	
	9	E409555-001SM	INDICATOR LENS	1	STANDBY	
	10	E310191-001SM	INDICATOR LENS	1	REC. A/B	
	11	E209146-002SM	PUSH BUTTON ASSY	1		A BS EF EN G VX
		E209146-004SM	P. BUTTON ASSY	1		UT
		E209146-005SM	PUSH BUTTON ASSY	1		U UB UP US
	12	E209149-001SM	PUSH BUTTON	1	SOURCE	
	13	E310190-001SM	PUSH BUTTON	1	DEMO	A BS EF EN G VX
		E310190-002SM	PUSH BUTTON	1	DEMO	U UB UP US UT
	14	VWF1233-20TTB	CARD WIRE	1		
	15	VWF1216-13TTB	FLAT WIRE ASSY	1		
	16	SDSF2608Z	SCREW	18		U UB UP US UT
	17	E310196-001SM	EJECT BUTTON	1		A BS EF EN G VX
		E310196-003SM	EJECT BUTTON	1		U UB UP US UT
	18	E310197-001SM	EJECT BUTTON	1		A BS EF EN G VX
		E310197-003SM	EJECT BUTTON	1		U UB UP US UT
	19	E208588-002SM	HOLDER BRACKET	1		
	20	SBSG3008Z	TAPPING SCREW	8		
	21	E103261-005SM	CASSETTE HOLDER	1		A BS EF EN G VX
		E103261-006SM	CASSETTE HOLDER	1		U UB UP US UT
	22	E209151-001SM	CASSETTE LENS	1		
	23	E406713-001	CASSETE SPRING	4		
	24	E310204-001SM	INDICATOR LENS	2		
	25	E103263-003SM	CASSETTE HOLDER	1		A BS EF EN G VX
		E103263-004SM	CASSETTE HOLDER	1		U UB UP US UT
	26	E209152-001SM	CASSETTE LENS	1		
	29	LE40300-001A	HOLDER SPRING	1		
	30	LE40286-001A	HOLDER SPRING	1		
	31	VYH7779-00D	DAMPER	2		
	32	E309477-222	EJECT STOPPER	1		
	33	E309478-222	EJECT STOPPER	1		
	34	E407801-002	SPRING	1		
	35	E407802-002	SPRING	1		
	36	SBSF3008Z	TAPPING SCREW	12		
	37	-----	CASSETTE MECHANISM ASSY	1		
	38	SBST3006Z	TAPPING SCREW	4		
	39	E309479-001SS	EJECT LEVER	1		
	40	E309480-001SS	EJECT LEVER	1		
	41	E408742-001SS	SPRING	1		
	42	SBST2604Z	SCREW	2		
	43	VWF1217-10TTB	FLAT WIRE	1		

■ Parts List

Block No. **M1M1**


△	Item	Parts Number	Parts Name	Q'ty	Description	Area
	44	-----	CD CHANGER MECHANISM ASSY	1		
	45	-----	CD MECHANISM ASSY	1		
	46	FMYH4003-001	INSULATOR	2		
	47	FMYH4003-002	INSULATOR	2		
	48	VKS3703-00FMM	CLAMPER	1		
	49	SPST2606Z	TAPPING SCREW	1		
	50	VKW5187-001	ROD	1		
	51	QUQ110-1509AJ	FLAT WIRE	1		
	52	VDM1001-M001A	SOCKET WIRE ASSY	1		
	53	VWF1207-07TTB	FLAT WIRE	1		
	54	VWF1210-27TTB	FLAT WIRE ASSY	1		
	55	VWF1211-22TTB	FLAT WIRE ASSY	1		
	56	VYSA1R2-033	SPACER	1		
	57	E309662-001	DISK STOPPER	1		
	59	E310198-001SM	P. W. BOARD BRACKET	1		
	60	E102616-230SM	CHASSIS BASE	1		
	61	E75896-006	FELT SPACER	2		
	62	E310075-001	COVER	1		
	63	SBST3008Z	TAPPING SCREW	2		
	64	E309789-004SM	HEAT SINK	1		
	65	E406969-002SM	SIDE BRACKET	1		
	66	FMPK4003-001	MICA SHEET	2		
	67	FMKL4007-001	HEAT SINK BRACKET	2		
	68	FMPK4004-001	MICA SHEET	1		
	69	SBSG3014CC	SCREW	6		
	70	JCE8005	TRANSISTOR KIT	2	Q757, Q758	
△	72	QQT0157-002	POWER TRANS	1		A BS EF EN G VX
△		QQT0157-003	POWER TRANS	1		U UB UP US UT
	73	E409015-001SM	SHIELD PLATE	1		
	74	E65389-002	SPECIAL SCREW	4		Except G
		E65389-005	ASSY SCREW	4		G
△	75	QMF51E2-3R1	FUSE	1	F101, F102 (T3. 1A/250V)	BS
△		QMF51E2-3R15J1	FUSE	1	F101, F102 (T3. 15A/250V)	Except BS
△	77	QMF51E2-1R2J1BS	FUSE	1	F001 (T1. 2A/250V)	BS
△		QMF51E2-1R25	FUSE	1	F001 (T1. 25A/250V)	A EF EN G VX
	80	LE40252-201A	PROTECT SHEET	1		
	81	E310243-002	PLASTIC RIVET	2		
△	82	EMP7000-200	POWER CORD	1		UP
△		QMP25F0-244	POWER CORD	1		A
△		QMP39E0-200	POWER CORD	1		EF EN G US VX
△		QMP5530-0085BS	POWER CORD	1		BS UB
△		QMP7520-200	POWER CORD	1		U UT
△	83	QHS3876-162	CORD STOPPER	1		
	84	E103265-017SM	REAR PANEL	1		UP
		E103265-024SM	REAR PANEL	1		U UB US UT
		E103265-025SM	REAR PANEL	1		BS EF EN G
		E103265-026SM	REAR PANEL	1		A
		E103265-027SM	REAR PANEL	1		VX
	85	E73273-003	SPECIAL SCREW	20		U UB US UT
	86	E207356-001SM	REAR COVER	1		
	87	E103267-003SM	METAL COVER	1		A BS EF EN G VX
		E103267-004SM	METAL COVER	1		U UB UP US UT
	88	SDSG3006M	TAPPING SCREW	2		
	89	E209153-001SM	CD FITTING	1	DISC 1	



■ Parts List

Block No.


△	Item	Parts Number	Parts Name	Q'ty	Description	Area
	90	E209155-001SM	CD FITTING	1	DISC 2	
	91	E209157-001SM	CD FITTING	1	DISC 3	
	92	E310080-226SM	VOLUME KNOB	1		U UB UP US UT
		E310080-227SM	VOLUME KNOB	1		A BS EF EN G VX
	93	E310195-001SM	STAY BRACKET	1		
	94	GBSG3008CC	TAPPING SCREW	3		
	95	EX0150010H09S11	FELT SPACER	1		
	96	E406309-002	SPACER	4		G
△	97	QMF51E2-1R25	FUSE	1	F002 (T1. 25A/250V)	UP
△		QMF51E2-2R5J1	FUSE	1	F002 (T2. 5A/250V)	U UB US UT
△	98	QMF51E2-1R25	FUSE	1	F003 (T1. 25A/250V)	U UB US UT
	99	E408765-003SM	VOLUME KNOB	1		U UB UP US UT
	100	VKS2250-003	TOP BRACKET	1		
	101	LE30001-010A	SPACER	1		G
	102	LE30001-011A	SPACER	7		
	103	LE40283-001A	SHEET	1		
	-	E309552-008	RATING LABEL	1		U
		LE40210-001A	CAUTION LABEL	1		UT



CD Changer Mechanism Ass'y and Parts List

Block No. **M2MM**

■ Grease Point



■ Parts List (Changer Mechanism Ass'y)

Block No. **M2MM**

△	Item	Parts Number	Parts Name	Q'ty	Description	Area
	1	VKS1144-003	CHASSIS BASE	1		
	2	VKS3698-003	TRAY GUIDE	2		
	3	VKS5532-003	PULLEY GEAR	2		
	4	VKB3000-164	DRIVE BELT	2		
	5	VKS5505-003	GEAR B	2		
	6	VKS5506-002	GEAR C	3		
	7	VKS5507-002	CROSS GEAR U	1		
	8	VKS5508-002	CROSS GEAR L	1		
	9	VKS5510-003	SELECT LEVER	1		
	10	VKH5769-001	GEAR STUD	1		
	11	VKS5511-002	SELECT GEAR	1		
	12	VKW5155-003	COMPRESS SPRING	1		
	13	VKM3846-001	GEAR BRACKET	1		
	14	VKS5509-002MM	CYLINDER GEAR	1		
	15	MSN5D257A-SA2	DC MOTOR ASSY	2		
	16	DPSP2616Z	SCREW	2		
	18	VKM3825-00A	GEAR BASE ASSY	1		
	19	VKZ3172-00A	CAM SWITCH ASSY	1		
	20	VKZ3173-00A	CAM SWITCH ASSY	1		
	21	SPST2606Z	TAPPING SCREW	3		
	22	VKS2263-002MM	DRIVING CAM	1		
	23	VKS2264-002MM	DRIVING CAM	1		
	24	VKS2265-002MM	CAM GEAR L	1		
	25	WDL316050	SLIT WASHER	2		
	27	SBSF2608Z	TAPPING SCREW	15		
	28	VKS3702-00FMM	DRIVE UNIT A	1		
	29	VKS2247-004	MECHA HOLDER	1		
	30	VKL7767-00B	MECHA BRACKET ASSY	1		
	31	SBSF2606Z	TAPPING SCREW	3		
	32	VKM3824-00A	MECHA HOLDER ASSY	1		
	33	VKL7802-00C	MECHA HOLDER ASSY	1		
	34	SDST2604Z	SCREW	2		
	35	VKL7810-00A	LIFTER	1		
	36	VKL7811-00A	LIFTER	1		
	37	VKL7812-00A	LIFTER	1		
	38	VKL2732-002	LIFTER BASE	1		
	39	VKM3823-001	LIFTER BRACKET	1		
	40	SDST2604Z	SCREW	1		
	41	WDL266035-2	SLIT WASHER	1		
	43	VKS5514-002MM	LOCK LEVER	3		
	44	VKY3133-002MM	RETURN SPRING	1		
	46	VKY3134-003	SPRING	1		
	47	VKS2252-00DMM	TRAY ASSY	3		
	48	VKS2250-003	TOP BRACKET	1		
	49	VKS5515-002	TRAY STOPPER	1		
	50	VKW5156-004	TORSION SPRING	1		
	51	VKS3703-00FMM	CLAMPER ASSY	1		
	69	VMC0325-010	CONNECTOR	1		

CD Mechanism Ass'y and Parts List


■ Grease Point

Block No. **M3MM**

G-31KB

(Grease to apply have to be a little for exchange)

G-31KB = Grease



Parts No.
G-31KB = EBS0006-013B

■ Parts List (CD Mechanism Ass'y)


Item	Parts Number	Parts Name	Q'ty	Description	Area
1	E102501-221SS	MECHA. BASE ASSY	1	Made in Singapore	
	EPB-002PK	MECHA. BASE ASSY	1	Made in Malaysia	
2	OPTIMA-150S	OPTICAL PICK UP	1		
3	E406777-001	CD SHAFT	1		
4	E307746-001	CD RACK	1		
5	E307745-221SS	MECHA GEAR	1		
6	SDSP2003N	SCREW	4		
7	E406750-001	PINION GEAR	1		
8	E75807-302	TURN TABLE	1		
9	MDN-4RA3ETA-1	FEED MOTOR	1	Made in Singapore	
	E406784-001	FEED MOTOR	1	Made in Malaysia	
10	E406783-001	SPINDLE MOTOR	1		
11	EMW10190-001 (S)	P. C. BOARD	1		
12	ESB1100-005	LEAF SWITCH	1		
13	E75832-001	SCREW	1		
14	EMV5109-006B	CONNECT TERMINAL	1	6PIN	
15	SDSF2006Z	SCREW	1		

CA-D701T

Cassette Mechanism Ass'y and Parts List

■ Grease Point

Block No. **M4M4**



EM-30L (■) } Grease
 FG-87HS (●)
 GE-676 (▲)

■ Parts List (Cassette Mechanism Ass'y)

Block No. **M4M**

△	Item	Parts Number	Parts Name	Q'ty	Description	Area
	1	VKM3835-00A	FLYWHEEL BRACKET	1		
	2	MMI-6H2LWK	DC MOTOR	1		
	3	VKR4740-003	MOTOR PULLEY	1		
	4	SPSP2603Z	WOOD SCREW	2		
	5	VKW5177-002	SPRING	1		
	6	VKS5524-001	THRUST GUIDE	1		
	7	VKR4741-002	IDLER PULLEY	1		
	8	VKF3202-00A	F. WHEEL (L) ASSY	2		
	9	VKF3200-00A	F. WHEEL (R) ASSY	2		
	10	VKB3000-161	CAPSTAN BELT	1		
	11	VKB3000-162	CAPSTAN BELT	1		
	12	VKS5523-00C	MAIN PULLY ASSY	2		
	13	VKB3000-167	REEL BELT	2		
	14	VKS1150-001	CONTROL CAM	2		
	15	VKW5170-002	SPRING	2		
	16	SBSF2608Z	TAPPING SCREW	6		
	17	VKS3719-001	RING	2		
	18	VKS5525-00B	TRIGGER ARM ASSY	2		
	19	VKS1151-00A	CHASSIS BASE ASSY	2		
	20	VGP2401-00A	SOLENOID ASSY	2		
	21	SDST2612Z	SCREW	2		
	22	VKS3714-00B	F. F./REW. ARM	2		
	23	VKW5173-001	SPRING	2		
	24	VKW5202-002	SPRING	2		
	25	VKS5519-002	IDLER GEAR	2		
	26	VKZ4690-002	MAGNET	2		
	27	VKS3707-002	REEL GEAR	2		
	28	VKW5162-002	SPRING	4		
	29	VKS3708-002	REEL CAP	4		
	30	VKS2261-002	REEL STOPPER	2		
	31	VKW5178-001	BRAKE SPRING	2		
	32	VKS2255-001	DIRECTION LEVER	2		
	33	VKW5163-001	SPRING	2		
	34	VKP4232-00B	PINCH ROLLER	2		
	35	VKP4231-00B	PINCH ROLLER	4		
	36	VKY4670-001	CASSETTE SPRING	2		
	40	VKM3834-00F	HEAD MOUNT ASSY	1	A Mecha.	
		VKM3832-00F	HEAD MOUNT ASSY	1	B Mecha.	
	46	MXS00220MVLO	CASSETTE SWITCH	7		
	47	DN6851-HI	I. C (M)	2		
	48	VKS3630-001MM	I. C. PROTECTOR	2		
	49	VMC0314-P08	CONNECT TERMINAL	1	A Mecha.	
		VMC0314-P14	CONNECT TERMINAL	1	B Mecha.	
	50	QSEC001-E03	LEVER SWITCH	2		
	51	1SR139-400	SI DIODE	2		
	52	VWSC04-11A13K	FLAT WIRE ASSY	1		

CA-D701T

Electrical Parts List (ENH-308)

Item	Parts Number	Description	Area
	I. C. S		
IC701	TDA7294	I. C (M)	
IC702	TDA7294	I. C (M)	
IC781	TDA7295	I. C (M)	
IC782	TDA7295	I. C (M)	
	DIODES		
D001	1N5402M-20	DIODE	
D002	1N5402M-20	DIODE	
D003	1N5402M-20	DIODE	
D004	1N5402M-20	DIODE	
D011	30DF2SFC	SI. DIODE	
D012	30DF2SFC	SI. DIODE	
D013	30DF2SFC	SI. DIODE	
D014	30DF2SFC	SI. DIODE	
D015	30DF2SFC	SI. DIODE	
D016	30DF2SFC	SI. DIODE	
D017	1SR35-100	SI. DIODE	
D018	1SR35-100	SI. DIODE	
D019	MTZ30JC	ZENER DIODE	
D020	MTZ5.6JC	ZENER DIODE	
D021	MTZ5.1JB	ZENER DIODE	
D022	1SS133	SI. DIODE	
D023	1SS133	SI. DIODE	
D024	1SS133	SI. DIODE	
D025	1SS133	SI. DIODE	
D027	1SR35-100	SI. DIODE	
D030	MTZ11JA	ZENER DIODE	
D043	1SS133	SI. DIODE	
D060	MTZ5.1JB	ZENER DIODE	
D061	MTZ11JC	ZENER DIODE	
D062	MTZ13JC	ZENER DIODE	
D063	MTZ11JC	ZENER DIODE	
D064	MTZ13JC	ZENER DIODE	
D065	MTZ8.2JC	ZENER DIODE	
D066	MTZ13JC	ZENER DIODE	
D067	MTZ13JC	ZENER DIODE	
D068	MTZ13JC	ZENER DIODE	
D069	MTZ13JC	ZENER DIODE	
D070	MTZ13JC	ZENER DIODE	
D703	1SS133	SI. DIODE	
D704	1SS133	SI. DIODE	
D719	1SS133	SI. DIODE	
D720	1SS133	SI. DIODE	
D728	1SS133	SI. DIODE	
D751	1SS133	SI. DIODE	
D752	1SS133	SI. DIODE	
D753	1SS133	SI. DIODE	
D754	1SS133	SI. DIODE	
D755	1SS133	SI. DIODE	
D756	1SS133	SI. DIODE	
D757	MTZ3.9JB	ZENER DIODE	
D758	MTZ3.9JB	ZENER DIODE	
D759	1SS133	SI. DIODE	
D760	1SS133	SI. DIODE	
D789	1SS133	SI. DIODE	
D790	1SS133	SI. DIODE	
	TRANSISTORS		
Q001	2SB1187 (F, G)	SI. TRANSISTOR	
Q003	KRC107M-T	DIGITAL TRANSISTOR	
Q004	KRC107M-T	DIGITAL TRANSISTOR	
Q005	KRC102M-T	DIGITAL TRANSISTOR	
Q030	2SD2061 (F, G)	SI. TRANSISTOR	
Q040	2SC945A	SI. TRANSISTOR	
Q041	DTC114YS	DIGITAL TRANSISTOR	
Q060	2SD2061 (F, G)	SI. TRANSISTOR	
Q061	2SC945A	SI. TRANSISTOR	
Q062	2SC945A	SI. TRANSISTOR	
Q063	2SD2061 (F, G)	SI. TRANSISTOR	
Q064	2SA933S (RS)	SI. TRANSISTOR	
Q065	2SC945A	SI. TRANSISTOR	

Item	Parts Number	Description	Area
Q066	2SD2061 (F, G)	SI. TRANSISTOR	
Q067	2SA933S (RS)	SI. TRANSISTOR	
Q068	2SC945A	SI. TRANSISTOR	
Q069	2SD2061 (F, G)	SI. TRANSISTOR	
Q070	2SC945A	SI. TRANSISTOR	
Q071	2SB1187 (F, G)	SI. TRANSISTOR	
Q072	2SA933S (RS)	SI. TRANSISTOR	
Q073	KRA104M-T	DIGITAL TRANSISTOR	
Q074	DTC144ES	DIGITAL TRANSISTOR	
Q075	KRC104M-T	DIGITAL TRANSISTOR	
Q076	DTA144ES	DIGITAL TRANSISTOR	
Q701	2SA1038 (R, S)	SI. TRANSISTOR	
Q702	2SA1038 (R, S)	SI. TRANSISTOR	
Q726	2SC2389 (S, E)	SI. TRANSISTOR	
Q727	2SA1038 (R, S)	SI. TRANSISTOR	
Q728	2SC1740S (R, S)	SI. TRANSISTOR	
Q733	2SD2144S (VW)	SI. TRANSISTOR	
Q734	2SD2144S (VW)	SI. TRANSISTOR	
Q735	2SD2144S (VW)	SI. TRANSISTOR	
Q736	2SD2144S (VW)	SI. TRANSISTOR	
Q737	KRA111M-T	DIGITAL TRANSISTOR	
Q751	2SC1685	SI. TRANSISTOR	
Q752	2SA933S (RS)	SI. TRANSISTOR	
Q753	2SC1685	SI. TRANSISTOR	
Q754	2SA933S (RS)	SI. TRANSISTOR	
Q755	2SA965 (Y)	SI. TRANSISTOR	
Q756	2SC2235 (O, Y)	SI. TRANSISTOR	
Q781	2SA1038 (R, S)	SI. TRANSISTOR	
Q782	2SA1038 (R, S)	SI. TRANSISTOR	
	CAPACITORS		
C001	QFV82AJ-104	0.1MF 100V THIN FILM	
C002	QFV82AJ-104	0.1MF 100V THIN FILM	
C003	QFV82AJ-104	0.1MF 100V THIN FILM	
C004	QEZ0360-568	5600MF ELECTRO	
C005	QEZ0360-568	5600MF ELECTRO	
C011	QFV81HJ-104	0.1MF 50V THIN FILM	
C012	QFV81HJ-104	0.1MF 50V THIN FILM	
C013	QFV81HJ-104	0.1MF 50V THIN FILM	
C014	QETB1VM-338	3300MF 35V AL. E. CAP.	
C015	QETB1VM-338	3300MF 35V AL. E. CAP.	
C016	QETN1VM-107Z	100MF 35V E. CAP.	
C017	QETN1JM-476Z	47MF 63V E. CAP.	
C018	QETN1HM-226Z	22MF 50V AL. E. CAP.	
C019	QCVB1CM-103Y	0.01MF 16V CER. CAP.	
C020	QETN1HM-226Z	22MF 50V AL. E. CAP.	
C021	QETN1HM-475Z	4.7MF 50V AL. E. CAP.	
C022	QETN1HM-475Z	4.7MF 50V AL. E. CAP.	
C023	QETN1HM-225Z	2.2MF 50V AL. E. CAP.	
C024	QETN1EM-106Z	10MF 25V E. CAP.	
C030	QETN1EM-226Z	22MF 25V E. CAP.	
C031	QCVB1CM-103Y	0.01MF 16V CER. CAP.	
C032	QETN1EM-226Z	22MF 25V E. CAP.	
C033	QFLB1HJ-103	0.01MF 50V MYLAR CAP.	A BS EF EN G VX
	QFV81HJ-224	0.22MF 50V THIN FILM	U UB UP US UT
C060	QETN1EM-226Z	22MF 25V E. CAP.	
C061	QCF21HP-103A	0.01MF 50V CER. CAP.	
C062	QETN1EM-226Z	22MF 25V E. CAP.	
C063	QETN1EM-226Z	22MF 25V E. CAP.	
C064	QCF21HP-103A	0.01MF 50V CER. CAP.	
C065	QETN1EM-226Z	22MF 25V E. CAP.	
C066	QETN1EM-226Z	22MF 25V E. CAP.	
C067	QCF21HP-103A	0.01MF 50V CER. CAP.	
C068	QETN1EM-226Z	22MF 25V E. CAP.	
C069	QETN1EM-226Z	22MF 25V E. CAP.	
C070	QCF21HP-103A	0.01MF 50V CER. CAP.	
C071	QETN1EM-226Z	22MF 25V E. CAP.	
C072	QETN1EM-226Z	22MF 25V E. CAP.	
C073	QCF21HP-103A	0.01MF 50V CER. CAP.	
C074	QETN1EM-226Z	22MF 25V E. CAP.	
C103	QFLB1HJ-103	0.01MF 50V MYLAR CAP.	

Electrical Parts List (ENH-308)

△	Item	Parts Number	Description	Area
	C703	QCCB1HK-101Y	100PF 50V CER. CAP.	
	C704	QCCB1HK-101Y	100PF 50V CER. CAP.	
	C705	QCCB1HK-181Y	180PF 50V CER. CAP.	
	C706	QCCB1HK-181Y	180PF 50V CER. CAP.	
	C707	QETN1EM-476Z	47MF 25V E. CAP.	
	C708	QETN1EM-476Z	47MF 25V E. CAP.	
	C709	QCSB1HJ-100Y	10PF 50V CER. CAP.	
	C710	QCSB1HJ-100Y	10PF 50V CER. CAP.	
	C711	QETN1HM-226Z	22MF 50V AL E. CAP.	
	C712	QETN1HM-226Z	22MF 50V AL E. CAP.	
	C713	QFV81HJ-104	0.1MF 50V THIN FILM	
	C714	QFV81HJ-104	0.1MF 50V THIN FILM	
	C715	QFV81HJ-104	0.1MF 50V THIN FILM	
	C716	QFV81HJ-104	0.1MF 50V THIN FILM	
	C721	QETN1HM-225Z	2.2MF 50V AL E. CAP.	
	C722	QETN1HM-225Z	2.2MF 50V AL E. CAP.	
	C726	QETN1EM-106Z	10MF 25V E. CAP.	
	C729	QETN1CM-476Z	47MF 16V AL E. CAP.	
	C751	QCY31HK-272Z	2700PF 50V CER. CAP.	
	C752	QCY31HK-272Z	2700PF 50V CER. CAP.	
	C753	QCY31HK-472Z	4700PF 50V CER. CAP.	
	C754	QCY31HK-472Z	4700PF 50V CER. CAP.	
	C755	QFV81HJ-105	1MF 50V THIN FILM	
	C756	QFV81HJ-105	1MF 50V THIN FILM	
	C757	QXCXB1CM-152Y	1500PF 16V CER. CAP.	
	C758	QXCXB1CM-152Y	1500PF 16V CER. CAP.	
	C781	QETN1HM-225Z	2.2MF 50V AL E. CAP.	
	C782	QETN1HM-225Z	2.2MF 50V AL E. CAP.	
	C783	QCCB1HK-101Y	100PF 50V CER. CAP.	
	C784	QCCB1HK-101Y	100PF 50V CER. CAP.	
	C785	QCCB1HK-181Y	180PF 50V CER. CAP.	
	C786	QCCB1HK-181Y	180PF 50V CER. CAP.	
	C787	QETN1EM-476Z	47MF 25V E. CAP.	
	C788	QETN1EM-476Z	47MF 25V E. CAP.	
	C789	QCSB1HJ-100Y	10PF 50V CER. CAP.	
	C790	QCSB1HJ-100Y	10PF 50V CER. CAP.	
	C791	QETN1HM-226Z	22MF 50V AL E. CAP.	
	C792	QETN1HM-226Z	22MF 50V AL E. CAP.	
	C793	QFV81HJ-104	0.1MF 50V THIN FILM	
	C794	QFV81HJ-104	0.1MF 50V THIN FILM	
	C795	QFV81HJ-104	0.1MF 50V THIN FILM	
	C796	QFV81HJ-104	0.1MF 50V THIN FILM	
	C799	QCVB1CM-103Y	0.01MF 16V CER. CAP.	
	C1073	QFLB1HJ-223	0.022MF 50V MYLAR CAP.	
	C1074	QFLB1HJ-223	0.022MF 50V MYLAR CAP.	
		RESISTORS		
	R003	QRD167J-332	3.3K 1/6W CARBON RE	
	R004	QRD167J-223	22K 1/6W CARBON RE	
	R005	QRD161J-104	100K 1/6W CARBON RE	
△	R006	QRZ0077-4R7	4.7 1/4W FUSE RESIS	
△	R007	QRZ0077-4R7	4.7 1/4W FUSE RESIS	
	R008	QRD161J-103	10K 1/6W CARBON RE	
	R009	QRD161J-103	10K 1/6W CARBON RE	
	R010	QRD161J-472	4.7K 1/6W CARBON RE	
	R011	QRD161J-102	1K 1/6W CARBON RE	
	R012	QRD167J-223	22K 1/6W CARBON RE	
	R013	QRD161J-103	10K 1/6W CARBON RE	
	R014	QRD161J-104	100K 1/6W CARBON RE	
	R030	QRD14CJ-4R7SX	4.7 1/4W UNF. CARBON	
	R031	QRD161J-681	680 1/6W CARBON RE	
	R040	QRD12CJ-271SX	270 1/2W UNF. CARBON	U UB UP US UT
		QRD12CJ-331SX	330 1/2W UNF. CARBON	A BS EF EN G VX
	R041	QRD12CJ-331SX	330 1/2W UNF. CARBON	
	R042	QRD161J-222	2.2K 1/6W CARBON RE	
	R043	QRD12CJ-271SX	270 1/2W UNF. CARBON	U UB UP US UT
		QRD12CJ-331SX	330 1/2W UNF. CARBON	A BS EF EN G VX
	R044	QRD12CJ-331SX	330 1/2W UNF. CARBON	
	R045	QRD161J-222	2.2K 1/6W CARBON RE	
	R062	QRD161J-331	330 1/6W CARBON RE	
	R063	QRD161J-331	330 1/6W CARBON RE	

△	Item	Parts Number	Description	Area
	R064	QRD161J-122	1.2K 1/6W CARBON RE	
	R065	QRD161J-561	560 1/6W CARBON RE	
	R066	QRD161J-561	560 1/6W CARBON RE	
	R067	QRD161J-122	1.2K 1/6W CARBON RE	
	R068	QRD161J-331	330 1/6W CARBON RE	
	R071	QRD161J-221	220 1/6W CARBON RE	
	R072	QRD161J-681	680 1/6W CARBON RE	
	R073	QRD161J-182	1.8K 1/6W CARBON RE	
	R076	QRD161J-221	220 1/6W CARBON RE	
	R077	QRD161J-681	680 1/6W CARBON RE	
	R078	QRD161J-182	1.8K 1/6W CARBON RE	
	R081	QRD167J-272	2.7K 1/6W CARBON RE	
	R082	QRD167J-562	5.6K 1/6W CARBON RE	
	R084	QRD167J-272	2.7K 1/6W CARBON RE	
	R085	QRD167J-562	5.6K 1/6W CARBON RE	
△	R701	QRD14CJ-100SX	10 1/4W UNF. CARBON	
△	R702	QRD14CJ-100SX	10 1/4W UNF. CARBON	
	R703	QRD161J-563	56K 1/6W CARBON RE	
	R704	QRD161J-563	56K 1/6W CARBON RE	
△	R705	QRD14CJ-182SX	1.8K 1/4W UNF. CARBON	
△	R706	QRD14CJ-182SX	1.8K 1/4W UNF. CARBON	
	R707	QRD161J-563	56K 1/6W CARBON RE	
	R708	QRD161J-563	56K 1/6W CARBON RE	
△	R709	QRX014J-R22	0.22 1W METAL FILM	
△	R710	QRX014J-R22	0.22 1W METAL FILM	
△	R711	QRX014J-R22	0.22 1W METAL FILM	
△	R712	QRX014J-R22	0.22 1W METAL FILM	
△	R713	QRD14CJ-100SX	10 1/4W UNF. CARBON	
△	R714	QRD14CJ-100SX	10 1/4W UNF. CARBON	
△	R715	QRD14CJ-100SX	10 1/4W UNF. CARBON	
△	R716	QRD14CJ-100SX	10 1/4W UNF. CARBON	
	R717	QRD161J-122	1.2K 1/6W CARBON RE	
	R718	QRD161J-122	1.2K 1/6W CARBON RE	
	R719	QRD167J-223	22K 1/6W CARBON RE	
	R720	QRD167J-223	22K 1/6W CARBON RE	
	R721	QRD161J-103	10K 1/6W CARBON RE	
	R722	QRD161J-103	10K 1/6W CARBON RE	
	R723	QRD161J-473	47K 1/6W CARBON RE	
	R724	QRD161J-473	47K 1/6W CARBON RE	
	R725	QRD161J-104	100K 1/6W CARBON RE	
	R726	QRD161J-823	82K 1/6W CARBON RE	
	R727	QRD161J-104	100K 1/6W CARBON RE	
	R728	QRD161J-103	10K 1/6W CARBON RE	
	R729	QRD161J-104	100K 1/6W CARBON RE	
	R730	QRD161J-103	10K 1/6W CARBON RE	
	R733	QRD161J-473	47K 1/6W CARBON RE	
	R734	QRD161J-473	47K 1/6W CARBON RE	
	R735	QRD161J-473	47K 1/6W CARBON RE	
	R736	QRD161J-473	47K 1/6W CARBON RE	
	R739	QRG01DJ-821X	820 1W OXIDE META	
	R740	QRG01DJ-821X	820 1W OXIDE META	
	R741	QRD161J-473	47K 1/6W CARBON RE	
	R742	QRD161J-473	47K 1/6W CARBON RE	
	R743	QRD167J-223	22K 1/6W CARBON RE	
	R744	QRD167J-223	22K 1/6W CARBON RE	
	R745	QRD161J-103	10K 1/6W CARBON RE	
	R746	QRD161J-103	10K 1/6W CARBON RE	
	R747	QRD161J-104	100K 1/6W CARBON RE	
	R748	QRD161J-823	82K 1/6W CARBON RE	
	R749	QRD161J-471	470 1/6W CARBON RE	
	R750	QRD161J-471	470 1/6W CARBON RE	
	R751	QRD167J-223	22K 1/6W CARBON RE	
	R752	QRD167J-223	22K 1/6W CARBON RE	
	R753	QRD161J-222	2.2K 1/6W CARBON RE	
	R754	QRD161J-222	2.2K 1/6W CARBON RE	
	R755	QRD161J-221	220 1/6W CARBON RE	
	R756	QRD161J-221	220 1/6W CARBON RE	
	R757	QRD167J-223	22K 1/6W CARBON RE	
	R758	QRD167J-223	22K 1/6W CARBON RE	
	R759	QRD167J-682	6.8K 1/6W CARBON RE	

CA-D701T

Electrical Parts List (ENH-308)

△	Item	Parts Number	Description	Area
	R760	QRD167J-682	6.8K 1/6W CARBON RE	
	R761	QRD161J-222	2.2K 1/6W CARBON RE	
	R762	QRD161J-222	2.2K 1/6W CARBON RE	
	R763	QRD167J-223	22K 1/6W CARBON RE	
	R764	QRD167J-223	22K 1/6W CARBON RE	
	R765	QRG01DJ-182X	1.8K 1W OXIDE META	
	R766	QRG01DJ-182X	1.8K 1W OXIDE META	
△	R767	QRD14CJ-681SX	680 1/4W UNF. CARBON	
△	R768	QRD14CJ-681SX	680 1/4W UNF. CARBON	
	R769	QRD14CJ-821SX	820 1/4W CARBON RE	
	R770	QRD14CJ-821SX	820 1/4W CARBON RE	
	R771	QRD161J-821	820 1/6W CARBON RE	
	R772	QRD161J-821	820 1/6W CARBON RE	
△	R773	QRD14CJ-101S	100 1/4W UNF. CARBON	
△	R774	QRD14CJ-101S	100 1/4W UNF. CARBON	
	R775	QRD161J-471	470 1/6W CARBON RE	
	R776	QRD161J-471	470 1/6W CARBON RE	
	R777	QRD14CJ-4R7SX	4.7 1/4W UNF. CARBON	
	R778	QRD14CJ-4R7SX	4.7 1/4W UNF. CARBON	
△	R781	QRD14CJ-100SX	10 1/4W UNF. CARBON	
△	R782	QRD14CJ-100SX	10 1/4W UNF. CARBON	
	R783	QRD161J-563	56K 1/6W CARBON RE	
	R784	QRD161J-563	56K 1/6W CARBON RE	
△	R785	QRD14CJ-182SX	1.8K 1/4W UNF. CARBON	
△	R786	QRD14CJ-182SX	1.8K 1/4W UNF. CARBON	
	R787	QRD161J-563	56K 1/6W CARBON RE	
	R788	QRD161J-563	56K 1/6W CARBON RE	
△	R789	QRX014J-R22	0.22 1W METAL FILM	
△	R790	QRX014J-R22	0.22 1W METAL FILM	
△	R791	QRX014J-R22	0.22 1W METAL FILM	
△	R792	QRX014J-R22	0.22 1W METAL FILM	
△	R793	QRD14CJ-100SX	10 1/4W UNF. CARBON	
△	R794	QRD14CJ-100SX	10 1/4W UNF. CARBON	
△	R795	QRD14CJ-100SX	10 1/4W UNF. CARBON	
△	R796	QRD14CJ-100SX	10 1/4W UNF. CARBON	
	R797	QRD161J-122	1.2K 1/6W CARBON RE	
	R798	QRD161J-122	1.2K 1/6W CARBON RE	
	R1073	QRD14CJ-4R7SX	4.7 1/4W UNF. CARBON	
	R1074	QRD14CJ-4R7SX	4.7 1/4W UNF. CARBON	
	R1091	QRD161J-104	100K 1/6W CARBON RE	U UB US UT
	R1092	QRD161J-104	100K 1/6W CARBON RE	U UB US UT
	R1093	QRD161J-104	100K 1/6W CARBON RE	U UB US UT
		OTHERS		
		EMW10687-202	CIR. BOARD	
		E61380-034	FUSE LABEL	UP
		E61380-037	FUSE LABEL	UP
		QWE880-08RR	VINYL WIRE	UP
		QWE880-12RR	VINYL WIRE	
		QWE881-20RR	VINYL WIRE	U UB US UT
		QWE882-25RR	VINYL WIRE	U UB US UT
		QWE883-18RR	VINYL WIRE	U UB US UT
		QWE884-24RR	VINYL WIRE	U UB US UT
		QWE886-18RR	VINYL WIRE	U UB US UT
		QWE888-18RR	VINYL WIRE	U UB US UT
		QWE889-22RR	VINYL WIRE	U UB US UT
	L701	EQL0011-R45J1	INDUCTOR	
	L702	EQL0011-R45J1	INDUCTOR	
	L781	EQL0011-R45J1	INDUCTOR	
	L782	EQL0011-R45J1	INDUCTOR	
	SO01	QSW0524-001	LEVER SWITCH	U UB US UT
	CN002	EMV7163-011	CONNECT TERMINAL	
	CN003	EMV7163-010	CONNECT TERMINAL	
	CN004	EMV7163-005	CONNECTOR	
	CN005	EMV7163-011	CONNECT TERMINAL	
	CN006	EMV7163-010	CONNECT TERMINAL	
	CN007	EMV7163-009	CONNECT TERMINAL	
	CN009	EMV5138-005	CONNECT TERMINAL	
	CN012	EMV5163-011R	CONNECT TERMINAL	
	CN013	EMV5163-010R	CONNECT TERMINAL	
	CN014	EMV5163-005R	CONNECTOR	

△	Item	Parts Number	Description	Area
	CN019	EWS285-002J	SOCKET WIRE ASSY	
	CN111	EMV7145-004Z	SOCKET ASSY	
	CN703	EMV5163-007R	CONNECT TERMINAL	
	CN704	EMV5163-006R	CONNECT TERMINAL	
	CN915	EMV7145-003Z	SOCKET ASSY	
	EP001	EMZ4002-002Z	EARTH PLATE	
	EP002	EMZ4002-002Z	EARTH PLATE	
	FT011	EMG7331-003Z	FUSE CLIP	A BS EF EN G VX
	FT012	EMG7331-003Z	FUSE CLIP	A BS EF EN G VX
	FT021	EMG7331-003Z	FUSE CLIP	U UB UP US UT
	FT022	EMG7331-003Z	FUSE CLIP	U UB UP US UT
	FT031	EMG7331-003Z	FUSE CLIP	U UB US UT
	FT032	EMG7331-003Z	FUSE CLIP	U UB US UT
	FT511	EMG7331-003Z	FUSE CLIP	
	FT512	EMG7331-003Z	FUSE CLIP	
	FT521	EMG7331-003Z	FUSE CLIP	
	FT522	EMG7331-003Z	FUSE CLIP	
	FW101	EWR34D-13LS	FLAT WIRE	
	TB001	EMZ4001-002Z	TAB	
	TB002	EMZ4001-002Z	TAB	
	TH002	QAD0095-4R7Z	POSITIVE THERMISTOR	
	TW799	EWZP01-025	TERMINAL WIRE	

Electrical Parts List (ENB-255)

Item	Parts Number	Description	Area
	I. C. S		
IC231	HA12136A	I. C (MONO-ANALOG)	
IC901	HD404719A71FS	I. C (MICRO-COMPUTER)	
IC902	MN172412JAAW	I. C (MICRO-COMPUTER)	
IC903	XR1099CP	I. C (MONO-ANALOG)	U UB UP US UT
IC904	GP1U271X	INFRARED DETECT UNIT	
IC912	BA1521B	I. C (MONO-ANALOG)	U UB UP US UT
IC914	BA7725S	I. C (MONO-ANALOG)	U UB UP US UT
IC915	BU9252S	I. C (DIGI-MOS)	U UB UP US UT
	DIODES		
D041	1SS133	SI. DIODE	
D042	1SS133	SI. DIODE	
D231	1SR35-100	SI. DIODE	
D232	SLR-342MCA47	L. E. D.	
D233	SLR-342MCA47	L. E. D.	
D234	SLR-342MCA47	L. E. D.	
D235	SLR-342MCA47	L. E. D.	
D236	SLR-342MCA47	L. E. D.	
D237	SLR-342MCA47	L. E. D.	
D801	MTZ2. 4JB	ZENER DIODE	
D802	SLR-342VC3F	L. E. D.	
D803	SLR-342VC3F	L. E. D.	
D804	SLR-342VC3F	L. E. D.	
D805	SLR-342VC3F	L. E. D.	
D806	SLR-342VC3F	L. E. D.	
D901	1SS119	SI. DIODE	
D902	1SS133	SI. DIODE	
D904	SLR-342DCA47	L. E. D.	
D905	SLR-342MCA47	L. E. D.	
D906	SLR-342MCA47	L. E. D.	
D907	SLR-342MCA47	L. E. D.	
D908	SLR-342MCA47	L. E. D.	
D909	SLR-342MCA47	L. E. D.	
D910	SLR-342MCA47	L. E. D.	
D911	SLR-342MCA47	L. E. D.	
D912	SLR-342MCA47	L. E. D.	
D913	SLR-342MCA47	L. E. D.	
D914	SLR-342MCA47	L. E. D.	
D915	SLR-342MCA47	L. E. D.	
D916	SLR-342MCA47	L. E. D.	
D917	SLR-342MCA47	L. E. D.	
D918	SLR-342MCA47	L. E. D.	
D919	SLR-342MCA47	L. E. D.	
D920	1SS133	SI. DIODE	
D921	1SS133	SI. DIODE	
D922	1SS133	SI. DIODE	
D923	MTZ5. 6JC	ZENER DIODE	
D924	MTZ5. 6JC	ZENER DIODE	
D925	MTZ5. 6JC	ZENER DIODE	
D931	1SS133	SI. DIODE	U UB UP US UT VX
D932	1SS133	SI. DIODE	VX
D933	1SS133	SI. DIODE	A U UB UP US UT
D934	1SS133	SI. DIODE	
D935	1SS133	SI. DIODE	U UB UP US UT
D941	MTZ5. 1JB	ZENER DIODE	U UB UP US UT
D996	1SS119	SI. DIODE	
D1101	MTZ5. 1JB	ZENER DIODE	U UB UP US UT
D1146	MTZ2. 4JB	ZENER DIODE	U UB UP US UT
	TRANSISTORS		
Q231	2SA934 (Q. R)	SI. TRANSISTOR	
Q232	DTC123YS	DIGITAL TRANSISTOR	
Q233	2SA934 (Q. R)	SI. TRANSISTOR	
Q234	DTC123YS	DIGITAL TRANSISTOR	
Q235	2SA933S (RS)	SI. TRANSISTOR	
Q236	KRC107M-T	DIGITAL TRANSISTOR	
Q237	KRC107M-T	DIGITAL TRANSISTOR	
Q901	KRC102M-T	DIGITAL TRANSISTOR	
Q902	KRC102M-T	DIGITAL TRANSISTOR	
Q903	KRC102M-T	DIGITAL TRANSISTOR	
Q904	KRC102M-T	DIGITAL TRANSISTOR	

Item	Parts Number	Description	Area
Q921	KRC107M-T	DIGITAL TRANSISTOR	
Q922	DTC114ES	DIGITAL TRANSISTOR	
Q923	DTC114ES	DIGITAL TRANSISTOR	
Q924	DTC114ES	DIGITAL TRANSISTOR	
Q925	DTC114ES	DIGITAL TRANSISTOR	
Q1101	KRC104M-T	DIGITAL TRANSISTOR	U UB UP US UT
Q1102	KRC104M-T	DIGITAL TRANSISTOR	U UB UP US UT
	CAPACITORS		
C050	QCY31HK-103Z	0. 01MF 50V CER. CAP.	BS EF EN G VX
C051	QFV81HJ-104	0. 1MF 50V THIN FILM CA	
C052	QFV81HJ-104	0. 1MF 50V THIN FILM CA	
C053	QCXB1CM-222Y	2200PF 16V CER. CAP.	
C054	QCXB1CM-222Y	2200PF 16V CER. CAP.	
C055	QFLB1HJ-393	0. 039MF 50V MYLAR CAP.	BS EF EN G VX
C056	QFLB1HJ-393	0. 039MF 50V MYLAR CAP.	BS EF EN G VX
C057	QCHB1EZ-223	0. 022MF 25V CER. CAP.	
C058	QCHB1EZ-223	0. 022MF 25V CER. CAP.	
C059	QFLB1HJ-393	0. 039MF 50V MYLAR CAP.	BS EF EN G VX
C233	QETC1HM-225ZM	2. 2MF 50V E. CAP.	
C234	QETC1HM-225ZM	2. 2MF 50V E. CAP.	
C235	QETC1HM-225ZM	2. 2MF 50V E. CAP.	
C236	QETC1HM-225ZM	2. 2MF 50V E. CAP.	
C237	QETC1HM-106ZM	10MF 50V E. CAP.	
C238	QETC1HM-225ZM	2. 2MF 50V E. CAP.	
C239	QETC1HM-225ZM	2. 2MF 50V E. CAP.	
C240	QCBB1HK-221Y	220PF 50V CER. CAP.	
C241	QCBB1HK-221Y	220PF 50V CER. CAP.	
C242	EETB1HM-475E	4. 7MF 50V E. CAP.	
C243	QFV81HJ-224	0. 22MF 50V THIN FILM CA	
C244	QFV81HJ-224	0. 22MF 50V THIN FILM CA	
C245	QCBB1HK-561Y	560PF 50V CER. CAP.	
C246	QCBB1HK-561Y	560PF 50V CER. CAP.	
C247	EETB1CM-476	47MF 16V E. CAP.	
C251	QETN1CM-107Z	100MF 16V E. CAP.	
C801	QCBB1HK-471Y	470PF 50V CER. CAP.	
C802	QCBB1HK-471Y	470PF 50V CER. CAP.	
C901	EETB1AM-107E	100MF 10V E. CAP.	
C902	QCZ0205-155	1. 5MF 25V C. CAP.	
C903	QEAD0HZ-479ZM	47000MF E. CAP.	
C904	QCHB1EZ-223	0. 022MF 25V CER. CAP.	
C905	QER50JM-107	100MF 6. 3V AL. E. CAP.	
C910	QCT26CH-330	33PF 50V CER. CAP.	
C911	QEAD0HZ-479ZM	47000MF E. CAP.	
C912	EETB1AM-476E	47MF 10V E. CAP.	
C914	QCZ0205-155	1. 5MF 25V C. CAP.	
C915	QCVB1CM-103Y	0. 01MF 16V CER. CAP.	
C916	QER51HM-474G	0. 47MF 50V AL. E. CAP.	
C921	QER50JM-107	100MF 6. 3V AL. E. CAP.	U UB UP US UT
C922	QER50JM-107	100MF 6. 3V AL. E. CAP.	U UB UP US UT
C923	QCGB1HK-102	1000PF 50V CER. CAP.	U UB UP US UT
C1112	QCBB1HK-151	150PF 50V CER. CAP.	U UB UP US UT
C1114	QCBB1HK-331Y	330PF 50V CER. CAP.	U UB UP US UT
C1115	EETB1EM-106E	10MF 25V E. CAP.	U UB UP US UT
C1116	EETC1EM-226ZE	22MF 25V E. CAP.	U UB UP US UT
C1117	QFLB1HJ-104	0. 1MF 50V MYLAR CAP.	U UB UP US UT
C1118	QETB1HM-474N	0. 47MF 50V E. CAP.	U UB UP US UT
C1119	QCXB1CM-562Y	5600PF 16V CER. CAP.	U UB UP US UT
C1120	QCGB1HK-821	820PF 50V CER. CAP.	U UB UP US UT
C1121	QFLB1HJ-183	0. 018MF 50V MYLAR CAP.	U UB UP US UT
C1122	QFLB1HJ-104	0. 1MF 50V MYLAR CAP.	U UB UP US UT
C1123	QCVB1CM-103Y	0. 01MF 16V CER. CAP.	U UB UP US UT
C1124	QCGB1HK-821	820PF 50V CER. CAP.	U UB UP US UT
C1125	QCXB1CM-562Y	5600PF 16V CER. CAP.	U UB UP US UT
C1126	QETB1HM-474N	0. 47MF 50V E. CAP.	U UB UP US UT
C1127	QFLB1HJ-104	0. 1MF 50V MYLAR CAP.	U UB UP US UT
C1128	QFLB1HJ-104	0. 1MF 50V MYLAR CAP.	U UB UP US UT
C1129	QFLB1HJ-104	0. 1MF 50V MYLAR CAP.	U UB UP US UT
C1130	QFLB1HJ-183	0. 018MF 50V MYLAR CAP.	U UB UP US UT
C1131	QETN1CM-107Z	100MF 16V E. CAP.	U UB UP US UT
C1132	EETB1HM-105E	1MF 50V E. CAP.	U UB UP US UT

CA-D701T

Electrical Parts List (ENB-255)

△	Item	Parts Number	Description	Area
	C1133	QFLB1HJ-104	0.1MF 50V MYLAR CAP.	U UB UP US UT
	C1134	QCBB1HK-221Y	220PF 50V CER. CAP.	U UB UP US UT
	C1135	QCVB1CM-103Y	0.01MF 16V CER. CAP.	U UB UP US UT
	C1138	EETB1AM-107E	100MF 10V E. CAP.	U UB UP US UT
	C1139	QCGB1HK-102	1000PF 50V CER. CAP.	U UB UP US UT
	C1140	EETB1EM-106E	10MF 25V E. CAP.	U UB UP US UT
	C1141	QCBB1HK-101Y	100PF 50V CER. CAP.	U UB UP US UT
	C1142	QCBB1HK-101Y	100PF 50V CER. CAP.	U UB UP US UT
	C1143	EETB1EM-106E	10MF 25V E. CAP.	U UB UP US UT
	C1144	EETB1EM-106E	10MF 25V E. CAP.	U UB UP US UT
	C1145	EETB1EM-106E	10MF 25V E. CAP.	U UB UP US UT
	C1146	QCY31HK-103Z	0.01MF 50V CER. CAP.	U UB UP US UT
	C1147	QCGB1HK-102	1000PF 50V CER. CAP.	U UB UP US UT
	C1148	QCGB1HK-102	1000PF 50V CER. CAP.	U UB UP US UT
	TC902	ENZ1003-015	0.1MF TRIMMER CAPA	
		RESISTORS		
	R047	QRD161J-333	33K 1/6W CARBON RES.	
	R048	QRD161J-333	33K 1/6W CARBON RES.	
	R049	QRD161J-102	1K 1/6W CARBON RES.	
	R051	QRD14CJ-4R7SX	4.7 1/4W UNF. CARBON R	
	R052	QRD14CJ-4R7SX	4.7 1/4W UNF. CARBON R	
	R235	QRD167J-153	15K 1/6W CARBON RES.	
	R236	QRD167J-153	15K 1/6W CARBON RES.	
	R237	QRD161J-681	680 1/6W CARBON RES.	
	R238	QRD161J-681	680 1/6W CARBON RES.	
△	R239	QRD14CJ-220S	22 1/4W UNF. CARBON R	
	R240	QRD161J-103	10K 1/6W CARBON RES.	
	R241	QRD161J-183	18K 1/6W CARBON RES.	
	R242	QRD161J-183	18K 1/6W CARBON RES.	
	R245	QRD167J-751	750 1/6W CARBON RES.	
	R246	QRD167J-751	750 1/6W CARBON RES.	
	R247	QRD161J-471	470 1/6W CARBON RES.	
△	R248	QRX022J-3R3A	3.3 2W METAL FILM R	
	R249	QRD161J-103	10K 1/6W CARBON RES.	
	R250	QRD161J-103	10K 1/6W CARBON RES.	
	R251	QRD161J-103	10K 1/6W CARBON RES.	
	R255	QRD167J-751	750 1/6W CARBON RES.	
	R256	QRD167J-751	750 1/6W CARBON RES.	
	R257	QRD161J-471	470 1/6W CARBON RES.	
△	R258	QRX022J-3R3A	3.3 2W METAL FILM R	
	R259	QRD161J-224	220K 1/6W CARBON RES.	
	R260	QRD161J-103	10K 1/6W CARBON RES.	
	R261	QRD161J-473	47K 1/6W CARBON RES.	
	R262	QRD161J-273	27K 1/6W CARBON RES.	
	R263	QRD161J-102	1K 1/6W CARBON RES.	
	R264	QRD161J-103	10K 1/6W CARBON RES.	
	R265	QRD161J-103	10K 1/6W CARBON RES.	
	R266	QRD161J-103	10K 1/6W CARBON RES.	
	R267	QRD161J-103	10K 1/6W CARBON RES.	
	R268	QRD161J-221	220 1/6W CARBON RES.	
	R269	QRD161J-221	220 1/6W CARBON RES.	
	R801	QRD167J-431	430 1/6W CARBON RES.	
	R802	QRD167J-431	430 1/6W CARBON RES.	
	R803	QRD161J-561	560 1/6W CARBON RES.	
	R804	QRD167J-751	750 1/6W CARBON RES.	
	R805	QRD161J-132	1.3K 1/6W CARBON RES.	
	R806	QRD161J-222	2.2K 1/6W CARBON RES.	
	R807	QRD167J-431	430 1/6W CARBON RES.	
	R808	QRD167J-431	430 1/6W CARBON RES.	
	R809	QRD161J-561	560 1/6W CARBON RES.	
	R810	QRD167J-751	750 1/6W CARBON RES.	
	R811	QRD161J-132	1.3K 1/6W CARBON RES.	
	R812	QRD161J-331	330 1/6W CARBON RES.	
	R813	QRD161J-331	330 1/6W CARBON RES.	
	R814	QRD161J-331	330 1/6W CARBON RES.	
	R815	QRD161J-331	330 1/6W CARBON RES.	
	R816	QRD161J-331	330 1/6W CARBON RES.	
	R817	QRD161J-103	10K 1/6W CARBON RES.	
	R818	QRD161J-103	10K 1/6W CARBON RES.	
	R900	QRD161J-103	10K 1/6W CARBON RES.	

△	Item	Parts Number	Description	Area
	R901	QRD161J-105	1M 1/6W CARBON RES.	
	R902	QRD161J-103	10K 1/6W CARBON RES.	
	R903	QRD161J-220	22 1/6W CARBON RES.	
	R904	QRD161J-222	2.2K 1/6W CARBON RES.	
	R905	QRD161J-103	10K 1/6W CARBON RES.	
	R906	QRD161J-221	220 1/6W CARBON RES.	
	R907	QRD161J-221	220 1/6W CARBON RES.	
	R908	QRD161J-221	220 1/6W CARBON RES.	
	R909	QRD161J-221	220 1/6W CARBON RES.	
	R910	QRD161J-221	220 1/6W CARBON RES.	
	R911	QRD161J-221	220 1/6W CARBON RES.	
	R915	QRD161J-222	2.2K 1/6W CARBON RES.	U UB UP US UT
	R918	QRD167J-431	430 1/6W CARBON RES.	
	R919	QRD167J-431	430 1/6W CARBON RES.	
	R920	QRD161J-561	560 1/6W CARBON RES.	
	R921	QRD167J-751	750 1/6W CARBON RES.	
	R922	QRD161J-132	1.3K 1/6W CARBON RES.	
	R923	QRD161J-222	2.2K 1/6W CARBON RES.	
	R924	QRD161J-512	5.1K 1/6W CARBON RES.	
	R925	QRD167J-431	430 1/6W CARBON RES.	
	R926	QRD167J-431	430 1/6W CARBON RES.	
	R927	QRD161J-561	560 1/6W CARBON RES.	
	R928	QRD167J-751	750 1/6W CARBON RES.	
	R929	QRD161J-132	1.3K 1/6W CARBON RES.	
	R930	QRD161J-222	2.2K 1/6W CARBON RES.	
	R931	QRD161J-512	5.1K 1/6W CARBON RES.	
	R932	QRD167J-431	430 1/6W CARBON RES.	
	R933	QRD167J-431	430 1/6W CARBON RES.	
	R934	QRD161J-561	560 1/6W CARBON RES.	
	R935	QRD167J-751	750 1/6W CARBON RES.	
	R936	QRD161J-132	1.3K 1/6W CARBON RES.	
	R937	QRD161J-222	2.2K 1/6W CARBON RES.	
	R938	QRD161J-512	5.1K 1/6W CARBON RES.	
	R939	QRD167J-431	430 1/6W CARBON RES.	
	R944	QRD161J-181	180 1/6W CARBON RES.	
	R945	QRD161J-181	180 1/6W CARBON RES.	
	R946	QRD161J-181	180 1/6W CARBON RES.	
	R947	QRD161J-181	180 1/6W CARBON RES.	
	R948	QRD161J-181	180 1/6W CARBON RES.	
	R949	QRD161J-181	180 1/6W CARBON RES.	
	R950	QRD161J-181	180 1/6W CARBON RES.	
	R951	QRD161J-181	180 1/6W CARBON RES.	
	R952	QRD161J-181	180 1/6W CARBON RES.	
	R953	QRD161J-221	220 1/6W CARBON RES.	
	R954	QRD161J-181	180 1/6W CARBON RES.	
	R955	QRD161J-181	180 1/6W CARBON RES.	
	R956	QRD161J-181	180 1/6W CARBON RES.	
	R957	QRD161J-181	180 1/6W CARBON RES.	
	R958	QRD161J-181	180 1/6W CARBON RES.	
	R959	QRD161J-181	180 1/6W CARBON RES.	
	R960	QRD161J-102	1K 1/6W CARBON RES.	
	R961	QRD161J-221	220 1/6W CARBON RES.	
	R962	QRD161J-102	1K 1/6W CARBON RES.	
	R963	QRD161J-222	2.2K 1/6W CARBON RES.	
	R964	QRD161J-221	220 1/6W CARBON RES.	
	R965	QRD161J-221	220 1/6W CARBON RES.	
	R966	QRD161J-221	220 1/6W CARBON RES.	
	R967	QRD161J-221	220 1/6W CARBON RES.	
	R968	QRD161J-221	220 1/6W CARBON RES.	
	R970	QRD167J-223	22K 1/6W CARBON RES.	
	R971	QRD161J-472	4.7K 1/6W CARBON RES.	
	R972	QRD161J-472	4.7K 1/6W CARBON RES.	
	R973	QRD161J-472	4.7K 1/6W CARBON RES.	
	R974	QRD161J-472	4.7K 1/6W CARBON RES.	
	R975	QRD161J-473	47K 1/6W CARBON RES.	
	R976	QRD161J-104	100K 1/6W CARBON RES.	
	R977	QRD161J-104	100K 1/6W CARBON RES.	
	R978	QRD161J-104	100K 1/6W CARBON RES.	
	R979	QRD161J-104	100K 1/6W CARBON RES.	
	R980	QRD167J-562	5.6K 1/6W CARBON RES.	U UB UP US UT

Electrical Parts List (ENB-255)

Δ	Item	Parts Number	Description	Area
	R981	QRD161J-331	330 1/6W CARBON RES.	U UB UP US UT
	R982	QRD161J-103	10K 1/6W CARBON RES.	U UB UP US UT
	R983	QRD161J-103	10K 1/6W CARBON RES.	U UB UP US UT
	R984	QRD161J-103	10K 1/6W CARBON RES.	U UB UP US UT
	R985	QRD167J-152	1.5K 1/6W CARBON RES.	U UB UP US UT
	R986	QRD161J-331	330 1/6W CARBON RES.	U UB UP US UT
	R987	QRD161J-103	10K 1/6W CARBON RES.	
	R988	QRD161J-103	10K 1/6W CARBON RES.	U UB UP US UT
	R989	QRD161J-103	10K 1/6W CARBON RES.	
	R992	QRD161J-104	100K 1/6W CARBON RES.	
	R993	QRD161J-104	100K 1/6W CARBON RES.	U UB UP US UT
	R994	QRD161J-104	100K 1/6W CARBON RES.	U UB UP US UT
	R995	QRD161J-104	100K 1/6W CARBON RES.	
	R996	QRD167J-151	150 1/6W CARBON RES.	
	RA901	QRB069J-222	2.2K 1/10W NETWORK RES.	
	R1101	QRD161J-472	4.7K 1/6W CARBON RES.	U UB UP US UT
	R1102	QRD161J-472	4.7K 1/6W CARBON RES.	U UB UP US UT
	R1103	QRD161J-393	39K 1/6W CARBON RES.	U UB UP US UT
	R1104	QRD161J-221	220 1/6W CARBON RES.	U UB UP US UT
	R1105	QRD161J-221	220 1/6W CARBON RES.	U UB UP US UT
	R1111	QRD167J-223	22K 1/6W CARBON RES.	U UB UP US UT
	R1112	QRD161J-273	27K 1/6W CARBON RES.	U UB UP US UT
	R1113	QRD161J-753	75K 1/6W CARBON RES.	U UB UP US UT
	R1114	QRD161J-563	56K 1/6W CARBON RES.	U UB UP US UT
	R1115	QRD167J-562	5.6K 1/6W CARBON RES.	U UB UP US UT
	R1116	QRD167J-152	1.5K 1/6W CARBON RES.	U UB UP US UT
	R1117	QRD161J-123	12K 1/6W CARBON RES.	U UB UP US UT
	R1118	QRD161J-103	10K 1/6W CARBON RES.	U UB UP US UT
	R1119	QRD161J-103	10K 1/6W CARBON RES.	U UB UP US UT
	R1120	QRD161J-103	10K 1/6W CARBON RES.	U UB UP US UT
	R1121	QRD161J-472	4.7K 1/6W CARBON RES.	U UB UP US UT
	R1122	QRD161J-103	10K 1/6W CARBON RES.	U UB UP US UT
	R1123	QRD161J-103	10K 1/6W CARBON RES.	U UB UP US UT
	R1124	QRD161J-103	10K 1/6W CARBON RES.	U UB UP US UT
	R1131	QRD161J-221	220 1/6W CARBON RES.	U UB UP US UT
	R1132	QRD161J-331	330 1/6W CARBON RES.	U UB UP US UT
	R1133	QRD161J-221	220 1/6W CARBON RES.	U UB UP US UT
	R1134	QRD167J-223	22K 1/6W CARBON RES.	U UB UP US UT
	R1135	QRD161J-103	10K 1/6W CARBON RES.	U UB UP US UT
	R1136	QRD167J-562	5.6K 1/6W CARBON RES.	U UB UP US UT
	R1137	QRD161J-104	100K 1/6W CARBON RES.	U UB UP US UT
	VR233	QVPA603-103A	10K TRIMMER RES.	
	VR902	QVQ0032-B54	50K VARIABLE RE	U UB UP US UT
		OTHERS		
		EMW10685-102	CIR. BOARD	
	J081	EMB10TV-401AJ3	SPEAKER TERMINAL	
	J082	EMN00TV-119AJ4	PIN JACK	
	J083	EMN00TV-303AJ4	PIN JACK	A U UB UP US UT
		EMN00TV-304AJ4	PIN JACK	BS EF EN G VX
	J801	QMS3R80-EE0S	HEADPHONE JACK	
	K801	ENZ8101-007	INDUCTOR	
	S801	ESP0001-023M	TACT SWITCH	
	S802	ESP0001-023M	TACT SWITCH	
	S803	ESP0001-023M	TACT SWITCH	
	S804	ESP0001-023M	TACT SWITCH	
	S805	ESP0001-023M	TACT SWITCH	
	S806	ESP0001-023M	TACT SWITCH	
	S807	ESP0001-023M	TACT SWITCH	
	S808	ESP0001-023M	TACT SWITCH	
	S809	ESP0001-023M	TACT SWITCH	
	S810	ESP0001-023M	TACT SWITCH	
	S811	ESP0001-023M	TACT SWITCH	
	S812	ESP0001-023M	TACT SWITCH	
	S813	ESP0001-023M	TACT SWITCH	
	S901	ESP0001-023M	TACT SWITCH	
	S902	ESP0001-023M	TACT SWITCH	
	S903	ESP0001-023M	TACT SWITCH	
	S904	ESP0001-023M	TACT SWITCH	
	S905	ESP0001-023M	TACT SWITCH	
	S906	ESP0001-023M	TACT SWITCH	

Δ	Item	Parts Number	Description	Area
	S907	ESP0001-023M	TACT SWITCH	
	S908	ESP0001-023M	TACT SWITCH	
	S909	ESP0001-023M	TACT SWITCH	
	S910	ESP0001-023M	TACT SWITCH	
	S911	ESP0001-023M	TACT SWITCH	
	S912	ESP0001-023M	TACT SWITCH	
	S913	ESP0001-023M	TACT SWITCH	
	S914	ESP0001-023M	TACT SWITCH	
	S915	ESP0001-023M	TACT SWITCH	
	S916	ESP0001-023M	TACT SWITCH	
	S917	ESP0001-023M	TACT SWITCH	
	S918	ESP0001-023M	TACT SWITCH	
	S919	ESP0001-023M	TACT SWITCH	
	S920	ESP0001-023M	TACT SWITCH	
	S921	ESP0001-023M	TACT SWITCH	
	S922	ESP0001-023M	TACT SWITCH	
	S923	ESP0001-023M	TACT SWITCH	
	S924	ESP0001-023M	TACT SWITCH	
	S925	ESP0001-023M	TACT SWITCH	
	S926	ESP0001-023M	TACT SWITCH	
	X901	ECX0004-194KM	CERAMIC RESONATOR	
	X902	ECX0006-000KNJ	CRYSTAL	
	BK901	E309782-002SM	P. W. BOARD BRACKET	
	BK902	E310200-001SM	L. E. D. HOLDER	
	CN015	EMV5163-011R	CONNECT TERMINAL	
	CN101	EMV7163-012R	CONNECT TERMINAL	
	CN121	EWS26C-A408	FLAT WIRE ASSY	
	CN301	EMV7172-014R	CONNECT TERMINAL	
	CN302	EMV7172-014R	CONNECT TERMINAL	
	CN313	VMC0314-S14	CONNECT TERMINAL	
	CN314	VMC0314-S08	CONNECT TERMINAL	
	CN401	VMC0163-R33	CONNECT TERMINAL	
	CN403	EMV7160-016	CONNECT TERMINAL	
	CN713	EMV7163-007	CONNECT TERMINAL	
	CN714	EMV7163-006	CONNECT TERMINAL	
	DI901	QLF0012-001	FLUORESCENT DISPLAY TUBE	
	FS050	E3400-431	FELT SPACER	BS EF EN G VX
	FS146	E3400-431	FELT SPACER	U UB UP US UT
	FS901	E3400-439	FELT SPACER	
	FS902	E3400-439	FELT SPACER	
	FW401	VWSC12-083K3K	FLAT WIRE ASSY	
	FW402	EWR33D-25LS	FLAT WIRE	
	FW411	EWR37D-10LS	FLAT WIRE	
	FW412	EWR37D-10LS	FLAT WIRE	U UB UP US UT
	JS801	QSJ4003-E01	PUSH SWITCH	
	J1101	QNS0007-002	PIN JACK	U UB UP US UT
	J1102	QNS0007-002	PIN JACK	U UB UP US UT
	RY001	ESK7D24-213R	RELAY	
	RY002	ESK7D24-213R	RELAY	
	SP901	VYH7653-001	LEAF SPRING	
	SP902	VYH7653-001	LEAF SPRING	
	TW001	EWT015-001	TERMINAL WIRE	
	TW002	EWT015-020	TERMINAL WIRE ASSY	U UB UP US UT
	X1101	ECX0000-400KS	CERAMIC RESONATOR	U UB UP US UT

CA-D701T

Electrical Parts List (ENC-139)

△	Item	Parts Number	Description	Area
		I. C. S		
	IC301	MN173222JAAX1	I. C (MICRO-COMPUTER)	
	IC302	BA15218N	I. C (MONO-ANALOG)	
	IC303	BA15218N	I. C (MONO-ANALOG)	
	IC304	BA3126N	I. C (MONO-ANALOG)	
	IC305	HA12206NT	I. C (MONO-ANALOG)	
	IC401	TDA7439	I. C (M)	
	IC402	BA15218	I. C (MONO-ANALOG)	
	IC403	BA15218	I. C (MONO-ANALOG)	U UB UP US UT
	IC404	TC4052BP	I. C (DIGI-MOS)	U UB UP US UT
	IC405	BA15218	I. C (MONO-ANALOG)	
	IC406	LA2650	I. C (MONO-ANALOG)	
	IC407	BA15218	I. C (MONO-ANALOG)	
	IC501	LA2786	I. C (MONO-ANALOG)	
	IC541	LV1016	I. C (M)	
	IC561	TDA7439	I. C (M)	
	IC562	BA15218	I. C (MONO-ANALOG)	
		DIODES		
	D201	1SS133	SI. DIODE	
	D202	1SS133	SI. DIODE	
	D203	1SS133	SI. DIODE	
	D290	1SS133	SI. DIODE	
	D303	1SS133	SI. DIODE	BS EF EN G VX
	D305	MTZ7.5JC	ZENER DIODE	
	D306	MTZ7.5JC	ZENER DIODE	
	D307	1SS133	SI. DIODE	
	D308	1SS133	SI. DIODE	
	D401	MTZ5.1JB	ZENER DIODE	U UB UP US UT
	D402	MTZ5.1JB	ZENER DIODE	U UB UP US UT
	D403	1SS133	SI. DIODE	
	D481	1SS133	SI. DIODE	
	D482	1SS133	SI. DIODE	
		TRANSISTORS		
	Q201	KRC107M-T	DIGITAL TRANSISTOR	
	Q321	2SD2144S (VW)	SI. TRANSISTOR	
	Q322	2SD2144S (VW)	SI. TRANSISTOR	
	Q323	KRA107M-T	DIGITAL TRANSISTOR	
	Q324	2SD2144S (VW)	SI. TRANSISTOR	
	Q325	2SD2144S (VW)	SI. TRANSISTOR	
	Q326	2SC1740S (R. S)	SI. TRANSISTOR	
	Q327	2SC1740S (R. S)	SI. TRANSISTOR	
	Q328	2SC1740S (R. S)	SI. TRANSISTOR	
	Q329	2SC1740S (R. S)	SI. TRANSISTOR	
	Q330	2SC1740S (R. S)	SI. TRANSISTOR	BS EF EN G VX
	Q331	KRA104M-T	DIGITAL TRANSISTOR	BS EF EN G VX
	Q341	KRC107M-T	DIGITAL TRANSISTOR	
	Q342	KRC107M-T	DIGITAL TRANSISTOR	
	Q343	KRC107M-T	DIGITAL TRANSISTOR	
	Q401	2SD2144S (VW)	SI. TRANSISTOR	
	Q402	2SD2144S (VW)	SI. TRANSISTOR	
	Q403	KRA102M-T	DIGITAL TRANSISTOR	
	Q481	2SD2144S (VW)	SI. TRANSISTOR	
	Q482	2SD2144S (VW)	SI. TRANSISTOR	
	Q483	KRA102M-T	DIGITAL TRANSISTOR	
	Q491	KRC102M-T	DIGITAL TRANSISTOR	
	Q492	2SB1565 (E. F)	SI. TRANSISTOR	
	Q501	2SD2144S (VW)	SI. TRANSISTOR	
	Q502	2SD2144S (VW)	SI. TRANSISTOR	
		CAPACITORS		
	C201	QETN1AM-227Z	220MF 10V E. CAP.	
	C202	QCZ0205-155	1.5MF 25V C. CAP.	
	C203	QCVB1CM-103Y	0.01MF 16V CER. CAP.	
	C205	QCBB1HK-221Y	220PF 50V CER. CAP.	
	C206	QCBB1HK-221Y	220PF 50V CER. CAP.	
	C211	QCVB1CM-103Y	0.01MF 16V CER. CAP.	
	C231	QFLB1HJ-104	0.1MF 50V MYLAR CA	
	C232	QFLB1HJ-104	0.1MF 50V MYLAR CA	
	C305	QCBB1HK-101Y	100PF 50V CER. CAP.	
	C306	QCBB1HK-101Y	100PF 50V CER. CAP.	
	C315	EETB1HM-105E	1MF 50V E. CAP.	

△	Item	Parts Number	Description	Area
	C316	EETB1HM-105E	1MF 50V E. CAP.	
	C317	EETB1EM-106E	10MF 25V E. CAP.	
	C318	QETN1CM-107Z	100MF 16V E. CAP.	
	C319	QCF21HP-223A	0.022MF 50V CER. CAP.	BS EF EN G VX
	C320	QFLB1HJ-682	6800PF 50V MYLAR CA	
	C321	QFLB1HJ-332	3300PF 50V MYLAR CA	
	C322	QFLB1HJ-332	3300PF 50V MYLAR CA	
	C323	QFLB1HJ-183	0.018MF 50V MYLAR CA	
	C324	QFP31HG-472	4700PF 50V POLYPROP	
	C325	QCBB1HK-101Y	100PF 50V CER. CAP.	
	C326	QCBB1HK-101Y	100PF 50V CER. CAP.	
	C327	QCBB1HK-561Y	560PF 50V CER. CAP.	BS EF EN G VX
	C328	QCHB1EZ-223	0.022MF 25V CER. CAP.	BS EF EN G VX
	C335	QCF21HP-472	4700PF 50V CER. CAP.	
	C336	QCF21HP-472	4700PF 50V CER. CAP.	
	C339	EETB1CM-476	47MF 16V E. CAP.	
	C340	EETB1CM-476	47MF 16V E. CAP.	
	C341	QFLB1HJ-472	4700PF 50V MYLAR CA	
	C342	QFLB1HJ-472	4700PF 50V MYLAR CA	
	C343	QETC1HM-225ZM	2.2MF 50V E. CAP.	
	C344	QETC1HM-225ZM	2.2MF 50V E. CAP.	
	C345	QFLB1HJ-104	0.1MF 50V MYLAR CA	
	C346	QFLB1HJ-104	0.1MF 50V MYLAR CA	
	C347	QETC1HM-225ZM	2.2MF 50V E. CAP.	
	C348	QETC1HM-225ZM	2.2MF 50V E. CAP.	
	C351	QCBB1HK-821Y	820PF 50V CER. CAP.	
	C352	QETB1HM-474M	0.47MF 50V E. CAP.	
	C353	QETN1HM-476Z	47MF 50V E. CAP.	
	C365	QETC1HM-225ZM	2.2MF 50V E. CAP.	
	C366	QETC1HM-225ZM	2.2MF 50V E. CAP.	
	C367	QFLB1HJ-822	8200PF 50V MYLAR CA	
	C368	QFLB1HJ-822	8200PF 50V MYLAR CA	
	C369	EETB1AM-107E	100MF 10V E. CAP.	
	C370	EETB1AM-107E	100MF 10V E. CAP.	
	C371	QETC1HM-225ZM	2.2MF 50V E. CAP.	
	C372	QETC1HM-225ZM	2.2MF 50V E. CAP.	
	C373	EETB1CM-476	47MF 16V E. CAP.	
	C374	QETC1EM-476ZM	47MF 25V E. CAP.	
	C375	QCBB1HK-101Y	100PF 50V CER. CAP.	
	C376	QCBB1HK-101Y	100PF 50V CER. CAP.	
	C377	QCXB1CM-122	1200PF 16V POLYPROP	
	C378	QCXB1CM-122	1200PF 16V POLYPROP	
	C379	QCBB1HK-331Y	330PF 50V CER. CAP.	
	C380	QCBB1HK-331Y	330PF 50V CER. CAP.	
	C381	EETB1CM-476	47MF 16V E. CAP.	
	C385	QFLB1HJ-822	8200PF 50V MYLAR CA	
	C386	QFLB1HJ-822	8200PF 50V MYLAR CA	
	C387	EETB1AM-107E	100MF 10V E. CAP.	
	C388	EETB1AM-107E	100MF 10V E. CAP.	
	C389	QETC1HM-225ZM	2.2MF 50V E. CAP.	
	C390	QETC1HM-225ZM	2.2MF 50V E. CAP.	
	C391	EETB1CM-476	47MF 16V E. CAP.	
	C392	EETB1CM-476	47MF 16V E. CAP.	
	C393	QCS21HJ-101A	100PF 50V CER. CAP.	
	C394	QCS21HJ-101A	100PF 50V CER. CAP.	
	C395	QCXB1CM-152Y	1500PF 16V CER. CAP.	
	C396	QCXB1CM-152Y	1500PF 16V CER. CAP.	
	C397	QCBB1HK-391Y	390PF 50V CER. CAP.	
	C398	QCBB1HK-391Y	390PF 50V CER. CAP.	
	C401	QFLB1HJ-472	4700PF 50V MYLAR CA	
	C402	QFLB1HJ-472	4700PF 50V MYLAR CA	
	C403	QFLB1HJ-102	1000PF 50V MYLAR CA	
	C404	QFLB1HJ-102	1000PF 50V MYLAR CA	
	C405	EETB1EM-106E	10MF 25V E. CAP.	
	C406	EETB1EM-106E	10MF 25V E. CAP.	
	C407	EETB1EM-106E	10MF 25V E. CAP.	
	C408	EETB1EM-106E	10MF 25V E. CAP.	
	C409	QFLB1HJ-392	3900PF 50V MYLAR CA	BS EF EN G VX
	C410	QFLB1HJ-392	3900PF 50V MYLAR CA	BS EF EN G VX
	C411	EETB1EM-106E	10MF 25V E. CAP.	

Electrical Parts List (ENC-139)

△	Item	Parts Number	Description	Area
	C412	EETB1EM-106E	10MF 25V E. CAP.	
	C413	QCB1HK-471Y	470PF 50V CER. CAP.	
	C414	QCB1HK-471Y	470PF 50V CER. CAP.	
	C415	EETB1EM-106E	10MF 25V E. CAP.	
	C416	EETB1EM-106E	10MF 25V E. CAP.	
	C417	EETB1EM-106E	10MF 25V E. CAP.	
	C418	EETB1EM-106E	10MF 25V E. CAP.	
	C419	EETB1EM-106E	10MF 25V E. CAP.	
	C420	QETN1AM-227Z	220MF 10V E. CAP.	
	C421	QFLB1HJ-104	0.1MF 50V MYLAR CA	
	C422	QFLB1HJ-104	0.1MF 50V MYLAR CA	
	C423	QFLB1HJ-104	0.1MF 50V MYLAR CA	
	C424	QFLB1HJ-104	0.1MF 50V MYLAR CA	
	C425	QFLB1HJ-183	0.018MF 50V MYLAR CA	
	C426	QFLB1HJ-183	0.018MF 50V MYLAR CA	
	C427	QFLB1HJ-223	0.022MF 50V MYLAR CA	
	C428	QFLB1HJ-223	0.022MF 50V MYLAR CA	
	C429	QFLB1HJ-562	5600PF 50V MYLAR CA	
	C430	QFLB1HJ-562	5600PF 50V MYLAR CA	
	C431	QETC1HM-225ZM	2.2MF 50V E. CAP.	
	C432	QETC1HM-225ZM	2.2MF 50V E. CAP.	
	C433	EETB1HM-105E	1MF 50V E. CAP.	
	C434	EETB1HM-105E	1MF 50V E. CAP.	
	C435	EETB1EM-106E	10MF 25V E. CAP.	
	C436	EETB1EM-106E	10MF 25V E. CAP.	
	C437	EETB1EM-106E	10MF 25V E. CAP.	U UB UP US UT
	C438	EETB1EM-106E	10MF 25V E. CAP.	U UB UP US UT
	C439	QETN1HM-224Z	0.22MF 50V AL. E. CA	U UB UP US UT
	C440	EETB1EM-106E	10MF 25V E. CAP.	U UB UP US UT
	C441	EETB1EM-106E	10MF 25V E. CAP.	U UB UP US UT
	C442	EETB1EM-106E	10MF 25V E. CAP.	U UB UP US UT
	C443	EETB1EM-106E	10MF 25V E. CAP.	
	C444	EETB1EM-106E	10MF 25V E. CAP.	
	C445	QCB1HK-101Y	100PF 50V CER. CAP.	
	C446	QCB1HK-101Y	100PF 50V CER. CAP.	
	C447	EETB1EM-106E	10MF 25V E. CAP.	
	C448	EETB1EM-106E	10MF 25V E. CAP.	
	C451	EETB1EM-106E	10MF 25V E. CAP.	U UB UP US UT
	C452	EETB1EM-106E	10MF 25V E. CAP.	U UB UP US UT
	C453	EETB1EM-106E	10MF 25V E. CAP.	U UB UP US UT
	C454	QCB1HK-101Y	100PF 50V CER. CAP.	U UB UP US UT
	C455	EETB1EM-106E	10MF 25V E. CAP.	U UB UP US UT
	C457	EETB1EM-106E	10MF 25V E. CAP.	
	C458	EETB1EM-106E	10MF 25V E. CAP.	
	C459	QFLB1HJ-333	0.033MF 50V MYLAR CA	
	C460	EETB1HM-475E	4.7MF 50V E. CAP.	
	C461	QETB1HM-474N	0.47MF 50V E. CAP.	
	C462	QFLB1HJ-393	0.039MF 50V MYLAR CA	
	C463	QETB1HM-474N	0.47MF 50V E. CAP.	
	C464	QETN1AM-227Z	220MF 10V E. CAP.	
	C465	QFLB1HJ-393	0.039MF 50V MYLAR CA	
	C466	QFLB1HJ-473	0.047MF 50V MYLAR CA	
	C467	EETB1HM-105E	1MF 50V E. CAP.	
	C468	QETC1EM-476ZM	47MF 25V E. CAP.	
	C469	EETB1EM-106E	10MF 25V E. CAP.	
	C470	EETB1EM-106E	10MF 25V E. CAP.	
	C471	QCB1HK-101Y	100PF 50V CER. CAP.	
	C472	QCB1HK-101Y	100PF 50V CER. CAP.	
	C473	QETC1EM-476ZM	47MF 25V E. CAP.	
	C474	QETC1EM-476ZM	47MF 25V E. CAP.	
	C475	EETB1EM-106E	10MF 25V E. CAP.	
	C476	EETB1EM-106E	10MF 25V E. CAP.	
	C477	EETB1HM-475E	4.7MF 50V E. CAP.	
	C481	QCB1HK-221Y	220PF 50V CER. CAP.	
	C482	QCB1HK-221Y	220PF 50V CER. CAP.	
	C483	QCXB1CM-222Y	2200PF 16V CER. CAP.	
	C485	QETB1AM-107	100MF 10V AL. E. CA	
	C489	QETB1CM-476	47MF 16V AL. E. CA	
	C490	QETB1CM-476	47MF 16V AL. E. CA	
	C493	QFLB1HJ-104	0.1MF 50V MYLAR CA	

△	Item	Parts Number	Description	Area
	C494	QFLB1HJ-104	0.1MF 50V MYLAR CA	
	C495	QFLB1HJ-104	0.1MF 50V MYLAR CA	
	C496	QFLB1HJ-104	0.1MF 50V MYLAR CA	
	C501	EETB1EM-106E	10MF 25V E. CAP.	
	C502	EETB1EM-106E	10MF 25V E. CAP.	
	C503	QFLB1HJ-223	0.022MF 50V MYLAR CA	
	C504	QFLB1HJ-473	0.047MF 50V MYLAR CA	
	C505	QETN1AM-227Z	220MF 10V E. CAP.	
	C506	EETB1EM-106E	10MF 25V E. CAP.	
	C507	EETB1EM-106E	10MF 25V E. CAP.	
	C508	EETB1EM-106E	10MF 25V E. CAP.	
	C509	EETB1EM-106E	10MF 25V E. CAP.	
	C510	QETN1AM-227Z	220MF 10V E. CAP.	
	C511	QFLB1HJ-104	0.1MF 50V MYLAR CA	
	C512	QFLB1HJ-104	0.1MF 50V MYLAR CA	
	C513	QFLB1HJ-104	0.1MF 50V MYLAR CA	
	C514	QFLB1HJ-104	0.1MF 50V MYLAR CA	
	C515	QETB1HM-474N	0.47MF 50V E. CAP.	
	C516	QETB1HM-474N	0.47MF 50V E. CAP.	
	C517	EETB1HM-475E	4.7MF 50V E. CAP.	
	C518	EETB1HM-475E	4.7MF 50V E. CAP.	
	C519	QETB1HM-474N	0.47MF 50V E. CAP.	
	C520	QETB1HM-474N	0.47MF 50V E. CAP.	
	C521	EETB1HM-475E	4.7MF 50V E. CAP.	
	C522	EETB1HM-475E	4.7MF 50V E. CAP.	
	C523	QFV81HJ-154	0.15MF 50V THIN FIL	
	C524	QFV81HJ-154	0.15MF 50V THIN FIL	
	C525	QETN1HM-335Z	3.3MF 50V ELECTRO	
	C526	QETN1HM-335Z	3.3MF 50V ELECTRO	
	C527	QFV81HJ-154	0.15MF 50V THIN FIL	
	C528	QFV81HJ-154	0.15MF 50V THIN FIL	
	C529	QFV71HJ-474ZM	0.47MF 50V THIN FIL	
	C530	QETC1EM-476ZM	47MF 25V E. CAP.	
	C531	QETN1CM-227ZS	220MF 16V E. CAP.	
	C532	QCB1HK-681Y	680PF 50V CER. CAP.	
	C533	QCB1HK-561Y	560PF 50V CER. CAP.	
	C535	QCB1HK-561Y	560PF 50V CER. CAP.	
	C541	QETC1HM-225ZM	2.2MF 50V E. CAP.	
	C542	QETN1CM-227ZS	220MF 16V E. CAP.	
	C543	QCF21HP-473A	0.047MF 50V CER. CAP.	
	C544	QETB1HM-474N	0.47MF 50V E. CAP.	
	C545	QETB1HM-474N	0.47MF 50V E. CAP.	
	C546	QFLB1HJ-823	0.082MF 50V MYLAR CA	
	C547	QCY31HK-332Z	3300PF 50V CER. CAP.	
	C548	QFLB1HJ-823	0.082MF 50V MYLAR CA	
	C549	QETN1AM-227Z	220MF 10V E. CAP.	
	C550	QCF21HP-473A	0.047MF 50V CER. CAP.	
	C551	QCS21HJ-300	30PF 50V CER. CAP.	
	C552	QCS21HJ-300	30PF 50V CER. CAP.	
	C553	EETB1EM-106E	10MF 25V E. CAP.	
	C554	EETB1EM-106E	10MF 25V E. CAP.	
	C555	EETB1EM-106E	10MF 25V E. CAP.	
	C556	EETB1EM-106E	10MF 25V E. CAP.	
	C561	QETC1HM-225ZM	2.2MF 50V E. CAP.	
	C562	QETC1HM-225ZM	2.2MF 50V E. CAP.	
	C563	EETB1HM-105E	1MF 50V E. CAP.	
	C564	EETB1HM-105E	1MF 50V E. CAP.	
	C565	EETB1EM-106E	10MF 25V E. CAP.	
	C566	QETN1AM-227Z	220MF 10V E. CAP.	
	C569	EETB1EM-106E	10MF 25V E. CAP.	
	C570	EETB1EM-106E	10MF 25V E. CAP.	
		RESISTORS		
	R202	QRD161J-102	1K 1/6W CARBON R	
	R203	QRD161J-102	1K 1/6W CARBON R	
	R204	QRD161J-102	1K 1/6W CARBON R	
	R205	QRD161J-102	1K 1/6W CARBON R	
	R206	QRD161J-103	10K 1/6W CARBON R	
	R207	QRD161J-103	10K 1/6W CARBON R	
	R208	QRD161J-472	4.7K 1/6W CARBON R	
	R209	QRD161J-223	22K 1/6W CARBON R	

CA-D701T

Electrical Parts List (ENG-139)

△	Item	Parts Number	Description	Area
	R211	QRD161J-103	10K 1/6W CARBON R	
	R213	QRD161J-472	4.7K 1/6W CARBON R	
	R214	QRD161J-103	10K 1/6W CARBON R	
	R217	QRD161J-103	10K 1/6W CARBON R	
	R218	QRD161J-221	220 1/6W CARBON R	
	R231	QRD161J-183	18K 1/6W CARBON R	
	R232	QRD161J-183	18K 1/6W CARBON R	
	R233	QRD167J-153	15K 1/6W CARBON R	
	R234	QRD167J-153	15K 1/6W CARBON R	
	R271	QRD161J-104	100K 1/6W CARBON R	
	R272	QRD161J-104	100K 1/6W CARBON R	
	R280	QRD161J-221	220 1/6W CARBON R	
	R281	QRD161J-224	220K 1/6W CARBON R	
	R282	QRD161J-224	220K 1/6W CARBON R	
	R283	QRD161J-100	10 1/6W CARBON R	
	R284	QRD161J-100	10 1/6W CARBON R	
	R285	QRD161J-393	39K 1/6W CARBON R	
	R286	QRD161J-393	39K 1/6W CARBON R	
	R287	QRD140J-6R8SX	6.8 1/4W UNF. CARB	
△	R288	QRZ0077-100	10 1/4W FUSIBLE	
	R290	QRD167J-332	3.3K 1/6W CARBON R	
	R292	QRD161J-181	180 1/6W CARBON R	
	R293	QRD167J-511	510 1/6W CARBON R	
	R294	QRD161J-561	560 1/6W CARBON R	
	R296	QRD161J-104	100K 1/6W CARBON R	
	R297	QRD161J-222	2.2K 1/6W CARBON R	
	R298	QRD161J-561	560 1/6W CARBON R	BS EF EN G VX
	R335	QRD161J-102	1K 1/6W CARBON R	
	R336	QRD161J-102	1K 1/6W CARBON R	
	R337	QRD161J-102	1K 1/6W CARBON R	
	R338	QRD161J-102	1K 1/6W CARBON R	
	R339	QRD161J-393	39K 1/6W CARBON R	
	R340	QRD161J-393	39K 1/6W CARBON R	
	R341	QRD167J-272	2.7K 1/6W CARBON R	
	R342	QRD167J-272	2.7K 1/6W CARBON R	
	R343	QRD167J-223	22K 1/6W CARBON R	
	R344	QRD161J-563	56K 1/6W CARBON R	
	R345	QRD161J-184	180K 1/6W CARBON R	
	R346	QRD161J-105	1M 1/6W CARBON R	
	R347	QRD161J-221	220 1/6W CARBON R	
	R348	QRD161J-221	220 1/6W CARBON R	
	R349	QRD161J-102	1K 1/6W CARBON R	
	R351	QRD161J-472	4.7K 1/6W CARBON R	
	R352	QRD161J-472	4.7K 1/6W CARBON R	
	R353	QRD167J-223	22K 1/6W CARBON R	
	R354	QRD167J-223	22K 1/6W CARBON R	
	R355	QRD161J-103	10K 1/6W CARBON R	
	R356	QRD161J-103	10K 1/6W CARBON R	
	R357	QRD167J-223	22K 1/6W CARBON R	
	R358	QRD167J-223	22K 1/6W CARBON R	
	R359	QRD161J-103	10K 1/6W CARBON R	
	R360	QRD161J-103	10K 1/6W CARBON R	
	R361	QRD167J-562	5.6K 1/6W CARBON R	
	R362	QRD167J-562	5.6K 1/6W CARBON R	
	R365	QRD161J-470	47 1/6W CARBON R	BS EF EN G VX
	R366	QRD161J-470	47 1/6W CARBON R	BS EF EN G VX
	R367	QRD161J-224	220K 1/6W CARBON R	
	R368	QRD161J-224	220K 1/6W CARBON R	
	R371	QRD161J-163	16K 1/6W CARBON R	
	R372	QRD161J-163	16K 1/6W CARBON R	
	R377	QRD161J-221	220 1/6W CARBON R	
	R378	QRD161J-221	220 1/6W CARBON R	
	R381	QRD161J-221	220 1/6W CARBON R	
	R382	QRD161J-221	220 1/6W CARBON R	
	R383	QRD161J-470	47 1/6W CARBON R	BS EF EN G VX
	R384	QRD161J-470	47 1/6W CARBON R	BS EF EN G VX
	R385	QRD161J-224	220K 1/6W CARBON R	
	R386	QRD161J-224	220K 1/6W CARBON R	
	R391	QRD161J-163	16K 1/6W CARBON R	
	R392	QRD161J-163	16K 1/6W CARBON R	

△	Item	Parts Number	Description	Area
	R401	QRD161J-222	2.2K 1/6W CARBON R	
	R402	QRD161J-222	2.2K 1/6W CARBON R	
	R403	QRD161J-222	2.2K 1/6W CARBON R	
	R404	QRD161J-222	2.2K 1/6W CARBON R	
	R405	QRD167J-152	1.5K 1/6W CARBON R	
	R406	QRD167J-152	1.5K 1/6W CARBON R	
	R407	QRD167J-562	5.6K 1/6W CARBON R	
	R408	QRD167J-562	5.6K 1/6W CARBON R	
	R409	QRD167J-332	3.3K 1/6W CARBON R	
	R410	QRD167J-332	3.3K 1/6W CARBON R	
	R411	QRD167J-562	5.6K 1/6W CARBON R	
	R412	QRD167J-562	5.6K 1/6W CARBON R	
	R413	QRD161J-102	1K 1/6W CARBON R	
	R414	QRD161J-102	1K 1/6W CARBON R	
	R415	QRD161J-823	82K 1/6W CARBON R	
	R416	QRD161J-823	82K 1/6W CARBON R	
	R417	QRD167J-562	5.6K 1/6W CARBON R	
	R418	QRD167J-562	5.6K 1/6W CARBON R	
	R419	QRD167J-272	2.7K 1/6W CARBON R	
	R420	QRD167J-272	2.7K 1/6W CARBON R	
	R421	QRD161J-104	100K 1/6W CARBON R	
	R422	QRD161J-104	100K 1/6W CARBON R	
	R423	QRD161J-303Y	30K 1/6W CARBON R	U UB UP US UT
	R424	QRD167J-153	15K 1/6W CARBON R	U UB UP US UT
	R425	QRD167J-153	15K 1/6W CARBON R	U UB UP US UT
	R426	QRD161J-303Y	30K 1/6W CARBON R	U UB UP US UT
	R427	QRD167J-153	15K 1/6W CARBON R	U UB UP US UT
	R428	QRD161J-104	100K 1/6W CARBON R	U UB UP US UT
	R429	QRD161J-471	470 1/6W CARBON R	U UB UP US UT
	R430	QRD161J-471	470 1/6W CARBON R	U UB UP US UT
	R431	QRD161J-104	100K 1/6W CARBON R	
	R432	QRD161J-104	100K 1/6W CARBON R	
	R433	QRD167J-562	5.6K 1/6W CARBON R	
	R434	QRD167J-562	5.6K 1/6W CARBON R	
	R435	QRD161J-392	3.9K 1/6W CARBON R	A BS EF EN G VX
		QRD161J-472	4.7K 1/6W CARBON R	U UB UP US UT
	R436	QRD161J-392	3.9K 1/6W CARBON R	A BS EF EN G VX
		QRD161J-472	4.7K 1/6W CARBON R	U UB UP US UT
	R437	QRD161J-472	4.7K 1/6W CARBON R	
	R438	QRD161J-472	4.7K 1/6W CARBON R	
	R439	QRD161J-432	4.3K 1/6W CARBON R	
	R440	QRD161J-432	4.3K 1/6W CARBON R	
	R441	QRD161J-104	100K 1/6W CARBON R	
	R442	QRD161J-104	100K 1/6W CARBON R	
	R443	QRD161J-203	20K 1/6W CARBON R	U UB UP US UT
	R444	QRD161J-203	20K 1/6W CARBON R	U UB UP US UT
	R445	QRD161J-303Y	30K 1/6W CARBON R	U UB UP US UT
	R446	QRD161J-303Y	30K 1/6W CARBON R	U UB UP US UT
	R447	QRD167J-153	15K 1/6W CARBON R	U UB UP US UT
	R448	QRD161J-104	100K 1/6W CARBON R	U UB UP US UT
	R450	QRD161J-224	220K 1/6W CARBON R	
	R451	QRD161J-104	100K 1/6W CARBON R	
	R452	QRD161J-104	100K 1/6W CARBON R	
	R453	QRD161J-104	100K 1/6W CARBON R	
	R454	QRD161J-104	100K 1/6W CARBON R	
	R455	QRD161J-103	10K 1/6W CARBON R	
	R456	QRD161J-103	10K 1/6W CARBON R	
	R457	QRD161J-752	7.5K 1/6W CARBON R	
	R458	QRD161J-752	7.5K 1/6W CARBON R	
	R459	QRD161J-104	100K 1/6W CARBON R	
	R460	QRD161J-104	100K 1/6W CARBON R	
	R461	QRD161J-221	220 1/6W CARBON R	
	R462	QRD161J-221	220 1/6W CARBON R	
	R463	QRD161J-103	10K 1/6W CARBON R	
	R464	QRD161J-103	10K 1/6W CARBON R	
	R465	QRD161J-102	1K 1/6W CARBON R	
	R469	QRD161J-221	220 1/6W CARBON R	
	R470	QRD161J-221	220 1/6W CARBON R	
	R471	QRD161J-103	10K 1/6W CARBON R	
	R472	QRD161J-103	10K 1/6W CARBON R	

Electrical Parts List (ENC-139)

△	Item	Parts Number	Description	Area
	R473	QRD161J-103	10K 1/6W CARBON R	
	R481	QRD161J-222	2.2K 1/6W CARBON R	
	R482	QRD161J-222	2.2K 1/6W CARBON R	
	R483	QRD161J-221	220 1/6W CARBON R	
	R484	QRD161J-221	220 1/6W CARBON R	
	R485	QRD161J-103	10K 1/6W CARBON R	
	R486	QRD161J-103	10K 1/6W CARBON R	
	R490	QRD161J-221	220 1/6W CARBON R	BS EF EN G VX
	R491	QRD161J-471	470 1/6W CARBON R	
	R492	QRD161J-103	10K 1/6W CARBON R	
	R493	QRD167J-113	11K 1/6W CARBON R	
	R494	QRD167J-113	11K 1/6W CARBON R	
	R497	QRD161J-104	100K 1/6W CARBON R	
	R498	QRD161J-104	100K 1/6W CARBON R	
	R501	QRD161J-102	1K 1/6W CARBON R	
	R502	QRD161J-102	1K 1/6W CARBON R	
	R541	QRD161J-105	1M 1/6W CARBON R	
	R542	QRD161J-393	39K 1/6W CARBON R	
	R543	QRD161J-102	1K 1/6W CARBON R	
	R544	QRD161J-102	1K 1/6W CARBON R	
	R545	QRD161J-203	20K 1/6W CARBON R	
	R553	QRD161J-104	100K 1/6W CARBON R	
	R554	QRD161J-104	100K 1/6W CARBON R	
	R555	QRD161J-104	100K 1/6W CARBON R	
	R556	QRD161J-104	100K 1/6W CARBON R	
	R561	QRD161J-473	47K 1/6W CARBON R	
	R562	QRD161J-473	47K 1/6W CARBON R	
	R563	QRD161J-103	10K 1/6W CARBON R	
	R564	QRD161J-103	10K 1/6W CARBON R	
	R565	QRD161J-162	1.6K 1/6W CARBON R	
	R566	QRD161J-162	1.6K 1/6W CARBON R	
	R567	QRD161J-104	100K 1/6W CARBON R	
	R568	QRD161J-104	100K 1/6W CARBON R	
	R569	QRD161J-221	220 1/6W CARBON R	
	R570	QRD161J-221	220 1/6W CARBON R	
	R571	QRD161J-103	10K 1/6W CARBON R	
	R572	QRD161J-103	10K 1/6W CARBON R	
	VR231	QVPA603-503A	50K VARIABLE	
	VR232	QVPA603-503A	50K VARIABLE	
	VR301	QVPA603-102AZA	1K TRIMMER	
	VR302	QVPA603-102AZA	1K TRIMMER	
	VR303	QVPA603-102AZA	1K TRIMMER	
	VR304	QVPA603-102AZA	1K TRIMMER	
	VR305	QVPA603-104A	100K TRIMMER	
	VR306	QVPA603-104A	100K TRIMMER	
	VR307	QVPA603-104A	100K TRIMMER	
	VR308	QVPA603-104A	100K TRIMMER	
	VR309	QVPA603-104A	100K TRIMMER	
	VR310	QVPA603-104A	100K TRIMMER	
		OTHERS		
		EMW10686-102	CIR. BOARD	
		E3400-431	FELT SPACER	
		QWE350-09RR	VINYL WIRE	
	J401	EMN00TV-414AJ2	4P PIN JACK	
	J701	EMV7145-004Z	SOCKET ASSY	
	J702	EMV7145-003Z	SOCKET ASSY	
	K301	ENZ8101-007	INDUCTOR	BS EF EN G VX
	K302	ENZ8101-007	INDUCTOR	BS EF EN G VX
	K303	ENZ8101-007	INDUCTOR	BS EF EN G VX
	K321	ENZ8101-007	INDUCTOR	BS EF EN G VX
	K392	ENZ8101-007	INDUCTOR	BS EF EN G VX
	L301	ENZ6002-012	OSCILLATOR COIL	
	L305	EQL2106-223	INDUCTOR	
	L306	EQL2106-223	INDUCTOR	
	S490	GSS7A12-E01	SLIDE SWITCH	BS EF EN G VX
	X201	ECX0060-000EM	CERAMIC RESONATOR	
	X541	ECXP8RO-001Z	CRYSTAL	
	CN016	EMV5163-010R	CONNECT TERMINAL	
	CN017	EMV5163-009R	CONNECT TERMINAL	
	CN131	EMV5109-012A	MALE CONNECTOR	

△	Item	Parts Number	Description	Area
	CN311	EMV5172-014B	CONNECT TERMINAL	
	CN312	EMV5172-014B	CONNECT TERMINAL	
	CN322	VMC0163-016	CONNECT TERMINAL	
	CN331	EMV7155-106R	CONNECT TERMINAL	
	CN332	EMV7155-106R	CONNECT TERMINAL	
	CN402	VMC0163-017	CONNECT TERMINAL	
	CN411	VMC0163-033	CONNECT TERMINAL	
	CN412	VMC0163-017	CONNECT TERMINAL	
	CN613	VMC0163-007	CONNECT TERMINAL	
	CN614	VMC0163-011	CONNECT TERMINAL	
	CN811	VMC0163-010	AC CONNECTOR	
△	CP401	1CP-N15	I. C. PROTECTOR	
	EP003	E409182-001SM	EARTH TERMINAL	
	FS485	E3400-431	FELT SPACER	
	JT201	EMV7145-003Z	SOCKET ASSY	U UB UP US UT
	JT202	EMV7145-004Z	SOCKET ASSY	U UB UP US UT
	SP301	VYH7653-001	LEAF SPRING	

CA-D701T

Electrical Parts List (ENN-488)

Δ	Item	Parts Number	Description	Area
		I. C. S		
	IC601	AN8806SB	I. C (MONO-ANALOG)	
	IC602	BA6897FPW	I. C (MONO-ANALOG)	
	IC603	MN35510-S	I. C (M)	
		DIODES		
	D631	MTZ5.6JB	ZENER DIODE	
		TRANSISTORS		
	Q601	2SA952 (L, K)	SI. TRANSISTOR	
	Q632	2SC2060 (Q, R)	SI. TRANSISTOR	
		CAPACITORS		
	C602	QCZ0205-155	1.5MF 25V C. CAP.	
	C603	QFLB1HJ-104	0.1MF 50V MYLAR CAP.	
	C605	EETB1EM-106E	10MF 25V E. CAP.	
	C606	QCBB1HK-102Y	1000PF 50V CER. CAP.	
	C607	QCBB1HK-102Y	1000PF 50V CER. CAP.	
	C608	EETB1HM-105E	1MF 50V E. CAP.	
	C609	QCBB1HK-101Y	100PF 50V CER. CAP.	
	C610	QFLB1HJ-273	0.027MF 50V MYLAR CAP.	
	C611	QCXB1CM-472Y	4700PF 16V CER. CAP.	
	C612	QCVB1CM-103Y	0.01MF 16V CER. CAP.	
	C613	QCBB1HK-331Y	330PF 50V CER. CAP.	
	C614	QFLB1HJ-104	0.1MF 50V MYLAR CAP.	
	C615	QCHB1EZ-223	0.022MF 25V CER. CAP.	
	C616	QCHB1EZ-223	0.022MF 25V CER. CAP.	
	C617	QCHB1EZ-223	0.022MF 25V CER. CAP.	
	C618	QCHB1EZ-223	0.022MF 25V CER. CAP.	
	C619	QCBB1HK-271Y	270PF 50V CER. CAP.	
	C620	QCSB1HJ-470	47PF 50V CER. CAP.	
	C621	QCBB1HK-102Y	1000PF 50V CER. CAP.	
	C622	QCF21HP-223A	0.022MF 50V CER. CAP.	
	C623	QFLB1HJ-104	0.1MF 50V MYLAR CAP.	
	C625	QCZ0205-155	1.5MF 25V C. CAP.	
	C630	QETN1AM-226ZS	22MF 10V E. CAP.	
	C631	QETN1AM-477Z	470MF 10V E. CAP.	
	C632	QEK61AM-227ZM	220MF 10V AL. E. CAP.	
	C636	EETB1AM-107E	100MF 10V E. CAP.	
	C641	QCVB1CM-103Y	0.01MF 16V CER. CAP.	
	C642	QFLB1HJ-103	0.01MF 50V MYLAR CAP.	
	C651	QCSB1HJ-120Y	12PF 50V CER. CAP.	
	C652	QCSB1HJ-120Y	12PF 50V CER. CAP.	
	C653	QCHB1EZ-223	0.022MF 25V CER. CAP.	
	C655	QFV81HJ-104	0.1MF 50V THIN FILM CAP.	
	C661	QCBB1HK-471Y	470PF 50V CER. CAP.	
	C662	QFV81HJ-104	0.1MF 50V THIN FILM CAP.	
	C663	QFLB1HJ-223	0.022MF 50V MYLAR CAP.	
	C664	QCHB1EZ-223	0.022MF 25V CER. CAP.	
	C665	QFV81HJ-104	0.1MF 50V THIN FILM CAP.	
	C671	QCXB1CM-222Y	2200PF 16V CER. CAP.	
	C672	QCXB1CM-222Y	2200PF 16V CER. CAP.	
	C674	QCHB1EZ-223	0.022MF 25V CER. CAP.	
	C675	QCHB1EZ-223	0.022MF 25V CER. CAP.	
	C679	QEK51AM-107	100MF 10V AL. E. CAP.	
	C693	QEK61AM-227ZM	220MF 10V AL. E. CAP.	
	C694	QCHB1EZ-223	0.022MF 25V CER. CAP.	
		RESISTORS		
	R601	QRD161J-123	12K 1/6W CARBON RES.	
	R603	QRD161J-125	1.2M 1/6W CARBON RES.	
	R605	QRD161J-274	270K 1/6W CARBON RES.	
	R606	QRD161J-154	150K 1/6W CARBON RES.	
	R607	QRD161J-273	27K 1/6W CARBON RES.	
	R609	QRD161J-114	110K 1/6W CARBON RES.	
	R610	QRD161J-104	100K 1/6W CARBON RES.	
	R611	QRD161J-473	47K 1/6W CARBON RES.	
	R612	QRD161J-822	8.2K 1/6W CARBON RES.	
	R613	QRD161J-121	120 1/6W CARBON RES.	
	R614	QRD161J-100	10 1/6W CARBON RES.	
	R615	QRD161J-120	12 1/6W CARBON RES.	
	R616	QRD161J-910Y	91 1/6W CARBON RES.	
	R632	QRD161J-151	150 1/6W CARBON RES.	
	R641	QRD161J-683	68K 1/6W CARBON RES.	

Δ	Item	Parts Number	Description	Area
	R642	QRD161J-222	2.2K 1/6W CARBON RES.	
	R643	QRD161J-822	8.2K 1/6W CARBON RES.	
	R644	QRD161J-223	22K 1/6W CARBON RES.	
	R645	QRD161J-223	22K 1/6W CARBON RES.	
	R646	QRD161J-222	2.2K 1/6W CARBON RES.	
	R647	QRD161J-472	4.7K 1/6W CARBON RES.	
	R650	QRD161J-182	1.8K 1/6W CARBON RES.	
	R651	QRD161J-102	1K 1/6W CARBON RES.	
	R652	QRD161J-102	1K 1/6W CARBON RES.	
	R653	QRD161J-102	1K 1/6W CARBON RES.	
	R660	QRD161J-102	1K 1/6W CARBON RES.	
	R661	QRD161J-683	68K 1/6W CARBON RES.	
	R662	QRD161J-275	2.7M 1/6W CARBON RES.	
	R663	QRD161J-124	120K 1/6W CARBON RES.	
	R664	QRD161J-471	470 1/6W CARBON RES.	
	R666	QRD161J-220	22 1/6W CARBON RES.	
	R667	QRD161J-220	22 1/6W CARBON RES.	
	R671	QRD161J-102	1K 1/6W CARBON RES.	
	R672	QRD161J-102	1K 1/6W CARBON RES.	
	R692	QRD161J-271	270 1/6W CARBON RES.	
		OTHERS		
		EMW10688-003A	CIR. BOARD	
	X651	ECX0169-344EF	CRYSTAL	
	CN601	EMV7171-115R	CONNECT TERMINAL	
	CN602	EMV5109-006A	CONNECT TERMINAL	
	CN603	VMC0163-R07	CONNECT TERMINAL	
	CN604	VMC0163-R11	CONNECT TERMINAL	
	CN605	EWS263-A912	SOCKET WIRE	
	SP601	VYH7237-001	I. C. COVER	
	SP602	VYH7237-003	I. C. COVER	
	SP603	VYH7237-003	I. C. COVER	
	TP601	QMV5004-002K	PLUG ASSY	
	TW601	EFW102-047	TERMINAL WIRE	

Electrical Parts List (ENA-178CM)

Δ	Item	Parts Number	Description	Area
		I. C. S		
	IC102	LA1837	I. C (MONO-ANALOG)	
	IC121	LC72131	I. C (M)	
		DIODES		
	D121	1SS133	SI. DIODE	
	D123	1SS133	SI. DIODE	
	D129	1SS133	SI. DIODE	
	D130	MTZ10JG	ZENER DIODE	
		TRANSISTORS		
	Q101	2SC461	SI. TRANSISTOR	
	Q102	2SC535	SI. TRANSISTOR	
	Q103	2SC461	SI. TRANSISTOR	
	Q111	2SD2144S (VW)	SI. TRANSISTOR	
	Q112	2SD2144S (VW)	SI. TRANSISTOR	
	Q113	2SD2144S (VW)	SI. TRANSISTOR	
	Q114	2SD2144S (VW)	SI. TRANSISTOR	
	Q121	DTA124ES	DIGITAL TRANSISTOR	
	Q123	2SC2060 (Q. R)	SI. TRANSISTOR	
		CAPACITORS		
	C101	QCVB1CM-103Y	0.01MF 16V CER. CAP.	
	C102	QETN1EM-107Z	100MF 25V E. CAP.	
	C103	QCHB1EZ-223	0.022MF 25V CER. CAP.	
	C104	QCHB1EZ-223	0.022MF 25V CER. CAP.	
	C105	QCHB1EZ-223	0.022MF 25V CER. CAP.	
	C107	QETN1EM-226Z	22MF 25V E. CAP.	
	C109	QETN1EM-226Z	22MF 25V E. CAP.	
	C111	QCHB1EZ-223	0.022MF 25V CER. CAP.	
	C112	QCT30CH-120Y	12PF 50V CER. CAP.	
	C113	QCHB1EZ-223	0.022MF 25V CER. CAP.	
	C117	QCSB1HK-5R6Y	5.6PF 50V CER. CAP.	
	C118	QCSB1HJ-150Y	15PF 50V CER. CAP.	
	C121	QCT30CH-180Y	18PF 50V CER. CAP.	
	C122	QCT30CH-180Y	18PF 50V CER. CAP.	
	C123	QCC21EM-473	0.047MF 25V CER. CAP.	
	C126	QCCB1HK-101Y	100PF 50V CER. CAP.	
	C128	QENB1HM-474	0.47MF 50V NP E. CAP.	
	C129	QCCB1HK-102	1000PF 50V CER. CAP.	
	C130	QETN1EM-107Z	100MF 25V E. CAP.	
	C133	QETN1EM-226Z	22MF 25V E. CAP.	
	C135	QCHB1EZ-223	0.022MF 25V CER. CAP.	
	C136	QETN1HM-105Z	1MF 50V AL E. CAP.	
	C137	QCCB1HK-391Y	390PF 50V CER. CAP.	
	C139	QFLB1HJ-473	0.047MF 50V MYLAR CAP.	
	C140	QFLB1HJ-473	0.047MF 50V MYLAR CAP.	
	C141	QCC21EM-473	0.047MF 25V CER. CAP.	
	C143	QCHB1EZ-223	0.022MF 25V CER. CAP.	
	C144	QCC21EM-473	0.047MF 25V CER. CAP.	
	C146	QETN1HM-105Z	1MF 50V AL E. CAP.	
	C147	QETN1HM-105Z	1MF 50V AL E. CAP.	
	C148	QETN1HM-474Z	0.47MF 50V AL E. CAP.	
	C149	QETN1HM-105Z	1MF 50V AL E. CAP.	
	C150	QETN1EM-226Z	22MF 25V E. CAP.	
	C156	QCHB1EZ-223	0.022MF 25V CER. CAP.	
	C157	QCC21EM-473	0.047MF 25V CER. CAP.	
	C158	QETN1EM-226Z	22MF 25V E. CAP.	
	C161	QETN1HM-105Z	1MF 50V AL E. CAP.	
	C162	QETN1HM-105Z	1MF 50V AL E. CAP.	
	C163	QCHB1EZ-223	0.022MF 25V CER. CAP.	
	C164	QCC21EM-473	0.047MF 25V CER. CAP.	
	C168	QFV81HJ-274	0.27MF 50V THIN FILM CAP.	
	C180	QETN1EM-107Z	100MF 25V E. CAP.	
	C181	QFLB1HJ-562	5600PF 50V MYLAR CAP.	
	C182	QFLB1HJ-562	5600PF 50V MYLAR CAP.	
	C183	QCHB1EZ-223	0.022MF 25V CER. CAP.	
	C184	QETN1EM-107Z	100MF 25V E. CAP.	
	C185	QETN1HM-105Z	1MF 50V AL E. CAP.	
	C186	QETN1HM-105Z	1MF 50V AL E. CAP.	
		RESISTORS		
	R102	QRD167J-332	3.3K 1/6W CARBON RES.	
	R103	QRD161J-221	220 1/6W CARBON RES.	

Δ	Item	Parts Number	Description	Area
	R104	QRD167J-272	2.7K 1/6W CARBON RES.	
	R105	QRD161J-391	390 1/6W CARBON RES.	
	R106	QRD161J-102	1K 1/6W CARBON RES.	
	R107	QRD161J-561	560 1/6W CARBON RES.	
	R108	QRD167J-332	3.3K 1/6W CARBON RES.	
	R109	QRD161J-221	220 1/6W CARBON RES.	
	R110	QRD161J-472	4.7K 1/6W CARBON RES.	
	R111	QRD161J-472	4.7K 1/6W CARBON RES.	
	R112	QRD161J-472	4.7K 1/6W CARBON RES.	
	R113	QRD161J-103	10K 1/6W CARBON RES.	
	R114	QRD161J-122	1.2K 1/6W CARBON RES.	
	R115	QRD161J-104	100K 1/6W CARBON RES.	
	R116	QRD161J-472	4.7K 1/6W CARBON RES.	
	R119	QRD161J-103	10K 1/6W CARBON RES.	
	R121	QRD161J-473	47K 1/6W CARBON RES.	
	R122	QRD161J-472	4.7K 1/6W CARBON RES.	
	R124	QRD161J-222	2.2K 1/6W CARBON RES.	
	R126	QRD167J-562	5.6K 1/6W CARBON RES.	
	R127	QRD167J-822	8.2K 1/6W CARBON RES.	
	R128	QRD161J-472	4.7K 1/6W CARBON RES.	
	R129	QRD161J-222	2.2K 1/6W CARBON RES.	
Δ	R130	QRZ0077-680	68 1/4W FUSIBLE RES.	
	R131	QRD161J-103	10K 1/6W CARBON RES.	
	R132	QRD161J-102	1K 1/6W CARBON RES.	
	R133	QRD167J-822	8.2K 1/6W CARBON RES.	
	R134	QRD161J-102	1K 1/6W CARBON RES.	
	R140	QRD161J-563	56K 1/6W CARBON RES.	
	R141	QRD161J-472	4.7K 1/6W CARBON RES.	
	R142	QRD161J-470	47 1/6W CARBON RES.	
	R143	QRD167J-562	5.6K 1/6W CARBON RES.	
	R144	QRD167J-332	3.3K 1/6W CARBON RES.	
	R145	QRD161J-103	10K 1/6W CARBON RES.	
	R146	QRD167J-562	5.6K 1/6W CARBON RES.	
	R147	QRD161J-273	27K 1/6W CARBON RES.	
	R148	QRD161J-561	560 1/6W CARBON RES.	
	R150	QRD161J-101	100 1/6W CARBON RES.	
	R157	QRD161J-182	1.8K 1/6W CARBON RES.	
	R158	QRD161J-182	1.8K 1/6W CARBON RES.	
	R161	QRD161J-102	1K 1/6W CARBON RES.	
	R162	QRD161J-102	1K 1/6W CARBON RES.	
	R163	QRD161J-472	4.7K 1/6W CARBON RES.	
	R164	QRD161J-472	4.7K 1/6W CARBON RES.	
	R181	QRD161J-102	1K 1/6W CARBON RES.	
	R182	QRD161J-103	10K 1/6W CARBON RES.	
	R183	QRD161J-103	10K 1/6W CARBON RES.	
	R184	QRD161J-103	10K 1/6W CARBON RES.	
		OTHERS		
		EMW10684-003A	PRINTED BOARD	
	L111	EQL4007-150T	INDUCTOR	
	T111	EQR7121-006	RF COIL	
	T141	QQR0613-001	I. F. TRANSFORMER	
	T142	QAX0303-001	CERAMIC FILTER	
	X121	ECX0007-200KWJ1	CRYSTAL	
	AT101	EMB41YV-302K	ANTENNA TERMINAL	
	BK001	E308963-002	SHIELD BKT	
	CF101	QAX0285-001Z	CERAMIC FILTER	
	CF102	QAX0285-001Z	CERAMIC FILTER	
	CN111	EMV5163-012R	CONNECT TERMINAL	
	FL141	EQF0101-013	LOWPASS FILTER	
	FL142	EQF0101-013	LOWPASS FILTER	
	RF101	GAU0005-001	FRONT END	

CA-D701T

Electrical Parts List (ENA-178DM)

Item	Parts Number	Description	Area
	I. C. S		
IC102	LA1837	I. C (MONO-ANALOG)	
IC121	LC72131	I. C (M)	
	DIODES		
D121	1SS133	SI. DIODE	
D123	1SS133	SI. DIODE	
D129	1SS133	SI. DIODE	
D130	MTZ10JC	ZENER DIODE	
	TRANSISTORS		
Q101	2SC461	SI. TRANSISTOR	
Q102	2SC535	SI. TRANSISTOR	
Q103	2SC461	SI. TRANSISTOR	
Q121	DTA124ES	DIGITAL TRANSISTOR	
Q123	2SC2060 (Q, R)	SI. TRANSISTOR	
	CAPACITORS		
C101	QCVB1CM-103Y	0.01MF 16V CER. CAP.	
C102	QETN1EM-107Z	100MF 25V E. CAP.	
C103	QCHB1EZ-223	0.022MF 25V CER. CAP.	
C104	QCHB1EZ-223	0.022MF 25V CER. CAP.	
C105	QCHB1EZ-223	0.022MF 25V CER. CAP.	
C107	QETN1EM-226Z	22MF 25V E. CAP.	
C109	QETN1EM-226Z	22MF 25V E. CAP.	
C111	QCHB1EZ-223	0.022MF 25V CER. CAP.	
C112	QCT30CH-120Y	12PF 50V CER. CAP.	
C117	QCSB1HK-5R6Y	5.6PF 50V CER. CAP.	
C118	QCSB1HJ-150Y	15PF 50V CER. CAP.	
C121	QCT30CH-180Y	18PF 50V CER. CAP.	
C122	QCT30CH-180Y	18PF 50V CER. CAP.	
C123	QCC21EM-473	0.047MF 25V CER. CAP.	
C126	QCBB1HK-101Y	100PF 50V CER. CAP.	
C128	QENB1HM-474	0.47MF 50V NP E. CAP.	
C129	QCSB1HK-102	1000PF 50V CER. CAP.	
C130	QETN1EM-107Z	100MF 25V E. CAP.	
C133	QETN1EM-226Z	22MF 25V E. CAP.	
C135	QCHB1EZ-223	0.022MF 25V CER. CAP.	
C136	QETN1HM-105Z	1MF 50V AL E. CAP.	
C137	QCBB1HK-561Y	560PF 50V CER. CAP.	
C139	QFLB1HJ-223	0.022MF 50V MYLAR CAP.	
C140	QFLB1HJ-223	0.022MF 50V MYLAR CAP.	
C141	QCC21EM-473	0.047MF 25V CER. CAP.	
C143	QCHB1EZ-223	0.022MF 25V CER. CAP.	
C144	QCC21EM-473	0.047MF 25V CER. CAP.	
C146	QETN1HM-105Z	1MF 50V AL E. CAP.	
C147	QETN1HM-105Z	1MF 50V AL E. CAP.	
C148	QETN1HM-474Z	0.47MF 50V AL E. CAP.	
C149	QETN1HM-105Z	1MF 50V AL E. CAP.	
C150	QETN1EM-226Z	22MF 25V E. CAP.	
C156	QCHB1EZ-223	0.022MF 25V CER. CAP.	
C157	QCC21EM-473	0.047MF 25V CER. CAP.	
C158	QETN1EM-226Z	22MF 25V E. CAP.	
C161	QETN1HM-105Z	1MF 50V AL E. CAP.	
C162	QETN1HM-105Z	1MF 50V AL E. CAP.	
C163	QCHB1EZ-223	0.022MF 25V CER. CAP.	
C164	QCC21EM-473	0.047MF 25V CER. CAP.	
C168	QFV81HJ-274	0.27MF 50V THIN FILM CAP.	
C180	QETN1EM-107Z	100MF 25V E. CAP.	
C181	QFLB1HJ-562	5600PF 50V MYLAR CAP.	
C182	QFLB1HJ-562	5600PF 50V MYLAR CAP.	
C183	QCHB1EZ-223	0.022MF 25V CER. CAP.	
C184	QETN1EM-107Z	100MF 25V E. CAP.	
C185	QETN1HM-105Z	1MF 50V AL E. CAP.	
C186	QETN1HM-105Z	1MF 50V AL E. CAP.	
	RESISTORS		
R102	QRD167J-332	3.3K 1/6W CARBON RES.	
R103	QRD161J-221	220 1/6W CARBON RES.	
R104	QRD167J-272	2.7K 1/6W CARBON RES.	
R105	QRD161J-391	390 1/6W CARBON RES.	
R106	QRD161J-102	1K 1/6W CARBON RES.	
R107	QRD161J-561	560 1/6W CARBON RES.	
R108	QRD167J-332	3.3K 1/6W CARBON RES.	

Item	Parts Number	Description	Area
R109	QRD161J-221	220 1/6W CARBON RES.	
R115	QRD161J-104	100K 1/6W CARBON RES.	
R119	QRD161J-103	10K 1/6W CARBON RES.	
R121	QRD161J-473	47K 1/6W CARBON RES.	
R122	QRD161J-472	4.7K 1/6W CARBON RES.	
R124	QRD161J-222	2.2K 1/6W CARBON RES.	
R126	QRD167J-562	5.6K 1/6W CARBON RES.	
R127	QRD167J-822	8.2K 1/6W CARBON RES.	
R128	QRD161J-472	4.7K 1/6W CARBON RES.	
R129	QRD161J-222	2.2K 1/6W CARBON RES.	
R130	QRZ0077-680	68 1/4W FUSIBLE RES.	
R132	QRD161J-102	1K 1/6W CARBON RES.	
R133	QRD167J-822	8.2K 1/6W CARBON RES.	
R134	QRD161J-102	1K 1/6W CARBON RES.	
R140	QRD161J-183	18K 1/6W CARBON RES.	
R141	QRD161J-472	4.7K 1/6W CARBON RES.	
R142	QRD161J-470	47 1/6W CARBON RES.	
R143	QRD167J-562	5.6K 1/6W CARBON RES.	
R144	QRD167J-332	3.3K 1/6W CARBON RES.	
R145	QRD161J-103	10K 1/6W CARBON RES.	
R146	QRD167J-332	3.3K 1/6W CARBON RES.	
R147	QRD161J-273	27K 1/6W CARBON RES.	
R148	QRD161J-561	560 1/6W CARBON RES.	
R150	QRD161J-101	100 1/6W CARBON RES.	
R157	QRD167J-682	6.8K 1/6W CARBON RES.	
R158	QRD167J-682	6.8K 1/6W CARBON RES.	
R161	QRD161J-102	1K 1/6W CARBON RES.	
R162	QRD161J-102	1K 1/6W CARBON RES.	
R163	QRD161J-472	4.7K 1/6W CARBON RES.	
R164	QRD161J-472	4.7K 1/6W CARBON RES.	
R181	QRD161J-102	1K 1/6W CARBON RES.	
R182	QRD161J-103	10K 1/6W CARBON RES.	
R183	QRD161J-103	10K 1/6W CARBON RES.	
R184	QRD161J-103	10K 1/6W CARBON RES.	
	OTHERS		
	EMW10684-003A	PRINTED BOARD	
L111	EQL4007-150T	INDUCTOR	
T111	EQR7121-007	RF COIL	
T141	QQR0613-001	I. F. TRANSFORMER	
T142	QAX0303-001	CERAMIC FILTER	
X121	ECX0007-200KWJ1	CRYSTAL	
AT101	FMMB10YY-401K	ANTENNA TERMINAL	
CF101	QAX0285-001Z	CERAMIC FILTER	
CF102	QAX0285-001Z	CERAMIC FILTER	
CN111	EMV5163-012R	CONNECT TERMINAL	
FL141	EQF0101-013	LOWPASS FILTER	
FL142	EQF0101-013	LOWPASS FILTER	
RF101	EAF2207-001	FRONT END	

Electrical Parts List (ENA-178EM)

△	Item	Parts Number	Description	Area
		I. C. S		
	IC102	LA1837	I. C. (MONO-ANALOG)	
	IC104	IR3R42	I. C.	
	IC121	LC72131	I. C. (M)	
		DIODES		
	D121	1SS133	SI. DIODE	
	D122	1SS133	SI. DIODE	
	D123	1SS133	SI. DIODE	
	D124	1SS133	SI. DIODE	
	D129	1SS133	SI. DIODE	
	D130	MTZ10JC	ZENER DIODE	
	D132	1SS133	SI. DIODE	
	D133	MTZ6.8JC	ZENER DIODE	
		TRANSISTORS		
	Q101	2SC461	SI. TRANSISTOR	
	Q102	2SC535	SI. TRANSISTOR	
	Q103	2SC461	SI. TRANSISTOR	
	Q111	2SD2144S (VW)	SI. TRANSISTOR	
	Q112	2SD2144S (VW)	SI. TRANSISTOR	
	Q113	2SD2144S (VW)	SI. TRANSISTOR	
	Q114	2SD2144S (VW)	SI. TRANSISTOR	
	Q121	DTA124ES	DIGITAL TRANSISTOR	
	Q123	2SC2060 (Q. R)	SI. TRANSISTOR	
	Q131	DTA124ES	DIGITAL TRANSISTOR	
	Q132	2SK301 (P. Q)	F. E. T.	
	Q133	2SC2060 (Q. R)	SI. TRANSISTOR	
	Q134	DTC114YS	DIGITAL TRANSISTOR	
		CAPACITORS		
	C101	QCVB10M-103Y	0.01MF 16V CER. CAP.	
	C102	QETN1EM-107Z	100MF 25V E. CAP.	
	C103	QCHB1EZ-223	0.022MF 25V CER. CAP.	
	C104	QCHB1EZ-223	0.022MF 25V CER. CAP.	
	C105	QCHB1EZ-223	0.022MF 25V CER. CAP.	
	C107	QETN1EM-226Z	22MF 25V E. CAP.	
	C109	QETN1EM-226Z	22MF 25V E. CAP.	
	C111	QCHB1EZ-223	0.022MF 25V CER. CAP.	
	C112	QCT30CH-120Y	12PF 50V CER. CAP.	
	C113	QCHB1EZ-223	0.022MF 25V CER. CAP.	
	C117	QCSB1HK-5R6Y	5.6PF 50V CER. CAP.	
	C118	QCSB1HJ-150Y	15PF 50V CER. CAP.	
	C121	QCT30CH-180Y	18PF 50V CER. CAP.	
	C122	QCT30CH-180Y	18PF 50V CER. CAP.	
	C123	QCC21EM-473	0.047MF 25V CER. CAP.	
	C126	QCSB1HK-101Y	100PF 50V CER. CAP.	
	C128	QENB1HM-474	0.47MF 50V NP E. CAP.	
	C129	QCSB1HK-102	1000PF 50V CER. CAP.	
	C130	QETN1EM-107Z	100MF 25V E. CAP.	
	C131	QETN1HM-105Z	1MF 50V AL E. CAP.	
	C132	QETN1HM-105Z	1MF 50V AL E. CAP.	
	C133	QETN1EM-226Z	22MF 25V E. CAP.	
	C135	QCHB1EZ-223	0.022MF 25V CER. CAP.	
	C136	QETN1HM-105Z	1MF 50V AL E. CAP.	
	C138	QCSB1HK-681Y	680PF 50V CER. CAP.	
	C139	QFLB1HJ-333	0.033MF 50V MYLAR CAP.	
	C140	QFLB1HJ-333	0.033MF 50V MYLAR CAP.	
	C141	QCC21EM-473	0.047MF 25V CER. CAP.	
	C143	QCHB1EZ-223	0.022MF 25V CER. CAP.	
	C144	QCC21EM-473	0.047MF 25V CER. CAP.	
	C146	QETN1HM-105Z	1MF 50V AL E. CAP.	
	C147	QETN1HM-105Z	1MF 50V AL E. CAP.	
	C148	QETN1HM-474Z	0.47MF 50V AL E. CAP.	
	C149	QETN1HM-105Z	1MF 50V AL E. CAP.	
	C150	QETN1EM-226Z	22MF 25V E. CAP.	
	C154	QETN1HM-105Z	1MF 50V AL E. CAP.	
	C155	QENB1HM-105Z	1MF 50V NP E. CAP.	
	C156	QCHB1EZ-223	0.022MF 25V CER. CAP.	
	C157	QCC21EM-473	0.047MF 25V CER. CAP.	
	C158	QETN1EM-226Z	22MF 25V E. CAP.	
	C159	QFLB1HJ-183	0.018MF 50V MYLAR CAP.	
	C160	QFLB1HJ-183	0.018MF 50V MYLAR CAP.	

△	Item	Parts Number	Description	Area
	C161	QETN1HM-105Z	1MF 50V AL E. CAP.	
	C162	QETN1HM-105Z	1MF 50V AL E. CAP.	
	C163	QCHB1EZ-223	0.022MF 25V CER. CAP.	
	C164	QCC21EM-473	0.047MF 25V CER. CAP.	
	C165	QCHB1EZ-223	0.022MF 25V CER. CAP.	
	C166	QETN1EM-107Z	100MF 25V E. CAP.	
	C167	QCHB1EZ-223	0.022MF 25V CER. CAP.	
	C168	QFV81HJ-274	0.27MF 50V THIN FILM CAP.	
	C170	QETN1HM-105Z	1MF 50V AL E. CAP.	
	C171	QFP81HJ-103	0.01MF 50V POLYPROPY. FILM	
	C172	QFP81HJ-103	0.01MF 50V POLYPROPY. FILM	
	C173	QCSB1HK-102Y	1000PF 50V CER. CAP.	
	C174	QCSB1HK-102Y	1000PF 50V CER. CAP.	
	C177	QCSB1HK-331Y	330PF 50V CER. CAP.	
	C178	QENB1HM-105Z	1MF 50V NP E. CAP.	
	C179	QCC21EM-473	0.047MF 25V CER. CAP.	
	C180	QETN1EM-107Z	100MF 25V E. CAP.	
	C181	QFLB1HJ-562	5600PF 50V MYLAR CAP.	
	C182	QFLB1HJ-562	5600PF 50V MYLAR CAP.	
	C183	QCHB1EZ-223	0.022MF 25V CER. CAP.	
	C184	QETN1EM-107Z	100MF 25V E. CAP.	
	C185	QETN1HM-105Z	1MF 50V AL E. CAP.	
	C186	QETN1HM-105Z	1MF 50V AL E. CAP.	
	C187	QCSB1HK-102	1000PF 50V CER. CAP.	
	C188	QENB1HM-474	0.47MF 50V NP E. CAP.	
	C189	QENB1HM-474	0.47MF 50V NP E. CAP.	
	C190	QFP81HJ-471	470PF 50V POLYPROPY. FILM	
	TC101	ENZ1003-015	0.1MF TRIMMER CAPA	
		RESISTORS		
	R102	QRD167J-332	3.3K 1/6W CARBON RES.	
	R103	QRD161J-221	220 1/6W CARBON RES.	
	R104	QRD167J-272	2.7K 1/6W CARBON RES.	
	R105	QRD161J-391	390 1/6W CARBON RES.	
	R106	QRD161J-102	1K 1/6W CARBON RES.	
	R107	QRD161J-561	560 1/6W CARBON RES.	
	R108	QRD167J-332	3.3K 1/6W CARBON RES.	
	R109	QRD161J-221	220 1/6W CARBON RES.	
	R110	QRD161J-472	4.7K 1/6W CARBON RES.	
	R111	QRD161J-472	4.7K 1/6W CARBON RES.	
	R112	QRD161J-472	4.7K 1/6W CARBON RES.	
	R113	QRD161J-103	10K 1/6W CARBON RES.	
	R114	QRD161J-122	1.2K 1/6W CARBON RES.	
	R115	QRD161J-104	100K 1/6W CARBON RES.	
	R116	QRD161J-472	4.7K 1/6W CARBON RES.	
	R119	QRD161J-103	10K 1/6W CARBON RES.	
	R122	QRD161J-472	4.7K 1/6W CARBON RES.	
	R124	QRD161J-222	2.2K 1/6W CARBON RES.	
	R126	QRD167J-562	5.6K 1/6W CARBON RES.	
	R127	QRD167J-822	8.2K 1/6W CARBON RES.	
	R128	QRD161J-472	4.7K 1/6W CARBON RES.	
	R129	QRD161J-222	2.2K 1/6W CARBON RES.	
	△ R130	QRZ0077-680	68 1/4W FUSIBLE RES.	
	R131	QRD161J-103	10K 1/6W CARBON RES.	
	R132	QRD161J-102	1K 1/6W CARBON RES.	
	R133	QRD167J-822	8.2K 1/6W CARBON RES.	
	R134	QRD161J-102	1K 1/6W CARBON RES.	
	R137	QRD161J-103	10K 1/6W CARBON RES.	
	R138	QRD161J-104	100K 1/6W CARBON RES.	
	R139	QRD161J-104	100K 1/6W CARBON RES.	
	R140	QRD161J-183	18K 1/6W CARBON RES.	
	R141	QRD161J-472	4.7K 1/6W CARBON RES.	
	R142	QRD161J-470	47 1/6W CARBON RES.	
	R143	QRD167J-562	5.6K 1/6W CARBON RES.	
	R144	QRD167J-332	3.3K 1/6W CARBON RES.	
	R145	QRD161J-103	10K 1/6W CARBON RES.	
	R146	QRD167J-562	5.6K 1/6W CARBON RES.	
	R147	QRD167J-153	15K 1/6W CARBON RES.	
	R148	QRD161J-561	560 1/6W CARBON RES.	
	R150	QRD161J-101	100 1/6W CARBON RES.	
	R151	QRD167J-153	15K 1/6W CARBON RES.	

CA-D701T

Electrical Parts List (ENA-178EM)

△	Item	Parts Number	Description	Area
	R152	QRD167J-153	15K 1/6W CARBON RES.	
	R153	QRD161J-103	10K 1/6W CARBON RES.	
	R155	QRD167J-223	22K 1/6W CARBON RES.	
	R156	QRD161J-473	47K 1/6W CARBON RES.	
	R157	QRD167J-332	3.3K 1/6W CARBON RES.	
	R158	QRD167J-332	3.3K 1/6W CARBON RES.	
	R159	QRD161J-392	3.9K 1/6W CARBON RES.	
	R160	QRD161J-392	3.9K 1/6W CARBON RES.	
	R161	QRD161J-102	1K 1/6W CARBON RES.	
	R162	QRD161J-102	1K 1/6W CARBON RES.	
	R163	QRD161J-472	4.7K 1/6W CARBON RES.	
	R164	QRD161J-472	4.7K 1/6W CARBON RES.	
	R167	QRD161J-102	1K 1/6W CARBON RES.	
	R168	QRD161J-470	47 1/6W CARBON RES.	
	R170	QRD161J-333	33K 1/6W CARBON RES.	
	R171	QRD167J-153	15K 1/6W CARBON RES.	
	R172	QRD161J-823	82K 1/6W CARBON RES.	
	R173	QRD161J-104	100K 1/6W CARBON RES.	
	R176	QRD161J-102	1K 1/6W CARBON RES.	
	R177	QRD161J-102	1K 1/6W CARBON RES.	
	R178	QRD161J-123	12K 1/6W CARBON RES.	
	R179	QRD167J-682	6.8K 1/6W CARBON RES.	
	R181	QRD161J-102	1K 1/6W CARBON RES.	
	R182	QRD161J-103	10K 1/6W CARBON RES.	
	R183	QRD161J-103	10K 1/6W CARBON RES.	
	R184	QRD161J-103	10K 1/6W CARBON RES.	
	VR101	QVPA601-103A	10K TRIMMER RES.	
	VR102	QVPA601-502A	5K TRIMMER RES.	
		OTHERS		
		EMW10684-003A	PRINTED BOARD	
	L111	EQL4007-150T	INDUCTOR	
	T111	EQR7121-006	RF COIL	
	T141	QQR0613-001	I. F. TRANSFORMER	
	T142	QAX0303-001	CERAMIC FILTER	
	T151	QQR0522-001	COIL	
	X121	ECX0007-200KG	CRYSTAL	
	AT101	EMB41YV-302K	ANTENNA TERMINAL	
	BK001	E308963-002	SHIELD BKT	
	CF101	QAX0285-001Z	CERAMIC FILTER	
	CF102	QAX0285-001Z	CERAMIC FILTER	
	CN111	EMV5163-012R	CONNECT TERMINAL	
	FL141	EQF0101-013	LOWPASS FILTER	
	FL142	EQF0101-013	LOWPASS FILTER	
	RF101	EAF2302-002	FRONT END	

■ Electrical Parts List (Changer Control P.C. Board)

△	Item	Parts Number	Description	Area
		I. C. S		
	IC801	UPD65612GB-208	I. C (M)	
	IC802	TA8409S	I. C (MONO-ANALOG)	
	IC803	TA8409S	I. C (MONO-ANALOG)	
		CAPACITORS		
	C801	QEK51AM-107	AL. E. CAP.	
	C802	QEK51EM-475	AL. E. CAP.	
	C803	QFLB1HJ-102	1000PF 50V MYLAR CAP.	
	C804	QCFB1HZ-104Y	0.1MF 50V CER. CAP.	
	C805	QCVB1CM-103Y	0.01MF 16V CER. CAP.	
	C806	QEK51CM-476	AL. E. CAP.	
	C808	QFLB1HJ-102	1000PF 50V MYLAR CAP.	
	C810	QCZ0205-155	1.5MF 25V C. CAP.	
	C811	QCZ0205-155	1.5MF 25V C. CAP.	
	C813	QCVB1CM-103Y	0.01MF 16V CER. CAP.	
	C821	QCB1HK-102Y	1000PF 50V CER. CAP.	
		RESISTORS		
	R805	QRD161J-102	1K 1/6W CARBON RES.	
	R806	QRD161J-471	470 1/6W CARBON RES.	
	R807	QRD161J-471	470 1/6W CARBON RES.	
	R808	QRD161J-102	1K 1/6W CARBON RES.	
	R810	QRD161J-684	680K 1/6W CARBON RES.	
	R811	QRD161J-105	1M 1/6W CARBON RES.	
	R813	QRD161J-102	1K 1/6W CARBON RES.	
	R814	QRD161J-102	1K 1/6W CARBON RES.	
	R815	QRD161J-102	1K 1/6W CARBON RES.	
	R816	QRD161J-102	1K 1/6W CARBON RES.	
	R817	QRD161J-102	1K 1/6W CARBON RES.	
	R818	QRD161J-102	1K 1/6W CARBON RES.	
	R819	QRD161J-102	1K 1/6W CARBON RES.	
	R820	QRD161J-102	1K 1/6W CARBON RES.	
	R821	QRD161J-102	1K 1/6W CARBON RES.	
	R822	QRD161J-102	1K 1/6W CARBON RES.	
	R823	QRD161J-102	1K 1/6W CARBON RES.	
	R824	QRD161J-102	1K 1/6W CARBON RES.	
	R825	QRD161J-102	1K 1/6W CARBON RES.	
	R826	QRD161J-102	1K 1/6W CARBON RES.	
	R827	QRD161J-102	1K 1/6W CARBON RES.	
	R828	QRD161J-102	1K 1/6W CARBON RES.	
	R829	QRD161J-102	1K 1/6W CARBON RES.	
	R830	QRD161J-102	1K 1/6W CARBON RES.	
	R832	QRD161J-181	180 1/6W CARBON RES.	
	R833	QRD161J-102	1K 1/6W CARBON RES.	
	R834	QRD161J-102	1K 1/6W CARBON RES.	
	R839	QRD167J-332	3.3K 1/6W CARBON RES.	
	R840	QRD167J-562	5.6K 1/6W CARBON RES.	
		OTHERS		
		VMW1377-004X	PW BOARD	
		SBSF2608Z	TAPPING SCREW	
		VYH7237-001SS	IC HOLDER	
	L801	VQP0018-100	INDUCTOR	
	L802	VQP0033-100Z	INDUCTOR	
	L803	VQP0033-100Z	INDUCTOR	
	L804	VQP0033-100Z	INDUCTOR	
	CN801	VMC0163-R10	CONNECT TERMINAL	
	CN802	VMC0289-P07	CONNECT TERMINAL	
	CN803	VMC0324-12310	CONNECT TERMINAL	
	CN804	VMC0289-S07K	CONNECTOR	


Accessories List

Block No. **M5MM**

△	Item	Parts Number	Parts Name	Q'ty	Description	Area
	1	E30580-2549A	INSTRUCTION BOOK	1		U UB US UT
		E30580-2550A	INSTRUCTION BOOK	1		EF G
		E30580-2551A	INSTRUCTION BOOK	1		A BS
		E30580-2552A	INSTRUCTION BOOK	1		EN
		E30580-2553A	INSTRUCTION BOOK	1		VX
		E30580-2609A	INSTRUCTION BOOK	1		UP
	2	E309758-003	ENVELOPE	1		Except UP
		E409559-001	ENVELOPE	1		UP
	3	EQB4001-015	LOOP ANTENNA	1		
	4	BT-56002-1	SERVICE NETWORK	1		A
	6	BT-20134	WARRANTY CARD	1		G
		BT-54003-1	WARRANTY CARD	1		BS
		BT-56001-1	WARRANTY CARD	1		A
		BT-56004-4	WARRANTY CARD	1		UP
	7	BT-20066A	DISTRIBUTOR LIST	1		BS
	8	EWP201-011	ANTENNA WIRE	1		A U UB UP US UT
	9	EWP503-001	ANTENNA WIRE	1		BS EF EN G VX
	10	E43486-340A	SAFETY SHEET	1		BS
	11	ENZ2203-001	ADAPTOR PLUG	1		U UT
△	12	ENZ2202-001	SIEMENS PLUG	1		US
	13	RM-SED70TEU	REMOCON	1		A BS EF EN G VX
		RM-SED70TXU	REMOCON	1		U UB UP US UT
	14	R6SPTT-2ST	BATTERY	1		

Packing Materials and Part Numbers

Block No. **M6MM**



JVC

VICTOR COMPANY OF JAPAN, LIMITED

AUDIO DIVISION, YAMATO PLANT, 1644, SHIMOTURUMA, YAMATO-SHI, KANAGAWA-KEN, 242, Japan