

# JVC


## SERVICE MANUAL

### COMPACT COMPONENT SYSTEM

# MX-GA77

**Area suffix**

B ----- U.K.  
 E ---- Continental Europe  
 EN ---- Northern Europe  
 EV ----- Eastern Europe



SP-MXGA77

CA-MXGA77

SP-MXGA77

COMPACT  
**dISC**  
 DIGITAL AUDIO



### Contents

Safety Precautions .....	1-2	Flow of functional operation	
Important for laser products .....	1-4	until TOC read .....	1-24
Preventing static electricity .....	1-5	Maintenance of laser pickup .....	1-25
Disassembly method .....	1-6	Replacement of laser pickup .....	1-25
Wiring connection .....	1-19	Trouble shooting .....	1-26
Adjustment method .....	1-20	Description of major ICs .....	1-30~44

## Safety Precautions

1. This design of this product contains special hardware and many circuits and components specially for safety purposes. For continued protection, no changes should be made to the original design unless authorized in writing by the manufacturer. Replacement parts must be identical to those used in the original circuits. Services should be performed by qualified personnel only.
2. Alterations of the design or circuitry of the product should not be made. Any design alterations of the product should not be made. Any design alterations or additions will void the manufacturer's warranty and will further relieve the manufacture of responsibility for personal injury or property damage resulting therefrom.
3. Many electrical and mechanical parts in the products have special safety-related characteristics. These characteristics are often not evident from visual inspection nor can the protection afforded by them necessarily be obtained by using replacement components rated for higher voltage, wattage, etc. Replacement parts which have these special safety characteristics are identified in the Parts List of Service Manual. Electrical components having such features are identified by shading on the schematics and by ( $\triangle$ ) on the Parts List in the Service Manual. The use of a substitute replacement which does not have the same safety characteristics as the recommended replacement parts shown in the Parts List of Service Manual may create shock, fire, or other hazards.
4. The leads in the products are routed and dressed with ties, clamps, tubings, barriers and the like to be separated from live parts, high temperature parts, moving parts and/or sharp edges for the prevention of electric shock and fire hazard. When service is required, the original lead routing and dress should be observed, and it should be confirmed that they have been returned to normal, after re-assembling.

### 5. Leakage current check (Electrical shock hazard testing)

After re-assembling the product, always perform an isolation check on the exposed metal parts of the product (antenna terminals, knobs, metal cabinet, screw heads, headphone jack, control shafts, etc.) to be sure the product is safe to operate without danger of electrical shock.


Do not use a line isolation transformer during this check.

- Plug the AC line cord directly into the AC outlet. Using a "Leakage Current Tester", measure the leakage current from each exposed metal parts of the cabinet, particularly any exposed metal part having a return path to the chassis, to a known good earth ground. Any leakage current must not exceed 0.5mA AC (r.m.s.).

- Alternate check method

Plug the AC line cord directly into the AC outlet. Use an AC voltmeter having, 1,000 ohms per volt or more sensitivity in the following manner. Connect a 1,500  $\Omega$  10W resistor paralleled by a 0.15  $\mu$ F AC-type capacitor between an exposed metal part and a known good earth ground. Measure the AC voltage across the resistor with the AC voltmeter.

Move the resistor connection to each exposed metal part, particularly any exposed metal part having a return path to the chassis, and measure the AC voltage across the resistor. Now, reverse the plug in the AC outlet and repeat each measurement. Voltage measured any must not exceed 0.75 V AC (r.m.s.). This corresponds to 0.5 mA AC (r.m.s.).



## Warning

1. This equipment has been designed and manufactured to meet international safety standards.
2. It is the legal responsibility of the repairer to ensure that these safety standards are maintained.
3. Repairs must be made in accordance with the relevant safety standards.
4. It is essential that safety critical components are replaced by approved parts.
5. If mains voltage selector is provided, check setting for local voltage.


## CAUTION

**Burrs formed during molding may be left over on some parts of the chassis. Therefore, pay attention to such burrs in the case of performing repair of this system.**

In regard with component parts appearing on the silk-screen printed side (parts side) of the PWB diagrams, the parts that are printed over with black such as the resistor ( $\blacksquare$ ), diode ( $\blacksquare$ ) and ICP ( $\bullet$ ) or identified by the " $\triangle$ " mark nearby are critical for safety.


(This regulation does not correspond to J and C version.)

## **Safety precautions** (U.K only)

1. This design of this product contains special hardware and many circuits and components specially for safety purposes. For continued protection, no changes should be made to the original design unless authorized in writing by the manufacturer. Replacement parts must be identical to those used in the original circuits.
2. Any unauthorised design alterations or additions will void the manufacturer's guarantee ; furthermore the manufacturer cannot accept responsibility for personal injury or property damage resulting therefrom.
3. Essential safety critical components are identified by (  ) on the Parts List and by shading on the schematics, and must never be replaced by parts other than those listed in the manual. Please note however that many electrical and mechanical parts in the product have special safety related characteristics. These characteristics are often not evident from visual inspection. Parts other than specified by the manufacturer may not have the same safety characteristics as the recommended replacement parts shown in the Parts List of the Service Manual and may create shock, fire, or other hazards.
4. The leads in the products are routed and dressed with ties, clamps, tubings, barriers and the like to be separated from live parts, high temperature parts, moving parts and/or sharp edges for the prevention of electric shock and fire hazard. When service is required, the original lead routing and dress should be observed, and it should be confirmed that they have been returned to normal, after re-assembling.

## **Warning**

1. Service should be performed by qualified personnel only.
2. This equipment has been designed and manufactured to meet international safety standards.
3. It is the legal responsibility of the repairer to ensure that these safety standards are maintained.
4. Repairs must be made in accordance with the relevant safety standards.
5. It is essential that safety critical components are replaced by approved parts.
6. If mains voltage selector is provided, check setting for local voltage.

 **CAUTION** Burrs formed during molding may be left over on some parts of the chassis. Therefore, pay attention to such burrs in the case of preforming repair of this system.



# Important for laser products

**1.CLASS 1 LASER PRODUCT**

**2.DANGER :** Invisible laser radiation when open and inter lock failed or defeated. Avoid direct exposure to beam.

**3.CAUTION :** There are no serviceable parts inside the Laser Unit. Do not disassemble the Laser Unit. Replace the complete Laser Unit if it malfunctions.

**4.CAUTION :** The compact disc player uses invisible laserradiation and is equipped with safety switches which prevent emission of radiation when the drawer is open and the safety interlocks have failed or are defeated. It is dangerous to defeat the safety switches.

**5.CAUTION :** If safety switches malfunction, the laser is able to function.


**6.CAUTION :** Use of controls, adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

**! CAUTION** Please use enough caution not to see the beam directly or touch it in case of an adjustment or operation check.

## REPRODUCTION AND POSITION OF LABELS

### CLASS 1 LASER PRODUCT

CLASS 1 LASER PRODUCT  
 KLASSE 1 LASER PRODUKT  
 LUOKAN 1 LASER LAITE  
 KLASSE 1 LASER APPARAT  
 PRODUCTO LASER CLASSE 1



### WARNING LABEL

CAUTION: INVISIBLE LASER RADIATION WHEN OPEN AND INTERLOCKS DEFEATED AVOID EXPOSURE TO BEAM  
 ADVARSEL: USYNLIG LASERSTRÅLING VED ÅBNING NÅR SIKKERHEDSBERYTERE ER UDE AF FUNKTION UNDGÅ UDSÆTTELSE FOR STRÅLING  
 VARNING: OSYNLIG LASERSTRÅLING NÄR DENNA DEL ÄR ÖPPNAD OCH SPÄRREN ÄR URKOPPLAD BETRÄKTA EJ STRÅLEN!





# Preventing static electricity

## 1. Grounding to prevent damage by static electricity

Electrostatic discharge (ESD), which occurs when static electricity stored in the body, fabric, etc. is discharged, can destroy the laser diode in the traverse unit (optical pickup). Take care to prevent this when performing repairs.

## 2. About the earth processing for the destruction prevention by static electricity

In the equipment which uses optical pick-up (laser diode), optical pick-up is destroyed by the static electricity of the work environment.


Be careful to use proper grounding in the area where repairs are being performed.

### 2-1 Ground the workbench

Ground the workbench by laying conductive material (such as a conductive sheet) or an iron plate over it before placing the traverse unit (optical pickup) on it.

### 2-2 Ground yourself

Use an anti-static wrist strap to release any static electricity built up in your body.



## 3. Handling the optical pickup

1. In order to maintain quality during transport and before installation, both sides of the laser diode on the replacement optical pickup are shorted. After replacement, return the shorted parts to their original condition. (Refer to the text.)

2. Do not use a tester to check the condition of the laser diode in the optical pickup. The tester's internal power source can easily destroy the laser diode.

## 4. Handling the traverse unit (optical pickup)

1. Do not subject the traverse unit (optical pickup) to strong shocks, as it is a sensitive, complex unit.

2. Cut off the shorted part of the flexible cable using nippers, etc. after replacing the optical pickup. For specific details, refer to the replacement procedure in the text. Remove the anti-static pin when replacing the traverse unit. Be careful not to take too long a time when attaching it to the connector.

3. Handle the flexible cable carefully as it may break when subjected to strong force.

4. It is not possible to adjust the semi-fixed resistor that adjusts the laser power. Do not turn it

## Attention when CD mechanism assembly is decomposed

**\*Please refer to "Disassembly method" in the text for pick-up and how to detach the CD mechanism assembly.**


1. Remove the CD changer unit.

2. Remove the CD changer mechanism.

3. Solder is put up before the card wire is removed from the pickup unit connector on the CD mechanism assembly.

(When the card wire is removed without putting up solder, the CD pick-up assembly might destroy.)

4. Please remove solder after connecting the card wire with the pickup unit connector when you install picking up in the substrate.



## Disassembly method

### ■ Removing the metal cover (See Fig.1)

1. Remove the three screws **A** attaching the metal cover on the back of the body.
2. Remove the six screws **B** attaching the metal cover on both sides of the body.
3. Remove the metal cover from the body by lifting the rear part of the cover.




Fig.1

#### ONE POINT

#### ■ How to eject the CD tray manually (see fig.2)

Turn the loading pulley gear at the bottom of the CD changer unit as shown in Fig.2 and draw the CD tray toward the front.




Fig.2

### ■ Removing the CD tray fitting (See Fig. 3)

- Prior to performing the following procedure, eject the CD tray.
1. After drawing the lower part of the tray fitting toward the front, remove the five claws. Then, while moving the tray fitting upward, remove it.




Fig.3

### ■ Removing the CD changer unit (See Fig.4 to 7)

- Prior to performing the following procedure, remove the metal cover and CD tray fitting.
1. Remove the card wire attached to CD changer unit on the adhesion tape.
  2. Disconnect the card wire from the connector CW105 on the CD board.
  3. Disconnect the harness from the connector CW104 on the main board.
  4. Remove the two screws **C** attaching the CD changer unit to the rear panel.
  5. Remove the two screws **D** attaching the CD changer unit to both sides of the front panel assembly.
  6. Draw the CD changer unit upward from behind while pulling the rear panel outward.




Fig.4






Fig.5




Fig.6




Fig.7

**■ Removing the front panel assembly (See Fig.8 to 10)**

• Prior to performing the following procedure, remove the metal cover and CD changer unit.

1. Disconnect the card wire from the connector CW101 on the main board.
2. Disconnect the harness from the connector CW108, CW109 and CW110 on the main board.
3. Remove the screw E fixing the lug wire.
4. Remove the two screws F attaching the front panel assembly to both sides of the body.
5. Remove the screw G attaching the main board to the front panel assembly.
6. Remove the screw H attaching the front panel assembly to bottom of the body.
7. Release the two joints1 and two joints2, and detach the front panel assembly toward the front.




Fig.8




Fig.9 (both sides)



**■Removing the heat sink & amp. board**  
(See Fig.8, 11 and 12)

- Prior to performing the following procedure, remove the metal cover and CD changer unit.
1. Disconnect the card wire from the connector ACW1 and the harness from the connector ACW2 on the amp. board.
  2. Remove the four screws **I** attaching the heat sink cover to the rear panel. Remove the heat sink cover.
  3. Remove the four screws **J** attaching the heat sink and two screws **K** attaching the speaker terminal to the rear panel.
  4. After moving the heat sink upward, remove the claws. Then pull out the heat sink & amp. board inward.




Fig.10




Fig.11

**■Removing the tuner board**  
(See Fig.12 and 13)

- Prior to performing the following procedure, remove the metal cover.
1. Disconnect the card wire from the connector CON01 on the tuner board.
  2. Remove the two screws **L** attaching the tuner board to the rear panel.




Fig.12

**■Removing the rear panel** (See Fig.12)

- Prior to performing the following procedure, remove the metal cover, CD changer unit, heat sink & amp. board and tuner board.
1. Remove the three screws **M** and three screws **N** attaching the rear panel.




Fig.13

**■Removing the main board (See Fig. 14)**

• Prior to performing the following procedure, remove the metal cover, CD changer unit and rear panel.

1. Disconnect the card wire from the connector CW101, and the harness from the connector CW108, CW109, CW110 and CW11, and the power cord from the connector PW103 on the main board.
2. Disconnect the harness from the connector PCW1 on the fuse board.
3. Remove the screw **G** attaching the main board to the front panel assembly. (See Fig.9)
4. Remove the two screws **O** attaching the heat sink to the bottom chassis.




Fig.14

**■Removing the power cord (See Fig. 14)**

• Prior to performing the following procedure, remove the metal cover, CD changer unit and rear panel.

1. Disconnect the power cord from the connector PW103 on the main board and pull up the power cord stopper upward.




Fig.15

**■Removing the power ICs (See Fig.15 and 16)**

• Prior to performing the following procedure, remove the metal cover, CD changer unit and heat sink & amp. board.

1. Unsolder the power ICs solder points.
2. Remove the four screws **P** attaching the power ICs to the heat sink.




Fig.16

**■Removing the power transformer (See Fig .17)**

• Prior to performing the following procedure, remove the metal cover, CD changer unit and heat sink & amp. board.

1. Disconnect the harness from the connector PW102 on the power supply board.
2. Disconnect the harness from the connector PCW1 on the fuse board.
3. Remove the four screws **Q** attaching the power transformer on the bottom chassis.




Fig.17



**<Front panel assembly>**

- Prior to performing the following procedure, remove the front panel assembly.

**■ Removing the CD switch board (See Fig.1)**

1. Disconnect the card wire from the connector UCW03 on the CD switch board.
2. Remove the five screws **A** attaching the CD switch board.

**■ Removing the front board (See Fig.1 and 2)**

1. Pull out the sound mode knob, volume knob, and preset knob from the front side of front panel assembly.
2. Disconnect the card wire from the connector UCW02 on the front board and the connector on the mecha. board.
3. Remove the fifteen screws **B** attaching the front board.
4. Disconnect the card wire from the connector UCW01 on the front board.




Fig.1

**■ Removing the headphone jack board (See Fig.3)**

- Prior to performing the following procedure remove the front board.

1. You can pull out the headphone jack board.




Fig.2

**■ Removing the cassette mechanism assembly (See Fig.3)**

1. Disconnect the card wire from the connector on the mecha. board.
2. Remove the six screws **C** attaching the cassette mechanism assembly.




Fig.3



**<CD changer unit>**

- Prior to performing the following procedure, remove the CD changer unit.

**■ Removing the CD tray (See Fig.1 and 2)**

1. Turn the black loading pulley gear on the under side of the CD changer unit in the direction of the arrow and draw the CD tray toward the front until it stops.
2. Disconnect the card wire from connector CW103 on the CD board.
3. Push down the two tray stoppers marked **a** and pull out the CD tray.




Fig.1




Fig.2

**■ Reinstall the CD tray (See Fig.3 and 4)**

1. Align the gear-cam with the gear-tray as shown fig.3, then mount the CD tray.
2. When assembling the CD tray, take extreme care not engage with gear - synchro.




Fig.3




Fig.4

**Removing the sensor board (See Fig.5)**

- Prior to performing the following procedure, remove the CD tray.
- 1. Remove the screw **A** attaching the sensor board on the CD tray.
- 2. Remove the sensor board releasing the two tabs **a**.
- 3. Disconnect the harness from the connector **CW1** on the sensor board.




Fig.5

**Removing the turn tray motor (See Fig.6 and 7)**

- Prior to performing the following procedure, remove the CD tray and sensor board.
- 1. Remove the screw **B** attaching the turn tray. Detach the turn tray from the base tray.
- 2. Pull outward the tab **b** attaching the turn tray motor on the base tray and detach the turn tray motor.

*Introductory notes:  
Base tray + Turn tray = CD tray*




Fig.6




Fig.7

**■Removing the belt, the CD board and the switch board (See Fig.8 and 9)**


• Prior to performing the following procedure, remove the CD tray.

1. Detach the belt from the pulley on the upper side of the CD changer unit (Do not stain the belt with grease).
2. Disconnect the card wire from the pickup unit connector on the under side of the CD changer unit.

**Attention :** Solder is put up before the card wire is removed from the pick-up unit connector on the CD mechanism assembly.  
(When the card wire is removed without putting up solder, the CD pick-up unit assembly might destroy.)

3. Disconnect the motor wire harness from connector on the CD board.
4. Remove the screw **C** attaching the switch board and release the two tabs **e** attaching the switch board outward and detach the switch board.
5. Remove the two screws **D** attaching the CD board. First release the two tabs **f** and two tabs **g** attaching the motor, then release the CD board.

※If the tabs **f** and **g** are hard to release, it is recommendable to unsolder the two soldered parts on the motor terminal of the CD board.



CD changer unit

Fig.8




Fig.9



■ Removing the CD mechanism holder assembly (mechanism included)

(See Fig.10 to 13)

1. Disconnect the harness from connector on the CD mechanism board in the CD mechanism assembly on the under side of the CD changer unit. Disconnect the card wire from the pickup unit connector.

**Attention :** Solder is put up before the card wire is removed from the pick-up unit connector on the CD mechanism assembly. (Refer to Fig.9)  
(When the card wire is removed without putting up solder, the CD pick-up unit assembly might destroy.)





Fig.10

2. Remove the screw **E** attaching the shaft on the right side of the CD mechanism holder assembly. Pull outward the stopper fixing the shaft on the left side and remove the CD mechanism holder assembly from behind in the direction of the arrow **y**.
3. Turn the CD mechanism holder assembly half around the lift up slide shaft **h** of the CD mechanism holder assembly until the turn table is reversed, and pull out the CD mechanism holder assembly.



CD mechanism holder assembly

Fig.11




Fig.13




Fig.12

### <CD mechanism section>

- Removing the CD mechanism holder from the CD chager unit.  
(Refer to "Removing the CD mechanism holder assembly" )

#### ■ Removing the pickup unit (See Fig.1)

1. Removing the cut washer on the feed gear sleeve and pull out the feed gear.
2. Remove the two screws **A** fixing the pickup shaft.
3. Removing the pickup unit.




Fig.1

#### ■ Removing the motor board (See Fig.2)

1. Unsolder the motor terminal on the motor board.
2. Remove the moter board.

#### ■ Removing the feed motor (See Fig.1)

Remove the two motor fixing screws at **B** and removing the feed motor.

#### ■ Removing the spindle motor

The spindle motor cannot be removed as a single unit.

When removing the spindle motor, change the chasis and turntable together as a unit.




Fig.2

**<Cassette mechanism section>**

· Prior to performing the following procedure, remove the cassette mechanism assembly.

**■Removing the R/P head.**

(See Fig.1 and 2)

1. Remove the screw **A** on the right side of the R/P head.
2. Remove the screw **B** on the left side of the R/P head.




Fig.1

**■Remove the erase head.**

(See Fig.1)

1. Remove the screw **C** fixing the erase head.




Fig.2

**■Remove the pinch roller.**

(See Fig.3)

1. Pull out the pinch roller stopper.
2. Pull out the pinch roller.




Fig.3



**Removing the motor (See Fig. 4 to 6)**

1. Slide the plastic cover in the direction of the arrow, and remove the three claws. Then remove the plastic cover.
2. Remove the two screws **D** fixing the motor. Be careful to grease's splash when the drive belt comes off.
3. Unsolder the motor terminal.




Fig.4

**Removing the mechanism board (See Fig. 5)**

1. Unsolder the four solder parts **a** and the four solder parts **b**.
2. Remove the two screws **E** attaching the mecha. board.




Fig.5

**Removing the flywheel (See Fig. 7 and 9)**

1. Remove the cut-washer at **c** from the capstan shaft, then remove the flywheel. When reassembling the flywheel, be sure to use new washers as they cannot be reused.




Fig.8




Fig.6




Fig.9




Fig.7

**< Speaker section >**

- It is exchange in a unit.  
Please do not decompose as much as possible.

**■ Removing the side panel (See Fig. 1)**

1. Remove the five screws **A** attaching the side panel and remove the side panel.




Fig.1

**■ Removing the side speaker (See Fig. 2 and 3)**

- Prior to performing the following procedure, remove the side panel.

1. Remove the four screws **B** attaching the side speaker.
2. Pull out the side speaker and remove the speaker cord from the speaker terminal.




Fig.2




Fig.3

# Wiring connection

Color codes are shown below.


- 1 ..... Brown
- 2 ..... Red
- 3 ..... Orange
- 4 ..... Yellow
- 5 ..... Green
- 6 ..... Blue
- 7 ..... Violet
- 8 ..... Gray
- 9 ..... White
- 0 ..... Black





# Adjustment method

## 1. Tuner



\* Adjustment Location of Tuner PCB

ITEAM	AM(MW) OSC Adjustment	AM(MW) RF Adjustment
Received FREQ.	522~1629 KHz	594 KHz
Adjustment point	MO	MA
Output	1~7.0 ± 0.5V	Maximum Output(Fig.1)




Fig.1 OSC Voltage

FM THD Adjustment	
SSG FREQ.	98 MHz
Adjustment point (FM DET)	FM DETECTOR COIL
Output	60 dB
Minimum Distortion (0.4% below) (Fig.2)	




Fig.2 IF CENTER and THD Adjustment

FM Search Level Adjustment	
SSG FREQ.	98 MHz
Adjustment point (SVR1)	BEACON SENSITIVITY SEMI-VR(10KΩ)
Output	28 dB (± 2dB)
Adjust SVR1 (Fig.3)	

\*Adjust FM S.S.G level to 28dB




Fig.3 FM Auto Search Level Adjustment

AM(MW) I.F Adjustment	
SSG FREQ.	450 kHz
Frequency	522 kHz
Adjustment point	AM IF
Maximum output (Fig.4)	




Fig.4 AM I.F Adjustment

## 2. Cassette Deck

### ■ To adjust tape speed

**Notes**

- 1) Measuring tape:
  - i) VT-712/MTT-111(or equivalent)  
(Tapes recorded with 3kHz)
  - ii) AC-225/MTT-5512(or equivalent)
- 2) Connect the cassette deck to the frequency counter as in fig.1.




Fig.1

Step	Item	Pre-Setup Condition	Pre-Setup	To Adjust	Standard	Remark
1	NOR SPEED Control	SPK OUT (connected to the frequency counter)	1) Deck 1:VT-712 2) Press PLAY SW button 3) Deck 2:Same as above	Turn VSR1 to left and right (FRONT PCB)	3KHz	±1% range

### ■ To adjust plabyback level/REC

**Notes**

- 1) Before the actual adjustment, clean the play/recording head.
- 2) Measuring tape :
  - i) VT-703/MTT-114N(or equivalent 10kHz AZIMUTH control)
  - ii) AC-225/MTT-5512(or equivalent)
- 3) The cassette deck is connections as shown in fig.2.




Fig.2



#### 1. Adjust Deck 1 Play Level

Step	Item	Pre-Setup Condition	Pre-Setup	To Adjust	Standard	Remark
1	AZIMUTH	SPK OUT (VTVM is connected to the scope)	After putting VT-703 into Deck 1 - Press FWD PLAY button.	Turn the control screw to as shown in Fig.3.	Max output and same phase (both channels)	After adjustment secure it with REGION LOCK.




## 2. Adjust Deck 2 Play Level/REC BIAS

Step	Item	Pre-Setup Condition	Pre-Setup	To Adjust	Standard	Remark
1	AZIMUTH	SPK OUT (VTVM is connected to the scope)	After putting VT-703 into Deck 2 1) Press FWD PLAY button.	Turn the control screw to as shown in Fig.3.	Max output and same phase (both channels)	After adjustment secure it with REGION LOCK.
2	Recording Bias Voltage	Fig.4	After putting AC-225 into Deck 2 1) Press REC PLAY button. 2) TAPE PCB JCW3, connected to VTVM	Turn JSR2L, JSR2R to the right and left	CHECK TO 7mV(±0.5mV)	



# Flow of functional operation until TOC read



## Maintenance of laser pickup


### (1) Cleaning the pick up lens

Before you replace the pick up, please try to clean the lens with a alcohol soaked cotton swab.

### (2) Life of the laser diode

When the life of the laser diode has expired, the following symptoms will appear.

1. The level of RF output (EFM output : amplitude of eye pattern) will below.



### (3) Semi-fixed resistor on the APC PC board

The semi-fixed resistor on the APC printed circuit board which is attached to the pickup is used to adjust the laser power. Since this adjustment should be performed to match the characteristics of the whole optical block, do not touch the semi-fixed resistor.

If the laser power is lower than the specified value, the laser diode is almost worn out, and the laser pickup should be replaced.

If the semi-fixed resistor is adjusted while the pickup is functioning normally, the laser pickup may be damaged due to excessive current.

## Replacement of laser pickup

Turn off the power switch and, disconnect the power cord from the ac outlet.

Replace the pickup with a normal one. (Refer to "Pickup Removal" on the previous page)

Plug the power cord in, and turn the power on. At this time, check that the laser emits for about 3 seconds and the objective lens moves up and down.  
Note: Do not observe the laser beam directly.

Play a disc.

Check the eye-pattern at TP1.


Finish.




# Troubleshooting

## 1. Amplifier


### Power malfunction




### No output




## 2.Tuner malfunction (FM/AM)



## 3.Tape




4.CD





## 5.CD - MP3 parts




1. Check the Connection Line between IC201 and IC601
  - IC601 #5 : 16.9 MHz
  - IC601 #20,#21,#22,#24,#25,#26,#27 DATA Line
2. Check the RAM Connection Line between IC602 and IC601
3. Check the MICOM Connection Line
  - IC601 #35,#36,#37,#38,#39


# Description of major ICs

## ■ LC876764 (UIC1) : Microcontroller

### 1.Pin layout



### 2.Block diagram



## 3. Pin function

(1/2)

Pin name	I/O	Function
VSS1, 2	-	Power supply (-)
VDD1,2,3,4	-	Power supply (+)
FIX0	-	Test pin Set as VSS with the user's option. (see Note 1)
PORT0 P00 to P07	I/O	<ul style="list-style-type: none"> <li>• 8bit input/output port</li> <li>• Data direction programmable in nibble units</li> <li>• Use of pull-up resistor can be specified in nibble units</li> <li>• Input for HOLD release</li> <li>• Input for port 0 interrupt</li> </ul>
PORT1 P10 to P17	I/O	<ul style="list-style-type: none"> <li>• 15V withstand at N-channel open drain output</li> <li>• 8bit input/output port</li> <li>• Data direction programmable for each bit</li> <li>• Use of pull-up resistor can be specified for each bit</li> <li>• Other pin functions P10: SIO0 data output P11: SIO0 data input / bus input / output P12: SIO0 clock input / output P13: SIO1 data output P14: SIO1 data input / bus input / output P15: SIO1 clock input / output P16: Timer 1 PWML output P17: Timer 1 PWMH output / Buzzer output</li> </ul>
PORT3 P30 to P37	I/O	<ul style="list-style-type: none"> <li>• 8bit input/output port</li> <li>• Data direction can be specified for each bit</li> <li>• Use of pull-up resistor can be specified for each bit</li> <li>• 15V withstand at N-channel open drain output</li> <li>• Other functions: P30 to P33: INT4 input / HOLD release input / Timer 1 event input / Timer 0L capture input / Timer 0H capture input P34 to P37: INT5 input / HOLD release input / Timer 1 event input / Timer 0L capture input / Timer 0H capture input</li> </ul>
PORT7 P70 to P73	I/O	<ul style="list-style-type: none"> <li>• 4bit input/output port</li> <li>• Data direction can be specified for each bit</li> <li>• Use of pull-up resistor can be specified for each bit</li> <li>• Other functions P70: INT0 input / HOLD release input / Timer0L capture input / Output for watchdog timer P71: INT1 input / HOLD release input / Timer0H capture input P72: INT2 input / HOLD release input / Timer 0 event input / Timer0L capture input / High speed clock counter input P73: INT3 input(noise rejection filter attached input) / Timer 0 event input / Timer 0H capture input AD input port: AN8(P70), AN9(P71), AN12(P72), AN13(P73)</li> </ul>
PORT8 P80 to P87	I/O	<ul style="list-style-type: none"> <li>• 8bit input/output port</li> <li>• Input/output can be specified in a bit unit</li> <li>• Other functions: AD input port: AN0 to AN7 Weak signal detector input port: MICIN(P87)</li> </ul>
S0/T0 to S8/T8	O	<ul style="list-style-type: none"> <li>• Large current output for VFD display controller digit (can be used for segment)</li> </ul>
S9/T9 to S15/T15	O	<ul style="list-style-type: none"> <li>• Large current output for VFD display controller segment/digit</li> </ul>
S16 to S23	I/O	<ul style="list-style-type: none"> <li>• Output for VFD display controller segment/digit</li> <li>• Other functions: High voltage input port: PC0 to PC7</li> </ul>
S24 to S31	I/O	<ul style="list-style-type: none"> <li>• Output for VFD display controller segment</li> <li>• Other functions: High voltage input port: PD0 to PD7</li> </ul>




3. Pin function

(2/2)

Pin name	I/O	Function
S32 to S39	I/O	<ul style="list-style-type: none"> <li>Output for VFD display controller segment</li> <li>Other functions:</li> </ul> High voltage input port: PE0 to PE7
S40 to S47	I/O	<ul style="list-style-type: none"> <li>Output for VFD display controller segment</li> <li>Other functions:</li> </ul> High voltage input/output port: PF0 to PF7
S48 to S51	I/O	<ul style="list-style-type: none"> <li>Output for VFD display controller segment</li> <li>Other functions:</li> </ul> High voltage input/output port: PG0 to PG3
RES	I	Reset terminal
XT1	I	<ul style="list-style-type: none"> <li>Input for 32.768kHz crystal oscillation</li> <li>Other functions:</li> </ul> General purpose input port When not in use, connect to VDD1. AD input port: AN10
XT2	I/O	<ul style="list-style-type: none"> <li>Output for 32.768kHz crystal oscillation</li> <li>Other functions:</li> </ul> General purpose input port When not in use, set to oscillation mode and leave open circuit.
CF1	I	AD input port: AN11
CF2	O	Input terminal for ceramic oscillator Output terminal for ceramic oscillator


■ KA9258D (IC301) : 4-ch Motor driver

1. Block diagram



**HA12237 (JIC01) : Audio signal processor**

1. Block diagram




2. Pin function


Pin No.	Symbol	Function	Pin No.	Symbol	Function	Pin No.	Symbol	Function
1	PB-NF2(R)	PB EQ feed back	15	REC MUTE OFF/ON	Mode control input	27	TAI(L)	Tape input
2	PB-EQ(R)	NAB output	16	Vcc	Vcc pin	28	EQOUT(L)	EQ output
3	EQOUT(R)	EQ output	17			29	PB-EQ(L)	NAB output
4	TAI(R)	Tape input	18	GND	GND pin	30	PB-NF2(L)	PB EQ feed back
5	PBOUT(R)	PB output	19	IREF	Equalizer reference current input	31	PB-NF(L)	PB EQ feed back
6	NC	NC pin	20	Test mode	Test mode pin	32	AIN(L)	PB A deck input
7	RECIN(R)	REC-EQ input	21	RECOUT(L)	REC output	33	RIP	Ripple filter
8			22	NC	NC pin	34	BIN(L)	PB B deck input
9	NC	NC pin	23			35	REC-RETURN	REC Return
10	RECOUT(R)	REC output	24	RECIN(L)	REC-EQ input	36	GND	GND pin
11	ALC ON/OFF	Mode control input	25	NC	NC pin	37	BIN(R)	PB B deck input
12	High/Norm	Mode control input	26	PBOUT(L)	PB output	38	NC	NC pin
13	A/B	Mode control input				39	AIN(R)	PB A deck input
14	MUTE ON/OFF	Mode control input				40	PB-NF1(R)	PB EQ feed back

■KB9226 (IC101) : RF amp. & servo signal processor

1. Pin layout



2. Block diagram






## 3. Pin function


Pin No.	Symbol	I/O	Function
1	RFM	I	RF summing amp. inverting input
2	RFO	O	RF summing amp. output
3	EQI	I	RFO DC eliminating input(use by MIRROR, FOK ,AGC & EQ terminal)
4	EQO	O	RF equalizer output
5	EFMI	I	EFM slice input. (input impedance 47K)
6	VCC	P	Main power supply
7	FRSH	I	Capcitor connection to focus search
8	FSET	I	Filter bias for focus,tracking,spindle
9	FLB	I	Capacitor connection to make focus loop rising band
10	FGD	I	Terminal to change the high frequency gain of focus loop
11	FSI	I	Focus servo input
12	TGU	I	Connect the component to change the high frequency of tracking Loop
13	ISTAT	O	Internal status output
14	MCK	I	Micom clock
15	MDATA	I	Data input
16	MLT	I	Data latch input
17	RESET	I	Reset input
18	CLVI	I	Input the spindle control output from DSP
19	WDCK	I	88.2KHz input terminal from DSP
20	LOCK	I	Sled run away inhibit pin (L: sled off & tracking gain up)
21	EFM	O	EFM output for RFO slice(to DSP)
22	ASY	I	Auto asymmetry control input
23	SPM	I	Spindle amp. inverting input
24	SPO	O	Spindle amp. output
25	SLM	I	Sled servo inverting input
26	SLO	O	Sled servo output
27	SLP	I	Sled servo noninverting input
28	TEM	I	Tracking servo amp.inverting input
29	TEO	O	Tracking servo amp. output
30	FEM	I	Focus servo amp. inverting input
31	FEO	O	Focus servo amp. output pin
32	GND	P	Main ground
33	TZC/ SSTOP	I	Tracking zero crossing input & Check the position of pick-up whether inside or not
34	TEIO	B	Tracking error output & Tracking servo input
35	LPFT	I	Tracking error integration input (to automatic control)
36	ATSC	I	Anti-shock input
37	LD	O	APC amp. output
38	PD	I	APC amp. input
39	PDAC	I	Photo diode A & C RF I/V amp. inverting input
40	PDBD	I	Photo diode B & D RF I/V amp. inverting input
41	PDF	I	Photo diode F & tracking(F) I/V amp. inverting input
42	PDE	I	Photo diode E & tracking(E) I/V amp. inverting input
43	DCB	I	Capacitor connection to limit the defect detection
44	MCP	I	Capacitor connection to mirror hold
45	DCCI	O	Output pin to connect the component for defect detect
46	DCCO	I	Input pin to connect the component for defect detect
47	VREF	O	(VCC+GND)/2 Voltage reference output
48	EQC	I	AGC_equalize level control terminal & capacitor terminal to input in to VCA

■ 5L9290 (IC201) : Digital signal processor for CDP

1. Pin layout



2. Block diagram




## 3. Pin function

NO.	Symbol	I/O	Function
1	VSSA_PLL	-	Analog Ground for DPLL
2	VCO1LF	O	Pump out for VCO1
3	VSSD_PLL	-	Digital Ground Separated Bulk Bias for DPLL
4	VDDD_PLL	-	Digital Power Separated Bulk Bias for DPLL (3V Power)
5	VDDD1-5V	-	Digital Power (5V Power, I/O PAD)
6	XIN	I	X'tal oscillator input (16.9344MHz)
7	XOUT	O	X'tal oscillator output
8	VSSD1	-	Digital Ground (I/O PAD)
9	EFMI	I	EFM signal input
10	LOCK	O	CLV Servo locking status output
11	SMEF	O	LPF time constant control of the spindle servo error signal
12	SMDP	O	Phase control output for Spindle Motor drive
13	SMDS	O	Speed control output for Spindle Motor drive
14	WDCK	O	Word clock output (Normal Speed : 88.2KHz, Double Speed : 176.4KHz)
15	TESTV	I	Various Data/Clock Input
16	LKFS	O	The Lock status output of frame sync
17	C4M	O	4.2336MHz clock output
18	RESETB	I	System Reset at 'L'
19	MLT	I	Latch signal input from Micom
20	MDAT	I	Serial data input from Micom
21	MCK	I	Serial data receiving clock input from Micom
22	ISTAT	O	The internal status output to Micom
23	S0S1	O	Subcode sync signal(S0+S1) output
24	SQCK	I	Subcode-Q data transferring bit clock input
25	SQDT	O	Subcode-Q data serial output
26	MUTE	I	System mute at 'H'
27	VDDD2-3V	-	Digital Power (3V Power, Internal Logic)
28	VSSD2	-	Digital Ground (Internal Logic)
28	VDDD3-5V	-	Digital Power (5V Power, I/O PAD)
30	SBCK	I	Subcode data transferring bit clock
31	JITB	O	Internal SRAM jitter margin status output
32	C2PO	O	C2 pointer output
33	DATX	O	Digital audio data output
34	SADTO	O	Serial audio data output (48 slot, MSB first)
35	LRCKO	O	Channel clock output
36	BCKO	O	Bit clock output
37	BCKI	I	Bit clock input
38	LRCKI	I	Channel clock input
39	SADTI	I	Serial audio data input (48 slot, MSB first)
40	VSSD_DAC	-	Digital Ground for DAC
41	VDDD_DAC	-	Digital Power for DAC (3V Power)
42	RCHOUT	O	Right-Channel audio output through DAC
43	VSSA_DAC	-	Analog Ground for DAC
44	VREF	O	Referance Voltage output for bypass
45	VHALF	O	Referance Voltage output for bypass
46	VDDA_DAC	-	Analog Power for DAC (3V Power)
47	LCHOUT	O	Left-Channel audio output through DAC
48	VDDA_PLL	-	Analog Power for PLL (3V Power)

**KS9274 (IC601) : CD-MP3 decoder**

1. Block diagram




2. Pin function

5	CLK	I	System clock input
6	RESETB	I	System reset active LOW
10	FILTER_0	O	820uF to GND 940uF to GND
14	FILTER_1	O	When "HIGH" PLL is bypassed, Tied to LOW in normal operation
15	PLL_BYPASS	I	
20	CD_DATA	I	
21	CD_LRCK	I	
22	CD_BCK	I	
24	ACLK	O	
25	BCLK	O	
26	LRCK	O	
27	ADAT	O	
35	MDAT	I	Write/Read data from MCU to CD-MP3
36	MCK	I	Data strobe signal from MCU
37	MLAT	I	Micom command identifier from MCU to CD-MP3
38	MDOUT	O	Data from CD-MP3 to MCU
39	MINT	O	Interrupt output to MCU
44	DDAT0		Data BUS
45	DDAT1		Data BUS
46	WEB	O	Write enable
47	RASB	O	Row address strobe
50	DDAT2		Data BUS
51	DDAT3		Data BUS
52	CASB	O	Column address strobe
53-62	DA9-DA0	O	Address output
63	OEB	O	Control output to make data output to "High-Z" at DRAM

**KA3082 (IC401, IC402) : DC motor driver**

1. Pin layout




2. Pin function

Pin No.	Symbol	I/O	Function
1	GND	-	Ground
2	VO1	O	Output 1
3	VZ1	-	Phase compensation
4	VCTL	I	Motor speed control
5	VIN1	I	Input 1
6	VIN2	I	Input 2
7	SVCC	-	Supply voltage (Signal)
8	PVCC	-	Supply voltage (Power)
9	VZ2	-	Phase compensation
10	VO2	O	Output 2




■ TDA7442D (EIC01) : Audio processor

1.Pin layout




2.Block diagram




■ BA4560 (FIC02) : Dual op amp.

1.Pin layout




■ L4959 (PIC02) : Voltage regulator

1.Pin layout



2.Block diagram




3.Pin function

Pin	Pins	Description
1	OUT 12V (b)	12V/1.3A SWITCHED OUTPUT VOLTAGE
2	V <sub>s</sub>	Supply Voltage
3	OUT 5.6V	5.6V/250mA OUTPUT VOLTAGE
4	N.C.	not connected
5	EN 12V (b)	Enable 12V/1.3A SWITCHED OUTPUT VOLTAGE
6	GND	Ground
7	EN 12V (a)	Enable 12V/0.8A SWITCHED OUTPUT VOLTAGE
8	EN 8.6V	Enable 8.6V/0.6A SWITCHED OUTPUT VOLTAGE
9	OUT 8.6	8.6V/0.6A SWITCHED OUTPUT VOLTAGE
10	V <sub>s</sub>	Supply Voltage
11	OUT 12V (a)	12V/0.8A SWITCHED OUTPUT VOLTAGE

■ M11L1644 (IC602) : DRAM

1. Block diagram




2. Pin function


Pin No.	Symbol	I/O	Function
3~11, 14~19, 7	A0~A10	I	Address Input Row Address : A0~A10 Column Address : A0~A10
5	RAS	I	Row Address Strobe
21	CAS	I	Column Address Strobe
4	WE	I	Write Enable
20	OE	I	Output Enable
2, 3, 22, 23	I/O0~I/O3	I/O	Data Input/ Ountput
1, 12	Vcc		Power (5V or 3.3V)
13, 24	Vss		Ground
6	NC	-	No Connect

■ STK403-070 (FIC01) : Power amp.

1.Pin layout




2.Block diagram




■ STK403-100 (WIC01) : Power amp.

1.Pin layout




2.Block diagram






■ PT8300 (UIC03, UIC04) : DRAM

1. Pin layout



2. Block diagram




3. Pin function


Pin No.	Pin Name	I/O	Function
1	VSS	-	Ground
2	/RESET	I	Reset pin
3	CLK	I	Clock input pin
4	LATCH	I	Latch input pin
5-12	P15~P8	I/O	Parallel data I/O pins
13	LATCH0	O	Latch output pin
14	CLK0	O	Clock output pin
15,25	DO1, DO2	O	Serial data output pins
26,17	DI1, DI2	I	Serial data input pins
17-24	P7~P0	O	Parallel data output pin
27	PULLUP	I	P8 to P15 control pin for internal pull-up resistor
			When P8 to P15 are in the output state, the PULLUP pin must be connected to VDD.
			When P8 to P15 are in the input state, the PULLUP pin must be connected to VSS.
28	VDD	-	Power supply pin

■ LA72723(IC03) : RDS demodulation

1. Pin layout



2. Block Diagram



3. Pin functions

Pin No.	Symbol	I/O	Function
1	VREF	O	Reference voltage output (Vdda/2)
2	MPXIN	I	Baseband (multiplexed) signal input
3	Vdda	—	Analog power supply (+5V)
4	Vssa	—	Analog ground
5	FLOUT	O	Subcarrier input (filter output)
6	CIN	I	Subcarrier input (comparator input)
7	TEST	I	Test input
8	XOUT	O	Crystal oscillator output (4.332MHz)
9	XIN	I	Crystal oscillator input (external reference input)
10	Vssd	—	Digital ground
11	Vddd	—	Digital power supply
12	MODE	I	Read mode setting (0:master,1:slave)
13	RST	I	RDS-ID/RAM reset (positive polarity)
14	RDDA	O	RDS data output
15	RDCL	I/O	RDS clock output (master mode)/RDS clock input (slave mode)
16	RDS-ID/READY	O	RDS-ID/READY output (negative polarity)

< MEMO >




**MX-GA77**



**JVC**

VICTOR COMPANY OF JAPAN, LIMITED  
AV & MULTIMEDIA COMPANY AUDIO/VIDEO SYSTEM CATEGORY 10-1,1 chome,Ohwatari-machi,maebashi-city,371-8543,Japan

(No.22083)

 Printed in Japan  
200307



# JVC





## COMPACT COMPONENT SYSTEM

# CA-MXGT88 CA-MXGA77

CA-MXGT88

CA-MXGA77



COMPACT  
**disc**  
DIGITAL AUDIO

**R-D-S**

COMPACT  
**disc**  
DIGITAL AUDIO

**R-D-S**

## INSTRUCTIONS

### For Customer Use:

Enter below the Model No. and Serial No. which are located either on the rear, bottom or side of the cabinet. Retain this information for future reference.

Model No. \_\_\_\_\_

Serial No. \_\_\_\_\_

LVT1010-003B

[B]

# Warnings, Cautions and Others

## IMPORTANT for the U.K.

**DO NOT** cut off the mains plug from this equipment. If the plug fitted is not suitable for the power points in your home or the cable is too short to reach a power point, then obtain an appropriate safety approved extension lead or consult your dealer.

**BE SURE** to replace the fuse only with an identical approved type, as originally fitted.

If nonetheless the mains plug is cut off ensure to remove the fuse and dispose of the plug immediately, to avoid a possible shock hazard by inadvertent connection to the mains supply.

If this product is not supplied fitted with a mains plug then follow the instructions given below:

### IMPORTANT:

**DO NOT** make any connection to the terminal which is marked with the letter E or by the safety earth symbol or coloured green or green-and-yellow.

The wires in the mains lead on this product are coloured in accordance with the following code:

Blue : Neutral  
Brown : Live


As these colours may not correspond with the coloured markings identifying the terminals in your plug proceed as follows:

The wire which is coloured blue must be connected to the terminal which is marked with the letter N or coloured black.

The wire which is coloured brown must be connected to the terminal which is marked with the letter L or coloured red.

**IF IN DOUBT - CONSULT A COMPETENT ELECTRICIAN.**

### Caution — switch!

Disconnect the mains plug to shut the power off completely. The  switch in any position does not disconnect the mains line. The power can be remote controlled.

### CAUTION


To reduce the risk of electrical shocks, fire, etc.:

1. Do not remove screws, covers or cabinet.
2. Do not expose this appliance to rain or moisture.

## IMPORTANT FOR LASER PRODUCTS

### REPRODUCTION OF LABELS

- ① CLASSIFICATION LABEL, PLACED ON EXTERIOR SURFACE



- ② WARNING LABEL, PLACED INSIDE THE UNIT

<b>CAUTION:</b> Invisible laser radiation when open and interlock failed or defeated. AVOID DIRECT EXPOSURE TO BEAM. (e)	<b>WARNING:</b> Osynlig laserstrålning när denna del är öppnad och spärren är urkopplad. Betrakta ej strålen. (s)	<b>ADVARSEL:</b> Usynlig laserstrålning ved åbning, når sikkerhedsafbrydere er ude af funktion. Undgå udsættelse for stråling. (d)	<b>VARO:</b> Avattaessa ja suojalukitus ohitettaessa olet alttiina näkymättömälle lasersäteilylle. Älä katso säteeseen. (f)
--	---	--	---

1. CLASS 1 LASER PRODUCT
2. **CAUTION:** Invisible laser radiation when open and interlock failed or defeated. Avoid direct exposure to beam.
3. **CAUTION:** Do not open the top cover. There are no user serviceable parts inside the Unit; leave all servicing to qualified service personnel.

### CAUTION

- Do not block the ventilation openings or holes. (If the ventilation openings or holes are blocked by a newspaper or cloth, etc., the heat may not be able to get out.)
- Do not place any naked flame sources, such as lighted candles, on the apparatus.
- When discarding batteries, environmental problems must be considered and local rules or laws governing the disposal of these batteries must be followed strictly.
- Do not expose this apparatus to rain, moisture, dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on the apparatus.

### Caution: Proper Ventilation

To avoid risk of electric shock and fire, and to prevent damage, locate the apparatus as follows:

#### 1 Front:


No obstructions and open spacing.

#### 2 Sides/ Top/ Back:

No obstructions should be placed in the areas shown by the dimensions below.

#### 3 Bottom:

Place on the level surface. Maintain an adequate air path for ventilation by placing on a stand with a height of 10 cm or more.



## **SAFETY INSTRUCTIONS**

### **“SOME DOS AND DON'TS ON THE SAFE USE OF EQUIPMENT”**

This equipment has been designed and manufactured to meet international safety standards but, like any electrical equipment, care must be taken if you are to obtain the best results and safety is to be assured.

\*\*\*\*\*

Do read the operating instructions before you attempt to use the equipment.

Do ensure that all electrical connections (including the mains plug, extension leads and interconnections between pieces of equipment) are properly made and in accordance with the manufacturer's instructions. Switch off and withdraw the mains plug when making or changing connections.

Do consult your dealer if you are ever in doubt about the installation, operation or safety of your equipment.

Do be careful with glass panels or doors on equipment.

\*\*\*\*\*

**DON'T** continue to operate the equipment if you are in any doubt about it working normally, or if it is damaged in any way—switch off, withdraw the mains plug and consult your dealer.

**DON'T** remove any fixed cover as this may expose dangerous voltages.

**DON'T** leave equipment switched on when it is unattended unless it is specifically stated that it is designed for unattended operation or has a standby mode.

Switch off using the switch on the equipment and make sure that your family know how to do this.

Special arrangements may need to be made for infirm or handicapped people.

**DON'T** use equipment such as personal stereos or radios so that you are distracted from the requirements of traffic safety. It is illegal to watch television whilst driving.

**DON'T** listen to headphones at high volume as such use can permanently damage your hearing.

**DON'T** obstruct the ventilation of the equipment, for example with curtains or soft furnishings.

Overheating will cause damage and shorten the life of the equipment.

**DON'T** use makeshift stands and **NEVER** fix legs with wood screws — to ensure complete safety always fit the manufacturer's approved stand or legs with the fixings provided according to the instructions.


**DON'T** allow electrical equipment to be exposed to rain or moisture.

#### **ABOVE ALL**

- **NEVER** let anyone, especially children, push anything into holes, slots or any other opening in the case -this could result in a fatal electrical shock.;
- **NEVER** guess or take chances with electrical equipment of any kind
- it is better to be safe than sorry!



# Introduction



We would like to thank you for purchasing one of our JVC products. Before operating this unit, read this manual carefully and thoroughly to obtain the best possible performance from your unit, and retain this manual for future reference.

## About This Manual

This manual is organized as follows:

- The manual mainly explains operations using the buttons and controls on the unit. You can also use the buttons on the remote control if they have the same or similar names (or marks) as those on the unit. If operation using the remote control is different from that using the unit, it is then explained.
- Basic and common information that is the same for many functions is grouped in one place, and is not repeated in each procedure. For instance, we do not repeat the information about turning on/off the unit, setting the volume, changing the sound effects, and others, which are explained in the section “Common Operations” on pages 9 to 11.
- The following marks are used in this manual:



Gives you warnings and cautions to prevent damage or risk of fire/electric shock. Also gives you information which is not good for obtaining the best possible performance from the unit.



Gives you information and hints you had better know.

## Precautions

### Installation

- Do not grasp the control knobs when moving or carrying the unit.
- Install in a place which is level, dry and neither too hot nor too cold—between 5°C and 35°C.
- Install the unit in a location with adequate ventilation to prevent internal heat built-up in the unit.
- Leave sufficient distance between the unit and the TV.
- Keep the speakers away from the TV to avoid interference with TV.



DO NOT install the unit in a location near heat sources, or in a place subject to direct sunlight, excessive dust or vibration.

### Power sources

- When unplugging from the wall outlet, always pull the plug, not the AC power cord.



DO NOT handle the AC power cord with wet hands.

### Moisture condensation

Moisture may condense on the lens inside the unit in the following cases:

- After starting heating in the room
  - In a damp room
  - If the unit is brought directly from a cold to a warm place
- Should this occur, the unit may malfunction. In this case, leave the unit turned on for a few hours until the moisture evaporates, unplug the AC power cord, and then plug it in again.

### Others


- Should any metallic object or liquid fall into the unit, unplug the unit and consult your dealer before operating any further.
- If you are not going to operate the unit for an extended period of time, unplug the AC power cord from the wall outlet.



DO NOT disassemble the unit since there are no user serviceable parts inside.

If anything goes wrong, unplug the AC power cord and consult your dealer.







<b>Location of the Buttons and Controls</b> .....	<b>3</b>
Front Panel .....	3
Remote Control .....	5
<b>Getting Started</b> .....	<b>6</b>
Unpacking .....	6
Putting the Batteries into the Remote Control .....	6
Connecting Antennas .....	6
Connecting Speakers .....	7
Connecting Other Equipment .....	8
Canceling the Display Demonstration .....	8
<b>Common Operations</b> .....	<b>9</b>
Turning On or Off the Power .....	9
Saving the Power Consumption While on Standby —ECO Mode .....	9
Setting the Clock .....	9
Selecting the Sources .....	9
Adjusting the Volume .....	10
Reinforcing the Bass Sound .....	10
Enjoying the Heavy Sound .....	10
Selecting the Sound Modes .....	11
Turning On or Off the Key-touch Tone .....	11
<b>Listening to the Radio</b> .....	<b>12</b>
Tuning in to a Station—Auto Search .....	12
Presetting Stations .....	12
Tuning in to a Preset Station .....	12
<b>Receiving FM Stations with RDS</b> .....	<b>13</b>
Changing the RDS Information .....	13
Searching for Programs by PTY Codes (PTY Search) .....	13
Switching Temporarily to a Program Type of Your Choice .....	14
<b>Playing Back CDs</b> .....	<b>15</b>
Loading CDs .....	15
Playing Back CDs—All Disc and One Disc .....	15
Basic CD Operations .....	17
Changing the MP3 Playback Mode .....	19
Turning On or Off the Resume Play for MP3 Disc ..	19
Programming the Playing Order of the Tracks —Program Play .....	20
Playing at Random—Random Play .....	21
Repeating Tracks or CDs—Repeat Play .....	21
Prohibiting Disc Ejection—Carrousel Lock .....	21
<b>Playing Back Tapes</b> .....	<b>22</b>
Playing Back a Tape .....	22
<b>Recording</b> .....	<b>23</b>
Recording a Tape on Deck B .....	23
Dubbing Tapes .....	24
CD Synchronized Recording .....	24
<b>Using the Timers</b> .....	<b>25</b>
Using Daily Timer .....	25
Using Recording Timer .....	27
Using Sleep Timer .....	28
Timer Priority .....	28
<b>Maintenance</b> .....	<b>29</b>
<b>Additional Information</b> .....	<b>30</b>
<b>Troubleshooting</b> .....	<b>31</b>
<b>Specifications</b> .....	<b>32</b>

# Location of the Buttons and Controls

Become familiar with the buttons and controls on your unit.

## Front Panel





See pages in the parentheses for details.

### Front Panel

- 1 (standby/on) button and STANDBY lamp (9, 26, 27)  
ECO button (9)
- 2 Carrousel
- 3 Sound mode lamps (11)
- 4 REC START/STOP button (23)  
CD REC START button (24)  
DUBBING button (24)
- 5 Display window
- 6 DISPLAY button (9)
- 7 Remote sensor
- 8 PHONES jack (10)
- 9 SOUND MODE control (11)
- 10 SOUND TURBO button (10)
- 11 SUBWOOFER LEVEL +/- buttons (10)
- 12 (stop) button (15 – 17, 20 – 24)  
BEEP button (11)
- 13 AUX button (9)  
*Pressing this button also turns on the unit.*
- 14 FM/AM button (9, 12)  
*Pressing this button also turns on the unit.*
- 15 TUNING +/- buttons (12)  
 (fast rewind/fast forward) buttons (17, 22)
- 16 Deck A cassette holder (22, 24)  
*Pressing the EJECT portion opens the holder.*
- 17 Disc number buttons and lamps (CD1, CD2, and CD3)  
(16, 17, 20, 21, 24)  
*Pressing one of these buttons also turns on the unit.*
- 18 (Carrousel open/close) button (15 – 17, 19 – 21)  
*Pressing this button also turns on the unit.*
- 19 DISC CHANGE button (15, 17)
- 20 REPEAT button (15, 17, 21)  
PROGRAM (MP3 Resume on/off) button (19, 20)  
RANDOM button (21)
- 21 CLOCK/TIMER button (9, 25 – 28)
- 22 SET button (9, 12, 20, 25 – 28)
- 23 CANCEL/DEMO button (8, 9, 20, 25 – 28)


- 24 PRESET +/- control (12)  
 (reverse search/forward search) control  
(9, 17 – 21, 25 – 27)
- 25 TAPE A/B button (22)
- 26 VOLUME control (10)
- 27 RDS operation buttons (13, 14)  
• DISPLAY MODE, RDS MODE, and SELECT +/- buttons
- 28 TAPE (play) button (9, 22, 24)  
*Pressing this button also turns on the unit.*
- 29 CD (play/pause) button (9, 15 – 17, 20)  
*Pressing this button also turns on the unit.*
- 30 Deck B cassette holder (22 – 24, 27)  
*Pressing the EJECT portion opens the holder.*

### Display window

- 1 Timer indicators  
• DAILY (daily timer), SLEEP (sleep timer), REC (recording timer), and (timer) indicators
- 2 GROUP indicator
- 3 TRACK indicator
- 4 RDS indicator
- 5 Main display  
• Shows the source name, frequency, etc.
- 6 NEWS indicator
- 7 INFO indicator
- 8 MP3 indicator
- 9 Tape operation indicators  
• A/B (operating deck), REC (recording), and (tape running) indicators
- 10 PRGM (program) indicator
- 11 SOUND MODE indicator
- 12 WOOFER indicator
- 13 TURBO indicator
- 14 CD track number indicators
- 15 RANDOM indicator
- 16 REPEAT mode indicators  
• REPEAT, 1, 1 DISC, ALL DISC indicators
- 17 Tuner operation indicators  
• MONO and ST (stereo) indicators
- 18 Volume level, Subwoofer level and Sound Mode pattern indicators




## Remote Control



## Remote Control


- 1 BEEP ON/OFF button (11)
- 2 SLEEP button (28)
- 3 Number buttons (12, 18)
- 4 SOUND TURBO button (10)
- 5 VOLUME + button (10)
- 6 ◀◀/◀◀ (reverse search/fast rewind) button (12, 17 – 19, 21, 22)
- 7 SUBWOOFER LEVEL – button (10)
- 8 AUX button (9)  
*Pressing this button also turns on the unit.*
- 9 FADE MUTING button (10)
- 10 FM/AM button (9, 12)  
*Pressing this button also turns on the unit.*
- 11 CD ▶/|| (play/pause) button (9, 15 – 17, 20)  
*Pressing this button also turns on the unit.*
- 12 ◻/I (power) STANDBY/ON button (9)
- 13 FM MODE button (12)  
MP3 button (19)
- 14 SOUND MODE button (11)
- 15 ■ (stop) button (15 – 17, 20 – 24)
- 16 ▶▶/▶▶ (forward search/fast forward) button (12, 17 – 19, 21, 22)
- 17 VOLUME – button (10)
- 18 SUBWOOFER LEVEL + button (10)
- 19 A/B button (22)
- 20 TAPE ▶ (play) button (9, 22)  
*Pressing this button also turns on the unit.*
- 21 DISC SKIP button (15, 17)
- 22 RDS operation buttons (13, 14)
  - DISPLAY MODE, SELECT +/-, and RDS MODE buttons



When using the remote control, point it at the remote sensor on the front panel.



# Getting Started

Continued 

## Unpacking

After unpacking, check to be sure that you have all the following items.


The number in the parentheses indicates the quantity of the pieces supplied.

- AM (MW) loop antenna (1)
- FM antenna (1)
- Remote control (1)
- Batteries (2)

If any is missing, consult your dealer immediately.

## Putting the Batteries into the Remote Control


Insert the batteries—R6P(SUM-3)/AA(15F)—into the remote control, by matching the polarity (+ and -) on the batteries with the + and - markings on the battery compartment. When the remote control can no longer operate the unit, replace both batteries at the same time.



- DO NOT use an old battery together with a new one.
- DO NOT use different types of batteries together.
- DO NOT expose batteries to heat or flame.
- DO NOT leave the batteries in the battery compartment when you are not going to use the remote control for an extended period of time. Otherwise, it will be damaged from battery leakage.

## Connecting Antennas

### FM antenna



- 1 Attach the FM antenna to the FM [75 Ω] coaxial terminal.**
- 2 Extend the FM antenna.**
- 3 Fasten it up in the position which gives you the best reception, then fix it on the wall, etc.**




#### About the supplied FM antenna

The FM antenna supplied with this unit can be used as temporary measure. If reception is poor, you can connect an outdoor FM antenna.


#### To connect an outdoor FM antenna

Before connecting it, disconnect the supplied FM antenna.



A 75 Ω antenna with coaxial type connector (DIN 45325) should be used.

## AM (MW) antenna



**1** Press and hold the clamp of the AM terminal on the rear of the unit.

**2** Insert the end of the AM (MW) loop antenna cord into the terminal.

- If the AM (MW) loop antenna wire is covered with vinyl, remove the vinyl by twisting it as shown in the diagram.

**3** Release the finger from the clamp.

**4** Turn the AM (MW) loop antenna until you have the best reception.

### To connect an outdoor AM (MW) antenna


When reception is poor, connect a single vinyl-covered wire to the AM terminal and extend it horizontally. (The AM (MW) loop antenna must remain connected.)



#### For better reception of both FM and AM (MW)

- Make sure the antenna conductors do not touch any other terminals and connecting cords.
- Keep the antennas away from metallic parts of the unit, connecting cords, and the AC power cord.

## Connecting Speakers



**1** Press and hold the clamp of the speaker terminal on the rear of the unit.

**2** Insert the end of the speaker cord into the terminal.

Match the colors (polarity): Blue (+) to blue (+) and black (-) to black (-); red (+) to red (+) and black (-) to black (-).

- If the wire is covered with vinyl, remove the vinyl by twisting it as shown in the diagram.

**3** Release the finger from the clamp.

### IMPORTANT:

- Use only speakers with the same speaker impedance as indicated by the speaker terminals on the rear of the unit.
- DO NOT connect more than one speaker to one speaker terminal.



## Connecting Other Equipment


You can connect audio equipment—used only as a playback device.



- DO NOT connect any equipment while the power is on.
- DO NOT plug in any equipment until all connections are complete.

### To connect audio equipment

Be sure that the plugs of the audio cords are color coded: White plugs and jacks are for left audio signals, and red ones for right audio signals.



For playing the other equipment through this unit, connect between the audio output jacks on the other equipment and AUX IN jacks by using audio cords (not supplied).

**NOW** you are ready to plug in the unit and other connected equipment.

## Canceling the Display Demonstration

When connecting the AC power cord into a wall outlet, the unit automatically starts the display demonstration.

### On the unit ONLY:

To cancel the display demonstration, press CANCEL/DEMO while the display demonstration is shown on the display.



### When you press other buttons

The display demonstration stops temporarily. It will start automatically again (if no operation is done for 2 minutes) until you cancel it.

### To start the display demonstration manually

Press and hold CANCEL/DEMO again for more than 2 seconds.



# Common Operations

## Turning On or Off the Power

To turn on the unit, press so that the STANDBY lamp goes off.

POWER ON



To turn off the unit (on standby), press again so that the STANDBY lamp lights up.



A little power is always consumed even while the unit is on standby.

To switch off the power supply completely, unplug the AC power cord from the AC outlet.

**notes** When you unplug the AC power cord or if a power failure occurs

The clock is reset to “-- : --” soon, while the tuner preset stations (see page 12) will be erased in a few days.

## Saving the Power Consumption While on Standby—ECO Mode

You can save the power consumption while the unit is turned off (on standby).

To activate the ECO mode, press ECO while the unit is turned off (on standby). The display illumination (including the display demonstration) disappears.



To deactivate the ECO mode, press ECO again. The display illumination appears.

- Turning on the unit also deactivates the ECO mode.

**notes** About the ECO mode

While the ECO mode is activated, the display demonstration is canceled temporarily.

## Setting the Clock

Before operating the unit any further, first set the clock built in this unit. You can set the clock whether the unit is on or off.

**On the unit ONLY:**

**1** Press CLOCK/TIMER.




0:00

The hour digits start flashing on the display.

**2** Turn the control to adjust the hour, then press SET.

7:00




The minute digits start flashing on the display.

- If you want to correct the hour after pressing SET, press CANCEL/DEMO. The hour digits start flashing again.

**3** Turn the control to adjust the minute, then press SET.

CLOCK OK



To check the clock time

Press DISPLAY while playing any source.

- Each time you press the button, the source indication and the clock time alternate on the display.



To adjust the clock again

If you have adjusted the clock before, you need to press CLOCK/TIMER repeatedly until “CLOCK” is selected.

- Each time you press the button, the clock/timer setting modes change as follows:



**notes** If there is a power failure

The clock loses the setting and is reset to “-- : --.” You need to set the clock again.


## Selecting the Sources

To listen to the radio, press FM/AM. (See page 12.)

To play back CDs, press CD . (See pages 15 – 21.)

To play back tapes, press TAPE . (See page 22.)

To select the external equipment as the source, press AUX.



When you press the play button for a particular source (AUX, FM/AM, CD , and TAPE , the unit turns on (and the unit starts playing the source if it is ready—COMPU PLAY CONTROL).




## Adjusting the Volume

You can adjust the volume level only while the unit is turned on.  
This function only affects the playback sound, not your recording.

Turn the **VOLUME** control clockwise to increase the volume or counterclockwise to decrease it.

- The volume level can be adjusted in 32 steps (VOL MIN, VOL 1 — VOL 30, and VOL MAX).



When using the remote control, press **VOLUME +** to increase the volume or press **VOLUME -** to decrease it.



### For private listening

Connect a pair of headphones to the PHONES jack. No sound comes out of the speakers. Be sure to turn down the volume before connecting or putting on headphones.



**DO NOT** turn off (on standby) the unit with the volume set to an extremely high level; otherwise, a sudden blast of sound can damage your hearing, speakers and/or headphones when you turn on the unit or start playing any source next time. **REMEMBER** you cannot adjust the volume level while the unit is on standby.

### To turn down the volume level temporarily

Press **FADE MUTING** on the remote control. The volume level gradually decreases to "VOL MIN."

To restore the sound, press the button again.



## Reinforcing the Bass Sound

This function only affects the playback sound, not your recording.


Press **SUBWOOFER LEVEL +** to increase the subwoofer sound or **SUBWOOFER LEVEL -** to decrease it.



- The subwoofer level can be adjusted in 3 steps (LEVEL 1 — LEVEL 3).

If you press **SUBWOOFER LEVEL +** to increase the level up to LEVEL 3, "MAX LEVEL" appears on the display.

WOOFER indicator also shows the current subwoofer level.



## Enjoying the Heavy Sound

You can enjoy the heavy sound by using the sound turbo. The function boosts the low and high frequency sound. This function only affects the playback sound, not your recording.


Press **SOUND TURBO**.



The **TURBO** indicator lights up on the display.

- Each time you press **SOUND TURBO**, the sound turbo turns on and off alternately.

TURBO indicator




### When you turn off the sound turbo

The subwoofer level is set to LEVEL 1.



### When the sound turbo is on

Turning the **SOUND MODE** control (or pressing **SOUND MODE** on the remote control) cancels the sound turbo.




## Selecting the Sound Modes

This function only affects the playback sound, not your recording.


You can select one of the 6 preset sound modes (3 surround modes and 3 SEA—Sound Effect Amplifier—modes).

To select the sound modes, turn the SOUND MODE control until the sound mode you want appears on the display.



SOUND MODE indicator also lights up on the display

- As you turn the control, the sound modes change as follows:




### Surround modes\*:


- D.CLUB** : Increases resonance and bass.
- HALL** : Adds depth and brilliance to the sound.
- STADIUM**: Adds clarity and spreads the sound, like in an outdoor stadium.

### SEA (Sound Effect Amplifier) modes:

- ROCK** : Boosts low and high frequency. Good for acoustic music.
- POP** : Good for vocal music.
- CLASSIC** : Good for classical music.
- OFF** : Cancels the sound mode.

\* Surround elements are added to the SEA elements to create being-there feeling in your room.

When one of these modes is selected, the SOUND MODE indicator lights up as .

While one of the SEA modes (SEA elements without surround elements) is selected, the SOUND MODE indicator lights up as .

- The corresponding sound mode lamp also flashes.




### When the sound mode is set to OFF

All sound mode indicators do not flash but light up.

When using the remote control, press SOUND MODE to select the sound mode.

- Each time you press the button, the sound modes change as follows:



### When the sound mode is activated

Pressing SOUND TURBO cancels the sound mode (set to OFF).

## Turning On or Off the Key-touch Tone

If you do not want the key-touch tone to beep each time you press a button or turn a control, you can deactivate it.

- You can turn on or off the key-touch tone as follows:

–When the unit is off:

You can turn on or off the key-touch tone by operating the unit.

–When the unit is on:

You can turn on or off the key-touch tone by operating the unit or the remote control.

### On the unit:

Press and hold BEEP for more than 2 seconds.



BEEP OFF

- Each time you press and hold the button, the key-touch tone turns on and off alternately.

### On the remote control:

Press BEEP ON/OFF when the unit is on.

- Each time you press the button, the key-touch tone turns on and off alternately.

BEEP ON/OFF



# Listening to the Radio



## Tuning in to a Station—Auto Search

### 1 Press FM/AM.

The unit automatically turns on and tunes in to the previously tuned station (either FM or AM—MW).


- Each time you press the button, the band alternates between FM and AM (MW).



### 2 Start searching for stations.

**On the unit:**

Press and hold **TUNING +** or **TUNING -** for more than 1 second.



**On the remote control:**

Press and hold **⏪/⏪** or **⏩/⏩** for more than 1 second.



The unit starts searching for stations and stops when a station of sufficient signal strength is tuned in to. If a program is broadcast in stereo, the ST (stereo) indicator lights up.

To stop during searching, press **TUNING +** or **TUNING -** (or **⏪/⏪** or **⏩/⏩** on the remote control).



When you press **TUNING +** or **TUNING -** (or **⏪/⏪** or **⏩/⏩** on the remote control) briefly and repeatedly

The frequency changes step by step.

### To change the FM reception mode

When an FM stereo broadcast is hard to receive or noisy, press **FM MODE** on the remote control so that “MONO” appears and the MONO indicator also lights up on the display. Reception improves.

FM MODE



To restore the stereo effect, press **FM MODE** again so that “STEREO” appears on the display.

In this stereo mode, you can hear stereo sounds when a program is broadcast in stereo.

## Presetting Stations

You can preset 30 FM and 15 AM (MW) stations.

In some cases, test frequencies have been already memorized for the tuner since the factory examined the tuner preset function before shipment. This is not a malfunction. You can preset the stations you want into memory by following the presetting method.

- There is a time limit in doing the following steps. If the setting is canceled before you finish, start from step 2 again.

## On the unit ONLY:

### 1 Tune in to the station you want to preset (in this example, of FM 87.50).

- See “Tuning in to a Station—Auto Search.”


FM 87.50

### 2 Press SET.




SET

### 3 Turn the PRESET +/- control to select a preset number.



P-01

### 4 Press SET again.



STORED

The tuned station in step 1 is stored in the preset number selected in step 3.

- Storing a new station on a used number erases the previously stored one.




When you unplug the AC power cord or if a power failure occurs

The preset stations will be erased in a few days. If this happens, preset the stations again.

## Tuning in to a Preset Station

### 1 Press FM/AM.


- See “Tuning in to a Station—Auto Search,” step 1 for details.



### 2 Select a preset number.

**On the unit:**

Turn the **PRESET +/-** control.



**On the remote control:**

Press the number buttons.

Ex.: For preset number 5, press 5.

For preset number 15,

press +10 then 5.

For preset number 20,

press +10, then 10.

For preset number 25, press +10, +10, then 5.

For preset number 30, press +10, +10, then 10.





# Receiving FM Stations with RDS

RDS (Radio Data System) allows FM stations to send an additional signal along with their regular program signals. For example, the stations send their station names, as well as information about what type of program they broadcast, such as sports or music, etc.

When tuned to an FM station which provides the RDS service, the RDS indicator lights up on the display.

With the unit, you can receive the following types of RDS signals.

## PS (Program Service):

Shows commonly known station names.

## RT (Radio Text):

Shows text messages the station sends.

## CT (Clock Time):

Shows clock time the station sends.

## PTY (Program Type):

Shows types of broadcast programs.

## Enhanced Other Networks:

Provides the information about the types of the programs sent by other RDS stations.



### More about RDS

- Some FM stations do not provide RDS signals.
- RDS services may vary among FM RDS stations. For details on RDS services in your area, check with local radio stations.
- RDS may not work correctly if the received station is not transmitting the signals properly or if the signal strength is weak.


## Changing the RDS Information

You can see RDS information on the display while listening to an FM station.

### Press DISPLAY MODE.

- Each time you press the button, the display changes as follows:

DISPLAY MODE



### About characters shown on the display

When the display shows PS name, RT or CT signals:

- The display cannot differentiate upper case and lower case letters and always uses upper case letters.
- Some special characters and marks may not be displayed correctly.



If no PS name, RT, or CT signals are sent by a station “NO PS,” “NO RT,” or “NO CT” appears on the display.

## Searching for Programs by PTY Codes (PTY Search)


One of the advantages of RDS is that you can locate a particular kind of program by specifying PTY codes.

- For details on the PTY codes, see “Additional Information” on page 30.

### To search for a program using PTY codes

- PTY Search is applicable only to preset FM RDS stations. If not yet done, see “Presetting Stations” on page 12.
- There is a time limit in doing the following steps. If the setting is canceled before you finish, start from step 1 again.

### 1 Press RDS MODE while listening to an FM station.



### 2 Press SELECT + or SELECT - until the PTY code you want appears on the display.




NEWS

- Each time you press the button, PTY codes change as follows:

NEWS ⇄ AFFAIRS ⇄ INFO ⇄ SPORT ⇄  
EDUCATE ⇄ DRAMA ⇄ CULTURE ⇄  
SCIENCE ⇄ VARIED ⇄ POP M ⇄ ROCK M ⇄  
M.O.R. M ⇄ LIGHT M ⇄ CLASSICS ⇄  
OTHER M ⇄ WEATHER ⇄ FINANCE ⇄  
CHILDREN ⇄ SOCIAL ⇄ RELIGION ⇄  
PHONE IN ⇄ TRAVEL ⇄ LEISURE ⇄ JAZZ ⇄  
COUNTRY ⇄ NATION M ⇄ OLDDIES ⇄  
FOLK M ⇄ DOCUMENT ⇄ (back to the beginning)

### 3 Press RDS MODE again while the PTY code selected in the previous step is still on the display.



The preset FM stations appear on the display with their preset numbers.

The unit searches 30 preset FM stations, stops when it finds the one you have selected and tunes in that station.

- If no program is found, the unit returns to the last received station.


### To stop during searching

Press SELECT + or SELECT -.

To check the PTY, press RDS MODE once so that the current PTY code appears.

- “NO PTY” appears if no signal is sent.





## Switching Temporarily to a Program Type of Your Choice

The Enhanced Other Networks function allows the unit to switch temporarily to a broadcast program of your choice (NEWS or INFO) from a different station.

### To activate the Enhanced Other Networks function

Enhanced Other Networks function is applicable only to preset FM RDS stations. If not yet done, see “Presetting Stations” on page 12.

- There is a time limit in doing the following steps. If the setting is canceled before you finish, start from step 1 again.


### 1 Press and hold RDS MODE for more than 1 second.

“E.SELECT” appears on the display.



### 2 Press SELECT + or SELECT - to select the data type.

- Each time you press the button, the data type of the Enhanced Other Networks changes as follows:



**NEWS:** News

**INFO:** Program the purpose of which is to impart advice in the widest sense.

**E.OFF:** The function is canceled.

The data type indicator (NEWS or INFO) you have selected also lights up on the display.

Now, the function is activated. See “How the Enhanced Other Networks function actually works.”

**To cancel the function,** repeat from step 1 and select “E.OFF” in step 2.

The data type indicator (NEWS or INFO) goes off.

## How the Enhanced Other Networks function actually works:

### CASE 1

#### If there is no station broadcasting the program you have selected

The unit continues tuning in to the current station.



When a station starts broadcasting the program you have selected, the unit automatically switches to the station. The selected data type indicator starts flashing on the display.



When the program is over, the unit goes back to the previously tuned station, but the Enhanced Other Networks function still remains activated.

### CASE 2

#### If there is a station broadcasting the program you have selected

The unit tunes in to the program. The selected data type indicator starts flashing.



When the program is over, the unit goes back to the previously tuned station, but the Enhanced Other Networks function still remains activated.

### CASE 3

#### If the FM station you are listening to is broadcasting the program you have selected

The unit continues to receive the station but the selected data type indicator starts flashing.



When the program is over, the indicator stops flashing, but the Enhanced Other Networks function still remains activated.



### More about the Enhanced Other Networks function

- Enhanced Other Networks data sent from some stations may not be compatible with this unit. In this case, the Enhanced Other Networks function may not work correctly.
- While listening to a program tuned in by this function, the station does not change even if another network station starts broadcasting a program of the same Enhanced Other Networks data.
- If the stations alternate intermittently between the station tuned by this function and the currently tuned station, cancel this function by following the procedure in the left column.
- The Enhanced Other Networks function is canceled when you change the source to CD, TAPE or AUX.
- The Enhanced Other Networks function is temporarily canceled when you change the band to AM (MW).

# Playing Back CDs

This unit has been designed to playback the following CDs:

- Audio CD
- CD-R (CD-Recordable)
- CD-RW (CD-ReWritable)
- MP3 disc (MP3 files recorded on a CD-R or CD-RW)\*

## When playing a CD-R or CD-RW

- User-edited CD-Rs (CD-Recordable) and CD-RWs (CD-ReWritable) can be played back when they are already “finalized.”
- Before playing back CD-Rs or CD-RWs, read their instructions or cautions carefully.
- Some CD-Rs or CD-RWs may not be played back on this unit because of their disc characteristics, damage or stain on them, or if the player’s lens is dirty.

## Important notices:

- In general, you will have the best performance by keeping your CDs and the mechanism clean.
  - Store CDs in their cases, and keep them in cabinets or on shelves.
  - Keep the unit’s carrousel closed when not in use.
- Continuous use of irregular shaped discs (heart-shape, octagonal, etc.) can damage the disc rotating mechanism.



- CD-RWs may require a longer readout time since the reflectance of CD-RWs is lower than for regular CDs.

## \*For MP3 discs

- This unit manages files and folders on MP3 discs as “tracks” and “albums.”
- Playback order of the MP3 files (tracks) recorded on a disc are determined by the writing (or encoding) application; therefore, playback order may be different from the one you have intended while recording the files and the folders.
- This unit show the file name—Available characters: 0–9, A–Z, \_ (underscore)—on the display when the file (tracks) starts play; however some file names are not shown correctly.



## More about MP3 discs

- MP3 discs (either CD-R or CD-RW) require a longer readout time. (It varies due to the complexity of the recording configuration.)
- When making an MP3 disc, select ISO 9660 Level 1 or Level 2 as the disc format.
- This unit does not support multisession recording.
- This unit can play MP3 files only with the following file extensions—“.MP3,” “.Mp3,” “.mp3,” and “.mp3.”
- Non-MP3 files are ignored. If non-MP3 files are recorded together with MP3 files, this unit will take a longer time to scan the disc. It may also cause the unit to malfunction.
- Some MP3 discs may not be played back because of their disc characteristics or recording conditions.


## Loading CDs

### 1 Press ▲.

The unit automatically turns on and the carrousel comes out.



### 2 Place one or two discs correctly on the front recesses of the disc tray, with its label side up.



- When using a CD single (8 cm), place it on the inner recess of the disc tray.

### 3 If you wish to load a third disc, press DISC CHANGE on the unit or DISC SKIP on the remote control.

The disc tray rotates by 120°.

DISC CHANGE



DISC SKIP



### 4 Press ▲ again.

The carrousel closes.



## Playing Back CDs—All Disc and One Disc

You can play all loaded CDs continuously—All Disc play, or one selected disc—One Disc play.


### All Disc play

#### On the unit ONLY:


### 1 Load CDs.

- If the current playing source is not the CD player, press CD ►/II, then ■ before going to the next step.


### 2 Press REPEAT repeatedly so that the ALL DISC indicator lights up on the display.



#### For Audio CD:



#### For MP3 disc:




GROUP indicator appears when the MP3 playback mode is the ALBUM mode. See also page 19.

- Each time you press the button, the indication on the display changes as follows:



\* See page 21.

### 3 Press one of the disc number buttons (CD1, CD2 or CD3) for the disc you want to start to play from.




CD play starts from the first track of the selected disc.


- Pressing CD ►/|| instead of the disc number buttons starts playing back if a CD is on the tray.

#### For Audio CD:

Track number of the currently playing disc flashes (Track numbers exceeding 16 are not displayed.)



- When the MP3 playback mode is the TRACK mode (See also page 19.)



\*\* In the TRACK mode, the unit manage only files (tracks) on the MP3 disc. Folders (albums) are not recognized.


To stop during play, press ■.

- For MP3 disc, this unit can store the number of the track that you have stopped playback. By pressing CD ►/||, you can start playback again from the beginning of the same track—Resume play (see also page 19).

To remove the disc, press ▲.

#### For MP3 disc:

- When the MP3 playback mode is the ALBUM mode (See also page 19.)



#### CD playback sequence

When 3 CDs are loaded on the disc trays, they are played in one of the following sequences.

- When CD1 is pressed : CD1 ⇒ CD2 ⇒ CD3 (then stops)
- When CD2 is pressed : CD2 ⇒ CD3 ⇒ CD1 (then stops)
- When CD3 is pressed : CD3 ⇒ CD1 ⇒ CD2 (then stops)

\* When only 2 CDs are loaded, they are played in the same order, but the disc tray without a CD is skipped.



#### About the disc number lamps (CD1, CD2, and CD3)

- Each disc number lamp corresponds to the disc tray of the same number.
- The disc number lamp flashes while the corresponding CD is being played.
- The disc number lamp goes off when the unit has detected that there is no CD on the corresponding disc tray.



## One Disc play


When 2 or 3 CDs are loaded on the disc trays, you can select one particular disc to be played back.

### On the unit ONLY:


#### 1 Load CDs.

- If the current playing source is not the CD player, press CD ►/||, then ■ before going to the next step.

#### 2 Press REPEAT repeatedly so that the 1 DISC indicator lights up on the display.




- Each time you press the button, the indication on the display changes as follows:



\* See page 21.

#### 3 Press one of the disc number buttons (CD1, CD2 or CD3) you want to listen.



Playback stops when all tracks of the selected disc are played once and resumes to All Disc play.

#### To stop during play, press ■.

- For MP3 disc, this unit can store the number of the track that you have stopped playback. By pressing CD ►/||, you can start playback again from the beginning of the same track—Resume play (see also page 19).

#### To remove the disc, press ▲.

To exit from One Disc play, press REPEAT repeatedly so that ALL DISC indicator lights up on the display.



The following operations will also cancel the One Disc play and restore All Disc play when—

- Turning off the power,
- Ejecting the carousel, or
- Changing the source to play.

## Basic CD Operations

While playing a CD, you can do the following operations.

#### To exchange CDs during playback of another

Press DISC CHANGE to change the CD and the carousel comes out.

DISC CHANGE

If you change CDs during play, the current play will not stop until all CDs you have changed are played.



To close the carousel, press DISC CHANGE or ▲.

#### To skip to the another CD in the carousel

Press DISC SKIP on the remote control.

DISC SKIP



#### To stop play for a moment

Press CD ►/||.

While pausing, "PAUSE" appears on the display.



To resume play, press CD ►/|| again.

#### To locate a particular point in a track

During play, press and hold ◀◀ or ▶▶.

- ◀◀: Fast reverses the disc.
- ▶▶: Fast forwards the disc.



When using the remote control, press and hold ◀◀/▶▶ or ▶▶/◀◀.




#### To go to another track

##### For Audio CD:

Turn the ◀◀/▶▶ control before or during playback.

- ◀◀: Goes back to the beginning of the current or previous tracks.
- ▶▶: Skips to the beginning of the next or succeeding tracks.



When using the remote control, press ◀◀/▶▶ or ▶▶/◀◀.




If you turn the ◀◀/▶▶ control (or press ◀◀/▶▶ or ▶▶/◀◀ on the remote control) to select a track while playback is stopped



The selected track starts playback.









**For MP3 disc:****When the MP3 playback mode is the TRACK mode**

(See also page 19.)

Turn the  control before or during playback.

- : Goes back to the beginning of the current or previous tracks.
- : Skips to the beginning of the next or succeeding tracks.


When using the remote control, press  or .



 **If you turn the  control (or press  or  on the remote control) to select a track while playback is stopped**



The selected track starts playback.





**To go to another album on an MP3 disc****When the MP3 playback mode is the ALBUM mode**

(See also page 19.)

Turn the  control before or during playback.

- : Goes back to the beginning of the first track in the previous albums.
- : Skips to the beginning of the first track in the next or succeeding albums.


When using the remote control, press  or .

 **If you turn the  control (or press  or  on the remote control) to select an album while playback is stopped**

The first track in the selected album starts playback.

**To go to another track directly using the number buttons****For Audio CD:**

Pressing the number button(s) before or during play allows you to start playing the selected track.



Ex.: For track number 5, press 5.

For track number 15, press +10, then 5.


For track number 20, press +10, then 10.

For track number 32, press +10, +10, +10, then 2.

**For MP3 disc:****• When the MP3 playback mode is the TRACK mode**

(See also page 19.)

Pressing the number button(s) before or during play allows you to start playing the selected track on the disc.



Ex.: For track number 5, press 5.

For track number 15, press +10, then 5.

For track number 20, press +10, then 10.


For track number 32, press +10, +10, +10, then 2.

For track number 123, press +10 twelve times, then 3.

**• When the MP3 playback mode is the ALBUM mode**

(See also page 19.)

Pressing the number button(s) before or during play allows you to start playing the selected track in the current album.



Ex.: For track number 5, press 5.

For track number 15, press +10, then 5.

For track number 20, press +10, then 10.

For track number 32, press +10, +10, +10, then 2.

For track number 123, press +10 twelve times, then 3.

**If your entry is ignored**

You have tried to enter a track number that does not exist on the disc or in the album (for example, selecting track 14 in the album that only has 12 tracks). Such entries are ignored.

## Changing the MP3 Playback Mode

When playing an MP3 disc, you can choose the playback mode of the MP3 disc as follows:

- **TRACK mode:**  
The unit recognizes only tracks (files). You can play an MP3 disc like an Audio CD.
- **ALBUM mode:**  
The unit recognizes tracks (files) and albums (folders) on an MP3 disc. You can play an MP3 disc according to the way how they are grouped.  
In this mode, you can do the following operations:
  - Turning the **◀◀/▶▶** control (or pressing **◀◀/▶▶** or **▶▶/▶▶** on the remote control) allows you to skip to the first track of the previous or next albums. (See page 18.)
  - Pressing the number button(s) allows you to start playing the selected track in the current album. (See page 18.)

### On the remote control ONLY:

Press **MP3** before or during playing an MP3 disc.



GROUP indicator appears when the MP3 playback mode is the ALBUM mode.

- Each time you press the button, the MP3 playback mode changes between “ALBUM” and “TRACK” alternately.

## Turning On or Off the Resume Play for MP3 Disc

For MP3 disc, this unit can store the number of the track that you have stopped playback. By pressing **CD ▶/||**, you can start playback again from the beginning of the same track—Resume play.

You can turn on and off the resume play for MP3 discs.

### On the unit ONLY:

Press **PROGRAM** before or during playing an MP3 disc.



- Each time you press **PROGRAM**, the resume play turns on and off alternately.



The following operations will erase the memory of the track number that you have stopped playback when—

- Pressing **▲** to eject the disc.
- Pressing one of the disc number buttons to change the disc to play.

## Programming the Playing Order of the Tracks —Program Play

You can arrange the order in which the tracks play before you start playing. **You can program up to 32 tracks.**

- To use Repeat play (see page 21) for Program play, press REPEAT after starting Program play.
- This function does not work for MP3 discs.

### On the unit ONLY:

#### 1 Load CDs.

- If the current playing source is not the CD player, press CD ►/||, then ■ before going to the next step.

#### 2 Press PROGRAM so that “PROGRAM” appears on the display.



The PRGM (program) indicator also lights up on the display.

- All Disc play is selected automatically. You cannot select One Disc play for Program play.



- If a program has been stored in memory, the program is called up.


#### 3 Press one of the disc number buttons (CD1, CD2, and CD3) to select the disc number you want to play.



#### 4 Turn the ◀◀/▶▶ control to select the track number, then press SET.

Each time you select a track and press SET, the selected track number is added to the track number indicator.

- You can select up to the 99th track on each disc.



#### 5 Program other tracks you want.

- To program tracks from the same disc, repeat step 4.
- To program tracks from a different disc, repeat steps 3 and 4.

#### 6 Press CD ►/||.

The tracks are played in the order you have programmed.




To stop during play, press ■.

To exit from Program play, press PROGRAM again before or after play so that the unit enters All Disc play. (The program you have made is stored in memory until you turn off the unit, eject the carousel, or erase the program.)

- Program play is also canceled when you press ▲.

#### To modify the program

Before playing, you can erase the last programmed track shown on the display by pressing CANCEL/DEMO.



- Each time you press the button, the last programmed track is erased from the program.

To check the program during play, perform the following procedure:

- You can check only the programmed tracks on the current disc at one time.

1 Press CD ►/|| to pause Program play.

2 Turn the ◀◀/▶▶ control.

The programmed tracks on the currently selected disc appear on the display in the programmed (or reverse) order.

- If tracks on another disc have been programmed, “PAUSE” appears on the display.

To check the programmed tracks on another disc, press CD ►/|| twice, then turn the ◀◀/▶▶ control.

- Pressing CD ►/|| again starts Program play from the track currently shown on the display.

To add tracks in the program before play, simply select the disc numbers and/or track numbers you want to add by following steps 3 and 4 of the programming procedure.

To erase the entire program before or during play, press ■ twice.

- Turning the power off or ejecting the carousel will also erase the stored memory.



If you try to program a 33rd track “FULL” will appear on the display.



If you have programmed a track from an empty tray, or a track number that does not exist on the disc Such program steps will be skipped.



If there is an MP3 disc on the disc tray

Even if you add tracks on the MP3 disc to the program in step 3 to 5, those tracks will be skipped.





## Playing at Random—Random Play


The tracks of the selected CD will play at random.

- To use Random play, you have to cancel the Program play.

### On the unit ONLY:

**1** Load a CD.

**2** Press one of the disc number buttons (CD1, CD2, and CD3) for the disc you want to play, then press ■.



**3** Press RANDOM so that “RANDOM” appears on the display.

The RANDOM indicator also lights up on the display.

- Activating Random play cancels Repeat play or All Disc play. (One Disc play is automatically selected.)
- For MP3 discs, activating Random play changes the ALBUM mode to the TRACK mode.



- The tracks are played automatically at random. Random play ends when all tracks are played once.

**To stop and cancel Random play, press ■.**

- If you press RANDOM again during play, Random play is canceled and the unit enters All Disc play mode.
- Random play is also canceled when you press ▲.



If you turn the ◀▶ control (or press ◀▶/◀◀ or ▶▶/▶▶ on the remote control)

Playback skips to the next track selected randomly.

## Repeating Tracks or CDs—Repeat Play

You can have all the CDs, the program or the individual track currently playing repeat as many times as you like.

- Repeat play and Random play cannot be used at the same time.

### On the unit ONLY:

**To repeat play, press REPEAT during or before playing.**



- Each time you press the button, Repeat play mode changes as follows, and the following indicator lights up on the display:



- REPEAT 1:** Repeats one track on one CD.
- REPEAT 1 DISC\*\*:** Repeats all the tracks on one CD.
- REPEAT ALL DISC:** Repeats all the tracks on all the CDs, or all the tracks on the program.

\* See pages 15 and 17.

\*\* REPEAT 1 DISC is not used for Program play.

**To cancel Repeat play, press REPEAT repeatedly until the REPEAT indicator (REPEAT 1, REPEAT 1 DISC or REPEAT ALL DISC) goes off from the display.**

- Repeat play is also canceled when you press ■ or ▲.

## Prohibiting Disc Ejection—Carrousel Lock

You can prohibit CD ejection from the unit and can lock the carrousel.

- This operation is possible only while the unit is on with CD selected as the source.

### On the unit ONLY:

**To prohibit disc ejection, press ▲ for the carrousel while holding ■.**

“LOCKED” appears for a while, and the carrousel is locked.



If you try to eject CDs

“LOCKED” appears to inform you that the Carrousel Lock is in use.

**To cancel the prohibition and unlock the carrousel, press ▲ for the carrousel while holding ■.**

“UN LOCKED” appears for a while, and the carrousel is unlocked.



When you unplug the AC power cord or if a power failure occurs

The setting of the Carrousel Lock will return to the initial setting (not to prohibit disc ejection) in a few days.




# Playing Back Tapes




## Playing Back a Tape

**1** Press **EJECT** for the deck you want to use.



**2** Put a cassette in, with the exposed part of the tape down and the side you want to play facing front.

- You can play back only type I tapes.



**3** Close the cassette holder gently.

If you put cassettes in both decks A and B, the last deck which you have put a cassette into is selected.

To operate the other deck, press TAPE A/B (or A/B on the remote control).

**4** Press **TAPE**.

The tape play starts and the tape running indicator starts flashing slowly.



When the tape plays to the end, the deck automatically stops.



To stop during play, press **■**.

To operate the other deck, press TAPE A/B (or A/B on the remote control), then TAPE **▶**.

To fast-forward the tape, press **▶▶** (or **▶▶/▶▶** on the remote control). The tape running indicator (**▶**) starts flashing quickly.

To rewind the tape, press **◀◀** (or **◀◀/◀◀** on the remote control). The tape running indicator (**◀**) starts flashing quickly.

To remove the cassette, press **EJECT** for deck A or **EJECT** for deck B.



The use of the C-120 or thinner tape is not recommended, since characteristic deterioration may occur and this tape easily jams in the pinch-rollers and the capstans.

# Recording

## IMPORTANT:


- It should be noted that it may be unlawful to re-record pre-recorded tapes, records, or discs without the consent of the owner of copyright in the sound or video recording, broadcast or cable program and in any literary, dramatic, musical, or artistic embodied therein.
- The recording level is automatically set correctly, so it is not affected by the VOLUME, the SUBWOOFER LEVEL, and the SOUND MODE controls. Thus, during recording you can adjust the sound you are actually listening to without affecting the recording level.
- While recording, you can hear the SOUND TURBO effect through the speakers or headphones. However, the sound is recorded without this effect (see page 10).
- If recordings you have made have excessive noise or static, the unit may be too close to a TV. Place the unit away from the TV.
- You can use type I tape for recording.

## To protect your recording

Cassettes have two small tabs on the back to protect unexpected erasure or re-recording.

To protect your recording, remove these tabs.

To re-record on a protected tape, cover the holes with adhesive tape.




## To keep the best recording and playback sound quality

If the heads, capstans, and pinch rollers of the cassette decks become dirty, the following will occur:

- Impaired sound quality
- Discontinuous sound
- Fading
- Incomplete erasure
- Difficulty in recording

## To clean the head, capstan, and pinch roller

Use a cotton swab moistened with alcohol.




## To demagnetize the head

Turn off the unit, and use a head demagnetizer (available at electronics and audio shops).

## Recording a Tape on Deck B

### On the unit ONLY:

**1** Press EJECT ▲ for deck B.



**2** Put a recordable cassette in, with the exposed part of the tape down and the side you want to record facing front.

**3** Close the cassette holder gently.

**4** Start playing the source—FM, AM, CD player or auxiliary equipment connected to AUX IN jacks.

- For duplicating tapes, see “Dubbing Tapes” on page 24.
- For recording from CD, see “CD Synchronized Recording” on page 24.


**5** Press REC START/STOP.

The REC (recording) indicator lights up on the display and recording starts.



To stop during recording, press REC START/STOP again or ■.


To remove the cassette, press EJECT ▲ for deck B.



## Dubbing Tapes

### On the unit ONLY:

**1** Press TAPE ►, then ■.



**2** Put the source cassette in deck A, and a recordable cassette into deck B.

**3** Press DUBBING.

Dubbing starts.  
“DUBBING” appears, and the REC (recording) indicator lights up on the display.



To stop during dubbing, press REC START/STOP or ■.

To remove the cassettes, press ▲ EJECT for deck A and EJECT ▲ for deck B.

## CD Synchronized Recording

You can easily record a CD onto a tape.


- This function does not work for MP3 discs. When recording an MP3 disc onto a tape, see “Recording a Tape on Deck B” on page 23.
- You can also record the tracks in the order you have made the program.  
If there is a track on the MP3 disc in the program, it will be skipped and some blank space will be recorded on the tape.

### On the unit ONLY:

**1** Put a recordable cassette into deck B.

**2** Place a disc correctly on the recess of the disc tray, with its label side up.

**3** Press one of the disc number buttons (CD1, CD2, and CD3) to select the disc, then ■.



**4** Press CD REC START.

“CD REC” appears, and the REC (recording) indicator lights up on the display.



Deck B starts recording and the CD player starts playing. When the recording from the selected CD is done, the CD player and deck B stop.

- When recording your program, the CD player and deck B stop after all tracks in the program are recorded.

To stop during CD Synchronized Recording, press REC START/STOP or ■.

To remove the cassette, press EJECT ▲ for deck B.



# Using the Timers


There are three timers available—Daily Timer, Recording Timer, and Sleep Timer.

Before using the timers, you need to set the clock built in the unit. (See “Setting the Clock” on page 9.)

## Using Daily Timer

With Daily Timer, you can wake to your favorite music or radio program. You can set the timer whether the unit is on or off.

### How Daily Timer actually works

The unit automatically turns on, set the volume level to the preset level, and starts playing the specified source when the on-time comes (the  indicator flashes while the timer is operating). Then, when the off-time comes, the unit automatically turns off (stands by).

Daily Timer works every day unless you cancel it.

- There is a time limit in doing the following steps. If the setting is canceled before you finish, start from step 1 again.
- If you have made a mistake while setting timer, press CANCEL/DEMO. (However, this does not always work. If CANCEL/DEMO does not work, press CLOCK/TIMER repeatedly and start from step 1 again.)


#### Before you start...

- *When using a CD as the source to play:*  
—Make sure there is a CD on the currently selected disc number tray.
- *When using a tape as the source to play:*  
—Make sure that a tape is in the deck whose deck indicator (A or B) is lit on the display.
- *When using the external component as the source to play:*  
—Set the timer equipped with the external component at the same time.

### On the unit ONLY:


- 1 Press **CLOCK/TIMER** repeatedly until “DAILY” appears on the display.



 indicator lights up and the DAILY (daily timer) indicator starts flashing on the display.



- Each time you press the button, the clock/timer setting modes change as follows:



- 2 Press **CLOCK/TIMER** again.

“ON TIME” appears for 2 seconds, then the unit enters on-time setting mode.



- 3 Set the on-time you want the unit to turn on.


1) Turn the  control to set the hour, then press SET.


2) Turn the  control to set the minute, then press SET.

“OFF TIME” appears for 2 seconds, then the unit enters off-time setting mode.



- 4 Set the off-time you want the unit to turn off (on standby).

1) Turn the  control to set the hour, then press SET.


2) Turn the  control to set the minute, then press SET.

The unit enters source selecting mode.





## 5 Turn the control to select the source to play, then press SET.

- Each time you turn the  control, the source changes as follows:



TUNER FM : tunes in to a specified preset FM station.

→ go to step 6.

TUNER AM : tunes in to a specified preset AM station.

→ go to step 6.

CD : plays the current disc from the first track.

→ go to step 7.

TAPE : plays a tape in deck A or B.

→ go to step 7.

AUX : plays an external source.

→ go to step 7.




## To turn on or off Daily Timer after its setting is done

- 1 Press CLOCK/TIMER repeatedly until “DAILY” appears on the display.



- 2 To turn off the Daily Timer, press CANCEL/DEMO.



The DAILY (daily timer) indicator goes off from the display (“OFF” appears for a while).


The Daily Timer is canceled, but the setting for the Daily Timer remains in memory until you change it.

### To turn on the Daily Timer, press SET.

The DAILY (daily timer) indicator lights up on the display. The settings you have done are shown on the display in sequence for your confirmation.



## 6 Select the preset station number.

Turn the  control to select the preset station number, then press SET. The unit enters volume setting mode.




## 7 Turn the control to set the volume level.

- You can select the volume level from VOL MIN, VOL 1 — VOL 30, and VOL MAX.




## 8 Press SET to complete the Daily Timer setting.

The DAILY (daily timer) indicator stops flashing and remains lit. The settings you have done are shown on the display in sequence for your confirmation.



## 9 Press to turn off the unit (on standby) if you have set the Daily Timer with the unit turned on.




If the unit is turned on when the timer-on time comes Daily Timer does not work.

## Using Recording Timer

With Recording Timer, you can make a tape of a radio broadcast automatically. You can set the timer whether the unit is on or off.

### How Recording Timer actually works

The unit automatically turns on, tunes in to the specified station, sets the volume level to “VOL MIN,” and starts recording when the on-time comes (the  indicator flashes while the timer is operating). Then, when the off-time comes, the unit automatically turns off (stands by).

Recording Timer works only once, but the timer setting remains in memory until you change it.


- There is a time limit in doing the following steps. If the setting is canceled before you finish, start from step 2 again.
- If you have made a mistake while setting the timer, press CANCEL/DEMO. (However, this does not always work. If CANCEL/DEMO does not work, press CLOCK/TIMER repeatedly and start from step 2 again.)


### On the unit ONLY:

**1** Put a recordable cassette into deck B.


**2** Press **CLOCK/TIMER** repeatedly until “REC” appears on the display.



-  indicator lights up and the REC (recording timer) indicator starts flashing on the display.



- Each time you press the button, the clock/timer setting modes change as follows:





**3** Press **CLOCK/TIMER** again.

“ON TIME” appears for 2 seconds, then the unit enters on-time setting mode.





**4** Set the on-time you want the unit to turn on.

- 1) Turn the  control to set the hour, then press SET.
  - 2) Turn the  control to set the minute, then press SET.
- “OFF TIME” appears for 2 seconds, then the unit enters off-time setting mode.





**5** Set the off-time you want the unit to turn off (on standby).


- 1) Turn the  control to set the hour, then press SET.
  - 2) Turn the  control to set the minute, then press SET.
- The unit enters preset station selecting mode.



**6** Select the preset station.

- 1) Turn the  control to select the band (“TUNER FM” or “TUNER AM”), then press SET.
- 2) Turn the  control to select a preset channel number, then press SET. The REC (recording timer) indicator stops flashing and remains lit. The settings you have done are shown on the display in sequence for your confirmation.



**7** Press  to turn off the unit (on standby) if necessary.



### About the recording source

If you change the source while recording, the recording source also changes.



## To turn on or off Recording Timer after its setting is done

1 Press **CLOCK/TIMER** repeatedly until “REC” appears on the display.



2 To turn off the Recording Timer, press **CANCEL/DEMO**.



The REC (recording timer) indicator goes off from the display (“OFF” appears for a while). The Recording Timer is canceled, but the setting for the Recording Timer remains in memory until you change it.

To turn on the Recording Timer, press **SET**.



The REC (recording timer) indicator lights up on the display. The settings you have done are shown on the display in sequence for your confirmation.

## Using Sleep Timer

With Sleep Timer, you can fall asleep to music. You can set Sleep Timer when the unit is turned on.

### How Sleep Timer actually works

The unit automatically turns off after the specified time length passes.


### On the remote control ONLY:

1 Press **SLEEP**.

The time length until the shut-off time appears and the SLEEP indicator starts flashing on the display.



• Each time you press the button, the time length changes as follows:



2 Wait for about 3 seconds after specifying the time length.

The SLEEP indicator stops flashing and remains lit.

To check the remaining time until the shut-off time, press SLEEP once so that the remaining time until the shut-off time appears for about 3 seconds.

To change the shut-off time, press SLEEP repeatedly until the desired time length appears on the display.

To cancel the setting, press SLEEP repeatedly until “OFF” appears on the display so that the SLEEP indicator goes off from the display.


• Sleep Timer is also canceled when you turn off the unit.

## Timer Priority


Since each timer can be set separately, you may wonder what happens if the setting for these timers overlaps. Here are some examples.

• **Recording Timer has priority over Daily Timer.**

If Recording Timer is set to come on while Daily Timer is operating, Daily Timer is canceled and Recording Timer start working.



• If Sleep Timer overlaps with another timer (either Daily Timer or Recording Timer), a timer with the earlier shut-off time has priority.



When using the Recording Timer and Sleep Timer at the same time, pay special attention to the shut-off time.

# Maintenance



To get the best performance of the unit, keep your discs, tapes, and mechanism clean.

## Cleaning the unit

### • Stains on the unit

Should be wiped off with a soft cloth. If the unit is heavily stained, wipe it with a cloth soaked in water-diluted neutral detergent and wrung well, then wipe clean with a dry cloth.


### • Avoid the following since they may cause damage to the unit.

- DO NOT wipe it with a hard cloth.
- DO NOT wipe it strong.
- DO NOT wipe it with thinner or benzine.
- DO NOT apply any volatile substance such as insecticides to it.
- DO NOT allow any rubber or plastic to remain in contact with it for a long time.

## Handling discs



- Remove the disc from its case by holding it at the edge while pressing the center hole lightly.
- Do not touch the shiny surface of the disc, or bend the disc.
- Put the disc back in its case after use to prevent warping.




- Be careful not to scratch the surface of the disc when placing it back in its case.
- Avoid exposure to direct sunlight, temperature extremes, and moisture.



### To clean the disc

Wipe the disc with a soft cloth in a straight line from center to edge.

## Handling cassette tapes



- If the tape is loose in its cassette, take up the slack by inserting a pencil in one of the reels and rotating.
- If the tape is loose, it may get stretched, cut, or caught in the cassette.



- Be careful not to touch the tape surface.



- Avoid the following places to store the tape:

- In dusty places
- In direct sunlight or heat
- In moist areas
- Near a magnet



**DO NOT** use any solvent—such as conventional record cleaner, spray, thinner, or benzine—to clean the disc.



# Additional Information




## Description of the PTY codes:

<b>NEWS:</b>	News.	<b>WEATHER:</b>	Weather reports and forecasts.
<b>AFFAIRS:</b>	Topical program expanding or enlarging upon the news — debate, or analysis.	<b>FINANCE:</b>	Stock Market reports, commerce, trading etc.
<b>INFO:</b>	Program the purpose of which is to impart advice in the widest sense.	<b>CHILDREN:</b>	Programs targeted at a young audience.
<b>SPORT:</b>	Program concerned with any aspect of sports.	<b>SOCIAL:</b>	Programs about sociology, history, geography, psychology and society.
<b>EDUCATE:</b>	Educational programs.	<b>RELIGION:</b>	Religious programs.
<b>DRAMA:</b>	All radio plays and serials.	<b>PHONE IN:</b>	Involving members of the public expressing their views either by phone or at a public forum.
<b>CULTURE:</b>	Programs concerning any aspect of national or regional culture, including language, theatre, etc.	<b>TRAVEL:</b>	Travel information.
<b>SCIENCE:</b>	Programs about natural sciences and technology.	<b>LEISURE:</b>	Programs about recreational activities.
<b>VARIED:</b>	Used for mainly speech-based programs like quizzes, panel games and personality interviews.	<b>JAZZ:</b>	Jazz music.
<b>POP M:</b>	Commercial music of current popular appeal.	<b>COUNTRY:</b>	Songs which originate from, or continue the musical tradition of the American Southern States.
<b>ROCK M:</b>	Rock music.	<b>NATION M:</b>	Current popular music of the nation or region in that country's language.
<b>M.O.R. M:</b>	Current contemporary music considered to be "easy-listening."	<b>OLDIES:</b>	Music from the so-called "golden age" of popular music.
<b>LIGHT M:</b>	Instrumental music, and vocal or choral works.	<b>FOLK M:</b>	Music which has its roots in the musical culture of a particular nation.
<b>CLASSICS:</b>	Performances of major orchestral works, symphonies, chamber music, etc.	<b>DOCUMENT:</b>	Program concerning factual matters, presented in an investigative style.
<b>OTHER M:</b>	Music not fitting into any of the other categories.		

Classification of the PTY codes for some FM stations may be different from the above list.

# Troubleshooting




If you are having a problem with your unit, check this list for a possible solution before calling for service.

If you cannot solve the problem from the hints given here, or the unit has been physically damaged, call a qualified person, such as your dealer, for service.

Symptom	Cause	Action
Unable to cancel the display demonstration.	Other buttons are pressed to cancel the display demonstration.	Press CANCEL/DEMO on the unit. (See page 8.)
No sound is heard.	Connections are incorrect or loose.	Check all connections and make corrections. (See pages 6 to 8.)
Hard to listen to broadcasts because of noise.	<ul style="list-style-type: none"> <li>Antennas are disconnected.</li> <li>The AM (MW) loop antenna is too close to the unit.</li> <li>The FM antenna is not properly extended and positioned.</li> </ul>	<ul style="list-style-type: none"> <li>Reconnect the antennas correctly and securely.</li> <li>Change the position and direction of the AM (MW) loop antenna.</li> <li>Extend the FM antenna at the best position.</li> </ul>
The disc sound is discontinuous.	The disc is scratched or dirty.	Clean or replace the disc. (See page 29.)
The carrousel does not open or close.	<ul style="list-style-type: none"> <li>The AC power cord is not plugged in.</li> <li>The carrousel is locked.</li> </ul>	<ul style="list-style-type: none"> <li>Plug the AC power cord.</li> <li>Unlock the carrousel. (See page 21.)</li> </ul>
The disc does not play.	The disc is placed upside down.	Place the disc with the label side up.
The MP3 disc does not play.	<ul style="list-style-type: none"> <li>No MP3 files are recorded on the disc.</li> <li>MP3 files do not have the file extension—.MP3, .Mp3, .mp3, or .mp3 in their file names.</li> <li>MP3 files are not recorded in the format compliant with ISO 9660 Level 1 or Level 2.</li> </ul>	Replace the disc.
The readout time of the MP3 disc is too long.	The readout time varies with the complexity of the recording configuration.	Do not use too many hierarchies and folders when recording. Also, do not record any other types of audio tracks together with MP3 files. (See page 15.)
The cassette holders cannot be opened.	Power supply from the AC power cord has been cut off while the tape was running.	Turn on the unit.
Impossible to record.	Small tabs on the back of the cassette are removed.	Cover the holes with adhesive tape.
Operations are disabled.	The built-in microprocessor may malfunction due to external electrical interference.	Unplug the AC power cord and then plug it back in.
Unable to operate the unit from the remote control.	<ul style="list-style-type: none"> <li>The path between the remote control and the remote sensor on the unit is blocked.</li> <li>The batteries are exhausted.</li> </ul>	<ul style="list-style-type: none"> <li>Remove the obstruction.</li> <li>Replace the batteries.</li> </ul>

# Specifications

Design and specifications are subject to change without notice.



## CA-MXGT88

### Amplifier section

Output Power

SUBWOOFERS : 100 W per channel, min. RMS, driven into 6  $\Omega$  at 63 Hz with no more than 10% total harmonic distortion. (IEC268-3)

75 W per channel, min. RMS, driven into 6  $\Omega$  at 63 Hz with no more than 0.9% total harmonic distortion. (DIN)

MAIN SPEAKERS : 55 W per channel, min. RMS, driven into 4  $\Omega$  at 1 kHz with no more than 10% total harmonic distortion. (IEC268-3)

35 W per channel, min. RMS, driven into 4  $\Omega$  at 1 kHz with no more than 0.9% total harmonic distortion. (DIN)

Audio input sensitivity/Impedance

(at 1 kHz, measured at MAIN SPEAKERS)

AUX : 400 mV/50 k $\Omega$

Speakers/Impedance : Subwoofers : 6  $\Omega$  – 16  $\Omega$   
Main speakers : 4  $\Omega$  – 8  $\Omega$

### Tuner

FM tuning range : 87.50 MHz – 108.00 MHz

AM (MW) tuning range : 522 kHz – 1 629 kHz

### CD player

CD Capacity : 3 CDs

Dynamic range : 85 dB

Signal-to-noise ratio : 85 dB

### Cassette deck

Frequency response

Normal (type I): 50 Hz — 14 000 Hz

Wow and flutter : 0.15% (WRMS)

### General

Power requirement : AC 230 V $\sim$ , 50 Hz

Power consumption : 160 W (at operation)

18 W (on standby; with power saving off—Normal Mode)

2.3 W (on standby; with power saving on—Eco mode)

Dimensions (approx.): 270 mm x 317 mm x 453 mm (W/H/D)

Mass (approx.) : 9.3 kg

### Supplied accessories

See page 6.

## CA-MXGA77

### Amplifier section

Output Power

SUBWOOFERS : 80 W per channel, min. RMS, driven into 6  $\Omega$  at 63 Hz with no more than 10% total harmonic distortion. (IEC268-3)

65 W per channel, min. RMS, driven into 6  $\Omega$  at 63 Hz with no more than 0.9% total harmonic distortion. (DIN)

MAIN SPEAKERS : 45 W per channel, min. RMS, driven into 4  $\Omega$  at 1 kHz with no more than 10% total harmonic distortion. (IEC268-3)

30 W per channel, min. RMS, driven into 4  $\Omega$  at 1 kHz with no more than 0.9% total harmonic distortion. (DIN)

Audio input sensitivity/Impedance

(at 1 kHz, measured at MAIN SPEAKERS)

AUX : 400 mV/50 k $\Omega$

Speakers/Impedance : Subwoofers : 6  $\Omega$  – 16  $\Omega$   
Main speakers : 4  $\Omega$  – 8  $\Omega$

### Tuner

FM tuning range : 87.50 MHz – 108.00 MHz

AM (MW) tuning range : 522 kHz – 1 629 kHz

### CD player

CD Capacity : 3 CDs

Dynamic range : 85 dB

Signal-to-noise ratio : 85 dB

### Cassette deck

Frequency response

Normal (type I): 50 Hz — 14 000 Hz

Wow and flutter : 0.15% (WRMS)

### General

Power requirement : AC 230 V $\sim$ , 50 Hz

Power consumption : 150 W (at operation)

17 W (on standby; with power saving off—Normal Mode)

2.3 W (on standby; with power saving on—Eco mode)

Dimensions (approx.): 270 mm x 317 mm x 453 mm (W/H/D)

Mass (approx.) : 9 kg

### Supplied accessories

See page 6.



**JVC**

VICTOR COMPANY OF JAPAN, LIMITED



EN

© 2003 VICTOR COMPANY OF JAPAN, LIMITED



0203TMMMDWSAM



# JVC

# INSTRUCTIONS



## SPEAKER SYSTEM SP-MXGA77

**BEDIENUNGSANLEITUNG: LAUTSPRECHERSYSTEM**  
**MANUEL D'INSTRUCTIONS: SYSTEME DES ENCEINTES**  
**GEBRUIKSAANWIJZING: LUIDSPREKERSYSTEEM**  
**MANUAL DE INSTRUCCIONES: SISTEMA DE ALTAVOCES**  
**ISTRUZIONI: SISTEMA DI ALTOPARLANTI**  
**BRUKSANVISNING: HÖGTALARSYSTEM**  
**KÄYTTÖOHJE: KAIUTINJÄRJESTELMÄ**  
**VEJLEDNING: HØJTTALERSYSTEM**

Thank you for purchasing JVC speakers.

Before you begin using them, please read the instructions carefully to be sure you get the best possible performance. If you have any questions, consult your JVC dealer.

Vielen Dank für den Kauf dieser JVC-Lautsprecher.

Lesen Sie bitte diese Bedienungsanleitung vor Ingebrauchnahme sorgfältig durch, um stets optimale Ergebnisse zu erzielen. Wenden Sie sich bei etwaigen Fragen bitte an Ihren JVC Händler.

Nous vous remercions pour l'achat de ces enceintes JVC.

Avant de les utiliser, lire ces instructions avec attention pour en obtenir les meilleures performances possibles. En cas de questions, consulter votre revendeur JVC.

Dank u voor de aanschaf van deze JVC luidsprekers.

Lees alvorens over te gaan tot aansluiten, deze gebruiksaanwijzing door zodat u de best mogelijke prestaties zult verkrijgen. Neem contact op met de JVC dealer indien u vragen heeft.

Le estamos muy agradecidos por haber adquirido estos altavoces de JVC.

Antes de utilizarlos, sírvase leer las instrucciones detenidamente a fin de obtener el mejor rendimiento posible. Si tienen alguna pregunta, acuda a su agente de JVC.

Grazie per aver acquistato questi altoparlanti della JVC.

Prima di cominciare l'uso degli altoparlanti, leggete attentamente le istruzioni per assicurare le migliori prestazioni. Qualora sorgessero dei dubbi, rivolgetevi al vostro rivenditore JVC.

Tack för ditt val av dessa JVC-högtalare.

Innan du kopplar in högtalarna i din ljudanläggning bör du för att få maximala prestanda från högtalarna läsa igenom bruksanvisningen noggrant. Kontakta din JVC-återförsäljare om du har frågor eller känner dig osäker.

Kiitos siitä että päädyit valinnassasi JVC-kaiuttimiin.

Ennen kuin alat käyttää niitä, lue käyttöohje huolellisesti, jotta ne toimisivat parhaalla mahdollisella tavalla. Jos Sinulla on kysyttävää ota yhteys JVC-edustajaan.

Tak for købet af JVC-højttalerne.

Gennemlæs venligst vejledningen omhyggeligt før de tages i brug, så De kan opnå den bedst mulige ydelse. Forhør hos Deres JVC forhandler hvis De har nogen spørgsmål.

### — SAFETY INSTRUCTIONS — “SOME DOS AND DON'TS ON THE SAFE USE OF EQUIPMENT”

This equipment has been designed and manufactured to meet international safety standards but, like any electrical equipment, care must be taken if you are to obtain the best results and safety is to be assured.

Do read the operating instructions before you attempt to use the equipment.

Do ensure that all electrical connections (including the mains plug, extension leads and interconnections between pieces of equipment) are properly made and in accordance with the manufacturer's instructions. Switch off and withdraw the mains plug when making or changing connections.

Do consult your dealer if you are ever in doubt about the installation, operation or safety of your equipment.

Do be careful with glass panels or doors on equipment.

DON'T continue to operate the equipment if you are in any doubt about it working normally, or if it is damaged in any way — switch off, withdraw the mains plug and consult your dealer.

DON'T remove any fixed cover as this may expose dangerous voltages.

DON'T leave equipment switched on when it is unattended unless it is specifically stated that it is designed for unattended operation or has a standby mode.

Switch off using the switch on the equipment and make sure that your family know how to do this.

Special arrangements may need to be made for infirm or handicapped people.

DON'T use equipment such as personal stereos or radios so that you are distracted from the requirements of traffic safety. It is illegal to watch television whilst driving.

DON'T listen to headphones at high volume as such use can permanently damage your hearing.

DON'T obstruct the ventilation of the equipment, for example with curtains or soft furnishing.

Overheating will cause damage and shorten the life of the equipment.

DON'T use makeshift stands and NEVER fix legs with wood screws — to ensure complete safety always fit the manufacturer's approved stand or legs with the fixings provided according to the instructions.

DON'T allow electrical equipment to be exposed to rain or moisture.

ABOVE ALL

— NEVER let anyone, especially children, push anything into holes, slots or any other opening in the case.

— this could result in a fatal electrical shock;

— NEVER guess or take chances with electrical equipment of any kind


— it is better to be safe than sorry!

**Connection  
Anschluß  
Raccordement  
Aansluiting  
Conexión**

**Collegamento  
Ansluiting  
Liitântä  
Tilslutning**

Right speaker  
Rechter Lautsprecher  
Enceinte de droite  
Rechter spreker  
Altavoz derecho  
Altoparlante destro  
Höger högtalare  
Oikea kaiutin  
Højre højttaler

Left speaker  
Linker Lautsprecher  
Enceinte de gauche  
Linker spreker  
Altavoz izquierdo  
Altoparlante sinistro  
Vänster högtalare  
Vasen kaiutin  
Venstre højttaler



**CONNECTION**

- DO NOT use other amplifier to operate this speaker system except for CA-MXGA77.
- Turn off power to the whole system before connecting the speakers to the amplifier.
- The maximum power handling capacity of the SP-MXGA77 main speaker is 55 W Subwoofer is 100 W. Excessive input will result in abnormal noise and possible damage. In cases where the signals described below are applied to the speakers, even if the signals are below the maximum allowable input, they may cause an overload and burn the wiring of the speakers. Be sure to lower the amplifier volume beforehand.
  - 1) Noise during FM tuning.
  - 2) High level signals containing high frequency components produced by a tape deck in the fast forward mode.
  - 3) Click noise produced when turning power of other components on and off.
  - 4) Click noise produced when connecting or disconnecting cords with the power on.
  - 5) Click noise produced when the cartridge is replaced with the power on.
  - 6) Click noise produced when operating amplifier switches.
  - 7) Continuous high frequency oscillation or high pitch electronically produced musical instrument sound.
  - 8) Howling when using a microphones.

**SPECIFICATIONS**

Type	: 3-way 3-speaker Bass-Reflex Type Twin Hyper Power-Drive Subwoofer
Speakers:	
Subwoofer	: 13.5 cm cone × 1
Main woofer	: 16.0 cm cone × 1
Tweeter	: 5.0 cm cone × 1
Power Handling Capacity:	
Subwoofer	: 100 W
Main Speaker	: 55 W
Impedance:	
Subwoofer	: 6 Ω
Main Speaker	: 4 Ω
Frequency Range:	
Subwoofer	: 32 Hz — 90 Hz
Main Speaker	: 90 Hz — 20 000 Hz
Sound Pressure Level:	
Subwoofer	: 86 dB/W·m
Main Speaker	: 75 dB/W·m
Dimensions (W × H × D)	: 290 mm × 317 mm × 336 mm
Mass	: 5.5 kg each

*Design and specifications subject to change without notice.*



## ANSCHLUSS

- Verwenden Sie zum Betrieb dieses Lautsprechersystems keinen anderen Verstärker, ausgenommen CA-MXGA77.
- Schalten Sie vor dem Anschluß der Lautsprecher an den Verstärker die Spannungsversorgung des gesamten Systems aus.
- Die maximale Belastbarkeit des SP-MXGA77-Hauptlautsprechers ist 55 W und die des Subwoofers ist 100 W. Eine Überlastung führt zu Verzerrungen und möglicherweise zu Beschädigungen. Signale der unten beschriebenen Art können, auch wenn sie unter dem maximal zulässigen Eingang liegen, eine Überlastung verursachen und die Lautsprecherwicklungen durchbrennen. Verringern Sie vorher die Lautstärke des Verstärkers.
  - 1) Geräusche beim Einstellen von UKW-Sendern.
  - 2) Hochpegelige Signale mit Hochfrequenz-Anteilen, die von Tonbanddecks beim Schnellvorspulen erzeugt werden.
  - 3) Klickgeräusche, wenn die Spannungsversorgung anderer Komponenten ein- und ausgeschaltet wird.
  - 4) Klickgeräusche, wenn Kabel angeschlossen oder abgetrennt werden, während die Spannungsversorgung eingeschaltet ist.
  - 5) Klickgeräusche, wenn der Tonabnehmer des Plattenspielers ausgewechselt wird, während die Spannungsversorgung eingeschaltet ist.
  - 6) Klickgeräusche, die beim Betätigen von Schaltern des Verstärkers erzeugt werden.
  - 7) Ständige Hochfrequenzschwingungen oder elektronisch erzeugte Töne von Musikinstrumenten mit hohen Tonhöhen.
  - 8) Rückkopplungen von Mikrofonen.

## TECHNISCHE DATEN

Typ	: 3-Weg, 3-Lautsprecher-Baßreflexbox Twin Hyper Power-Drive Subwoofer
Lautsprecher:	
Subwoofer	: 13,5 cm Konus × 1
Hauptwoofer	: 16,0 cm Konus × 1
Hochtöner	: 5,0 cm konus × 1
Belastbarkeit:	
Subwoofer	: 100 W
Hauptlautsprecher	: 55 W
Impedanz:	
Subwoofer	: 6 Ω
Hauptlautsprecher	: 4 Ω
Frequenzbereich:	
Subwoofer	: 32 Hz — 90 Hz
Hauptlautsprecher	: 90 Hz — 20 000 Hz
Schalldruckpegel:	
Subwoofer	: 86 dB/W·m
Hauptlautsprecher	: 75 dB/W·m
Abmessungen (B × H × T)	: 290 mm × 317 mm × 336 mm
Gewicht	: Je 5,5 kg

Technische Änderungen vorbehalten.

## RACCORDEMENT

- NE PAS utiliser d'autre amplificateur que le CA-MXGA77 pour faire fonctionner les enceintes.
- Mettre hors circuit tout le système avant de raccorder les enceintes à l'amplificateur.
- La puissance maximale admissible par le haut-parleur principal du SP-MXGA77 est de 55 W, celle admissible par le haut-parleur d'extrêmes graves est de 100 W. En dépassant la puissance admissible, cela provoquera des bruits anormaux et détériorera les enceintes. Au cas où les signaux décrits ci-dessous sont envoyés aux enceintes, et même si ces signaux sont inférieurs à la puissance d'entrée maximum admissible, ils risquent de provoquer une surcharge ou même un incendie. S'assurer de bien diminuer le volume sonore de l'amplificateur.
  - 1) Parasites durant une syntonisation FM.
  - 2) Signaux de niveau élevé contenant des composants à haute fréquence, comme ceux générés par une platine d'enregistrement en mode avance rapide.
  - 3) Cliquetis se produisant lorsque d'autres appareils sont mis en ou hors circuit.
  - 4) Cliquetis se produisant lorsque des appareils sont branchés ou dé-branchés alors que leur alimentation est en circuit.
  - 5) Cliquetis se produisant lorsque la cellule d'une platine tourne-disque est changée alors que l'alimentation est en circuit.
  - 6) Cliquetis se produisant lorsque les commandes de l'amplificateur sont manipulées.
  - 7) Oscillations continues à haute fréquence ou sons très aigus provenant d'instruments de musique électroniques.
  - 8) Hurllements dus à l'utilisation de micros.

## CARACTÉRISTIQUES

Typ	: Enceinte 3 voix, 3 haut-parleurs type à réflexion des basses Twin Hyper Power-Drive Subwoofer
Haut-parleurs:	
Extrêmes graves	: conique de 13,5 cm × 1
Principal	: conique de 16,0 cm × 1
Aigus	: conique de 5,0 cm × 1
Puissance maximale admissible:	
Haut-parleur d'extrêmes graves	: 100 W
Haut-parleur principal	: 55 W
Impédance:	
Haut-parleur d'extrêmes graves	: 6 Ω
Haut-parleur principal	: 4 Ω
Bande passante:	
Haut-parleur d'extrêmes graves	: 32 Hz — 90 Hz
Haut-parleur principal	: 90 Hz — 20 000 Hz
Pression sonore:	
Haut-parleur d'extrêmes graves	: 86 dB/W·m
Haut-parleur principal	: 75 dB/W·m
Dimensions (L × H × P)	: 290 mm × 317 mm × 336 mm
Masse	: 5,5 kg chaque

Présentation et caractéristiques modifiables sans préavis.

## AANSLUITINGEN

- Gebruik GEEN andere versterker dan de CA-MXGA77 om dit luidsprekersysteem aan te sturen.
- Schakel de spanning van alle aangesloten componenten uit alvorens de luidsprekers met de versterker te verbinden.
- Het maximale vermogen van de SP-MXGA77 hoofd-luidspreker is 55 W en van de subwoofer 100 W. Te hoge ingang kan in abnormale geluidsreproductie en in beschadigingen resulteren.

Overbelasting en verbranding van de bedrading kan worden veroorzaakt, wanneer de hieronder beschreven signalen naar de luidsprekers worden gevoed, zelfs wanneer de signalen onder het maximaal toegestane ingangsvermogen zijn.

Verminder eerst het volume van de versterker.

- 1) Ruis, zoals dit optreedt tijdens afstemming op een FM-zender.
- 2) Hoogfrequentie signalen van een hoog niveau, zoals die tijdens het vooruitspoelen van een tapedeck worden geproduceerd.
- 3) Klikkende geluiden, die worden veroorzaakt door het in- en uitschakelen van de netspanning van andere componenten.
- 4) Klikkende geluiden, zoals die worden geproduceerd bij het tot stand brengen of verbreken van aansluitingen terwijl de netspanning is ingeschakeld.
- 5) Klikkende geluiden, zoals die optreden bij het vervangen van het element van een draaitafel terwijl de netspanning is ingeschakeld.
- 6) Klikkende geluiden, zoals die worden geproduceerd door bediening van de schakelaars van de versterker.
- 7) Voortdurende hoogfrequentie-oscillatie, of hoogtonige, elektronisch geproduceerde geluiden van muziekinstrumenten.
- 8) Rondzingend geluid bij gebruik van microfoons.

## TECHNISCHE GEGEVENS

Type	: 3-weg 3-luidsprekers bass reflex Twin Hyper Power-Drive Subwoofer
Luidsprekers:	
Subwoofer	: 13,5 cm kegeltipe × 1
Hoofdwoofer	: 16,0 cm kegeltipe × 1
Tweeter	: 5,0 cm kegeltipe × 1
Maximale vermogen:	
Subwoofer	: 100 W
Hoofd-luidspreker	: 55 W
Impedantie:	
Subwoofer	: 6 Ω
Hoofd-luidspreker	: 4 Ω
Frekwentiebereik:	
Subwoofer	: 32 Hz — 90 Hz
Hoofd-luidspreker	: 90 Hz — 20 000 Hz
Geluidsdruk-niveau:	
Subwoofer	: 86 dB/W·m
Hoofd-luidspreker	: 75 dB/W·m
Afmetingen (B × H × D)	: 290 mm × 317 mm × 336 mm
Gewicht	: Elk 5,5 kg

*Veranderingen in technische gegevens et ontwerp onder voorbehoud.*

## CONEXIÓN

- NO utilice ningún otro amplificador para operar este sistema de altavoces excepto CA-MXGA77.
  - Desactive la alimentación de todo el sistema antes de conectar los altavoces al amplificador.
  - La capacidad máxima de potencia del altavoz principal del SP-MXGA77 es de 55 W y la del altavoz de subgraves es de 100 W. Uná entrada excesiva resultará en ruido anormal y posibles daños. En casos donde las señales descritas más abajo se apliquen a los altavoces, aunque las mismas resulten menores que la entrada máxima permisible, pueden causar una sobrecarga y quemar el cableado de los altavoces. Asegúrese de disminuir el volumen del amplificador con anterioridad.
- 1) Ruido durante la sintonía en FM.
  - 2) Señales de alto nivel que contengan componentes de alta frecuencia producidos por un magnetófono en el modo de avance rápido.
  - 3) Ruidos de conmutación provocados al encender y apagar otros componentes.
  - 4) Ruido de conmutación al conectar o desconectar cables con los componentes encendidos.
  - 5) Ruido de conmutación cuando se reemplaza la cápsula con los componentes encendidos.
  - 6) Ruido de conmutación provocados por la operación de los selectores del amplificador.
  - 7) Continua oscilación de alta frecuencia o de sonidos de tonos altos provocados por instrumentos electrónicos.
  - 8) Aullidos a utilizar micrófonos.

## ESPECIFICACIONES

Tipo	: Reflex bajo con 3-altavoces y 3 vías Twin Hyper Power-Drive Subwoofer
Altavoces:	
De subgraves	: Tipo cónico de 13,5 cm × 1
Principal	: Tipo cónico de 16,0 cm × 1
De agudos	: Tipo cónico de 5,0 cm × 1
Capacidad de potencia:	
De subgraves	: 100 W
Principal	: 55 W
Impedancia:	
De subgraves	: 6 Ω
Principal	: 4 Ω
Gama de frecuencias:	
De subgraves	: 32 Hz — 90 Hz
Principal	: 90 Hz — 20 000 Hz
Nivel de presión acústica:	
De subgraves	: 86 dB/W·m
Principal	: 75 dB/W·m
Dimensiones (An × Al × Prf)	: 290 mm × 317 mm × 336 mm
Peso	: 5,5 kg cada uno

*El diseño y las especificaciones están sujetos a cambio sin aviso.*



## COLLEGAMENTO

- NON usare un amplificatore diverso dal modello CA-MXGA77 per utilizzare questo sistema di altoparlanti.
- Spegnete la corrente dell'intero sistema prima di collegare gli altoparlanti all'amplificatore.
- La capacità di potenza massima dell'altoparlante principale del modello SP-MXGA77 è di 55 W e quella del subwoofer è di 100 W. Un ingresso eccessivo causerà un suono anormale e possibili danni. Nel caso in cui i segnali descritti qui sotto vengono applicati agli altoparlanti, possono causare un sovraccarico e bruciare il cablaggio degli altoparlanti, anche se i segnali siano al di sotto dell'ingresso massimo ammesso. Assicuratevi di diminuire il livello del volume dell'altoparlante prima di procedere.

- 1) Generazione di rumore durante la sintonizzazione FM.
- 2) Segnali di alto livello che contengono dei componenti ad alta frequenza riprodotti da una piastra a cassette nel modo di avanzamento rapido.
- 3) Si sentirà uno scatto quando accendete o spegnete la corrente degli altri componenti.
- 4) Si sentirà uno scatto quando collegate o scollegate i cavi con la corrente accesa.
- 5) Si sentirà uno scatto quando viene sostituita la cartuccia con la corrente accesa.
- 6) Si sentirà uno scatto quando vengono usati gli interruttori dell'amplificatore.
- 7) Oscillazione continua ad alta frequenza o suoni acuti da strumenti musicali elettronici.
- 8) Ululato quando usate i microfoni.

## SPECIFICAZIONI

Tipo	: Reflex basso con 3-altoparlanti e 3 vie Twin Hyper Power-Drive Subwoofer
Altoparlanti:	
Subwoofer	: Cono da 13,5 cm × 1
Woofer principale	: Cono da 16,0 cm × 1
Tweeter	: Cono da 5,0 cm × 1
Capacità di potenza:	
Subwoofer	: 100 W
Altoparlante principale	: 55 W
Impedenza:	
Subwoofer	: 6 Ω
Altoparlante principale	: 4 Ω
Gamma di frequenza:	
Subwoofer	: 32 Hz — 90 Hz
Altoparlante principale	: 90 Hz — 20 000 Hz
Livello di pressione sonora:	
Subwoofer	: 86 dB/W·m
Altoparlante principale	: 75 dB/W·m
Dimensioni (L × A × P)	: 290 mm × 317 mm × 336 mm
Massa	: 5,5 kg ciascuno

*Il disegno e le specifiche sono soggetti a cambiamenti senza preavviso.*

## ANSLUTNING

- Använd INTE någon annan förstärkare än CA-MXGA77 till att driva detta högtalarsystem med.
  - Slå av strömmen i alla apparater i ljudanläggningen innan högtalarna ansluts till förstärkaren.
  - Maximal effekthanteringskapacitet för SP-MXGA77 är 55 W för huvudhögtalare/100 W för lågbashögtalare. Brus uppstår i ljudet och högtalarna kan skadas om de matas med för hög effekt. I situationerna som beskrivs nedan kan högtalarna också överbelastas och kabeltråden inne i högtalarna brännas sönder, fastän högtalarnas effekt inte har överskridits. Sänk därför ljudstyrkan på förhand.
- 1) Brus under inställning av FM-radiostationer.
  - 2) Starka, högfrekventa signaler från ett kassettdäck under snabbspolning framåt.
  - 3) Ljudbangar som uppstår när andra apparater i anläggningen slås till och från.
  - 4) Skrapljud som uppstår när anslutningskablar ansluts eller kopplas från medan strömmen är på.
  - 5) Skrapljud som uppstår när pickupelementet på en skivspelare byts medan strömmen är på.
  - 6) Ljudbangar som uppstår när du använder förstärkarens omkopplare.
  - 7) Kontinuerliga, högfrekvenssvängningar eller högfrekvent ljud från elektroniska musikinstrument.
  - 8) Akustisk återkoppling (tjutande ljud) vid bruk av mikrofoner.

## TEKNISKA DATA

Typ	: 3-vägs, 3-elements basreflexhögtalare Twin Hyper Power-Drive Subwoofer
Högtalarelement:	
Lågbaselement	: 13,5 cm kon × 1
Huvudbaselement	: 16,0 cm kon × 1
Diskantelement	: 5,0 cm kon × 1
Effekthanteringskapacitet:	
Lågbashögtalare	: 100 W
Huvudhögtalare	: 55 W
Impedans:	
Lågbashögtalare	: 6 Ω
Huvudhögtalare	: 4 Ω
Frekvensomfång:	
Lågbashögtalare	: 32 Hz — 90 Hz
Huvudhögtalare	: 90 Hz — 20 000 Hz
Ljudtrycksnivå:	
Lågbashögtalare	: 86 dB/W·m
Huvudhögtalare	: 75 dB/W·m
Ytermått (B × H × D)	: 290 mm × 317 mm × 336 mm
Vikt	: 5,5 kg perst.

*Rätt till ändringar av utförande och specifikationer förbehålles utan föregående meddelande.*

## LIITÄNTÄ

- ÄLÄ käytä muuta vahvistinta tämän kaiutinjärjestelmän käyttöön paitsi mallille CA-MXGA77.
- Katkaise koko järjestelmän virta ennen kuin suoritat liitännät kaiuttimista vahvistimeen.
- Mallin SP-MXGA77 pääkaiuttimen enimmäisteho on 55 W, apubassokaiuttimen 100 W. Liiallinen antoteho aiheuttaa epänormaalia kohinaa ja jopa vahinkoa. Tapauksissa, missä kaiuttimet joutuvat alla kuvattujen signaalien kohteeksi, vaikka signaalit olisivat alle sallitun maksimi antotehon, ne saattavat aiheuttaa ylikuormitusta ja polttaa kaiuttimien johdot. Vähennä siis vahvistimen äänenvoimakkuutta jo ennalta.
  - 1) Kohinaa FM-virityksen aikana.
  - 2) Kasettitekistä eteenpäinkelauksen aikana muodostuneet vahvat, korkeataajuuksisia komponentteja sisältävät signaalit.
  - 3) Klik-ääni, joka syntyy silloin kun toisten osien virta kytketään ja katkaistaan.
  - 4) Klik-ääni, joka syntyy silloin kun kytketään tai irrotetaan johtoja virran ollessa päällä.
  - 5) Klik-ääni, joka syntyy silloin kun vaihdetaan hylsy virran ollessa päällä.
  - 6) Klik-ääni, joka syntyy silloin kun käytetään vahvistimen kytkimiä.
  - 7) Jatkuva korkea värähtely tai elektronisesti tuotettu korkea soittimen ääni.
  - 8) Ulinaa mikrofonia käytettäessä.

## TEKNISET TIEDOT

Tyyppi	: 3-tie, 3 kaiuttimen bassorefleksi Twin Hyper Power-Drive Subwoofer
Kaiuttimet:	
Apubasso	: 13,5 cm karitomuotoinen × 1
Päabasso	: 16,0 cm karitomuotoinen × 1
Diskantti	: 5,0 cm karitomuotoinen × 1
Enimmäisteho:	
Apubasso	: 100 W
Pääkaiutin	: 55 W
Impedanssi:	
Apubasso	: 6 Ω
Pääkaiutin	: 4 Ω
Taajuusala:	
Apubasso	: 32 Hz — 90 Hz
Pääkaiutin	: 90 Hz — 20 000 Hz
Äänenpainetaso:	
Apubasso	: 86 dB/W·m
Pääkaiutin	: 75 dB/W·m
Mitat (L × K × S)	: 290 mm × 317 mm × 336 mm
Paino	: 5,5 kg perst.

*Oikeudet muutoksiin pidätetään.*

## TILSLUTNING

- Anvend IKKE anden forstærker end CA-MXGA77 til drift af dette højttalersystem.
- Sluk for strømmen til hele systemet før højttalerne forbindes til forstærkeren.
- Den maksimale belastningskapacitet for SP-MXGA77 hovedhøjttaleren er 55 W/for subwooferen 100 W. For kraftigt indgangssignal vil resultere i unormal støj og muligvis beskadigelse. I tilfælde hvor højttalerne udsættes for signaler beskrevet nedenfor, kan der forekomme overbelastning og overbrænding af ledningerne i højttalerne selv om signalstyrken er under den maksimale tilladte værdi. Husk derfor at at sænke højttalerlydstyrken i forvejen.
  - 1) Støj under FM-afstemning.
  - 2) Signaler med høje niveauer der indeholder højfrekvente komponenter dannet af en båndoptager der er indstillet til hurtig fremspoling.
  - 3) Klikstøj dannet når der tændes eller slukkes for strømmen til andre domponenter.
  - 4) Klikstøj der dannes når ledninger tilsluttes eller tages ud af forbindelse mens der er tændt for strømmen.
  - 5) Klikstøj der dannes når pickuppen udskiftes mens der er tændt for strømmen.
  - 6) Klikstøj der dannes når forstærkerens omskiftere betjenes.
  - 7) Fortsat høj frekvenssvingning, eller en højlyd dannet af et elektronisk instrument.
  - 8) Hyletoner når der anvendes en mikrofon.

## SPECIFIKATIONER

Type	: 3-vejs basrefleks-højttaler med 3-elementer Twin Hyper Power-Drive Subwoofer
Højttalere:	
Subwoofer	: 13,5 cm membran × 1
Hoved-højttaler	: 16,0 cm membran × 1
Diskantenhed	: 5,0 cm membran × 1
Belastningskapacitet:	
Subwoofer	: 100 W
Hovedhøjttaler	: 55 W
Impedans:	
Subwoofer	: 6 Ω
Hovedhøjttaler	: 4 Ω
Frekvensområde:	
Subwoofer	: 32 Hz — 90 Hz
Hovedhøjttaler	: 90 Hz — 20 000 Hz
Lydtryksniveau:	
Subwoofer	: 86 dB/W·m
Hovedhøjttaler	: 75 dB/W·m
Mål (B × H × D)	: 290 mm × 317 mm × 336 mm
Vægt	: 5,5 kg hver

*Design og specifikationer kan blive ændret uden varsel.*

# PARTS LIST

[ MX-GA77 ]

\* All printed circuit boards and its assemblies are not available as service parts.

## Area suffix

B ----- U.K.  
 E ----- Continental Europe  
 EN ----- Northern Europe  
 EV ----- Eastern Europe

## - Contents -

Exploded view of general assembly and parts list (Block No.M1) .....	3- 3
Exploded view of general assembly and parts list (Block No.M2) .....	3- 5
CD changer mechanism assembly and parts list (Block No.MA) .....	3- 6
Cassette mechanism assembly and parts list (Block No.MP) .....	3- 8
Electrical parts list (Block No.01~04) .....	3-10
Packing materials and accessories parts list (Block No.M3,M5) .....	3-22


< MEMO >





# Exploded view of general assembly and parts list

Block No. **M 1 M M**



MX-GA77

MX-GA77

■ Parts list (General assembly)

Block No. M1MM

■ Parts list (General assembly)

Block No. M1MM


△	Item	Parts number	Parts name	Q'ty	Description	Area
	1	AH64-02252C	FRONT CABINET	1		
	2	AH64-02253B	CASSETTE DOOR A	1		
	3	AH64-02254B	CASSETTE DOOR B	1		
	4	AH64-02255B	CD DOOR	1		
	5	AH64-02256E	WINDOW VFD	1		
	6	AH64-02257A	WINDOW DOOR A	1		
	7	AH64-02258A	WINDOW DOOR B	1		
	8	AH640-2259B	KNOB DISC	1		
	A	AH64-01106G	SCREW	4	M3X10 SILVER	
	B	6002-000126	SCREW	3	FH M3X10 BLK	
	C	6003-000276	SCREW	40	BH M3X10 YEL	
	D	6003-000275	SCREW	26	BH M3X10 BLACK	
	E	AH60-10107A	SCREW	4	M4X6 YEL	
	F	6003-000277	SCREW	4	BH M3X12 YEL	
	G	6002-000398	SCREW	3	BH M3X6 YEL	
	H	6003-001230	SCREW	4	BH M3 14 YEL	
	J	6003-000283	SCREW	3	BH M3X8 YEL	
	L 1	AH68-01253C	RATING LABEL	1		B,E,EN
		AH68-01253D	RATING LABEL	1		EV
	L 2	AH68-00332A	CARTON LABEL	1		
	L 3	AH68-00331A	GOST LABEL	1		EV
	L 5	AH68-50275D	CD STICKER	1		
	L10	AH68-00486A	CAUTION LABEL B	1		EV
	10	AH64-02261B	KNOB POWER ECO	1		
	11	AH64-02262B	KNOB REC	1		
	12	AH64-02263B	KNOB REPEAT	1		
	13	AH64-02264B	KNOB SOUND	2		
	14	AH64-02265B	KNOB VOLUME	1		
	15	AH64-02266B	DECO RING	1		
	16	AH64-02267B	KNOB TURBO	1		
	18	AH64-02269B	KNOB RDS	1		
	19	AH64-02270B	KNOB FUNCTION L	1		
	20	AH64-02271B	KNOB FUNCTION R	1		
	22	AH67-00200B	LENS DISC	1		
	23	AH67-00201A	LENS POWER	1		
	24-1	AH67-00202B	LENS-EQ L1	1	ROCK	
	24-2	AH67-00202C	LENS-EQ L2	1	POP	
	24-3	AH67-00202D	LENS-EQ L3	1	CLASSIC	
	25-1	AH67-00203B	LENS-EQ R1	1	DANCE	
	25-2	AH67-00203C	LENS-EQ R2	1	HALL	
	25-3	AH67-00203D	LENS-EQ R3	1	STADIUM	
	26	AH67-00204B	LENS INNER L	1		
	27	AH67-00205B	LENS INNER R	1		
	28	AH67-00208A	LENS MILKY	2		
	29	AH61-01258A	VFD HOLDER	1		
	30	AH63-00507A	SHEET MIRROR	1		
	31	AH61-01261A	PCB BRAKET	1		
	32	AH61-01262A	H SINK BRAKET	2		

△	Item	Parts number	Parts name	Q'ty	Description	Area
	33	AH64-02273E	REAR CABINET	1		
	34	AH62-00042A	HEAT SINK	1	4959	
	35	AH63-00278A	PCB COVER	1		
	36	AH61-40014A	SUPPORT RIVET	3		
	37	AH95-50001A	LATCH ASSY	2		
	38	AH61-80030A	DAMPER ASSY	2		
	39	AH61-00552A	DOOR SPRING A	1		
	40	AH61-00553A	DOOR SPRING B	1		
	41	AH64-00462C	BADGE JVC	1		
	42	AH64-30416E	BOTTOM CABINET	1		
	43	AH64-30390K	TOP CABINET	1		
	44	AH69-20031A	CUSHION FOOT	2		
	45	AH63-00250B	HEAT SINK COVER	1		
	46	AH62-00080E	HEAT SINK	1	MAIN	
△	47	AH26-00188A	TRANS POWER	1	230V 40.5/40/4	
	53	AH07-00098A	VFD	1	BJ904GNK	
	54	-----	CASSETTE MECHA	1	CWM43FF09	
△	56	AH39-00257A	POWER CORD	1	250V 2.5A 1830MM	E,EN,EV
△		AH39-00258Q	POWER CORD	1	250V 5A 1830MM	B
	57	AH39-50001X	GROUND WIRE	1		
	58	AH40-00050A	TUNER PACK	1	KST-MJ111MS0-60	
	59	AH61-01400A	KNOB DECK	1		
	60	AH64-02551B	KNOB	1		

# Exploded view of general assembly and parts list

Block No. M 2 M M

## SPEAKER BOX




### ■ Parts list (General assembly)

Block No. M2MM

Item	Parts number	Parts name	Q'ty	Description	Area
1	AH81-00959E	SIDE PANEL	1	RIGHT	
	AH81-00959F	SIDE PANEL	1	LEFT	
2	AH81-01121A	SCREW	5	4.0X40MM BK	
3	AH81-00959M	SPEAKER	1	130MM 6OHM 120W	
4	AH81-00959Z	SCREW	4	3.5MMX16MM BK	
5	AH91-00959X	SHEET	1	EVA	

# CD changer mechanism assembly and parts list

Block No. M A M M





**Parts list (CD changer mechanism)**

Block No. MAMM

△	Item	Parts number	Parts name	Q'ty	Description	Area
	1	AH66-80022A	SLIDE CAM	1	ABS HF-380 NTR	
	2	AH66-60034A	BELT LOAD	1	CR	
	3	AH66-20186A	GEAR PULLEY	1	POM (M90-44)WHT	
	4	AH66-20187A	GEAR-LOAD	1	POM (M90-44)BLK	
	5	AH66-20188A	GEAR-CAM	1	POM(M90-44)WHT	
	6	AH66-20189A	GEAR-TRAY	1	POM(M90-44)BLK	
	7	AH66-20190A	GEAR-CONVERTOR	1	POM (M90-44) WH	
	8	AH66-20191A	GEAR-SYNCRO	1	ABS HF-380 NTR	
	9	AH66-20192A	GEAR-WORM	1	POM (M90-44)WHT	
	10	AH31-12001A	LOADING MOTOR	1	FF-030PN-09120	
	11	AH66-20193A	GEAR-ROULETTE	1	POM(M90-44)BLK	
	12	AH66-90056A	TRAY-ROULETTE	1	ABS XR-401 BLK	
	13	AH66-90055A	TRAY DISC	1	ABS XR-401 BLK	
	14	AH32-10001F	SENSOR	1	KPI-L06	
	15	AH61-20428A-1	BASE MAIN	1	CMS-300,BLK	
	16	3302-000159	MAGNET-FERRITE	1	3500-3800G,6P	
	17	AH66-90053A	TABTE-CHUCK UNI	1	BLK,CMS300	
	18	AH63-00068B	SHEET CHUCK	1	HYMERON,BLK,0.4	
	19	3404-000101	SWICH MICRO	1	MLS-24	
	20	AH31-10021A	DC MORTOR	1	RF-500TB,9VDC	
	21	AH66-10008A	PULLEY-MOTOR	1	BLK,CMS-CR3	
	22	AH73-10031A	RUBBER-CD	1	RCD380,RED	
	23	AH91-60150C	SP MOTOR ASS'Y	1	CMS-D73SG6U	
	24	AH66-30098A	LEVER-LIFTER	1	ABS(BLK),CMS-30	
	25	AH30-00007A	CD PICKUP	1	SOH-AD3	
	26	AH73-10034A	RUBBER-CD(G)	1	CMS-300D,GREEN	
	27	AH61-00255A	BRKT CHUCK	1	SECL 0.8T	

# Cassette mechanism assembly and parts list

Block No. M P M M

CWM43FF09



Note: Parts listed on the Parts List below can be supplied. However, parts that are not listed below cannot be supplied individually but only by purchasing the whole Cassette Mechanism Assembly Unit. (When ordering, use the Parts No. AH59-01132A for Cassette Mechanism Assembly Unit.)

**Parts list (Cassette mechanism)**

Block No. MPMM

Item	Parts number	Parts name	Q'ty	Description	Area
1	AH81-00472A	PB HEAD	2	TC881CB067P	
2	AH81-00472B	E HEAD	1	TC2131	
3	AH81-00472N	PINCH ROLLER	2	22-027-41054	
4	AH81-00902E	MOTOR ASSY	1	50-093-4879	
5	AH81-00902G	BF BELT	1	02-083-4236	
6	AH81-00902J	AF BELT	1	02-083-4234	
7	AH81-00902K	FR BLET	2	02-083-4188	
8	AH81-00902L	SOLENOID ASSY	2	50-093-4748	
10	AH81-00902Q	HOUSING	1	6216016100	
11	AH81-00472V	CLUTCH ASSY	2	50-093-4503	
12	AH81-00902W	MODE SWITCH	1	MPU11570MLB0	
13	AH81-00902X	PHOTO INTERRUPT	1	RP1352	
14	AH81-00902Y	LEAF SWITCH	1	LSA11355	
15	AH81-00903A	SPRING62	2	01-082-4686	
16	AH81-00473H	SPRING 04	2	01-080-4635	

## ■ Electrical parts list (Main board)

Block No. 01

△	Item	Parts number	Parts name	Remarks	Area	△	Item	Parts number	Parts name	Remarks	Area
	AC101	2301-000216	M.CAPACITOR	220NF 5% 50V			AR119	2001-000281	CARBON RESISTOR	100 5% 1/8W	
	AC102	2301-000474	M.CAPACITOR	8.2NF 10% 50V			AR120	2001-000281	CARBON RESISTOR	100 5% 1/8W	
	AC103	2301-000390	M.CAPACITOR	15NF 10% 50V			AR121	2001-000802	CARBON RESISTOR	5.6K 5% 1/8W	
	AC104	2301-000216	M.CAPACITOR	220NF 5% 50V			AR122	2001-000522	CARBON RESISTOR	22K 5% 1/8W	
	AC105	2301-000419	M.CAPACITOR	27NF 10% 50V			AR123	2001-000258	CARBON RESISTOR	1.8K 5% 1/8W	
	AC106	2301-000449	M.CAPACITOR	47NF 10% 50V			AR124	2001-000331	CARBON RESISTOR	12K 5% 1/8W	
	AC107	2301-000375	M.CAPACITOR	100NF 10% 50V			AR125	2001-000522	CARBON RESISTOR	22K 5% 1/8W	
	AC108	2301-000375	M.CAPACITOR	100NF 10% 50V			AR126	2001-000522	CARBON RESISTOR	22K 5% 1/8W	
	AC109	2301-000419	M.CAPACITOR	27NF 10% 50V			AR127	2001-000890	CARBON RESISTOR	6.8K 5% 1/8W	
	AC110	2301-000216	M.CAPACITOR	220NF 5% 50V			AR128	2001-000522	CARBON RESISTOR	22K 5% 1/8W	
	AC111	2201-000144	C.CAPACITOR	0.1NF 5% 50V			AR129	2001-000281	CARBON RESISTOR	100 5% 1/8W	
	AD101	0401-000101	DIODE	1N4148 100V			AR130	2001-000281	CARBON RESISTOR	100 5% 1/8W	
	AD102	0401-000101	DIODE	1N4148 100V			AR131	2001-000281	CARBON RESISTOR	100 5% 1/8W	
	AD103	0401-000101	DIODE	1N4148 100V			AR132	2001-000508	CARBON RESISTOR	220K 5% 1/8W	
	AD104	0401-000101	DIODE	1N4148 100V			AR133	2001-000449	CARBON RESISTOR	2.2K 5% 1/8W	
	AE101	2401-001893	E.CAPACITOR	100UF 20% 16V			AR134	2001-001000	CARBON RESISTOR	82K 5% 1/8W	
	AE102	2401-001893	E.CAPACITOR	100UF 20% 16V			AR135	2001-000273	CARBON RESISTOR	100K 5% 1/8W	
	AE103	2401-001954	E.CAPACITOR	4.7UF 20% 50V			AR136	2001-000273	CARBON RESISTOR	100K 5% 1/8W	
	AE104	2401-001954	E.CAPACITOR	4.7UF 20% 50V			AR137	2001-000786	CARBON RESISTOR	47K 5% 1/8W	
	AE105	2401-001893	E.CAPACITOR	100UF 20% 16V			AR138	2001-000786	CARBON RESISTOR	47K 5% 1/8W	
	AE106	2401-001893	E.CAPACITOR	100UF 20% 16V			AR139	2001-000554	CARBON RESISTOR	270 5% 1/8W	
	AE107	2401-001893	E.CAPACITOR	100UF 20% 16V			AR140	2001-000802	CARBON RESISTOR	5.6K 5% 1/8W	
	AE108	2401-001893	E.CAPACITOR	100UF 20% 16V			AR141	2001-000281	CARBON RESISTOR	100 5% 1/8W	
	AE109	2401-001511	E.CAPACITOR	47UF 20% 16V			AR301	2001-000281	CARBON RESISTOR	100 5% 1/8W	
	AE110	2401-001511	E.CAPACITOR	47UF 20% 16V			BC01L	2301-000361	M.CAPACITOR	1.2NF 10% 50V	
	AE111	2401-001912	E.CAPACITOR	1UF 20% 50V			BC01R	2301-000361	M.CAPACITOR	1.2NF 10% 50V	
	AE112	2401-001893	E.CAPACITOR	100UF 20% 16V			BD101	0401-000101	DIODE	1N4148 100V	
	AE113	2401-001893	E.CAPACITOR	100UF 20% 16V			BL01L	AH26-10002W	TRANS TRAP COIL	BIAS-TRAP105K	
	AE114	2401-001511	E.CAPACITOR	47UF 20% 16V			BL01R	AH26-10002W	TRANS TRAP COIL	BIAS-TRAP105K	
	AE115	2401-001511	E.CAPACITOR	47UF 20% 16V			BQ02L	0501-000010	TRANSISTOR	KSC1008 NPN	
	AE116	2401-002180	E.CAPACITOR	2.2UF 20% 50V			BQ02R	0501-000010	TRANSISTOR	KSC1008 NPN	
	AE117	2401-003621	E.CAPACITOR	47UF 20% 63V			BQ03L	0501-000010	TRANSISTOR	KSC1008 NPN	
	AIC01	1201-000191	IC	BA4558 DIP 8P			BQ03R	0501-000010	TRANSISTOR	KSC1008 NPN	
	AIC02	1201-000191	IC	BA4558 DIP 8P			BQ101	0504-001128	DIGI TRANSISTOR	KRA103M PNP	
	AIC03	1201-000191	IC	BA4558 DIP 8P			BR01L	2001-000281	CARBON RESISTOR	100 5% 1/8W	
	AIC04	1201-000191	IC	BA4558 DIP 8P			BR01R	2001-000281	CARBON RESISTOR	100 5% 1/8W	
	AQ101	0501-002409	TRANSISTOR	KTC945B NPN			BR02L	2001-000890	CARBON RESISTOR	6.8K 5% 1/8W	
	AQ102	0501-002409	TRANSISTOR	KTC945B NPN			BR02R	2001-000890	CARBON RESISTOR	6.8K 5% 1/8W	
	AQ103	0501-002409	TRANSISTOR	KTC945B NPN			BR03L	2001-000890	CARBON RESISTOR	6.8K 5% 1/8W	
	AR01L	2001-000522	CARBON RESISTOR	22K 5% 1/8W			BR03R	2001-000890	CARBON RESISTOR	6.8K 5% 1/8W	
	AR01R	2001-000522	CARBON RESISTOR	22K 5% 1/8W			BR101	2001-000522	CARBON RESISTOR	22K 5% 1/8W	
	AR02L	2001-000786	CARBON RESISTOR	47K 5% 1/8W			CE101	2401-001893	E.CAPACITOR	100UF 20% 16V	
	AR02R	2001-000786	CARBON RESISTOR	47K 5% 1/8W			CE102	2401-001893	E.CAPACITOR	100UF 20% 16V	
	AR03L	2001-000508	CARBON RESISTOR	220K 5% 1/8W			CE103	2401-001887	E.CAPACITOR	100UF 20% 50V	
	AR03R	2001-000508	CARBON RESISTOR	220K 5% 1/8W			CQ01L	0504-001125	DIGI TRANSISTOR	KRC110M NPN	
	AR101	2001-000563	CARBON RESISTOR	27K 5% 1/8W			CQ01R	0504-001125	DIGI TRANSISTOR	KRC110M NPN	
	AR102	2001-000563	CARBON RESISTOR	27K 5% 1/8W			CQ101	0504-001128	DIGI TRANSISTOR	KRA103M PNP	
	AR103	2001-000548	CARBON RESISTOR	270K 5% 1/8W			CR01L	2001-000864	CARBON RESISTOR	56K 5% 1/8W	
	AR104	2001-000273	CARBON RESISTOR	100K 5% 1/8W			CR01R	2001-000864	CARBON RESISTOR	56K 5% 1/8W	
	AR105	2001-000273	CARBON RESISTOR	100K 5% 1/8W			CR02L	2001-000411	CARBON RESISTOR	18K 5% 1/8W	
	AR106	2001-000522	CARBON RESISTOR	22K 5% 1/8W			CR02R	2001-000411	CARBON RESISTOR	18K 5% 1/8W	
	AR107	2001-000522	CARBON RESISTOR	22K 5% 1/8W			CW101	3708-001577	CONNECTOR	30P 1.25MM	
	AR108	2001-000281	CARBON RESISTOR	100 5% 1/8W			CW103	3708-000412	CONNECTOR	12P 1.25MM	
	AR109	2001-000281	CARBON RESISTOR	100 5% 1/8W			CW104	3711-001137	CONNECTOR	8P 2MM	
	AR110	2001-000273	CARBON RESISTOR	100K 5% 1/8W			CW105	3708-001167	CONNECTOR	14P 1.25MM	
	AR111	2001-000273	CARBON RESISTOR	100K 5% 1/8W			CW106	AH39-00295A	LEAD CONNECTOR	MAX-L85 9P	
	AR112	2001-000273	CARBON RESISTOR	100K 5% 1/8W			CW107	AH39-00338A	LEAD CONNECTOR		
	AR113	2001-000281	CARBON RESISTOR	100 5% 1/8W			CW108	3711-001062	CONNECTOR	6P 1R 2MM	
	AR114	2001-000864	CARBON RESISTOR	56K 5% 1/8W			CW109	3711-003111	CONNECTOR	6P 1R 2.5MM	
	AR115	2001-000258	CARBON RESISTOR	1.8K 5% 1/8W			CW11	AH37-22001N	CONNECTOR JACK	10MM YFW800-02 2P	
	AR116	2001-000977	CARBON RESISTOR	8.2K 5% 1/8W			CW110	3711-003107	CONNECTOR	3P 1R 2.5MM	
	AR117	2001-000281	CARBON RESISTOR	100 5% 1/8W			CW111	3711-000907	CONNECTOR	3P 1R 2MM	
	AR118	2001-000508	CARBON RESISTOR	220K 5% 1/8W			EC07L	2301-000454	M.CAPACITOR	5.6NF 10% 50V	



## ■ Electrical parts list (Main board)


Block No. 01

△	Item	Parts number	Parts name	Remarks	Area	△	Item	Parts number	Parts name	Remarks	Area
	EC07R	2301-000454	M.CAPACITOR	5.6NF 10% 50V			ER104	2001-000022	CARBON RESISTOR	47 5% 1/4W	
	EC08L	2301-000216	M.CAPACITOR	220NF 5% 50V			ER109	2001-000290	CARBON RESISTOR	10K 5% 1/8W	
	EC08R	2301-000216	M.CAPACITOR	220NF 5% 50V			ER110	2001-000773	CARBON RESISTOR	470K 5% 1/8W	
	EC09L	2301-000216	M.CAPACITOR	220NF 5% 50V			ER111	2001-000515	CARBON RESISTOR	220 5% 1/8W	
	EC09R	2301-000216	M.CAPACITOR	220NF 5% 50V			ER112	2001-000645	CARBON RESISTOR	330K 5% 1/8W	
	EC10L	2201-000368	C.CAPACITOR	0.22NF 10% 50V			ER113	2001-000989	CARBON RESISTOR	820K 5% 1/8W	
	EC10R	2201-000368	C.CAPACITOR	0.22NF 10% 50V			ER13L	2001-000864	CARBON RESISTOR	56K 5% 1/8W	
	EC101	2301-000361	M.CAPACITOR	1.2NF 10% 50V			ER13R	2001-000864	CARBON RESISTOR	56K 5% 1/8W	
	EC102	2301-000375	M.CAPACITOR	100NF 10% 50V			ER14L	2001-000008	CARBON RESISTOR	15K 5% 1/8W	
	EC103	2201-000783	C.CAPACITOR	100NF +80-20% 50V			ER14R	2001-000008	CARBON RESISTOR	15K 5% 1/8W	
	EC11L	2201-000368	C.CAPACITOR	0.22NF 10% 50V			ER15L	2001-000290	CARBON RESISTOR	10K 5% 1/8W	
	EC11R	2201-000368	C.CAPACITOR	0.22NF 10% 50V			ER15R	2001-000290	CARBON RESISTOR	10K 5% 1/8W	
	ED102	0401-000101	DIODE	1N4148 100V			ER16L	2001-000003	CARBON RESISTOR	330 5% 1/8W	
	EE01L	2401-001912	E.CAPACITOR	1UF 20% 50V			ER16R	2001-000003	CARBON RESISTOR	330 5% 1/8W	
	EE01R	2401-001912	E.CAPACITOR	1UF 20% 50V			ER17L	2001-000003	CARBON RESISTOR	330 5% 1/8W	
	EE02L	2401-001912	E.CAPACITOR	1UF 20% 50V			ER17R	2001-000003	CARBON RESISTOR	330 5% 1/8W	
	EE02R	2401-001912	E.CAPACITOR	1UF 20% 50V			EZD01	0403-000372	ZENER DIODE	UZ9.1BM 9.1V	
	EE03L	2401-001917	E.CAPACITOR	1UF 20% 50V GP			EZD02	0403-000372	ZENER DIODE	UZ9.1BM 9.1V	
	EE03R	2401-001912	E.CAPACITOR	1UF 20% 50V			HC01L	2201-000642	C.CAPACITOR	0.68NF 10% 50V	
	EE04L	2401-001912	E.CAPACITOR	1UF 20% 50V			HC01R	2201-000642	C.CAPACITOR	0.68NF 10% 50V	
	EE04R	2401-001912	E.CAPACITOR	1UF 20% 50V			HC02L	2202-000781	C.CAPACITOR	100PF 10% 50V	
	EE05L	2401-001912	E.CAPACITOR	1UF 20% 50V			HC02R	2202-000781	C.CAPACITOR	100PF 10% 50V	
	EE05R	2401-001912	E.CAPACITOR	1UF 20% 50V			HC03L	2201-000389	C.CAPACITOR	0.022NF 5% 50V	
	EE06L	2401-001919	E.CAPACITOR	2.2UF 20% 50V			HC03R	2201-000389	C.CAPACITOR	0.022NF 5% 50V	
	EE06R	2401-001919	E.CAPACITOR	2.2UF 20% 50V			HE01L	2401-001912	E.CAPACITOR	1UF 20% 50V	
	EE07L	2401-001917	E.CAPACITOR	1UF 20% 50V GP			HE01R	2401-001912	E.CAPACITOR	1UF 20% 50V	
	EE07R	2401-001912	E.CAPACITOR	1UF 20% 50V			HE02L	2401-001164	E.CAPACITOR	33UF 20% 16V	
	EE08L	2401-001917	E.CAPACITOR	1UF 20% 50V GP			HE02R	2401-001164	E.CAPACITOR	33UF 20% 16V	
	EE08R	2401-001917	E.CAPACITOR	1UF 20% 50V GP			HE101	2401-000830	E.CAPACITOR	220UF 20% 25V	
	EE101	2401-000438	E.CAPACITOR	10UF 20% 25V			HE102	2401-000830	E.CAPACITOR	220UF 20% 25V	
	EE102	2401-001511	E.CAPACITOR	47UF 20% 16V			HE103	2401-001511	E.CAPACITOR	47UF 20% 16V	
	EE103	2401-000830	E.CAPACITOR	220UF 20% 25V			HIC01	1201-001285	IC	BA4556 SOP 8P	
	EE107	2401-001954	E.CAPACITOR	4.7UF 20% 50V			HQ01L	0501-002375	TRANSISTOR	KTC8050 NPN	
	EE108	2401-001954	E.CAPACITOR	4.7UF 20% 50V			HQ01R	0501-002375	TRANSISTOR	KTC8050 NPN	
	EE109	2401-000759	E.CAPACITOR	220NF 20% 50V			HR01L	2001-000449	CARBON RESISTOR	2.2K 5% 1/8W	
	EIC01	1204-001776	IC	TDA7442D			HR01R	2001-000449	CARBON RESISTOR	2.2K 5% 1/8W	
	EIC02	1201-000191	IC	BA4558 DIP 8P			HR02L	2001-000449	CARBON RESISTOR	2.2K 5% 1/8W	
	EJ101	3722-000379	PIN JACK	4P/2C 3.5MM			HR02R	2001-000449	CARBON RESISTOR	2.2K 5% 1/8W	
△	EPT01	AH26-80144W	TRANS POWER	SUB POWER TRANS			HR03L	2001-000734	CARBON RESISTOR	4.7K 5% 1/8W	
	EQ101	0501-002409	TRANSISTOR	KTC945B NPN			HR03R	2001-000734	CARBON RESISTOR	4.7K 5% 1/8W	
	ER01L	2001-000786	CARBON RESISTOR	47K 5% 1/8W			HR04L	2001-000290	CARBON RESISTOR	10K 5% 1/8W	
	ER01R	2001-000786	CARBON RESISTOR	47K 5% 1/8W			HR04R	2001-000290	CARBON RESISTOR	10K 5% 1/8W	
	ER02L	2001-000591	CARBON RESISTOR	3.3K 5% 1/8W			HR05L	2001-000019	CARBON RESISTOR	10 5% 1/2W	
	ER02R	2001-000591	CARBON RESISTOR	3.3K 5% 1/8W			HR05R	2001-000019	CARBON RESISTOR	10 5% 1/2W	
	ER03L	2001-000411	CARBON RESISTOR	18K 5% 1/8W			HR06L	2001-000591	CARBON RESISTOR	3.3K 5% 1/8W	
	ER03R	2001-000411	CARBON RESISTOR	18K 5% 1/8W			HR06R	2001-000591	CARBON RESISTOR	3.3K 5% 1/8W	
	ER04L	2001-000411	CARBON RESISTOR	18K 5% 1/8W			HR101	2001-000028	CARBON RESISTOR	100 5% 1/2W	
	ER04R	2001-000411	CARBON RESISTOR	18K 5% 1/8W			HR102	2001-000019	CARBON RESISTOR	10 5% 1/2W	
	ER05L	2001-000515	CARBON RESISTOR	220 5% 1/8W			HR103	2001-000890	CARBON RESISTOR	6.8K 5% 1/8W	
	ER05R	2001-000515	CARBON RESISTOR	220 5% 1/8W			HR104	2001-000290	CARBON RESISTOR	10K 5% 1/8W	
	ER06L	2001-000786	CARBON RESISTOR	47K 5% 1/8W			JC00R	2201-000368	C.CAPACITOR	0.22NF 10% 50V	
	ER06R	2001-000786	CARBON RESISTOR	47K 5% 1/8W			JC00L	2201-000368	C.CAPACITOR	0.22NF 10% 50V	
	ER07L	2001-000591	CARBON RESISTOR	3.3K 5% 1/8W			JC01L	2201-000642	C.CAPACITOR	0.68NF 10% 50V	
	ER07R	2001-000591	CARBON RESISTOR	3.3K 5% 1/8W			JC01R	2201-000642	C.CAPACITOR	0.68NF 10% 50V	
	ER08L	2001-000786	CARBON RESISTOR	47K 5% 1/8W			JC02L	2301-000379	M.CAPACITOR	10NF 10% 50V	
	ER08R	2001-000786	CARBON RESISTOR	47K 5% 1/8W			JC02R	2301-000379	M.CAPACITOR	10NF 10% 50V	
	ER09L	2001-000947	CARBON RESISTOR	7.5K 5% 1/8W			JC03L	2301-000375	M.CAPACITOR	100NF 10% 50V	
	ER09R	2001-000947	CARBON RESISTOR	7.5K 5% 1/8W			JC03R	2301-000375	M.CAPACITOR	100NF 10% 50V	
	ER10L	2001-000273	CARBON RESISTOR	100K 5% 1/8W			JC04L	2301-000375	M.CAPACITOR	100NF 10% 50V	
	ER10R	2001-000273	CARBON RESISTOR	100K 5% 1/8W			JC04R	2301-000375	M.CAPACITOR	100NF 10% 50V	
	ER101	2001-000515	CARBON RESISTOR	220 5% 1/8W			JC05L	2301-000430	M.CAPACITOR	33NF 10% 50V	
	ER102	2001-000515	CARBON RESISTOR	220 5% 1/8W			JC05R	2301-000430	M.CAPACITOR	33NF 10% 50V	
	ER103	2001-000023	CARBON RESISTOR	47 5% 1/4W			JC06L	2201-000674	C.CAPACITOR	0.82NF 10% 50V	



## ■ Electrical parts list (Main board)

Block No. 01

△	Item	Parts number	Parts name	Remarks	Area	△	Item	Parts number	Parts name	Remarks	Area
	JC06R	2201-000674	C.CAPACITOR	0.82NF 10% 50V			PCB	AH41-00555A	MAIN PCB		
	JC101	2201-000557	C.CAPACITOR	0.47NF 10% 50V		△	PC201	2201-000161	C.CAPACITOR	10NF +80-20%	
	JC102	2301-000407	M.CAPACITOR	2.7NF 10% 50V		△	PC202	2201-000161	C.CAPACITOR	10NF +80-20%	
	JC103	2301-000404	M.CAPACITOR	2.2NF 10% 50V		△	PC203	2201-000161	C.CAPACITOR	10NF +80-20%	
	JC104	2301-000404	M.CAPACITOR	2.2NF 10% 50V			PD101	0401-000101	DIODE	1N4148 100V	
	JC105	2202-000781	C.CAPACITOR	100PF 10% 50V			PD102	0402-000127	DIODE	1N4002 100V 1A	
	JC106	2202-000781	C.CAPACITOR	100PF 10% 50V			PD104	0402-000127	DIODE	1N4002 100V 1A	
	JC107	2202-000781	C.CAPACITOR	100PF 10% 50V			PD105	0402-000127	DIODE	1N4002 100V 1A	
	JC108	2202-000781	C.CAPACITOR	100PF 10% 50V			PD106	0402-000127	DIODE	1N4002 100V 1A	
	JC111	2202-000781	C.CAPACITOR	100PF 10% 50V			PD107	0402-000127	DIODE	1N4002 100V 1A	
	JD101	0401-000101	DIODE	1N4148 100V			PD108	0402-000127	DIODE	1N4002 100V 1A	
	JE01L	2401-002180	E.CAPACITOR	2.2UF 20% 50V			PD13	0402-000127	DIODE	1N4002 100V 1A	
	JE01R	2401-002180	E.CAPACITOR	2.2UF 20% 50V			PD201	0402-000127	DIODE	1N4002 100V 1A	
	JE02L	2401-002180	E.CAPACITOR	2.2UF 20% 50V			PD202	0402-000127	DIODE	1N4002 100V 1A	
	JE02R	2401-002180	E.CAPACITOR	2.2UF 20% 50V			PD204	0402-000127	DIODE	1N4002 100V 1A	
	JE101	2401-001511	E.CAPACITOR	47UF 20% 16V			PD205	0401-000101	DIODE	1N4148 100V	
	JE102	2401-001164	E.CAPACITOR	33UF 20% 16V			PD206	0401-000101	DIODE	1N4148 100V	
	JE103	2401-001912	E.CAPACITOR	1UF 20% 50V			PD208	0401-000101	DIODE	1N4148 100V	
	JE104	2401-001164	E.CAPACITOR	33UF 20% 16V			PD209	0402-000127	DIODE	1N4002 100V 1A	
	JE105	2401-000438	E.CAPACITOR	10UF 20% 25V			PD210	0402-000127	DIODE	1N4002 100V 1A	
	JE106	2401-002180	E.CAPACITOR	2.2UF 20% 50V			PE101	2401-001413	E.CAPACITOR	470UF 20% 35V	
	JIC01	1201-001899	IC	HA12237F QFP 40P			PE102	2401-001912	E.CAPACITOR	1UF 20% 50V	
	JL101	2701-000298	INDUCTOR	470UH 10%			PE103	2401-001954	E.CAPACITOR	4.7UF 20% 50V	
	JL102	AH26-10003C	TRANS TRAP COIL	PCHNS-5371EQJ		△	PE201	2401-002258	E.CAPACITOR	4700UF 20% 50V	
	JQ01L	0501-002375	TRANSISTOR	KTC8050 NPN		△	PE202	2401-002258	E.CAPACITOR	4700UF 20% 50V	
	JQ01R	0501-002375	TRANSISTOR	KTC8050 NPN		△	PE203	2401-003381	E.CAPACITOR	3300UF 20% 63V	
	JQ101	0501-002176	TRANSISTOR	KTD863 NPN 1W		△	PE204	2401-003381	E.CAPACITOR	3300UF 20% 63V	
	JQ102	0501-000422	TRANSISTOR	KTA1273 PNP		△	PE205	2401-003116	E.CAPACITOR	4700UF 20% 35V	
	JQ103	0501-002409	TRANSISTOR	KTC945B NPN			PE206	2401-000830	E.CAPACITOR	220UF 20% 25V	
	JQ104	0504-001128	DIGI TRANSISTOR	KRA103M PNP			PE207	2401-001938	E.CAPACITOR	22UF 20% 25V	
	JR01L	2001-000977	CARBON RESISTOR	8.2K 5% 1/8W			PE208	2401-000407	E.CAPACITOR	10UF 20% 16V	
	JR01R	2001-000977	CARBON RESISTOR	8.2K 5% 1/8W			PE209	2401-001912	E.CAPACITOR	1UF 20% 50V	
	JR02L	2001-000241	CARBON RESISTOR	1.5K 5% 1/8W			PE212	2401-000230	E.CAPACITOR	100UF 20% 100V	
	JR02R	2001-000241	CARBON RESISTOR	1.5K 5% 1/8W			PE213	2401-001954	E.CAPACITOR	4.7UF 20% 50V	
	JR03L	2001-000449	CARBON RESISTOR	2.2K 5% 1/8W			PE214	2401-000438	E.CAPACITOR	10UF 20% 25V	
	JR03R	2001-000449	CARBON RESISTOR	2.2K 5% 1/8W		△	PF101	2008-000135	FUSIBLE RESISTOR	1 5% 1/2W	
	JR04L	2001-000734	CARBON RESISTOR	4.7K 5% 1/8W		△	PIC01	AC14-12001G	IC	KA78L05	
	JR04R	2001-000734	CARBON RESISTOR	4.7K 5% 1/8W			PIC02	1203-001653	IC	L4959	
	JR05L	2001-000802	CARBON RESISTOR	5.6K 5% 1/8W			PL101	3501-001159	RELAY	12VDC 0.54W	
	JR05R	2001-000802	CARBON RESISTOR	5.6K 5% 1/8W			PL102	2701-000298	INDUCTOR	470UH 10%	
	JR06L	2001-000449	CARBON RESISTOR	2.2K 5% 1/8W			PL103	AH27-10001F	COIL	27UH	
	JR06R	2001-000449	CARBON RESISTOR	2.2K 5% 1/8W			PL104	AH27-10001F	COIL	27UH	
	JR07L	2001-000302	CARBON RESISTOR	10 5% 1/8W			PQ101	0501-002375	TRANSISTOR	KTC8050 NPN	
	JR07R	2001-000302	CARBON RESISTOR	10 5% 1/8W			PQ102	0504-000144	DIGI TRANSISTOR	KSR2002 PNP	
	JR08L	2001-000008	CARBON RESISTOR	15K 5% 1/8W			PQ103	0504-001123	DIGI TRANSISTOR	KRC103M NPN	
	JR08R	2001-000008	CARBON RESISTOR	15K 5% 1/8W			PQ104	0501-000331	TRANSISTOR	KSC1009-Y NPN	
	JR101	2001-000290	CARBON RESISTOR	10K 5% 1/8W			PQ105	0501-000422	TRANSISTOR	KTA1273 PNP	
	JR102	2001-000456	CARBON RESISTOR	2.2 5% 1/4W			PQ106	0501-002408	TRANSISTOR	MPS751 PNP	
	JR103	2001-000023	CARBON RESISTOR	47 5% 1/4W			PR101	2001-001195	CARBON RESISTOR	82 5% 1/2W	
	JR104	2001-000786	CARBON RESISTOR	47K 5% 1/8W			PR102	2001-000890	CARBON RESISTOR	6.8K 5% 1/8W	
	JR105	2001-000591	CARBON RESISTOR	3.3K 5% 1/8W			PR103	2001-000429	CARBON RESISTOR	1K 5% 1/8W	
	JR106	2001-000734	CARBON RESISTOR	4.7K 5% 1/8W			PR104	2001-000734	CARBON RESISTOR	4.7K 5% 1/8W	
	JR107	2001-000429	CARBON RESISTOR	1K 5% 1/8W			PR105	2001-000734	CARBON RESISTOR	4.7K 5% 1/8W	
	JR108	2001-000290	CARBON RESISTOR	10K 5% 1/8W			PR201	2001-000591	CARBON RESISTOR	3.3K 5% 1/8W	
	JR109	2001-000591	CARBON RESISTOR	3.3K 5% 1/8W			PR202	2001-000734	CARBON RESISTOR	4.7K 5% 1/8W	
	JR110	2001-000281	CARBON RESISTOR	100 5% 1/8W			PR203	2001-000429	CARBON RESISTOR	1K 5% 1/8W	
	JR112	2001-000435	CARBON RESISTOR	1M 5% 1/8W			PR204	2001-000786	CARBON RESISTOR	47K 5% 1/8W	
	JR113	2001-000522	CARBON RESISTOR	22K 5% 1/8W			PR205	2001-000290	CARBON RESISTOR	10K 5% 1/8W	
	JVR01	2103-000248	ROTA V RESISTOR	200K 30% 1/10W			PR206	2003-000455	CARBON RESISTOR	100 5% 2W	
	JVR02	2103-000248	ROTA V RESISTOR	200K 30% 1/10W			PR207	2001-000563	CARBON RESISTOR	27K 5% 1/8W	
△	PBD01	0402-001258	DIODE	GBU606 600V 6A			PR208	2001-000734	CARBON RESISTOR	4.7K 5% 1/8W	
△	PBD02	0402-001258	DIODE	GBU606 600V 6A			PR209	2001-000111	CARBON RESISTOR	150 5% 1/4W	
△	PBD03	0402-001077	DIODE	KBP202G 200V 2A			PR210	2001-000055	CARBON RESISTOR	4.7K 5% 1/4W	

 Electrical parts list (Main board)

Block No. 01

 Item	Parts number	Parts name	Remarks	Area
PR211	2001-000038	CARBON RESISTOR	390 5% 1/4W	
PR216	2003-000701	CARBON RESISTOR	470 5% 2W	
PR217	2001-001153	CARBON RESISTOR	47 5% 1/2W	
PR218	2001-001153	CARBON RESISTOR	47 5% 1/2W	
PR219	2001-000734	CARBON RESISTOR	4.7K 5% 1/8W	
PR220	2001-000290	CARBON RESISTOR	10K 5% 1/8W	
PR221	2001-000660	CARBON RESISTOR	33K 5% 1/8W	
PR222	2001-000319	CARBON RESISTOR	120K 5% 1/8W	
PW103	3711-000190	CONNECTOR	2P 1R 7.92MM	
PZD01	0403-000354	ZENER DIODE	UZ5.1B 5.1V	
PZ102	0403-000564	ZENER DIODE	TZP16A 16V	
PZ103	0403-000564	ZENER DIODE	TZP16A 16V	
PZ104	0403-000393	ZENER DIODE	UZP5.1B 5.1V	
PZ105	0403-000379	ZENER DIODE	UZP12B 12V	
 RFS9	3601-001334	FUSE	250V 5A	



## ■ Electrical parts list (Front board)

Block No. 02

△	Item	Parts number	Parts name	Remarks	Area	△	Item	Parts number	Parts name	Remarks	Area
	BUZZ1	3002-001134	BUZZER	85DB 12V			FR203	2001-000034	CARBON RESISTOR	220 5% 1/4W	
	CW01B	AH39-00247A	LEAD CONNECTOR				FR204	2001-000855	CARBON RESISTOR	560 5% 1/4W	
	FR101	2001-000734	CARBON RESISTOR	4.7K 5% 1/8W			FR205	2001-000995	CARBON RESISTOR	820 5% 1/8W	
	FR102	2001-000734	CARBON RESISTOR	4.7K 5% 1/8W			FR206	2001-000429	CARBON RESISTOR	1K 5% 1/8W	
	FR103	2001-000734	CARBON RESISTOR	4.7K 5% 1/8W			FR207	2001-000221	CARBON RESISTOR	1.2K 5% 1/8W	
	FR104	2001-000734	CARBON RESISTOR	4.7K 5% 1/8W			FR208	2001-000241	CARBON RESISTOR	1.5K 5% 1/8W	
	FR105	2001-000734	CARBON RESISTOR	4.7K 5% 1/8W			FR209	2001-000258	CARBON RESISTOR	1.8K 5% 1/8W	
	FR106	2001-000734	CARBON RESISTOR	4.7K 5% 1/8W			FR210	2001-000449	CARBON RESISTOR	2.2K 5% 1/8W	
	FR107	2001-000734	CARBON RESISTOR	4.7K 5% 1/8W			FSR01	2103-000341	VR SEMI	2K 30% 1/10W	
	FR108	2001-000734	CARBON RESISTOR	4.7K 5% 1/8W			HC201	2202-000807	C.CAPACITOR	22NF +80-20%	
	FR109	2001-000734	CARBON RESISTOR	4.7K 5% 1/8W			HC202	2202-000807	C.CAPACITOR	22NF +80-20%	
	FR110	2001-000734	CARBON RESISTOR	4.7K 5% 1/8W			HC203	2202-000850	C.CAPACITOR	2.2NF 20%	
	FR111	2001-000734	CARBON RESISTOR	4.7K 5% 1/8W			HC204	2202-000850	C.CAPACITOR	2.2NF 20%	
	FR112	2001-000734	CARBON RESISTOR	4.7K 5% 1/8W			HD201	0401-000101	DIODE	1N4148 100V	
	FR113	2001-000734	CARBON RESISTOR	4.7K 5% 1/8W			HJACK	3722-000351	PHONE JACK	11P 3.5PI AG	
	FR114	2001-000734	CARBON RESISTOR	4.7K 5% 1/8W			HJ201	3811-000389	WIRE-NO SHEATH CU	SPCW 300V	
	FR115	2001-000734	CARBON RESISTOR	4.7K 5% 1/8W			HR201	2001-000429	CARBON RESISTOR	1K 5% 1/8W	
	FR116	2001-000734	CARBON RESISTOR	4.7K 5% 1/8W			LD101	0601-001739	LED	ROUND RED	
	FR117	2001-000734	CARBON RESISTOR	4.7K 5% 1/8W			LD102	0601-001739	LED	ROUND RED	
	FR118	2001-000786	CARBON RESISTOR	47K 5% 1/8W			LD103	0601-001739	LED	ROUND RED	
	FR119	2001-000786	CARBON RESISTOR	47K 5% 1/8W			LD104	0601-001739	LED	ROUND RED	
	FR120	2001-000786	CARBON RESISTOR	47K 5% 1/8W			LD105	0601-001739	LED	ROUND RED	
	FR121	2001-000786	CARBON RESISTOR	47K 5% 1/8W			LD106	0601-001739	LED	ROUND RED	
	FR122	2001-000786	CARBON RESISTOR	47K 5% 1/8W			LD107	0601-001739	LED	ROUND RED	
	FR123	2001-000786	CARBON RESISTOR	47K 5% 1/8W			LD108	0601-001739	LED	ROUND RED	
	FR124	2001-000786	CARBON RESISTOR	47K 5% 1/8W			LD201	0601-001739	LED	ROUND RED	
	FR125	2001-000786	CARBON RESISTOR	47K 5% 1/8W			LD202	0601-001739	LED	ROUND RED	
	FR126	2001-000786	CARBON RESISTOR	47K 5% 1/8W			LD203	0601-001739	LED	ROUND RED	
	FR127	2001-000786	CARBON RESISTOR	47K 5% 1/8W			LD204	0601-001739	LED	ROUND RED	
	FR128	2001-000786	CARBON RESISTOR	47K 5% 1/8W			PCB	AH41-00552A	FRONT PCB		
	FR129	2001-000786	CARBON RESISTOR	47K 5% 1/8W			SW101	3404-001048	TACT SWITCH	DC12V 50MA	
	FR130	2001-000786	CARBON RESISTOR	47K 5% 1/8W			SW102	3404-001048	TACT SWITCH	DC12V 50MA	
	FR131	2001-000786	CARBON RESISTOR	47K 5% 1/8W			SW103	3404-001048	TACT SWITCH	DC12V 50MA	
	FR132	2001-000786	CARBON RESISTOR	47K 5% 1/8W			SW104	3404-001048	TACT SWITCH	DC12V 50MA	
	FR133	2001-000786	CARBON RESISTOR	47K 5% 1/8W			SW105	3404-001048	TACT SWITCH	DC12V 50MA	
	FR134	2001-000786	CARBON RESISTOR	47K 5% 1/8W			SW106	3404-001048	TACT SWITCH	DC12V 50MA	
	FR135	2001-000786	CARBON RESISTOR	47K 5% 1/8W			SW107	3404-001048	TACT SWITCH	DC12V 50MA	
	FR136	2001-000786	CARBON RESISTOR	47K 5% 1/8W			SW201	3404-001048	TACT SWITCH	DC12V 50MA	
	FR140	2001-000995	CARBON RESISTOR	820 5% 1/8W			SW202	3404-001048	TACT SWITCH	DC12V 50MA	
	FR141	2001-000429	CARBON RESISTOR	1K 5% 1/8W			SW203	3404-001048	TACT SWITCH	DC12V 50MA	
	FR142	2001-000221	CARBON RESISTOR	1.2K 5% 1/8W			SW204	3404-001048	TACT SWITCH	DC12V 50MA	
	FR143	2001-000241	CARBON RESISTOR	1.5K 5% 1/8W			SW205	3404-001048	TACT SWITCH	DC12V 50MA	
	FR144	2001-000258	CARBON RESISTOR	1.8K 5% 1/8W			SW206	3404-001048	TACT SWITCH	DC12V 50MA	
	FR145	2001-000449	CARBON RESISTOR	2.2K 5% 1/8W			SW207	3404-001048	TACT SWITCH	DC12V 50MA	
	FR146	2001-000591	CARBON RESISTOR	3.3K 5% 1/8W			SW208	3404-001048	TACT SWITCH	DC12V 50MA	
	FR147	2001-000890	CARBON RESISTOR	6.8K 5% 1/8W			SW209	3404-001048	TACT SWITCH	DC12V 50MA	
	FR148	2001-000734	CARBON RESISTOR	4.7K 5% 1/8W			SW210	3404-001048	TACT SWITCH	DC12V 50MA	
	FR149	2001-000290	CARBON RESISTOR	10K 5% 1/8W			SW211	3404-001048	TACT SWITCH	DC12V 50MA	
	FR150	2001-000522	CARBON RESISTOR	22K 5% 1/8W			SW212	3404-001048	TACT SWITCH	DC12V 50MA	
	FR151	2001-000010	CARBON RESISTOR	68K 5% 1/8W			SW301	3404-001048	TACT SWITCH	DC12V 50MA	
	FR152	2001-000995	CARBON RESISTOR	820 5% 1/8W			SW302	3404-001048	TACT SWITCH	DC12V 50MA	
	FR153	2001-000429	CARBON RESISTOR	1K 5% 1/8W			SW303	3404-001048	TACT SWITCH	DC12V 50MA	
	FR154	2001-000221	CARBON RESISTOR	1.2K 5% 1/8W			SW304	3404-001048	TACT SWITCH	DC12V 50MA	
	FR155	2001-000241	CARBON RESISTOR	1.5K 5% 1/8W			SW305	3404-001048	TACT SWITCH	DC12V 50MA	
	FR156	2001-000258	CARBON RESISTOR	1.8K 5% 1/8W			SW306	3404-001048	TACT SWITCH	DC12V 50MA	
	FR157	2001-000449	CARBON RESISTOR	2.2K 5% 1/8W			SW307	3404-001048	TACT SWITCH	DC12V 50MA	
	FR158	2001-000591	CARBON RESISTOR	3.3K 5% 1/8W			SW308	3404-001048	TACT SWITCH	DC12V 50MA	
	FR159	2001-000734	CARBON RESISTOR	4.7K 5% 1/8W			SW309	3404-001048	TACT SWITCH	DC12V 50MA	
	FR160	2001-000890	CARBON RESISTOR	6.8K 5% 1/8W			SW310	3404-001048	TACT SWITCH	DC12V 50MA	
	FR161	2001-000290	CARBON RESISTOR	10K 5% 1/8W			SW311	3404-001048	TACT SWITCH	DC12V 50MA	
	FR162	2001-000522	CARBON RESISTOR	22K 5% 1/8W			SW312	3404-001048	TACT SWITCH	DC12V 50MA	
	FR201	2001-000034	CARBON RESISTOR	220 5% 1/4W			SW313	3404-001048	TACT SWITCH	DC12V 50MA	
	FR202	2001-000034	CARBON RESISTOR	220 5% 1/4W			UCW01	3708-001577	CONNECTOR	30P 1.25MM	



## ■ Electrical parts list (Front board)

Block No. 02

△	Item	Parts number	Parts name	Remarks	Area	△	Item	Parts number	Parts name	Remarks	Area
	UCW02	3708-000492	CONNECTOR	9P 1.25MM			UR102	2001-000734	CARBON RESISTOR	4.7K 5% 1/8W	
	UCW03	3708-000492	CONNECTOR	9P 1.25MM			UR103	2001-000508	CARBON RESISTOR	220K 5% 1/8W	
	UCW04	3708-000454	CONNECTOR	22P 1.25MM			UR104	2001-000793	CARBON RESISTOR	47 5% 1/8W	
	UCW05	3708-000178	CONNECTOR	16P 1.25MM			UR105	2001-000295	CARBON RESISTOR	10M 5% 1/8W	
	UC001	2201-000783	C.CAPACITOR	100NF +80-20% 50V			UR106	2001-000850	CARBON RESISTOR	560K 5% 1/8W	
	UC101	2401-002180	E.CAPACITOR	2.2UF 20% 50V			UR107	2001-000435	CARBON RESISTOR	1M 5% 1/8W	
	UC102	2401-000759	E.CAPACITOR	220NF 20% 50V			UR108	2001-000290	CARBON RESISTOR	10K 5% 1/8W	
	UC103	2401-001355	E.CAPACITOR	470UF 20% 10V			UR109	2001-000290	CARBON RESISTOR	10K 5% 1/8W	
	UC104	2401-000240	E.CAPACITOR	100UF 20% 10V			UR110	2001-000290	CARBON RESISTOR	10K 5% 1/8W	
	UC105	2201-000389	C.CAPACITOR	0.022NF 5% 50V			UR111	2001-000290	CARBON RESISTOR	10K 5% 1/8W	
	UC106	2201-000389	C.CAPACITOR	0.022NF 5% 50V			UR112	2001-000290	CARBON RESISTOR	10K 5% 1/8W	
	UC107	2202-000854	C.CAPACITOR	47NF 30% 50V			UR113	2001-000429	CARBON RESISTOR	1K 5% 1/8W	
	UC108	2202-000854	C.CAPACITOR	47NF 30% 50V			UR114	2001-000429	CARBON RESISTOR	1K 5% 1/8W	
	UC109	2202-000796	C.CAPACITOR	1NF 10% 50V			UR115	2001-000429	CARBON RESISTOR	1K 5% 1/8W	
	UC110	2201-000565	C.CAPACITOR	47NF +80-20% 50V			UR116	2001-000429	CARBON RESISTOR	1K 5% 1/8W	
	UC111	2401-000475	E.CAPACITOR	10UF 20% 50V			UR117	2001-000281	CARBON RESISTOR	100 5% 1/8W	
	UC112	2202-000854	C.CAPACITOR	47NF 30% 50V			UR118	2001-000281	CARBON RESISTOR	100 5% 1/8W	
	UC113	2401-000475	E.CAPACITOR	10UF 20% 50V			UR119	2001-000281	CARBON RESISTOR	100 5% 1/8W	
	UC114	2201-000783	C.CAPACITOR	100NF +80-20% 50V			UR120	2001-000281	CARBON RESISTOR	100 5% 1/8W	
	UC115	2401-000240	E.CAPACITOR	100UF 20% 10V			UR121	2001-000290	CARBON RESISTOR	10K 5% 1/8W	
	UC116	2401-001364	E.CAPACITOR	470UF 20% 16V			UR122	2001-000281	CARBON RESISTOR	100 5% 1/8W	
	UC118	2401-000830	E.CAPACITOR	220UF 20%			UR123	2001-000281	CARBON RESISTOR	100 5% 1/8W	
	UC130	2401-000240	E.CAPACITOR	100UF 20% 10V			UR124	2001-000281	CARBON RESISTOR	100 5% 1/8W	
	UC131	2201-000783	C.CAPACITOR	100NF +80-20% 50V			UR125	2001-000281	CARBON RESISTOR	100 5% 1/8W	
	UC132	2202-000780	C.CAPACITOR	100NF +80-20% 50V			UR126	2001-000281	CARBON RESISTOR	100 5% 1/8W	
	UC133	2202-000780	C.CAPACITOR	100NF +80-20% 50V			UR127	2001-000281	CARBON RESISTOR	100 5% 1/8W	
	UC135	2202-000781	C.CAPACITOR	100PF 10% 50V			UR128	2001-000281	CARBON RESISTOR	100 5% 1/8W	
	UC137	2401-001572	E.CAPACITOR	47UF 20% 50V			UR129	2001-000290	CARBON RESISTOR	10K 5% 1/8W	
	UC138	2401-001511	E.CAPACITOR	47UF 20% 16V			UR130	2001-000290	CARBON RESISTOR	10K 5% 1/8W	
	UD05	0401-000101	DIODE	1N4148 100V			UR131	2001-000290	CARBON RESISTOR	10K 5% 1/8W	
	UD06	0401-000101	DIODE	1N4148 100V			UR132	2001-000290	CARBON RESISTOR	10K 5% 1/8W	
	UD101	0401-000101	DIODE	1N4148 100V			UR133	2001-000290	CARBON RESISTOR	10K 5% 1/8W	
	UD102	0401-000101	DIODE	1N4148 100V			UR134	2001-000290	CARBON RESISTOR	10K 5% 1/8W	
	UD103	0402-000127	DIODE	1N4002 100V 1A			UR135	2001-000290	CARBON RESISTOR	10K 5% 1/8W	
	UD104	0401-000101	DIODE	1N4148 100V			UR136	2001-000290	CARBON RESISTOR	10K 5% 1/8W	
	UD105	0402-000127	DIODE	1N4002 100V 1A			UR137	2001-000290	CARBON RESISTOR	10K 5% 1/8W	
	UD106	0402-000127	DIODE	1N4002 100V 1A			UR138	2001-000290	CARBON RESISTOR	10K 5% 1/8W	
	UD107	0402-000127	DIODE	1N4002 100V 1A			UR139	2001-000290	CARBON RESISTOR	10K 5% 1/8W	
	UD108	0402-000127	DIODE	1N4002 100V 1A			UR140	2001-000290	CARBON RESISTOR	10K 5% 1/8W	
	UD109	0402-000127	DIODE	1N4002 100V 1A			UR141	2001-000290	CARBON RESISTOR	10K 5% 1/8W	
	UD110	0402-000127	DIODE	1N4002 100V 1A			UR142	2001-000290	CARBON RESISTOR	10K 5% 1/8W	
	UD25	0401-000101	DIODE	1N4148 100V			UR143	2001-000290	CARBON RESISTOR	10K 5% 1/8W	
	UIC01	AH11-00095B	MASK ROM	LC876764C			UR144	2001-000290	CARBON RESISTOR	10K 5% 1/8W	
	UIC02	AC59-60060A	MODULE REMOCON	GP1U281R			UR145	2001-000522	CARBON RESISTOR	22K 5% 1/8W	
	UIC03	0904-001621	IC	PT8300 SOP 28P			UR146	2001-000522	CARBON RESISTOR	22K 5% 1/8W	
	UIC04	0904-001621	IC	PT8300 SOP 28P			UR147	2001-000522	CARBON RESISTOR	22K 5% 1/8W	
	UQ101	0501-002409	TRANSISTOR	KTC945B NPN			UR148	2001-000449	CARBON RESISTOR	2.2K 5% 1/8W	
	UQ102	0504-001123	DIGI TRANSISTOR	KRC103M NPN			UR149	2001-000734	CARBON RESISTOR	4.7K 5% 1/8W	
	UQ103	0504-001123	DIGI TRANSISTOR	KRC103M NPN			UR150	2001-000522	CARBON RESISTOR	22K 5% 1/8W	
	UQ104	0504-001123	DIGI TRANSISTOR	KRC103M NPN			UR152	2001-000034	CARBON RESISTOR	220 5% 1/4W	
	UQ107	0501-000422	TRANSISTOR	KTA1273 PNP			UR153	2001-000034	CARBON RESISTOR	220 5% 1/4W	
	UQ108	0501-000422	TRANSISTOR	KTA1273 PNP			UR154	2001-000034	CARBON RESISTOR	220 5% 1/4W	
	UQ109	0501-000422	TRANSISTOR	KTA1273 PNP			UR155	2001-000034	CARBON RESISTOR	220 5% 1/4W	
	UQ118	0501-002375	TRANSISTOR	KTC8050 NPN			UR156	2001-000034	CARBON RESISTOR	220 5% 1/4W	
	UQ119	0501-002375	TRANSISTOR	KTC8050 NPN			UR157	2001-000034	CARBON RESISTOR	220 5% 1/4W	
	UQ120	0501-002375	TRANSISTOR	KTC8050 NPN			UR158	2001-000034	CARBON RESISTOR	220 5% 1/4W	
	UQ201	0502-001063	TR POWER	KTD2092 NPN			UR159	2001-000034	CARBON RESISTOR	220 5% 1/4W	
	UR001	2001-000429	CARBON RESISTOR	1K 5% 1/8W			UR160	2001-001178	CARBON RESISTOR	680 5% 1/2W	
	UR002	2001-000290	CARBON RESISTOR	10K 5% 1/8W			UR161	2001-001178	CARBON RESISTOR	680 5% 1/2W	
	UR003	2003-000500	OMF RESISTOR	150 5% 1W			UR162	2001-001178	CARBON RESISTOR	680 5% 1/2W	
	UR004	2001-000429	CARBON RESISTOR	1K 5% 1/8W			UR166	2001-000613	CARBON RESISTOR	3.9K 5% 1/8W	
	UR100	2001-000734	CARBON RESISTOR	4.7K 5% 1/8W			UR170	2001-000290	CARBON RESISTOR	10K 5% 1/8W	
	UR101	2001-000449	CARBON RESISTOR	2.2K 5% 1/8W			UR171	2001-000290	CARBON RESISTOR	10K 5% 1/8W	

## ■ Electrical parts list (Front board)

Block No. 02

△	Item	Parts number	Parts name	Remarks	Area
	UR172	2001-000786	CARBON RESISTOR	47K 5% 1/8W	
	UR173	2001-000786	CARBON RESISTOR	47K 5% 1/8W	
	UR180	2001-000008	CARBON RESISTOR	15K 5% 1/8W	
	UR181	2001-000660	CARBON RESISTOR	33K 5% 1/8W	
	UR182	2001-000281	CARBON RESISTOR	100 5% 1/8W	
	UR183	2001-000786	CARBON RESISTOR	47K 5% 1/8W	
	UR184	2001-000786	CARBON RESISTOR	47K 5% 1/8W	
	UX101	2801-001394	CRYSTAL	32.768KHZ 20PPM	
	UX102	2802-001174	RESONATOR	10MHZ 0.5%	
	VFD	AH07-00098A	VFD	BJ904GNK	
	VR101	3406-001085	ROTARY SWITCH	NO CLICK	
	VR102	3406-001084	ROTARY SWITCH	CLICK	
	VR103	3406-001084	ROTARY SWITCH	CLICK	
	ZD101	0403-000334	ZENER DIODE	UZ2.7BSA 2.7V	
	ZD102	0403-000334	ZENER DIODE	UZ2.7BSA 2.8V	
	ZD103	0403-000334	ZENER DIODE	UZ2.7BSA 2.9V	
	ZD104	0403-000361	ZENER DIODE	UZ6.2BSB 6.2V	

## ■ Electrical parts list (Amp. board)

Block No. 03

△	Item	Parts number	Parts name	Remarks	Area	△	Item	Parts number	Parts name	Remarks	Area
	ACE1	2202-000817	C.CAPACITOR	4.7NF 20% 16V			AL20R	AH27-90001A	COIL SPRING	2.2UH	
	ACE4	2202-000817	C.CAPACITOR	4.7NF 20% 16V			AL21L	AH27-90001A	COIL SPRING	2.2UH	
	ACW1	3708-001167	CONNECTOR	14P 1.25MM			AL21R	AH27-90001A	COIL SPRING	2.2UH	
	ACW2	3711-003113	CONNECTOR	9P 1R 2.5MM			AQ10R	0501-002375	TRANSISTOR	KTC8050 NPN	
	AC10L	2202-000263	C.CAPACITOR	470PF 10% 50V			AQ10L	0501-002375	TRANSISTOR	KTC8050 NPN	
	AC10R	2202-000263	C.CAPACITOR	470PF 10% 50V			AQ100	0501-002375	TRANSISTOR	KTC8050 NPN	
	AC11L	2201-000557	C.CAPACITOR	0.47NF 10% 50V			AQ200	0501-002375	TRANSISTOR	KTC8050 NPN	
	AC11R	2201-000557	C.CAPACITOR	0.47NF 10% 50V			AQ301	0501-000010	TRANSISTOR	KSC1008 NPN	
	AC12L	2201-000838	C.CAPACITOR	0.003NF 0.25PF 50V			AQ50L	0501-002375	TRANSISTOR	KTC8050 NPN	
	AC12R	2201-000838	C.CAPACITOR	0.003NF 0.25PF 50V			AQ50R	0501-002375	TRANSISTOR	KTC8050 NPN	
	AC13L	2301-000375	M.CAPACITOR	100NF 10% 50V			AQ603	0501-002375	TRANSISTOR	KTC8050 NPN	
	AC13R	2301-000375	M.CAPACITOR	100NF 10% 50V			ARL1	3501-001197	RELAY	12VDC 0.54W 44.4MA	
	AC14L	2202-000817	C.CAPACITOR	4.7NF 20% 16V			AR10L	2001-000591	CARBON RESISTOR	3.3K 5% 1/8W	
	AC14R	2202-000817	C.CAPACITOR	4.7NF 20% 16V			AR10R	2001-000591	CARBON RESISTOR	3.3K 5% 1/8W	
	AC20L	2202-000263	C.CAPACITOR	470PF 10% 50V			AR101	2003-000008	OMF RESISTOR	100 5% 1W	
	AC20R	2202-000263	C.CAPACITOR	470PF 10% 50V			AR102	2001-000660	CARBON RESISTOR	33K 5% 1/8W	
	AC21L	2202-000781	C.CAPACITOR	100PF 10% 50V			AR103	2001-000429	CARBON RESISTOR	1K 5% 1/8W	
	AC21R	2202-000781	C.CAPACITOR	100PF 10% 50V			AR11L	2001-000429	CARBON RESISTOR	1K 5% 1/8W	
	AC22L	2201-000838	C.CAPACITOR	0.003NF 0.25PF 50V			AR11R	2001-000429	CARBON RESISTOR	1K 5% 1/8W	
	AC22R	2201-000838	C.CAPACITOR	0.003NF 0.25PF 50V			AR12L	2001-000864	CARBON RESISTOR	56K 5% 1/8W	
	AC23L	2202-000817	C.CAPACITOR	4.7NF 20% 16V			AR12R	2001-000864	CARBON RESISTOR	56K 5% 1/8W	
	AC23R	2202-000817	C.CAPACITOR	4.7NF 20% 16V			AR13L	2001-000472	CARBON RESISTOR	2.7K 5% 1/8W	
	AC24L	2202-000817	C.CAPACITOR	4.7NF 20% 16V			AR13R	2001-000472	CARBON RESISTOR	2.7K 5% 1/8W	
	AC24R	2202-000817	C.CAPACITOR	4.7NF 20% 16V			AR14L	2001-000258	CARBON RESISTOR	1.8K 5% 1/8W	
	AC25L	2301-000375	M.CAPACITOR	100NF 10% 50V			AR14R	2001-001055	CARBON RESISTOR	1.8K 5% 1/2W	
	AC25R	2301-000375	M.CAPACITOR	100NF 10% 50V			AR15L	2003-000390	OMF RESISTOR	0.27 5% 2W	
	AC50L	2201-000381	C.CAPACITOR	22NF +80% 50V			AR15R	2003-000390	OMF RESISTOR	0.27 5% 2W	
	AC50R	2201-000381	C.CAPACITOR	22NF +80% 50V			AR16L	2001-000017	CARBON RESISTOR	4.7 5% 1/4W	
	AC51L	2201-000381	C.CAPACITOR	22NF +80% 50V			AR16R	2001-000017	CARBON RESISTOR	4.7 5% 1/4W	
	AC51R	2201-000381	C.CAPACITOR	22NF +80% 50V			AR17L	2003-000689	OMF RESISTOR	4.7 5% 1W	
	AC603	2201-000783	C.CAPACITOR	100NF +80-20% 50V			AR17R	2003-000689	OMF RESISTOR	4.7 5% 1W	
	AC604	2201-000783	C.CAPACITOR	100NF +80-20% 50V			AR18L	2001-000010	CARBON RESISTOR	68K 5% 1/8W	
	AC607	2201-000547	C.CAPACITOR	4.7NF 20% 500V			AR18R	2001-000010	CARBON RESISTOR	68K 5% 1/8W	
	AC608	2201-000547	C.CAPACITOR	4.7NF 20% 500V			AR20L	2001-000429	CARBON RESISTOR	1K 5% 1/8W	
	AD100	0401-000101	DIODE	1N4148 100V			AR20R	2001-000429	CARBON RESISTOR	1K 5% 1/8W	
	AD200	0401-000101	DIODE	1N4148 100V			AR200	2001-000258	CARBON RESISTOR	1.8K 5% 1/8W	
	AD303	0402-000127	DIODE	1N4002 100V 1A			AR201	2001-000660	CARBON RESISTOR	33K 5% 1/8W	
	AE10L	2401-002180	E.CAPACITOR	2.2UF 20% 50V			AR202	2001-000429	CARBON RESISTOR	1K 5% 1/8W	
	AE10R	2401-002180	E.CAPACITOR	2.2UF 20% 50V			AR203	2003-000008	OMF RESISTOR	100 5% 1W	
	AE100	2401-000357	E.CAPACITOR	100UF 0.2 50V			AR204	2001-000331	CARBON RESISTOR	12K 5% 1/8W	
	AE101	2401-001164	E.CAPACITOR	33UF 20% 16V			AR21L	2001-000864	CARBON RESISTOR	56K 5% 1/8W	
	AE102	2401-000357	E.CAPACITOR	100UF 0.2 50V			AR21R	2001-000864	CARBON RESISTOR	56K 5% 1/8W	
	AE103	2401-000357	E.CAPACITOR	100UF 0.2 50V			AR22L	2001-000258	CARBON RESISTOR	1.8K 5% 1/8W	
	AE11L	2401-000438	E.CAPACITOR	10UF 20% 25V			AR22R	2001-000258	CARBON RESISTOR	1.8K 5% 1/8W	
	AE11R	2401-000438	E.CAPACITOR	10UF 20% 25V			AR23L	2001-000864	CARBON RESISTOR	56K 5% 1/8W	
	AE20L	2401-002180	E.CAPACITOR	2.2UF 20% 50V			AR23R	2001-000864	CARBON RESISTOR	56K 5% 1/8W	
	AE20R	2401-002180	E.CAPACITOR	2.2UF 20% 50V			AR24L	2003-000390	OMF RESISTOR	0.27 5% 2W	
	AE201	2401-001164	E.CAPACITOR	33UF 20% 16V			AR24R	2003-000390	OMF RESISTOR	0.27 5% 2W	
	AE202	2401-000230	E.CAPACITOR	100UF 20% 100V			AR25L	2001-000017	CARBON RESISTOR	4.7 5% 1/4W	
	AE203	2401-000230	E.CAPACITOR	100UF 20% 100V			AR25R	2001-000017	CARBON RESISTOR	4.7 5% 1/4W	
	AE204	2401-000230	E.CAPACITOR	100UF 20% 100V			AR27L	2003-000689	OMF RESISTOR	4.7 5% 1W	
	AE21L	2401-000438	E.CAPACITOR	10UF 20% 25V			AR27R	2003-000689	OMF RESISTOR	4.7 5% 1W	
	AE21R	2401-000438	E.CAPACITOR	10UF 20% 25V			AR301	2001-000449	CARBON RESISTOR	2.2K 5% 1/8W	
	AE50L	2401-000459	E.CAPACITOR	10UF 20% 35V			AR302	2001-000273	CARBON RESISTOR	100K 5% 1/8W	
	AE50R	2401-000459	E.CAPACITOR	10UF 20% 35V			AR303	2001-000515	CARBON RESISTOR	220 5% 1/8W	
	AE500	2401-001893	E.CAPACITOR	100UF 20% 16V			AR50L	2001-000864	CARBON RESISTOR	56K 5% 1/8W	
	AE501	2401-001893	E.CAPACITOR	100UF 20% 16V			AR50R	2001-000864	CARBON RESISTOR	56K 5% 1/8W	
	AJW9	2001-000331	CARBON RESISTOR	12K 5% 1/8W			AR500	2001-000281	CARBON RESISTOR	100 5% 1/8W	
	AL10L	AH27-90001A	COIL SPRING	2.2UH			AR501	2001-000281	CARBON RESISTOR	100 5% 1/8W	
	AL10R	AH27-90001A	COIL SPRING	2.2UH			AR51L	2001-001000	CARBON RESISTOR	82K 5% 1/8W	
	AL11L	AH27-90001A	COIL SPRING	2.2UH			AR51R	2001-001000	CARBON RESISTOR	82K 5% 1/8W	
	AL11R	AH27-90001A	COIL SPRING	2.2UH			AR52L	2001-000429	CARBON RESISTOR	1K 5% 1/8W	
	AL20L	AH27-90001A	COIL SPRING	2.2UH			AR52R	2001-000429	CARBON RESISTOR	1K 5% 1/8W	

## ■ Electrical parts list (Amp. board)

Block No. 03

△	Item	Parts number	Parts name	Remarks	Area
	AR53L	2001-000522	CARBON RESISTOR	22K 5% 1/8W	
	AR53R	2001-000522	CARBON RESISTOR	22K 5% 1/8W	
	AR54L	2001-000786	CARBON RESISTOR	47K 5% 1/8W	
	AR54R	2001-000786	CARBON RESISTOR	47K 5% 1/8W	
	AR55L	2001-000591	CARBON RESISTOR	3.3K 5% 1/8W	
	AR55R	2001-000591	CARBON RESISTOR	3.3K 5% 1/8W	
	AR603	2001-000591	CARBON RESISTOR	3.3K 5% 1/8W	
△	FIC01	1201-001955	IC POWER AMP	STK403-070 14P	
	FIC02	1201-000191	IC	BA4558 DIP 8P	
	HRFS2	3602-000147	FUSE CLIP		
	HRFS5	3602-000147	FUSE CLIP		
	HRFS6	3602-000147	FUSE CLIP		
	HRFS7	3602-000147	FUSE CLIP		
	HRFS8	3602-000147	FUSE CLIP		
	PCB	AH41-00553A	AMP PCB		
	PCW1	3711-000588	CONNECTOR	10P 1R 2.5MM	
	PC101	2201-000546	C.CAPACITOR	4.7NF 20% 400V	
	PC102	2201-000546	C.CAPACITOR	4.7NF 20% 400V	
	PL101	AH27-10001F	COIL	27UH	
	PL102	AH27-10001F	COIL	27UH	
	PW102	AH37-22001N	CONNECTOR JACK	10MM YFW800-02	
△	RFS2	3601-000282	FUSE	250V 4A	
△	RFS5	3601-000301	FUSE	250V 6.3A	
△	RFS6	3601-000301	FUSE	250V 6.3A	
△	RFS7	3601-001290	FUSE	250V 8A	
△	RFS8	3601-001290	FUSE	250V 8A	
	SPK	3716-001208	TERMINAL BLOCK	SOLDER 8P 12.5MM	
△	WIC01	1201-001963	IC-POWER AMP	STK403-100 SIP 14P	



## ■ Electrical parts list (CD board)

Block No. 04

△	Item	Parts number	Parts name	Remarks	Area	△	Item	Parts number	Parts name	Remarks	Area
	CW101	3708-001252	CONNECTOR	16P 1MM			C402	2203-000260	CHIP CAPACITOR	10NF 10% 50V	
	CW102	AH39-20561P	LEAD CONNECTOR	6P 150MM			C403	2203-000203	CHIP CAPACITOR	100NF 10% 16V	
	CW103	3708-001131	CONNECTOR	5P 1.25MM			C501L	2401-001954	E.CAPACITOR	4.7UF 20% 50V	
	CW104	3711-003379	CONNECTOR	3P 1R 2.5MM			C501R	2401-001954	E.CAPACITOR	4.7UF 20% 50V	
	CW105	3708-001438	CONNECTOR	22P 1.25MM			C502L	2203-001537	CHIP CAPACITOR	1NF 10% 50V	
	CW106	AH39-00060A	LEAD CONNECTOR	51015-08 51004-08			C502R	2203-001537	CHIP CAPACITOR	1NF 10% 50V	
	CW107	3711-000906	CONNECTOR	3P 1R 2MM			C601	2203-000260	CHIP CAPACITOR	10NF 10% 50V	
	C101	2401-000240	E.CAPACITOR	100UF 20% 10V			C602	2203-000260	CHIP CAPACITOR	10NF 10% 50V	
	C102	2203-001537	CHIP CAPACITOR	1NF 10% 50V			C603	2401-000240	E.CAPACITOR	100UF 20% 10V	
	C103	2203-001551	CHIP CAPACITOR	1.5NF 10% 50V			C603A	2202-000780	C.CAPACITOR	100NF +80-20% 50V	
	C104	2203-001551	CHIP CAPACITOR	1.5NF 10% 50V			C604	2203-000203	CHIP CAPACITOR	100NF 10% 16V	
	C105	2203-000609	CHIP CAPACITOR	22NF 10% 50V			C605	2203-001223	CHIP CAPACITOR	0.82NF 10% 50V	
	C106	2203-001137	CHIP CAPACITOR	68NF +80-20% 50V			C606	2203-000203	CHIP CAPACITOR	100NF 10% 16V	
	C107	2401-000240	E.CAPACITOR	100UF 20% 10V			C607	2203-000203	CHIP CAPACITOR	100NF 10% 16V	
	C108	2401-000240	E.CAPACITOR	100UF 20% 10V			C608	2203-001223	CHIP CAPACITOR	0.82NF 10% 50V	
	C111	2203-000892	CHIP CAPACITOR	4.7NF 10% 50V			C610	2203-000203	CHIP CAPACITOR	100NF 10% 16V	
	C112	2203-000892	CHIP CAPACITOR	4.7NF 10% 50V			C611	2203-000203	CHIP CAPACITOR	100NF 10% 16V	
	C113	2202-000780	C.CAPACITOR	100NF +80-20% 50V			C612	2203-000203	CHIP CAPACITOR	100NF 10% 16V	
	C114	2401-001625	E.CAPACITOR	6.8UF 20% 50V			C801	2401-002183	E.CAPACITOR	220UF 20% 16V	
	C115	2203-000203	CHIP CAPACITOR	100NF 10% 16V			C803	2203-000787	CHIP CAPACITOR	0.33NF 5% 50V	
	C116	2203-000203	CHIP CAPACITOR	100NF 10% 16V			C804	2202-000243	C.CAPACITOR	33PF 5% 50V	
	C117	2203-001537	CHIP CAPACITOR	1NF 10% 50V			C805	2202-000243	C.CAPACITOR	33PF 5% 50V	
	C118	2203-000203	CHIP CAPACITOR	100NF 10% 16V			C806	2202-000243	C.CAPACITOR	33PF 5% 50V	
	C119	2203-000802	CHIP CAPACITOR	33NF 10% 50V			DR1	2007-000872	CHIP RESISTOR	4.7K 5% 1/10W	
	C120	2401-001968	E.CAPACITOR	470NF 20% 50V			DR2	2007-000872	CHIP RESISTOR	4.7K 5% 1/10W	
	C121	2203-000260	CHIP CAPACITOR	10NF 10% 50V			D301	0402-000151	DIODE	1N5392 100V 1.5A	
	C122	2203-001137	CHIP CAPACITOR	68NF +80-20% 50V			IC101	1204-001799	IC	KB9226 48P	
	C123	2401-000438	E.CAPACITOR	10UF 20% 25V			IC201	0904-001524	IC	S5L9290 48P	
	C124	2203-000203	CHIP CAPACITOR	100NF 10% 16V			IC301	1003-000179	IC	KA9258D 28P	
	C124A	2203-001064	CHIP CAPACITOR	56NF 10% 50V			IC401	1003-001162	IC	KA3082 10PIN	
	C125	2203-000840	CHIP CAPACITOR	0.39NF 5% 50V			IC402	1003-001162	IC	KA3082 10PIN	
	C126	2203-000495	CHIP CAPACITOR	2.2NF 10% 50V			IC601	1204-001885	IC	S5L9276 64P	
	C127	2203-000595	CHIP CAPACITOR	0.22NF 5% 50V			IC602	1105-001339	IC	M11L1644 24P	
	C128	2203-000802	CHIP CAPACITOR	33NF 10% 50V			IC801	AC14-12001G	IC	KA78L05	
	C129	2203-000203	CHIP CAPACITOR	100NF 10% 16V			PCB	AH41-00282B	CD PCB		
	C130	2203-000203	CHIP CAPACITOR	100NF 10% 16V			Q101	0501-000314	TRANSISTOR	KSA812 PNP	
	C131	2203-000203	CHIP CAPACITOR	100NF 10% 16V			Q301	0501-000610	TRANSISTOR	KSA928A-Y PNP	
	C132	2203-000203	CHIP CAPACITOR	100NF 10% 16V			Q302	0501-000010	TRANSISTOR	KSC1008 NPN	
	C133	2401-000240	E.CAPACITOR	100UF 20% 10V			R101	2007-001039	CHIP RESISTOR	56K 5% 1/10W	
	C134	2203-000260	CHIP CAPACITOR	10NF 10% 50V			R102	2007-001039	CHIP RESISTOR	56K 5% 1/10W	
	C135	2401-001968	E.CAPACITOR	470NF 20% 50V			R103	2007-001039	CHIP RESISTOR	56K 5% 1/10W	
	C201	2203-001619	CHIP CAPACITOR	0.027NF 5% 50V			R104	2007-001039	CHIP RESISTOR	56K 5% 1/10W	
	C202	2203-001619	CHIP CAPACITOR	0.027NF 5% 50V			R105	2007-000409	CHIP RESISTOR	15K 5% 1/10W	
	C203	2203-001223	CHIP CAPACITOR	0.82NF 10% 50V			R105	2007-001208	CHIP RESISTOR	82K 5% 1/10W	
	C204	2203-000203	CHIP CAPACITOR	100NF 10% 16V			R106	2007-001208	CHIP RESISTOR	82K 5% 1/10W	
	C205	2203-000203	CHIP CAPACITOR	100NF 10% 16V			R107	2007-001216	CHIP RESISTOR	82 5% 1/10W	
	C207	2203-000260	CHIP CAPACITOR	10NF 10% 50V			R108	2007-000308	CHIP RESISTOR	10 5% 1/10W	
	C208	2203-000858	CHIP CAPACITOR	0.039NF 5% 50V			R110	2007-000409	CHIP RESISTOR	15K 5% 1/10W	
	C209	2203-000260	CHIP CAPACITOR	10NF 10% 50V			R112	2007-001195	CHIP RESISTOR	820K 5% 1/10W	
	C211	2203-000203	CHIP CAPACITOR	100NF 10% 16V			R113	2007-000444	CHIP RESISTOR	180K 5% 1/10W	
	C212	2401-000240	E.CAPACITOR	100UF 20% 10V			R114	2007-000001	CHIP RESISTOR	68K 5% 1/10W	
	C213	2203-000260	CHIP CAPACITOR	10NF 10% 50V			R115	2007-001177	CHIP RESISTOR	8.2K 5% 1/10W	
	C214	2203-000260	CHIP CAPACITOR	10NF 10% 50V			R116	2007-000546	CHIP RESISTOR	20K 5% 1/10W	
	C215	2401-000240	E.CAPACITOR	100UF 20% 10V			R117	2001-000331	CARBON RESISTOR	12K 5% 1/8W	
	C216	2203-000260	CHIP CAPACITOR	10NF 10% 50V			R118	2007-000477	CHIP RESISTOR	1M 5% 1/10W	
	C217	2401-000240	E.CAPACITOR	100UF 20% 10V			R119	2007-001208	CHIP RESISTOR	82K 5% 1/10W	
	C218	2203-000260	CHIP CAPACITOR	10NF 10% 50V			R120	2007-001039	CHIP RESISTOR	56K 5% 1/10W	
	C301	2401-001102	E.CAPACITOR	330UF 20% 16V			R121	2007-000409	CHIP RESISTOR	15K 5% 1/10W	
	C302	2401-000240	E.CAPACITOR	100UF 20% 10V			R123	2007-000941	CHIP RESISTOR	47K 5% 1/10W	
	C303	2401-000240	E.CAPACITOR	100UF 20% 10V			R124	2007-000338	CHIP RESISTOR	120K 5% 1/10W	
	C304	2203-000260	CHIP CAPACITOR	10NF 10% 50V			R125	2007-000338	CHIP RESISTOR	120K 5% 1/10W	
	C305	2203-000260	CHIP CAPACITOR	10NF 10% 50V			R126	2007-001039	CHIP RESISTOR	56K 5% 1/10W	
	C401	2203-000260	CHIP CAPACITOR	10NF 10% 50V			R127	2007-001208	CHIP RESISTOR	82K 5% 1/10W	

## ■ Electrical parts list (CD board)

Block No. 04

△	Item	Parts number	Parts name	Remarks	Area
	R128	2007-000653	CHIP RESISTOR	27K 5% 1/10W	
	R129	2007-000941	CHIP RESISTOR	47K 5% 1/10W	
	R132	2007-000300	CHIP RESISTOR	10K 5% 1/10W	
	R133	2007-000300	CHIP RESISTOR	10K 5% 1/10W	
	R201	2007-000290	CHIP RESISTOR	100 5% 1/10W	
	R202	2007-000477	CHIP RESISTOR	1M 5% 1/10W	
	R203	2007-000290	CHIP RESISTOR	100 5% 1/10W	
	R204	2007-000468	CHIP RESISTOR	1K 5% 1/10W	
	R205	2007-000468	CHIP RESISTOR	1K 5% 1/10W	
	R206	2007-000468	CHIP RESISTOR	1K 5% 1/10W	
	R207	2007-000468	CHIP RESISTOR	1K 5% 1/10W	
	R208	2007-000468	CHIP RESISTOR	1K 5% 1/10W	
	R209	2007-000468	CHIP RESISTOR	1K 5% 1/10W	
	R210	2007-000572	CHIP RESISTOR	220 5% 1/10W	
	R211	2001-000429	CARBON RESISTOR	1K 5% 1/8W	
	R212	2001-000429	CARBON RESISTOR	1K 5% 1/8W	
	R213	2007-000468	CHIP RESISTOR	1K 5% 1/10W	
	R301	2008-000140	FUSIBLE RESISTOR	2.2 5% 1/2W	
	R302	2001-001006	CARBON RESISTOR	82 5% 1/8W	
	R501L	2007-000282	CHIP RESISTOR	100K 5% 1/10W	
	R501R	2007-000282	CHIP RESISTOR	100K 5% 1/10W	
	R502L	2007-000290	CHIP RESISTOR	100 5% 1/10W	
	R502R	2007-000290	CHIP RESISTOR	100 5% 1/10W	
	R601	2007-000468	CHIP RESISTOR	1K 5% 1/10W	
	R602	2007-000468	CHIP RESISTOR	1K 5% 1/10W	
	R603	2007-000468	CHIP RESISTOR	1K 5% 1/10W	
	R604	2001-000515	CARBON RESISTOR	220 5% 1/8W	
	R605	2001-000429	CARBON RESISTOR	1K 5% 1/8W	
	R801	2007-000468	CHIP RESISTOR	1K 5% 1/10W	
	R802	2007-000468	CHIP RESISTOR	1K 5% 1/10W	
	R803	2001-000429	CARBON RESISTOR	1K 5% 1/8W	
	R804	2007-000468	CHIP RESISTOR	1K 5% 1/10W	
	R805	2007-000468	CHIP RESISTOR	1K 5% 1/10W	
	R806	2007-000468	CHIP RESISTOR	1K 5% 1/10W	
	R807	2007-000872	CHIP RESISTOR	4.7K 5% 1/10W	
	R808	2007-000872	CHIP RESISTOR	4.7K 5% 1/10W	
	R809	2007-000872	CHIP RESISTOR	4.7K 5% 1/10W	
	R809	2007-000300	CHIP RESISTOR	10K 5% 1/10W	
	R810	2001-000362	CARBON RESISTOR	150 5% 1/8W	
	R811	2007-000468	CHIP RESISTOR	1K 5% 1/10W	
	R812	2007-000468	CHIP RESISTOR	1K 5% 1/10W	
	R813	2007-000941	CHIP RESISTOR	47K 5% 1/10W	
	X201	2802-000211	RESONATOR	16.93MHZ 0.5%	
	ZD301	0403-000344	ZENER DIODE	UZ3.9B 3.9V	
	ZD401	0403-000361	ZENER DIODE	UZ6.2BSB 6.2V	
	ZD402	0403-000352	ZENER DIODE	UZ4.7BM 4.7V	

< MEMO >




# Packing materials and accessories parts list

Block No. M 3 M M

Block No. M 5 M M

## B,E,EN Version





**Parts list (Packing B,E,EN Version)**

Block No. M3MM

Item	Parts number	Parts name	Q'ty	Description	Area
P 1	AH69-00905B	PACKING CASE	1	SET	B,E,EN
P 2	AH69-00867A	CUSHION	1	FRONT	B,E,EN
P 3	AH69-00868A	CUSHION	1	REAR	B,E,EN
P 4	AH69-30012T	PORY BAG	1	SET	
P 5	AH69-00525A	PORY BAG	1	INSTRUCTIONS	
P 6	AH81-00959Q	CUSHION TOP	1	SPEAKER BOX	
P 7	AH81-00929R	CUSHION BOTTOM	1	SPEAKER BOX	
P 8	AH81-00631U	PORY BAG	2	SPEAKER BOX	
P 9	AH81-00959S	PACKING CASE	1	SPEAKER BOX	B,E,EN

**Parts list (Accessories B,E,EN Version)**

Block No. M5MM

Item	Parts number	Parts name	Q'ty	Description	Area
A 1	AH68-01227D	INSTRUCTIONS	1	LVT1010-003B	B
	AH68-01227E	INSTRUCTIONS	1	LVT1010-004B	E
	AH68-01227F	INSTRUCTIONS	1	LVT1010-005B	EN
A 2	AH59-01163A	REMOCON ASSY	1	RM-MXGT88R	
A 3	AH38-10001A	FM WIRE	1		
A 4	AH42-20001P	ANT LOOP	1		
A 5	-----	BATTERY	2		
A 6	AH68-00415J	IMPORTANT CARD	1		
A 7	AH68-00416A	SAFETY CARD	1		
A 8	MXGA77-SPBOX-R	SPEAKER BOX R	1		
A 9	MXGA77-SPBOX-L	SPEAKER BOX L	1		
A10	LVT1066-001A	INSTRUCTIONS	1	SPEAKER BOX	B,E,EN

# Packing materials and accessories parts list


Block No. 

M	3	M	M
---	---	---	---

Block No. 

M	5	M	M
---	---	---	---

## EV Version



**Parts list (Packing EV Version)**

Block No. M3MM

Item	Parts number	Parts name	Q'ty	Description	Area
P 1	AH69-00906D	MASTER CARTON	1		EV
P 2	AH69-00867C	CUSHION L	1	FRONT	EV
P 3	AH69-00868C	CUSHION R	1	REAR	EV
P 4	AH69-30012T	PORY BAG	1	SET	
P 5	AH69-00525A	PORY BAG	1	INSTRUCTIONS	
P 6	AH81-00959Q	CUSHION TOP	1	SPEAKER BOX	
P 7	AH81-00929R	CUSHION BOTTOM	1	SPEAKER BOX	
P 8	AH81-00631U	PORY BAG	2	SPEAKER BOX	

**Parts list (Accessories EV Version)**

Block No. M5MM

Item	Parts number	Parts name	Q'ty	Description	Area
A 1	AH68-01227G	INSTRUCTIONS	1	LVT1010-006A	EV
A 2	AH59-01163A	REMOCON ASSY	1	RM-MXGT88R	
A 3	AH38-10001A	FM WIRE	1		
A 4	AH42-20001P	ANT LOOP	1		
A 5	-----	BATTERY	2		
A 6	AH68-00415J	IMPORTANT CARD	1		
A 7	AH68-00416A	SAFETY CARD	1		
A 8	MXGA77-SPBOX-R	SPEAKER BOX R	1		
A 9	MXGA77-SPBOX-L	SPEAKER BOX L	1		

# JVC

# SCHEMATIC DIAGRAMS


## COMPACT COMPONENT SYSTEM

### MX-GA77

CD-ROM No.SML200307

#### Area suffix

B ----- U.K.  
 E ---- Continental Europe  
 EN ---- Northern Europe  
 EV ----- Eastern Europe



SP-MXGA77

CA-MXGA77

SP-MXGA77

COMPACT  
**disc**  
 DIGITAL AUDIO

**R-D-S**

### Contents

Block diagram-----	2-1
Standard schematic diagrams-----	2-2
Printed circuit boards-----	2-7~10




In regard with component parts appearing on the silk-screen printed side (parts side) of the PWB diagrams, the parts that are printed over with black such as the resistor (■), diode (▣) and ICP (●) or identified by the "△" mark nearby are critical for safety.

(This regulation does not correspond to J and C version.)



Block diagram



# Standard schematic diagrams

## ■ Main section

To ACW1  
Sheet 3/5

5

To UCW01  
Sheet 2/5

4


To CON01  
Sheet 5/5

3

To CW106  
Sheet 4/5

2

1



SHEET NUMBER	CIRCUIT DESCRIPTION
1/5	Main
2/5	FL display & System control
3/5	Amp.
4/5	CD
5/5	Tuner

- MAIN signal
- TUNER signal
- TAPE P.B. signal
- CD signal
- TAPE REC. signal

▲ Parts are safety assurance parts. When replacing those parts, make sure to use the specified parts.



FL display & System control section


5

4

3

2

1



To CW101 Sheet 1/5

To CW105 Sheet 4/5



■ Amp. section

5

4


3

2

1

To CW106  
Sheet 1/5

To CW105  
Sheet 1/5




MX-GT77E. AMP

▲ Parts are safety assurance parts.  
When replacing those parts, make  
sure to use the specified parts.

➡ MAIN signal

CD section

5  
4  
3  
2  
1



To CW104  
SHEET 1/5


To CW2  
Sensor board

To CW3  
Switch board

To UCW04  
SHEET 2/5

➔ CD signal

■ Tuner section




➔ FM/TUNER signal  
➡ AM signal



# Printed circuit boards


## ■ Main board






Front board

5



4




3

2

1



■ Amp. board





■ CD servo board

■ Power supply board



< MEMO >





**MX-GA77**




**JVC**

VICTOR COMPANY OF JAPAN, LIMITED

AV & MULTIMEDIA COMPANY AUDIO/VIDEO SYSTEM CATEGORY 10-1,1 chome,Ohwatari-machi,maebashi-city,371-8543,Japan

No.22083SCH

 Printed in Japan  
200307