

JVC


SERVICE MANUAL

COMPACT COMPONENT SYSTEM

MX-KC2

Area suffix

UW ----- Brazil,Mexico,Peru
UY ----- Argentina



COMPACT
disc
DIGITAL AUDIO

Lead free solder used in the board (material : Sn-Ag-Cu, melting point : 219 Centigrade)

TABLE OF CONTENTS

1 PRECAUTION	1-3
2 SPECIFIC SERVICE INSTRUCTIONS	1-4
3 DISASSEMBLY	1-5
4 ADJUSTMENT	1-17
5 TROUBLESHOOTING	1-17

SPECIFICATION

Amplifier	Output Power	50 W per channel, min. RMS, driven into 6 Ω at 1kHz, with no more than 10% total harmonic distortion. (IEC 268-3)
Input Sensitivity/Impedance (1 kHz)	AUX IN	400 mV/50 kΩ
	Speaker terminals	6 Ω - 16 Ω
	Phones	32 Ω - 1 kΩ 15 mW/ch output into 32 Ω
Cassette Deck Section	Frequency Response Type I (NORMAL)	63 Hz - 12 500 Hz
	Wow And Flutter	0.15% (WRMS)
CD Player	CD Capacity	3 CDs
	Dynamic Range	83 dB
	Signal-To-Noise Ratio	85 dB
	Wow And Flutter	Unmeasurable
Tuner	FM Tuner : Tuning Range	87.5 MHz - 108.0 MHz(at AM10 kHz channel space) 87.50 MHz - 108.00 MHz(at AM9 kHz channel space)
	AM Tuner : Tuning Range	530 kHz - 1710 kHz (at AM10 kHz channel space) 531 kHz - 1710 kHz (at AM9 kHz channel space)
Unit	Dimensions	270 mm × 308 mm × 410 mm (W/H/D)
	Mass	Approx. 6.5 kg
Speaker Specifications (each unit)	Type	2-way bass-reflex type
	Speaker Unit	Woofer : 13 cm cone × 1 Tweeter : 5 cm cone × 1
	Power Handling Capacity	50 W
	Impedance	6 Ω
	Frequency Range	45 Hz - 22 000 Hz
	Sound pressure level	87 dB/W·m
	Dimensions	205 mm × 308 mm × 209 mm (W/H/D)
Power Specifications	Mass	Approx. 2.9 kg
	Power Requirements	AC 110 V - 127 V/220 V - 240 V , adjustable with voltage selector, 50 Hz/60 Hz
	Power Consumption	110 W (power on mode) 13 W (in Standby mode) 1.2 W (in Eco mode)

Design and specifications are subject to change without notice.

SECTION 1

PRECAUTION

1.1 Safety Precautions

- (1) This design of this product contains special hardware and many circuits and components specially for safety purposes. For continued protection, no changes should be made to the original design unless authorized in writing by the manufacturer. Replacement parts must be identical to those used in the original circuits. Services should be performed by qualified personnel only.
- (2) Alterations of the design or circuitry of the product should not be made. Any design alterations of the product should not be made. Any design alterations or additions will void the manufacturers warranty and will further relieve the manufacture of responsibility for personal injury or property damage resulting therefrom.
- (3) Many electrical and mechanical parts in the products have special safety-related characteristics. These characteristics are often not evident from visual inspection nor can the protection afforded by them necessarily be obtained by using replacement components rated for higher voltage, wattage, etc. Replacement parts which have these special safety characteristics are identified in the Parts List of Service Manual. Electrical components having such features are identified by shading on the schematics and by (Δ) on the Parts List in the Service Manual. The use of a substitute replacement which does not have the same safety characteristics as the recommended replacement parts shown in the Parts List of Service Manual may create shock, fire, or other hazards.
- (4) The leads in the products are routed and dressed with ties, clamps, tubings, barriers and the like to be separated from live parts, high temperature parts, moving parts and/or sharp edges for the prevention of electric shock and fire hazard. When service is required, the original lead routing and dress should be observed, and it should be confirmed that they have been returned to normal, after reassembling.
- (5) Leakage shock hazard testing

After reassembling the product, always perform an isolation check on the exposed metal parts of the product (antenna terminals, knobs, metal cabinet, screw heads, headphone jack, control shafts, etc.) to be sure the product is safe to operate without danger of electrical shock. Do not use a line isolation transformer during this check.

- Plug the AC line cord directly into the AC outlet. Using a "Leakage Current Tester", measure the leakage current from each exposed metal parts of the cabinet, particularly any exposed metal part having a return path to the chassis, to a known good earth ground. Any leakage current must not exceed 0.5mA AC (r.m.s.).


- Alternate check method

Plug the AC line cord directly into the AC outlet. Use an AC voltmeter having, 1,000 Ω per volt or more sensitivity in the following manner. Connect a 1,500 Ω 10W resistor paralleled by a 0.15 μ F AC-type capacitor between an exposed metal part and a known good earth ground.

Measure the AC voltage across the resistor with the AC

voltmeter.

Move the resistor connection to each exposed metal part, particularly any exposed metal part having a return path to the chassis, and measure the AC voltage across the resistor. Now, reverse the plug in the AC outlet and repeat each measurement. Voltage measured any must not exceed 0.75 V AC (r.m.s.). This corresponds to 0.5 mA AC (r.m.s.).



1.2 Warning

- (1) This equipment has been designed and manufactured to meet international safety standards.
- (2) It is the legal responsibility of the repairer to ensure that these safety standards are maintained.
- (3) Repairs must be made in accordance with the relevant safety standards.
- (4) It is essential that safety critical components are replaced by approved parts.
- (5) If mains voltage selector is provided, check setting for local voltage.

1.3 Caution

Burrs formed during molding may be left over on some parts of the chassis.

Therefore, pay attention to such burrs in the case of performing repair of this system.

1.4 Critical parts for safety

In regard with component parts appearing on the silk-screen printed side (parts side) of the PWB diagrams, the parts that are printed over with black such as the resistor (- - -), diode (| |) and ICP (●) or identified by the " Δ " mark nearby are critical for safety. When replacing them, be sure to use the parts of the same type and rating as specified by the manufacturer. (This regulation dose not Except the J and C version)

SECTION 2

SPECIFIC SERVICE INSTRUCTIONS

This service manual does not describe SPECIFIC SERVICE INSTRUCTIONS.

SECTION 3 DISASSEMBLY

3.1 Disassembly of the main blocks of the set

Replacement of the fuses and the power IC

3.1.1 Replacing the fuses

(See Fig.1)

- Prior to performing the following procedure, remove the left side board.
- (1) Replace the fuses inside.

Caution:

Be sure to use fuses with the specified ratings.




Fig.1

3.1.2 Replacing the power IC

(See Fig.2)

- Prior to performing the following procedure, remove the top cover.
- (1) Remove the two screws **A** from the heat sink between the power IC.
- (2) Remove the solder fixing the power IC.




Fig.2

3.1.3 Replacing the heat sink cover

(See Fig.3)

- (1) Remove four screws **B** from the rear panel.
- (2) Pull the heat sink cover outward.




Fig.3

3.1.4 Removing the top cover right cabinet and left cabinet (See Fig.4 and 5)

- (1) Remove three screws **C** that retain the top cover from the panel rear of the body.
- (2) Remove six screws **D** that retain the left cabinet from the body.
- (3) Remove six screws **c** that retain the right cabinet from the body.




Fig.4




Fig.5

3.1.5 Removing the CD changer unit

(See Fig.6 to 8)

- Prior to performing the following procedures, remove the top cover.

Caution:




Although the CD mechanism unit can be removed without removing the CD tray panel, it is still recommended to remove it in order to prevent damage.

- From the front panel side of this set, push in the sections marked with arrows and pull out the CD tray toward the front.
- Remove the CD tray panel by pushing both of its extremities upward in the direction of the arrows.
- Push the CD tray deep into the set.

(1) Disconnect the cord wires from the CD board [CN703](#) and [CN203](#).

(2) From the rear of the set, remove two screws **E**, and four screws **G** on the front panel left and right side.

(3) Handle the CD changer unit rear, take out the unit.



3.1.6 Removing the front panel assembly

(See Fig.9 to 10)

- Prior to performing the following procedures, remove the top cover.
- Also remove the CD changer unit.
 - Disconnect the parallel wire and the cord wire from the connectors CN701, CN101 on the power amp. board.
 - Remove one screws **H** retaining the front panel assembly onto the bottom of the body.
 - Remove two screws **I** on the front cabinet and bottom cabinet and then remove then GND lug **b** that comes from the power amp and supply board.
 - Disengage the claws **c** on both sides of the front panel assembly and then remove the assembly.




Fig.9




Fig.10

3.2 Disassembly of units and assembly inside this set

3.2.1 Removing the Main board

(See Fig.11 to 12)

- Prior to performing the following procedures, remove the top cover.
 - Also remove the CD changer unit.
- Disconnect the wires from [CN603A](#), [CN603B](#) and [CN604](#) on the Main board, which is located on the back side of the CD changer unit.
 - The four screws **J** that retain the CD board should be removed.
 - Remove the CD board by pulling it toward the side where the [CN601](#) is located.
 - Using solder, short the CD pickup to connect to short round.

Caution:

After re-connecting the wires, be sure to remove the shorting solder from the GND connection.

- Disconnect the card wire from the connector [CN601](#) on the Main board and then remove the Main board.




Fig.11




Fig.12

3.2.2 Removing the CD changer mechanism assembly

(See Fig.13 to 14)

- Prior to performing the following procedures, remove the top cover.
 - Also remove the CD changer unit.
- (1) Turn the CD changer mechanism cover base and remove the screws **d** connecting the unit to the CD changer mechanism assembly.
 - (2) Removing four screws **e** retaining the CD mechanism holder assembly.

Caution:

When replacing the CD changer mechanism assembly, be sure not to mistake the positions of the silver color and copper color spring.




Fig.13




Fig.14

3.2.3 Removing the CD pickup

(See Fig.15)

- Prior to performing the following procedures, remove the top cover.
- Also remove the CD changer unit.
- Also remove the CD changer mechanism.
 - (1) Widen the section **f**.
 - (2) While keeping the section **f** wide open, push the section **g** in the direction of the arrow to remove the shaft, and then remove the CD pickup.




Fig.15

3.2.4 Replacing the loading motor and rotor belt of the CD changer

(See Fig.16)

- Prior to performing the following procedures, remove the top cover.
- Also open the CD changer tray.
 - (1) Remove the two screws **L** retaining the CD changer tray loading motor.
 - (2) Remove the two screws **M** retaining the gear plate and take it out, after remove the rotor belt from the pulley.




Fig.16

3.2.5 Replacing the CD turn table and removing the motor

(See Fig. 17)

- Prior to performing the following procedures, remove the top cover.
- Also remove the CD changer unit.
 - (1) Remove the one screw retaining the CD (Turn table).
 - (2) Remove the two screws retaining the stopper brackets on both sides of the CD changer unit.
 - (3) Remove the stopper brackets from both sides of the CD changer unit.
 - (4) Pull out the CD tray from the CD changer unit, all the way and lift the tray to remove.
 - (5) Remove the gear and after push out the tray motor locker and pull out the tray motor from the CD tray.




Fig.17

3.2.6 Removing the cassette deck mechanism

(See Fig.18)

- Prior to performing the following procedures, remove the top cover.
- Also remove the CD changer unit.
- Also remove the front panel assembly.
(1) Remove six screws retaining the cassette deck mechanism.




Fig.18

3.2.7 Removing the key open board & the key REC board

(See Fig.19)

- Prior to performing the following procedures, remove the top cover.
- Also remove the CD changer unit.
- Also remove the front panel assembly.
(1) Remove 25 screws P that retains the key open board.




Fig.19

3.2.8 Removing the display board

(See Fig.20)

- Prior to performing the following procedures, remove the top cover.
- Also remove the CD changer unit.
- Also remove the front panel assembly.
(1) Remove 25 screws Q that retain the front board from the back of the front panel unit.




Fig.20

3.2.9 Removing the Switch board and sound mode and CD function switch board (See Fig.19 to 22)

- Prior to performing the following procedures, remove the top cover.
- Also remove the CD changer unit.
- Also remove the front panel assembly.
 - (1) Pull out the volume control knob from the front of the front panel assembly.(Fig.21)
 - (2) Remove six screws **Q** retaining the front panel assembly.
 - (3) Remove the Control/FL board.
 - (4) Remove eleven screws **R** retaining the Switch (key 1) board.(Fig.19)
 - (5) Remove two screws **S** retaining the sound mode and CD function (key 2) switch board.(Fig.20)




Fig.21




Fig.22

3.2.10 Removing the cassette deck main motor, and replacing the main belts (See Fig.18, 23 and 24)

- Prior to performing the following procedures, remove the top cover and both sides board.
- Also remove the CD changer unit.
- Also remove the front panel assembly.
- (1) Remove six screws **Z** retaining the cassette deck mechanism. (Fig.18)
- (2) Remove the cassette deck mechanism.
- (3) Remove two screws **t** retaining the main motor from the front side of the cassette deck.

Caution:

After attaching the main motor, check the orientation of the motor and the polarity of the wires.

- (4) From the backside of the cassette deck, remove the main motor and two main belts.

Caution:

The lengths of the cassette A(playback only) and cassette B(record/play) main belts are different. When attaching the main belts, use the longer belt for cassette A.




Fig.23





Fig.24

3.2.11 Removing the leaf switches of the cassette deck mechanism (See Fig. 18 and 25)

- Prior to performing the following procedures, remove the top cover and both sides board.
- Also remove the CD changer unit.
- Also remove the front panel assembly.
- (1) Remove the six screws **Z** that retain the cassette deck mechanism. (Fig.18)
- (2) Remove the cassette deck mechanism.
- (3) Turn the cassette deck mechanism upside down.
- (4) Remove the solder from around the leaf switches.
- (5) Pull out the leaf switches from the front side of the cassette deck mechanism.



Cassette deck mechanism
(Back side)

Fig.24

3.2.12 Removing the cassette deck heads

(See Fig. 18 and 26)

- Prior to performing the following procedures, remove the top cover and both sides board.
 - Also remove the CD changer unit.
 - Also remove the front panel assembly.
- (1) Remove six screws **Z** that retain the cassette deck mechanism. (Fig.18)
- (2) Remove the cassette deck mechanism and place it so that the front side faces up.
- (3) Remove the solder from the bottom side of the head terminal and disconnect the wire.
- (4) Remove screws **U** that retains the head.
- (5) Remove screws **V** that retains the head.
- (6) Hold the head and slide it in the direction of the arrow to remove it.

Cassette deck mechanism (Front side)




Fig.26

3.2.13 Removing the 3-pin regulator and bridge diode

(See Q604, Q608, D614, D615 and Fig.27)

- Prior to performing the following procedures, remove the top cover and both sides board.
- (1) Remove two screws **A** that connect the heat sink.
- (2) Remove two screws **W** that connect the heat sink.
- (3) Remove the solder fixing the 3-pin terminal regulator Q604, Q608.
- (4) Remove the solder fixing the 4-pin bridge diode (D614, D615).




Fig.27

3.2.14 Removing the power amp and Supply board and the Power trans board

(See Fig. 2, 28 to 30)

- Prior to performing the following procedures, remove the top cover and CD changer unit.
- (1) Remove four screws **B** from the rear panel. (Fig.3)
- (2) Pull the heat sink cover outward.
- (3) Remove four screws **AA** from the rear panel between the heat sink holder.
- (4) Remove two screws **YY** that retains the rear panel, and then remove the rear panel.
- (5) Disconnect the parallel wires from the connectors **FW951** on the Power trans board.
- (6) Remove screws **Z** that retain the power amp and Supply board and then remove the assembly.
- (7) Remove the clamp of AC power cord from the chassis.
- (8) Remove four screws that retain the Power trans board and then remove the assembly.




Fig.28




Fig.29




Fig.30

SECTION 4 ADJUSTMENT

This service manual does not describe ADJUSTMENT.

SECTION 5 TROUBLESHOOTING

This service manual does not describe TROUBLESHOOTING.



Victor Company of Japan, Limited

AV & MULTIMEDIA COMPANY AUDIO/VIDEO SYSTEMS CATEGORY 10-1, 1chome, Ohwatari-machi, Maebashi-city, 371-8543, Japan

(No.MB434)



Printed in Japan
VPT

JVC

SCHEMATIC DIAGRAMS


COMPACT COMPONENT SYSTEM

MX-KC2

CD-ROM No.SML200510

Area suffix

UW ----- Brazil,Mexico,Peru
UY ----- Argentina




Lead free solder used in the board (material : Sn-Ag-Cu, melting point : 219 Centigrade)

Contents

Block diagram	-----	2-1
Standard schematic diagrams	-----	2-2
Printed circuit boards	-----	2-8 to 13


In regard with component parts appearing on the silk-screen printed side (parts side) of the PWB diagrams, the parts that are printed over with black such as the resistor (■), diode (■) and ICP (●) or identified by the "Δ" mark nearby are critical for safety.

Block diagram




Standard schematic diagrams


■ Primary section



■ Power amp. section




Micon section




*OPTION TABLE(TUNER)

VERSION	J/C	B/E*	A	US/UJ/U	UW/UY	UX		
R386	0	390	910	1.6K	2.7K	4.3K	6.8K	12K 27K


■ Source selector section



■ CD section




■ Front section



Printed circuit boards

■ Main board Lead free solder used in the board (material : Sn-Ag-Cu, melting point : 219 Centigrade)


forward side



Main board

Lead free solder used in the board (material : Sn-Ag-Cu, melting point : 219 Centigrade)


reverse side




Amp board

Lead free solder used in the board (material : Sn-Ag-Cu, melting point : 219 Centigrade)

forward side




reverse side



■ Front board Lead free solder used in the board (material : Sn-Ag-Cu, melting point : 219 Centigrade)

forward side




■ Front board Lead free solder used in the board (material : Sn-Ag-Cu, melting point : 219 Centigrade)

reverse side

This schematic diagram shows the reverse side of a front board. It features a complex arrangement of component pads, tracks, and via holes. Key components labeled include resistors R221, R220, R222, R223, R224, R225, R226, R227, R228, R229, R230, R231, R232, R233, R234, R235, R236, R237, R238, R239, R240, R241, R242, R243, R244, R245, R246, R247, R248, R249, R250, R251, R252, R253, R254, R255, R256, R257, R258, R259, R260, R261, R262, R263, R264, R265, R266, R267, R268, R269, R270, R271, R272, R273, R274, R275, R276, R277, R278, R279, and R280; capacitors C204, C205, C206, C207, C208, C209, C210, C211, C212, C213, C214, C215, C216, C217, C218, C219, C220, C221, C222, C223, C224, C225, C226, C227, C228, C229, C230, C231, and C232; diodes D1, D2, D3, D4, D5, D6, D7, and D8; and an integrated circuit IC1. Numerous screw holes and vias are also visible throughout the layout.

2-12

■ Trans board Lead free solder used in the board (material : Sn-Ag-Cu, melting point : 219 Centigrade)



JVC

Victor Company of Japan, Limited

AV & MULTIMEDIA COMPANY AUDIO/VIDEO SYSTEMS CATEGORY 10-1,1chome,Ohwatari-machi,Maebashi-city,371-8543,Japan

(No.MB434SCH)

 Printed in Japan
VPT

PARTS LIST

[MX-KC2]

* All printed circuit boards and its assemblies are not available as service parts.


Area suffix	
UW	Brazil,Mexico,Peru
UY	Argentina


- Contents -

Exploded view of general assembly and parts list (Block No.M1)	3- 2
CD changer mechanism assembly and partslist (Block No.MA)	3- 5
Electrical parts list (Block No.01~05)	3- 7
Packing materials and accessories parts list (Block No.M3)	3-14

Exploded view of general assembly and parts list

Block No. M 1 M M





The parts without symbol number are not service.


General Assembly

Block No. [M][1][M][M]

△	Symbol No.	Part No.	Part Name	Description	Local
	1	BI1081090101V1	CASS LENS L		
	2	BI1081100101V1	CASS LENS R		
	3	BI1081160101V1	CASSETTE BOX	R	
	4	BI202929010101	C DOOR SPRING	R	
	5	BI1081060101V1	VOL KNOB		
	6	BI1081040102X1	FRONT CABINET	94HB	
	7	BI301779010101	CUSHION	BACK FOAM(x2)	
	8	BI300924010101	DAMPER		
	9	BI1077330101U1	VOL RING	ABS 700	
	10	BI2029250101W1	BOTTOM CABINET		
	11	BI3021970101V1	RUBBER FOOT	(x2)	
	12	BI250111002000	CASSETTE MECH	CWN42FF06	
	13	BI1081120101V1	SOUND MODE KEY		
	14	BI1081560101V1	LED HDLR		
△	15	BI211011128001	POWER TRANS	EI66X50 DB-EI66-3700A PT901	
	16	BI1081180101V1	RIGHT CABINET		
	18	BI202560010101	HEAT SINK HLDLR	R SBCC T=0.80mm	UW
	19	BI2029260301W1	BACK PANEL		UY
	19	BI2029260401W1	BACK PANEL		
	20	BI107843010101	HT SINK COVER	KA6 PA-757	
	21	BI2Z5094901VV	TUNER PACK		
	22	BI1081140101V1	TOP CABINET		
	23	BI202923010201	HEAT SINK AL		
	24	BI202553010101	HEAT SINK HLDLR	L SBCC T=0.80mm	
	25	BI202555010101	HEAT SINK		
	26	BI251030093100	3CD MECHANISM	CMS-FR3BN	
	28	BI1081170101V1	LEFT CABINET		
	29	BI2702221V	VFD DISPLAY	VFD1 BJ967GNK	
	30	BI1081110101V1	CD PLAY KEY		
	31	BI1081130101V1	LENS POWER		
	32	BI1081080101V1	KEY FUNC		
	33	BI1077330101U1	VOL RING	ABS 700	
	34	BI300924010101	DAMPER		
	35	BI2029680101W1	HOLDER PLATE		
	36	BI109835010101	BADGE	700194HB	
	37	BI1081050101V1	CD DOOR		
	38	BI1081070101V1	WIN DISP		
	39	BI202928010101	C DOOR SPRING	L	
	40	BI1081150101V1	CASSETTE BOX	L	
	41	BI2029270101W1	SENSOR BRACKET		
	43	BI1081190101V1	VFD BRACKET		
	44	BI202772010101	CASSETTE SPRING	SUS WPB 0.40	
	45	BI202773010101	C LOCKER SPRING		
	46	BIRT000611B3	SCREW	3 X L8 B-TYPE(x26)	
	47	BIRT000617B3	SCREW	3 X L10 B-TYPE(x19)	
	48	BIRM000603S3	SCREW	3 X L6 S-TYPE(x7)	
	49	BIRM000604S3	SCREW	3X L8 S-TYPE(x6)	
	50	BIBT000418	SCREW	2.6 XL8(x25)	
△	52	BI402891	FUSE	T1.6AL 250V F901	
△	53	BI402821	FUSE	1A 250V F902	
△	54	BI1401761V	POWER CORD		UW
△	54	BI1401791X	POWER CORD		UY

CD changer mechanism assembly and parts list

Block No. M A M M



The parts without symbol number are not service.


CD changer mechanism

Block No. [M][A][M][M]

△	Symbol No.	Part No.	Part Name	Description	Local
1		BIAJ7200601J	BASE-MAIN	1X1	
2		BIAJ6100601P	BRKT-CHUCK		
3		BI3302000158	MAGNET-FERRITE		
4		BIAJ7200601L	TABLE-CHUCK	1X4	
5		BIAJ6300601A	SHEET-CHUCK	(x3)	
6		BIAJ7300601B	BELT-LOAD		
7		BIAJ6600601N	GEAR-SYNCRO	1X2	
8		BIAJ6600601L	GEAR-CONVERT	1X4	
9		BIAJ6600601M	GEAR-TRAY	1X4	
10		BIAJ6600601R	GEAR-CAM	1X2	
11		BIAJ6600601K	GEAR-LOAD	1X4	
12		BIAJ6600601J	GEAR-PULLEY	1X4	
13		BIAJ7200601N	SLIDER-CAM	1X4	
14		BI3405000101	SWITCH-MICRO	(x2)	
15		BI3711003379	CONNECTOR-HEADE		
16		BIAJ4100601K	PCB-SW		
17		BIAJ6100601K	PULLEY-MOTOR	1X4	
18		BIAJ3100601F	MOTOR-DC		
19		BI3710001248	CONNECTOR-SOCE		
20		BI3711003692	CONNECTOR-HEADE		
21		BI3708001163	CONNECTOR-FPC		
22		BIAJ4100601L	PCB-MECHA		
23		BIAJ7200601P	TRAY-ROULETTE	1X2	
24		BIAJ7200601Q	TRAY-DISC	1X2	
25		BIAJ6600601Q	GEAR-ROULETTE	1X4	
26		BIAJ6600601P	GEAR-WORM	1X2	
27		BIAJ3100601K	MOTOR-LOADING		
28		BIAJ6300601B	SHEET-MOTOR		
29		BIAJ3900601A	WIRE-ROULETTE		
32		BIAJ3900601B	WIRE-TRAY		
33		BI3711000003	CONNECTOR-HEADE		
34		BIAJ4100601J	PCB-SENSOR		
35		BIAJ3200601A	SENSOR-ROULETTE		
36		BIAJ9050605F	CMS-B31NG6U		
37		BIAJ6000601F	SCREW	(x4)	
38A		BIAJ7300601F	RUBBER-B31Y	(x2)	
38B		BIAJ7300601D	RUBBER-B31	(x2)	
39		BIAJ7200602F	LEVER-LIFTER	1X2	

Packing materials and accessories parts list

Block No. M 3 M M



Packing and Accessories

Block No. [M][3][M][M]

△	Symbol No.	Part No.	Part Name	Description	Local
	A 1	BI440001553000	INST BOOK	ENG SPA POR LVT1346-006A	UW
	A 1	BI440001552000	INST BOOK	SPA LVT1346-007A	UY
△	A 2	BI23A0094V	PLUG CONVERSION	JT-0476	
	A 3	-----	BATTERY	(x2)	
	A 4	BIAN01051	FM ANT WIRE		
	A 5	BIAN01031V	AM LOOP ANT		
	A 6	BI643MXKC206SX	REMOTE CONTROL		
	A 7	MXKC2UW-SPBOX-L	SPEAKER BOX L	BI644MXKC2238S	UW
	A 7	MXKC2UY-SPBOX-L	SPEAKER BOX L	BI644MXKC2209S	UY
	A 8	MXKC2UW-SPBOX-R	SPEAKER BOX R	BI644MXKC2238S	UW
	A 8	MXKC2UY-SPBOX-R	SPEAKER BOX R	BI644MXKC2209S	UY
	P 1	BI430001863000	CARTON		
	P 2	BI470011031001	POLY BAG		
	P 3	BI470011057001	POLY BAG		
	P 4	BI4005355	POLY BAG	for Remote control	
	P 5	BI450012028000	POLY FORM L		
	P 6	BI450012029000	POLY FORM R		
	P 7	BI450011145001	MAT SHEET		
	P 8	BI470011032001	POLY BAG	unit	
	P 9	BI450012006000	POLY FORM	TOP	
	P 10	BI450012007000	POLY FORM	BOTTOM	