

**JVC**

# SERVICE MANUAL

AUDIO/VIDEO CONTROL RECEIVER

## RX-8000VBK

**Area Suffix**

J -----	U.S.A.
C -----	Canada

**DIGITAL AP**

**Dynamic Super-A**



**TEXT  
COMPU LINK**

**AV COMPU LINK**

**COMPU LINK  
///Remote///**

**3D  
3D-PHONIC**  
**DIGITAL  
dts  
SURROUND**

**DOLBY  
DIGITAL**



### Contents

Safety precautions -----	1-2	Block diagrams -----	2-23
Instructions -----	1-3~17	Standard schematic diagrams --	2-27
Disassembly method -----	2-1	Printed circuit boards -----	2-36~40
Adjustment method -----	2-7	Parts list -----	3-1~20
Description of major ICs -----	2-8		

## Safety precautions

1. This design of this product contains special hardware and many circuits and components specially for safety purposes. For continued protection, no changes should be made to the original design unless authorized in writing by the manufacturer. Replacement parts must be identical to those used in the original circuits. Services should be performed by qualified personnel only.
2. Alterations of the design or circuitry of the product should not be made. Any design alterations of the product should not be made. Any design alterations or additions will void the manufacturer's warranty and will further relieve the manufacturer of responsibility for personal injury or property damage resulting therefrom.
3. Many electrical and mechanical parts in the products have special safety-related characteristics. These characteristics are often not evident from visual inspection nor can the protection afforded by them necessarily be obtained by using replacement components rated for higher voltage, wattage, etc. Replacement parts which have these special safety characteristics are identified in the Parts List of Service Manual. Electrical components having such features are identified by shading on the schematics and by () on the Parts List in the Service Manual. The use of a substitute replacement which does not have the same safety characteristics as the recommended replacement parts shown in the Parts List of Service Manual may create shock, fire, or other hazards.
4. The leads in the products are routed and dressed with ties, clamps, tubings, barriers and the like to be separated from live parts, high temperature parts, moving parts and/or sharp edges for the prevention of electric shock and fire hazard. When service is required, the original lead routing and dress should be observed, and it should be confirmed that they have been returned to normal, after re-assembling.
5. Leakage current check (Electrical shock hazard testing)
 

After re-assembling the product, always perform an isolation check on the exposed metal parts of the product (antenna terminals, knobs, metal cabinet, screw heads, headphone jack, control shafts, etc.) to be sure the product is safe to operate without danger of electrical shock. Do not use a line isolation transformer during this check.

  - Plug the AC line cord directly into the AC outlet. Using a "Leakage Current Tester", measure the leakage current from each exposed metal parts of the cabinet, particularly any exposed metal part having a return path to the chassis, to a known good earth ground. Any leakage current must not exceed 0.5mA AC (r.m.s.)
  - Alternate check method
 

Plug the AC line cord directly into the AC outlet. Use an AC voltmeter having, 1,000 ohms per volt or more sensitivity in the following manner. Connect a  $1,500\Omega$  10W resistor paralleled by a  $0.15\mu F$  AC-type capacitor between an exposed metal part and a known good earth ground. Measure the AC voltage across the resistor with the AC voltmeter. Move the resistor connection to each exposed metal part, particularly any exposed metal part having a return path to the chassis, and measure the AC voltage across the resistor. Now, reverse the plug in the AC outlet and repeat each measurement. Voltage measured must not exceed 0.75 V AC (r.m.s.). This corresponds to 0.5 mA AC (r.m.s.).

## Warning

1. This equipment has been designed and manufactured to meet international safety standards.
2. It is the legal responsibility of the repairer to ensure that these safety standards are maintained.
3. Repairs must be made in accordance with the relevant safety standards.
4. It is essential that safety critical components are replaced by approved parts.
5. If mains voltage selector is provided, check setting for local voltage.

**CAUTION** Burrs formed during molding may be left over on some parts of the chassis. Therefore, pay attention to such burrs in the case of performing repair of this system.

## Instructions



## **AUDIO/VIDEO CONTROL RECEIVER**

RX-8000VBK

**JVC**  
VICTOR COMPANY OF JAPAN, LIMITED





**WARNING: TO REDUCE THE RISK OF FIRE  
OR ELECTRIC SHOCK, DO NOT EXPOSE  
THIS APPLIANCE TO RAIN OR MOISTURE.**



**CAUTION**

To reduce the risk of electrical shocks, fire, etc.:

1. Do not remove screws, covers or cabinet.
2. Do not expose this appliance to rain or moisture.



This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
• Reorient or relocate the receiving antenna.  
• Increase the separation between the equipment and receiver.  
• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.



***INSTRUCTIONS***

**For Customer Use:**  
Enter below the Model No. and Serial No. which are located either on the rear, bottom or side of the cabinet. Retain this information for future reference.


LVT0427-001A

## **Table of Contents**


<b>Parts Identification</b>	<b>2</b>
<b>Getting Started</b>	<b>3</b>
Before Installation	3
Checking the Supplied Accessories	3
Connecting the FM and AM Antennas	3
Connecting the Speakers	4
Connecting the Video Components	5
Connecting the Power Cord	5
Putting Batteries in the Remote Control	9
<b>Basic Operations</b>	<b>10</b>
Turning the Power On and Off (Standby)	10
Selecting the Source to Play	10
Adjusting the Volume	11
Selecting the Front Speaker	12
Moving the Sound	12
Refreshing the Bass	12
Attenuating the Input Signal	12
Adjusting the Subwoofer Output Level	12
<b>Basic Settings</b>	<b>13</b>
Recording a Source	13
Adjusting the Front Speaker Output Balance	13
Changing the Source Name	13
Setting the IP Address Information	14
Setting the Spots for the DSP Modes	14
Digital Input (DIGITAL IN) Terminal Setting	16
Selecting Analog or Digital Input Mode	16
Showing the Test Information at the Display	17
Showing the Basic Setting and Adjustments - One-Touch	18
Operating	18
Using the Sleep Timer	18
<b>Receiving Radio Broadcasts</b>	<b>19</b>
Tuning in Stations Manually	19
Using Preset Tuning	20
Selecting the FM Reception Mode	20
Assigning Names to Preset Stations	20
<b>Using the SEA Modes</b>	<b>21</b>
Selecting Your Favorite SEA Mode	21
Creating Your Own SEA Mode	21
<b>Using the DSP Modes</b>	<b>22</b>
Available DSP Modes According to the Speaker Arrangement	24
Adjusting the 3D-PHONIC Mode	25
Adjusting the DAP Mode	25
Adjusting the Surround Modes	25
Activating the DSP Mode	29
<b>Using the DVD MULTI Playback Mode</b>	<b>31</b>
Activating the DVD MULTI Playback Mode	31
<b>Using the On-Screen Menus</b>	<b>33</b>
Selecting the Source to Play	33
Selecting Different Sources for Picture and Sound	33
Activating the DSS Mode	33
Selecting the Type of Digital Input Mode	34
Adjusting the Front Speaker Output Balance	34
Refreshing the Bass	34
Attenuating the Input Signal	34
Adjusting the Subwoofer Output Level	34
Adjusting the DSP Mode	35
Adjusting the DVD MULTI Playback Mode	35
Selecting Your Favorite SEA Mode	35
Creating Your Own SEA Mode	35
Selecting the Basic Setting Items	36
Operating the Tuner	36
Storing the Preset Stations	37
Assigning Names to Preset Stations	37
<b>COMPUM LINK Remote Control System</b>	<b>38</b>
<b>TEXT COMPUM LINK Remote Control System</b>	<b>39</b>
■ Showing the Disc Information on the TV Screen	40
■ Searching for a Disc (Only for the CD player)	41
■ Entering the Disc Information	42
<b>AV COMPUM LINK Remote Control System</b>	<b>44</b>
<b>Operating JVC's Audio/Video Components</b>	<b>46</b>
Operating Audio Components	46
Operating Video Components	48
<b>Operating Other Manufacturers' Video Equipment</b>	<b>48</b>
<b>Troubleshooting</b>	<b>52</b>
<b>Specifications</b>	<b>53</b>

## Parts Identification

Become familiar with the buttons and controls on the receiver before use.  
Refer to the pages in parentheses for details.




### Remote Control



### Front Panel

- 1 TV POWER button (48, 49)
- 2 CAV/DVS POWER button (50)
- 3 Source selecting button (10)
- 4 DVD, DVD MULT. CD, TAPE/MD, TUNERS, VIDEO, PHONO, FM/AM, VCR, LD, CD/VR, 2 SURROUND ON/OFF button and lamp (27, 29)
- 5 INPUT ANALOG/DIGITAL button (17)
- 6 FM MODE button (28)
- 7 SURROUND MODE button (25)
- 8 CD/DISC button (47)
- 9 SOUND button (21, 25, 31)
- 10 On-screen operation buttons (33, 40)
- 11 MENU, SET, EXIT,  $\Delta$ ,  $\nabla$ ,  $<$ ,  $>$
- 12 TV VOL +/- buttons (48, 49)
- 13 Operating buttons for individual components (46, 48, 51)
- 14 AUDIO POWER buttons (10)
- 15 FM BAND selection (45, 51)
- 16 SLEEP button (18)
- 17 ANALOG/DIGITAL buttons (17)
- 18 10 keys for selecting preset channels (20)
- 19 10 keys for adjusting sound (21, 25 – 28, 32)
- 20 10 keys for operating audio/video components (46 – 51)
- 21 Remote control mode selector (10, 46, 49)
- 22 TEXT DISPLAY button (40)
- 23 CHANNEL +/- buttons (48 – 51)
- 24 VOLUME +/- buttons (11)
- 25 MUTING button (12)
- 26 VIDEO input jacks (7)

### AM Antenna Connections



Turn the loop until you have the best reception.

#### Notes:

- Make sure the antenna conductors do not touch any other terminal, connecting cords and power cord. This could cause poor reception.
- If reception is poor, connect an outdoor single vinyl-covered wire to the AM EXT. ANT. terminal (Keep the AM-loop antenna connected.)

### Connecting the Speakers

You can connect the following speakers:

- Two pairs of speakers to produce normal stereo sound.
- One pair of rear speakers to enjoy the surround effect.
- One center speaker to produce more effective surround effect (to emphasize human voices).
- One subwoofer to enhance the bass.


**IMPORTANT:** After connecting the speakers listed above, set the speaker setting information properly to obtain the best possible DSP effect. For details, see page 14.

For each speaker (except for a subwoofer), connect the (-) and (+) terminals on the rear panel or the (1) and (2) terminals marked on the speakers. For connecting a subwoofer, see page 5.

#### CAUTION:

Use speakers with the SPEAKER IMPEDANCE indicated by the speaker terminals.

### Basic connecting procedure



1 Cut, twist and remove the insulation at the end of each speaker signal cable (not supplied).


2 Turn the knob counterclockwise.

3 Insert the speaker signal cable.

4 Turn the knob clockwise.

### Connecting the front speakers

Connect two pairs of front speakers (one pair to the FRONT SPEAKERS (1) terminals, and another pair to the FRONT SPEAKERS (2) terminals).



### IMPORTANT:

To obtain the best possible output power from the receiver, and to prevent the receiver from being overheated, the receiver has the SPEAKER LOAD SELECTOR which has to be set as follows:

- Set it to the HIGH position when the impedance of the front speakers is connected to within the range of 4 ohms to 6 ohms.

- Set it to the LOW position when the impedance of the front speakers connected is within the range of 4 ohms to 6 ohms.

## Getting Started

This section explains how to connect audio/video components and speakers to the receiver, and how to connect the power supply.

### Before Installation

#### General

- Be sure your hands are dry.
- Turn the power off to all components.
- Read the manuals supplied with the components you are going to connect.

#### Locations

- Install the receiver in a location that is level and protected from moisture.
- The temperature around the receiver must be between -5°C and 35°C (33°F and 95°F).
- Make sure there is good ventilation around the receiver. Poor ventilation could cause overheating and damage the receiver.

#### Handling the receiver

- Do not insert any metal object into the receiver.
- Do not disassemble the receiver or remove screws, covers, or casings.
- Do not expose the receiver to rain or moisture.

### Checking the Supplied Accessories


Please be sure you have all of the following items, which are supplied with the receiver.  
The number in the parentheses indicates quantity of the pieces supplied.

- Remote Control (1)
- Batteries (2)
- AM Loop Antenna (1)
- FM Antenna (1)

If anything is missing, contact your dealer immediately.

### Connecting the FM and AM Antennas

#### FM Antenna Connections



#### A. Using the Supplied FM Antenna

The FM antenna provided can be connected to the FM 25Ω COAXIAL terminal as temporary measure.

#### B. Using the Standard Type Connector (Not Supplied)


A standard type connector should be connected to the FM 75Ω COAXIAL terminal.

#### Note:

If reception is poor, connect the outdoor antenna.  
Before attaching a 75Ω coaxial cable (the kind with a round wire going to an outdoor antenna), disconnect the supplied FM antenna.

### Connecting the rear and center speakers

Connect rear speakers to the REAR SPEAKERS terminals and a center speaker to the CENTER SPEAKER terminals.



### Analog connections


#### Audio component connections

Use the cables with RCA pin plugs (not supplied). Connect the white plug to the audio left jack, and the red plug to the audio right jack.

#### CAUTION:

If you connect a sound-enhancing device such as a graphic equalizer between the source components and this receiver, the sound output through this receiver may be distorted.

#### Turntable



#### Note:

Any turntable incorporating a small-drum cartridge such as an MC (moving-coil) type must be connected to this receiver through a commercial line amplifier or step-up transformer. Direct connection may result in insufficient results.

### Connecting the subwoofer speaker

Now connect the subwoofer speaker by connecting a subwoofer. Connect the input pair of a powered subwoofer to the SUBWOOFER OUT jack or speaker panel, using a cable with RCA pin plugs (not supplied).





### Connecting Audio/Video Components

You can connect the following audio/video components to this receiver. Refer also to manuals supplied with your components.

Audio Components	Video Components
• Turntable	• DVB player*
• CD player*	• TV*
• Cassette deck or MD recorder*	• DBS tuner*
• • or MD recorder*	• VCR(s)
• CD recorder*	• Video camera

\* You can connect these components using the methods described in "Analog connections" (to the right) or in "Digital connections" (see page 8).




**IMPORTANT:**

This receiver is equipped with both the composite video and S-video input terminals for connecting video components. You do not have to connect both the composite video and S-video terminals. However, remember that the video signals from the composite video input terminals are output only through the composite video output terminals. If the oven has the S-video input terminals, it is recommended that you connect the S-video input terminals. Therefore, if a recording video component and a playing video component are connected to the receiver through the different video terminals, you cannot record the picture from the playing component on the recording component. In addition, if the TV and a playing video component are connected to the receiver through the different video terminals, you cannot view the playback picture from the playing component on the TV.

To view and record the playback picture from the video component connected to the **DVR/VCR 2** jacks, you must connect the TV and the recording video component through the composite video terminals.

**Note:**

You can connect either a cassette deck or an MD recorder to the TAPE/MD slots. When connecting an MD recorder to the TAPE/MD slots, change the source name, which will be shown on the display, when selected as the source, to "MD". See page 13 for details.

**CD recorder**

If your audio component has a COMPULINK or TEXT COMPULINK jack


- See also page 38 for detailed information about the connection and the COMPULINK remote control system.
- See also page 39 for detailed information about the connection and the TEXT COMPULINK remote control system.

**Video component connections**

Use the cables with RCA pin plugs (not supplied).

Connect the white plug to the audio left jack, the red plug to the audio right jack, and the yellow plug to the video jack.




If your video component has S-video (Y/C separation) terminals, connect them using S-video cables (not supplied). Connecting these video components through the S-video input/output terminals will give better picture playback (or recording) quality.

**VCR**

- A To left/right channel audio output
- B To left/right channel audio input
- C To S-video output
- D To composite video output
- E To composite video input
- F To S-video input

**Video camera**

The VIDEO input jacks on the front panel are convenient when connecting and disconnecting the equipment frequently.

**TV and/or DBS tuner**

To composite video output

To S-video output

- A To center channel audio output
- B To subwoofer audio output
- C To S-video output
- D To front left/right channel audio output
- E To rear left/right channel audio output
- F To composite video output


**DVD player**

When you connect the DVD player with stereo output jacks:



- A To front left/right channel audio output (or to audio mixed output if necessary)
- B To S-video output
- C To composite video output

When you connect the DVD player with its analog discrete output (3.1 CH reproduction) jacks:



- A To center channel audio output
- B To subwoofer audio output
- C To S-video output
- D To front left/right channel audio output
- E To rear left/right channel audio output
- F To composite video output

**Note:**

When connecting the DBS tuner to the TV SOUND(DBS) jacks, change the source name, which will be shown on the display when selected as that source, to "DBS". See page 13 for details.

**Digital connections**

This receiver is equipped with four DIGITAL IN terminals — one digital coaxial terminal and three digital optical terminals, and one DIGITAL OUT terminal.

You can connect any digital equipment such as —


- DBS tuner;
- Digital TV broadcast tuner;
- DVD player;
- CD player;
- CD recorder; and
- MD recorder.

**IMPORTANT:**


When connecting the DVD player, digital TV broadcast tuner or DBS tuner using the digital terminals, you also need to connect it to the video jack (either composite video terminal or S-video terminal) on the rear. Without connecting it to the video jack, you can view no playback picture.

After connecting the components using the DIGITAL IN terminals, set the following correctly if necessary.

- Set the digital input (DIGITAL IN) terminal setting correctly. For details, see "Digital Input (DIGITAL IN Terminal Setting)" on page 16.
- Select the digital input mode correctly. For details, see "Selecting the Analog or Digital Input Mode" on page 18.

**Digital Input terminals****Notes:**

- When shipped from the factory, the DIGITAL IN terminals have been set for use with the following components:
  - DIGITAL 1 (optional): For DVD player
  - DIGITAL 2 (optional): For digital TV broadcast tuner
  - DIGITAL 3 (optional): For digital TV broadcast tuner
  - DIGITAL 4 (optional): For CD recorder
- When you want to operate the CD player, CD recorder, or MD recorder using the COMPULINK remote control system, connect the terminals in the same way as described in "Analog connections" (page 5 and 6).
- When you want to operate the DVD player using the AV COMPULINK remote control system, connect the DVD player also as described in "Analog connections" (see page 7).

**Digital output terminal**

When the digital recording equipment such as an MD recorder has a digital optical terminal, connecting it to the DIGITAL OUT terminal enables you to perform digital-to-digital recording.

**Connecting the Power Cord**

Before plugging the receiver into an AC outlet, make sure that all connections have been made.

Plug the power cord into an AC outlet.



Keep the power cord away from the connecting cables and the antenna. The power cord may cause noise or screen interference. We recommend that you use a coaxial cable to connect the antenna, since it is well-shielded against interference.

**Note:**

The power settings such as power channels and sound adjustment may be changed in a few days in the following cases:


- When you unplug the power cord.
- When a power failure occurs.

**CAUTIONS:**

- Do not touch the power cord with wet hands.
- Do not pull on the power cord to unplug the cord. When unplugging the cord, always grasp the plug as not to damage the cord.

**Putting Batteries in the Remote Control**

Before using the remote control, put two supplied batteries first. When using the remote control, aim the remote control directly at the remote sensor on the receiver.



- On the back of the remote control, remove the battery cover.

- Insert batteries. Make sure to match the polarity: (+) to (+), (-) to (-).

- Replace the cover.

If the range or effectiveness of the remote control decreases, replace the batteries. Use two R6P(SUM-3)/AA(15F) type dry-cell batteries.

**CAUTION:**

- Follow these precautions to avoid heating or cracking cells.
- Place batteries in the remote control so they match the polarity: (+) to (+), (-) to (-).
  - Do not mix old and new batteries. Batteries that look similar may differ in voltage.
  - Always replace both batteries at the same time.
  - Do not expose batteries to heat or flame.

When the component has a digital coaxial output terminal, connect it to the DIGITAL 2 (CD), DIGITAL 3 (TV) or DIGITAL 4 (CD) terminal, using the digital coaxial cable (not supplied).

When the component has a digital optical output terminal, connect it to the DIGITAL 1 (DVD), DIGITAL 2 (CD), DIGITAL 3 (TV) or DIGITAL 4 (CD) terminal, using the digital optical cable (not supplied).

Before connecting a digital optical cable, unplug the protective plug.

## Basic Operations


The following operations are commonly used when you play any sound source.

**IMPORTANT:**  
When using the remote control, check to see if its remote control mode selector is set to the correct position.  
To operate this receiver, set it to "AUDIO/TV/VCR".

### Turning the Power On and Off (Standby)

**On the front panel:**

To turn on the power, press POWER. The STANDBY lamp goes off. The name of the current source (or station frequency) appears on the display.



Current source name appears  
Current volume level is shown here

To turn off the power (into standby mode), press POWER again. The STANDBY lamp lights up. A small amount of power is consumed in standby mode. To turn the power off completely, unplug the AC power cord.

**From the remote control:**

To turn on the power, press AUDIO POWER.

The STANDBY lamp goes off. The name of the current source (or station frequency) appears on the display.

To turn off the power (into standby mode), press AUDIO POWER again. The STANDBY lamp lights up.

### Selecting the Source to Play

**On the front panel:**

Turn SOURCE SELECTOR until the source name you want appears on the display.  
As you turn the selector, the source changes as follows:

CD	—	PHONO	—	Tape	—	FM	—
AM	—	DVD MULTI	—	TV SOUND or DBS	—	VCR 1	—
TV SOUND or DBS	—	VCR 1	—	CDR/VCR 2	—	VIDEO	—
CDR/VCR 2	—	VIDEO	—	—	—	PHONE	—
—	—	PHONE	—	—	—	FM/AM	—

The selected source lamp also lights up.  
The DVD lamp lights up both for "DVD" and "DVD MULTI".

10

### Listening only with headphones

You can listen with the headphones without deactivating both pairs of speakers; however, if you want to use the HEADPHONE mode (see below), you must turn off both pairs of speakers.

1. Connect a pair of headphones to the PHONES jack on the front panel.
2. Press SPEAKERS 1 and/or 2 so no lamps on the buttons are lit on.  
This cancels the surround mode or DSP mode currently selected, and activates the HEADPHONE mode (see below).
3. The HEADPHONE indicator lights up on the display.

#### HEADPHONE mode:

This mode can reproduce the LFE channel signals, mixing them with the front channel signals. So you will notice the subwoofer sounds even if you listen to a source using the headphones.

#### Note:

- While in the headphones mode, you cannot use any other DSP modes (see page 22).
- Activating the speaker cancels the headphones mode and turns on the DSP mode previously selected.

#### CAUTION:

Be sure to turn down the volume before connecting or putting on headphones, as high volume can damage both the headphones and your hearing.

### Muting the Sound

#### From the remote control ONLY:

Press MUTING to mute the sound through all speakers and headphones connected.  
"MUTING" appears on the display and the volume turns off (the volume level indicator goes off).

- To restore the sound, press MUTING again so that "OFF" appears on the display.  
• Turning MASTER VOLUME on the front panel or pressing VOLUME +/- on the remote control also restores the sound.

### Reinforcing the Bass

You can boost the bass level.

#### On the front panel ONLY:

- Press BASS BOOST (SOURCE NAME) briefly to select the bass boost function.  
Each time you press this button, the bass-boost function turns on ("BASSBOOST ON") and off ("BASSBOOST OFF").  
• Select "BASSBOOST ON" to activate the bass boost function. The BASS BOOST lamp also lights up on the display.  
• Select "BASSBOOST OFF" to cancel it.  
The indicator goes off.

#### Note:


The function affects the front speaker sounds only.

### Using the remote control:

Press one of the source selecting buttons.



Selected source name appears



**DVD/DVD MULTI:** Select the DVD player.  
For viewing the digital video disc using the analog discrete output mode (S-VIDEO reproduction) on the DVD player. To enjoy the DVD MDI playback, see page 31.

**CD+TAPE/MD:** Select the cassette deck (or MD recorder).  
Select TV sound (or the DBS tuner).

**VIDEO:** Select video component connected to the VIDEO jacks.

**PHONE/FM/AM:** Select the antenna.  
Select FM or AM broadcast.

**VCR 1:** Select the video component connected to the VCR 1 jacks.

**CDR/VCR 2:** Select the CD recorder or video component connected to the CDR/VCR 2 jacks.

**Notes:**

- When connecting an MD recorder to the TAPE/MD jacks, and a DBS tuner to the TV SOUND/DBS jacks, change the source name shown on the display for details, see page 13.
- When you select one of the source selecting buttons on the remote control marked above with an asterisk (\*), the receiver automatically names on.

**Notes:**

- When connecting an MD recorder to the TAPE/MD jacks, and a DBS tuner to the TV SOUND/DBS jacks, change the source name shown on the display for details, see page 13.
- When you select "DVD MULTI," all the signal indicators except "S" light up.

**Selecting different sources for picture and sound:**

You can watch picture from a video component while listening to sound from another component.

**On the front panel:**

1. Press SOUND SELECT (INPUT ATT.) briefly while viewing the picture from a video component such as the VCR or DVD player, etc.

"SOUND SELECT" appears on the display.

**2. Turn SOURCE SELECTOR to select the sound (except the TV sound), while the indication of the above step is still on the display.**

**From the remote control:**

Press one of the audio source selecting buttons (CD, TAPE/MD, PHONE, FM/AM, VIDEO/S\*), while viewing the picture from a video component such as the VCR or DVD player, etc.

**Notes:**

- Once you have selected a video source, pictures of the selected source are sent to the TV until you select another video source.

The "VOLUME" button only works for selecting "DBS" as the source but not for selecting "TV SOUND." When you use the DBS tuner, change the source name correctly (see page 13).

### Signal and speaker indications on the display

The signal indicators light up to indicate the incoming channel signals.

Only the indicators for the incoming signals light up.

The frame of the signal indicator (except for "L", "C", and "R") lights up if the corresponding speaker is set to "LARGE" or "SMALL" (for subwoofer, "YES").

The frames of "L" and "R" indicators always light up.

**Adjusting the Volume**

**On the front panel:**

To increase the volume, turn MASTER VOLUME clockwise.

To decrease the volume, turn it counter-clockwise.

• When you turn MASTER VOLUME rapidly, the volume level also changes rapidly.

• When you turn MASTER VOLUME slowly, the volume level also changes slowly.

**From the remote control:**

To increase the volume, press VOLUME +.

To decrease the volume, press VOLUME -.

**CAUTION:**

Always set the volume to the minimum before starting any source. If the volume is set at its high level, the sudden blast of sound energy can permanently damage your hearing and/or ruin your speakers.

**Notes:**

The volume level can be adjusted within the range of "0" (minimum) to "90" (maximum).

### Selecting the Front Speakers

**On the front panel ONLY:**

When you have connected two pairs of the front speakers, you can select which to use.

**Press SPEAKERS 1 or SPEAKERS 2 to select the speaker to use.**

1. Each time you press the button, the lamp on the respective button turns on and off. When the lamp on either button lights up, the respective speakers are activated.

**IMPORTANT:**

You can choose two pairs of the front speakers at the same time only when the SPEAKER LOAD SELECTOR on the rear panel is set to "HIGH" and when no signals are sent to the center and rear speakers. Otherwise, activating one pair of the speakers deactivates the other.

**Notes:**

- If you use any of the DSP modes other than the 3D-PHONIC modes with both front speakers activated, the speakers connected to the FRONT SPEAKERS terminals are deactivated.

## Basic Settings

Some of the following settings are required after connecting and positioning your speakers in your listening room, while others will make operations easier.

### IMPORTANT:

When using the remote control, check to see if its remote control mode selector is set to the correct position.

To operate this receiver, set it to "AUDIO/TV/VCR".

### Recording a Source

#### For analog-to-analog recording

You can record any analog source through the receiver to —

• the cassette deck (or MD recorder) connected to the TAPE/MD jacks.

• the VCR connected to the VCR 1 jacks, and

• the CD recorder (or VCR) connected to the CDR/VCR 2 jacks — at the same time.

#### For digital-to-digital recording

You can record any digital source through the receiver to —

• the digital recording device connected to the DIGITAL OUT terminals.

#### Notes:

- Analog-to-digital and digital-to-analog recordings are not possible.

• The output volume level, bass boost (see page 12), SEA modes (see page 21), and DSP modes (see page 22) cannot affect the recording.

• The digital output signal (see page 25, 26) does not come out through the DIGITAL OUT terminals.

### Adjusting the Subwoofer Output Level

You can adjust the subwoofer output level if you have selected "YES" for the "SUBWOOFER" (see page 14).

Once it has been adjusted, the receiver memorizes the adjustment.

**Before you start, remember...**

- There is a time limit in doing the following steps. If the setting is canceled before you finish, start from step 1 again.

• When the front speakers are all disconnected, the subwoofer level cannot be adjusted.

**On the front panel:**

1. Press BALANCE/SURROUND ADJUST repeatedly until "SUBWFR LEVEL" appears on the display.

The display changes to show the current setting.

**2. Turn MULTI JOG to adjust the subwoofer output level (-10 dB to +10 dB).**

**From the remote control:**

1. Press SOUND.

The 10 keys are activated for sound adjustments.

**2. Press SUBWOOFER +/- to adjust the subwoofer output level (-10 dB to +10 dB).**

**Notes:**

- You can only assign the correct source name to "TAPE/MD" and "TV SOUND/DBS" but not to "CDR/VCR 2".

• Without changing the source name, you can still use the connected components. However, there may be some inconvenience.

• "TAPE/MD" and "SOUND/DBS" appear on the display when you select the MD recorder or DBS tuner.

• You cannot use the digital input (see page 16) for the MD recorder.

• You cannot use the COMPU LINK remote control system (see page 36) to operate the MD recorder.

**On the front panel:**

1. Press BALANCE/SURROUND ADJUST repeatedly until "L/R BALANCE" appears on the display.

The display changes to show the current setting.

**2. Turn MULTI JOG to adjust the balance.**

• Turning clockwise increases the left channel output.

• Turning counter-clockwise decreases the right channel output.

**Setting the Subwoofer Information**

Register whether or not you have connected a subwoofer.

Before you start, remember...

- \* There is a time limit in doing the following steps. If the setting is canceled before you finish, start from step 1 again.

On the front panel:

1. Press **SETTING** repeatedly until "SUBWOOFER" appears on the display.



2. Turn **MULTI JOG** to register whether you have connected a subwoofer or not.

- \* As you turn it, the subwoofer setting alternates between "YES" and "NO".

- YES:** Select this when a subwoofer is used. lights up on the display (see page 15).  
**NO:** Select this when no subwoofer is used.

**Setting the Speakers for the DSP Modes**

To obtain the best possible surround sound of the DSP modes, you have to register the information about the speaker arrangement after all connections are completed.

Before you start, remember...

- \* There is a time limit in doing the following steps. If the setting is canceled before you finish, start from step 1 again.

**Front, Center, and Rear Speaker Setting**

Registers the size of all the connected speakers.

- \* When you change your speakers, you need to register the information about the speakers again.

On the front panel ONLY:

1. Press **SETTING** repeatedly until "FRONT SPK" (Front Speaker), "CENTER SPK" (Center Speaker) or "REAR SPK" (Rear Speaker) appears on the display.



2. Turn **MULTI JOG** to select the appropriate item about the speaker selected in the above step.

- \* As you turn it, the display changes to show the following:

**LARGE —> SMALL —> NONE**

- LARGE:** Select this when the speaker size is relatively large.  
**SMALL:** Select this when the speaker size is relatively small.  
**NONE:** Select this when you have not connected a speaker. (Not selectable for the front speakers)

3. Repeat steps 1 and 2 to select the appropriate items for the other speakers.

**Notes:**

- \* Keep the following comment in mind as reference when adjusting.
  - If the size of the center speaker unit built in your speaker is greater than 4 1/4 inches (11 cm), select "LARGE", and it is smaller than 4 1/4 inches (11 cm), select "SMALL".
  - All previous settings "NO" for the subwoofer settings automatically select "NONE" for the front speaker settings.
  - If you have selected "SMALL" for the front speaker setting, you cannot select "LARGE" for the center and rear speaker settings.

**Center Delay Time Setting**

Registers the delay time of the sound from the center speaker, comparing to that of the sound from the front speakers.

- If the distance from your listening point to the center speaker is equal to that of the front speakers, select 0 msec. As the distance to the center speaker becomes shorter, increase the delay time.
- 1 msec increase in delay time corresponds to 11 7/8 inches (30 cm) deviation (in accuracy) in distance.

\* When shipped from the factory, delay time is set to 0 msec.

On the front panel ONLY:

1. Press **SETTING** repeatedly until "CENTER DELAY" appears on the display.



2. Turn **MULTI JOG** to select the delay time of the center speaker output.

- \* Turn it clockwise to increase the delay time from 0 msec ("C. DELAY: 0msec") to 5 msec ("C. DELAY: 5msec").
- \* Turn it counter-clockwise to decrease the delay time from 5 msec ("C. DELAY: 5msec") to 0 msec ("C. DELAY: 0msec").

**Notes:**

- \* Center delay time setting is not valid for the DVD MULTI playback mode.
- \* You cannot adjust the center delay time when you have set "CENTER SPK" to "NONE".

**Rear Delay Time Setting**

Registers the delay time of the sound from the rear speakers, comparing to that of the sound from the front speakers.

- If the distance from your listening point to the rear speakers is equal to that of the front speakers, select 0 msec. As the distance to the rear speakers becomes shorter, increase the delay time.

- \* Turn it clockwise to increase the delay time from 0 msec ("R. DELAY: 0msec") to 5 msec ("R. DELAY: 5msec").
- \* Turn it counter-clockwise to decrease the delay time from 5 msec ("R. DELAY: 5msec") to 0 msec ("R. DELAY: 0msec").

\* When shipped from the factory, delay time is set to 5 msec.

On the front panel ONLY:

1. Press **SETTING** repeatedly until "REAR DELAY" appears on the display.



2. Turn **MULTI JOG** to select the appropriate item about the speaker selected in the above step.

- \* As you turn it, the display changes to show the following:

**LARGE —> SMALL —> NONE**

- LARGE:** Select this when the speaker size is relatively large.  
**SMALL:** Select this when the speaker size is relatively small.  
**NONE:** Select this when you have not connected a speaker. (Not selectable for the front speakers)

2. Turn **MULTI JOG** to select the delay time of the rear speaker output.

- \* Turn it clockwise to increase the delay time from 0 msec ("R. DELAY: 0msec") to 15 msec ("R. DELAY: 15msec").
- \* Turn it counter-clockwise to decrease the delay time from 15 msec ("R. DELAY: 15msec") to 0 msec ("R. DELAY: 0msec").

**Notes:**

- \* Rear delay time setting is not valid for the DVD MULTI playback mode.
- \* You cannot adjust the rear delay time when you have set "REAR SPK" to "NONE".

**Crossover Frequency Setting**

Small speakers cannot reproduce the bass sound very well. So, if you have used a small speaker for any of the front, center, and rear channels, this receiver automatically relocates the bass elements originally assigned to the channel for which you have connected the small speaker, to another channel (for which you have connected the larger speaker).

\* Since this function properly, you have to set the crossover frequency level according to the size of the small speaker connected.

\* If you have selected "LARGE" for all speakers (see page 16), this function is set to "OFF" and cannot be adjusted.

On the front panel ONLY:

1. Press **SETTING** repeatedly until "CROSSOVER FREQ" (Crossover Frequency) appears on the display.



2. Turn **MULTI JOG** to select the crossover frequency level according to the size of the small speaker connected.

- \* Turn it clockwise to increase the delay time from 0 msec ("C. DELAY: 0msec") to 5 msec ("C. DELAY: 5msec").
- \* Turn it counter-clockwise to decrease the delay time from 5 msec ("C. DELAY: 5msec") to 0 msec ("C. DELAY: 0msec").

**Notes:**

- \* Center delay time setting is not valid for the DVD MULTI playback mode.
- \* If you have selected "LARGE" for all speakers (see page 16), this function is set to "OFF" and cannot be adjusted.

**Low Frequency Effect Attenuator Setting**

If the bass sound is distorted while playing back a source using Dolby Digital or DTS Digital Surround, follow the procedure below.

On the front panel ONLY:

1. Press **SETTING** repeatedly until "LFE ATT" (Low Frequency Effect Attenuator) appears on the display.

The display changes to show the current setting.

\* As you turn it, the display changes to show the following:

**0dB —> -10dB**

- MIN:** Normally select this.  
**MAX:** Select this when the bass sound is distorted.

**Notes:**

- \* Low frequency effect attenuator setting is not valid for the DVD MULTI playback mode.

**Dynamic Range Compression Setting**

You can compress the dynamic range difference between maximum sound and minimum sound of the reproduced sound. This is useful when enjoying surround sound at night.

\* This function takes effect only when playing back a source using Dolby Digital.

On the front panel ONLY:

1. Press **SETTING** repeatedly until "D. RANGE COMP" (Dynamic Range Compression) appears on the display.

The display changes to show the current setting.

2. Turn **MULTI JOG** to select the appropriate item about the compression level.

- \* As you turn it, the display changes to show the following:

**60Hz —> 100Hz —> 120Hz**

**Notes:****Crossover Frequency Setting****Note:****Crossover frequency setting is not valid for the DVD MULTI playback mode.****DOLBY DIGITAL****DTS****DOLBY DIGITAL (Digital)****DTS (Digital)****DOLBY DIGITAL (Digital)**



## Using the DSP Modes

The built-in Surround Processor provides three types of the DSP (Digital Signal Processor) mode — 3D-PHONIC mode, DAP (Digital Acoustic Processor) mode and Surround mode.

### 3D-PHONIC modes

The 3D-PHONIC mode gives you such a nearly surround effect as is reproduced through the Dolby Surround decoder, which is widely used to reproduce sounds with the feeling of movie theater. This capability is unique to this receiver. The 3D-PHONIC mode is the result of research on sound localization technology carried out at JVC for many years. This mode can be used when the front speakers are connected to this receiver (without respect to the rear/center speaker connection).

**3D ACTION:** Best for action and war movies — where the action is fast and explosive.

**3D THEATER:** Reproduces the sound field of a large theater. This mode can be selected when only front speakers are connected to this receiver and "REAR SPK" and "CENTER SPK" are set to "NONE" (see page 14).

### DAP modes

The sound heard in a concert hall or club consists of direct sound and indirect sound — early reflections and reflections from behind. Direct sounds reach the listener directly without any reflection. On the other hand, indirect sounds are delayed by the distance of the ceiling and walls. These direct sound and indirect sounds are the most important elements of the acoustic surround effects. The DAP mode can create these important elements, and gives you a "being there" feeling. This mode can be used when the front speakers are connected to this receiver (without respect to the rear/center speaker connection).



You can select one of the following in your preference while playing an analog or linear PCM source:

**LIVE CLUB:** Gives the feeling of a live music club with a low ceiling.

**DANCE CLUB:** Gives a throbbing bass beat.

**HALL:** Gives clear vocal and the feeling of a concert hall.

**PAVILION:** Gives the spacious feeling of a pavilion with a high ceiling.



### Surround modes

With this receiver, you can use three types of the Surround mode. Following modes cannot be used when only the front speakers are connected to this receiver (without the rear speakers or center speaker).

#### Dolby Surround (Dolby Digital and Dolby Pro Logic)

Used to watch the soundtracks of software encoded with Dolby Digital (bearing the mark ) or with Dolby Surround (bearing the mark ).


Dolby Surround decoding formats the left front channel, right front channel, center channel, and rear channel (total 4 channels) signals into 2 channels. The Dolby Pro Logic decoder built in this receiver decodes these 2 channel signals into original 4 channel signals — matrix-based multichannel reproduction, and allows you to enjoy the realistic stereo sounds in your listening room.

On the other hand, Dolby Digital encoding method (so called a discrete 5.1 channel digital audio format) records and compresses the left front channel, right front channel, center channel, left rear channel, right rear channel, and LFE channel (total 6 channels), but LFE channel is output as 0.1 channel, therefore, it is called 5.1.

This receiver de-encodes Dolby Digital signals independently from other channel signals to avoid interference, therefore, you can obtain much better sound quality with much stereo and surround effects.

The Dolby Digital decoder built in this receiver can create much more realistic sound field in your listening room. You may feel as if you were in a real theater. In addition, Dolby Digital enables stereo rear sounds, and sets the cutoff frequency of the rear subtitle at 20 kHz, comparing to 7 kHz for Dolby Surround format, so you can hear more detail in the comment and background feelings much more than Dolby Pro Logic.

To enjoy the software encoded with Dolby Digital, you must connect the source component using the digital terminal on the rear of this receiver. (See page 8.)



### Notes:

- The DSP modes have no effect on monaural sources.
- When you select "DVD MULTI" as the source to play, you cannot select or adjust the DSP modes.
- The lights up when the Dolby Pro Logic decoder built in this receiver is activated.

### DVD MULTI Playback Mode

This receiver provides the DVD MULTI playback mode for reproducing the analog discrete 5.1 channel output mode of the DVD player or other equipment. You can adjust the DVD MULTI playback mode while playing back a video software such as a DVD using the analog discrete 5.1 channel output mode.

- For the DVD MULTI playback mode connection, see page 7.
- For details on the DVD MULTI playback mode, see page 31.

\* Manufactured under license from Dolby Laboratories. "Dolby," and the double-D symbol are trademarks of Dolby Laboratories. Confidential Unpublished Works. ©1992-1997 Dolby Laboratories, Inc. All rights reserved.

\*\* Manufactured under license from Digital Theater Systems, Inc. US Pat. No. 5,491,942 and other world-wide patents issued or pending. DTS® and DTS Digital Surround™ are trademarks of Digital Theater Systems, Inc. ©1995 Digital Theater Systems, Inc. All rights reserved.

## Available DSP Modes According to the Speaker Arrangement

Available DSP modes will vary depending on how many speakers are used with this receiver. Make sure that you have set the speaker information correctly (see page 14).

Speaker arrangements	Available DSP modes
	<p>Each time you press DSP MODE on the front panel or SURROUND MODE on the remote control, the DSP modes change as follows:</p> <ul style="list-style-type: none"> <li>3D THEATER</li> <li>LIVE CLUB</li> <li>DANCE CLUB</li> <li>HALL</li> <li>PAVILION</li> <li>3D ACTION</li> <li>DSP OFF (DSP mode is canceled)</li> </ul>
	<p>Each time you press DSP MODE on the front panel or SURROUND MODE on the remote control, the DSP modes change as follows:</p> <p>By pressing SURROUND MODE:</p> <ul style="list-style-type: none"> <li>THEATER</li> <li>LIVE CLUB</li> <li>DANCE CLUB</li> <li>HALL</li> <li>PAVILION</li> <li>3D ACTION</li> <li>DSP OFF (DSP mode is canceled)</li> </ul> <p>To activate the Surround mode, press SURROUND ON/OFF button so that the lamp on the button lights up.</p> <p>Notes:</p> <ul style="list-style-type: none"> <li>Activated automatically only when "AUTOPCM" is selected as the digital input and playback source in selected Dolby Digital Surround.</li> <li>Activated automatically only when "AUTOPCM" is selected as the digital input and playback source in encoded with DTS Digital Surround.</li> </ul>
	<p>Each time you press SURROUND MODE repeatedly until "3D ACTION" or "3D THEATER" appears on the display.</p> <p>Notes:</p> <ul style="list-style-type: none"> <li>If Surround mode is canceled while playing back a multichannel source such as Dolby Digital and DTS Digital Surround, all channel signals are mixed with left and right front channel and are output through the front speakers.</li> <li>While playing back a multichannel source such as Dolby Digital and DTS Digital Surround, DAP mode, and 3D-PHONIC modes cannot be used. Once the source is played back, the Surround mode, DAP mode, and 3D-PHONIC mode, the currently selected mode will be activated and Dolby Digital or DTS Digital Surround mode will be activated.</li> </ul>

### IMPORTANT:

When using the remote control, check to see if the remote control mode selector is set to the correct position.  
To operate this receiver, set it to "AUDIO/TV".

VCR

### 3. Press EFFECT to select an effect level you want.

- Each time you press the button, the effect level changes as follows:

~ DSP EFFECT 1 → DSP EFFECT 2 → DSP EFFECT 3 → DSP EFFECT 5 ← → DSP EFFECT 4

### Adjusting the 3D-PHONIC Modes

Once you have adjusted the 3D-PHONIC modes, the adjustment is memorized for each 3D-PHONIC mode.

Before you start, remember...

- Make sure that you have set the speaker information correctly (see page 14).
- There is a time limit in doing the following steps. If the setting is canceled before you finish, start from step 1 again.

To cancel before you finish, start from step 1 again.

#### On the front panel:

- Press DSP MODE repeatedly until "3D ACTION" or "3D THEATER" appears on the display.

The 3D-PHONIC, DSP, and DOLBY PRO LOGIC indicators also light up on the display.

#### 2. Adjust the effect level.

- Turn BALANCE/SURROUND ADJUST repeatedly until "DOLBY EFFECT" appears on the display. The display changes to show the current setting.

- Turn MULTI JOG to select the effect level.

As you turn it, the effect level changes as follows:

DSP EFFECT 1 → DSP EFFECT 2 → DSP EFFECT 3 → DSP EFFECT 5 ← → DSP EFFECT 4

As the number increases, the selected 3D-PHONIC mode becomes stronger.

#### From the remote control:

- Press SURROUND MODE repeatedly until "3D ACTION" or "3D THEATER" appears on the display.

The 3D-PHONIC, DSP, and DOLBY PRO LOGIC indicators also light up on the display.

#### 2. Press SOUND.

The 10 keys are activated for sound adjustments.



### Adjusting the DAP Modes

Once you have adjusted the DAP modes, the adjustment is memorized for each DAP mode.

Before you start, remember...

- Make sure that you have set the speaker information correctly (see page 14).
- There is a time limit in doing the following steps. If the setting is canceled before you finish, start from step 1 again.

To cancel before you finish, start from step 1 again.

#### On the front panel:

- Press DSP MODE repeatedly until the DAP mode — LIVE CLUB, DANCE CLUB, HALL, or PAVILION — appears on the display.

The DAP indicator also lights up on the display.

- When you have set "REAR SPK" to "NONE", the 3D-PHONIC indicator also lights up.

- When the DAP mode is used with the SEA mode (see page 21), sounds may be distorted. If this happens, turn off the SEA mode.

Before you start, remember...

- Make sure that you have set the speaker information correctly (see page 14).
- There is a time limit in doing the following steps. If the setting is canceled before you finish, start from step 1 again.

- Turn MULTI JOG to adjust the effect level when you have set "REAR SPK" to "NONE". See page 14.

- When the DAP mode is used with the SEA mode (see page 21), sounds may be distorted. If this happens, turn off the SEA mode.

#### On the front panel:

- Press DSP MODE repeatedly until the DAP mode — LIVE CLUB, DANCE CLUB, HALL, or PAVILION — appears on the display.

The DAP indicator also lights up on the display.

- When you have set "REAR SPK" to "NONE", the 3D-PHONIC indicator also lights up.

- Turn MULTI JOG to adjust the effect level.

- To adjust the left rear speaker level, turn R.R. (Rear Right) MULTI JOG.
- To adjust the right rear speaker level, turn R.L. (Rear Left) MULTI JOG.

- Repeat 1) and 2) to adjust the other speaker output level.







### ■ Adjusting the Front Speaker Output Balance

(Also see page 13)

1. Press MENU.
- The MAIN MENU appears on the TV.  
• Pressing one of the  $\Delta/\nabla/\leftarrow/\rightarrow$  buttons also displays the MAIN MENU.
2. Press  $\Delta/\nabla$  to move  $\square$  to "SOUND CONTROL," then press  $\leftarrow/\rightarrow$ .  
The SOUND CONTROL menu appears.
3. Press  $\Delta/\nabla$  to move  $\square$  to "BAL." (Balance).
4. Press  $\leftarrow/\rightarrow$  to adjust the balance.
5. When you finish, press EXIT repeatedly until the menu disappears from the TV.

### ■ Reinforcing the Bass

(Also see page 12)

1. Press MENU.
- The MAIN MENU appears on the TV.  
• Pressing one of the  $\Delta/\nabla/\leftarrow/\rightarrow$  buttons also displays the MAIN MENU.
2. Press  $\Delta/\nabla$  to move  $\square$  to "SOUND CONTROL," then press  $\leftarrow/\rightarrow$ .  
The SOUND CONTROL menu appears.
3. Press  $\Delta/\nabla$  to move  $\square$  to "BASS BOOST."
4. Press  $\leftarrow/\rightarrow$  to turn the bass boost function "ON" or "OFF."
5. When you finish, press EXIT repeatedly until the menu disappears from the TV.

### ■ Attenuating the Input Signal

(Also see page 12)

1. Press MENU.
- The MAIN MENU appears on the TV.  
• Pressing one of the  $\Delta/\nabla/\leftarrow/\rightarrow$  buttons also displays the MAIN MENU.
2. Press  $\Delta/\nabla$  to move  $\square$  to "SOUND CONTROL," then press  $\leftarrow/\rightarrow$ .  
The SOUND CONTROL menu appears.
3. Press  $\Delta/\nabla$  to move  $\square$  to "INPUT ATT."
4. Press  $\leftarrow/\rightarrow$  to turn the input attenuator mode "ATT ON" or "NORMAL."
5. When you finish, press EXIT repeatedly until the menu disappears from the TV.

34

### ■ Adjusting the Subwoofer Output Level

(Also see page 12)

1. Press MENU.
- The MAIN MENU appears on the TV.  
• Pressing one of the  $\Delta/\nabla/\leftarrow/\rightarrow$  buttons also displays the MAIN MENU.
2. Press  $\Delta/\nabla$  to move  $\square$  to "SOUND CONTROL," then press  $\leftarrow/\rightarrow$ .  
The SOUND CONTROL menu appears.
3. Press  $\Delta/\nabla$  to move  $\square$  to "SUBWFR LEVEL."
4. Press  $\leftarrow/\rightarrow$  to adjust the subwoofer output level.
5. When you finish, press EXIT repeatedly until the menu disappears from the TV.

### ■ Adjusting the DSP Modes

(Also see pages 25 ~ 29)

1. Press MENU.
- The MAIN MENU appears on the TV.  
• Pressing one of the  $\Delta/\nabla/\leftarrow/\rightarrow$  buttons also displays the MAIN MENU.
2. Press  $\Delta/\nabla$  to move  $\square$  to "SOUND CONTROL," then press  $\leftarrow/\rightarrow$ .  
The SOUND CONTROL menu appears.
3. Press  $\leftarrow/\rightarrow$  to select the DSP mode you want to adjust.  
In this example, "THEATER" is selected.
4. Press  $\Delta/\nabla$  to move  $\square$  to "SOUND CONTROL," then press  $\leftarrow/\rightarrow$ .  
The SOUND CONTROL menu appears.
5. Press  $\Delta/\nabla$  to move  $\square$  to "SURROUND LEVEL," then press  $\leftarrow/\rightarrow$ .  
The SURROUND LEVEL menu appears.
6. Press  $\Delta/\nabla$  to move  $\square$  to the item you want to set or adjust, then press  $\leftarrow/\rightarrow$ .  
On these adjustment menus, you can do the following:  
For 3D-PHONIC (3D ACTION, 3D THEATER):  
"DSP EFFECT": Select the effect level.

When you finish, press EXIT repeatedly until the menu disappears from the TV.

### ■ For DAP (LIVE CLUB, DANCE CLUB, HALL, PAVILION)

"REAR L LEVEL": Adjust the left rear speaker output level.  
"REAR R LEVEL": Adjust the right rear speaker output level.  
"DSP EFFECT": Select the effect level.

### For Dolby Pro Logic:

"TEST TONE": Outputs a test tone.  
"CENTER LEVEL": Adjust the center speaker output level.  
"REAR L LEVEL": Adjust the left rear speaker output level.  
"REAR R LEVEL": Adjust the right rear speaker output level.  
"CENTER TONE": Select the center tone level.  
"DOLBY DIGITAL and DTS Digital Surround":  
"TEST TONE": Outputs a test tone.  
"CENTER LEVEL": Adjust the center speaker output level.  
"REAR L LEVEL": Adjust the left rear speaker output level.  
"REAR R LEVEL": Adjust the right rear speaker output level.  
"CENTER TONE": Select the center tone level.  
"DSP EFFECT": Select the effect level.

6. Press  $\Delta/\nabla$  to move  $\square$  to the item you want to set or adjust, then press  $\leftarrow/\rightarrow$ .  
On this adjustment menu, you can do the following:  
"CENTER LEVEL": Adjust the center speaker output level.  
"REAR L LEVEL": Adjust the left rear speaker output level.  
"REAR R LEVEL": Adjust the right rear speaker output level.  
"CENTER TONE": Select the center tone level.

7. When you finish, press EXIT repeatedly until the menu disappears from the TV.

### ■ Selecting Your Favorite SEA Mode

(Also see page 21)

1. Press MENU.
- The MAIN MENU appears on the TV.  
• Pressing one of the  $\Delta/\nabla/\leftarrow/\rightarrow$  buttons also displays the MAIN MENU.
2. Press  $\Delta/\nabla$  to move  $\square$  to "SOUND CONTROL," then press  $\leftarrow/\rightarrow$ .  
The SOUND CONTROL menu appears.
3. Press  $\Delta/\nabla$  to move  $\square$  to "SEA," then press  $\leftarrow/\rightarrow$ .  
The SEA menu appears.
4. Press  $\Delta/\nabla$  to move  $\square$  to "SEA MODE."
5. Press  $\leftarrow/\rightarrow$  to select the SEA mode you want.
6. When you finish, press EXIT repeatedly until the menu disappears from the TV.

### ■ Creating Your Own SEA Mode

(Also see page 21)

1. Press MENU.
- The MAIN MENU appears on the TV.  
• Pressing one of the  $\Delta/\nabla/\leftarrow/\rightarrow$  buttons also displays the MAIN MENU.
2. Press  $\Delta/\nabla$  to move  $\square$  to "SOUND CONTROL," then press  $\leftarrow/\rightarrow$ .  
The SOUND CONTROL menu appears.
3. Press  $\Delta/\nabla$  to move  $\square$  to "DVD MULTI."
4. Press  $\Delta/\nabla$  to move  $\square$  to "SOUND CONTROL," then press  $\leftarrow/\rightarrow$ .  
The SOUND CONTROL menu appears.
5. Press  $\Delta/\nabla$  to move  $\square$  to "SURROUND LEVEL," then press  $\leftarrow/\rightarrow$ .  
The SURROUND LEVEL menu appears.

35

### ■ Setting the Basic Setting Items

(Also see pages 13 ~ 17)

1. Press MENU.
- The MAIN MENU appears on the TV.  
• Pressing one of the  $\Delta/\nabla/\leftarrow/\rightarrow$  buttons also displays the MAIN MENU.
2. Press  $\Delta/\nabla$  to move  $\square$  to "SETTING," then press  $\leftarrow/\rightarrow$ .  
The SETTING 1 or SETTING 2 menu appears.
3. Press  $\Delta/\nabla$  to move  $\square$  to the item you want to set or adjust, then press  $\leftarrow/\rightarrow$ .  
To go to the "SWITCHING PAGE" menu, move  $\square$  to "NEXT PAGE," then press  $\leftarrow/\rightarrow$ .  
To go back to the SETTING 1 menu, move  $\square$  to "PREVIOUS PAGE," then press  $\leftarrow/\rightarrow$ .
- On the SETTING 1 and 2 menus, you can do the following:  
"SUBWOOFER": Set the subwoofer information (see page 14).  
"FRONT SPK": Set the front speaker information (see page 14).  
"CENTER SPK": Set the center speaker information (see page 14).  
"REAR SPK": Set the rear speaker information (see page 14).  
"CNR DELAY": Adjust the delay time of the center speaker output (see page 14).  
"REAR DELAY": Adjust the delay time of the rear speaker output (see page 14).  
"CROSSOVER": Set the crossover frequency (see page 15).
4. When you finish, press EXIT repeatedly until the menu disappears from the TV.

### ■ Operating the Tuner

(Also see pages 19 and 20)

1. Press MENU.
- The MAIN MENU appears on the TV.  
• Pressing one of the  $\Delta/\nabla/\leftarrow/\rightarrow$  buttons also displays the MAIN MENU.
2. Press  $\Delta/\nabla$  to move  $\square$  to "TUNER CONTROL," then press  $\leftarrow/\rightarrow$ .  
The TUNER CONTROL menu appears.
3. Press  $\Delta/\nabla$  to move  $\square$  to the item you want to set or adjust, then press  $\leftarrow/\rightarrow$ .  
On the TUNER CONTROL menu, you can do the following:  
"PRESET CH": Select a preset channel station.  
"BAND": Select the band.  
"FREQUENCY": Tune in a station manually.  
"FM MODE": Select the FM reception mode.  
"PRESET MEMORY": See "Storing the Preset Stations" on the next page.
4. When you finish, press EXIT repeatedly until the menu disappears from the TV.

### ■ Storing the Preset Stations

(Also see page 19)

1. Press MENU.
- The MAIN MENU appears on the TV.  
• Pressing one of the  $\Delta/\nabla/\leftarrow/\rightarrow$  buttons also displays the MAIN MENU.
2. Press  $\Delta/\nabla$  to move  $\square$  to "TUNER CONTROL," then press  $\leftarrow/\rightarrow$ .  
The TUNER CONTROL menu appears.
3. Tune into a station on the TUNER CONTROL menu, referring to "Operating the Tuner" on the previous page.
4. Press  $\Delta/\nabla$  to move  $\square$  to "PRESET MEMORY," then press  $\leftarrow/\rightarrow$ .  
The PRESET MEMORY menu appears.
5. Press  $\leftarrow/\rightarrow$  to select a preset station number you want.
6. Press SET to store the setting.
7. When you finish, press EXIT repeatedly until the menu disappears from the TV.

### ■ Assigning Names to Preset Stations

(Also see page 20)

1. Press MENU.
- The MAIN MENU appears on the TV.  
• Pressing one of the  $\Delta/\nabla/\leftarrow/\rightarrow$  buttons also displays the MAIN MENU.
2. Press  $\Delta/\nabla$  to move  $\square$  to "TUNER CONTROL," then press  $\leftarrow/\rightarrow$ .  
The TUNER CONTROL menu appears.
3. Press  $\Delta/\nabla$  to move  $\square$  to "PRESET CH," then press  $\leftarrow/\rightarrow$ .  
The PRESET CH menu appears.
4. Press  $\leftarrow/\rightarrow$  to select a preset station.
5. Press  $\Delta/\nabla$  to move  $\square$  to "PRESET MEMORY," then press  $\leftarrow/\rightarrow$ .  
The PRESET MEMORY menu appears.


11. When you finish, press EXIT repeatedly until the menu disappears from the TV.

## COMPU LINK Remote Control System

The COMPU LINK remote control system allows you to operate JVC audio components through the remote sensor on the receiver.

To use this remote control system, you need to connect JVC audio components through the COMPU LINK jacks (see below) in addition to the connections using cables with RCA pin plugs (see pages 5 and 6).

- Make sure that the AC power cords of these components are unplugged before connection. Plug the AC power cords only after all connections are complete.



**Note:**

- There are four versions of COMPU LINK remote control systems. This receiver is equipped with the fourth version — COMPU LINK-4. This version is added systematic operations with the CD recorder to the previous version — COMPU LINK-3.
- If your audio component has two COMPU LINK jacks, you can use either one. If it has only one COMPU LINK jack, connect it so that it is the last item in the series of components. (For example, the turntable or CD player in the diagram above.)
- To operate the cassette deck or MD recorder using the COMPU LINK remote control system, set the source name correctly. (See page 13.)
- Refer also to the manuals supplied with your audio components.

This remote control system allows you to use four functions listed below.

### Remote Control through the Remote Sensor on the Receiver

You can control the connected audio components through the remote sensor on the receiver using this remote control. Aim the remote control directly at the remote sensor on the receiver. For details, see pages 46 and 47.


### Automatic Source Selection

When you press the play button on a connected component or on its own remote control, the receiver automatically turns on and changes the source to the component. On the other hand, if you select a new source on the receiver or on the remote control, the selected component begins playing immediately.

In both cases, the previously selected source continues playing without sound for a few seconds.


## OPERATIONS

To use this remote control system, you need to connect the TV to the MONITOR OUT jack on the rear panel (see page 7), and set the TV's input selector to the channel to which the receiver's MONITOR OUT jack is connected. Make sure you have connected the CD player or MD recorder equipped with the TEXT COMPU LINK remote control system. If not, you cannot use the following functions.



### Showing the Disc Information on the TV Screen

Press TEXT DISPLAY while "CD" or "MD" is selected as the source. The Disc Information screen appears on the TV.



## TEXT COMPU LINK Remote Control System

### TEXT COMPU LINK Remote Control System


The TEXT COMPU LINK remote control system has been newly developed to deal with the disc information recorded in the CD Text\* and MD. Using these information in the discs, you can operate the CD player or MD recorder equipped with the TEXT COMPU LINK remote control system through the receiver.

#### CONNECTIONS:


To use this remote control system, you need to connect the CD player and/or MD recorder you want to operate, following the procedures below.

- If you have already plugged your CD player, MD recorder, and this receiver as follows, through the COMPU LINK jacks and TEXT COMPU LINK jacks.
- Connect your CD player, MD recorder, and this receiver as follows, through the COMPU LINK jacks and TEXT COMPU LINK jacks.

#### 1) COMPU LINK jacks:



#### 2) TEXT COMPU LINK jacks:



- Put a tape in the cassette deck (or MD in the MD recorder), and a disc in the CD player (or a record on the turntable).

- Synchronized recording starts the cassette deck (or MD recorder) or turntable as soon as a CD or record begins playing.
- When using a CD recorder for synchronized recording, refer to the manual supplied with it.

To use synchronized recording, follow these steps:

- Put a tape in the cassette deck (or MD in the MD recorder), and a disc in the CD player (or a record on the turntable).
- Press the record (•) button and the pause (II) button on the cassette deck (or MD recorder) at the same time.

This puts the cassette deck (or MD recorder) into recording pause.

If you do not press the record (•) button and pause (II) button at the same time, the synchronized recording feature will not operate.

- Press the play (I>) button on the CD player or on the turntable.

The source changes on the receiver, and as soon as play starts, the cassette deck (or MD recorder) starts recording. When the play ends, the cassette deck (or MD recorder) enters recording pause, and stops about 4 seconds later.

#### Notes:

- During synchronized recording, the selected source cannot be changed.
- If the power of any component is shut off during synchronized recording, the TEXT COMPU LINK remote control system may not operate properly. In this case, you must start again from the beginning.

#### Notes:

- The current playing (selected) track is indicated in yellow.
- When you press  $\Delta$  or  $\nabla$  to a track number, you can change the track by pressing  $\Delta$  or  $\nabla$  again. Each time you press the button, track information alternates between its track title and its performer.
- Select this track (in front), then press SET to go to the DISC SEARCH screen (see page 41).
- Select this track (in front), then press SET to go to the TITLE INPUT screen (see page 42).
- Thus appears only when a disc title is entered.
- Disc information such as disc title, performer, and music title that is selected (in front) changes.
- When you press  $\Delta$  or  $\nabla$  to move  $\square$  in front of the disc title, then press SET, the disc information (see Note on  $\square$ ) changes.
- Select  $\square$  or  $\nabla$ , then press SET to change the track.
- Useful buttons and their functions for the current selection.
- Indication here will be changed according to what is currently selected ( $\square$  in front) on the screen. See "Note on  $\square$ ".

#### Note on $\square$ :

- The following information will appear on the display:
- For CD — Disc title, Performer, Genre, Song writer, Composer, Arranger, Message
  - Only recorded information will be shown. If there is no data, "NO DATA" will appear.
  - For MD — Disc title
  - If there is no data, "NO DATA" will appear.

#### Note on $\square$ :

For example the SET button will be used to start play (PLAY), to go to the next screen (ENTER), and to determine the function (ENTER).

#### To exit from the Disc information screen:

Press EXIT.

#### Notes:

- The on-screen display will disappear in the following cases:
  - No operation is done for about 10 minutes.
  - If you do any operation other than explained in this section.
- To control the MD recorder using the TEXT COMPU LINK remote control system, you have to change the source name shown on the display from "TAPE" to "MD" (see page 13).
- Some special characters and marks cannot be displayed correctly.

### TEXT COMPU LINK Remote Control System


The TEXT COMPU LINK remote control system has been newly developed to deal with the disc information recorded in the CD Text\* and MD. Using these information in the discs, you can operate the CD player or MD recorder equipped with the TEXT COMPU LINK remote control system through the receiver.

#### CONNECTIONS:


To use this remote control system, you need to connect the CD player and/or MD recorder you want to operate, following the procedures below.

- If you have already plugged your CD player, MD recorder, and this receiver as follows, through the COMPU LINK jacks and TEXT COMPU LINK jacks.
- Connect your CD player, MD recorder, and this receiver as follows, through the COMPU LINK jacks and TEXT COMPU LINK jacks.

#### 1) COMPU LINK jacks:



#### 2) TEXT COMPU LINK jacks:



- Put a tape in the cassette deck (or MD in the MD recorder), and a disc in the CD player (or a record on the turntable).

- Synchronized recording starts the cassette deck (or MD recorder) or turntable as soon as play starts.
- When using a CD recorder for synchronized recording, refer to the manual supplied with it.

To use synchronized recording, follow these steps:

- Put a tape in the cassette deck (or MD in the MD recorder), and a disc in the CD player (or a record on the turntable).
- Press the record (•) button and the pause (II) button on the cassette deck (or MD recorder) at the same time.

This puts the cassette deck (or MD recorder) into recording pause.

If you do not press the record (•) button and pause (II) button at the same time, the synchronized recording feature will not operate.

- Press the play (I>) button on the CD player or on the turntable.

The source changes on the receiver, and as soon as play starts, the cassette deck (or MD recorder) starts recording. When the play ends, the cassette deck (or MD recorder) enters recording pause, and stops about 4 seconds later.

#### Notes:

- During synchronized recording, the selected source cannot be changed.
- If the power of any component is shut off during synchronized recording, the TEXT COMPU LINK remote control system may not operate properly. In this case, you must start again from the beginning.

#### Notes:

- The current playing (selected) track is indicated in yellow.
- When you press  $\Delta$  or  $\nabla$  to a track number, you can change the track by pressing  $\Delta$  or  $\nabla$  again. Each time you press the button, track information alternates between its track title and its performer.
- Select this track (in front), then press SET to go to the DISC SEARCH screen (see page 41).
- Select this track (in front), then press SET to go to the TITLE INPUT screen (see page 42).
- Thus appears only when a disc title is entered.
- Disc information such as disc title, performer, and music title that is selected (in front) changes.
- Select  $\square$  or  $\nabla$ , then press SET to change the track.
- Useful buttons and their functions for the current selection.
- Indication here will be changed according to what is currently selected ( $\square$  in front) on the screen. See "Note on  $\square$ ".

#### Notes:

- The current playing (selected) track is indicated in yellow.
- When you press  $\Delta$  or  $\nabla$  to a track number, you can change the track by pressing  $\Delta$  or  $\nabla$  again. Each time you press the button, track information alternates between its track title and its performer.
- Select this track (in front), then press SET to go to the DISC SEARCH screen (see page 41).
- Select this track (in front), then press SET to go to the TITLE INPUT screen (see page 42).
- Thus appears only when a disc title is entered.
- Disc information such as disc title, performer, and music title that is selected (in front) changes.
- Select  $\square$  or  $\nabla$ , then press SET to change the track.
- Useful buttons and their functions for the current selection.
- Indication here will be changed according to what is currently selected ( $\square$  in front) on the screen. See "Note on  $\square$ ".

### Searching for a Disc (Only for the CD player)


#### Search for a disc by its performance:

- Press TEXT DISPLAY while "CD" is selected as the source.

The Disc Information screen appears on the TV.

- Press  $\Delta$  /  $\nabla$  to move  $\square$  to "SEARCH," then press SET.

The DISC SEARCH screen appears.



- Press  $\Delta$  /  $\nabla$  to move  $\square$  to "PERFORMER," then press SET.

The PERFORMER SEARCH screen appears.



- Press  $\Delta$  /  $\nabla$  /  $\square$  to move  $\square$  in front of the first character of the disc title you want to search, then press SET.


To correct the incorrect entry, press  $\Delta$  /  $\nabla$  /  $\square$  to move  $\square$  in front of the correct character, then press SET.

Note:

Symbols such as  $\oplus$ ,  $\otimes$ , or  $\$$  cannot be available for search.

- Press SET again.

Disc search starts, then the SEARCH RESULT screen appears.



- On the SEARCH RESULT screen, you can do the following:

- Changing the indication of the disc information: Press  $\Delta$  /  $\nabla$  to move  $\square$  to a searched disc, then press  $\square$  /  $\square$ . Each time you press  $\square$  /  $\square$ , the disc information alternates between its disc title and its performer.

- Starting a disc play and going to the Disc Information screen (see page 40). Press  $\Delta$  /  $\nabla$  to move  $\square$  to a searched disc, then press SET.

- Showing unused disc information (if more than 5 discs are listed as a result of the search): Press  $\Delta$  /  $\nabla$  until they appear.

- Going back to the DISC TITLE SEARCH screen: Press EXIT.


### Search for a disc by its disc title:

- Press TEXT DISPLAY while "CD" is selected as the source.

The Disc Information screen appears on the TV.


- Press  $\Delta$  /  $\nabla$  to move  $\square$  to "SEARCH," then press SET.

The DISC SEARCH screen appears.



- Press  $\Delta$  /  $\nabla$  to move  $\square$  to "DISC TITLE," then press SET.

The DISC TITLE SEARCH screen appears.



- Press  $\Delta$  /  $\nabla$  /  $\square$  to move  $\square$  in front of the first character of the disc title you want to search, then press SET.

To correct the incorrect entry, press  $\Delta$  /  $\nabla$  /  $\square$  to move  $\square$  in front of the correct character, then press SET.

Note:

Symbols such as  $\oplus$ ,  $\otimes$ , or  $\$$  cannot be available for search.

- Press SET again.

Disc search starts, then the SEARCH RESULT screen appears.



- On the SEARCH RESULT screen, you can do the following:

- Changing the indication of the disc information: Press  $\Delta$  /  $\nabla$  to move  $\square$  to a searched disc, then press  $\square$  /  $\square$ . Each time you press  $\square$  /  $\square$ , the disc information alternates between its disc title and its performer.

- Starting a disc play and going to the Disc Information screen (see page 40). Press  $\Delta$  /  $\nabla$  to move  $\square$  to a searched disc, then press SET.

- Showing unused disc information (if more than 5 discs are listed as a result of the search): Press  $\Delta$  /  $\nabla$  until they appear.

- Going back to the DISC TITLE SEARCH screen: Press EXIT.

**Search for a disc by its genre:**

1. Press TEXT DISPLAY while "CD" is selected as the source.

The Disc Information screen appears on the TV.

2. Press  $\Delta$  /  $\nabla$  to move  $\square$  to "SEARCH," then press SET. The DISC SEARCH screen appears.

3. Press  $\Delta$  /  $\nabla$  to move  $\square$  to "GENRE," then press SET. The GENRE SEARCH screen appears.

4. Press  $\Delta$  /  $\nabla$  to move  $\square$  to the genre you want to search, then press SET.

To show the unseen genres, press  $\Delta$  /  $\nabla$  until they appear. Disc search starts, then the SEARCH RESULT screen shows the disc titles, steps 1 through 4.

5. On the SEARCH RESULT screen, you can do the following:

- Changing the indication of the disc information: Press  $\Delta$  /  $\nabla$  to move  $\square$  to a searched disc, then press  $\square$ . Each time you press  $\square$ , the disc information alternates between its disc title and its performer.

- Starting a disc play and going to the Disc Information screen (see page 40): Press  $\Delta$  /  $\nabla$  to move  $\square$  to a searched disc, then press SET.

- Showing unseen disc information (if more than 5 discs are listed as a result of the search): Press  $\Delta$  /  $\nabla$  until they appear.

- Going back to the GENRE SEARCH screen: Press EXIT.

**Entering the Disc Information****For the CD Player with the disc memory function:**

You can use the disc memory function through this receiver. The disc information (its performer, disc title, and music genre) of normal audio CDs will be stored into the memory built in the CD player.

For the disc memory function, refer to the manual supplied with your CD player.

- The performer, disc title, and music genre information are usually recorded in a CD Text. However, if a CD Text has no genre information recorded in the disc itself, you can input its music genre by yourself.

**Note:**

You can enter the TITLE INPUT screen for a CD Text and inputs disc titles. However, you cannot store the titles you have input for a CD Text.

**Example:** Entering the following information for Disc 1:  
Disc title: "MY FAVORITE"

1. Press TEXT DISPLAY while "CD" is selected as the source.

The Disc Information screen appears on the TV.

2. Press  $\Delta$  /  $\nabla$  to move  $\square$  to "TITLE INPUT," then press SET. The TITLE INPUT screen appears.



3. Press  $\Delta$  /  $\nabla$  /  $\lhd$  /  $\rhd$  to move  $\square$  in front of a character you want, then press SET to enter the character.

- If the current CD is a CD Text, go to step 5 without entering the performer.

- To use the lower case letters, press  $\Delta$  /  $\nabla$  /  $\lhd$  /  $\rhd$  to move  $\square$  to  $\text{[a-z]}$ , then press SET.

- To use the upper case letters again, press  $\Delta$  /  $\nabla$  /  $\lhd$  /  $\rhd$  to move  $\square$  to  $\text{[A-Z]}$ , then press SET.

- Press TEXT DISPLAY while "CD" is selected as the source.



4. Repeat step 3 until you finish putting a performer name (up to 32 characters).

To insert a space, press  $\Delta$  /  $\nabla$  /  $\lhd$  /  $\rhd$ , then press SET, then press SET.

To clear all the incorrect characters, then press SET.

5. Press  $\Delta$  /  $\nabla$  /  $\lhd$  /  $\rhd$  to move  $\square$  to the correct character, then press SET to enter the correct character.



6. Repeat step 3 until you finish putting a song title (up to 32 characters).

To insert a space, press  $\Delta$  /  $\nabla$  /  $\lhd$  /  $\rhd$ , then press SET.

To clear all the incorrect characters, then press SET.

7. Press  $\Delta$  /  $\nabla$  /  $\lhd$  /  $\rhd$  to move  $\square$  to "DISC 1: MICHAEL (in this example)," then press SET. The TITLE INPUT: DISC 1 screen appears.



8. Press  $\Delta$  /  $\nabla$  to move  $\square$  to the genre you want, then press SET. The Disc Information screen appears again.

To show the unseen genres, press  $\Delta$  /  $\nabla$  until they appear.

9. Press  $\Delta$  /  $\nabla$  /  $\lhd$  /  $\rhd$  to move  $\square$  to the disc title you have just entered, then press SET.

The disc title is stored into the memory, and the screen TITLE INPUT: DISC 1 screen appears.

10. Press  $\Delta$  /  $\nabla$  to move  $\square$  to the genre you want, then press SET. The Disc Information screen appears again.

To show the unseen genres, press  $\Delta$  /  $\nabla$  until they appear.

11. Press  $\Delta$  /  $\nabla$  /  $\lhd$  /  $\rhd$  to move  $\square$  to the song title you have just entered, then press SET.

The song title is stored into the memory, and the screen TITLE INPUT: DISC 1 screen appears again.

12. Press  $\Delta$  /  $\nabla$  /  $\lhd$  /  $\rhd$  to move  $\square$  to the song title you have just entered, then press SET.

The song title is stored into the memory, and the screen TITLE INPUT: DISC 1 screen appears again.

13. Enter the title, referring to steps 3 and 4 of "For the CD Player with the disc memory function" to the left.

• You can enter up to 32 characters for the disc title.

14. Press  $\Delta$  /  $\nabla$  /  $\lhd$  /  $\rhd$  to move  $\square$  to the disc title you have just entered, then press SET.

The disc title is stored into the memory, and the screen TITLE INPUT: DISC 1 screen appears.

15. Enter the song title, referring to steps 3 and 4 of "For the CD Player with the disc memory function" to the left.

• You can enter up to 32 characters for the song title.

16. Press  $\Delta$  /  $\nabla$  /  $\lhd$  /  $\rhd$  to move  $\square$  to the song title you have just entered, then press SET.

The song title is stored into the memory, and the screen TITLE INPUT: DISC 1 screen appears again.

**For the MD recorder:**

You can write the disc information (disc title and song titles) into the memory. You can only write the song title for the song currently selected.

• If you have the CD-MD combination deck, you can also enter the disc information (its performer, disc title, and its music genre) of normal audio CDs into the memory built in the CD-MD combination deck. (To do this, follow the procedure of "For the CD Player with the disc memory function" to the left.)

• If you change the disc or song title with more than 32 characters, the characters following 32nd will be erased from the title.

1. Press TEXT DISPLAY while "MD" is selected as the source. The Disc Information screen appears on the TV.

2. Press  $\Delta$  /  $\nabla$  to move  $\square$  to "TITLE INPUT," then press SET. The DISC-TITLE INPUT screen appears.



3. Enter the title, referring to steps 3 and 4 of "For the CD Player with the disc memory function" to the left.

• You can enter up to 32 characters for the disc title.

4. Press  $\Delta$  /  $\nabla$  /  $\lhd$  /  $\rhd$  to move  $\square$  to the disc title you have just entered, then press SET.

The disc title is stored into the memory, and the screen TITLE INPUT: DISC 1 screen appears.

5. Enter the song title, referring to steps 3 and 4 of "For the CD Player with the disc memory function" to the left.

• You can enter up to 32 characters for the song title.

6. Press  $\Delta$  /  $\nabla$  /  $\lhd$  /  $\rhd$  to move  $\square$  to the song title you have just entered, then press SET.

The song title is stored into the memory, and the screen TITLE INPUT: DISC 1 screen appears again.

7. Enter the title, referring to steps 3 and 4 of "For the CD Player with the disc memory function" to the left.

• You can enter up to 32 characters for the disc title.

8. Press  $\Delta$  /  $\nabla$  /  $\lhd$  /  $\rhd$  to move  $\square$  to the disc title you have just entered, then press SET.

The disc title is stored into the memory, and the screen TITLE INPUT: DISC 1 screen appears.

9. Enter the song title, referring to steps 3 and 4 of "For the CD Player with the disc memory function" to the left.

• You can enter up to 32 characters for the song title.

10. Press  $\Delta$  /  $\nabla$  /  $\lhd$  /  $\rhd$  to move  $\square$  to the song title you have just entered, then press SET.

The song title is stored into the memory, and the screen TITLE INPUT: DISC 1 screen appears again.

11. Enter the title, referring to steps 3 and 4 of "For the CD Player with the disc memory function" to the left.

• You can enter up to 32 characters for the disc title.

12. Press  $\Delta$  /  $\nabla$  /  $\lhd$  /  $\rhd$  to move  $\square$  to the disc title you have just entered, then press SET.

The disc title is stored into the memory, and the screen TITLE INPUT: DISC 1 screen appears.

13. Enter the song title, referring to steps 3 and 4 of "For the CD Player with the disc memory function" to the left.

• You can enter up to 32 characters for the song title.



14. Press  $\Delta$  /  $\nabla$  /  $\lhd$  /  $\rhd$  to move  $\square$  to the song title you have just entered, then press SET.

The song title is stored into the memory, and the screen TITLE INPUT: DISC 1 screen appears again.

**AV COMPULINK Remote Control System****AV COMPULINK Remote Control System**

The AV COMPULINK remote control system allows you to operate JVC video components (TV, VCR, and DVD player) through one receiver.

To use this remote control system, you need to connect the video components you want to operate, following the diagrams below and the procedure on the next page.

**CONNECTIONS 1:****CONNECTIONS 2:**

1. If you have already plugged your VCR 1 (VCR), DVD player, and TV connected to the VCR 1 jacks), then plug the VCR 1, DVD player, and TV into the AC outlets, unplug their AC power cords first.

2. Connect your VCR 1, DVD player, TV, and this receiver as follows, using the cables with the monaural mini-plug (not supplied):

- See "CONNECTIONS 1" on the previous page.

3. Connect the audio input/output jacks on VCR 1, DVD player, TV, and this receiver using the cables with RCA phono plug or S-video plug.

- See "CONNECTIONS 2" on the previous page.

4. Connect the video input/output jacks on VCR 1, DVD player, TV, and this receiver, using the cables with the RCA pin plug or with S-video plug.

- See "CONNECTIONS 2" on the previous page.

5. Plug the AC power cords of the components into the AC outlets.

6. When turning on the TV for the first time after the AV COMPULINK connection, turn the TV volume to the minimum using the TV volume control on the TV.

7. Turn on the other connected components first, then turn on this receiver.

- When turning on VCR 1, set the remote control switch to "VCR 1".

The AV COMPULINK remote control system allows you to use the five basic functions listed below.

**Remote Control of the TV, DVD player, and VCR 1**

The TV, VCR 1, and DVD player are controlled by this receiver.

- You can directly control the TV, VCR 1, and DVD player.

• If you previously selected source as "VIDEO1" ("CON/VIDEO2"), "TV SOUND1" ("TV DIGITAL1") or "TV SOUND2" ("TV DIGITAL2"), the TV automatically turns on and changes the input mode to the position you last used before turning off the TV input mode.

• If the previously selected source is "DVD" ("DVD DIGITAL1") or "DVD MULTI", the TV and DVD player will automatically turn on.

• When you turn off the receiver, the TV, VCR 1 and the DVD player will turn off.

**Note:**

If you turn off the receiver while recording on the VCR 1, the VCR 1 will not turn off but continue recording.

**One-Touch Video Play**

Simply by inserting a video cassette with an ordinary image into VCR 1 or VCR 1 jacks, then you can enjoy the video play back with settings set automatically.

The receiver automatically turns on and changes the input mode to the position you last used before turning off the play picture.

When you insert a video cassette with a video tape, press its play button on the VCR 1 or on the receiver control, the play picture begins.

When you insert a video cassette with an ordinary image, the play picture begins.

**One-Touch DVD Play**

Simply by starting playback on the DVD player, you can enjoy the playback without setting up manually.

• When the DVD player is connected through the analog input jacks, the receiver automatically turns on and changes the source to "DVD" ("DVD MULTI").

• When the DVD player is connected through the digital input jacks or digital input as source to the receiver, the receiver automatically turns on and changes the source to "DVD DIGITAL".

The TV automatically turns on and changes the input mode to the position that you last used before turning off the play picture.

When you insert a video cassette with a video tape, press its play button on the VCR 1 or on the receiver control, the play picture begins.

When you insert a video cassette with an ordinary image, the play picture begins.


## Operating JVC's Audio/Video Components

You can operate JVC's audio and video components with this receiver's remote control, since control signals for JVC components are preset in the remote control.

### Operating Audio Components

#### IMPORTANT:

- To operate JVC's audio components using this remote control:  
• You need to connect JVC audio components through the COMPU-LINK jacks (see page 39) in addition to the connections using cables with RCA pin plugs (see pages 5 and 7).
- Aim the remote control directly at the remote sensor on the receiver.
- If you use the buttons on the front panel or the menu function to control the component, the remote control that you use to operate a source with the remote control, the source must be selected using source selection buttons on the remote control.
- To operate the cassette deck or MD recorder using the COMPU-LINK remote control system, set the source name correctly. (See page 13.)
- Refer also to the manuals supplied with your components.



#### Turner

You can always perform the following operations (with the remote control mode selector set to "AUDIO/TV/VCR").

**FM/AM:** Alternates between FM and AM.

After pressing FM/AM (with the remote control mode selector set to "AUDIO/TV/VCR"), you can perform the following operations:

- 1 - 10, +10: Selects a preset channel number directly.  
For channel number 5, press 5.  
For channel number 15, press +10, then 5.  
For channel number 20, press +10, then 10.

**TUNING UP/TUNING DOWN:** Tunes into stations.

**FM MODE:** Changes the FM reception mode.

#### Sound control section (Amplifier)

You can always perform the following operations (with the remote control mode selector set to "AUDIO/TV/VCR").

**SURROUND ON/OFF:** Turns on or off the surround modes— Dolby Pro Logic, Dolby Digital, and DTS Digital Surround.

**SURROUND MODE:** Selects the DSP modes.

After pressing SOUND (with the remote control mode selector set to "AUDIO/TV/VCR"), you can perform the following operations:

**SEA MODE:** Changes the SEA modes.

**SUBWOOFER** / - / +: Adjusts the subwoofer output level.

**CENTER** / - / +: Adjusts the center speaker output level.

**REAR L** / - / +: Adjusts the left rear speaker output level.

**REAR R** / - / +: Adjusts the right rear speaker output level.

**EFFECT:** Selects the effect level.

**TEST:** Turns on or off the test tone output.

**CNT/TONE:** Selects the center tone.

#### Note:

After adjusting sounds, press the corresponding source selecting button or CD-DISC to operate your target source by using the 10 keys; otherwise, the 10 keys cannot be used for operating your target source.

#### CD player

After pressing CD (with the remote control mode selector set to "AUDIO/TV/VCR"), you can perform the following operations on the CD player:

**PLAY:** Starts playing.

**■■■:** Returns to the beginning of the current (or previous) track.

**■■■:** Skips to the beginning of the next track.

**STOP:** Stops playing.

**PAUSE:** Pauses playing. To release it, press PLAY.

- 1 - 10, +10: Selects a track number directly.  
For track number 5, press 5.  
For track number 15, press +10, then 5.  
For track number 20, press +10, then 10.  
For track number 30, press +10, +10, then 10.

#### Note:

When you start recording on the CD recorder, use the buttons on the CD recorder itself or on the remote control supplied with it.

#### CD player-changer

After pressing CD-DISC (with the remote control mode selector set to "AUDIO/TV/VCR"), you can perform the following operations on a CD player-changer:

**PLAY:** Starts playing.

**■■■:** Returns to the beginning of the current (or previous) track.

**■■■:** Skips to the beginning of the next track.

**STOP:** Stops playing.

**PAUSE:** Pauses playing. To release it, press PLAY.

- 1 - 6, 7/P: Selects the number of a disc installed in a CD player-changer.

After pressing CD (with the remote control mode selector set to "AUDIO/TV/VCR"), you can perform the following operations on the CD player-changer:

- 1 - 10, +10: Selects a track number directly.

For track number 5, press 5.

For track number 15, press +10, then 5.

For track number 20, press +10, then 10.

For track number 30, press +10, +10, then 10.

If your CD changer is of 200-disc loading capability (except for XL-MC100 and XL-MC301), you can do the following operations using the number buttons after pressing CD:

1. Select a disc number.

2. Then select a track number (always enter two digits).

3. Start playback.

**EXAMPLES:**

• Selecting disc number 3, track number 2, and starting playback: Press 3, then 0, 2, then ▶.

• Selecting disc number 10, track number 3, and starting playback: Press 1, 0, then 0, 3, then ▶.

• Selecting disc number 100, track number 12, and starting playback: Press 1, 0, 0, then 1, 2 then ▶.

#### CD recorder

After pressing CDR/VCR 2 (with the remote control mode selector set to "AUDIO/TV/VCR"), you can perform the following operations on a CD recorder:

**PLAY:** Starts playing.

**■■■:** Returns to the beginning of the current (or previous) track.

**■■■:** Skips to the beginning of the next track.

**STOP:** Stops playing.

**PAUSE:** Pauses playing. To release it, press PLAY.

- 1 - 10, +10: Selects a track number directly.  
For track number 5, press 5.  
For track number 15, press +10, then 5.  
For track number 20, press +10, then 10.  
For track number 30, press +10, +10, then 10.

#### Note:

When you start recording on the CD recorder, use the buttons on the CD recorder itself or on the remote control supplied with it.

#### Turntable

After pressing PHONO (with the remote control mode selector set to "AUDIO/TV/VCR"), you can perform the following operations on a turntable:

**PLAY:** Starts playing.

**STOP:** Stops operations.

#### Cassette deck

After pressing TAPE/MD or TAPE/MD CONTROL (with the remote control mode selector set to "AUDIO/TV/VCR"), you can perform the following operations on a cassette deck:

**PLAY:** Starts playing.

**■■■:** Fast winds the tape from right to left.

**■■■:** Fast winds the tape from left to right.

**STOP:** Stops operations.

**PAUSE:** Pauses playing. To release it, press PLAY.

**REC:** Starts recording. Press this button with the PLAY button to start recording.

Press this button with the PAUSE button to enter recording pause.

#### MD recorder

After pressing TAPE/MD or TAPE/MD CONTROL (with the remote control mode selector set to "AUDIO/TV/VCR"), you can perform the following operations on the MD recorder:

**PLAY:** Starts playing.

**■■■:** Returns to the beginning of the current (or previous) track.

**■■■:** Steps to the beginning of the next track.

**STOP:** Stops playing.

**PAUSE:** Pauses playing. To release it, press PLAY.

- 1 - 10, +10: Selects a disc number.

For track number 5, press 5.

For track number 15, press +10, then 5.

For track number 20, press +10, then 10.

For track number 30, press +10, +10, then 10.

**Note:**


You can use either TAPE/MD or TAPE/MD CONTROL button to activate the buttons listed above. If you press TAPE/MD, the playing source also changes. On the other hand, if you press TAPE/MD CONTROL, the playing source does not change.

## Operating Other Manufacturers' Video Equipment

### Operating Video Components

#### IMPORTANT:

- To operate JVC's video components using this remote control:  
• You need to connect JVC video components through the AV COMPULINK terminals (see page 44) in addition to the connections using cables with RCA pin plugs (see pages 5 and 7).  
• Some JVC VCRs can accept two types of the control signals—remote code "A" and "B". Before using this remote control, make sure that the remote control code of the VCR connected to the VCR 1 jacks is set to code "A".
- When using the remote control:  
• For the DVD player and VCR operations, aim the remote control directly at the remote sensor on each component, not on the receiver.  
• For the TV operations:  
■ If the TV has the AV COMPULINK terminal "RECEIVER", aim the remote control directly at the remote sensor on the receiver.  
■ If the TV has the AV COMPULINK terminal "AV COMPULINK EX", aim the remote control directly at the remote sensor on the TV.



#### VCR 1 (JCR connected to the VCR 1 jacks)

You can always perform the following operations (with the remote control mode selector set to "AUDIO/TV/VCR").

**VCR 1 POWER:** Turns on or off the VCR 1.

After pressing VCR 1 POWER (with the remote control mode selector set to "AUDIO/TV/VCR"), you can perform the following operations:

**1 - 9, 0:** Selects the TV channels on VCR 1.

**PLAY:** Starts playing.

**■■■:** Rewinds a tape.

**■■■:** Fast winds a tape.

**STOP:** Stops operations.

**PAUSE:** Pauses playing. To release it, press PLAY.

**REC:** Starts recording. Press this button with the PAUSE button to start recording.

Press this button with the PAUSE button to enter recording pause.

**CHANNEL +/-:** Changes the TV channels on the VCR.

**Note:**  
You can use either VCR 1 button or the VCR 1 CONTROL button to activate the buttons listed above. If you press VCR 1, the playing source also changes. On the other hand, if you press VCR 1 CONTROL, the playing source does not change.

#### DVD player

After pressing DVD or DVD MULTI (with the remote control mode selector set to "AUDIO/TV/VCR"), you can perform the following operations on a DVD player:

**PLAY:** Starts playing.

**■■■:** Returns to the beginning of the current (or previous) track.

**■■■:** Skips to the beginning of the next track.

**STOP:** Stops playing.

**PAUSE:** Pauses playing temporarily. To release it, press PLAY.

**AFTER PRESSING DVD OR DVD MULTI:** These buttons can be used for DVD menu operations:

For detailed menu operations, refer to the instructions supplied with the discs or the DVD player.

**Note:**  
Check to see if the remote control mode selector is set to the correct position.  
To operate the audio system, TVs, VCRs, and DVD players, set it to "AUDIO/TV/VCR".

**To operate the CATV converter and DBS tuner, set it to "CATV/DBS".**

**TV POWER:** Turns on or off the TV.

**TV VOL +/-:** Adjusts the volume.

**TV/VIDEO:** Sets the input mode (either TV or VIDEO).

**After pressing TV/VIDEO (with the remote control mode selector set to "AUDIO/TV/VCR"), you can perform the following operations:**

**1 - 10, 0, 100, +10:** Selects the channels.

**CHANNEL +/-:** Changes the channels.

**1 - 9, 0, 100, +10:** Selects the channels.

**RETURN:** Alternates between the previously selected channel and the current channel.

**Note:**  
Check to see if the remote control mode selector is set to the correct position.  
To operate the audio system, TVs, VCRs, and DVD players, set it to "AUDIO/TV/VCR".

**To operate your TV by pressing TV POWER.**

When your TV turns over off, you have entered the correct code.

If there are more than one code listed for your brand of TV, try each one until the correct one is entered.

To change the transmittable signals for operating another manufacturer's TV

1. Set the remote control mode to "AUDIO/TV/VCR".
2. Press and hold TV POWER.
3. Press TV/DBS.

The following buttons can be used for operating the TV (with the remote control mode selector set to "AUDIO/TV/VCR"):

**TV POWER:** Turns on and off the TV.

**TV VOL +/-:** Adjusts the volume.

**TV/VIDEO:** Sets the input mode (either TV or VIDEO).

After pressing TV/DBS (with the remote control mode selector set to "AUDIO/TV/VCR"), you can perform the following operations:

**CHANNEL +/-:** Changes the channels.

**1 - 10, 0, 100, +10:** Selects the channels.

The 100 (+10) button will function as the ENTER button if your TV requires pressing ENTER after selecting a channel number.

**Note:**

Refer to the manual supplied with your TV.

6. Try to operate your TV by pressing TV POWER.

When your TV turns over off, you have entered the correct code.

If there are more than one code listed for your brand of TV, try each one until the correct one is entered.

Manufacturer	Code	Manufacturer	Code
JVC	01	SAMSUNG	12
HYACHI	10	SANYO	13
MAGNAVOX	02	SHARP	06
MITSUBISHI	03	SONY	07
PANASONIC	04, 11	TOSHIBA	08
RCA	05	ZENITH	09

Manufacturers' codes are subject to change without notice. If they are changed, this remote control cannot operate the equipment.

**To change the transmittable signals for operating a CATV converter**

- Set the remote control mode to "CATV/DBS."
- Press and hold CATV/DBS POWER.
- Press TV/DBS.
- Enter manufacturer's code (two digits) using buttons 1-9, and 0.  
See the list below to find the code.  
Example: For an RCA product, press 1, 9.  
For a SONY product, press 2, 0.
- Release CATV/DBS POWER.**

After setting the remote control mode selector to "CATV/DBS," you can perform the following operations on the CATV converter:

**CATV/DBS POWER** Turns on and off the CATV converter.  
CHANNEL +/- Changes the channels.  
1 - 10, 0, 100+ (+10) Selects the channel.  
The 100+ (+10) button will function as the ENTER button if your equipment requires pressing ENTER after selecting a channel number.

**Notes:**

- Refer to the manual supplied with your CATV converter.
- You cannot set the remote control mode selector both for the CATV converter and the DBS tuner at the same time.

**6. Try to operate your CATV converter by pressing CATV/DBS POWER.**

When your CATV converter turns on or off, you have entered the correct code.

If there are more than one code listed for your brand of CATV converter, try each one until the correct one is entered.

Manufacturer	Codes
GI JERRLD	01, 02, 03, 04, 05, 06, 07, 08
HAMLIN/REGAL	15, 16, 17, 18
PIONEER	13, 14
RCA	19
SCIENTIFIC ATLANTA	09, 10
SONY	20
ZENITH	11, 12

Manufacturers' codes are subject to change without notice. If they are changed, this remote control cannot operate the equipment.

**To change the transmittable signals for operating a DBS tuner**

- Set the remote control mode to "CATV/DBS."
- Press and hold CATV/DBS POWER.
- Press TV/DBS.
- Enter manufacturer's code (two digits) using buttons 1-9, and 0.  
See the list below to find the code.  
Example: For a JVC product, press 2, 1.  
For an RCA product, press 2, 5.
- Release CATV/DBS POWER.**

After setting the remote control mode selector to "CATV/DBS," you can perform the following operations on the DBS tuner:

**CATV/DBS POWER** Turns on and off the DBS tuner.  
CHANNEL +/- Changes the channels.  
1 - 10, 0, 100+ (+10) Selects the channel.  
The 100+ (+10) button will function as the ENTER button if your equipment requires pressing ENTER after selecting a channel number.

**Notes:**

- Refer to the manual supplied with your DBS tuner.
- You cannot set the remote control mode selector both for the CATV converter and the DBS tuner at the same time.

**6. Try to operate your DBS tuner by pressing CATV/DBS POWER.**

When your DBS tuner turns on or off, you have entered the correct code.

If there are more than one code listed for your brand of DBS tuner, try each one until the correct one is entered.

Manufacturer	Codes
JVC	21
ECHOSTAR	22
GI	23
HITACHI	24
HTS	25
HUGHES	26
NETWORK SYSTEMS	27
PANASONIC	27
PRIME STAR	28
RCA	29, 30
SONY	31
TOSHIBA	32

Manufacturers' codes are subject to change without notice. If they are changed, this remote control cannot operate the equipment.

**To change the transmittable signals for operating another manufacturer's VCR**

- Set the remote control mode to "AUDIO/TV/VCR."
- Press and hold VCR 1 POWER.
- Press VCR 1.
- Enter manufacturer's code (two digits) using buttons 1-9, and 0.  
See the list below to find the code.  
Example: For a JVC product, press 0, 1.  
For an RCA product, press 2, 5.
- Release VCR 1 POWER.**

The following button can be used for operating the VCR (with the remote control mode selector set to "AUDIO/TV/VCR"):

**VCR 1 POWER** Turns on and off the VCR.  
**CHANNEL +/-** Changes the channels.  
1 - 10, 0, 100+ (+10) Selects the channel.  
The 100+ (+10) button will function as the ENTER button if your equipment requires pressing ENTER after selecting a channel number.

**Notes:**

- Refer to the manual supplied with your VCR.
- You cannot set the remote control mode selector both for the CATV converter and the DBS tuner at the same time.

**6. Try to operate your VCR by pressing CATV/DBS POWER.**

When your VCR turns on or off, you have entered the correct code.

If there are more than one code listed for your brand of VCR, try each one until the correct one is entered.

Manufacturer	Codes	Manufacturer	Codes
JVC	01, 02, 03, 04, 05, 06, 07, 08	PHILIPS	09
EMERSON	11, 26	PANASONIC	05, 06
FISHER	29	SAMSUNG	24
FUNAI	10, 14, 15, 16	SANYO	21, 22, 23
GOLD STAR	12	SHARP	27, 28
HITACHI	04	SHINTOM	30
MITSUBISHI	13	SONY	18, 19, 20
NEC	25	ZENITH	08
PANASONIC	07, 17		

Manufacturers' codes are subject to change without notice. If they are changed, this remote control cannot operate the equipment.

**To change the transmittable signals for operating a DVD player**

- Set the remote control mode to "AUDIO/TV/VCR."
- Press and hold VCR 1 POWER.
- Press DVD.
- Enter manufacturer's code (two digits) using buttons 1-9, and 0.  
See the list below to find the code.  
Example: For a JVC product, press 0, 1.  
For an RCA product, press 2, 5.
- Release VCR 1 POWER.**

The following button can be used for operating the DVD (with the remote control mode selector set to "AUDIO/TV/VCR"):

**PLAY** Starts playing.  
**PREVIOUS** Returns to the beginning of the current (or previous) track.  
**NEXT** Skips to the beginning of the next track.  
**STOP** Stops playing.  
**PAUSE** Pauses playing temporarily. To release it, PRESS PLAY.

After pressing DVD, these buttons  
can be used for the DVD menu  
operations.

**Note:**  
Refer to the manual supplied with your DVD player.

**6. Try to operate your DVD player by pressing one of the above buttons.**

DO NOT forget to turn on the DVD player before pressing one of the above buttons.

Manufacturer	Codes
JVC	01
PANASONIC	02
PHILIPS	07
PIONEER	03
SONY	05
TOSHIBA	04
YAMAHA	06

Manufacturers' codes are subject to change without notice. If they are changed, this remote control cannot operate the equipment.

**Troubleshooting**

Use this chart to help you solve daily operational problems. If there is any problem you cannot solve, contact your JVC service center.

PROBLEM	POSSIBLE CAUSE	SOLUTION
The display does not light up.	The power cord is not plugged in.	Plug the power cord into an AC outlet.
No sound from speakers.	Speaker signal cables are not connected.	Check speaker wiring and reconnect if necessary.
The SPEAKERS 1 and 2 buttons are not set correctly.	Press SPEAKERS 1 and 2 correctly.	
An incorrect source is selected.	Select the correct source.	
Muting is activated.	Press MUTING to cancel the mute.	
Sound from one speaker only.	Speaker signal cables are not connected properly.	Check speaker wiring and reconnect if necessary.
The balance is set to one extreme.	The volume is set to one extreme.	Adjust the balance properly (see page 33).
Continuous hiss or buzzing during FM reception.	Interfering signal is too weak.	Connect an outdoor FM antenna or connect your dealer.
The station is too far away.	Select a new station.	
An incorrect antenna is used.	Check with your dealer to see if you have the correct antenna.	
Antennas are not connected properly.	Check connections.	
Occasional crackling noise during FM reception.	Ignition noise from automobiles.	Move the antenna further from automobile traffic.
No colors on the on-access display.	The color system of the connected TV is not NTSC.	Connect an NTSC TV.
Howling during record playing.	Your turntable is too close to speakers.	Move speakers away from the turntable.
"OVERLOAD" starts flashing on the display.	Speakers are overloaded because of high volume.	1. Press POWER on the front panel to turn off the receiver. 2. Stop the playback source. 3. Turn on the receiver again, and adjust the volume.
Speakers are overloaded because of short circuits of speaker terminals.	Press POWER on the front panel, then check the speaker wiring. If "OVERLOAD" does not disappear, unplug the AC power cord, then plug it back again. If speaker wiring is not short-circuited, contact your dealer.	
Remote control does not work.	The remote control mode selector is not set correctly.	Set the selector correctly (either to "AUDIO/TV/VCR" or to "CATV/DBS").
	There is an obstruction in front of the remote sensor on the receiver.	Remove the obstruction.
	Batteries are weak.	Replace batteries.

**Specifications****Amplifier****Output Power**

At Stereo operation:  
Front channels: 120 W per channel, min. RMS, driven into 8 Ω, 20 Hz to 20 kHz with no more than 0.02% total harmonic distortion.

At Surround operation:  
Front channels: 100 W per channel, min. RMS, driven into 8 Ω at 1 kHz, with no more than 0.05% total harmonic distortion.

Center channel: 100 W, min. RMS, driven into 8 Ω at 1 kHz, with no more than 0.05% total harmonic distortion.

Rear channels: 100 W per channel, min. RMS, driven into 8 Ω at 1 kHz, with no more than 0.05% total harmonic distortion.

**Audio**

Radio Input Sensitivity/Toneband (1 kHz): PHONO (MM): 2.5 mV/47 kHz  
CD, TAPE/MD, TV SOUND/DBS, VCR 1, CDR/VCR 2, VIDEO, DVD: 200 mV/47 kHz

Audio Input (DIGITAL IN): Coaxial: DIGITAL 1 (DVD): 0.3 Vp-p/97.5 Q  
Optical: DIGITAL 2 (CD), DIGITAL 3 (TV), DIGITAL 4 (CDR): -21 dBm to -3 dBm (660 nm ±30 nm)

\*Corresponding to Linear PCM, Dolby Digital, and DTS Digital Surround (with sampling frequency = 32 kHz, 44.1 kHz, 48 kHz).

Audio Output Level: TAPE/MD, VCR 1, CDR/VCR 2: 200 mV

Digital output: Optical: DIGITAL OUTPUT  
Signal wave length: 660 nm  
Output level: -21 dBm to +1.5 dBm

Signaled-to-Noise Ratio (IHF78 (HP)): PHONO: 70 dB/78 dB (at REC OUT)  
CD, TAPE/MD, TV SOUND/DBS, VCR 1, CDR/VCR 2, VIDEO, DVD: 92 dB/90 dB

Frequency Response (8 Ω): PHONO: 20 Hz to 20 kHz (+1 dB)

CD, TAPE/MD, TV SOUND/DBS, VCR 1, CDR/VCR 2, VIDEO, DVD: 20 Hz to 100 kHz (+1 dB, -3 dB)

RIAA Phono Equivalents: ±1.0 dB (20 Hz to 20 kHz)

Base boost: +6 ±1.0 dB at 100 Hz (Volume control at -30 dB)

SEI: Center frequencies: 100 Hz, 1 kHz, 10 kHz  
Control range: ±10 dB ±2 dB

**Video**

Video Input Sensitivity/Toneband:  
Composite video: TV SOUND/DBS, VCR 1, CDR/VCR 2, VIDEO, DVD: 1 V(p-p)/75 Ω

S-video: TV SOUND/DBS, VCR 1, VIDEO, DVD: 1 V(p-p)/75 Ω

(C: chrominance, baset): 0.286 V(p-p)/75 Ω

Video Output Level:  
Composite video: VCR 1, CDR/VCR 2, MONITOR OUT:  
S-video: VCR 1, MONITOR OUT: 1 V(p-p)/75 Ω

(C: chrominance, baset): 0.286 V(p-p)/75 Ω

Synchronization: Negative

Signal-to-Noise Ratio: 45 dB

On-Screen Color System: NTSC

**FM tuner (MEI)**

Tuning Range: 87.5 MHz to 108.0 MHz  
 Usable Sensitivity: Monoaural: 12.8 dBf (1.2 µV/75 Ω)  
 50 dB Quoting Sensitivity: Monoaural: 21.3 dBf (3.2 µV/75 Ω)  
 Stereo: 41.3 dBf (31.5 µV/75 Ω)  
 Signal-to-Noise Ratio (THF-A weighted): Monoaural: 78 dB at 85 dB  
 Stereo: 75 dB at 85 dB  
 Total Harmonic Distortion: Monoaural: 0.4% at 1 kHz  
 Stereo: 0.6% at 1 kHz  
 Stereo Separation at REC OUT: 35 dB at 1 kHz  
 Alternate Channel Selectivity: 45 dB: (±400 kHz)  
 Frequency Response: 30 Hz to 15 kHz (+0.5 dB, -3 dB)

**AM tuner**

Tuning Range: 530 kHz to 1,710 kHz  
 Usable Sensitivity: Loop antenna 400 µV/m  
 Signal-to-Noise Ratio: 50 dB (100 mV/m)

**General**

Power Requirements: AC 120V<sup>1</sup>; 60 Hz  
 Power Consumption: 320 watts/420 VA (at operation)  
 2 watts (in standby mode)  
 Dimensions (W x H x D): 435 mm x 157 mm x 412.5 mm  
 (17 1/2 in. x 6 1/8 in. x 16 1/4 in.)  
 Max.: 13.9 kg (26.3 lbs)

Designs & specifications are subject to change without notice.

QUALITY **JVC** SERVICE

**HOW TO LOCATE YOUR JVC SERVICE CENTER**

TOLL FREE : 1-800-537-6722

<http://www.jvcservice.com>

**Dear customer:**

In order to receive the most satisfaction from your purchase, read the instruction booklet before operating the unit. In the event that repair is necessary, or for the address nearest your location, please refer to the factory service center list below or within the Continental United States, Call 1-800-537-6722 for your authorized servicer. Remember to retain your Bill of Sale for Warranty Service.

-JVC

**JVC SERVICE & ENGINEERING COMPANY OF AMERICA**

DIVISION OF JVC AMERICAS CORP.

**FACTORY SERVICE CENTER LOCATIONS**

10 New Maple Avenue  
 Pine Brook, NJ 07058-9641  
 (973) 386-1000

1500 Lakes Parkway  
 Lawrenceville, GA 30243-5657  
 (770) 339-2582

705 Enterprise Street  
 Aurora, IL 60504-8149  
 (830) 851-7855

5665 Corporate Avenue  
 Cypress, CA 90630-0024  
 (714) 229-8011

2869 Mapunapuna Place  
 Honolulu, HI 96819-2040  
 (808) 833-5828

10700 Hammetry, Suite 110  
 Houston, TX 77043  
 (713) 935-0331

13 Cummings Park  
 Woburn, MA 01801  
 (781) 375-9100

8192 State Road B4  
 Davie, FL 33324  
 (954) 472-1960

890 Dubuque Avenue  
 South San Francisco, CA 94080-1804  
 (650) 871-2566

Sophisticated electronic products may require occasional service. Just as quality is a keyword in the engineering and production of the wide array of JVC products, service is the key to maintaining the high level of performance for which JVC is world famous. The JVC service and engineering organization stands behind our products.

NATIONAL HEADQUARTERS  
**JVC SERVICE & ENGINEERING COMPANY OF AMERICA**  
 DIVISION OF JVC AMERICAS CORP.  
 1700 Valley Road  
 Wayne, NJ 07470

**If you ship the product \*\*\***

Pack your JVC unit in the original carton or one of equivalent size and strength. Enclose, with the unit, a letter stating the problem or symptom that caused you to return the unit, and also a copy of the receipt showing the date received when you purchased your JVC unit. Print your home return address on the outside and the inside of the carton. Send to the appropriate JVC Factory Service Center as listed above.

**Don't service it yourself.**

**CAUTION**  
 To prevent electrical shock, do not open the cabinet. No user serviceable parts inside.  
 Refer servicing to qualified service personnel.

**ACCESSORIES**

To purchase accessories for your JVC product, you may contact your local JVC Dealer.

Or from the 48 Continental United States call toll free : 800-882-2345

**JVC LIMITED WARRANTY AUDIO-2**

JVC COMPANY OF AMERICA warrants this product and all parts thereof, except as set forth below ONLY TO THE ORIGINAL PURCHASER AT RETAIL, to be FREE FROM DEFECTIVE MATERIAL AND WORKMANSHIP from the date of original retail purchase for the period as shown below. (\*The Warranty Period)

PARTS	2YR	LABOR	2YR
-------	-----	-------	-----

THIS LIMITED WARRANTY IS VALID ONLY IN THE FIFTY (50) UNITED STATES, THE DISTRICT OF COLUMBIA AND IN COMMONWEALTH OF PUERTO RICO.

**WHAT WE WILL DO:**

If this product is found to be defective, JVC will repair or replace defective parts at no charge to the original owner. Such repair or replacement services shall be rendered by JVC during normal business hours at JVC authorized service centers. Parts used for replacement are warranted only for the remainder of the Warranty Period. All products and parts thereof may be brought to a JVC authorized service center on a carry-in basis except for television sets having a screen size 25 inches and above which are covered on an in-home basis.

**WHAT YOU MUST DO FOR WARRANTY SERVICE:**

Return your product to a JVC authorized service center with a copy of your bill of sale. For your nearest JVC authorized service center, please call toll free: (800) 537-6722. It is your responsibility to pack the unit carefully, preferably in the original carton, and ship, insured, with a copy of your bill of sale plus a letter of explanation of the problem to the nearest JVC Factory Service Center, the name and location of which will be given to you by the toll-free number.

If you have any questions concerning your JVC Product, please contact our Customer Relations Department.

**WHAT IS NOT COVERED:**

This limited warranty is provided by JVC does not cover:

1. Damage which results from accident, abuse, misuse, faulty installation, lack of reasonable care, or if repaired or serviced by anyone other than a service facility authorized by JVC to render such service, or if affixed to any attachment not provided with the products, or if the model number or serial number has been altered, tampered with, defaced or removed;

2. Initial installation and installation and removal for repair;

3. Operational adjustments covered in the Owner's Manual, normal maintenance, video and audio head cleaning;

4. Damage that occurs in shipment, due to act of God, and cosmetic damage;

5. Signal reception problems and failures due to line power surge;

6. Video Pickup Tubes/CCD Image Sensor, Cartridge, Styloskop (Neonlite) are covered for 60 days from the date of purchase;

7. Accessories;

8. Batteries (except the Rechargeable Batteries are covered for 90 days from the date of purchase);

There are no express warranties except as listed above.

THE DURATION OF ANY IMPLIED WARRANTIES, INCLUDING THE IMPLIED WARRANTY OF MERCHANTABILITY, IS LIMITED TO THE DURATION OF THE EXPRESS WARRANTY HEREIN.

JVC SHALL NOT BE LIABLE FOR THE LOSS OF USE OF THE PRODUCT, INCONVENIENCE, LOSS OR ANY OTHER DAMAGES, WHETHER DIRECT, INCIDENTAL OR CONSEQUENTIAL (INCLUDING, WITHOUT LIMITATION, DAMAGE TO TAPES, RECORDS OR MATERIALS) RESULTING FROM THE USE OF THIS PRODUCT, OR ARISING OUT OF A BREACH OF THIS WARRANTY. EXCEPT AS PROVIDED ABOVE, NO PERSON IS AUTHORIZED TO ASSUME FOR JVC ANY LIABILITY OR RESPONSIBILITY FOR PARTICULAR PURPOSE, ARE LIMITED TO THE WARRANTY PERIOD SET FORTH ABOVE.

Some states do not allow the exclusion of incidental or consequential damages or limitations on how long an implied warranty lasts, so these limitations or exclusions may not apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

JVC COMPANY OF AMERICA  
 DIVISION OF JVC AMERICAS CORP.

1700 Valley Road  
 Wayne, NJ 07470

REFURBISHED PRODUCTS CARRY A SEPARATE WARRANTY. THIS WARRANTY DOES NOT APPLY. FOR DETAILS OF REFURBISHED PRODUCT WARRANTY, PLEASE REFER TO THE REFURBISHED PRODUCT WARRANTY INFORMATION PACKAGED WITH EACH REFURBISHED PRODUCT.

**For customer use:**

Please enter below the Model No. and Serial No. which is located either on the rear, bottom or side of the cabinet. Retain this information for future reference.

Model No.:  Serial No.:

Purchase date:  Name of dealer:

RX-8000VBK

**-MEMO-**

## Disassembly method

### ■ Removing the top cover (See Fig.1)

1. Remove the four screws A attaching the top cover on both sides of the body.
2. Remove the three screws B on the back of the body.
3. Remove the top cover from behind in the direction of the arrow while pulling both sides outward.




Fig.1

### ■ Removing the front panel assembly (See Fig.2 and 3)

- Prior to performing the following procedure, remove the top cover.
1. Disconnect the card wire from connector CN400 on the main board and CN402 on the power supply board in the front panel assembly.
  2. Cut off the tie band fixing the harness.
  3. Disconnect the harness from connector CN416 on the V-audio board, CN202 and CN206 on the video board and CN244 on the S-video board respectively.
  4. Remove the three screws C attaching the front panel assembly.
  5. Remove the five screws D attaching the front panel assembly on the bottom of the body. Detach the front panel assembly toward the front.




Fig.2

### ■ Removing the rear panel (See Fig.4)

- Prior to performing the following procedure, remove the top cover.
1. Remove the power cord stopper from the rear panel by moving it in the direction of the arrow.
  2. Remove the twenty-eight screws E attaching the each boards to the rear panel on the back of the body.
  3. Remove the three screws F attaching the rear panel on the back of the body.




Fig.3




Fig.4

**■ Removing each board connected to the rear side of the main board  
(See Fig.5 to 9)**

- Prior to performing the following procedure, remove the top cover and the rear panel.

- Cut off the tie band fixing the harness.
- Disconnect the harness from connector CN416 on the V-audio board, CN202 and CN206 on the video board and CN244 on the S-video board respectively.
- Disconnect the tuner board from connector CN101 on the main board.
- Disconnect the SEA board and the audio board from connector CN452, CN301 and CN302 on the main board.
- Disconnect the V-audio board from connector CN303 on the main board.
- Disconnect the relay board 4. Then, disconnect the video board and the S-video board from connector CN201 and CN241 on the main board.
- Disconnect the DSP board from connector CN501 and CN601 on the main board while removing the DSP board from the bracket fixing the lower part of the DSP board at the same time.
- Disconnect the compulink board from connector CN255 on the main board.




Fig.5




Fig.6




Fig.7




Fig.9




Fig.8

## ■ Removing the main board / regulator board (See Fig.10 to 12)

- Prior to performing the following procedure, remove the top cover and the rear panel.

**ATTENTION:** It is not necessary to remove the boards connected to the back of the main board. But to disassemble the main board and the power supply board efficiently, remove them.

- Disconnect the card wire from connector CN400 on the main board.
- Cut off the three tie bands fixing the harnesses.
- Disconnect the harness from connector CN811 on the power transformer board.
- Disconnect the relay board 1,2 and 3 from the main board and the power supply board.
- Disconnect the harness from connector CN704, CN821, CN901, CN711, CN712, CN931 and CN932.
- Remove the screw G attaching the regulator board to the heat sink cover.
- Remove the eight screws H attaching the main board to the heat sink cover.
- Remove the five screws I and the screw J attaching the main board to the chassis base (The resistor board will come off at the same time).




Fig.10




Fig.11




Fig.12




Fig.13

## ■ Removing the amplifier board

(See Fig.10 and 14)

- Prior to performing the following procedure, remove the top cover.
- Cut off the four tie bands fixing the harnesses.
  - Disconnect the harnesses from connector CN711, CN712, CN704 and CN901 on the main board respectively.
  - Remove the four screws K and six screws L attaching the amplifier board.
  - If necessary, unsolder the harness connected to connector CN803 and CN952 on the amplifier board.




Fig.10




Fig.14




Fig.15




Fig.16

## ■ Removing the power supply board (See Fig.17 and 18)

- Prior to performing the following procedure, remove the top cover and the front panel.
- Remove the one nut attaching the headphone jack of the power supply board on the front side of the body.
  - Disconnect the relay board 1, 2 and 3 from the power supply board and the main board respectively.
  - Unsolder the harness connected to connector CN55 and CN56 on the power transformer board (If necessary, cut off the band fixing the harness on the side of the base chassis).
  - Remove the four screws O attaching the power supply board and pull out the power supply board from the front bracket backward.
  - Unsolder the three harnesses connected to the power supply board.




Fig.17




Fig.18

## ■ Removing the system control board / power switch board (See Fig.19 to 20)

- Prior to performing the following procedure, remove the top cover and the front panel assembly.
- Pull out the volume knob on the front side of the front panel and remove the nut attaching the system control board.
  - Remove the six screws P attaching the system control board on the back of the front panel and disconnect the harness from connector CN422 on the system control board.
  - Disconnect the harness from connector CN430 on the power switch board.
  - Remove the five screws Q attaching the power switch board.




Fig.19







Fig.20

**■Removing the operation switch board  
(See Fig.21 to 23)**

- Prior to performing the following procedure, remove the top cover, the front panel assembly and the system control board.

- Remove the six screws R attaching the operation switch board on the back of the front panel.
- On the back of the front panel, release the four joints by pushing the joint tabs inward. Remove the operation switch board toward the front.
- Pull out the multi jog knob and the source selector knob.
- Remove the two screws S attaching the operation switch board.



# Adjustment method

## ■ Tuner section

- 1.Tuner range
 

FM	87.5MHz~108.0MHz
AM(MW)	530kHz~1710kHz

## ■ Power amplifier section

### Adjustment of idling current

Measurement location      TP781  
 Adjustment part            VR787(Lch) , VR788(Rch)

#### Attention


**This adjustment does not obtain a correct adjustment value immediately after the amplifier is used (state that an internal temperature has risen).**

**Please adjust immediately after using the amplifier after turning off the power supply of the amplifier and falling an internal temperature.**

#### <Adjustment method>

- 1.Set the volume control to minimum during this adjustment.(No signal & No load)
- 2.Set the surround mode OFF.
- 2.Turn VR787 and VR788 fully counterclockwise to warm up before adjustment.  
 If the heat sink is already warm from previous use the correct adjustment can not be made.
- 3.For L-ch,connect a DC voltmeter between TP781's pin1 and pin2 (Lch)  
 And,connect it between pin3 and pin4(Rch).
- 4.30 minutes later after power on, adjust VR787 for L-ch, or VR788 for R-ch so that the DC voltmeter value has 1mV~10mV.


\* It is not abnormal though the idling current might not become 0mA even if it is finished to turn variable resistance (VR787,VR788) in the direction of counterclockwise.




## Description of major ICs

### ■ AK4527 (IC601) : A/D,D/A Converter

#### 1. Pin layout



#### 2. Block diagram



Block Diagram (DIR and AC-3 DSP are external parts)

## 3. Pin function (1/2)

AK4527(1/2)

No.	Pin name	I/O	Function
1	SDOS	I	SDTO Source select pin "L" : Internal ADC output, "H" : DAUX input ORed with serial control register if P/S="L".
2	OCKS	I	MCKO Clock frequency select pin "L" : MCLK, "H" : MCLK/2. ORed with serial control register if P/S= "L".
3	MIS	I	Connect to GND
4	BICK	I	Audio serial data clock pin
5	LRCK	I/O	Input/Output channel clock pin
6	SDTI1	I	DAC1 Audio serial data input pin
7	SDTI2	I	DAC2 Audio serial data input pin
8	SDTI3	I	DAC3 Audio serial data input pin
9	SDTO	O	Audio serial data output pin
10	DAUX	I	AUX Audio serial data input pin
11	DFS	I	Double speed sampling mode pin "L" : Normal speed, "H" : Double speed, the ADC is powered down. ORed with serial control register if P/S="L".
12	DEM1	I	De-emphasis pin ORed with serial control register if P/S="L"
13	DEMO	I	De-emphasis Pin ORed with serial control register if P/S="L"
14	MCKO	O	Master clock output pin
15	DVDD	-	Digital power supply pin
16	DVSS	-	Digital ground pin
17	PD	I	Power-down & Reset pin When "L", the AK4527 is powered-down and the control registers are reset to default state. If the state of CAD0-1 changes, then the AK4527 must be reset by PDN.
18	XTS	I	X'tal oscillator Select/Test mode pin "H" : X'tal Oscillator selected "L" : External clock source selected
19	ICKS1	I	Input clock select 1 pin
20	ICKS0	I	Input clock select 0 pin
21	CAD1	I	Chip address pin Used during the serial control mode.
22	CAD0	I	Chip address pin Used during the serial control mode.
23	LOUT3	O	Lch #3 analog output pin
24	ROUT3	O	Rch #3 analog output pin
25	LOUT2	O	Lch #2 analog output pin
26	ROUT2	O	Rch #2 analog output pin
27	LOUT1	O	Lch #2 analog output pin
28	ROUT1	O	Rch #1 analog output pin
29	LIN-	I	Lch analog negative Input Pin
30	LIN+	I	Lch analog positive Input Pin
31	RIN-	I	Rch analog negative Input Pin
32	RIN+	I	Rch analog positive Input Pin

## 3.Pin function (2/2)

AK4527(2/2)


No.	Pin Name	I/O	Function
33	VREFL	I	Negative voltage reference Input pin, AVSS
34	VCOM	O	Common voltage output pin, AVDD/2 Large external capacitor around 2.2uF is used to reduce power-supply noise
35	VREFH	I	Positive voltage reference input pin, AVDD
36	AVDD	-	Analog power supply pin
37	AVSS	-	Analog ground pin
38	XTI	I	X'tal input pin
39	XTO	O	X'tal output pin if XTS="H"
	MCKI	I	External master clock input pin if XTS="L"
40	P/S	I	Parallel/Serial select pin "L" : Serial control mode, "H" : Parallel control mode
41	DIF0	I	Audio data interface format pin in parallel mode
	CS	I	Chip select pin in serial mode
42	DIF1	I	Audio data interface format pin in parallel mode
	CCLK	I	Control data clock pin in serial mode
43	LOOP0	I	Loop back mode pin in parallel mode Enables digital loop-back from ADC to 3 DACs.
	CDTI	I	Control data input pin in serial mode
44	LOOP1	I	Loop back mode pin in parallel mode Enable all 3 DAC channels to be input from SDTII.
	CDTO	O	Control data output pin in serial mode

## ■ TC9162AN (IC321): Analog switch

## 1.Function


Switch to On/Off of S1 to S8 by control of LSI.

## 2.Terminal Lay out &amp; Block Diagram



## ■ BU2092(IC402,IC405):LED Controller

### 1.Terminal Layout




### 2.Pin Function


Pin No.	Symbol	I/O	Function						
1	Vss	-	Connect to GND						
2	DATA	I	Serial Data input						
3	CLOCK	I	Shift Clock of Data						
4	LCK	I	Latch Clock of Data						
5~16	Q0~Q11	O	Parallel Data Output <table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <td>Latch Data</td> <td>L</td> <td>H</td> </tr> <tr> <td>OUTPUT</td> <td>ON</td> <td>OFF</td> </tr> </table>	Latch Data	L	H	OUTPUT	ON	OFF
Latch Data	L	H							
OUTPUT	ON	OFF							
17	OE	I	Output Enable						
18	Vdd	-	Power Supply						

### ■ BU4051BC(IC341):Analog multiplex/DE multiplex

#### 2.Block diagram




#### 1.Pin layout



### ■ NJM2285D (IC202) : Video switch

#### 1.Terminal layout & Block diagram




### ■ W24L011AJ-15(IC641):SDRAM

#### 1.Pin layout

A0	1	32	A16
A1	2	31	A15
A2	3	30	A14
A3	4	29	A13
CS	5	28	OE
I/O1	6	27	I/O8
I/O2	7	26	I/O7
VDD	8	25	VSS
VSS	9	24	VDD
I/O3	10	23	I/O6
I/O4	11	22	I/O5
WE	12	21	A12
A4	13	20	A11
A5	14	19	A10
A6	15	18	A9
A7	16	17	A8

#### 2.Block diagram




#### 3.Pin function

Symbol	Description
A0~A16	Address inputs
I/O1~I/O8	Data inputs/outputs
CS	Chip select inputs
WE	Write enable input
OE	Output enable input
Vdd	Power supply
Vss	Ground

## ■ LA1838(IC102): FM AM IF AMP&detector, FM MPX Decoder

### 1. Block Diagram



### 2. Pin Function


Pin No.	Symbol	I/O	Function	Pin No.	Symbol	I/O	Function
1	FM IN	I	This is an input terminal of FM IF signal.	16	R OUT	O	Right channel signal output.
2	AM MIX	O	This is an out put terminal for AM mixer.	17	L OUT	O	Left channel signal output.
3	FM IF	I	Bypass of FM IF	18	R IN	I	Input terminal of the Right channel post AMP.
4	AM IF	I	Input of AM IF Signal.	19	L IN	I	Input terminal of the Left channel post AMP.
5	GND	-	This is the device ground terminal.	20	RO	O	Mpx Right channel signal output.
6	TUNED	O	When the set is tunning, this terminal becomes "L".	21	LO	O	Mpx Left channel signal output.
7	STEREO	O	Stereo indicator output. Stereo "L", Mono: "H"	22	IF IN	I	Mpx input terminal
8	VCC	-	This is the power supply terminal.	23	FM OUT	O	FM detection output.
9	FM DET	-	FM detect transformer.	24	AM DET	O	AM detection output.
10	AM SD	-	This is a terminal of AM ceramic filter.	25	AM AGC	I	This is an AGC voltage input terminal for AM
11	FM VSM	O	Adjust FM SD sensitivity.	26	AFC	-	This is an output terminal of voltage for FM-AFC.
12	AM VSM	O	Adjust AM SD sensitivity.	27	AM RF	I	AM RF signal input.
13	MUTE	I/O	When the signal of IF REQ of IC121(LC72131) appear, the signal of FM/AM IF output. //Muting control input.	28	REG	O	Register value between pin 26 and pin28 besides the frequency width of the input signal.
14	FM/AM	I	Change over the FM/AM input. "H" :FM, "L" : AM	29	AM OSC	-	This is a terminal of AM Local oscillation circuit.
15	MONO/ST	O	Stereo : "H", Mono: "L"	30	OSC BUFFER	O	AM Local oscillation Signal output.

#### ■ LC72136N (IC121) : PLL Frequency synthesizer

## 1. Pin layout

	XT	1	22	XT
	FM/AM	2	21	GND
	CE	3	20	LPFOUT
	DI	4	19	LPFIN
	CLOCK	5	18	PD
	DO	6	17	VCC
FM/ST/VCO		7	16	FMIN
	AM/FM	8	15	AMIN
		9	14	
		10	13	IFCONT
	SDIN	11	12	IFIN

## 2. Block diagram




### 3. Pin function


Pin No.	Symbol	I/O	Function	Pin No.	Symbol	I/O	Function
1	XT	I	X'tal oscillator connect (75kHz)	12	IFIN	I	IF counter signal input
2	FM/AM	O	LOW:FM mode	13	IFCONT	O	IF signal output
3	CE	I	When data output/input for 4pin(input) and 6pin(output): H	14		-	Not use
4	DI	I	Input for receive the serial data from controller	15	AMIN	I	AM Local OSC signal output
5	CLOCK	I	Sync signal input use	16	FMIN	I	FM Local OSC signal input
6	DO	O	Data output for Controller Output port	17	VCC	-	Power supply(VDD=4.5-5.5V) When power ON:Reset circuit move
7	FM/ST/VCO	O	"Low": MW mode	18	PD	O	PLL charge pump output(H: Local OSC frequency Height than Reference frequency. L: Low Agreement: Height impedance)
8	AM/FM	O	Open state after the power on reset	19	LPPFIN	I	Input for active lowpassfilter of PLL
9	LW	I/O	Input/output port	20	LPFOUT	O	Output for active lowpassfilter of PLL
10	MW	I/O	Input/output port	21	GND	-	Connected to GND
11	SDIN	I/O	Data input/output	22	XT	I	X'tal oscillator(75KHz)

## ■ LC7522 (IC451) : SEA Control

1.Pin layout



2.Block diagram



3.Pin function


Pin No.	Symbol	Function
1	V <sub>DD</sub>	Power Supply terminal for Audio signal +7V(typ)
18	V <sub>SS</sub>	Power Supply terminal 0V
14	V <sub>EE</sub>	Power Supply terminal for Audio signal. Single channel use, joint VSS.
15	V <sub>CC</sub>	Power Supply terminal +5V(typ)
2,27 3,26	IN 1 IN 2	Audio signal Input terminal IN1 joint opposite input of Operation amp. IN2 joint inapposite input of Operation amp. It have Right and Left.
16	D1	Data input terminal from CPU Shumit inverter style
17	CLK	Clock input terminal from CPU Shumit inverter style
4~10 19~25	f <sub>1~f7</sub>	Joint terminal of B.P.F. f <sub>1~f7</sub> X Right, Left Total 14 terminal
11 12	TEST1 TEST2	Internal test terminal of IC It can use open condition
13	S	Select terminal for 2 tip use "1" input, key code 7C3 - VDD joint "0" input, key code 7C2 - VEE joint
28	NC	No use

■ MB90088 (IC203) : On screen display controller

1.Terminol layout

YIN	1	AVss
VIN	2	YOUT
CIN	3	VOUT
AVcc	4	COUT
FSCO	5	CS
VBLK	6	SIN
Vcc	7	SCLK
EXS	8	TEST
XS	9	VOC0
HSYNC	10	VOC1
VSYNC	11	VOC2
EXHYSN	12	VOB
EXVSYN	13	XD
Vss	14	EXD


2.Block diagram



## 3.Pin functions (MB90088)

pin no	Symbol	I/O	Function
1	YIN	I	Brightness signal Input terminal for Superinpulse indication
2	VIN	I	Composite video signal input terminal for Superinpulse indication
3	CIN	I	Contrast signal input terminal for Superinpulse indication
4	AVcc	-	Analog power supply terminal
5	IOUT	O	Color (Brightness) signal output terminal
6	VOC	O	Character output terminal
7	Vcc	-	Power supply terminal
8	EXS	I	Clock generator outside circuit terminal for color burst
9	XS	O	
10	H SYNC	O	Horizontal signal output terminal
11	V SYNC	O	Vertical signal output terminal
12	EXH SYNC	I	EXT horizontal signal input terminal
13	EXV SYNC	I	EXT vertical signal input terminal
14	Vss	-	GND
15	EXD	I	Dot clock generator outside circuit signal terminal for indication
16	XD	O	
17	VOB	O	Character & background signal output terminal
18	GOUT	O	Color signal (Green, Red, Blue)
19	ROUT		
20	BOUT		
21	TEST	I	Test signal input terminal
22	SCLK	I	Shift clock input terminal for serial transmission
23	SIN	I	Serial data input terminal
24	CS	I	Chip select terminal
25	COUT	O	Contrast signal output terminal
26	VOUT	O	Composite video signal output terminal
27	YOUT	O	Brightness signal output terminal
28	AVss	-	Analog GND terminal

## ■ BA7625 (IC242,IC201) / BA7626 (IC241): Video selector



			MONITOR OUT
A	B	E	MONITOR OUT
L	L	*	IN1
H	L	*	IN2
L	H	*	IN3
H	H	L	IN4
H	H	H	IN5

			VOUT1
C	D	E	VOUT1
L	L	*	--
H	L	*	IN2
L	H	*	IN3
H	H	L	IN4
H	H	H	IN5

			VOUT2
C	D	E	VOUT2
L	L	*	IN1
H	L	*	--
L	H	*	IN3
H	H	L	IN4
H	H	H	IN5

## ■ MN101C15FDE (IC401) : System control micon

### 1. Pin layout


●	80 ~ 61
1	60
20	41
21 ~ 40	

### 2. Pin function

Pin No	Symbol	Functions	Pin No	Symbol	Functions
1	GND	Ground	41	VIDEO3	VIDEO 3 signal terminal
2	DVD-S/C	DVD S/C signal select terminal	42	VIDEO4	VIDEO 4 signal terminal
3	VCR1-S/C	VCR1 S/C signal select terminal	43	S.MUTE	Source mute control terminal
4	VIDEO-S/C	VIDEO S/C signal select terminal	44	_____	No use
5	TV-S/C	TV S/C select terminal	45	_____	No use
6	4/8-IN	4 ohm / 8 ohm select signal terminal	46	_____	No use
7	_____	_____	47	RDS-DATA	RDS control signal terminal
8	GND	Ground	48	_____	No use
9	PROTECT	Protect	49	RDS-CLK	RDS control signal clock
10	GND	Ground	50	DSP-READY	DSP control signal clock
11	VDD	Power supply	51	DSP-RESET	DSP reset signal terminal
12	OSC 12	Oscillation terminal	52	M/CS	Control signal from IC400
13	OSC 11	Oscillation terminal	53	M-RESET	Reset signal from IC400
14	VSS	Ground	54	M-STATUS	Status signal from IC400
15	X1	Ground	55	M-COMMAND	Command signal from IC400
16	X0	Ground	56	M-CLK	Clock signal from IC400
17	GND	Ground	57	SEA-CLK	SEA clock signal from terminal
18	TEXT-OUT	Text signal output terminal	58	SEA-DATA	SEA data signal terminal
19	TEXT-IN	Text signal input terminal	59	VL/VH	Connect to power supply board
20	MASTER	Master signal terminal	60	4/8 OUT	4 ohm / 8 ohm select signal terminal
21	DSP-COMMAND	DSP control signal terminal	61	SW-DATA	Switch data signal terminal
22	DSP-STATUS	DSP control signal terminal	62	SW-CLK	Switch clock signal terminal
23	DSP-CLK	DSP control signal terminal	63	VOL-STB	Volume strobe signal terminal
24	_____	No use	64	VOL-DATA	Volume data signal terminal
25	RESET-IN	Reset signal input terminal	65	VOL-CLK	Volume clock signal terminal
26	TUNER-CE	Tuner chip enable	66	SW-STB	Switch strobe signal terminal
27	TUNER-CLK	Tuner clock signal terminal	67	_____	No use
28	_____	No use	68	_____	No use
29	TUNER-DATA	Tuner control signal terminal	69	FR1-RELAY	Relay 1 signal terminal
30	TUNER-MUTE	Tuner mute signal terminal	70	FR2-RELAY	Relay 2 signal terminal
31	TUNER-IN	Tuner signal input terminal	71	CNTR-RELAY	Center speaker relay terminal
32	STEREO-IN	Stereo signal input terminal	72	SUR-RELAY	Surround speaker relay terminal
33	RDS-ST	No use	73	SUB-MUTE	SUB woofer out mute control
34	M-BUSY	Busy signal from IC400	74	LED-LCK2	LED latch clock signal terminal
35	INH	No use	75	C.TONE3	Center tone 3 signal terminal
36	OSD-DATA	OSD data signal input terminal	76	C.TONE2	Center tone 2 signal terminal
37	OSD-STB	OSD standby signal terminal	77	C.TONE1	Center tone 1 signal terminal
38	OSD-CLK	OSD clock signal terminal	78	LED-LCK1	LED latch clock signal terminal
39	VIDEO1	VIDEO 1 signal terminal	79	LED-DATA	LED data signal terminal
40	VIDEO2	VIDEO 2 signal terminal	80	LED-CLK	LED clock signal terminal

## ■ MN173222DF(IC400):FL Display & Operation switch control

### 1.Pin layout



### 2.Key matrix

	KEY OUT 0	KEY OUT1	KEY OUT 2	KEY OUT 3	KEY OUT 5
KEY IN 0	POWER	ANALOG/ DIGITAL	SEA ADJUST	FM/AM TUNING	ONE TOUCH OPERATION
KEY IN 1	SURROUND	DSP MODE	FM MODE	TUNER PRESET	_____
KEY IN 2	SPEAKER 1	LOUDNESS	LEVEL ADJUST	MEMORY	_____
KEY IN 3	SPEAKER 2	SEA MODE	SOUND SELECT	SETTING	_____

### 3.Pin function

Pin No.	Symbol	I/O	Description
1~22	S22~S1	O	FL Segment control signal
23	VPP	-	Power supply terminal
24~39	G15~G1/KO0~5	O	FL grid control signal / Key matrix output
40,41	JOG1,2	I	Source select JOG1,2
42,43	JOG3,4	I	Volume JOG 3,4
44	M BUSY	O	BUSY Signal output to IC401
45	M CLK	I/O	Clock signal to IC401
46	M COMMAND	I	Command data input from IC401
47	M STATUS	O	Status signal output to IC401
48	M CS	I	Chip select signal input from IC401
49	RM	I	Remote control signal input
50	VCRI	I	AV Compu-link VCR input
51	DCSI	I	AV Compu-link DCS input
52	DCSO	O	AV Compu-link DCS output
53	VCRO	O	AV Compu-link VCR output
54	TVD	O	AV Compu-link TV output
55	TVC	O	AV Compu-link TV control output
56,57	JOG5,6	I	Multi JOG 5,6
58	POWER	I	Power ON control output
59		O	STANDBY LED control H:Lighting
60~63	KI3~KI0	I	Key matrix input
64~67	S36~S33	O	FL Segment control signal
68	RST	I	Reset input
69	X1	-	Connect to GND
70	X2	-	Non connect
71	VSS	-	Connect to GND
72	OSC2	-	Oscillation terminal 6MHz
73	OSC1	-	Oscillation terminal 6MHz
74		-	Not use
75~84	S32~S23	O	FL Segment control signal


**■ TC9446F-013(IC631):Digital signal processor for dolby digital  
/ DTS audio decode**

Pin No.	Symbol	I/O	Function
1	RST	I	Reset signal input terminal (L:reset H:Operation usually)
2	MIMD	I	Microcomputer interface mode selection input terminal (L:serial H:IC bus)
3	MICS	I	Microcomputer interface chip select input terminal
4	MILP	I	Microcomputer interface latch pulse input
5	MIDIO	I/O	Microcomputer interface data I/O terminal
6	MICK	I	Microcomputer interface clock input terminal
7	MIACK	O	Microcomputer interface acknowledge output terminal
8~11	F10~3	I	Flag input terminal 0~3
12	IRQ	I	Interrupt input terminal
13	VSS	-	Digital ground terminal
14	LRCKA	I	Audio interface LR clock input terminal A
15	BCKA	I	Audio interface bit clock input terminal A
16~18	SDO0~2	O	Audio interface data output terminal 0
19	SD03	-	Non connect
20	LRCKB	I	Audio interface LR clock input terminal B
21	BCKB	I	Audio interface bit clock input terminal B
22	SDT0	I	Audio interface data input terminal 0
23	SDT1	I	Audio interface data input terminal 1
24	VDD	-	Power supply for digital circuit
25	LRCKOA	O	Audio interface LR clock output terminal A
26	BCKOA	O	Audio interface bit clock output terminal A
27,28	TEST0,1	I	Test input terminal 0/1 (L:test H:operation usually)
29~31	LRCKOB,BCKOB,TXO	-	Non connect
32,33	TEST2,3	I	Test input terminal (L:test H:operation usually)
34	RX	I	SPDIF input terminal
35	VSS	-	Ground terminal for digital circuit
36	TSTSUB0	I	Test sub input terminal 0 (L:test H:operation usually)
37	FCONT	O	VCO Frequency control output terminal
38,39	TSTSUB1,TSTSUB2	I	Test sub input terminal 1,2 (L:test H:operation usually)
40	PDO	O	Phase error signal output terminal
41	VDDA	-	Power supply for analog circuit
42	PLON	I	Clock selection input terminal (L:external clock H:VCO clock)
43	AMPI	I	AMP.input terminal for LPF
44	AMPO	O	AMP.output terminal for LPF
45	CKI	I	External clock input terminal
46	VSSA	-	Ground terminal for analog circuit
47	CKO	O	DIR Clock output terminal
48	LOCK	O	VCO Lock detection output terminal
49	VSS	-	Ground terminal for digital circuit
50	WR	O	External SRAM writing signal output terminal
51	OE	O	External SRAM output enable signal output terminal
52	CE	O	External SRAM chip enable signal output terminal
53	VDD	-	Power supply terminal for digital circuit
54~61	IO7~0	I/O	External SRAM data I/O terminal 7~0
62	VSS	-	Ground terminal for digital circuit
63~70	AD0~7	O	External SRAM address output terminal 0~7
71	VDD	-	Power supply terminal for digital circuit
72~80	AD8~16	O	External SRAM address output terminal 8~16
81	VSS	-	Ground terminal for digital circuit
82~89	PO0~7	O	General purpose output terminal 0~7
90	VDDL	-	Power supply terminal for DLL
91	LPFO	O	LPF output terminal for DLL
92,93	DLON,DLCKS	I	Refer to the undermentioned table
94	SCKO	-	Non connect
95	VSSDL	-	Ground terminal for DLL
96	SCKI	I	External system clock input terminal
97	VSSX	-	Ground terminal for oscillation circuit
98,99	XO,XI	I/O	Oscillation I/O terminal
100	VDDX	-	Power supply terminal for oscillation circuit


DLCKS terminal	DLONterminal	DLL clock setting
L	L	SCKI input (DLL circuit OFF)
L	H	Four times XI clock
H	L	Three times XI clock
H	H	Six times XI clock

## ■ TC9459F (IC331,IC332,IC333) : Electronic volume control

### 1. Pin layout



### 2. Block diagram




### 3. Pin function

Pin No.	Symbol	Function	Pin No.	Symbol	Function
1	VSS	Negative power supply pin	13	DATA	Volume setup serial data input
2	L-OUT	Volume output pin	14	STB	Data write strobe input
3	NC	No connection	15	NC	No connection
4	NC	No connection	16	CS2	Chip select input pin
5	L-LD1	Loudness tap output pin	17	NC	No connection
6	L-LD2	Loudness tap output pin	18	R-A-GND	Analog GND pin
7	L-A-GND	Analog GND pin	19	R-LD2	Loudness tap output pin
8	NC	No connection	20	R-LD1	Loudness tap output pin
9	CS1	Chip select input pin	21	R-IN	Volume input pin
10	NC	No connection	22	NC	No connection
11	NC	No connection	23	R-OUT	Volume output pin
12	CK	Data transfer clock input	24	VDD	Positive power supply pin

**■ UPD784215AGC(IC671):UNIT CPU**

## 1.Pin layout




## 2.Pin function


Pin No.	Symbol	I/O	Function
1~8		-	Non connect
9	VDD	-	Power supply terminal
10	X2	O	Connecting the crystal oscillator for system main clock
11	X1	I	Connecting the crystal oscillator for system main clock
12	VSS	-	Connect to GND
13	XT2	O	Connecting the crystal oscillator for system sub clock
14	XT1	I	Connecting the crystal oscillator for system sub clock
15	RESET	I	System reset signal input
16	AUTODATA	I	Output of DSP to general-purpose port
17	LOCK	I	Output of DSP to general-purpose port
18	DIGITAL0	I	Output of DSP to general-purpose port
19	FORMAT	I	Output of DSP to general-purpose port
20	CHANNEL	I	Output of DSP to general-purpose port
21	ERR	I	Output of DSP to general-purpose port
22	RSTDET	I	Reset signal input
23	AVDD	-	Power supply terminal
24	AVREF0	-	Connect to GND
25~32		-	Connect to GND
33	AVSS	-	Connect to GND
34,35		-	Non connect
36		-	Power supply terminal
37,38	RX,TX	-	Not use
39		-	Non connect
40	DSPCOM	I	Communication port from IC401
41	DSPSTS	O	Status communication port to IC401
42	DSPCLK	I	Clock input from IC401
43	DSPRDY	I	Ready signal input from IC401
44		-	Non connect
45,46	MIDIO_IN/OUT	I/O	Interface I/O terminal with microcomputer
47	MICK	O	Interface I/O terminal with microcomputer of clock signal
48	MICS	O	Interface I/O terminal with microcomputer of chip select
49	MILP	O	Interface I/O terminal with microcomputer
50	MIACK	O	Interface I/O terminal with microcomputer
51,52		-	Non connect
53	DSPRST	O	Reset signal output of DSP
54~63		-	Non connect
64,65	CDTI/CDTO	I/O	Interface I/O terminal with microcomputer
66	CCLK	O	Interface I/O terminal with microcomputer of clock signal
67	CS	O	Interface I/O terminal with microcomputer of chip select
68	XTS	O	OSC Select
69,70		-	Non connect
71	PD	O	Reset signal output
72	GND	-	Connect to GND
73~80		-	Non connect
81	VDD	-	Power supply
82	3D-ON	-	Non connect
83	3D-ON	O	Switch at output destination of surround channel
84	ANAT-TONE	O	Test tone control
85	REF-MIX	O	Control at output destination of LFE channel
86		-	Non connect
87	D.MUTE	O	Mute of the digital out terminal is controlled
88	S.MUTE	O	Mute of the audio signal is controlled
89		-	Non connect
90~93	ASW1~4	O	Selection of digital input selector
94	TEST	-	Test terminal
95~100		-	Non connect

## Block diagrams


#### ■ System control & Video I/O section




### ■ Power amplifier & Audio I/O section



### ■ DSP Section



### ■ Tuner section




RX-8000VBK

**-MEMO-**



# Standard schematic diagrams

## ■ Power supply section




SHEET NUMBER	CIRCUIT DESCRIPTION
1/8	PRIMARY / RECTIFYING
2/8	VOLUME (FRONT/CENTER/REAR ch.) / SEA / SOURCE SELECT IC
3/8	AUDIO AMP (FRONT ch.) / SPEAKER TERMINAL (FRONT ch.) / REGULATOR / RECTIFYING
4/8	AUDIO AMP (CENTER/REAR ch.) / SPEAKER TERMINAL (CENTER/REAR ch.)
5/8	AUDIO SIGNAL INPUT TERMINAL / SOURCE SELECT IC / SYSTEM CONTROL SIGNAL TERMINAL
6/8	VIDEO SIGNAL INPUT TERMINAL / SOURCE SELECT IC
7/8	USER CONTROL KEYS / SYSTEM CONTROL LSI / FL DISPLAY
8/8	SURROUND IC / DIGITAL SIGNAL INPUT TERMINAL

A

B

C

D




MODEL BX-8000VBK SHEET 1 / 8

 Parts are safety assurance parts.  
When replacing those parts make  
sure to use the specified one.

**EXPLANATION OF OVERALL OF SCHEMA.**


**RX-8000VBK**

## ■ Main amplifier section 1/2



 CENTER Signal  
 SURROUND Signal

- AUDIO Signal
- TUNER Signal



DNT Signal

**⚠ Parts are safety assurance parts.**  
When replacing those parts make  
sure to use the specified one.

MODEL

RX-8000VBK

SHEET  
2 / 8

LVA10015-1(1)

D


E

F

G

H

## ■ Main amplifier section 2/2



LVA10015-1(2)

52-301  
FROM FWD  
OF LVA101


A

B

---

8

D





→ AUDIO Signal

 **⚠ Parts are safety assurance parts.**  
When replacing those parts make  
sure to use the specified one.

## ■ Center / Rear amplifier section

LVA10131-7





 Parts are safety assurance parts.  
When replacing those parts make  
sure to use the specified one.

→ CENTER Signal


 SURROUND Signal

## MODEL


BX-8000VRK

SHEET  
4 / 8

## ■ Audio signal section



LVA10018-2



→ CD / AUDIO Signal

→ TUNER Signal


→ SURROUND Signal


MODEL RX-8000VBK

SHEET  
5 / 8

**⚠ Parts are safety assurance parts.  
When replacing those parts make  
sure to use the specified one.**

## ■ Video signal section





**⚠ Parts are safety assurance parts.**  
When replacing those parts make  
sure to use the specified one.

MODEL  
RX-8000VBK

SHEET  
6 / 8

LVA10018-7

D

E


F

G

H

## ■ FL Display & System control section

LVA10016-1




A

B

C


D



## ■ DSP Section

LVA10086


5



→ SURROUND Signal  
→ CENTER Signal

→ AUDIO Signal  
→ FRONT Signal

⚠ Pa  
Wi  
su



 Parts are safety assurance parts.  
When replacing those parts make  
sure to use the specified one.

MODEL

RX-8000VBK

SHEET

8  
8

D

E


E

0

H

## Tuner section

FOR J, C, U, A  
LVA10009



\* NOTE C139 AND C140 ARE CHANGED AS BELOW TABLE.

	C139, C140
J. C	0.033
U. A	0.022


D124 AND D125 ARE USED IN J/C VERSION ONLY

A

B


C


D




# Printed circuit boards


### Main board







#### ■ FL Display & System control board





■ Input / output board





D

E


F


---

6

上


## ■ Power AMP. & Power supply board






## DSP board


Reverse side



Forward side



■ Tuner board



D

E

F

G

H



## PARTS LIST

[ RX-8000VBK ]

\* All printed circuit boards and its assemblies are not available as service parts.

Area suffix

J ----- The U.S.A.  
C ----- Canada

### - Contents -

Exploded view of general assembly and parts list	-----	3-3
Electrical parts List	-----	3-5
Packing materials and accessories parts list	-----	3-20


RX-8000VBK

**-MEMO-**




# Exploded view of general assembly and parts list

Block No. M 1 M M



1



## Parts list ( General assembly )

Block No. M1MM

▲	Item	Parts number	Parts name	Q'ty	Description	Area
	1	LV10018-035A	FRONT PANEL	1		
	2	VJD5429-001SS	JVC MARK	1		
	3	LV20031-018A	LENS	1		
	4	LV20032-011A	FRONT ESC	1		
	5	LV20034-001A	PUSH BUTTON	1		
	6	LV40099-001A	INDICATOR	1		
	7	QYSDSF2608Z	SCREW	19		
	8	LV30068-001A	P.BUTTON(POWER)	1		
	9	FSJD4001-002	INDICATOR	1	POWER	
	10	LV30069-001A	P.BUTTON ASSY	1		
	11	LV30071-001A	P.BUTTON ASSY	1	DOLBY	
	13	E308744-002	REMOTE LENS	1		
	14	LV30073-001A	SOURCE INDICATO	1		
	15	QUQC12-2120CJ	CARD WIRE	1		
	16	QUQC12-2722CJ	CARD WIRE	1		
	17	QYSDSG3008M	SCREW	5	FRONT D	
	18	QYSBKG3008E	T.SCREW	8		
	19	LV10019-002A	CHASSIS BASE	1		
	20	EXO150010H09S11	FELT SPACER	1	FOR C.BASE	
	21	LV10020-001A	FRONT BRACKET	1		
	22	QYSDSG3008E	T.SCREW	7	C.B-F.B	
	23	LE40139-001A	H.P. BKT	1		
	24	E68587-223SM	CB BKT	3		
	25	QYSBST3006E	T.SCREW	7		
	26	QZF6018-001	FOOT	2		
	27	E47227-036	FOOT	2		
	28	QYSBST3010Z	T.SCREW	4	FOOT	
	29	LV30075-203A	HEAT SINK	1		
▲	30	2SC3858/PG/-F1	TRANSISTOR	2	Q761.Q762	
▲	31	2SA1494/PG/-F1	TRANSISTOR	2	Q763.Q764	
▲	32	2SD2488/Z1/-F1	TRANSISTOR	2	Q1851.Q1852	
▲	33	2SD2488/Z1/-F1	TRANSISTOR	1	Q1751	
▲	33	2SB1620/OP/-F1	TRANSISTOR	1	Q1752	
▲	33	2SB1620/OP/-F1	TRANSISTOR	2	Q1853.Q1854	
	34	E73525-003SS	SCREW	14	TR	
	35	LV41603-001A	LEAF SPRING	1		
	36	LV20035-001A	H.S BRACKET(R)	1		
	37	LV20036-001A	H.S BRACKET(L)	1		
	38	QYSBKG3008E	T.SCREW	17		
	39	VKZ4150-001	SPECIAL NUT	1	H.P	
▲	40	QQT0211-001	POWER TRANSF	1		
	41	QYSDSTL4008E	SPECIAL SCREW	4	P.TRANS	
	42	LV10021-067A	REAR PANEL	1		
	43	QYSBKG3008E	SPECIAL SCREW	34		
	44	E302321-001	FASTNER	1	SPACER	
	45	LV41240-002A	BRACKET	1		
	48	E409257-001	GND TERMINAL	1		
▲	49	QMPD220-200-JD	POWER CORD	1		

■ Parts list ( General assembly )

Block No. M1MM

▲	Item	Parts number	Parts name	Q'ty	Description	Area
▲	50	QHS3771-108	CORD STOPPER	1		
	51	LV30076-001A	PROTECTOR	1		
	52	LV20038-006A	TOP COVER	1		
	53	E406308-003	SPECIAL SCREW	4		
	54	LV30480-004A	VOL KNOB ASS'Y	1		
	55	LV30481-001A	JOG KNOB ASS'Y	2		
▲	56	QMF51U1-6R3-J8	FUSE	1	F1	
▲	57	QMF51U1-2R0-J8	FUSE	2	F61.F62	
▲	59	E409394-001	CAUTION LABEL	1	VER.J	
▲		E409396-001	CAUTION LABEL	1	VER.C	
	60	E310243-002	PLASTIC RIVET	1		
	73	E408632-002	C=CSA LABEL	1	VER.C	
▲	74	E67199-001	CAUTION LABEL	1	VER.J	
▲		E65507-001	CAUTION LABEL	1	VER.C	
	75	QYSBSG3008E	T.SCREW	1	TR(LEAF)	
	88	QYSBSG3008E	T.SCREW	3		



# Electrical parts list

## ■ Electrical parts list ( Main board )

Block No. 01

▲	Item	Parts number	Parts name	Remarks	Area
	C 701	QETN1HM-105Z	E CAPACITOR	1.0MF 20% 50V	
	C 702	QETN1HM-105Z	E CAPACITOR	1.0MF 20% 50V	
	C 703	QCS11HJ-101	C CAPACITOR	100PF 5% 50V	
	C 704	QCS11HJ-101	C CAPACITOR	100PF 5% 50V	
	C 707	QETN1CM-107Z	E CAPACITOR	100MF-20% 16V	
	C 708	QETN1CM-107Z	E CAPACITOR	100MF 20% 16V	
	C 709	QCS11HJ-100	C CAPACITOR	10PF 5% 50V	
	C 710	QCS11HJ-100	C CAPACITOR	10PF 5% 50V	
	C 719	QFLC1HJ-472Z	M CAPACITOR	4700PF 5% 50V	
	C 720	QFLC1HJ-472Z	M CAPACITOR	4700PF 5% 50V	
	C 741	QETN2AM-476Z	E CAPACITOR	.47MF 20% 100V	
	C 742	QETN2AM-476Z	E CAPACITOR	.47MF 20% 100V	
	C 743	QETN1EM-476Z	E CAPACITOR	.47MF 20% 25V	
	C 744	QCF31HZ-472Z	C CAPACITOR	.4700PF +80:-20%	
	C 751	QCS32HJ-470Z	C CAPACITOR	.47PF 5% 500V	
	C 752	QCS32HJ-470Z	C CAPACITOR	.47PF 5% 500V	
	C 753	QCS32HJ-470Z	C CAPACITOR	.47PF 5% 500V	
	C 754	QCS32HJ-470Z	C CAPACITOR	.47PF 5% 500V	
	C 791	QFLC1HJ-473Z	M CAPACITOR	.047MF 5% 50V	
	C 792	QFLC1HJ-473Z	M CAPACITOR	.047MF 5% 50V	
	C 793	QFLC1HJ-473Z	M CAPACITOR	.047MF 5% 50V	
	C 794	QFLC1HJ-473Z	M CAPACITOR	.047MF 5% 50V	
	C 801	QCE22HP-103	C CAPACITOR	.010MF +100:-0%	
	C 802	QCE22HP-103	C CAPACITOR	.010MF +100:-0%	
	C 805	QCE22HP-103	C CAPACITOR	.010MF +100:-0%	
	C 807	QEZO490-129	E CAPACITOR	12000MF	
	C 808	QEZO490-129	E CAPACITOR	12000MF	
	C 821	QEHC1EM-107Z	E CAPACITOR	100MF 20% 25V	
	C 822	QCF31HZ-472Z	C CAPACITOR	4700PF +80:-20%	
	C 831	QEHC1EM-107Z	E CAPACITOR	100MF 20% 25V	
	C 832	QCF31HZ-472Z	C CAPACITOR	4700PF +80:-20%	
	C 841	QEHC1EM-107Z	E CAPACITOR	100MF 20% 25V	
	C 842	QCF31HZ-472Z	C CAPACITOR	4700PF +80:-20%	
	C 851	QEHC1EM-107Z	E CAPACITOR	100MF 20% 25V	
	C 852	QCF31HZ-472Z	C CAPACITOR	4700PF +80:-20%	
	C 861	QEHC1EM-107Z	E CAPACITOR	100MF 20% 25V	
	C 862	QCF31HZ-472Z	C CAPACITOR	4700PF +80:-20%	
	C 871	QEHC1EM-107Z	E CAPACITOR	100MF 20% 25V	
	C 872	QCF31HZ-472Z	C CAPACITOR	4700PF +80:-20%	
	C 875	QETN0JM-477Z	E CAPACITOR	470MF 20% 6.3V	
	C 903	QER61HM-226Z	E CAPACITOR	22MF 20% 50V	
	C 904	QCF11HZ-103	C CAPACITOR	.010MF +80:-20%	
	C 905	QCB31HK-102Z	C CAPACITOR	1000PF 10% 50V	
	C 906	QETN1EM-476Z	E CAPACITOR	47MF 20% 25V	
	C 920	QETN1HM-226Z	E CAPACITOR	22MF 20% 50V	
	C 921	QER61CM-107Z	E CAPACITOR	100MF 20% 16V	
CN 81	QGB2510J1-08	CONNECTOR			
CN 82	QGB2510J1-08	CONNECTOR			
CN 83	QGB2510J1-05	CONNECTOR			
CN101	QGB2501J1-12	CONNECTOR			
CN201	QGB2510J1-05	CONNECTOR			
CN241	QGB2510J1-04	CONNECTOR			
CN255	QGB2510J1-05	CONNECTOR			
CN301	QGB2510J1-17	CONNECTOR			
CN302	QGB2510J1-09	CONNECTOR			
CN303	QGB2510J1-12	CONNECTOR			
CN342	QGB2510J1-08	CONNECTOR			
CN400	QGF1205C1-27	CONNECTOR			
CN452	QGB2510J1-09	CONNECTOR			
CN501	QGB1214J3-18S	CONNECTOR			
CN601	QGB1214J3-12S	CONNECTOR			
CN704	QGA3901C1-08	8P CONNECTOR			
CN706	QGB2510J1-12	CONNECTOR			
CN711	QGA2501C1-02	2P CONNECTOR			
CN712	QGA2501C1-03	3P CONNECTOR			
CN801	QJK012-032803	SKT WIRE ASSY			
CN821	QGD2501C1-05Z	SOCKET			

▲	Item	Parts number	Parts name	Remarks	Area
	CN901	QGD2501C1-03Z	SOCKET		
	CN931	QGD2501C1-04Z	SOCKET		
	CN932	QGD2501C1-03Z	SOCKET		
	CN961	QGD2501C1-03Z	SOCKET		
	C1301	QETN1EM-476Z	E CAPACITOR	.47MF 20% 25V	
	C1302	QETN1EM-476Z	E CAPACITOR	.47MF 20% 25V	
	C1309	QFVJ1HJ-224Z	CAPACITOR	.22MF 5% 50V	
	C1310	QFVJ1HJ-224Z	CAPACITOR	.22MF 5% 50V	
	C1311	QETN1HM-475Z	E CAPACITOR	.47MF 20% 50V	
	C1312	QETN1HM-475Z	E CAPACITOR	.47MF 20% 50V	
	C1313	QETN1HM-475Z	E CAPACITOR	.47MF 20% 50V	
	C1314	QETN1HM-475Z	E CAPACITOR	.47MF 20% 50V	
	C1315	QETN1EM-476Z	E CAPACITOR	.47MF 20% 25V	
	C1316	QETN1EM-476Z	E CAPACITOR	.47MF 20% 25V	
	C1319	QCBB1HK-221Y	C CAPACITOR	.220PF 10% 50V	
	C1321	QETN1HM-475Z	E CAPACITOR	.47MF 20% 50V	
	C1322	QETN1HM-475Z	E CAPACITOR	.47MF 20% 50V	
	C1323	QETN1HM-475Z	E CAPACITOR	.47MF 20% 50V	
	C1324	QETN1HM-475Z	E CAPACITOR	.47MF 20% 50V	
	C1325	QETN1EM-476Z	E CAPACITOR	.47MF 20% 25V	
	C1326	QETN1EM-476Z	E CAPACITOR	.47MF 20% 25V	
	C1329	QCBB1HK-221Y	C CAPACITOR	.220PF 10% 50V	
	C1331	QETN1HM-475Z	E CAPACITOR	.47MF 20% 50V	
	C1332	QETN1HM-475Z	E CAPACITOR	.47MF 20% 50V	
	C1333	QETN1HM-475Z	E CAPACITOR	.47MF 20% 50V	
	C1334	QETN1HM-475Z	E CAPACITOR	.47MF 20% 50V	
	C1335	QETN1EM-476Z	E CAPACITOR	.47MF 20% 25V	
	C1336	QETN1EM-476Z	E CAPACITOR	.47MF 20% 25V	
	C1339	QCBB1HK-221Y	C CAPACITOR	.220PF 10% 50V	
	C1361	QETN1HM-106Z	E CAPACITOR	10MF 20% 50V	
	C1362	QETN1HM-106Z	E CAPACITOR	10MF 20% 50V	
	C1369	QETN1EM-476Z	E CAPACITOR	.47MF 20% 25V	
	C1370	QETN1EM-476Z	E CAPACITOR	.47MF 20% 25V	
	C1371	QETN1HM-106Z	E CAPACITOR	10MF 20% 50V	
	C1372	QETN1HM-106Z	E CAPACITOR	10MF 20% 50V	
	C1379	QETN1EM-476Z	E CAPACITOR	.47MF 20% 25V	
	C1380	QETN1EM-476Z	E CAPACITOR	.47MF 20% 25V	
	C1381	QETN1HM-106Z	E CAPACITOR	10MF 20% 50V	
	C1382	QETN1HM-106Z	E CAPACITOR	10MF 20% 50V	
	C1389	QETN1EM-476Z	E CAPACITOR	.47MF 20% 25V	
	C1390	QETN1EM-476Z	E CAPACITOR	.47MF 20% 25V	
	C1391	QFLC1HJ-562Z	M CAPACITOR	.5600PF 5% 50V	
	C1392	QFLC1HJ-562Z	M CAPACITOR	.5600PF 5% 50V	
	C1405	QETN1CM-226Z	E CAPACITOR	22MF 20% 16V	
	C1406	QENC1HM-106Z	NP E CAPACITOR	10MF 20% 50V	
	C1744	QCF31HZ-472Z	C CAPACITOR	.4700PF +80:-20%	
	C1844	QCF31HZ-472Z	C CAPACITOR	.4700PF +80:-20%	
D 741	MTZJ10C-T2	Z DIODE			
D 742	MTZJ16C-T2	Z DIODE			
D 743	MTZJ18C-T2	Z DIODE			
D 771	1SS133-T2	SI DIODE			
D 772	1SS133-T2	SI DIODE			
D 773	1SS133-T2	SI DIODE			
D 774	1SS133-T2	SI DIODE			
D 781	1SS133-T2	SI DIODE			
D 782	1SS133-T2	SI DIODE			
▲ D 801	30DF2-FC	DIODE			
▲ D 802	30DF2-FC	DIODE			
▲ D 803	30DF2-FC	DIODE			
▲ D 804	30DF2-FC	DIODE			
D 821	MTZJ6.8C-T2	Z DIODE			
D 822	1SS133-T2	SI DIODE			
D 831	MTZJ6.2C-T2	Z DIODE			
D 832	1SS133-T2	SI DIODE			
D 841	MTZJ6.2C-T2	Z DIODE			
D 842	1SS133-T2	SI DIODE			
D 851	MTZJ15C-T2	Z DIODE			

# RX-8000VBK

## ■ Electrical parts list ( Main board )

Block No. 01

▲	Item	Parts number	Parts name	Remarks	Area
	D 852	1SS133-T2	SI DIODE		
	D 861	MTZJ15C-T2	Z DIODE		
	D 862	1SS133-T2	SI DIODE		
	D 871	MTZJ10C-T2	Z.DIODE		
	D 872	1SS133-T2	SI DIODE		
	D 901	1SS133-T2	SI DIODE		
	D 902	1SS133-T2	SI DIODE		
	D 921	MTZJ4.7B-T2	Z DIODE		
	D 931	1SS133-T2	SI DIODE		
	D 932	1SS133-T2	SI DIODE		
	D 933	1SS133-T2	SI DIODE		
	D 934	1SS133-T2	SI DIODE		
	D 953	1SS133-T2	SI DIODE		
	D 954	1SS133-T2	SI DIODE		
	D 971	1SS133-T2	SI DIODE		
	D 972	1SS133-T2	SI DIODE		
	D1435	1SS133-T2	SI DIODE		
	D1436	1SS133-T2	SI DIODE		
	D1437	MTZJ4.7B-T2	Z DIODE		
	D1438	1SS133-T2	SI DIODE		
	D1741	MTZJ10C-T2	Z DIODE		
	D1742	MTZJ15C-T2	Z DIODE		
	D1841	MTZJ10C-T2	Z DIODE		
	D1842	MTZJ15C-T2	Z DIODE		
	EP801	QNZ0136-001Z	EARTH PLATE		
	FL391	QQR0590-001	FILTER		
	FL392	QQR0590-001	FILTER		
	FW811	QUM133-10Z4Z4	PARA RIBON WIRE		
	FW821	QUM135-08DGZ4	PARA RIBON WIRE		
	FW881	QUM133-26DGZ4	PARA RIBON WIRE		
	FW931	QUM137-16DGZ4	PARA RIBON WIRE		
	HL331	VYH7653-002	IC HOLDER		
	HL332	VYH7653-002	IC HOLDER		
	HL333	VYH7653-002	IC HOLDER		
▲	HS851	E70306-001	HEAT SINK		
▲	HS861	E70306-001	HEAT SINK		
▲	HS871	E70306-001	HEAT SINK		
	IC321	TC9162AN	IC		
	IC331	TC9459F	IC		
	IC332	TC9459F	IC		
	IC333	TC9459F	IC		
	IC361	NJM4580L	IC		
	IC362	BA15218N	IC		
	IC363	BA15218N	IC		
	IC781	VC5022-2	IC		
	IC782	VC5022-2	IC		
	IC901	TA7317P	IC		
	L 791	QQLZ003-1R0	INDUCTOR		
	L 792	QQLZ003-1R0	INDUCTOR		
▲	Q 741	2SD2394/EF/	TRANSISTOR		
	Q 742	2SC2240/GL-T	TRANSISTOR		
	Q 751	2SC2389S/S-T	TRANSISTOR		
	Q 752	2SC2389S/S-T	TRANSISTOR		
	Q 753	2SA1038S/S-T	TRANSISTOR		
	Q 754	2SA1038S/S-T	TRANSISTOR		
	Q 755	2SD669A/BC/	TRANSISTOR		
	Q 756	2SD669A/BC/	TRANSISTOR		
	Q 757	2SB649A/BC/	TRANSISTOR		
	Q 758	2SB649A/BC/	TRANSISTOR		
	Q 771	2SC2389S/SE/-T	TRANSISTOR		
	Q 772	2SC2389S/SE/-T	TRANSISTOR		
	Q 773	2SA1038S/SE/-T	TRANSISTOR		
	Q 774	2SA1038S/SE/-T	TRANSISTOR		
	Q 781	2SD637/QR/	TRANSISTOR		
	Q 782	2SD637/QR/	TRANSISTOR		
▲	Q 821	2SD2061/EF/	TRANSISTOR		
▲	Q 831	2SD2061/EF/	TRANSISTOR		

▲	Item	Parts number	Parts name	Remarks	Area
	Q 841	2SD2061/EF/	TRANSISTOR		
	Q 851	2SD2061/EF/	TRANSISTOR		
	Q 861	2SB1187/EF/	TRANSISTOR		
	Q 871	2SD2061/EF/	TRANSISTOR		
	Q 901	2SC2389S/SE/-T	TRANSISTOR		
	Q 902	2SC2389S/SE/-T	TRANSISTOR		
	Q 903	2SA1038S/SE/-T	TRANSISTOR		
	Q 921	KTC3199/GL-T	TRANSISTOR		
	Q 931	KRC105M-T	D.TRANSISTOR		
	Q 932	KRC105M-T	D.TRANSISTOR		
	Q 951	KRC105M-T	D.TRANSISTOR		
	Q 952	KRC105M-T	D.TRANSISTOR		
	Q1401	2SC2878/AB/-T	TRANSISTOR		
	Q1402	2SC2878/AB/-T	TRANSISTOR		
	Q1405	KRA104M-T	D.TRANSISTOR		
	Q1411	2SC2878/AB/-T	TRANSISTOR		
	Q1421	2SC2878/AB/-T	TRANSISTOR		
	Q1422	2SC2878/AB/-T	TRANSISTOR		
	Q1435	KTA1267/YG-T	TRANSISTOR		
	Q1438	KRA104M-T	D.TRANSISTOR		
▲	Q1741	2SD2394/EF/	TRANSISTOR		
	Q1742	2SC2240/GL-T	TRANSISTOR		
▲	Q1841	2SD2394/EF/	TRANSISTOR		
	Q1842	2SC2240/GL-T	TRANSISTOR		
	R 701	QRE141J-222Y	C RESISTOR	2.2K 5% 1/4W	
	R 702	QRE141J-222Y	C RESISTOR	2.2K 5% 1/4W	
	R 703	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
	R 704	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
	R 711	QRE141J-621Y	C RESISTOR	620 5% 1/4W	
	R 712	QRE141J-621Y	C RESISTOR	620 5% 1/4W	
	R 713	QRE141J-183Y	C RESISTOR	18K 5% 1/4W	
	R 714	QRE141J-183Y	C RESISTOR	18K 5% 1/4W	
	R 715	QRE141J-823Y	C RESISTOR	82K 5% 1/4W	
	R 716	QRE141J-823Y	C RESISTOR	82K 5% 1/4W	
▲	R 741	QRJ146J-120X	UNF C RESISTOR	12.5% 1/4W	
▲	R 742	QRJ146J-120X	UNF C RESISTOR	12.5% 1/4W	
▲	R 743	QRJ146J-562	UNF.OMF.RESISTO	5.6K 5% 1/2W	
▲	R 744	QRK126J-103X	UNF C RESISTOR	10K 5% 1/2W	
	R 745	QRE141J-473Y	C RESISTOR	47K 5% 1/4W	
	R 746	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
▲	R 751	QRJ146J-100X	UNF C RESISTOR	10.5% 1/4W	
▲	R 752	QRJ146J-100X	UNF C RESISTOR	10.5% 1/4W	
▲	R 753	QRJ146J-100X	UNF C RESISTOR	10.5% 1/4W	
▲	R 754	QRJ146J-100X	UNF C RESISTOR	10.5% 1/4W	
▲	R 759	QRJ146J-272X	UNF C RESISTOR	2.7K 5% 1/4W	
▲	R 760	QRJ146J-272X	UNF C RESISTOR	2.7K 5% 1/4W	
▲	R 761	QRJ146J-4R7X	UNF C RESISTOR	4.7.5% 1/4W	
▲	R 762	QRJ146J-4R7X	UNF C RESISTOR	4.7.5% 1/4W	
▲	R 763	QRJ146J-4R7X	UNF C RESISTOR	4.7.5% 1/4W	
▲	R 764	QRJ146J-4R7X	UNF C RESISTOR	4.7.5% 1/4W	
	R 765	QRJ146J-120X	UNF C RESISTOR	12.5% 1/4W	
	R 766	QRJ146J-120X	UNF C RESISTOR	12.5% 1/4W	
	R 767	QRJ146J-120X	UNF C RESISTOR	12.5% 1/4W	
	R 768	QRJ146J-120X	UNF C RESISTOR	12.5% 1/4W	
	R 769	QRJ146J-271X	UNF C RESISTOR	270 5% 1/4W	
▲	R 770	QRJ146J-271X	UNF C RESISTOR	270 5% 1/4W	
	R 771	QRE141J-561Y	C RESISTOR	560 5% 1/4W	
	R 772	QRE141J-561Y	C RESISTOR	560 5% 1/4W	
	R 773	QRE141J-561Y	C RESISTOR	560 5% 1/4W	
	R 774	QRE141J-561Y	C RESISTOR	560 5% 1/4W	
	R 775	QRE141J-201Y	C RESISTOR	200 5% 1/4W	
	R 776	QRE141J-201Y	C RESISTOR	200 5% 1/4W	
	R 777	QRE141J-201Y	C RESISTOR	200 5% 1/4W	
	R 778	QRE141J-201Y	C RESISTOR	200 5% 1/4W	
▲	R 779	QRZ0196-R22	EMIT.RESISTOR	1/1W	
▲	R 780	QRZ0196-R22	EMIT.RESISTOR	1/1W	
	R 781	QRE141J-391Y	C RESISTOR	390 5% 1/4W	

## ■ Electrical parts list ( Main board )

Block No. 01

▲ Item	Parts number	Parts name	Remarks	Area
R 782	QRE141J-391Y	C RESISTOR	390 5% 1/4W	
R 783	QRE141J-471Y	C RESISTOR	470 5% 1/4W	
R 784	QRE141J-471Y	C RESISTOR	470 5% 1/4W	
R 785	QRE141J-101Y	C RESISTOR	100 5% 1/4W	
R 786	QRE141J-101Y	C RESISTOR	100 5% 1/4W	
▲ R 791	QRJ125J-330	UNF C RESISTOR	33 5% 1/2W	
▲ R 792	QRJ125J-330	UNF C RESISTOR	33 5% 1/2W	
▲ R 793	QRL022J-100	UNF.OMF.RESISTO	10 5% 1/2W	
▲ R 794	QRL022J-100	UNF.OMF.RESISTO	10 5% 1/2W	
R 801	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
R 802	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
▲ R 823	QRJ146J-122X	UNF C RESISTOR	1.2K 5% 1/4W	
▲ R 833	QRJ146J-122X	UNF C RESISTOR	1.2K 5% 1/4W	
▲ R 843	QRJ146J-122X	UNF C RESISTOR	1.2K 5% 1/4W	
▲ R 851	QRK126J-120X	UNF C RESISTOR	12 5% 1/2W	
▲ R 853	QRJ146J-222X	UNF C RESISTOR	2.2K 5% 1/4W	
▲ R 861	QRK126J-120X	UNF C RESISTOR	12 5% 1/2W	
▲ R 863	QRJ146J-222X	UNF C RESISTOR	2.2K 5% 1/4W	
▲ R 871	QRJ146J-120X	UNF C RESISTOR	12 5% 1/4W	
▲ R 873	QRJ146J-332X	UNF C RESISTOR	3.3K 5% 1/4W	
▲ R 875	QRZ9005-220X	F RESISTOR	22 1/0W	
R 901	QRE141J-272Y	C RESISTOR	2.7K 5% 1/4W	
R 902	QRE141J-272Y	C RESISTOR	2.7K 5% 1/4W	
R 903	QRE141J-153Y	C RESISTOR	15K 5% 1/4W	
R 904	QRE141J-153Y	C RESISTOR	15K 5% 1/4W	
R 905	QRE141J-123Y	C RESISTOR	12K 5% 1/4W	
R 906	QRE141J-123Y	C RESISTOR	12K 5% 1/4W	
R 909	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
R 911	QRE141J-332Y	C RESISTOR	3.3K 5% 1/4W	
R 912	QRE141J-473Y	C RESISTOR	47K 5% 1/4W	
R 913	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
R 914	QRE141J-823Y	C RESISTOR	82K 5% 1/4W	
R 915	QRE141J-823Y	C RESISTOR	82K 5% 1/4W	
R 916	QRE141J-563Y	C RESISTOR	56K 5% 1/4W	
R 917	QRE141J-683Y	C RESISTOR	68K 5% 1/4W	
R 918	QRE141J-822Y	C RESISTOR	8.2K 5% 1/4W	
R 919	QRE141J-822Y	C RESISTOR	8.2K 5% 1/4W	
R 920	QRE141J-224Y	C RESISTOR	220K 5% 1/4W	
R 921	QRE141J-473Y	C RESISTOR	47K 5% 1/4W	
R 922	QRE141J-222Y	C RESISTOR	2.2K 5% 1/4W	
▲ R 931	QRJ146J-120X	UNF C RESISTOR	12 5% 1/4W	
▲ R 932	QRJ146J-120X	UNF C RESISTOR	12 5% 1/4W	
▲ R 971	QRJ146J-120X	UNF C RESISTOR	12 5% 1/4W	
▲ RY931	QSK0042-001	RELAY		
▲ RY932	QSK0042-001	RELAY		
▲ RY971	QSK0057-001	RELAY		
R1301	QRE141J-222Y	C RESISTOR	2.2K 5% 1/4W	
R1302	QRE141J-222Y	C RESISTOR	2.2K 5% 1/4W	
R1303	QRE141J-272Y	C RESISTOR	2.7K 5% 1/4W	
R1304	QRE141J-272Y	C RESISTOR	2.7K 5% 1/4W	
R1305	QRE141J-122Y	C RESISTOR	1.2K 5% 1/4W	
R1306	QRE141J-122Y	C RESISTOR	1.2K 5% 1/4W	
▲ R1309	QRZ9005-680X	F RESISTOR	68 1/0W	
▲ R1310	QRZ9005-680X	F RESISTOR	68 1/0W	
▲ R1311	QRZ9005-680X	F RESISTOR	68 1/0W	
▲ R1312	QRZ9005-680X	F RESISTOR	68 1/0W	
R1313	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
R1314	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
▲ R1321	QRZ9005-680X	F RESISTOR	68 1/0W	
▲ R1322	QRZ9005-680X	F RESISTOR	68 1/0W	
R1323	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
R1324	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
▲ R1331	QRZ9005-680X	F RESISTOR	68 1/0W	
▲ R1332	QRZ9005-680X	F RESISTOR	68 1/0W	
R1333	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
R1334	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
R1361	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	

▲ Item	Parts number	Parts name	Remarks	Area
R1362	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
R1363	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
R1364	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
R1365	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
R1366	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
▲ R1369	QRZ9005-680X	F RESISTOR	68 1/0W	
▲ R1370	QRZ9005-680X	F RESISTOR	68 1/0W	
R1371	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
R1372	QRE141J-153Y	C RESISTOR	15K 5% 1/4W	
R1373	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
R1374	QRE141J-512Y	C RESISTOR	5.1K 5% 1/4W	
R1375	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
R1376	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
▲ R1379	QRZ9005-680X	F RESISTOR	68 1/0W	
▲ R1380	QRZ9005-680X	F RESISTOR	68 1/0W	
R1381	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
R1382	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
R1383	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
R1384	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
R1385	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
R1386	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
▲ R1389	QRZ9005-680X	F RESISTOR	68 1/0W	
▲ R1390	QRZ9005-680X	F RESISTOR	68 1/0W	
R1391	QRE141J-472Y	C RESISTOR	4.7K 5% 1/4W	
R1392	QRE141J-472Y	C RESISTOR	4.7K 5% 1/4W	
R1401	QRE141J-102Y	C RESISTOR	1.0K 5% 1/4W	
R1402	QRE141J-102Y	C RESISTOR	1.0K 5% 1/4W	
R1403	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
R1404	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
R1405	QRE141J-102Y	C RESISTOR	1.0K 5% 1/4W	
R1406	QRE141J-474Y	C RESISTOR	470K 5% 1/4W	
R1411	QRE141J-102Y	C RESISTOR	1.0K 5% 1/4W	
R1412	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
R1421	QRE141J-102Y	C RESISTOR	1.0K 5% 1/4W	
R1422	QRE141J-102Y	C RESISTOR	1.0K 5% 1/4W	
R1423	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
R1424	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
R1435	QRE141J-683Y	C RESISTOR	68K 5% 1/4W	
R1436	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
R1437	QRE141J-474Y	C RESISTOR	470K 5% 1/4W	
R1438	QRE141J-474Y	C RESISTOR	470K 5% 1/4W	
▲ R1741	QRJ146J-511X	UNF C RESISTOR	510 5% 1/4W	
▲ R1744	QRK126J-103X	UNF C RESISTOR	10K 5% 1/2W	
R1745	QRE141J-473Y	C RESISTOR	47K 5% 1/4W	
R1746	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
▲ R1841	QRJ146J-241X	UNF C RESISTOR	240 6% 1/4W	
▲ R1844	QRK126J-103X	UNF C RESISTOR	10K 5% 1/2W	
R1845	QRE141J-473Y	C RESISTOR	47K 5% 1/4W	
R1846	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
S 931	QSW0509-001	SLIDE SW.		
ST931	QNB0048-001	SPK.TERMINAL		
▲ TH781	QAD0010-351	THERMISTOR		
▲ TH782	QAD0010-351	THERMISTOR		
TP781	QMV8005-004K	4P PLUG ASSY		
VR787	QVP0004-501Z	SEMI.V.RESISTOR		
VR788	QVP0004-501Z	SEMI.V.RESISTOR		

# RX-8000VBK

## ■ Electrical parts list ( Front board )

Block No. 02

A	Item	Parts number	Parts name	Remarks	Area
	BK400	E308566-001SM	F.L.HOLDER		
	BK401	E308566-002SM	F.L.HOLDER		
	BK499	E70225-003SS	EARTH PLATE		
C 400	QEKC1HM-475Z	E CAPACITOR	4.7MF 20% 50V		
C 401	QEKC0JM-107Z	E CAPACITOR	100MF 20% 6.3V		
C 402	QCZ0202-155Z	ML C CAPCITOR	1.5MF		
C 403	QEZ0227-10AZ	EDL.CAPACITOR	PF		
C 404	QER61HM-225Z	E CAPACITOR	2.2MF 20% 50V		
C 406	QCBB1HK-331Y	C CAPACITOR	330PF 10% 50V		
C 407	QCZ0202-155Z	ML C CAPCITOR	1.5MF		
C 408	QFVJ1HJ-104Z	TF CAPACITOR	.10MF 5% 50V		
C 409	QEKC1HM-475Z	E CAPACITOR	4.7MF 20% 50V		
C 410	QEKC1HM-475Z	E CAPACITOR	4.7MF 20% 50V		
C 412	QEKC0JM-107Z	E CAPACITOR	100MF 20% 6.3V		
C 413	QDYB1CM-103Y	C CAPACITOR			
C 414	QDYB1CM-103Y	C CAPACITOR			
C 477	QCBB1HK-471Y	C CAPACITOR	470PF 10% 50V		
C 478	QCBB1HK-471Y	C CAPACITOR	470PF 10% 50V		
C 479	QCBB1HK-471Y	C CAPACITOR	470PF 10% 50V		
C 480	QCBB1HK-471Y	C CAPACITOR	470PF 10% 50V		
C 491	QCFB1HZ-104Y	C CAPACITOR	.10MF+80:-20%		
C 492	QCBB1HK-101Y	C CAPACITOR	100PF 10% 50V		
C 493	QCBB1HK-271Y	C CAPACITOR	270PF 10% 50V		
C 494	QDVB1EZ-223Y	C CAPACITOR			
C 497	QDVB1EZ-223Y	C CAPACITOR			
C 498	QFVJ1HJ-104Z	TF CAPACITOR	.10MF 5% 50V		
C 499	QEKC0JM-107Z	E CAPACITOR	100MF 20% 6.3V		
CN 61	QGB2510K1-08	CONNECTOR			
CN 62	QGB2510K1-08	CONNECTOR			
CN 63	QGB2510K1-05	CONNECTOR			
CN 71	QGB2510K1-08	CONNECTOR			
CN 72	QGB2510K1-08	CONNECTOR			
CN 73	QGB2510K1-05	CONNECTOR			
CN341	QGB2510K1-08	CONNECTOR			
CN406	WJP0003-001A	SKT WIRE ASSY	(VIDEO)		
CN410	QGF1205F1-27	CONNECTOR			
CN412	QGF1210G1-21	CONNECTOR			
CN420	QJK018-100800	SKT WIRE	(LEFT)		
CN422	QGA2001F1-14	14P PLUG ASSY			
CN430	QGA2001F1-10	10P PLUG ASSY			
CN432	QJK018-140804	SKT WIRE ASSY			
CN450	QJK021-104000	C-B WIRE ASSY	(VIDEO)		
CN451	QGB2510K1-09	CONNECTOR			
CN881	QGD2501C1-03Z	SOCKET I.M			
C1341	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V		
C1342	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V		
C1343	QCS11HJ-101	C CAPACITOR	100PF 5% 50V		
C1346	QFLC1HJ-103Z	M CAPACITOR	.010MF 5% 50V		
C1347	QFLC1HJ-123Z	M CAPACITOR	.012MF 5% 50V		
C1349	QETN1EM-476Z	E CAPACITOR	47MF 20% 25V		
C1350	QETN1EM-476Z	E CAPACITOR	47MF 20% 25V		
C1351	QETN1EM-476Z	E CAPACITOR	47MF 20% 25V		
C1352	QETN1EM-476Z	E CAPACITOR	47MF 20% 25V		
C1355	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V		
C1356	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V		
C1451	QER61HM-475Z	E CAPACITOR	4.7MF 20% 50V		
C1452	QER61HM-475Z	E CAPACITOR	4.7MF 20% 50V		
C1453	QCS11HJ-101	C CAPACITOR	100PF 5% 50V		
C1454	QCS11HJ-101	C CAPACITOR	100PF 5% 50V		
C1455	QER61HM-475Z	E CAPACITOR	4.7MF 20% 50V		
C1456	QER61HM-475Z	E CAPACITOR	4.7MF 20% 50V		
C1457	QER61HM-475Z	E CAPACITOR	4.7MF 20% 50V		
C1458	QER61HM-475Z	E CARAGITOR	4.7MF 20% 50V		
C1459	QER61HM-475Z	E CAPACITOR	4.7MF 20% 50V		
C1460	QER61HM-475Z	E CAPACITOR	4.7MF 20% 50V		
C1461	QETN1EM-476Z	E CAPACITOR	47MF 20% 25V		
C1462	QETN1EM-476Z	E CAPACITOR	47MF 20% 25V		

A	Item	Parts number	Parts name	Remarks	Area
	C1465	QETN1EM-476Z	E CAPACITOR	47MF 20% 25V	
	C1469	QCS11HJ-470	C CAPACITOR	47PF 5% 50V	
	C1470	QCS11HJ-470	C CAPACITOR	47PF 5% 50V	
	C1471	QFVJ1HJ-333Z	CAPACITOR	.033MF 5% 50V	
	C1472	QFVJ1HJ-333Z	CAPACITOR	.033MF 5% 50V	
	C1473	QER41HM-105	E CAPACITOR	1.0MF 20% 50V	
	C1474	QER41HM-105	E CAPACITOR	1.0MF 20% 50V	
	C1475	QFLC1HJ-332Z	M CAPACITOR	3300PF 5% 50V	
	C1476	QFLC1HJ-332Z	M CAPACITOR	3300PF 5% 50V	
	C1477	QFVJ1HJ-104Z	TF CAPACITOR	.10MF 5% 50V	
	C1478	QFVJ1HJ-104Z	TF CAPACITOR	.10MF 5% 50V	
	C1479	QCS11HJ-331Z	C CAPACITOR	330PF 5% 50V	
	C1480	QCS11HJ-331Z	C CAPACITOR	330PF 5% 50V	
	C1481	QFLC1HJ-103Z	M CAPACITOR	.010MF 5% 50V	
	C1482	QFLC1HJ-103Z	M CAPACITOR	.010MF 5% 50V	
	C1483	QER61HM-475Z	E CAPACITOR	4.7MF 20% 50V	
	C1484	QER61HM-475Z	E CAPACITOR	4.7MF 20% 50V	
	C1487	QETN1EM-476Z	E CAPACITOR	47MF 20% 25V	
	D 400	1SR35-400A-T5	DIODE		
	D 401	1SR35-400A-T5	DIODE		
	D 402	1SR35-400A-T5	DIODE		
	D 404	1SS133-T2	SI DIODE		
	D 405	1SS133-T2	SI DIODE		
	D 406	1SS133-T2	SI DIODE		
	D 407	1SS133-T2	SI DIODE		
	D 408	1SS133-T2	SI DIODE		
	D 409	1SS133-T2	SI DIODE		
	D 410	1SS133-T2	SI DIODE		
	D 411	1SS133-T2	SI DIODE		
	D 412	1SS133-T2	SI DIODE		
	D 413	1SS133-T2	SI DIODE		
	D 418	1SS133-T2	SI DIODE		
	D 420	1SS133-T2	SI DIODE		
	D 430	SLR-342VC-T	LED	(DVD)	
	D 431	SLR-342VC-T	LED	(TV)	
	D 432	SLR-342VC-T	LED	(VCR1)	
	D 433	SLR-342VC-T	LED	(VCR2)	
	D 434	SLR-342VC-T	LED	(VIDEO)	
	D 435	SLR-342VC-T	LED	(AM)	
	D 436	SLR-342VC-T	LED	(FM)	
	D 437	SLR-342VC-T	LED	(TAPE)	
	D 438	SLR-342VC-T	LED	(PHONO)	
	D 439	SLR-342VC-T	LED	(CD)	
	D 440	SLR-342VC-T	LED	(SURROUND)	
	D 442	SLR-342VC-T	LED	(OTO)	
	D 481	SLR-342VC-T	LED	(STANDBY)	
	D 482	SLR-342VC-T	LED	(SPK1)	
	D 483	SPR-325MVW/L-T	LED	(SPK2)	
	D 493	1SS133-T2	SI DIODE		
	D 490	QLF0071-001	FL TUBE		
	D 1351	MTZJ5.1C-T2	ZENER DIODE		
	D 1352	MTZJ6.1C-T2	ZENER DIODE		
	D 1451	MTZJ6.8C-T2	Z DIODE		
	D 1452	MTZJ6.8C-T2	Z DIODE		
	D 1453	MTZJ5.1C-T2	ZENER DIODE		
	FS400	E3400444	FELT SPACER		
	FS401	E3400-444	FELT SPACER		
	HL400	VYH7653-001	IC HOLDER		
	HL401	VYH7237-003	IC HOLDER		
	IC341	BU4081BC	IC		
	IC342	BA15218N	IC		
	IC343	BA15218N	IC		
	IC400	MN173222DG	IC	MP	
	IC401	MN103C15FDE	IC	MP	
	IC402	BU2082	IC		
	IC403	IC-PST9139-T	IC		

## ■ Electrical parts list ( Front board )

Block No. 02

▲	Item	Parts number	Parts name	Remarks	Area
	IC404	GP1U271X	RM RECIVER		
	IC405	BU2092	IC		
	IC451	LC7522	IC		
	IC452	M5243AP12	IC		
	IC453	BA15218N	IC		
	J 400	QND0026-001	S JACK		
	JS400	QSW0502-001	SW		
	JS401	QSW0672-001	ROTARY ENCODER	(MULTI)	
	JS402	QSW0672-001	ROTARY ENCODER	(SOURCE)	
	Q 401	KRC107M-T	D.TRANSISTOR		
	Q 402	KRC111M-T	TRANSISTOR		
	Q 403	KRC109M-T	D.TRANSISTOR		
	Q 404	KRC107M-T	D.TRANSISTOR		
	Q 405	KRC104M-T	D.TRANSISTOR		
	Q 406	KRC107M-T	D.TRANSISTOR		
	Q 407	KRC107M-T	D.TRANSISTOR		
	Q 408	KRC107M-T	D.TRANSISTOR		
	Q 413	KRA107M-T	D.TRANSISTOR		
	Q 414	KRA107M-T	D.TRANSISTOR		
	Q 415	KRA107M-T	D.TRANSISTOR		
	Q 416	KRA107M-T	D.TRANSISTOR		
	Q 442	KRA107M-T	D.TRANSISTOR		
	Q 488	KRA107M-T	D.TRANSISTOR		
	R 400	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
	R 401	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
	R 402	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
	R 403	QRE141J-331Y	C RESISTOR	330 5% 1/4W	
	R 404	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
	R 405	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
	R 406	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
	R 407	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
	R 408	QRE141J-223Y	C RESISTOR	22K 5% 1/4W	
	R 410	QRE141J-223Y	C RESISTOR	22K 5% 1/4W	
	R 411	QRE141J-472Y	C RESISTOR	4.7K 5% 1/4W	
	R 412	QRE141J-181Y	C RESISTOR	180 5% 1/4W	
	R 414	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
	R 415	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
	R 416	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
	R 417	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
	R 418	QRE141J-471Y	C RESISTOR	470 5% 1/4W	
	R 423	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
	R 424	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
	R 425	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
	R 426	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
	R 427	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
	R 430	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
	R 431	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
	R 433	QRE141J-221Y	C RESISTOR	220 5% 1/4W	
	R 434	QRE141J-221Y	C RESISTOR	220 5% 1/4W	
	R 435	QRE141J-221Y	C RESISTOR	220 5% 1/4W	
	R 436	QRE141J-102Y	C RESISTOR	1.0K 5% 1/4W	
	R 437	QRE141J-102Y	C RESISTOR	1.0K 5% 1/4W	
	R 438	QRE141J-102Y	C RESISTOR	1.0K 5% 1/4W	
	R 439	QRE141J-102Y	C RESISTOR	1.0K 5% 1/4W	
	R 440	QRE141J-474Y	C RESISTOR	470K 5% 1/4W	
	R 441	QRE141J-474Y	C RESISTOR	(PULLDOWN)	
	R 442	QRE141J-474Y	C RESISTOR	(PULLDOWN)	
	R 443	QRE141J-474Y	C RESISTOR	(PULLDOWN)	
	R 445	QRE141J-221Y	C RESISTOR	220 5% 1/4W	
	R 446	QRE141J-221Y	C RESISTOR	220 5% 1/4W	
	R 447	QRE141J-221Y	C RESISTOR	220 5% 1/4W	
	R 448	QRE141J-221Y	C RESISTOR	220 5% 1/4W	
	R 449	QRE141J-221Y	C RESISTOR	220 5% 1/4W	
	R 450	QRE141J-221Y	C RESISTOR	220 5% 1/4W	
	R 451	QRE141J-102Y	C RESISTOR	1.0K 5% 1/4W	
	R 452	QRE141J-102Y	C RESISTOR	1.0K 5% 1/4W	
	R 453	QRE141J-102Y	C RESISTOR	1.0K 5% 1/4W	

▲	Item	Parts number	Parts name	Remarks	Area
	R 454	QRE141J-102Y	C RESISTOR	1.0K 5% 1/4W	
	R 455	QRE141J-102Y	C RESISTOR	1.0K 5% 1/4W	
	R 456	QRE141J-102Y	C RESISTOR	1.0K 5% 1/4W	
	R 457	QRE141J-102Y	C RESISTOR	1.0K 5% 1/4W	
	R 458	QRE141J-102Y	C RESISTOR	1.0K 5% 1/4W	
	R 459	QRE141J-102Y	C RESISTOR	1.0K 5% 1/4W	
	R 460	QRE141J-221Y	C RESISTOR	220 5% 1/4W	
	R 461	QRE141J-221Y	C RESISTOR	220 5% 1/4W	
	R 462	QRE141J-102Y	C RESISTOR	1.0K 5% 1/4W	
	R 463	QRE141J-221Y	C RESISTOR	220 5% 1/4W	
	R 464	QRE141J-102Y	C RESISTOR	1.0K 5% 1/4W	
	R 465	QRE141J-102Y	C RESISTOR	1.0K 5% 1/4W	
	R 466	QRE141J-102Y	C RESISTOR	1.0K 5% 1/4W	
	R 468	QRE141J-271Y	C RESISTOR	270 5% 1/4W	
	R 471	QRE141J-750Y	C RESISTOR	75 5% 1/4W	
	R 472	QRE141J-750Y	C RESISTOR	75 5% 1/4W	
	R 474	QRE141J-750Y	C RESISTOR	75 5% 1/4W	
	R 475	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
	R 476	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
	R 477	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
	R 478	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
	R 479	QRE141J-102Y	C RESISTOR	1.0K 5% 1/4W	
	R 483	QRE141J-473Y	C RESISTOR	47K 5% 1/4W	
	R 484	QRE141J-331Y	C RESISTOR	330 5% 1/4W	
	R 485	QRE141J-221Y	C RESISTOR	220 5% 1/4W	
	R 487	QRE141J-331Y	C RESISTOR	330 5% 1/4W	
	R 488	QRE141J-331Y	C RESISTOR	330 5% 1/4W	
	R 495	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
	R 496	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
	R 497	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
	R 498	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
	R 499	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
▲	R 881	QRZ0209-3R3	RESISTOR	3.3 1/2W	
▲	R 882	QRZ0209-3R3	RESISTOR	3.3 1/2W	
▲	R 883	QRZ0209-3R3	RESISTOR	3.3 1/2W	
▲	R 884	QRZ0209-3R3	RESISTOR	3.3 1/2W	
	R1341	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
	R1342	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
	R1343	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
	R1344	QRE141J-203Y	C RESISTOR	20K 5% 1/4W	
	R1345	QRE141J-273Y	C RESISTOR	27K 5% 1/4W	
	R1346	QRE141J-223Y	C RESISTOR	22K 5% 1/4W	
	R1347	QRE141J-132Y	C RESISTOR	1.3K 5% 1/4W	
	R1348	QRE141J-182Y	C RESISTOR	1.8K 5% 1/4W	
▲	R1349	QRZ9005-680X	F RESISTOR	68 1/0W	
▲	R1350	QRZ9005-680X	F RESISTOR	68 1/0W	
	R1351	QRE141J-222Y	C RESISTOR	2.2K 5% 1/4W	
	R1352	QRE141J-222Y	C RESISTOR	2.2K 5% 1/4W	
	R1353	QRE141J-682Y	C RESISTOR	6.8K 5% 1/4W	
	R1354	QRE141J-752Y	C RESISTOR	7.5K 5% 1/4W	
	R1355	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
	R1356	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
	R1357	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
	R1358	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
	R1359	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
	R1360	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
	R1451	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
	R1452	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
	R1453	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
	R1454	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
	R1455	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
	R1456	QRE141J-113Y	C RESISTOR	11K 5% 1/4W	
	R1461	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
	R1462	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
	R1463	QRE141J-333Y	C RESISTOR	33K 5% 1/4W	

# RX-8000VBK

## ■ Electrical parts list ( Front board )

Block No. 02

△	Item	Parts number	Parts name	Remarks	Area
	R1464	QRE141J-333Y	C RESISTOR	33K 5% 1/4W	
	R1465	QRE141J-124Y	C RESISTOR	120K 5% 1/4W	
	R1466	QRE141J-124Y	C RESISTOR	120K 5% 1/4W	
△	R1471	QRJ146J-561X	UNF C RESISTOR	560 5% 1/4W	
△	R1472	QRJ146J-561X	UNF C RESISTOR	560 5% 1/4W	
△	R1473	QRJ146J-681X	UNF C RESISTOR	680 5% 1/4W	
	R1475	QRE141J-474Y	C RESISTOR	470K 5% 1/4W	
	R1476	QRE141J-474Y	C RESISTOR	470K 5% 1/4W	
	R1477	QRE141J-474Y	C RESISTOR	470K 5% 1/4W	
	R1478	QRE141J-474Y	C RESISTOR	470K 5% 1/4W	
	R1479	QRE141J-474Y	C RESISTOR	470K 5% 1/4W	
	R1480	QRE141J-474Y	C RESISTOR	470K 5% 1/4W	
	R1481	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
	R1482	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
	R1483	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
	R1484	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
	R1485	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
	R1486	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
△	R1487	QRZ9005-680X	F RESISTOR	68 1/0W	
△	R1488	QRZ9005-680X	F RESISTOR	68 1/0W	
	S 400	QSW0683-001Z	PUSH SWITCH	(POWER)	
	S 401	QSW0683-001Z	PUSH SWITCH	(SPK1)	
	S 402	QSW0683-001Z	PUSH SWITCH	(SPK2)	
	S 407	QSW0683-001Z	PUSH SWITCH	(SURROUND)	
	S 408	QSW0683-001Z	PUSH SWITCH	(DIGITAL)	
	S 409	QSW0683-001Z	PUSH SWITCH	(DSP MODE)	
	S 410	QSW0683-001Z	PUSH SWITCH	(LOUDNESS)	
	S 411	QSW0683-001Z	PUSH SWITCH	(SEA MODE)	
	S 412	QSW0683-001Z	PUSH SWITCH	(SEA ADJ)	
	S 413	QSW0683-001Z	PUSH SWITCH	(FM MODE)	
	S 414	QSW0683-001Z	PUSH SWITCH	(ADJUST)	
	S 415	QSW0683-001Z	PUSH SWITCH	(S.SELECT)	
	S 416	QSW0683-001Z	PUSH SWITCH	(TUNING)	
	S 417	QSW0683-001Z	PUSH SWITCH	(PRESET)	
	S 418	QSW0683-001Z	PUSH SWITCH	(MEMORY)	
	S 419	QSW0683-001Z	PUSH SWITCH	(SETTING)	
	S 420	QSW0683-001Z	PUSH SWITCH	(OTO)	
	X 400	QAX0112-001Z	RESONATOR		
	X 401	QAX0246-001Z	RESONATOR		

## ■ Electrical parts list ( Input board )

Block No. 03

▲	Item	Parts number	Parts name	Remarks	Area
C 201	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V		
C 202	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V		
C 203	QETN0JM-477Z	E CAPACITOR	470MF 20% 6.3V		
C 204	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V		
C 205	QETN0JM-477Z	E CAPACITOR	470MF 20% 6.3V		
C 206	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V		
C 207	QETN0JM-477Z	E CAPACITOR	470MF 20% 6.3V		
C 208	QETN1EM-476Z	E CAPACITOR	47MF 20% 25V		
C 209	QCF11HZ-103	C CAPACITOR	.010MF +80:-20%		
C 210	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V		
C 211	QETN1HM-107Z	E CAPACITOR	100MF 20% 50V		
C 212	QETN1EM-476Z	E CAPACITOR	47MF 20% 25V		
C 213	QCF11HZ-103	C CAPACITOR	.010MF +80:-20%		
C 214	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V		
C 215	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V		
C 216	QDX31EM-473Z	C CAPACITOR			
C 217	QETN1AM-477Z	E CAPACITOR	470MF 20% 10V		
C 218	QCZ0202-155Z	MLC CAPACITOR	1.5MF		
C 219	QDC31HJ-150Z	C CAPACITOR			
C 220	QDC31HJ-100Z	C CAPACITOR			
C 221	QDC31HJ-470Z	C CAPACITOR			
C 222	QDC31HJ-270Z	ACCAPACITOR			
C 223	QDGB1HK-102Y	C CAPACITOR			
C 224	QCBB1HK-271Y	C CAPACITOR	270PF 10% 50V		
C 225	QCBB1HK-121Y	C CAPACITOR	120PF 10% 50V		
C 241	QDX31EM-473Z	C CAPACITOR			
C 242	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V		
C 244	QDX31EM-473Z	C CAPACITOR			
C 245	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V		
C 246	QDX31EM-473Z	C CAPACITOR			
C 247	QETN0JM-477Z	E CAPACITOR	470MF 20% 6.3V		
C 249	QDX31EM-473Z	C CAPACITOR			
C 250	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V		
C 251	QDX31EM-473Z	C CAPACITOR			
C 252	QETN0JM-477Z	E CAPACITOR	470MF 20% 6.3V		
C 254	QDX31EM-473Z	C CAPACITOR			
C 255	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V		
C 256	QCF11HZ-103	C CAPACITOR	.010MF +80:-20%		
C 257	QETN1EM-476Z	E CAPACITOR	47MF 20% 25V		
C 258	QCF11HZ-103	C CAPACITOR	.010MF +80:-20%		
C 259	QETN1EM-476Z	E CAPACITOR	47MF 20% 25V		
C 260	QDX31EM-473Z	C CAPACITOR			
C 261	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V		
C 268	QCS11HJ-470	C CAPACITOR	47PF 5% 50V		
C 269	QCS11HJ-470	C CAPACITOR	47PF 5% 50V		
C 270	QCS11HJ-101	C CAPACITOR	100PF 5% 50V		
C 271	QCS11HJ-101	C CAPACITOR	100PF 5% 50V		
C 277	QCS11HJ-470	C CAPACITOR	47PF 5% 50V		
C 301	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V		
C 302	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V		
C 303	QCS11HJ-101	C CAPACITOR	100PF 5% 50V		
C 304	QCS11HJ-101	C CAPACITOR	100PF 5% 50V		
C 305	QFLC1HJ-182Z	M CAPACITOR	1800PF 5% 50V		
C 306	QFLC1HJ-182Z	M CAPACITOR	1800PF 5% 50V		
C 307	QFLC1HJ-682Z	M CAPACITOR	6800PF 5% 50V		
C 308	QFLC1HJ-682Z	M CAPACITOR	6800PF 5% 50V		
C 309	QCS11HJ-101	C CAPACITOR	100PF 5% 50V		
C 310	QCS11HJ-101	C CAPACITOR	100PF 5% 50V		
C 311	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V		
C 312	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V		
C 313	QETN1CM-107Z	E CAPACITOR	100MF 20% 16V		
C 314	QETN1CM-107Z	E CAPACITOR	100MF 20% 16V		
C 315	QETN1EM-476Z	E CAPACITOR	47MF 20% 25V		
C 316	QETN1EM-476Z	E CAPACITOR	47MF 20% 25V		
C 317	QETN1HM-226Z	E CAPACITOR	22MF 20% 50V		
C 318	QETN1HM-226Z	E CAPACITOR	22MF 20% 50V		
C 321	QETN1HM-226Z	E CAPACITOR	22MF 20% 50V		

▲	Item	Parts number	Parts name	Remarks	Area
C 322	QETN1HM-226Z	E CAPACITOR	22MF 20% 50V		
C 323	QCS11HJ-221	C CAPACITOR	220PF 5% 50V		
C 324	QCS11HJ-221	C CAPACITOR	220PF 5% 50V		
C 331	QCS11HJ-471	C CAPACITOR	470PF 5% 50V		
C 332	QCS31HJ-391Z	C CAPACITOR	390PF 5% 50V		
C 333	QCS31HJ-391Z	C CAPACITOR	390PF 5% 50V		
C 334	QCS31HJ-391Z	C CAPACITOR	390PF 5% 50V		
C 337	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V		
C 338	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V		
C 339	QETN1HM-226Z	E CAPACITOR	22MF 20% 50V		
C 340	QETN1HM-226Z	E CAPACITOR	22MF 20% 50V		
C 341	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V		
C 342	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V		
C 343	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V		
C 344	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V		
C 345	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V		
C 346	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V		
C 347	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V		
C 348	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V		
C 349	QETN1HM-226Z	E CAPACITOR	22MF 20% 50V		
C 350	QETN1HM-226Z	E CAPACITOR	22MF 20% 50V		
C 353	QETN1HM-226Z	E CAPACITOR	22MF 20% 50V		
C 354	QETN1HM-226Z	E CAPACITOR	22MF 20% 50V		
C 358	QCBB1HK-561Y	C CAPACITOR	560PF 10% 50V		
C 363	QETN1HM-226Z	E CAPACITOR	22MF 20% 50V		
C 364	QETN1HM-226Z	E CAPACITOR	22MF 20% 50V		
C 370	QCBB1HK-561Y	C CAPACITOR	560PF 10% 50V		
C 371	QETN1EM-476Z	E CAPACITOR	47MF 20% 25V		
C 372	QETN1EM-476Z	E CAPACITOR	47MF 20% 25V		
C 373	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V		
C 374	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V		
CN200	QGB2510K1-05	CONNECTOR			
CN202	QGA2001F1-10	10P PLUG ASSY			
CN204	QGB1214K1-14S	CONNECTOR			
CN205	QGB1214J1-14S	CONNECTOR			
CN206	QGA2501F1-02	CONNECTOR			
CN240	QGB2510K1-04	CONNECTOR			
CN242	QGB1214K1-14S	CONNECTOR			
CN243	QGB1214J1-14S	CONNECTOR			
CN244	QGA2501F1-04	CONNECTOR			
CN254	QGB2510K1-05	CONNECTOR			
CN311	QGB2510K1-17	CONNECTOR			
CN312	QGB2510K1-09	CONNECTOR			
CN313	QGB2510K1-12	CONNECTOR			
CN416	QGA2501F1-03	CONNECTOR			
C1250	QCBB1HK-221Y	C CAPACITOR	220PF 10% 50V		
C1251	QCBB1HK-221Y	C CAPACITOR	220PF 10% 50V		
C1252	QCBB1HK-221Y	C CAPACITOR	220PF 10% 50V		
D 200	1SS133-T2	SI DIODE			
D 201	1SS133-T2	SI DIODE			
D1250	MTZJ6.2C-T2	Z DIODE			
D1251	MTZJ6.2C-T2	Z DIODE			
D1252	MTZJ6.2C-T2	Z DIODE			
IC201	BA7625	IC			
IC202	NJM2285D	IC			
IC203	MB90088PF-131	IC			
IC241	BA7626	IC			
IC242	BA7625	IC			
IC301	NJM4580D-D	IC			
IC302	NJM4580L	IC			
IC303	NJM4580L	IC			
IC304	TC9164AN	IC			
IC305	NJM4580L	IC			
IC311	TC9163AN	IC			
IC391	BA15218N	IC			
J 201	QNN0078-001	PIN JACK			
J 202	QNN0067-001	PIN JACK			

# RX-8000VBK

## ■ Electrical parts list ( Input board )

Block No. 03

▲	Item	Parts number	Parts name	Remarks	Area
	J 203	QNN0078-001	PIN JACK		
	J 241	QND0002-001	S-CONNECTOR		
	J 242	QND0028-001	DIN CONNECTOR		
	J 243	QND0024-001	S JACK		
	J 301	QNN0056-001	PIN JACK		
	J 302	QNN0056-001	PIN JACK		
	J 303	QNN0185-001	PIN JACK		
	J 311	QNN0056-001	PIN JACK		
	J 312	QNN0056-001	PIN JACK		
	J 313	QNN0056-001	PIN JACK		
	J 314	QNN0107-001	PIN JACK		
	J1250	QNS0077-001	3.5 JACK		
	J1251	QNS0083-001	3.5 JACK		
	J1252	QNS0001-001	3.5 JACK		
	J1253	QNS0001-001	3.5 JACK		
	J1254	QNS0001-001	3.5 JACK		
	L 200	QQL231K-220Y	INDUCTOR		
	Q 200	KTA1267/YG-T	TRANSISTOR		
	Q 201	KTA1267/YG-T	TRANSISTOR		
	Q 202	KRC110M-T	TRANSISTOR		
	Q 203	KRC107M-T	D.TRANSITOR		
	Q 204	KTA1267/YG-T	TRANSISTOR		
	Q 205	KTA1267/YG-T	TRANSISTOR		
	Q 206	KTA1267/YG-T	TRANSISTOR		
	Q 240	KTA1267/YG-T	TRANSISTOR		
	Q 241	KTA1267/YG-T	TRANSISTOR		
	Q 301	2SC2878/AB-T	TRANSISTOR		
	Q 302	2SC2878/AB-T	TRANSISTOR		
	R 200	QRE141J-750Y	C RESISTOR	75 5% 1/4W	
	R 201	QRE141J-750Y	C RESISTOR	75 5% 1/4W	
	R 202	QRE141J-750Y	C RESISTOR	75 5% 1/4W	
	R 203	QRE141J-750Y	C RESISTOR	75 5% 1/4W	
	R 204	QRE141J-750Y	C RESISTOR	75 5% 1/4W	
	R 205	QRE141J-750Y	C RESISTOR	75 5% 1/4W	
	R 206	QRE141J-750Y	C RESISTOR	75 5% 1/4W	
	R 207	QRE141J-331Y	C RESISTOR	330 5% 1/4W	
	R 208	QRE141J-331Y	C RESISTOR	330 5% 1/4W	
	R 209	QRE141J-473Y	C RESISTOR	47K 5% 1/4W	
	R 210	QRE141J-331Y	C RESISTOR	330 5% 1/4W	
	R 211	QRE141J-473Y	C RESISTOR	47K 5% 1/4W	
	R 212	QRE141J-331Y	C RESISTOR	330 5% 1/4W	
	R 213	QRE141J-473Y	C RESISTOR	47K 5% 1/4W	
	R 214	QRE141J-151Y	C RESISTOR	150 5% 1/4W	
	R 215	QRE141J-151Y	C RESISTOR	150 5% 1/4W	
	R 216	QRE141J-301Y	C RESISTOR	300 5% 1/4W	
	R 217	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
	R 218	QRE141J-331Y	C RESISTOR	330 5% 1/4W	
	R 219	QRE141J-101Y	C RESISTOR	100 5% 1/4W	
	R 220	QRE141J-121Y	C RESISTOR	120 5% 1/4W	
	R 221	QRE141J-151Y	C RESISTOR	150 5% 1/4W	
	R 222	QRE141J-561Y	C RESISTOR	560 5% 1/4W	
	R 223	QRE141J-561Y	C RESISTOR	560 5% 1/4W	
	R 224	QRE141J-561Y	C RESISTOR	560 5% 1/4W	
▲	R 225	QRJ146J-3R3X	UNF C RESISTOR	3.3 5% 1/4W	
	R 240	QRE141J-750Y	C RESISTOR	75 5% 1/4W	
	R 241	QRE141J-750Y	C RESISTOR	75 5% 1/4W	
	R 242	QRE141J-750Y	C RESISTOR	75 5% 1/4W	
	R 243	QRE141J-750Y	C RESISTOR	75 5% 1/4W	
	R 244	QRE141J-750Y	C RESISTOR	75 5% 1/4W	
	R 245	QRE141J-750Y	C RESISTOR	75 5% 1/4W	
	R 246	QRE141J-750Y	C RESISTOR	75 5% 1/4W	
	R 247	QRE141J-750Y	C RESISTOR	75 5% 1/4W	
	R 248	QRE141J-151Y	C RESISTOR	150 5% 1/4W	
	R 249	QRE141J-121Y	C RESISTOR	120 5% 1/4W	
	R 256	QRE141J-472Y	C RESISTOR	4.7K 5% 1/4W	
	R 257	QRE141J-471Y	C RESISTOR	470 5% 1/4W	
	R 258	QRE141J-472Y	C RESISTOR	4.7K 5% 1/4W	

▲	Item	Parts number	Parts name	Remarks	Area
	R 259	QRE141J-471Y	C RESISTOR	470 5% 1/4W	
	R 264	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
	R 265	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
	R 266	QRE141J-750Y	C RESISTOR	75 5% 1/4W	
	R 267	QRE141J-473Y	C RESISTOR	47K 5% 1/4W	
	R 268	QRE141J-750Y	C RESISTOR	75 5% 1/4W	
▲	R 269	QRE141J-473Y	C RESISTOR	47K 5% 1/4W	
▲	R 271	QRJ146J-6R8X	UNF C RESISTOR	6.8 5% 1/4W	
	R 301	QRE141J-222Y	C RESISTOR	2.2K 5% 1/4W	
	R 302	QRE141J-222Y	C RESISTOR	2.2K 5% 1/4W	
	R 303	QRE141J-473Y	C RESISTOR	47K 5% 1/4W	
	R 304	QRE141J-473Y	C RESISTOR	47K 5% 1/4W	
	R 305	QRE141J-621Y	C RESISTOR	620 5% 1/4W	
	R 306	QRE141J-621Y	C RESISTOR	620 5% 1/4W	
	R 307	QRE141J-393Y	C RESISTOR	39K 5% 1/4W	
	R 308	QRE141J-393Y	C RESISTOR	39K 5% 1/4W	
	R 309	QRE141J-474Y	C RESISTOR	470K 5% 1/4W	
	R 310	QRE141J-474Y	C RESISTOR	470K 5% 1/4W	
	R 311	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
	R 312	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
	R 313	QRJ146J-331X	UNF C RESISTOR	330 5% 1/4W	
	R 314	QRJ146J-331X	UNF C RESISTOR	330 5% 1/4W	
▲	R 315	QRZ9005-680X	F.RES. I.M	68 1/0W	
▲	R 316	QRZ9005-680X	F.RES. I.M	68 1/0W	
	R 325	QRE141J-471Y	C RESISTOR	470 5% 1/4W	
	R 326	QRE141J-471Y	C RESISTOR	470 5% 1/4W	
	R 327	QRE141J-471Y	C RESISTOR	470 5% 1/4W	
	R 328	QRE141J-471Y	C RESISTOR	470 5% 1/4W	
	R 329	QRE141J-471Y	C RESISTOR	470 5% 1/4W	
	R 330	QRE141J-471Y	C RESISTOR	470 5% 1/4W	
	R 331	QRE141J-561Y	C RESISTOR	560 5% 1/4W	
	R 332	QRE141J-561Y	C RESISTOR	560 5% 1/4W	
	R 333	QRE141J-561Y	C RESISTOR	560 5% 1/4W	
	R 334	QRE141J-561Y	C RESISTOR	560 5% 1/4W	
	R 335	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
	R 336	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
	R 337	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
	R 338	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
	R 339	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
	R 340	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
	R 341	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
	R 342	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
	R 343	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
	R 344	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
	R 345	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
	R 346	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
	R 347	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
	R 348	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
	R 349	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
	R 350	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
	R 351	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
	R 352	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
▲	R 353	QRZ9005-680X	F RESISTOR	68 1/0W	
▲	R 354	QRZ9005-680X	F RESISTOR	68 1/0W	
	R 355	QRE141J-471Y	C RESISTOR	470 5% 1/4W	
	R 356	QRE141J-471Y	C RESISTOR	470 5% 1/4W	
	R 357	QRE141J-471Y	C RESISTOR	470 5% 1/4W	
	R 358	QRE141J-471Y	C RESISTOR	470 5% 1/4W	
	R 359	QRE141J-471Y	C RESISTOR	470 5% 1/4W	
	R 360	QRE141J-471Y	C RESISTOR	470 5% 1/4W	
	R 361	QRE141J-471Y	C RESISTOR	470 5% 1/4W	
	R 362	QRE141J-471Y	C RESISTOR	470 5% 1/4W	
	R 363	QRE141J-471Y	C RESISTOR	470 5% 1/4W	
	R 364	QRE141J-471Y	C RESISTOR	470 5% 1/4W	
	R 365	QRE141J-471Y	C RESISTOR	470 5% 1/4W	
	R 366	QRE141J-471Y	C RESISTOR	470 5% 1/4W	
	R 379	QRE141J-471Y	C RESISTOR	470 5% 1/4W	
	R 380	QRE141J-471Y	C RESISTOR	470 5% 1/4W	
	R 381	QRE141J-183Y	C RESISTOR	18K 5% 1/4W	
	R 382	QRE141J-102Y	C RESISTOR	1.0K 5% 1/4W	
	R 383	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
	R 384	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
	R 385	QRE141J-471Y	C RESISTOR	470 5% 1/4W	
	R 386	QRE141J-471Y	C RESISTOR	470 5% 1/4W	
	R 387	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
	R 388	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
	R 389	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
	R 390	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
	R 391	QRE141J-221Y	C RESISTOR	220 5% 1/4W	
	R 392	QRE141J-221Y	C RESISTOR	220 5% 1/4W	
	R 393	QRE141J-471Y	C RESISTOR	470 5% 1/4W	
	R 394	QRE141J-221Y	C RESISTOR	220 5% 1/4W	
	R 395	QRE141J-221Y	C RESISTOR	220 5% 1/4W	
	R 396	QRE141J-221Y	C RESISTOR	220 5% 1/4W	
	R 397	QRE141J-221Y	C RESISTOR	220 5% 1/4W	
	R 398	QYH7653-005	IC HOLDER	220 5% 1/4W	
	X 200	QAX0269-001Z	CRYSTAL		

## ■ Electrical parts list ( AC supply board )

Block No. 04

▲	Item	Parts number	Parts name	Remarks	Area
▲	C 1	QCZ9019-472	C CAPACITOR	4700PF	
	C 51	QFN32AK-472Z	M CAPACITOR	4700PF 10% 100V	
	C 52	QETN1EM-108Z	E CAPACITOR	1000MF 20% 25V	
	C 54	QETN1CM-477Z	E CAPACITOR	470MF 20% 16V	
	C 55	QCF31HZ-472Z	C CAPACITOR	4700PF +80:-20%	
	C 56	QCZ0202-155Z	MLC CAPACITOR	1.5MF	
	C 61	QFN32AJ-104Z	M CAPACITOR	.10MF 5% 100V	
	C 62	QFN32AJ-104Z	M CAPACITOR	.10MF 5% 100V	
	C 63	QFN32AJ-104Z	M CAPACITOR	.10MF 5% 100V	
	C 65	QETM1VM-338	E CAPACITOR	3300MF 20% 35V	
	C 66	QETM1VM-228	E CAPACITOR	2200MF 20% 35V	
	C 67	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V	
	C 68	QFLC1HJ-473Z	M CAPACITOR	.047MF 5% 50V	
	C 69	QFLC1HJ-473Z	M CAPACITOR	.047MF 5% 50V	
	C 70	QETN1HM-227Z	E CAPACITOR	220MF 20% 50V	
	C 71	QETN1JM-227Z	E CAPACITOR	220MF 20% 63V	
	C 72	QETN1HM-226Z	E CAPACITOR	22MF 20% 50V	
	C 73	QETN1HM-226Z	E CAPACITOR	22MF 20% 50V	
	C 74	QETN1HM-105Z	E CAPACITOR	1.0MF 20% 50V	
	C 705	QCS11HJ-101	C CAPACITOR	100PF 5% 50V	
	C 706	QCS11HJ-101	C CAPACITOR	100PF 5% 50V	
	C 711	QFLC1HJ-103Z	M CAPACITOR	.010MF 5% 50V	
	C 712	QFLC1HJ-103Z	M CAPACITOR	.010MF 5% 50V	
	C 713	QCS11HJ-680	C CAPACITOR	68PF 5% 50V	
	C 714	QCS11HJ-680	C CAPACITOR	68PF 5% 50V	
	C 715	QCS11HJ-680	C CAPACITOR	68PF 5% 50V	
	C 716	QCS11HJ-680	C CAPACITOR	68PF 5% 50V	
	C 717	QCS32HJ-220Z	C CAPACITOR	22PF 5% 500V	
	C 718	QCS32HJ-220Z	C CAPACITOR	22PF 5% 500V	
	CN 51	QGB2510J1-08	CONNECTOR		
	CN 52	QGB2510J1-08	CONNECTOR		
	CN 53	QGB2510J1-05	CONNECTOR		
	CN 55	QGD2501C1-03Z	SOCKET I.M		
	CN 56	QGD2501C1-04Z	SOCKET I.M		
	CN402	OGF1205C1-21	CONNECTOR		
	CN701	QJP002-021401	SHI CR C-B WIRE		
	CN702	QJP001-031401	SHI CR C-B WIRE		
	CN703	WJK0034-001A	SKT WIRE ASSY	(WITH CN803)	
	CN705	QGB2510K1-12	CONNECTOR		
	CN811	QGA3901F2-03	CONNECTOR		
	CN951	QJL005-063201	SIN CR B-B WIRE		
	C1701	QETN1HM-105Z	E CAPACITOR	1.0MF 20% 50V	
	C1702	QCS11HJ-101	C CAPACITOR	100PF 5% 50V	
	C1703	QCS11HJ-101	C CAPACITOR	100PF 5% 50V	
	C1704	QETN1EM-476Z	E CAPACITOR	47MF 20% 25V	
	C1705	QCS31HJ-5R0Z	C CAPACITOR	5.0PF 5% 50V	
	C1711	QCS32HJ-330Z	C CAPACITOR	33PF 5% 500V	
	C1712	QFLC1HJ-103Z	M CAPACITOR	.010MF 5% 50V	
	C1713	QETN1HM-225Z	E CAPACITOR	2.2MF 20% 50V	
	C1715	QETN1HM-476Z	E CAPACITOR	47MF 20% 50V	
	C1741	QETN2AM-476Z	E CAPACITOR	47MF 20% 100V	
	C1742	QETN2AM-476Z	E CAPACITOR	47MF 20% 100V	
	C1743	QETN1EM-476Z	E CAPACITOR	47MF 20% 25V	
	C1751	QCS32HJ-470Z	C CAPACITOR	47PF 5% 500V	
	C1752	QCS32HJ-470Z	C CAPACITOR	47PF 5% 500V	
	C1761	QFLC1HJ-473Z	M CAPACITOR	.047MF 5% 50V	
	C1762	QFLC1HJ-473Z	M CAPACITOR	.047MF 5% 50V	
	C1791	QCF31HZ-223Z	C CAPACITOR	.022MF +80:-20%	
	C1801	QETN1HM-105Z	E CAPACITOR	1.0MF 20% 50V	
	C1802	QETN1HM-105Z	E CAPACITOR	1.0MF 20% 50V	
	C1803	QCS11HJ-101	C CAPACITOR	100PF 5% 50V	
	C1804	QCS11HJ-101	C CAPACITOR	100PF 5% 50V	
	C1805	QCS11HJ-101	C CAPACITOR	100PF 5% 50V	
	C1806	QCS11HJ-101	C CAPACITOR	100PF 5% 50V	
	C1807	QETN1EM-476Z	E CAPACITOR	47MF 20% 25V	
	C1808	QETN1EM-476Z	E CAPACITOR	47MF 20% 25V	
	C1809	QCS31HJ-5R0Z	C CAPACITOR	5.0PF 5% 50V	

▲	Item	Parts number	Parts name	Remarks	Area
	C1810	QCS31HJ-5R0Z	C CAPACITOR	5.0PF 5% 50V	
	C1811	QCS32HJ-330Z	C CAPACITOR	33PF 5% 500V	
	C1812	QCS32HJ-330Z	C CAPACITOR	33PF 5% 500V	
	C1813	QFLC1HJ-103Z	M CAPACITOR	.010MF 5% 50V	
	C1814	QFLC1HJ-103Z	M CAPACITOR	.010MF 5% 50V	
	C1815	QEKC1HM-225Z	E CAPACITOR	2.2MF 20% 50V	
	C1816	QEKC1HM-225Z	E CAPACITOR	2.2MF 20% 50V	
	C1817	QETN1HM-476Z	E CAPACITOR	47MF 20% 50V	
	C1818	QETN1HM-476Z	E CAPACITOR	47MF 20% 50V	
	C1841	QETN2AM-476Z	E CAPACITOR	47MF 20% 100V	
	C1842	QETN2AM-476Z	E CAPACITOR	47MF 20% 100V	
	C1843	QETN1HM-106Z	E CAPACITOR	10MF 20% 50V	
	C1851	QCS32HJ-470Z	C CAPACITOR	47PF 5% 500V	
	C1852	QCS32HJ-470Z	C CAPACITOR	47PF 5% 500V	
	C1853	QCS32HJ-470Z	C CAPACITOR	47PF 5% 500V	
	C1854	QCS32HJ-470Z	C CAPACITOR	47PF 5% 500V	
	C1861	QFLC1HJ-473Z	M CAPACITOR	.047MF 5% 50V	
	C1862	QFLC1HJ-473Z	M CAPACITOR	.047MF 5% 50V	
	C1863	QFLC1HJ-473Z	M CAPACITOR	.047MF 5% 50V	
	C1864	QFLC1HJ-473Z	M CAPACITOR	.047MF 5% 50V	
	C1891	QCF31HZ-223Z	C CAPACITOR	.022MF +80:-20%	
	C1892	QCF31HZ-223Z	C CAPACITOR	.022MF +80:-20%	
▲	D 51	1SR35-400A-T5	DIODE		
▲	D 52	1SR35-400A-T5	DIODE		
▲	D 53	1SR35-400A-T5	DIODE		
▲	D 54	1SR35-400A-T5	DIODE		
	D 56	MTZJ6.2A-T2	Z.DIODE		
	D 57	1SS133-T2	SI DIODE		
▲	D 61	10E2-FD	DIODE		
▲	D 62	1SR35-400A-T5	DIODE		
▲	D 63	10E2-FD	DIODE		
▲	D 64	1SR35-400A-T5	DIODE		
	D 65	1SS133-T2	SI DIODE		
	D 66	1SS133-T2	SI DIODE		VER.J
	D 67	1SS133-T2	SI DIODE		VER.C
	D 68	1SS133-T2	SI DIODE		VER.C
▲	D 71	1SR35-400A-T5	DIODE		
▲	D 72	1SR35-400A-T5	DIODE		
▲	D 73	1SR35-400A-T5	DIODE		
	D 74	MTZJ33C-T2	Z DIODE		
	D 75	MTZJ6.2C-T2	Z DIODE		
	D 701	1SS133-T2	SI DIODE		
	D 702	1SS133-T2	SI DIODE		
	D 703	1SS133-T2	SI DIODE		
	D 704	1SS133-T2	SI DIODE		
	D 951	1SS133-T2	SI DIODE		
	D 952	1SS133-T2	SI DIODE		
	D 1701	1SS133-T2	SI DIODE		
	D 1702	MTZJ18C-T2	Z DIODE		
	D 1771	1SS133-T2	SI DIODE		
	D 1772	1SS133-T2	SI DIODE		
	D 1791	1SS133-T2	SI DIODE		
	D 1801	1SS133-T2	SI DIODE		
	D 1802	1SS133-T2	SI DIODE		
	D 1805	MTZJ18C-T2	Z.DIODE		
	D 1871	1SS133-T2	SI DIODE		
	D 1872	1SS133-T2	SI DIODE		
	D 1873	1SS133-T2	SI DIODE		
	D 1874	1SS133-T2	SI DIODE		
	D 1891	1SS133-T2	SI DIODE		
	D 1892	1SS133-T2	SI DIODE		
EP 1	E409182-001SM		GRAND TERMINAL		
EP 2	QN20136-001Z		EARTH PLATE		
EP 51	QN20136-001Z		EARTH PLATE		
FC 1	QNG0020-001Z		FUSE CLIP	F001	
FC 2	QNG0020-001Z		FUSE CLIP	F001	
FC 61	QNG0020-001Z		FUSE CLIP	F061	

# RX-8000VBK

## ■ Electrical parts list ( AC supply board )

Block No. 04

▲ Item	Parts number	Parts name	Remarks	Area
	FC 62	QNG0020-001Z	FUSE CLIP	F061
	FC 63	QNG0020-001Z	FUSE CLIP	F062
	FC 64	QNG0020-001Z	FUSE CLIP	F062
	FW 51	QUM137-10DGZ4	PARA RIBON WIRE	
	FW901	QUM133-08DGZ4	PARA RIBON WIRE	
	FW961	QUM133-15DGZ4	PARA RIBON WIRE	
	J 91	QNS0023-001	JACK	
	L1761	QQLZ005-R45	INDUCTOR	
	L1861	QQLZ005-R45	INDUCTOR	
	L1862	QQLZ005-R45	INDUCTOR	
	Q 52	2SC2235/OY/-T	TRANSISTOR	
	Q 53	KRC105M-T	D.TRANSISTOR	
	Q 61	KRC107M-T	D.TRANSISTOR	
▲	Q 71	2SB1357/EF/-T	TRANSISTOR	
	Q 72	KRC102M-T	D.TRANSISTOR	
	Q 73	KRA104M-T	D.TRANSISTOR	
	Q 74	2SC2240/GL/-T	TRANSISTOR	
	Q 701	2SC2240-BL/AB/T	TRANSISTOR	
	Q 702	2SC2240-BL/AB/T	TRANSISTOR	
	Q 703	2SC2240-BL/AB/T	TRANSISTOR	
	Q 704	2SC2240-BL/AB/T	TRANSISTOR	
	Q 705	2SA1038S/SE/-T	TRANSISTOR	
	Q 706	2SA1038S/SE/-T	TRANSISTOR	
	Q 707	2SA933AS/RS/-T	TRANSISTOR	
	Q 708	2SA933AS/RS/-T	TRANSISTOR	
	Q 709	2SA1038S/SE/-T	TRANSISTOR	
	Q 710	2SA1038S/SE/-T	TRANSISTOR	
	Q 711	2SC2389S/SE/-T	TRANSISTOR	
	Q 712	2SC2389S/SE/-T	TRANSISTOR	
	Q1701	2SC2240-BL/AB/T	TRANSISTOR	
	Q1702	2SC2240-BL/AB/T	TRANSISTOR	
	Q1703	2SA1038S/S-T	TRANSISTOR	
	Q1731	2SD637/QR/	TRANSISTOR	
	Q1771	2SC2389S/SE/-T	TRANSISTOR	
	Q1772	2SA1038S/SE/-T	TRANSISTOR	
	Q1791	2SC2389S/SE/-T	TRANSISTOR	
	Q1801	2SC2240-BL/AB/T	TRANSISTOR	
	Q1802	2SC2240-BL/AB/T	TRANSISTOR	
	Q1803	2SC2240-BL/AB/T	TRANSISTOR	
	Q1804	2SC2240-BL/AB/T	TRANSISTOR	
	Q1805	2SA1038S/S-T	TRANSISTOR	
	Q1806	2SA1038S/S-T	TRANSISTOR	
	Q1831	2SD637/QR/	TRANSISTOR	
	Q1832	2SD637/QR/	TRANSISTOR	
	Q1871	2SC2389S/SE/-T	TRANSISTOR	
	Q1872	2SC2389S/SE/-T	TRANSISTOR	
	Q1873	2SA1038S/SE/-T	TRANSISTOR	
	Q1874	2SA1038S/SE/-T	TRANSISTOR	
	Q1891	2SC2389S/SE/-T	TRANSISTOR	
	Q1892	2SC2389S/SE/-T	TRANSISTOR	
▲	R 1	QRZ044-335	COMP.RESISTOR	3.3M 1/0W
▲	R 53	QRJ146J-3R9X	UNF C RESISTOR	3.9 5% 1/4W
	R 54	QRE141J-821Y	C RESISTOR	820 5% 1/4W
▲	R 55	QRT022J-1R0	MF RESISTOR	1.0 5% 1/2W
▲	R 61	QRT012J-R22	UNF.MF.RESISTOR	5% 1/1W
▲	R 62	QRT012J-R22	UNF.MF.RESISTOR	5% 1/1W
▲	R 66	QRJ146J-2R2X	UNF C RESISTOR	2.2 5% 1/4W
▲	R 67	QRJ146J-120X	UNF C RESISTOR	12.5% 1/4W
	R 68	QRE141J-562Y	C RESISTOR	5.6K 5% 1/4W
	R 69	QRE141J-822Y	C RESISTOR	8.2K 5% 1/4W
	R 70	QRE141J-103Y	C RESISTOR	10K 5% 1/4W
▲	R 72	QRJ146J-332X	UNF C RESISTOR	3.3K 5% 1/4W
	R 73	QRE141J-223Y	C RESISTOR	22K 5% 1/4W
	R 74	QRE141J-104Y	C RESISTOR	100K 5% 1/4W
▲	R 91	QRL022J-471	UNF OMF.RESISTO	470 5% 1/2W
▲	R 92	QRL022J-471	UNF OMF.RESISTO	470 5% 1/2W
	R 705	QRE141J-202Y	C RESISTOR	2.0K 5% 1/4W

▲ Item	Parts number	Parts name	Remarks	Area
	R 706	QRE141J-202Y	C RESISTOR	2.0K 5% 1/4W
	R 707	QRE141J-202Y	C RESISTOR	2.0K 5% 1/4W
	R 708	QRE141J-202Y	C RESISTOR	2.0K 5% 1/4W
	R 709	QRE141J-912Y	C RESISTOR	9.1K 5% 1/4W
	R 710	QRE141J-912Y	C RESISTOR	9.1K 5% 1/4W
▲	R 711	QRJ146J-562X	UNF C RESISTOR	5.6K 5% 1/4W
▲	R 718	QRJ146J-562X	UNF C RESISTOR	5.6K 5% 1/4W
▲	R 719	ORK126J-103X	UNF.C RESISTOR	10K 5% 1/2W
▲	R 720	ORK126J-103X	UNF.C RESISTOR	10K 5% 1/2W
▲	R 721	QRJ146J-151X	UNF C RESISTOR	150 5% 1/4W
▲	R 722	QRJ146J-151X	UNF C RESISTOR	150 5% 1/4W
	R 723	QRE141J-391Y	C RESISTOR	390 5% 1/4W
	R 724	QRE141J-391Y	C RESISTOR	390 5% 1/4W
	R 725	QRE141J-152Y	C RESISTOR	1.5K 5% 1/4W
	R 726	QRE141J-152Y	C RESISTOR	1.5K 5% 1/4W
	R 727	QRE141J-333Y	C RESISTOR	33K 5% 1/4W
	R 728	QRE141J-333Y	C RESISTOR	33K 5% 1/4W
	R 729	QRE141J-391Y	C RESISTOR	390 5% 1/4W
	R 730	QRE141J-391Y	C RESISTOR	390 5% 1/4W
	R 731	QRE141J-391Y	C RESISTOR	390 5% 1/4W
	R 732	QRE141J-391Y	C RESISTOR	390 5% 1/4W
	R 733	QRE141J-221Y	C RESISTOR	220 5% 1/4W
	R 734	QRE141J-221Y	C RESISTOR	220 5% 1/4W
▲	R 951	QRJ146J-120X	UNF C RESISTOR	12.5% 1/4W
▲	R 952	QRJ146J-120X	UNF C RESISTOR	12.5% 1/4W
▲	RY 1	OSK0098-001	RELAY	
▲	RY 61	QSK0082-001	RELAY	VER.J
▲	RY 62	QSK0088-001	RELAY	VER.C
▲	RY 63	QSK0088-001	RELAY	VER.C
▲	RY951	QSK0109-001	RELAY	
▲	RY952	QSK0109-001	RELAY	
	R1701	QRE141J-222Y	C RESISTOR	2.2K 5% 1/4W
	R1702	QRE141J-124Y	C RESISTOR	120K 5% 1/4W
	R1703	QRE141J-202Y	C RESISTOR	2.0K 5% 1/4W
	R1705	QRE141J-123Y	C RESISTOR	12K 5% 1/4W
	R1711	QRE141J-621Y	C RESISTOR	620 5% 1/4W
	R1712	QRE141J-104Y	C RESISTOR	100K 5% 1/4W
▲	R1721	QRJ146J-221X	UNF C RESISTOR	220 5% 1/4W
	R1722	QRE141J-332Y	C RESISTOR	3.3K 5% 1/4W
	R1723	QRE141J-332Y	C RESISTOR	3.3K 5% 1/4W
	R1724	QRE141J-332Y	C RESISTOR	3.3K 5% 1/4W
	R1725	QRE141J-332Y	C RESISTOR	3.3K 5% 1/4W
	R1731	QRE141J-751Y	C RESISTOR	750 5% 1/4W
	R1732	QRE141J-391Y	C RESISTOR	390 5% 1/4W
▲	R1742	QRJ146J-221X	UNF C RESISTOR	220 5% 1/4W
▲	R1743	QRL022J-562	UNF.OMF.RESISTO	5.6K 5% 1/2W
▲	R1751	QRJ146J-100X	UNF.C RESISTOR	10 5% 1/4W
▲	R1752	QRJ146J-100X	UNF.C RESISTOR	10 5% 1/4W
▲	R1753	QRZ0196-R22	EMIT.RESISTOR	1/1W
▲	R1761	QRJ125J-330	UNF.C RESISTOR	33 5% 1/2W
▲	R1762	QRL022J-100	UNF.OMF.RESISTO	10 5% 1/2W
	R1771	QRE141J-391Y	C RESISTOR	390 5% 1/4W
	R1772	QRE141J-391Y	C RESISTOR	390 5% 1/4W
	R1773	QRE141J-201Y	C RESISTOR	200 5% 1/4W
	R1774	QRE141J-201Y	C RESISTOR	200 5% 1/4W
	R1791	QRE141J-272Y	C RESISTOR	2.7K 5% 1/4W
	R1792	QRE141J-153Y	C RESISTOR	15K 5% 1/4W
	R1793	QRE141J-123Y	C RESISTOR	12K 5% 1/4W
	R1794	QRE141J-104Y	C RESISTOR	100K 5% 1/4W
	R1801	QRE141J-222Y	C RESISTOR	2.2K 5% 1/4W
	R1802	QRE141J-222Y	C RESISTOR	2.2K 5% 1/4W
	R1803	QRE141J-124Y	C RESISTOR	120K 5% 1/4W
	R1804	QRE141J-124Y	C RESISTOR	120K 5% 1/4W
	R1805	QRE141J-202Y	C RESISTOR	2.0K 5% 1/4W
	R1806	QRE141J-202Y	C RESISTOR	2.0K 5% 1/4W
	R1809	QRE141J-123Y	C RESISTOR	12K 5% 1/4W
	R1810	QRE141J-123Y	C RESISTOR	12K 5% 1/4W

## ■ Electrical parts list ( AC supply board )

Block No. 04

A	Item	Parts number	Parts name	Remarks	Area
	R1811	QRE141J-621Y	C RESISTOR	620 5% 1/4W	
	R1812	QRE141J-621Y	C RESISTOR	620 5% 1/4W	
	R1813	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
	R1814	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
▲	R1821	QRJ146J-221X	UNF C RESISTOR	220 5% 1/4W	
▲	R1822	QRJ146J-221X	UNF C RESISTOR	220 5% 1/4W	
	R1823	QRE141J-332Y	C RESISTOR	3.3K 5% 1/4W	
	R1824	QRE141J-332Y	C RESISTOR	3.3K 5% 1/4W	
	R1825	QRE141J-332Y	C RESISTOR	3.3K 5% 1/4W	
	R1826	QRE141J-332Y	C RESISTOR	3.3K 5% 1/4W	
	R1827	QRE141J-332Y	C RESISTOR	3.3K 5% 1/4W	
	R1828	QRE141J-332Y	C RESISTOR	3.3K 5% 1/4W	
	R1829	QRE141J-332Y	C RESISTOR	3.3K 5% 1/4W	
	R1830	QRE141J-332Y	C RESISTOR	3.3K 5% 1/4W	
	R1831	QRE141J-751Y	C RESISTOR	750 5% 1/4W	
	R1832	QRE141J-751Y	C RESISTOR	750 5% 1/4W	
	R1833	QRE141J-391Y	C RESISTOR	390 5% 1/4W	
	R1834	QRE141J-391Y	C RESISTOR	390 5% 1/4W	
▲	R1842	QRJ146J-221X	UNF C RESISTOR	220 5% 1/4W	
▲	R1843	QRL022J-562	UNF.OMF.RESISTO	5.6K 5% 1/2W	
▲	R1851	QRJ146J-100X	UNF.C RESISTOR	10 5% 1/4W	
▲	R1852	QRJ146J-100X	UNF.C RESISTOR	10 5% 1/4W	
▲	R1853	QRJ146J-100X	UNF.C RESISTOR	10 5% 1/4W	
▲	R1854	QRJ146J-100X	UNF.C RESISTOR	10 5% 1/4W	
▲	R1855	QRZ0196-R22	EMIT.RESISTOR	1/1W	
▲	R1856	QRZ0196-R22	EMIT.RESISTOR	1/1W	
▲	R1861	QRJ125J-330	UNF.C RESISTOR	33.5% 1/2W	
▲	R1862	QRJ125J-330	UNF.C RESISTOR	33.5% 1/2W	
▲	R1863	QRL022J-100	UNF.OMF.RESISTO	10 5% 1/2W	
▲	R1864	QRL022J-100	UNF.OMF.RESISTO	10 5% 1/2W	
	R1871	QRE141J-391Y	C RESISTOR	390 5% 1/4W	
	R1872	QRE141J-391Y	C RESISTOR	390 5% 1/4W	
	R1873	QRE141J-391Y	C RESISTOR	390 5% 1/4W	
	R1874	QRE141J-391Y	C RESISTOR	390 5% 1/4W	
	R1875	QRE141J-201Y	C RESISTOR	200 5% 1/4W	
	R1876	QRE141J-201Y	C RESISTOR	200 5% 1/4W	
	R1877	QRE141J-201Y	C RESISTOR	200 5% 1/4W	
	R1878	QRE141J-201Y	C RESISTOR	200 5% 1/4W	
	R1891	QRE141J-272Y	C RESISTOR	2.7K 5% 1/4W	
	R1892	QRE141J-272Y	C RESISTOR	2.7K 5% 1/4W	
	R1893	QRE141J-153Y	C RESISTOR	15K 5% 1/4W	
	R1894	QRE141J-153Y	C RESISTOR	15K 5% 1/4W	
	R1895	QRE141J-123Y	C RESISTOR	12K 5% 1/4W	
	R1896	QRE141J-123Y	C RESISTOR	12K 5% 1/4W	
	R1897	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
	R1898	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
	ST951	QNB0078-001	SPK TERMINAL		
▲	T 2	QQT0281-001	POWER TRANSF		
	TA 1	QNZ0079-001Z	TAB I.M		
	TA 2	QNZ0079-001Z	TAB I.M		
▲	TH 71	QAD0095-4R7Z	POSISTOR		
▲	TH731	QAD0012-202	THERMISTOR		
▲	TH831	QAD0012-202	THERMISTOR		
▲	TH832	QAD0012-202	THERMISTOR		

# RX-8000VBK

## ■ Electrical parts list ( AC-3 board )

Block No. 05

A	Item	Parts number	Parts name	Remarks	Area
	C 601	NCB31HK-102X	C CAPACITOR		
	C 602	NCB31HK-102X	C CAPACITOR		
	C 603	NEA70JM-476X	E CAPACITOR		
	C 604	NEA70JM-476X	E CAPACITOR		
	C 605	NCB31CK-104X	C CAPACITOR		
	C 606	NCB31CK-104X	C CAPACITOR		
	C 607	NEA71CM-476X	E CAPACITOR		
	C 608	NCB31CK-104X	C CAPACITOR		
	C 609	NCB31CK-104X	C CAPACITOR		
	C 610	NEA70JM-476X	E CAPACITOR		
	C 611	NEA70JM-226X	E CAPACITOR		
	C 612	NCB31CK-103X	C CAPACITOR		
	C 621	NEA71HM-105X	E CAPACITOR		
	C 622	NCB31HK-101X	C CAPACITOR		
	C 623	NCB30JK-105X	C CAPACITOR		
	C 624	NCB31CK-104X	C CAPACITOR		
	C 625	NCB31CK-104X	C CAPACITOR		
	C 628	NCB31CK-103X	C CAPACITOR		
	C 629	NCB31CK-104X	C CAPACITOR		
	C 631	NEA70GM-107X	E CAPACITOR		
	C 632	NCB31CK-103X	C CAPACITOR		
	C 633	NCB31CK-104X	C CAPACITOR		
	C 634	NCB31CK-104X	C CAPACITOR		
	C 635	NCB31CK-104X	C CAPACITOR		
	C 636	NCB31CK-104X	C CAPACITOR		
	C 637	NCB31CK-104X	C CAPACITOR		
	C 638	NEA70JM-476X	E CAPACITOR		
	C 639	NCB31CK-103X	C CAPACITOR		
	C 641	NEA70JM-107X	E CAPACITOR		
	C 642	NCB31CK-103X	C CAPACITOR		
	C 643	NCB31AK-474X	C CAPACITOR		
	C 644	NCB31CK-103X	C CAPACITOR		
	C 645	NCS31HJ-101X	C CAPACITOR		
	C 646	NCB31CK-103X	C CAPACITOR		
	C 647	NCS31HJ-220X	C CAPACITOR		
	C 648	NCS31HJ-180X	C CAPACITOR		
	C 649	NCS31HJ-121X	C CAPACITOR		
	C 653	NCB31CK-104X	C CAPACITOR		
	C 654	NEA70GM-107X	E CAPACITOR		
	C 661	NCB31CK-103X	C CAPACITOR		
	C 671	NCB31CK-103X	C CAPACITOR		
	C 672	NEA70GM-107X	E CAPACITOR		
	C 673	NCB31CK-103X	C CAPACITOR		
	C 677	NCB31HK-101X	C CAPACITOR		
	C 679	NCB31HK-101X	C CAPACITOR		
	C 681	NCB31CK-103X	C CAPACITOR		
	C 682	NCB31CK-103X	C CAPACITOR		
	C 683	NCB31CK-103X	C CAPACITOR		
	C 684	NEA70JM-107X	E CAPACITOR		
	C 685	NEA71CM-476X	E CAPACITOR		
	C 686	NEA71CM-476X	E CAPACITOR		
	C 687	NCB31CK-103X	C CAPACITOR		
	C 688	NEA70JM-107X	E CAPACITOR		
	C 689	NCB31CK-103X	C CAPACITOR		
	C 690	NEA70JM-107X	E CAPACITOR		
	C 691	NEA71HM-105X	E CAPACITOR		
	C 692	NEA71HM-105X	E CAPACITOR		
	C 693	NCB31CK-103X	C CAPACITOR		
	C 694	NCB31CK-103X	C CAPACITOR		
	C 695	NEA71HM-105X	E CAPACITOR		
	C 696	NEA71HM-105X	E CAPACITOR		
	C 697	NEA71HM-105X	E CAPACITOR		
	C 698	NEA71HM-105X	E CAPACITOR		
	CN681	QGB1214K3-18W	CONNECTOR		
	CN687	QGB1214K3-12W	CONNECTOR		
	C2500	NEA71CM-226X	E CAPACITOR		
	C2501	NCB31AK-474X	C CAPACITOR		

A	Item	Parts number	Parts name	Remarks	Area
	C2503	NEA71EM-475X	E CAPACITOR		
	C2504	NEA71EM-475X	E CAPACITOR		
	C2505	NCS31HJ-560X	C CAPACITOR		
	C2506	NCS31HJ-560X	C CAPACITOR		
	C2507	NCS31HJ-560X	C CAPACITOR		
	C2508	NCS31HJ-560X	C CAPACITOR		
	C2509	NCF31CZ-104X	C CAPACITOR		
	C2510	NCF31CZ-104X	C CAPACITOR		
	C2511	NCB31AK-474X	C CAPACITOR		
	C2512	NCB31AK-474X	C CAPACITOR		
	C2513	NCB31CK-183X	C CAPACITOR		
	C2514	NCB31CK-183X	C CAPACITOR		
	C2515	NCB31HK-182X	C CAPACITOR		
	C2516	NCB31HK-182X	C CAPACITOR		
	C2517	NCB31HK-562X	C CAPACITOR		
	C2518	NCB31HK-562X	C CAPACITOR		
	C2519	NCF31CZ-104X	C CAPACITOR		
	C2520	NCF31CZ-104X	C CAPACITOR		
	C2521	NCB31CK-103X	C CAPACITOR		
	C2522	NCB31CK-103X	C CAPACITOR		
	C2523	NCB31HK-272X	C CAPACITOR		
	C2524	NCB31HK-272X	C CAPACITOR		
	C2525	NCB31HK-392X	C CAPACITOR		
	C2526	NCB31HK-392X	C CAPACITOR		
	C2527	NEA71HM-225X	E CAPACITOR		
	C2528	NEA71HM-225X	E CAPACITOR		
	C2529	NCF31CZ-104X	C CAPACITOR		
	C2530	NCF31CZ-104X	C CAPACITOR		
	C2531	NCS31HJ-560X	C CAPACITOR		
	C2532	NCS31HJ-560X	C CAPACITOR		
	C2533	NEA71EM-475X	E CAPACITOR		
	C2534	NEA71EM-475X	E CAPACITOR		
	C2539	NCF31CZ-104X	C CAPACITOR		
	C2540	NCF31CZ-104X	C CAPACITOR		
	C2541	NCS31HJ-560X	C CAPACITOR		
	C2542	NCS31HJ-560X	C CAPACITOR		
	C2543	NEA71EM-475X	E CAPACITOR		
	C2544	NEA71EM-475X	E CAPACITOR		
	C2549	NCF31CZ-104X	C CAPACITOR		
	C2550	NCF31CZ-104X	C CAPACITOR		
	C2551	NCS31HJ-560X	C CAPACITOR		
	C2552	NCS31HJ-560X	C CAPACITOR		
	C2553	NCB31HK-562X	C CAPACITOR		
	C2554	NCB31HK-562X	C CAPACITOR		
	C2555	NCF31CZ-104X	C CAPACITOR		
	C2556	NCF31CZ-104X	C CAPACITOR		
	C2559	NCF31CZ-104X	C CAPACITOR		
	C2560	NCF31CZ-104X	C CAPACITOR		
	C2561	NEA71HM-105X	E CAPACITOR		
	C2562	NEA71HM-105X	E CAPACITOR		
	C2563	NCS31HJ-220X	C CAPACITOR		
	C2564	NCS31HJ-220X	C CAPACITOR		
	C2569	NCF31CZ-104X	C CAPACITOR		
	C2570	NCF31CZ-104X	C CAPACITOR		
	C2571	NCB31CK-103X	C CAPACITOR		
	C2572	NCB31CK-103X	C CAPACITOR		
	C2573	NCB31HK-272X	C CAPACITOR		
	C2574	NCB31HK-272X	C CAPACITOR		
	C2575	NCB31HK-392X	C CAPACITOR		
	C2576	NCB31HK-392X	C CAPACITOR		
	C2577	NEA71HM-225X	E CAPACITOR		
	C2578	NEA71HM-225X	E CAPACITOR		
	C2579	NCF31CZ-104X	C CAPACITOR		
	C2580	NCF31CZ-104X	C CAPACITOR		
	C2581	NEA71HM-105X	E CAPACITOR		
	C2582	NEA71CM-106X	E CAPACITOR		
	C2583	NCS31HJ-220X	C CAPACITOR		

## ■ Electrical parts list ( AC-3 board )

Block No. 05

▲	Item	Parts number	Parts name	Remarks	Area
	C2584	NCS31HJ-560X	C CAPACITOR		
	C2585	NCF31CZ-104X	C CAPACITOR		
	C2586	NCF31CZ-104X	C CAPACITOR		
	C2587	NCS31HJ-560X	C CAPACITOR		
	C2588	NEA71CM-106X	E CAPACITOR		
	C2589	NCF31CZ-104X	C CAPACITOR		
	C2590	NCF31CZ-104X	C CAPACITOR		
	C2591	NCB31CK-103X	C CAPACITOR		
	C2592	NCB31HK-223X	C CAPACITOR		
	C2593	NCB31HK-272X	C CAPACITOR		
	C2594	NCB31CK-104X	C CAPACITOR		
	C2595	NCB31HK-392X	C CAPACITOR		
	C2597	NEA71HM-225X	E CAPACITOR		
	C2598	NEA71EM-475X	E CAPACITOR		
	C2599	NCF31CZ-104X	C CAPACITOR		
	C2600	NCF31CZ-104X	C CAPACITOR		
D 602	1SS355-X	DIODE			
D 607	1SS355-X	DIODE			
D 608	1SS355-X	DIODE			
EP601	E409182-001SM	GRAND TERMINAL			
IC501	BA15218F-XE	IC			
IC510	BA15218F-XE	IC			
IC511	BA15218F-XE	IC			
IC521	BA15218F-XE	IC			
IC531	BA15218F-XE	IC			
IC541	BA15218F-XE	IC			
IC551	BA15218F-XE	IC			
IC561	BA15218F-XE	IC			
IC571	BA15218F-XE	IC			
IC581	BA15218F-XE	IC			
IC591	BA15218F-XE	IC			
IC592	BA15218F-XE	IC			
IC601	AK4527VQ	IC			
IC602	BU4066BCF-X	IC			
IC611	BU4066BCF-X	IC			
IC621	TC7SU04FU-X	IC			
IC622	TC7SU04FU-X	IC			
IC631	TC9446F-013	IC			
IC641	W24L011AJ-15-X	IC			
IC671	UPD784215AGC102	IC			
IC672	TC7SET32FU-X	IC			
IC681	PQ3DZ53-X	IC			
IC683	PQ3DZ53-X	IC			
J 601	EMN00TV-107A	PIN JACK			
K 501	NQR0269-007X	FERRITE BEADS			
K 502	NQR0269-007X	FERRITE BEADS			
K 503	NQR0269-007X	FERRITE BEADS			
K 504	NQR0269-007X	FERRITE BEADS			
K 531	NQR0269-007X	FERRITE BEADS			
K 532	NQR0269-007X	FERRITE BEADS			
K 541	NQR0269-007X	FERRITE BEADS			
K 542	NQR0269-007X	FERRITE BEADS			
K 561	NQR0269-007X	FERRITE BEADS			
K 562	NQR0269-007X	FERRITE BEADS			
K 581	NQR0269-007X	FERRITE BEADS			
K 582	NQR0269-007X	FERRITE BEADS			
K 601	NQR0269-007X	FERRITE BEADS			
K 611	NQR0269-007X	FERRITE BEADS			
K 612	NQR0269-007X	FERRITE BEADS			
K 613	NQR0269-007X	FERRITE BEADS			
K 614	NQR0269-007X	FERRITE BEADS			
K 615	NQR0269-007X	FERRITE BEADS			
K 616	NQR0269-007X	FERRITE BEADS			
K 617	NQR0269-007X	FERRITE BEADS			
K 618	NQR0269-007X	FERRITE BEADS			
K 619	NQR0269-007X	FERRITE BEADS			
K 620	NQR0269-007X	FERRITE BEADS			

▲	Item	Parts number	Parts name	Remarks	Area
	K 621	NQR0269-007X	FERRITE BEADS		
	K 622	NQR0269-007X	FERRITE BEADS		
	K 687	NQR0319-001X	FERRITE BEADS		
	L 661	NQL024J-470X	INDUCTOR CM		
	L 662	NQL024J-470X	INDUCTOR CM		
	L 663	NQL024J-470X	INDUCTOR CM		
	L 664	NQL024J-470X	INDUCTOR CM		
	LC601	NQR0321-001X	EMI FILTER		
	LC632	NQR0321-001X	EMI FILTER C.M		
	LC641	NQR0321-001X	EMI FILTER C.M		
	LC671	NQR0321-001X	EMI FILTER C.M		
	Q 601	DTC114YE-X	TRANSISTOR		
	Q 607	DTA144EKA-X	TRANSISTOR		
	Q 670	DTC114YE-X	TRANSISTOR		
	Q 671	2SD1328/ST-/X	TRANSISTOR		
	Q 672	DTC114YE-X	TRANSISTOR		
	Q 673	DTA144EKA-X	TRANSISTOR		
	Q 674	DTC114YE-X	TRANSISTOR		
	Q 675	DTC114YE-X	TRANSISTOR		
	Q 2501	DTA144EKA-X	TRANSISTOR		
	Q 2521	2SD1328/ST-/X	TRANSISTOR		
	Q 2522	2SD1328/ST-/X	TRANSISTOR		
	Q 2561	2SD1328/ST-/X	TRANSISTOR		
	Q 2562	2SD1328/ST-/X	TRANSISTOR		
	Q 2581	2SD1328/ST-/X	TRANSISTOR		
	Q 2582	2SD1328/ST-/X	TRANSISTOR		
	R 601	NRSA63J-473X	MG RESISTOR		
	R 602	NRSA63J-473X	MG RESISTOR		
	R 603	NRSA63J-473X	MG RESISTOR		
	R 604	NRSA63J-473X	MG RESISTOR		
	R 605	NRSA63J-473X	MG RESISTOR		
	R 606	NRSA63J-221X	MG RESISTOR		
	R 607	NRSA63J-221X	MG RESISTOR		
	R 608	NRSA63J-221X	MG RESISTOR		
	R 609	NRSA63J-221X	MG RESISTOR		
	R 610	NRSA63J-221X	MG RESISTOR		
	R 611	NRSA63J-332X	MG RESISTOR		
	R 612	NRSA63J-103X	MG RESISTOR		
	R 613	NRSA63J-822X	MG RESISTOR		
	R 615	NRSA63J-432X	MG RESISTOR		
	R 617	NRSA63J-103X	MG RESISTOR		
	R 618	NRSA63J-103X	MG RESISTOR		
	R 619	NRSA63J-221X	MG RESISTOR		
	R 620	NRSA63J-221X	MG RESISTOR		
	R 621	NRSA63J-221X	MG RESISTOR		
	R 622	NRSA63J-750X	MG RESISTOR		
	R 623	NRSA63J-101X	MG RESISTOR		
	R 625	NRSA63J-101X	MG RESISTOR		
	R 627	NRSA63J-472X	MG RESISTOR		
	R 628	NRSA63J-183X	MG RESISTOR		
	R 629	NRSA63J-101X	MG RESISTOR		
	R 633	NRSA63J-221X	MG RESISTOR		
	R 639	NRSA63J-472X	MG RESISTOR		
	R 641	NRSA63J-102X	MG RESISTOR		
	R 642	NRSA63J-103X	MG RESISTOR		
	R 643	NRSA63J-101X	MG RESISTOR		
	R 644	NRSA63J-563X	MG RESISTOR		
	R 645	NRSA63J-102X	MG RESISTOR		
	R 646	NRSA63J-103X	MG RESISTOR		
	R 647	NRSA63J-225X	MG RESISTOR		
	R 648	NRSA63J-472X	MG RESISTOR		
	R 649	NRSA63J-1R0X	MG RESISTOR		
	R 650	NRSA63J-0R0X	MG RESISTOR		
	R 651	NRSA63J-0R0X	MG RESISTOR		
	R 652	NRSA63J-1R0X	MG RESISTOR		
	R 657	NRSA63J-103X	MG RESISTOR		
	R 661	NRSA63J-221X	MG RESISTOR		

# RX-8000VBK

## ■ Electrical parts list ( AC-3 board )

Block No. 05

A	Item	Parts number	Parts name	Remarks	Area
	R 662	NRSA63J-221X	MG RESISTOR		
	R 663	NRSA63J-221X	MG RESISTOR		
	R 664	NRSA63J-221X	MG RESISTOR		
	R 669	NRSA63J-103X	MG RESISTOR		
	R 670	NRSA63J-103X	MG RESISTOR		
	R 671	NRSA63J-103X	MG RESISTOR		
	R 672	NRSA63J-105X	MG RESISTOR		
	R 673	NRSA63J-432X	MG RESISTOR		
	R 674	NRSA63J-432X	MG RESISTOR		
	R 675	NRSA63J-432X	MG RESISTOR		
	R 676	NRSA63J-432X	MG RESISTOR		
	R 677	NRSA63J-822X	MG RESISTOR		
	R 678	NRSA63J-822X	MG RESISTOR		
	R 679	NRSA63J-822X	MG RESISTOR		
	R 680	NRSA63J-822X	MG RESISTOR		
	R 681	NRSA63J-103X	MG RESISTOR		
	R 682	NRSA63J-103X	MG RESISTOR		
	R 683	NRSA63J-0R0X	MG RESISTOR		
	R 685	NRSA63J-103X	MG RESISTOR		
	R 686	NRSA63J-151X	MG RESISTOR		
	R 691	NRSA63J-104X	MG RESISTOR		
	R 692	NRSA63J-104X	MG RESISTOR		
	R 695	NRSA63J-104X	MG RESISTOR		
	R 696	NRSA63J-104X	MG RESISTOR		
	R 697	NRSA63J-104X	MG RESISTOR		
	R 698	NRSA63J-104X	MG RESISTOR		
	R2500	NRSA63J-102X	MG RESISTOR		
	R2501	NRSA63J-104X	MG RESISTOR		
	R2502	NRSA63J-104X	MG RESISTOR		
	R2503	NRSA63J-183X	MG RESISTOR		
	R2504	NRSA63J-183X	MG RESISTOR		
	R2505	NRSA63J-103X	MG RESISTOR		
	R2506	NRSA63J-103X	MG RESISTOR		
	R2507	NRSA63J-103X	MG RESISTOR		
	R2508	NRSA63J-103X	MG RESISTOR		
	R2509	NRSA63J-103X	MG RESISTOR		
	R2510	NRSA63J-103X	MG RESISTOR		
	R2511	NRSA63J-102X	MG RESISTOR		
	R2512	NRSA63J-102X	MG RESISTOR		
	R2513	NRSA63J-102X	MG RESISTOR		
	R2514	NRSA63J-102X	MG RESISTOR		
	R2515	NRSA63J-102X	MG RESISTOR		
	R2516	NRSA63J-102X	MG RESISTOR		
	R2517	NRSA63J-102X	MG RESISTOR		
	R2518	NRSA63J-102X	MG RESISTOR		
	R2519	NRSA63J-102X	MG RESISTOR		
	R2520	NRSA63J-102X	MG RESISTOR		
	R2521	NRSA63J-102X	MG RESISTOR		
	R2522	NRSA63J-102X	MG RESISTOR		
	R2523	NRSA63J-102X	MG RESISTOR		
	R2524	NRSA63J-102X	MG RESISTOR		
	R2525	NRSA63J-102X	MG RESISTOR		
	R2526	NRSA63J-102X	MG RESISTOR		
	R2527	NRSA63J-104X	MG RESISTOR		
	R2528	NRSA63J-104X	MG RESISTOR		
	R2529	NRSA63J-103X	MG RESISTOR		
	R2530	NRSA63J-103X	MG RESISTOR		
	R2531	NRSA63J-113X	MG RESISTOR		
	R2532	NRSA63J-113X	MG RESISTOR		
	R2533	NRSA63J-103X	MG RESISTOR		
	R2534	NRSA63J-103X	MG RESISTOR		
	R2535	NRSA63J-103X	MG RESISTOR		
	R2536	NRSA63J-103X	MG RESISTOR		
	R2537	NRSA63J-104X	MG RESISTOR		
	R2538	NRSA63J-104X	MG RESISTOR		
	R2541	NRSA63J-113X	MG RESISTOR		
	R2542	NRSA63J-113X	MG RESISTOR		

A	Item	Parts number	Parts name	Remarks	Area
	R2543	NRSA63J-103X	MG RESISTOR		
	R2544	NRSA63J-103X	MG RESISTOR		
	R2545	NRSA63J-562X	MG RESISTOR		
	R2546	NRSA63J-562X	MG RESISTOR		
	R2547	NRSA63J-104X	MG RESISTOR		
	R2548	NRSA63J-104X	MG RESISTOR		
	R2550	NRSA63J-272X	MG RESISTOR		
	R2551	NRSA63J-103X	MG RESISTOR		
	R2552	NRSA63J-103X	MG RESISTOR		
	R2553	NRSA63J-153X	MG RESISTOR		
	R2554	NRSA63J-153X	MG RESISTOR		
	R2555	NRSA63J-822X	MG RESISTOR		
	R2556	NRSA63J-822X	MG RESISTOR		
	R2557	NRSA63J-103X	MG RESISTOR		
	R2558	NRSA63J-223X	MG RESISTOR		
	R2560	NRSA63J-105X	MG RESISTOR		
	R2561	NRSA63J-104X	MG RESISTOR		
	R2562	NRSA63J-104X	MG RESISTOR		
	R2563	NRSA63J-103X	MG RESISTOR		
	R2564	NRSA63J-103X	MG RESISTOR		
	R2565	NRSA63J-302X	MG RESISTOR		
	R2566	NRSA63J-302X	MG RESISTOR		
	R2567	NRSA63J-103X	MG RESISTOR		
	R2568	NRSA63J-103X	MG RESISTOR		
	R2571	NRSA63J-102X	MG RESISTOR		
	R2572	NRSA63J-102X	MG RESISTOR		
	R2573	NRSA63J-102X	MG RESISTOR		
	R2574	NRSA63J-102X	MG RESISTOR		
	R2575	NRSA63J-102X	MG RESISTOR		
	R2576	NRSA63J-102X	MG RESISTOR		
	R2577	NRSA63J-104X	MG RESISTOR		
	R2578	NRSA63J-104X	MG RESISTOR		
	R2581	NRSA63J-104X	MG RESISTOR		
	R2582	NRSA63J-104X	MG RESISTOR		
	R2583	NRSA63J-103X	MG RESISTOR		
	R2584	NRSA63J-223X	MG RESISTOR		
	R2585	NRSA63J-302X	MG RESISTOR		
	R2586	NRSA63J-332X	MG RESISTOR		
	R2587	NRSA63J-103X	MG RESISTOR		
	R2588	NRSA63J-103X	MG RESISTOR		
	R2589	NRSA63J-104X	MG RESISTOR		
	R2590	NRSA63J-333X	MG RESISTOR		
	R2591	NRSA63J-102X	MG RESISTOR		
	R2592	NRSA63J-333X	MG RESISTOR		
	R2593	NRSA63J-102X	MG RESISTOR		
	R2594	NRSA63J-333X	MG RESISTOR		
	R2595	NRSA63J-102X	MG RESISTOR		
	R2596	NRSA63J-102X	MG RESISTOR		
	R2597	NRSA63J-104X	MG RESISTOR		
	R2598	NRSA63J-104X	MG RESISTOR		
	UN661	GP1FA550RZ	OPT RECEIVER		
	UN662	GP1FA550RZ	OPT RECEIVER		
	UN663	GP1FA550TZ	OPT TRANSMITTER		
	UN664	GP1FA550RZ	OPT RECEIVER		
X-631	NAX0385-001X	CRYSTAL			
X-671	NAX0275-001X	C OSCILLATOR			

## ■ Electrical parts list ( Tuner board )

Block No. 06


▲	Item	Parts number	Parts name	Remarks	Area
	AT101	QNB0014-001	ANT TERMINAL		
BK 1	LV31618-001A	SHIELD BKT			
C 101	NCB21HK-103X	C CAPACITOR			
C 103	NCB21HK-223X	C CAPACITOR			
C 105	NCB21HK-223X	C CAPACITOR			
C 107	QEKC1CM-226Z	E CAPACITOR	22MF 20% 16V		
C 111	NCB21HK-473X	C CAPACITOR			
C 112	NDC21HJ-120X	C CAPACITOR			
C 121	NDC21HJ-120X	C CAPACITOR			
C 122	NDC21HJ-120X	C CAPACITOR			
C 123	NCB21HK-473X	C CAPACITOR			
C 126	NCS21HJ-101X	C CAPACITOR			
C 128	QENC1HM-474Z	NP E CAPACITOR	.47MF 20% 50V		
C 129	NCB21HK-102X	C CAPACITOR	C/M B		
C 130	QEKC1AM-107Z	E CAPACITOR	100MF 20% 10V		
C 133	QEKC1CM-226Z	E CAPACITOR	22MF 20% 16V		
C 134	NCB21HK-222X	C CAPACITOR			
C 135	NCB21HK-223X	C CAPACITOR			
C 136	QEKC1HM-105Z	E CAPACITOR	1.0MF 20% 50V		
C 137	NCB21HK-331X	C CAPACITOR			
C 138	NCB21HK-473X	C CAPACITOR			
C 139	NCB21HK-333X	C CAPACITOR			
C 140	NCB21HK-333X	C CAPACITOR			
C 141	NCB21HK-473X	C CAPACITOR			
C 143	NCB21HK-223X	C CAPACITOR			
C 144	NCB21HK-473X	C CAPACITOR			
C 146	QEKC1HM-105Z	E CAPACITOR	1.0MF 20% 50V		
C 147	QEKC1HM-105Z	E CAPACITOR	1.0MF 20% 50V		
C 148	QEKC1HM-224Z	E CAPACITOR	.22MF 20% 50V		
C 149	QEKC1HM-105Z	E CAPACITOR	1.0MF 20% 50V		
C 150	QEKC1CM-226Z	E CAPACITOR	22MF 20% 16V		
C 156	QDGB1HK-102Y	C CAPACITOR			
C 157	NCB21HK-473X	C CAPACITOR			
C 158	QEKC1CM-226Z	E CAPACITOR	22MF 20% 16V		
C 161	QEK41CM-106	E CAPACITOR	10MF 20% 16V		
C 162	QEK41CM-106	E CAPACITOR	10MF 20% 16V		
C 163	NCB21HK-223X	C CAPACITOR			
C 164	NCB21HK-473X	C CAPACITOR			
C 168	QEKC1HM-105Z	E CAPACITOR	1.0MF 20% 50V		
C 184	QEKC1CM-107Z	E CAPACITOR	100MF 20% 16V		
C 185	QEK41CM-106	E CAPACITOR	10MF 20% 16V		
C 186	QEK41CM-106	E CAPACITOR	10MF 20% 16V		
CF101	QAX0419-001Z	C FILTER			
CF102	QAX0604-001Z	C FILTER			
CF103	QAX0519-001Z	C FILTER			
CN111	QGB2501K2-12	CONNECTOR			
D 121	ISS133-T2	SI DIODE			
D 123	ISS133-T2	SI DIODE			
D 124	ISS133-T2	SI DIODE			
D 125	ISS133-T2	SI DIODE			
D 129	ISS133-T2	SI DIODE			
IC102	LA1838	IC			
IC121	LC72136N	IC			
Q 102	2SC535/BC-T	TRANSISTOR			
Q 103	2SC461/BC-T	TRANSISTOR			
Q 121	DTA124ESA-T	D. TRANSISTOR			
R 103	NRSA02J-221X	MG RESISTOR			
R 104	NRSA02J-272X	MG RESISTOR			
R 105	NRSA02J-391X	MG RESISTOR			
R 106	NRSA02J-102X	MG RESISTOR			
R 107	NRSA02J-391X	MG RESISTOR			
R 108	NRSA02J-332X	MG RESISTOR			
R 109	NRSA02J-221X	MG RESISTOR			
R 115	NRSA02J-104X	MG RESISTOR			
R 119	NRSA02J-103X	MG RESISTOR			
R 122	NRSA02J-472X	MG RESISTOR			
R 124	NRSA02J-222X	MG RESISTOR			

▲	Item	Parts number	Parts name	Remarks	Area
	R 126	NRSA02J-562X	MG RESISTOR		
	R 127	NRSA02J-822X	MG RESISTOR		
	R 128	NRSA02J-472X	MG RESISTOR		
	R 129	NRSA02J-222X	MG RESISTOR		
	R 130	QRZ9005-680X	F RESISTOR	68 1/W	
	R 132	NRSA02J-393X	MG RESISTOR		
	R 133	NRSA02J-392X	MG RESISTOR		
	R 134	NRSA02J-102X	MG RESISTOR		
	R 140	NRSA02J-183X	MG RESISTOR		
	R 141	NRSA02J-102X	MG RESISTOR		
	R 142	NRSA02J-470X	MG RESISTOR		
	R 143	NRSA02J-562X	MG RESISTOR		
	R 144	NRSA02J-332X	MG RESISTOR		
	R 145	NRSA02J-103X	MG RESISTOR		
	R 146	NRSA02J-392X	MG RESISTOR		
	R 147	NRSA02J-332X	MG RESISTOR		
	R 150	NRSA02J-331X	MG RESISTOR		
	R 157	NRSA02J-682X	MG RESISTOR		
	R 158	NRSA02J-682X	MG RESISTOR		
	R 161	NRSA02J-102X	MG RESISTOR		
	R 162	NRSA02J-102X	MG RESISTOR		
	R 182	NRSA02J-103X	MG RESISTOR		
	R 183	NRSA02J-103X	MG RESISTOR		
	R 184	NRSA02J-103X	MG RESISTOR		
	RF101	OAU0124-002	FRONT END		
	T 111	OQR0796-001	COIL BLOCK		
	T 142	OQR0973-001	IFT		
	X 121	QAX0402-001	CRYSTAL		

## Packing materials and accessories parts list

Block No. M 2 M M

Block No. M 3 M M



### Packing parts list

Block No. M2MM

▲	Item	Parts number	Parts name	Q'ty	Description	Area
	P 1	LV30044-0F9A	CARTON BOX	1	RX-8000VBK	
	P 2	LV20039-002A	PACKING PAD	1		
	P 3	LV20040-001A	PACKING PAD	1		
	P 5	QPC06507015P	POLY BAG	1		
	P 6	LV32034-003A	SHEET	2		
	P 8	QPA02503505P	POLY BAG	1		

### Accessories parts list

Block No. M3MM

▲	Item	Parts number	Parts name	Q'ty	Description	Area
	A 1	LVT0427-002A	I.BOOK(VER.C)	1	(ENG.FRE)	
		LVT0427-001A	I.BOOK(VER.J)	1	(ENG)	
	A 3	EWP503-001C	ANT.WIRE	1		
	A 4	QAL0204-001	AM LOOP ANT	1		
	A 5	BT-51020-2	J=REGIST CARD	1	VER.J	
	A 6	RM-SRX8000J	REMOCON	1		
	A 7	-----	BATTERY	1		
	A 8	BT-20044G	SAFETY SHEET	1	VER.J	
	A 9	BT-52004-1	WARRANTY CARD	1	VER.C	
	A 10	BT-20071B	SERVICE NETWORK	1	VER.C	

**-MEMO-**

**RX-8000VBK**



**JVC**

VICTOR COMPANY OF JAPAN, LIMITED  
AUDIO DIVISION, 10-1, 1chome, Ohwatari-machi, Maebashi-city, 371-8543, Japan

No.20812

 Printed in Japan  
200002(V)