



CA-D702T
CA-D752TR

JVC

SERVICE MANUAL

COMPACT COMPONENT SYSTEM

CA-D702T / SP-D702 CA-D752TR / SP-D752



COMPACT
DISC
DIGITAL AUDIO

C-R-D-S EON

Area Suffix	
CA-D702T	
UT	Taiwan
US	Singapore
UB	Hong Kong
UP	Korea
UX	Saudi arabia
U	Universal
A	Australia
CA-D752TR	
B	U.K
E	Continental Europe
EN	Northern Europe
EE	Eastern Europe

Contents

Safety Precaution	1-2	Maintenance of Laser Pickup	2-30
Instructions	1-5~28	Replacement of Laser Pickup	2-30
Description of Major ICs	2-1	Adjustment Procedures	2-31
Internal Connection of FL Display	2-15	Block Diagrams	2-35
Disassembly Procedures	2-16	Schematic Diagrams	2-37
Flow of Functional Operation		Printed Circuit Board	2-49~54
Unit TOC Read	2-29	Parts List	3-1~27


Safety Precautions

1. This design of this product contains special hardware and many circuits and components specially for safety purposes. For continued protection, no changes should be made to the original design unless authorized in writing by the manufacturer. Replacement parts must be identical to those used in the original circuits. Services should be performed by qualified personnel only.
2. Alterations of the design or circuitry of the product should not be made. Any design alterations of the product should not be made. Any design alterations or additions will void the manufacturer's warranty and will further relieve the manufacturer of responsibility for personal injury or property damage resulting therefrom.
3. Many electrical and mechanical parts in the products have special safety-related characteristics. These characteristics are often not evident from visual inspection nor can the protection afforded by them necessarily be obtained by using replacement components rated for higher voltage, wattage, etc. Replacement parts which have these special safety characteristics are identified in the Parts List of Service Manual. Electrical components having such features are identified by shading on the schematics and by (▲) on the Parts List in the Service Manual. The use of a substitute replacement which does not have the same safety characteristics as the recommended replacement parts shown in the Parts List of Service Manual may create shock, fire, or other hazards.
4. The leads in the products are routed and dressed with ties, clamps, tubings, barriers and the like to be separated from live parts, high temperature parts, moving parts and/or sharp edges for the prevention of electric shock and fire hazard. When service is required, the original lead routing and dress should be observed, and it should be confirmed that they have been returned to normal, after re-assembling.
5. Leakage current check (Electrical shock hazard testing)

After re-assembling the product, always perform an isolation check on the exposed metal parts of the product (antenna terminals, knobs, metal cabinet, screw heads, headphone jack, control shafts, etc.) to be sure the product is safe to operate without danger of electrical shock. Do not use a line isolation transformer during this check.

 - Plug the AC line cord directly into the AC outlet. Using a "Leakage Current Tester", measure the leakage current from each exposed metal parts of the cabinet, particularly any exposed metal part having a return path to the chassis, to a known good earth ground. Any leakage current must not exceed 0.5mA AC (r.m.s.)
 - Alternate check method

Plug the AC line cord directly into the AC outlet. Use an AC voltmeter having, 1,000 ohms per volt or more sensitivity in the following manner. Connect a $1,500\Omega$ 10W resistor paralleled by a $0.15\mu F$ AC-type capacitor between an exposed metal part and a known good earth ground. Measure the AC voltage across the resistor with the AC voltmeter. Move the resistor connection to each exposed metal part, particularly any exposed metal part having a return path to the chassis, and measure the AC voltage across the resistor. Now, reverse the plug in the AC outlet and repeat each measurement. Voltage measured must not exceed 0.75 V AC (r.m.s.). This corresponds to 0.5 mA AC (r.m.s.).



Warning

1. This equipment has been designed and manufactured to meet international safety standards.
2. It is the legal responsibility of the repairer to ensure that these safety standards are maintained.
3. Repairs must be made in accordance with the relevant safety standards.
4. It is essential that safety critical components are replaced by approved parts.
5. If mains voltage selector is provided, check setting for local voltage.

⚠ CAUTION Burrs formed during molding may be left over on some parts of the chassis. Therefore, pay attention to such burrs in the case of performing repair of this system.

Safety Precautions (U.K only)

1. This design of this product contains special hardware and many circuits and components specially for safety purposes. For continued protection, no changes should be made to the original design unless authorized in writing by the manufacturer. Replacement parts must be identical to those used in the original circuits.
2. Any unauthorised design alterations or additions will void the manufacturer's guarantee ; furthermore the manufacturer cannot accept responsibility for personal injury or property damage resulting therefrom.
3. Essential safety critical components are identified by () on the Parts List and by shading on the schematics, and must never be replaced by parts other than those listed in the manual. Please note however that many electrical and mechanical parts in the product have special safety related characteristics. These characteristics are often not evident from visual inspection. Parts other than specified by the manufacturer may not have the same safety characteristics as the recommended replacement parts shown in the Parts List of the Service Manual and may create shock, fire, or other hazards.
4. The leads in the products are routed and dressed with ties, clamps, tubings, barriers and the like to be separated from live parts, high temperature parts, moving parts and/or sharp edges for the prevention of electric shock and fire hazard. When service is required, the original lead routing and dress should be observed, and it should be confirmed that they have been returned to normal, after re-assembling.

Warning

1. Service should be performed by qualified personnel only.
2. This equipment has been designed and manufactured to meet international safety standards.
3. It is the legal responsibility of the repairer to ensure that these safety standards are maintained.
4. Repairs must be made in accordance with the relevant safety standards.
5. It is essential that safety critical components are replaced by approved parts.
6. If mains voltage selector is provided, check setting for local voltage.

 **CAUTION** Burrs formed during molding may be left over on some parts of the chassis. Therefore, pay attention to such burrs in the case of performing repair of this system.

Important for Laser Products

1.CLASS 1 LASER PRODUCT

2.DANGER : Invisible laser radiation when open and interlock failed or defeated. Avoid direct exposure to beam.
3.CAUTION : There are no serviceable parts inside the Laser Unit. Do not disassemble the Laser Unit. Replace the complete Laser Unit if it malfunctions.

4.CAUTION : The compact disc player uses invisible laserradiation and is equipped with safety switches which prevent emission of radiation when the drawer is open and the safety interlocks have failed or are defeated. It is dangerous to defeat the safety switches.

VARNING : Osynlig laserstrålning är denna del är öppnad och spärren är urkopplad. Betrakta ej strålen.

VARO : Avattaessa ja suojalukitus ohittetaessa olet alittiina näkymättömälle lasersäteilylle. Älä katso sääteeseen.

5.CAUTION : If safety switches malfunction, the laser is able to function.

6.CAUTION : Use of controls, adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

ADVARSEL : Usynlig laserstråling ved åbning , når sikkerhedsafbrydere er ude af funktion. Undgå udsættelse for stråling.

ADVARSEL : Usynlig laserstråling ved åpning,når sikkerhetsbryteren er avslott. unngå utsettelse for stråling.

REPRODUCTION AND POSITION OF LABELS

WARNING LABEL



(Except for the U.S.A. and Canada and UP)

DANGER : Invisible laser radiation
when open and interlock or
defeated.
AVOID DIRECT EXPOSURE TO
BEAM (e)

VARO : Avattaessa ja suojalukitus
ohittetaessa olet alittiina
näkymättömälle lasersäteilylle. Älä
katso sääteeseen. (d)

VARNING : Osynlig laserstrålning är
denna del är öppnad och spärren är
urkopplad. Betrakta ej strålen. (s)

ADVARSEL :Usynlig laserstråling
ved åbning , når
sikkerhedsafbrydere er ude af
funktion. Undgå utsættelse for
stråling. (f)



JVC

Warnings, Cautions and Others / Warnings, Achtung und sonstige Hinweise /Mises en garde, précautions et indications diverses /Waarschuwingen, voorzorgen en andere mededelingen/Avisos, precauciones y otras notas / Avertenze e precauzioni da osservare

Instructions

CA-D702T/D752TR

Caution — Ⓛ switch!
Disconnect the mains plug to shut the power off completely. The Ⓛ switch in any position does not disconnect the mains line. The power can be remote controlled.

Achtung — Ⓛ-Schalter!
Den Netzstecker aus der Steckdose ziehen, um die Stromversorgung in keiner Stellung der Fernbedienung ein- und ausschalten. Die Stromversorgung kann mit der Fernbedienung eingeschaltet werden.

Attention — Commutateur Ⓛ!
Déconnecter la ligne de secteur pour couper complètement le courant. Le commutateur Ⓛ ne coupe jamais complètement la ligne de secteur, quelle que soit sa position. Le courant peut être télécommandé.

Vorichtung — Ⓛ/ schließen!
Um den Stromkreis zu trennen, zieht der Stecker uit het stopcontact. Anders zal er altijd een geringe hoeveelheid stroom naar het apparaat lopen, ongacht de stand van de Ⓛ/schakelaar. U kunt het apparaat niet met de afstandsbediening aan- en uitschakelen.

Precaución — Interruptor Ⓛ!
Desconectar la línea de sectores para cortar completamente el corriente. El interruptor Ⓛ/ne corps jamás completamente la linea de sectores, quelle que soit sa position. Le corriente può essere telecomandata.

Aviso — Interruptor Ⓛ!
Desconectar la alimentación para desactivar la alimentación totalmente. Cuálquier que sea la posición del interruptor Ⓛ/ne linea de alimentación no es cortada completamente. La alimentación puede ser controlada remotamente.

Attenzione — Interruttore Ⓛ!
Disinnestare la spina del cavo di alimentazione dalla presa della rete elettrica per staccare completamente l'alimentazione. L'interruttore Ⓛ/ne linea di alimentazione non è staccata alla linea di alimentazione principale. È possibile il controllo remoto dell'alimentazione.

IMPORTANT for the U.K.

DO NOT cut off the mains plug from this equipment. If the plug fitted is not suitable for the power points in your home or the cable is too short to reach a power point, then obtain an approved safe safety approved extension lead or consult your dealer.

BE SURE to replace the fuse only with an identical approved type, as originally fitted.
If nonetheless the mains plug is cut off ensure to remove the fuse and dispose of the plug immediately to avoid a possible shock hazard by inadvertent connection to the mains supply.

If this product is not supplied fitted with a mains plug then follow the instructions given below.

IMPORTANT:

DO NOT make any connection to the terminal which is marked with the letter E or the safety earth symbol or coloured green or green-and-yellow.

The wires in the mains lead on this product are coloured in accordance with the following code:

Blue : Live

Brown : Neutral

As these colours may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows:

The wire which is coloured blue must be connected to the terminal which is marked with the letter N or coloured black.

The wire which is coloured brown must be connected to the terminal which is marked with the letter L or coloured red.

IF IN DOUBT - CONSULT A COMPETENT ELECTRICIAN.

Per l'Italia:

'Si dichiara che il questo prodotto di marca JVC è conforme alle prescrizioni del Decreto Ministeriale n.548 del 20/08/05 pubblicato sulla Gazzetta Ufficiale della Repubblica Italiana n.361 del 28/12/95.'

CAUTION

To reduce the risk of electrical shocks, fire, etc.:

1. Do not remove screws, covers or cabinet.
2. Do not expose this appliance to rain or moisture.

ACHTUNG

Zur Vermeidung von elektrischen Schlägen, Bränden, etc.:

1. Keine Schrauben, Rosen oder Abdichtungen entfernen und das Gehäuse nicht öffnen.
2. Dieses Gerät wieder Regen noch Feuchtigkeit aussetzen.

ATTENTION

Afin de réduire tout risque d'électrocution, d'incendie, etc.:

1. Ne pas enlever les vis ni les parneaux et ne pas ouvrir le coffret de l'appareil.
2. Ne pas exposer l'appareil à la pluie ni à l'humidité.

VOORZICHTIG
Ter verminderen van gevaar voor brand, elektrische schokken, enz.:

1. Verwijder geen Schroeven, deksels of behuizing.
2. Stel het toestel niet bloot aan regen of vocht.

PRECAUCIÓN

Para reducir riesgos de choques eléctricos, incendio, etc.

1. No extraiga los tornillos ni las cubiertas ni la caja.
2. No exponga este aparato a la lluvia o a la humedad.

ATTENZIONE
Per ridurre il rischio di shock elettrici, incendi, ecc.:

1. Non togliere viti, coperture o scatola.
2. Non esporre l'apparecchio alla pioggia e all'umidità.

INSTRUCTIONS
BEDIENUNGSANLEITUNG
MANUEL D'INSTRUCTIONS
GEBRUIKSAANWIJZING
MANUAL DE INSTRUCCIONES
ISTRUZIONI

For Customer Use:
Enter below the Model No. and Serial No. which are located either on the rear, bottom or side of the cabinet. Retain this information for future reference.
Model No. _____
Serial No. _____

GV70004-006A
[E]


G1

COMPACT COMPONENT SYSTEM
KOMPAKT-KOMPONENTEN-SYSTEM
SISTÈME DE COMPOSANTS COMPACT
KOMPACTO KOMPONENTEN-SYSTEEM
SISTEMAS DE COMPONENTES COMPACTOS
IMPIANTO A COMPONENTI COMPATTO

CA-D752TR

COMPACT
d5c
DIGITAL AUDIO

OR-D·S EON





Caution: Proper Ventilation
To avoid risk of electric shock and fire, and to prevent damage, locate the apparatus as follows:
 1 Front: No obstructions and open spacing.
 2 Sides/Top/Back: No obstacles should be placed in the areas shown by the dimensions below.
 3 Bottom: Place on the level surface. Maintain an adequate air path for ventilation by placing on a stand with a height of 10 cm or more.

Achtung: Ausreichende Belüftung
Zur Vermeidung von elektrischen Schlägen, Feuer und sonstigen Schäden sollte das Gerät unter folgenden Bedingungen aufgestellt werden:
 1 Vorderseite: Hindernisfrei und gut zugänglich.
 2 Seiten- und Rückwände: Hindernisse in allen gedeckten Abständen (s. Abbildung).
 3 Unterseite: Die Stofffläche muss absolut eben sein. Sorgen Sie für ausreichende Lufzirkulation durch Ausstellung auf einem Stand mit mindestens 10 cm Höhe.

Attention: Aération correcte
Pour prévenir tout risque de décharge électrique ou d'incendie et éviter toute déformation, installez l'appareil de la manière suivante:
 1 Avant: Bien dégagé de tout objet.
 2 Côtés/dessous/dessous:
 Assurez-vous que rien ne bloque les espaces indiqués sur le schéma ci-dessous.
 3 Dessous:
 Posez l'appareil sur une surface plane et horizontale. Veillez à ce que sa ventilation correcte puisse se faire en placant sur un support d'au moins dix centimètres de hauteur.

Attention: Ventilation correcte
Para evitar el riesgo de descargas eléctricas e incendio y prevenir posibles daños, instale el equipo en un lugar que cumpla los siguientes requisitos:
 1 Parte frontal: Sin obstrucciones, espacio abierto.
 2 Lados/oposición, espacio abierto.
 3 Parte inferior: No debe haber ninguna obstrucción en las áreas mostradas con las dimensiones de la siguiente figura.
 Sitúe el equipo sobre una superficie nivelada. Mantenga un espacio adecuado para permitir el paso del aire y una correcta ventilación, situando el equipo sobre un soporte de 10 o más cms de altura.

Attenzione: Per una corretta ventilazione
Per prevenire il rischio di scosse elettriche o di incendio ed evitare possibili danni, collocare le apparecchiature nel modo seguente:
 1 Parte anteriore: Nessun ostacolo e spazio libero.
 2 Lati/Parte superiore/Fondo:
 Lasciare libere le zone indicate dalle dimensioni di seguito
 3 Base:
 Collocare su una superficie piana. Consentire un'adeguata ventilazione dell'impianto appoggiandolo su un tavolino alto almeno 10 cm.



IMPORTANT FOR LASER PRODUCTS/WICHTIGER HINWEIS FÜR LASER-PRODUKTE / IMPORTANTE PARA LOS PRODUCTOS LASER/ IMPORTANTE PER I PRODOTTI LASER

BELANGRIJKE INFORMATIE VOOR DE LASERPRODUKTEN / VERKLARING VAN DE LABELS/REPRODUCTION DE ETIQUETTES/VERKLARING VAN DE LABELS/REPDUCCION DE ETIQUETAS/REPDUCCIONE DELLE ETICHETTE

REPRODUCTION OF LABELS/ANBRINGUNGSORT FÜR LASER-PRODUKTER REPDUCTION DES ETIQUETTES/VERKLARING VAN DE LABELS/REPDUCCION DE ETIQUETAS/REPDUCCIONE DELLE ETICHETTE

1 CLASSIFICATION LABEL, PLACED ON REAR ENCLOSURE

1 KLASIFICATIELABEL, OP DE ACHTERZIJDE VAN HET APPARAAT

1 ETIQUETA DE CLASIFICACIÓN, PEGADA EN LA PARTE POSTERIOR DE LA CAJA

1 RIVESTIMENTO POSTERIORE



2 WARNING LABEL, PLACED INSIDE THE UNIT

2 WARNEKETTE IM GERÄT/ETIQUETTE AVVERTIMENTO NELL'APPARECCHIO

2 ETIQUETA ADVERTENCIA, SITUADA ALL'INTERNO DELL'APPARECCHIO

2 WAARSCHUWINGSLABEL IN HET APPARAAT

2 ETIQUETA DE ADVERTENCIA, PEGADA EN EL INTERIOR DE LA UNIDAD

2 ETICHETTA DI AVVERTENZA, SITUATA ALL'INTERNO DELL'APPARECCHIO

2 ETIQUETA DE CLASIFICACIÓN, PEGADA EN LA PARTE POSTERIOR DE LA CAJA

2 ETIQUETA DI CLASSIFICAZIONE, SITUATA SUL RIVESTIMENTO POSTERIORE

2 ETIQUETA DE ADVERTENCIA, PEGADA EN EL INTERIOR DE LA UNIDAD

2 ETICHETTA DI AVVERTENZA, SITUATA ALL'INTERNO DELL'APPARECCHIO

1 PRODUCTO LASER CLASE 1

1 PRODUKT LASER KLASSE 1

1 PRODUITO LASER CLASSE 1

1 PRODUCE LASER CLASSE 1

Thank you for purchasing the JV-C Compact Component System.
We hope it will be a valued addition to your home, giving you years of enjoyment.
Be sure to read this instruction manual carefully before operating your new stereo system.
Here you will find all the information you need to set up and use the system.
For questions that are not answered in the manual, contact your dealer.

Features

Here are some of the things that make your System powerful and easy to use.

- The controls and operations have been designed to make them very easy to use, so you can spend your time listening to music.
- With the One Touch Operation feature of JV-C's **COMPU PLAY**, you can turn on the System and start the radio, the Cassette Deck, or the CD Player with a single touch.
- To get such great sound from such a compact package, the System has:
- Built-in **Dolby Pro Logic** and **Dolby 3ch Logic** effects. Combined with the optional centre and rear speakers, this allows you to enjoy the dynamic, pulsating sound effects of a cinema. Programmed sound mode includes live surround effects **D. CLUB**, **HALL**, and **STADIUM**. It also includes **SEA** Sound Effect Amplifier effects **ROCK**, **POP**, and **CLASSIC**. You can also register up to three customized settings (**MANUAL 1** to **3**).
- The System is compatible with RDS (Radio Data System) broadcasting.
- The EON data enables you to stand-by for desired information.
- The PTV Search function searches for programmes in the category you wish.
- In addition, Radio Text can be displayed using data sent by station.
- CD changer function can operate 3 discs.
- Discs can be changed during play using the **TRIPLE TRAY**.
- Continuous, random or program play of 3 discs.
- The three timers, **Daily Timer**, **Recording Timer**, and **Sleep Timer** are extremely easy to set.

Easy operation



COMPU PLAY

Great sound

RDS/EON

Triple Tray

Three timers

Table of Contents

English
English

Features	23
How This Manual Is Organized	24
IMPORTANT PRECAUTIONS	24
Getting Started	3
Accessories	3
How to Put Batteries in the Remote Control	3
Using the Remote Control	3
Connecting the FM Antenna	4
Connecting the AM (MW/LW) Antenna	4
Connecting the Speakers	5
Connecting the Optional Speakers	5
Connecting Auxiliary Equipment	6
COMPU PLAY	7
Common Operations	8
DEMO Mode	8
Setting the Clock	9
Turning the Power On and Off	9
Turning the System On	9
Turning the System Off	9
Adjusting the Volume	10
Balance Adjustment	10
Reinforcing the Bass Sound	10
Sound Modes	11
Customizing a Sound Mode	11
When a Rear Speaker is Connected	12
Adjusting the Rear Speaker Level	12
Listening to Auxiliary Equipment	13
Dolby Surround	14
Preparing the Dolby Surround	15
Getting Ready To Use Dolby Pro Logic	16
Speaker Arrangements for Dolby Pro Logic	16
Setting-up Dolby Pro Logic	16
Getting Ready To Use Dolby 3 Channel Logic	17
Speaker Arrangements for Dolby 3 Channel Logic	17
Setting the Daily Timer	17
Turning the Daily Timer On and Off	18
Setting the Recording Timer	19
Turning the Recording Timer On and Off	19
Setting the Sleep Timer	20
Timer Priority	21
Care and Maintenance	42
Troubleshooting	43
Specifications	44
Using the CD Player	23
Loading CDs	24
Basics of Using the CD Player —	24
Continuous Play	24
Playing a CD	24
Selecting a Track	25
Locating a Track with the Remote Control	25
Directly	25
Fast Forward / Reverse	25
Changing Discs While Playing	25
Programming the Playing Order of the Tracks	26
Checking the Program	27
Changing the Program	27
Random Play	27
Repeating a Selection or the Discs	28
Tray Lock Function	28
Locking the Trays	28
Unlocking the Trays	28
Using the Cassette Deck (Playing)	29
Regular Play	30
Fast Left and Fast Right	30
Music Scan	30
Finding the Beginning of the Current Selection	30
Finding the Beginning of the Next Selection	30
Reverse Mode	31
Using the Cassette Deck (Recording)	32
Things to Know before You Start Recording	32
Standard Recording	33
Recording AM Station to Tape	34
CD Direct Recording	34
Auto Edit Recording	34
Tape to Tape Recording (Dubbing)	35
How to Use the DUBBING Button	35

How This Manual Is Organized

In this manual we have incorporated some special features.

- Basic information that is the same for many different functions is grouped in one place, and not repeated in each procedure. For instance, in the section on playing a C.D. we do not repeat the information about setting the volume and the sound conditions, which are discussed in the Common Operations section.
 - Name of buttons and controls are written in all capital letters like this: **SOUND MODE**.
- The manual has a table of contents to help you quickly look up what you want to know. We've enjoyed making this manual for you, and hope you will use it to enjoy the sound and many features built into your System.

IMPORTANT PRECAUTIONS

1. Installation of the Unit

- Select a place which is level, dry and neither too hot nor too cold. (Between 5°C and 35°C, or 41°F and 95°F.)
- Leave sufficient distance between the Unit and a TV.
- Do not use the Unit in a place subject to vibrations.

2. Power cord

- Do not handle the power cord with wet hands!
- Some power (12 watts) is always consumed as long as the power cord is connected to the wall outlet.
- When unplugging the Unit from the wall outlet, always pull the plug—not the power cord.
- There are no user-serviceable parts inside. If anything goes wrong, unplug the power cord and consult your dealer.
- Do not insert any metallic object into the Unit.

3. Malfunctions, etc.

- Receiving FM Stations with RDS
- What Information RDS Can Provide
- Changing the Display
- Searching for Programmes by PTY Codes
- EON Function
- ALARM function

Getting Started



Accessories

Check that you have all of the following items, which are supplied with the System.


- AM (MW/LW) Loop Antenna (1)
- Remote Control (1)
- Batteries (2)
- FM Wire Antenna (1)

If any of these items is missing, contact your dealer immediately.

How to Put Batteries in the Remote Control

Match the polarity (+ and -) on the batteries with the + and - markings in the battery compartment.

R6P (SUM-3VAA (15F))




CAUTION: Handle batteries properly.

To avoid battery leakage or explosion:

- Remove batteries when the Remote Control will not be used for a long time.
- When you need to replace the batteries, replace both batteries at the same time with new ones.
- Do not use an old battery with a new one.
- Do not use different types of batteries together.

Using the Remote Control

The Remote Control makes it easy to use many of the functions of the System from a distance of up to 7m (23 feet) away.
You need to point the Remote Control at the remote sensor on the System's front panel.



CAUTION: Make all connections before plugging the Unit into an AC power outlet.

Connecting the FM Antenna


A. Using the Supplied Wire Antenna

The FM Wire Antenna provided can be connected to a FM 75-ohm COAXIAL as temporary measure.

Extend the supplied wire antenna horizontally.

B. Using the Standard Type Connector (Not Supplied)

A standard type connector (H/C or DIN 45335) should be connected to the FM 75-ohm COAXIAL terminal (1).



If reception is poor, connect the outside antenna.


Before attaching a 75-ohm coaxial lead (the kind with a round wire going to an outside antenna), disconnect the supplied FM Wire Antenna.

CAUTION: To avoid noise, keep antennas away from metallic parts of the System, connecting cord and the AC power cord.

Connecting the AM (MW/LW) Antenna

AM Antenna Wire (not supplied)

Note: Even when connecting an outside AM antenna, keep the indoor AM loop connected.



If reception is poor, connect the outside antenna.

Snap the tabs on the loop into the slots of the base to attach the AM Loop.


Turn the loop until you have the best reception.

CAUTION: Make all connections before plugging the Unit into an AC power outlet.

Connecting the Speakers

■ Refer to instructions for speakers as well when you connect speakers.

- For each speaker, connect one end of the speaker wires to the speaker terminals on the back of the System.
 1. Open each of the terminals and insert the speaker wires firmly, then close the terminals.
 2. Connect the red (+) and black (-) terminals of the right side speaker to the red (+) and black (-) terminal marked RIGHT on the System.
 Connect the red (+) and black (-) terminals of the left side speaker to the red (+) and black (-) terminals marked LEFT on the System.




IMPORTANT: Use speakers with the correct impedance only.
 The correct impedance is indicated on the back panel.

CAUTION: If a TV is installed near the speakers, the TV may display irregular colours. In this case, set the speakers away from the TV.

Connecting the Optional Speakers

Connect the optional centre speaker and rear speakers.




English

Connecting Auxiliary Equipment

VCR or other equipment

To listen to this source, press A.L.X.



Now you can plug the AC power cord into the wall outlet, and your System is at your command!


COMPU PLAY

COMPU PLAY is JVC's feature that lets you control the most frequently used functions of the System with a single touch. One Touch Operation starts playing a CD, turns on the radio, plays a tape etc. with a single press of the play button for that function. What One Touch Operation does for you is to turn the power on, then start the function you have specified. If the Unit is not ready, such as no CD or tape in place, the Unit still powers on so you can insert a CD or tape.

How One Touch Operation works in each case is explained in the section dealing with that function.


The COMPU PLAY buttons are:

- CD Player DISC 1 to DISC 3 buttons
- CD Player Open/Close (▲) buttons
- CD ▶/II button
- TAPE ▶ button
- FM/A.M button
- AUX button





On the Remote Control

- FM button
- AM button
- DISC 1 to DISC 3 buttons
- TAPE button
- FM/A.M button
- AUX button



Common Operations

English




Demo Mode

When the System is connected to an AC power outlet, a Demo automatically starts showing some of the System's features.

The Demo display cycles through the following items repeatedly.

- Scrolling display of "DEMO MODE START".
- Demo of PRO LOGIC and 3CH LOGIC.
- Demo of Sound Modes.
- Demo of S.A. BASS
- Demo of continuous play from DISC 1 to DISC 3.



To turn the Demo off, press any of the operation buttons. "DEMO OFF" appears on the display and the Demo automatically stops.

To turn the Demo on, press CANCEL/DEMO for more than 2 seconds.

Setting the Clock

Before operating the unit, set the correct time.
You can set the clock whether the Unit is on or off.

- Press TIMER/CLOCK.**

The hour digits begin flashing.

- Press ↪ P. DOWN or ↵ P. UP on the MULTI CONTROL to set the hours.**

Press ↪ P. UP to increase the hour. Press ↩ P. DOWN to decrease the hour. Holding down continuously changes the hour setting more rapidly.

- Press SET.**

The minute digits begin flashing.

- Press ↪ P. DOWN or ↵ P. UP on the MULTI CONTROL to set the minutes.**

Press ↪ P. UP to increase the minute. Press ↩ P. DOWN to decrease the minutes. Holding down continuously changes the minute setting more rapidly.

- Press SET.**

"CLOCK OK" appears on the display. The clock stops flashing, and the clock timer starts from 0 second.

- If the clock is not set, "00:00" will flash instead of the clock indication.
- When the time has been set, TIMER/CLOCK can be used to operate the Daily Timer and Recording Timer.
- To adjust the time once the clock has been set, press TIMER/CLOCK 5 times and follow the procedure above.

CAUTION: If there is a power failure, the clock loses its setting.
The display shows "0:00", and the clock must be reset.

Turning the Power On and Off

Turning the System On

Press \odot/I .

"WELCOME" appears on the display and the STANDBY indicator goes out.

- The system comes on ready to continue in the mode it was in when the power was last turned off.
- If the last thing you were doing was listening to a tape in Deck B, you are now ready to listen to a tape again in Deck B, or you can change to another source.
- If you were listening to the Tuner last, the Tuner comes on playing the station it was last set to.

Turning the System Off

Press \odot/I again.


- "GOOD BYE" appears on the display for a while, and the STANDBY indicator lights up. The clock time appears on the display.
- Some power (1.2 watts) is always consumed even though the power is on standby.
- To switch off the Unit completely, unplug the AC power cord from the AC outlet. When you unplug the AC power cord, the clock will be reset to 00:00 immediately, and preset Tuner stations will be erased in a few days.




English

Adjusting the Volume

Turn VOLUME clockwise to increase the volume or anticlockwise to decrease it.
Turning VOLUME quickly also adjusts the volume level quickly.
When using the Remote Control, press VOLUME + to increase the volume or press VOLUME - to decrease it.
You can adjust the volume level between 0 and 50.




or



or



or



or



or




or



or



or



or




or




or




or



or



or



or



or



or



or



or

CAUTION: The Volume cannot be adjusted while the Unit is on STANDBY.
DO NOT turn on the Unit and/or start playing any source without setting the VOLUME control to 0; otherwise, the sudden blast of sound can damage your hearing, speakers and/or headphones.

For private listening

Connect a pair of headphones to the PHONES jack. No sound comes out of the speakers. Be sure to turn down the volume before connecting or putting on headphones.

Balance Adjustment

You can use the Remote Control to adjust the left and right balance of the speakers.

- Press SHIFT.**

The display changes to show the balance adjustment.

- Press BALANCE L (10) or R (+10).**

The display changes to show the balance adjustment.

- Press L (10) moves the pointer to the left; pressing R (+10) moves the pointer to the right.**

Pressing L (+10) moves the time to the left; pressing R (+10) moves the time to the right.

Display when set for no sound from the right speaker.

Display when set for no sound from the left speaker.

- The balance is normally set to the centre position.
- The note: If no adjustments are made for 2 seconds in balance adjustment mode, the display reverts to the previous display.

Reinforcing the Bass Sound

Press S.A. BASS.

Pressing S.A. (Signal Adaptive) BASS changes the bass setting in the following order
→ SA-BASS1 → SA-BASS2 → OFF → back to the beginning

- The S.A. BASS indicator lights up, and "SA-BASS1" or "SA-BASS2" appears on the display for three seconds.
- SA-BASS2 enhances low tones more than SA-BASS1.

- To cancel the effect,** press S.A. BASS until "OFF" appears on the display. The button light goes out.

To recall the previous S.A. BASS mode,

press S.A. BASS once.

- When listening to recording with low volume low tones, the difference between SA-BASS1 and SA-BASS2 is clear. When listening to recording with louder low tones, however, the difference between SA-BASS1 and SA-BASS2 may not be so clear.

Setting the Clock

Before operating the unit, set the correct time.
You can set the clock whether the Unit is on or off.

- Press TIMER/CLOCK.**

The hour digits begin flashing.

- Press ↪ P. DOWN or ↵ P. UP on the MULTI CONTROL to set the hours.**

Press ↪ P. UP to increase the hour. Press ↩ P. DOWN to decrease the hour. Holding down continuously changes the hour setting more rapidly.

- Press SET.**

The minute digits begin flashing.

- Press ↪ P. DOWN or ↵ P. UP on the MULTI CONTROL to set the minutes.**

Press ↪ P. UP to increase the minute. Press ↩ P. DOWN to decrease the minutes. Holding down continuously changes the minute setting more rapidly.

- Press SET.**

"CLOCK OK" appears on the display. The clock stops flashing, and the clock timer starts from 0 second.

- If the clock is not set, "00:00" will flash instead of the clock indication.
- When the time has been set, TIMER/CLOCK can be used to operate the Daily Timer and Recording Timer.
- To adjust the time once the clock has been set, press TIMER/CLOCK 5 times and follow the procedure above.

Turning the Power On and Off

Turning the System On

Press \odot/I .

"WELCOME" appears on the display and the STANDBY indicator goes out.

- The system comes on ready to continue in the mode it was in when the power was last turned off.
- If the last thing you were doing was listening to a tape in Deck B, you are now ready to listen to a tape again in Deck B, or you can change to another source.
- If you were listening to the Tuner last, the Tuner comes on playing the station it was last set to.

Turning the System Off

Press \odot/I again.

- "GOOD BYE" appears on the display for a while, and the STANDBY indicator lights up. The clock time appears on the display.
- Some power (1.2 watts) is always consumed even though the power is on standby.
- To switch off the Unit completely, unplug the AC power cord from the AC outlet. When you unplug the AC power cord, the clock will be reset to 00:00 immediately, and preset Tuner stations will be erased in a few days.

Adjusting the Volume


Turn VOLUME clockwise to increase the volume or anticlockwise to decrease it.
Turning VOLUME quickly also adjusts the volume level quickly.
When using the Remote Control, press VOLUME + to increase the volume or press VOLUME - to decrease it.
You can adjust the volume level between 0 and 50.




or



or




or



or



or




or



or



or



or




or




or



or



or



or



or




or



or



or



or



English

Sound Modes

The System has some preset sound effects that give you control of the way your music sounds, so you can tailor it for your room and/or the quality of the source. We can give you some idea of how each one affects the music, but the only way to really tell is to try them yourself! You can also create up to three of your own customized S.E.A. (Sound Effect Amplifier) settings and store them in the Unit's memory (MANUAL 1, MANUAL 2, MANUAL 3).

■ The preset sound modes include modes using surround effects and modes using S.E.A. effects.

■ Sound Mode effects cannot be recorded.

To get an effect, press SOUND MODE repeatedly until the Sound Mode you want appears on the display. The Sound Mode selected will appear on the display for three seconds. When a surround effect mode is selected, the frame around the SOUND MODE indicator will light up. When a S.E.A. effect mode is selected, the frame around the S.E.A. indicator will light up. Each time you press SOUND MODE, the Sound Mode changes as follows:

→ D. CLUB → HALL → STADIUM → ROCK → POP → CLASSIC → MANUAL 1 →
MANUAL 2 → MANUAL 3 → OFF → (back to the beginning)

Surround effect modes

D. CLUB (Dance Club)

HALL

STADIUM

Increases resonance and bass.

Adds depth and brilliance to the sound, like in a concert hall.

Adds clarity and spreads the sound, like in an outdoor stadium.

S.E.A. effect modes

ROCK

POP

CLASSIC

Boosts low and high frequencies.

Good for vocal music.

Set for wide and dynamic sound stereo systems.

To cancel an effect, press SOUND MODE until "OFF" appears on the display. The SOUND MODE indicator goes out.

To recall the previous Sound Mode, press SOUND MODE once.

Customizing a Sound Mode

You can change an existing sound mode to suit your own preferences. These changed settings can be stored in the Unit's sound mode memory.

Select the Sound Mode you want to change.

If you select D. CLUB, HALL, or STADIUM, the surround effect remains unchanged, but you can adjust the S.E.A. effect.

2. Press SEA CONTROL.

The low tone section of the tone equalizer flashes. Once "SEA CONT" appears, the low tone levels will appear.



Note: If no adjustments are made for 10 seconds after SEA CONTROL is pressed, Sound Mode will appear on the display then revert to the previous display.



Use MULTI CONTROL to adjust to any Sound Mode desired.

Press ↪ P. DOWN or ↪ P. UP on the MULTI CONTROL to select the tone range you want to adjust. You can adjust "LOW", "MID", or "HIGH" tone.



Press TUNING DOWN ↓ or ↑ TUNING UP ↑ on the MULTI CONTROL to adjust the level.

The level can be adjusted between -3 and +3 in 7 steps. "MANUAL" appears on the display.

4. Press SET again. "MEMORY" appears for 2 seconds.

The setting that has been created is stored in the memory.

■ The adjustment you have made will apply to the sound you hear.

■ If you store new settings to a memory number that has already been used, the new settings replace the existing setting.

When a Rear Speaker is Connected

If the optional rear speaker is connected, you can use the rear speaker to enjoy Surround effects when a Surround effect (D. CLUB, HALL, STADIUM, or a MANUAL setting based on one of these Sound Mode) is selected.

■ The rear speaker cannot be used when an S.E.A. effect (ROCK, POP, CLASSIC) is selected.



Adjusting the Rear Speaker Level

You can use the steps below to adjust the rear speaker level.

1. Select a Surround effect Sound Mode.

2. Start playback from the desired source.

3. Press SHIFT on the Remote Control.



4. Press REAR LEVEL + (8) or - (7) on the Remote Control to adjust the rear speaker level. Each time you press the button, the level changes one step.

• You can set the level between -10 and +10 in 21 steps.

• The rear speaker level changes equally for both left and right. You cannot adjust the left and right balance for the rear speaker independently.

• You can adjust the rear speaker level for each of the Surround effect modes.

Listening to Auxiliary Equipment

By playing the sound from auxiliary equipment through the System, you can gain control over how the music or program sounds. Once the connected equipment is playing through the System, you can apply the sound effects.

- First make sure that the auxiliary equipment is properly connected to the System. (See page 6.)

1 Turn down the volume level to 0.

2 Press AUX.
"AUX" appears on the display. The AUX button on the Unit lights up.



3. COMPU PLAY

When AUX is pressed while the power is on standby, the power is automatically turned on.

4. Start playing the equipment.




5. Adjust the volume level to the desired listening level.

6. Select a Sound Mode, if you wish.

To cancel the setting
Change the source by turning any one of the System's built-in sound sources, such as the Tuner or CD Player first.

Dolby Surround

English
English



When the System is being used, the display shows other items as well.
However, we have only shown the items described in this section.

Accessing the Dolby Surround Functions

Press the operation keys with green labels on the Remote Control to use the Dolby Surround functions.
To use the function marked in green, press SHIFT first, then press the desired operation key.

The Dolby Surround has been also developed to reproduce the important elements of the acoustic surround at home. To watch the sound tracks of video software bearing the mark which include the same encoded surround information as found in Dolby Stereo film, the Unit can provide you with two Dolby Surround programs (Dolby Pro Logic and Dolby "k" logic).

Dolby Pro Logic: Select this mode when the optional rear speakers are connected.

Dolby "k" Logic: Select this mode when no rear speakers are connected.

Manufactured under license from Dolby Laboratories Licensing Corporation. "Dolby", the double-D symbol, and "Pro Logic" are trademarks of Dolby Laboratories Licensing Corporation.

- You need to connect the optional centre speaker and rear speakers to use the Dolby Surround functions.

Preparing the Dolby Surround

To use the Dolby Surround effects, you need to prepare the various settings. These settings are set using the Remote Control.

The Dolby Surround settings are:

Centre Speaker Mode

Centre Speaker mode contains the following four settings:
PHANTOM: Select this setting if you have not connected a centre speaker. The left and right front speakers project the sound to give the effect of a centre speaker (PRO LOGIC only).

NORMAL: Select this setting if you are using a small centre speaker. Since the centre speaker cannot boost the low tones effectively, this setting uses the front speakers to boost the low tones from the centre speaker.

WIDE: Select this setting if you are using a centre speaker that is similar in power to the front speakers.

Select this setting to turn off the output for the centre speaker.

Delay Time Mode

Delay Time mode contains the following four settings:
DELAY 1: Select this setting if the rear speakers are further away from your listening position than the front speakers. (Delay time: 15 msec.)

DELAY 2: Select this setting if the rear speakers and front speakers are about the same distance away from your listening position. (Delay time: 20 msec.)

DELAY 3: Select this setting if the rear speakers are nearer to your listening position than the front speakers. (Delay time: 25 msec.)

DELAY 4: Select this setting if the rear speakers are very close to your listening position compared to the front speakers. (Delay time: 30 msec.)

Adjusting the level of the Centre Speaker

Adjust the level of the centre speaker between +10 and -10. Set the level so that it is about the same as the level from the front speakers.


Adjusting the level of the Rear Speakers (For PRO LOGIC only)

Adjust the level of the rear speakers between +10 and -10. Set the level so that it is about the same as the level from the front speakers.

■ You cannot adjust the levels of the left and right rear speakers independently.

Getting Ready To Use Dolby Pro Logic

Speaker Arrangements for Dolby Pro Logic



Setting-up Dolby Pro Logic

1. Press **PRO LOGIC/3CH LOGIC** to select **PRO LOGIC**.
 Each time you press the button, Dolby Surround programme changes as follows:
 → **PRO LOGIC** → **3CH LOGIC** → **OFF** → (back to the beginning)

2. Select the desired **Centre Speaker mode**.
 Press **SHIFT** on the Remote Control, then press **CENTER** MODE.
 Each time you press the button, Centre Speaker modes change as follows:
 → **NORMAL** → **WIDE** → **OFF** → **PHANTOM** → (back to the beginning)

3. Select the **Delay time**.
 Press **9** **DELAY TIME**. Each time you press the button, Delay time changes as follows:
 → **DELAY 2** → **DELAY 3** → **DELAY 4** → **DELAY 1** → (back to the beginning)

4. Set the volume to the level you like.
 Press **VOLUME** or **TEST TONE**. A test tone comes out of the speakers in the following order:
 → **LEFT** → **CENTER** → **RIGHT** → **REAR** → (back to the beginning)

5. Press **3 TEST TONE**.
 When a test tone comes out of the rear speakers, "SURROUND" appears on the display.
 • When "PHANTOM" or "OFF" is selected for Centre Speaker mode, no test tone comes out of the center speaker.

6. Adjust the level for the centre speaker.
 Press **CENTER LEVEL** **+** or **-**. Set the level so that it is about the same as the level from the front speakers.

• You cannot adjust the level for the centre speaker if "PHANTOM" or "OFF" is selected for Centre Speaker mode.

7. Adjust the level for the rear speakers.
 Press **REAR LEVEL** **+** or **-**. Set the level so that it is about the same as the level from the front speakers.

8. Press **3 TEST TONE** again.

Test Tone mode is cancelled.

This completes the preparations required for using Dolby Pro Logic.

English

Getting Ready To Use Dolby 3 Channel Logic

Speaker Arrangements for Dolby 3 Channel Logic



Setting-up Dolby 3ch Logic

Press PRO LOGIC/3CH LOGIC to select 3CH LOGIC.

Each time you press the button, Dolby Surround programmes change as follows:
→ PRO LOGIC → 3CH LOGIC → OFF → (back to the beginning)

When using the Remote Control, press SHIFT then press the 2. 3CH LOGIC.

Perform the steps below using the buttons on the Remote Control.

Select the desired Centre Speaker mode.

Press SHIFT on the Remote Control then press 6 CENTER MODE.

Each time you press the button, Centre Speaker modes change as follows:
→ NORMAL → WIDE → OFF → (back to the beginning)

Set the volume to the level you like.

Press 3 TEST TONE.

A test tone comes out of the speakers in the following order:
• When "OFF" is selected for Centre Speaker mode, no test tone comes out of the centre speaker.
→ LEFT → CENTER → RIGHT → (back to the beginning)

Adjust the level for the centre speaker.

Press CENTER LEVEL 5 + or 4 - . Set the level so that it is about the same as the level from the front speakers.

• You cannot adjust the level for the center speaker if "OFF" is selected for Center Speaker mode.
• You cannot adjust the level for the front speakers.

Press 3 TEST TONE again.

This completes the preparations required for using Dolby 3 Channel Logic.

• You cannot adjust the Delay Time or rear speaker levels in Dolby 3 Channel Logic mode.

Using Dolby Surround

Press PRO LOGIC/3CH LOGIC and select the desired mode.

If you are using the Remote Control, press 1 PRO LOGIC or 3 3CH LOGIC after pressing SHIFT. Make sure that the center speaker and rear speakers have been set up correctly, as described on page 15 to 17.

Playback as source with the mark.


Enjoy the great sound achieved through Dolby Surround.

To Cancel Dolby Surround Effects

Press PRO LOGIC/3CH LOGIC until the Dolby Surround indicator goes out. If you are using the Remote Control, press the Dolby Surround buttons (1 PRO LOGIC or 3 3CH LOGIC) after pressing SHIFT.

Using the Tuner

English
English



You can listen to both FM and AM (MW/LW) stations. Stations can be tuned in manually, automatically, or from preset memory storage.

- Before listening to the radio:
 - Check that both the FM and AM antennas are firmly connected. (See page 4.)

Tuning in a Station

Press FM/AM on the Unit (or FM or AM on the Remote Control) to turn on the radio.
The frequency of the previously selected channel appears on the display.


Switching between Frequency Bands
On the Unit
Press FM/AM.
Each time you press the button, the band alternates between FM and AM (MW/LW).

Receiving FM Stations with RDS



English
English

On the Remote Control
To tune in FM stations, press **FM**.
To tune in AM stations, press **AM**.



Three Ways to Select a Station

- Press TUNING DOWN \blacktriangleleft or \triangleright TUNING UP on the MULTI CONTROL repeatedly to move from frequency to frequency until you find the one you want. (Manual Tuning).
- Press and hold TUNING DOWN \blacktriangleleft or \triangleright TUNING UP on the MULTI CONTROL for a few seconds. The frequency starts changing on the display. When a station is tuned in, the frequency stops changing. (Auto Tuning).

- You can also use the Remote Control to tune in preset channels:**
- Press FM or AM so that you can receive the last station tuned in.
 - Select the station by entering the number keys of the Remote Control.
 - Example: For channel 15, press +10 then 5.
 - For channel 20, press +10 then 10. For channel 30, press +10 twice then 10.
 - After you have selected the preset number and the number appears, the broadcast frequency of the selected channel appears on the display.

Presetting Stations

You can preset up to 30 FM stations and up to 15 AM (MW/LW) stations for the preset numbers. Note: In some cases, test frequencies have been already memorized for the tuner since the factory examined the tuner preset function before shipment. This is not a malfunction. You can preset the stations you want into memory by following the presetting method.

Select a Band by pressing FM/AM on the Unit.

When using the Remote Control, press FM or AM.

2. Press TUNING DOWN \blacktriangleleft or \triangleright TUNING UP on the MULTI CONTROL to tune into a station.

3. Press SET.

"SET" flashes for 5 seconds. While it's still flashing, carry out the following procedure.

4. Press \blacktriangleleft P. DOWN or \triangleright P. UP on the MULTI CONTROL on the Unit to set the preset number.

5. Press SET again.

"STORED" appears for 2 seconds. The preset station is stored in the memory.

- Repeat steps 1 to 5 for each station you want to store in memory using different preset numbers.

CAUTION: If the Unit is unplugged or if a power failure occurs, the preset stations will be erased in a few days. If this happens, preset the station again.

Changing the FM Reception Mode

When an FM stereo broadcast is hard to receive or noisy, press FM MODE on the Remote Control so that the MONO indicator lights up on the display. Reception improves, but there is no stereo effect.

To restore the stereo effect, press FM MODE on the Remote Control so that the MONO indicator goes out. In this stereo mode, the STEREO indicator lights up and you can hear stereo effects, when a program is broadcast in stereo.

RDS

RDS (Radio Data System) allows the FM stations to send additional signals along with their regular programme signals. For example, the stations send their station names and information about what type of programme they broadcast, such as sports, or music, etc. When tuned to an FM station which provides the RDS service, the station frequency (and then the station name if sent) is displayed.

One convenient RDS service is "Enhanced Other Networks (EON)". This allows the Unit to automatically switch to a programme type of your choice when one starts in your broadcast area.

- Not all FM stations provide RDS service, nor do all RDS stations provide the same services. If in doubt, check with local radio stations for details on RDS services in your area.
- RDS may not work correctly if the station to which you are tuned is not transmitting properly or if the signal strength is weak.

What Information RDS can Provide

The System can use the following RDS service.

PS (Programme Service name)

Identifies each station by its name.

TA (Traffic Announcement Identification)

Identifies that a traffic announcement is being broadcast in your area.

RT (Radio Text)

Allows the RDS station to send text messages that appear on the display of the unit.

PTY (Programme Type)

Identifies the type of RDS programme. This allows you to locate a specific type of programme being broadcast.

The programme types are as follows:

NEWS	AFFAIRS	INFO	SPORT
DRAMA	CULTURE	SCIENCE	VARIED
M.O.R. M	ROCK M	LIGHT M	CLASSICS
WEATHER	FINANCE	CHILDREN	SOCIAL A
PHONE IN	TRAVEL	LEISURE	JAZZ
NATIONAL	OLDIES	FOLK M	DOCUMENT
		ALARM	COUNTRY TRAFFIC

EON (Enhanced Other Networks)

Provides information available on RDS stations other than the one which is being received.

Changing the Display

You can see RDS information on the display while listening to a FM station. To view RDS information on the display, press DISPLAY MODE. (When using the Remote Control, press 6 DISPLAY MODE after pressing RDS CONTROL). Each time you press the button, the display changes to show the following information:



PS (Programme Service):

Station names will be displayed.

PTY (Programme Type):

Types of broadcast programmes will be displayed.

RT (Radio Text):

Text message sent by stations will be displayed.

Station Frequency:

Station frequencies.

- While RDS information is being received from a station, "PS", "PTY", or "RT" may appear on the display.

Searching for Programmes by PTY codes

One of the advantages of the RDS service is that you can locate a particular kind of programme by specifying the PTY codes.

- The PTY Search function is applicable to preset stations only.

To search for a programme using the PTY codes, follow this procedure:**1. Press PTY/ON once.**

- When using the Remote Control, press 3 PTY/ON after pressing RDS CONTROL.
- "PTY" and "SELECT" appear alternately on the display.

Note: If no adjustments are made for 10 seconds in PTY Select mode, the display reverts to the previous display. Perform the next step while "PTY" and "SELECT" are being displayed.

2. Press SELECT + or SELECT - to select a PTY.

- When using the Remote Control, press 8 SELECT + or 9 SELECT -.
- Each time you press the button, PTY codes change as follows:

SELECT +

↔ NEWS ↔ AFFAIRS ↔ SPORT ↔ EDUCATE ↔ DRAMA ↔
 CULTURE ↔ SCIENCE ↔ VARIED ↔ POP M ↔ ROCK M ↔ M.O.R. M ↔
 LIGHT M ↔ CLASSICS ↔ OTHER M ↔ WEATHER ↔ FINANCE ↔
 CHILDREN ↔ SOCIAL A ↔ RELIGION ↔ PHONE IN ↔ TRAVEL ↔
 LEISURE ↔ JAZZ ↔ COUNTRY ↔ NATIONAL ↔ OLDIES ↔ FOLK M ↔
 DOCUMENT ↔ TRAFFIC ↔

SELECT -

3. Press PTY/ON again.

- When using the Remote Control, press 3 PTY/ON.
- While the search function is running, the selected programme type and "SEARCH" alternate on the display.

Once the station which is broadcasting the selected PTY (Programme Type) is located, searching will stop. Then the station name (if PS code is being sent) will be indicated and the broadcast will commence. The indicator will stay flashing for 10 seconds from the end of the searching function. If you press PTY/ON again during this period, search for the same PTY (Programme Type) will restart.

■ If a station broadcasting a selected PTY (Programme Type) cannot be found, "NOTFOUND" appears on the display after the Unit has searched through the preset numbers. The Unit will return to the station to which it was tuned prior to the start of the PTY search.

To cancel a PTY Search operation, press PTY/ON. (When using the Remote Control, press 3 PTY/ON.)**EON Function**

With the EON (Enhanced Other Networks) code, the Unit can perform a stand-by reception which will enable you to obtain desired information which is available from other stations.

- "EON" will be shown while receiving stations with an EON code.
- EON Stand-by reception is applicable for preset stations only.
- You can set EON Stand-by reception regardless of types of receiving bands.

Setting EON Stand-by reception**1. Press PTY/ON twice.**

- When using the Remote Control, press 3 PTY/ON after pressing RDS CONTROL.
- The last EON information type selected is displayed.

**2. Select information you want by pressing SELECT + or SELECT -.**

- When using the Remote Control, press the 9 SELECT + or 8 SELECT - button.
- TA: Identified that a traffic announcement is being broadcast in your area.

- NEWS: Programmes on medical services, weather forecast, etc.
- Each time you press the button, EON codes change as follows:



SELECT +

↔ TA ↔ NEWS ↔ INFO ↔ OFF ↔
 ← SELECT -

3. Press PTY/ON.

- When using the Remote Control, press 3 PTY/ON.
- As soon as your selection is entered, the Unit will go into EON Stand-by reception mode.

To cancel the EON function, select "OFF" by following the steps above.

When this Unit carries out EON Stand-by reception, the indication will change as follows:**1. Waiting for EON Stand-by reception.****2. Preset stations are being searched for and while preparing to change the station, sound will be muted.****Light up****3. The station will be changed and the Station name being received will appear on the display.**

- To view the other RDS information on the display, press DISPLAY MODE. (When using the Remote Control, press 6 DISPLAY MODE after pressing RDS CONTROL.)

Notes:

- EON broadcasts of some stations may not be compatible with this Unit. In the case of an incompatible EON broadcast, "EON" will not appear on the display.
- If the reception is unsatisfactory for a station among the preset stations, the station is searched for again. If after searching through the channels, the broadcasting station cannot be found, "NOTFOUND" appears on the display. The Unit will return to the station to which it was previously tuned.

When broadcasting of the desired information has been completed, the Unit will automatically go back to the station which had previously been tuned to.

- While receiving information on EON Stand-by reception, the station will not change to other stations even if the same information is available from them.
- If the information you are waiting for is available from the current station, the indicator will flash.




ALARM function

If an ALARM (Emergency) signal is received while receiving an EON code from a station, the Unit automatically switches to the station broadcasting the ALARM signal.

Using the CD Player



Loading CDs



The System's CD Player has an Automatic Changer with 3 disc trays. You can use Continuous, Random, Program or Repeat Play for the discs in DISC 1, DISC 2 and DISC 3. Repeat Play can repeat all the tracks on all the CD's or one track on one CD. There is also the Tray Lock function, which safely keeps discs in the trays.

Here are the basic things you need to know to play a CD and locate the different selections on it. Each selection is called a track, so when we are talking about locating a track, we are also talking about how you find a certain song or performance.

The System's CD Player has an Automatic Changer with 3 disc trays. You can use Continuous, Random, Program or Repeat Play for the discs in DISC 1, DISC 2 and DISC 3. Repeat Play can repeat all the tracks on all the CD's or one track on one CD. There is also the Tray Lock function, which safely keeps discs in the trays.

When the System is being used, the display shows other items as well. However, we have only shown the items described in this section.

Entering CD Operation Mode with the Remote Control

Pressing CD CONTROL or DISC 1 to 3 makes the Remote Control ready for the CD operations. Operate the CD player with \blacktriangle/II , MULTI CONTROL, and number keys. The explanation provided in this section assumes that the Remote Control has been put into CD operation mode. When you use the Remote Control, press CD CONTROL first.

- When you press CD \blacktriangle/II or DISC 1 to 3, while the disc tray is open, the tray will automatically close before beginning to play.
- If there is no CD in the disc tray, "NO DISC" appears on the display.

- When you press CD \blacktriangle/II or DISC 1 to 3, while the power is on standby, the power is automatically turned on.
- When DISC 3 has finished, the CD Player stops.
- When playback starts from DISC 2, the playing order is DISC 2 \rightarrow DISC 3 \rightarrow DISC 1.
- When DISC 1 has finished, the CD Player stops.
- When playback starts from DISC 3, the playing order is DISC 3 \rightarrow DISC 1 \rightarrow DISC 2.
- When DISC 2 has finished, the CD Player stops.
- If any of the disc trays are empty, the CD Player skips that disc tray and continues through the remaining disc trays in the order shown above. When the last disc has finished playing, the Unit will stop automatically.

Basics of Using the CD Player — Continuous Play

Playing a CD

Prepare the CDs.

On the Unit

Press CD \blacktriangle/II .

The source is set to CD and play starts from the first track of the currently selected CD whose disc number is shown on the CD indicator.

Press DISC 1 to 3 of the disc you want to play.

The source is set to CD and play starts from the first track of the selected CD.

Playing order of discs

- When you press CD \blacktriangle/II or DISC 1 to 3, while the disc tray is open, the tray will automatically close before beginning to play.
- If there is no CD in the disc tray, "NO DISC" appears on the display.
- When you press CD \blacktriangle/II or DISC 1 to 3, while the power is on standby, the power is automatically turned on.
- When DISC 3 has finished, the CD Player stops.
- When playback starts from DISC 2, the playing order is DISC 2 \rightarrow DISC 3 \rightarrow DISC 1.
- When DISC 1 has finished, the CD Player stops.
- When playback starts from DISC 3, the playing order is DISC 3 \rightarrow DISC 1 \rightarrow DISC 2.
- When DISC 2 has finished, the CD Player stops.
- If any of the disc trays are empty, the CD Player skips that disc tray and continues through the remaining disc trays in the order shown above. When the last disc has finished playing, the Unit will stop automatically.

Programming the Playing Order of the Tracks

English
English

On the Remote Control

Press CD CONTROL then press ▶.

The source is set to CD and play starts from the first track of the currently selected CD whose disc number is shown on the CD indicator.

- If the above operation is carried out while the power is on standby, the power is automatically turned on.
- Press DISC (1 to 3) of the disc you want to play.**
- The source is set to CD and play starts from the first track of the selected CD.

COMPU PLAY

When DISC 1 to 3 on the Remote Control is pressed while the power is on standby, the power is automatically turned on.

- To stop playing the disc, press ■ STOP or □ on the Remote Control. The display will show the total number of tracks and total playing time of the disc that was playing followed by the playing time of the first track.

To stop play and remove the disc, press ▲ for the disc being played.

To pause, press CD ▶ II or □ on the Remote Control. The playing time will flash.

To cancel pause, press CD ▶ II or □ on the Remote Control. Play continues from the point where it was paused.

Selecting a Track

Press ▲ P. DOWN or ▷ P. UP on the MULTI CONTROL to select the track.

The selected track starts playing.

Each time you press ▲ P. DOWN or ▷ P. UP, the track changes by one.

Press and hold ▲ P. DOWN or ▷ P. UP to continuously change tracks.

Locating a Track with the Remote Control Directly

Press the DISC (1 to 3) for the disc tray containing the track you want to listen to.

Enter the number of the track you want to listen to with the number keys.

The selected track starts playing.

- Example: for track 5, press 5. For track 15, press + 10 then 5. For track 20, press +10, then 10, then 2, then 3, press +10 three times, then 2.

Fast Forward / Reverse

Use TUNING DOWN ▲ or ▷ TUNING UP on the MULTI CONTROL.

For Fast Forward, press and hold down ▲ TUNING UP. For Reverse, press and hold down TUNING DOWN. ▲ Release the button when the part you wish to listen to is reached.

Changing Discs While Playing

Press ▲ of the tray not being used.

You can replace a CD in a tray not being used, while another CD is playing.

- Press ▲ of the tray not being used.**
- The tray opens.
- Replace the disc in the tray.**
- Press ▲ to close the tray.**

Programming the Playing Order of the Tracks

You can change the order in which the discs and tracks play, and select only the discs and tracks you want from among those loaded in the CD Player.

- You can programme up to 32 steps in any desired order from among the discs in the CD player.

You can only programme the CD Player when it is stopped.

On the Unit

1. Press PROGRAM/RANDOM.

"PROGRAM" appears on the display and the PROGRAM indicator lights up. If you have already created a programme, the last step of the previous programme will appear on the display.

Each time you press the button, play mode changes as follows:
→ PROGRAM → RANDOM → No Play mode indicator (Continuous Play) → back to the beginning)

2. Select a disc with DISC (1 to 3).

The display changes to the Programme Entry display and the disc number and track number flash (for a few seconds).

■ While the indications are flashing, perform the operations in steps 3 to 4. When the flashing indications change to "PROGRAM", repeat the operations in steps 2 to 4.

3. Press ▲ P. DOWN or ▷ P. UP on the MULTI CONTROL to select a track for programming.

The disc number and track number starts flashing on the display.

4. Press SET.

The indications on the display stop flashing and remains lit. The step number appears on the display.

Repeat steps 2 to 4 to select the other tracks for the programme.

5. Press CD ▶ II.

To select another track from the same disc, repeat the procedure from step 3.

6. Press CD ▶ II.

The Uni plays the tracks in the order you have programmed them.

On the Remote Control

1. Press PROGRAM/RANDOM on the Unit.

"PROGRAM" appears on the display and the PROGRAM indicator lights up. If you have already created a programme, the last step of the previous programme will appear on the display unless you have erased the programme.

Each time you press the button, play mode changes as follows:
→ PROGRAM → RANDOM → No Play mode indicator (Continuous Play) → back to the beginning)

2. Select a disc with DISC (1 to 3).

The display changes to the Programme Entry display and the disc number and track number flash (for a few seconds).

■ While the indications are flashing, perform the operation in step 3. When the flashing indications change to "PROGRAM", repeat the operations in steps 2 to 3.

③ Press the number keys [1 to 10 and +10] to select the tracks.

The indications on the display stop flashing and remains lit.

- Example: For track 5, press 5.
- For track 15, press +10 then 5.
- For track 20, press +10 then 10.
- For track 32, press +10 three times, then 2.

4 Repeat steps 2 to 3 to select the other tracks for the programme.

5 Press ▶.

The Unit plays the tracks in the order you have programmed them.

- If you try to programme a 33½ track, "FULL" will appear on the display to let you know that the programme is full.
- If you try to programme a disc tray that is empty, or a track number that does not exist on a disc (for example, selecting track 14 on a disc that only has 12 tracks), the selected disc or track are skipped when the programme is played.
- You can skip to a particular programme step by pressing the MULTI CONTROL (◀ P. DOWN or ▶ P. UP or ▲ or ▼ on the Remote Control) during programme play.
- To play the programmed tracks repeatedly, press REPEAT. For details, refer to "Repeating a Track or the Disc" on page 28.

To stop playing, press ■ STOP (or ■ on the Remote Control) once.

To delete all the tracks in a programme, press ■ STOP (or ■ on the Remote Control) while the CD Player is stopped. The programme is deleted and "PROGRAM" appears on the display.

To cancel programme play, press ■ STOP (or ■ on the Remote Control) while "PROGRAM" is shown on the display.

Checking the Programme

While the CD Player is stopped, use ▶ or ▷ (on the Remote Control) to check the contents of the programme. Each time you press ▶ or ▷, the programme contents are shown on the display in the programmed order.

Pressing ▶ displays the previous step in the programme.

Changing the Programme

Modify the contents of a programme while the CD Player is stopped.

Press CANCEL/DEMO while the CD Player is stopped. Each time you press the button, the last step in the programme is deleted. To add a step to the programme, follow the procedure above (on either the Unit or the Remote Control). The new steps are added to the end of the programme.

Random Play

The tracks of all loaded CDs will play at random.

- 1 Press PROGRAM/RANDOM while the CD Player is stopped to change to the Random Mode display.

Each time you press the button, play mode changes as follows:
→ PROGRAM → RANDOM → No Play mode indicator (Continuous Play) → (back to the beginning)

- 2 Press CD ▶/II.

The tracks of all the CDs are played in random order.
When all of the tracks have been played, the CD Player stops.

Note: Random Play cannot be activated with the DISC buttons and the number keys.

- You can skip to the next track by pressing ▶ P. UP on the MULTI CONTROL (or ▶ on the Remote Control) during Random Play. Each time you press the button, the next track is jumped to. (You cannot skip to the previous tracks, nor to the beginning of the current track during Random Play.)
- To continue with a different random track selection after the last track is played, press REPEAT to select REPEAT ALL before or during Random Play.

To cancel Random Play, press ■ STOP (or ■ on the Remote Control) twice. When the RANDOM indicator goes out, Continuous Play mode is resumed.

Repeating a Track or the Discs

You can have all the discs, the program or the individual track currently playing repeat as many times as you like.

Press REPEAT on the Unit.

Each time you press the button, the Repeat Modes change as follows:
→ REPEAT ALL → REPEAT 1 → No indicator (back to the Beginning)

REPEAT ALL: Repeats all the tracks on the CDs, or all the tracks in the program.

REPEAT 1: Repeats one track on one CD.

To exit Repeat Mode, press REPEAT until the Repeat Mode indicator on the display goes out.

Tray Lock Function

In order to safely keep the discs in the CD Player, the three trays can be electronically locked in a single operation.


When the Tray Lock function is on, the trays cannot be opened even if the ▲ button is pressed. This function can only be accessed by using the buttons on the Unit itself.

Locking the Trays

1 Put the System's power into STANDBY mode.

2 While pressing ■ STOP, press ▲ for DISC 1 on the Unit.

"LOCKED" appears on the display to let you know that the trays have been locked.




When the CD Player trays are locked, pressing ▲ displays the message "LOCKED" on the display and the trays do not open. Also, ▲ cannot be used to automatically turn on the power.

Unlocking the Trays

1 Put the System's power into STANDBY mode.







2 While pressing ■ STOP, press ▲ for DISC 1 on the Unit.

When the unlock operation is done, "UNLOCKED" appears on the display to show that the lock has been taken off.



The trays can now be opened by pressing ▲.

▲ can also be used to automatically turn on the power.



Using the Cassette Deck (Playing)



Regular Play

When the power is already on, you can use this basic procedure:



1 Press down ▲ for the deck you want to use.

2 When the cassette holder opens, put a cassette in, with the exposed part of the tape down, toward the base of the Unit.

• If the cassette holder does not open, turn the power off, then back on and press down ▲ again.

3 Close the holder gently.

When both Deck A and Deck B contain a tape, the last deck to have a tape inserted is selected. To change the selected deck, press DECK A/B. When using the Remote Control, press TAPE A or TAPE B.

4 Press TAPE ▶▶ on the Unit.

MULTI CONTROL

TAPE ▶▶
When TAPE ▶▶ is selected as the source, the button lights up.

STOP
REVERSE MODE


DECK A/B

Eject (Deck A) ▲ Eject (Deck B)

Display

Tape Direction Indicator on the Display

The Tape Direction indicator tells you which direction the selected tape deck will use for playback. During playback, the direction indicator flashes slowly. During fast left or fast right, the indicator flashes quickly. During Music Scan mode, the indicator flashes slowly and quickly alternately.



Reverse Mode indicator
Tape Direction indicator
A B : DECK A, B indicator


When the System is being used, the display shows other items as well. However, we have only shown the items described in this section.

The Cassette Deck allows you to play, record and dub audio tapes.

■ With Automatic Tape Detection, you can listen to Type I or II tapes without changing any settings. The use of tapes longer than 120 minutes is not recommended, since characteristic deterioration may occur and these tapes easily jam in the pinch-rollers and the capstans.

Entering the TAPE Operation Mode with the Remote Control

Pressing TAPE CONTROL makes the Remote Control ready for the Cassette Deck operations. Operate the Cassette Deck with ▲ and MULTI CONTROL. The explanation provided in "Using the Cassette Deck" section assumes that the Remote Control has been put into Cassette Deck operation mode. When you use the Remote Control, press TAPE CONTROL first.



Tape Direction Indicator on the Display

When the power is stopped, press TUNING DOWN ▶▶ on the MULTI CONTROL (or ▶▶ on the Remote Control) and the tape will wind rapidly to the left side of the cassette without playing. While the tape is stopped, press ▶▶ TUNING UP on the MULTI CONTROL (or ▶▶ on the Remote Control) and the tape will wind rapidly to the right side of the cassette without playing.

Note: Deck A and Deck B cannot be used for play back at the same time.

Music Scan

To find the beginning of a music track during play, use the Music Scan function. Music Scan searches for blank portions that usually separate selections, then plays the next selection.

Finding the Beginning of the Current Selection

Press TUNING DOWN ▶▶ or ▶▶ TUNING UP on the MULTI CONTROL (or ▶▶ or ▶▶ on the Remote Control) during play.

■ Make sure that you press TUNING DOWN ▶▶ or ▶▶ TUNING UP on the MULTI CONTROL (or ▶▶ or ▶▶ on the Remote Control) in the opposite direction to that in which the tape is playing. Searching stops at the beginning of the current selection, and the current selection starts automatically.

Finding the Beginning of the Next Selection

Press TUNING DOWN ▶▶ or ▶▶ TUNING UP on the MULTI CONTROL (or ▶▶ or ▶▶ on the Remote Control) during play.

■ Make sure that you press TUNING DOWN ▶▶ or ▶▶ TUNING UP on the MULTI CONTROL (or ▶▶ or ▶▶ on the Remote Control) in the same direction as that in which the tape is playing. Searching stops at the beginning of the next selection, and the next selection starts automatically.



or



Music Scan works by detecting a 4-second long blank at the beginning of a song. A blank will occur when a song starts.

- No blank at the beginning of a selection.
 - Noise (often caused by much use or poor quality dubbing) which fills the blank with noise.
 - Long, very soft pauses or pauses in a selection. The scan will detect these as 4-second long blanks. If this happens, just scan again until you reach the selection you want.

Using the Cassette Deck (Recording)

English



Reverse Mode

- **Use Reverse Mode** to make the tape automatically reverse at the end of a side and start playing the other side.
Each time you press REVERSE MODE, the Reverse Mode turns on and off alternately.



Display



When the System is being used, the display shows other items as well. However, we have only shown the items described in this section.

Things to Know before You Start Recording —

- It may be unlawful to record or play back copyrighted material without the consent of the copyright owner.
 - When you want to record onto both sides of a tape, you can set Reverse mode on to do so. However, recording automatically stops after recording in the ▲ direction in Reverse mode. Therefore, make sure that the tape direction is ▲ when recording with Reverse mode on.
 - The recording level, which is the volume at which the new tape is being made, is automatically set correctly, so it is not affected by volume control. Thus, during recording you can adjust the sound you are actually listening to without affecting the recording level.
 - Two small tabs on the back of the cassette tape; one for side A and one for side B, can be removed to prevent accidental erasure or re-recording. To record on a cassette with the tabs removed, you must cover the holes with adhesive tape first.
 - However, when a Type II tape is used, only cover part of the hole as shown, since the other part of the hole is used to detect the tape type.
 - When recording, you can hear Sound Mode effects through the speakers or headphones. However, the sound is recorded without Sound Mode effects.
 - Type I and Type II tapes can be used for recording.

Note: At the start and end of cassette tapes, there is leader tape, which cannot be recorded onto. Depending on the recording source, the first part of the recording may be missing because of the leader. When recording CDs or radio broadcasts, to get the beginning of the recording on the tape, first wind up the cassette tape until the beginning of the recording is heard. Before recording, turn on the microphone recording switch. When recording, turn off the microphone recording switch.



CAUTION: If recordings you have made have excessive noise or static, the Unit may be too close to a TV which was on during recording. Either turn off the TV or increase the distance between the TV and the System.

Standard Recording

This is the basic method for recording any source. The System also has special ways for recording CD to tape, and tape to tape, which give you time and effort, as well as give you some special effects. However, when you need to add a selection to a tape you have made, or are combining selections from several sources on one tape, use the method described below; just substitute the source you want into this procedure, such as a CD or the Tuner. You can also record from an auxiliary source with this procedure.

Using the Unit

1. **Insert a blank or erasable tape into Deck B.**
2. **Press REVERSE MODE if you want to record on both sides of the tape.**
Reverse Mode comes on.
When using Reverse Mode, insert the tape so that it will be recorded in the forward (►) direction.
3. **Check the recording direction for the tape.**
Check that the Tape Direction indicator is the same as that for the tape in the tape deck. If the directions are different, press ■ STOP after pressing TAPE ▶▶ to set the tape direction.
When using the Reverse Mode to record both sides of a tape, check that the Tape Direction indicator is in the forward (►) direction. If the direction indicator is not in the forward (►) direction, press TAPE ▶▶ then press ■ STOP.
4. **Prepare the source, for example, by tuning in a radio station, loading CDs, or turning on connected equipment.**
5. **Press REC START/STOP**
The REC indicator lights up and the System begins recording.
6. **Using the Remote Control**
Press TAPE CONTROL then press ►▶.
Recording starts.
The REC indicator stops flashing and remains lit.
7. **Press REC PAUSE.**
The REC indicator starts flashing.



English

Recording AM Station to Tape

When recording an AM broadcast, beats may be produced which are not heard when listening to the broadcast. In this case, press PROGRAM/RANDOM on the CD Player to eliminate the beats.

1. Set to AM station and start recording.

2. Press PROGRAM/RANDOM repeatedly until the beats are eliminated.

Each time you press the button, the indication on the display changes as follows:
→ CUT 2 → CUT 3 → CUT 4 → CUT 1 → back to the beginning!

CD Direct Recording

Everything on the CD goes onto the tape in the order it is on the CD, or according to the order you have set in a program.

1. Press CD ▶▶/II, then ■ STOP.

2. Prepare CDs. (See page 24.)

Check that the CD Player is not playing a CD.
• Insert a blank or erasable cassette in Deck B.

• When you want to record on both sides of a tape, press REVERSE MODE to turn on Reverse Mode. Check that the recording direction for the tape and the Tape Direction indicator are correct.
(See page 33 "Notes for using Reverse Mode for recording.")

3. Press CD REC START.

"CD REC" appears on the display, the REC indicator lights up, and the System begins recording. If the tape reaches its end while recording a song, the last song will be re-recorded at the beginning of the other side.
When the recording is finished, "CD REC FINISHED" scrolls on the display. The CD Player and Cassette Deck stop.

To stop at any time during the recording process, press ■ STOP.

Note: When making Sleep Timer settings while doing CD Direct recording, set the time so that there is enough leeway to finish the recording before the power turns off. If the time is set to about the length of the CD, the power may turn off before recording finishes.

For CD Direct Recording using more than one disc, use a blank tape. If you use a prerecorded tape, prerecorded material may not be erased between newly-recorded tracks.

Auto Edit Recording

Using Auto Edit, you can record the CD tracks to fit the tape, so a selection is not cut off. Auto Edit is one of the best ways to copy all of a CD onto a tape. Auto Edit programs the CD tracks in numerical order. To prevent the end of the last track on the front side from being cut off, the last track on the front side is selected to fit on the remaining tape length.

1. Press CD ▶▶/II, then ■ STOP.


2. Prepare CDs. (See page 24.)

Check that the CD Player is not playing a CD.
• "DISC" appears on the display.

3. Press EDIT (1 to 3) for the disc you want to record.

After TAPE C ▶▶, the optimum tape length for the disc appears on the display.
• You can select a different length of tape, depending on the actual size of the tape you are using.
From eleven possibilities programmed into the Unit: 40, 46, 50, 54, 60, 64, 70, 74, 80, 84, 90.
Select the tape length that corresponds to the length of tape you are using, or the nearest length to it, by adjusting ▲ P. DOWN or ▼ P. UP on the MULTI CONTROL.

• If you select a tape length shorter than the total playing time of the CD, the last tracks on both sides of the tape will be faded out as the tape ends.



Using the Timer



5. Press SET.

The tracks to be recorded on side B appear on the display.

- Each time you press the button, the tracks to be recorded on side A and side B appear on the display alternately.

6. Insert a blank or erasable cassette in Deck B.

When you want to record on both sides of a tape, press REVERSE MODE to turn Reverse mode on.



7. Press CD REC START.

The Unit plays the CD and starts recording. If the tape has not been rewound, the Unit rewinds the tape before starting to record the CD.


To stop at any time while recording, press ■ STOP or REC START/STOP on the Unit. If ■ STOP is pressed, the Cassette Deck will create a four-second blank space after the CD Player stops. If REC START/STOP is pressed, the CD Player and Cassette Deck will stop simultaneously. When ■ is pressed in the Remote Control, the stop time of the CD Player and Cassette Deck vary according to their mode (CD operation mode or Cassette Deck operation mode). If the Remote Control is in CD operation mode, the Cassette Deck will stop four seconds after the CD Player stops. If the Remote Control is in Cassette Deck operation mode, the CD Player and Cassette Deck will stop simultaneously.

To cancel Auto Edit, press PROGRAM/RANDOM while the CD Player is stopped or press ▲ for the disc number being recorded.

Note: When making Sleep timer settings, while doing Auto Edit recording, set the time so there is enough leeway to finish the recording before the power goes out. If the time is set to about the length of the CD, the power may go out before recording finishes.



Display



Clock, timer, on time etc.

Timer indicator

When the System is being used, the display shows other items, as well. However, we have only shown the items described in this section.

The timers let you control recording and listening functions automatically. Three types of timers are available.

- Daily Timer** — Use this timer to set wake up everyday to music from any source, instead of an alarm clock.
- Recording Timer** — Used for recording of radio broadcasts. You can set the starting time and stopping time of the recording.
- Sleep Timer** — Fall asleep and have your Unit turn off automatically after a certain length of time.

Note: When operating the Daily Timer and Recording Timer, always set the clock first. If the clock is not set, the Daily Timer and Recording Timer functions cannot be used. For details, refer to "Setting the Clock" on page 9.

Tape to Tape Recording (Dubbing)

Recording from one tape to another is called dubbing.

- When dubbing tapes, make sure that the playback direction of Deck A and Deck B are the same.
- When you record both sides of a tape, press REVERSE MODE to turn on the Reverse Mode.
- It is preferable that the type of tape (Type I or Type II) you record from be the same as the type you record onto.

How to Use DUBBING

1. Press TAPE ▶, then ■ STOP.

2. Insert the source cassette you want to copy from into Deck A for playback.

Insert the cassette so that it will be played in the forward ▶ direction.

3. Insert the blank or erasable cassette you want to copy onto into Deck B for recording.

Insert the cassette so that it will be recorded in the forward ▶ direction.

4. Press DUBBING.

Deck A and Deck B start simultaneously.

To stop dubbing, press ■ STOP.



■ When dubbing, you can hear Sound Mode effects through the speakers or headphones. However, the sound is dubbed without Sound Mode effects.

Setting the Daily Timer

With this timer you can wake up to music from a CD, tape your favourite radio program.

■ You can set the Daily Timer whether the Unit is on or off.

Procedure For Setting the Daily Timer

1. Press TIMER/CLOCK so that "DAILY" appears on the display.

The DAILY indicator flashes on the display.

- Each time you press the button, the timer setting indication changes as follows:

- DAILY → ON TIME (flashes) → REC → ON TIME (flashes) → Clock setting → Cancelled (current source) → back to the beginning)


Note: If the clock has not been set, even if TIMER/CLOCK is pressed, you cannot select the Daily Timer.

After "ON TIME" flashes for 2 seconds, it switches to the on-time setting display.




2. Press TIMER/CLOCK again.

Press → P DOWN or → P UP on the MULTI CONTROL to adjust the hours and press SET. Then press → P DOWN or → P UP to adjust the minutes and press SET.




3. Set the time you want the Unit to turn on.

Press → P DOWN or → P UP on the MULTI CONTROL to adjust the hours and press SET. Then press → P DOWN or → P UP on the MULTI CONTROL to adjust the minutes and press SET.




4. Set the time you want the Unit to turn off.

Press → P DOWN or → P UP on the MULTI CONTROL to adjust the hours and press SET. Then press → P DOWN or → P UP on the MULTI CONTROL to adjust the minutes and press SET.



5. Select the source you want to listen to.

To use a CD as the source:
1. Press → P DOWN or → P UP on the MULTI CONTROL repeatedly until "...CD ..." flashes on the display and press SET.





2. Press → P DOWN or → P UP on the MULTI CONTROL repeatedly to select the CD disc number to be played and press SET.

If you press SET without selecting a disc, the last disc played by the Unit will be used.



3. Press → P DOWN or → P UP on the MULTI CONTROL repeatedly to select the CD track number to be played and press SET.
If you press SET without selecting a track, playback will start from the first track on the CD.



**To use the Tuner as the source
(Possible only after presetting stations):**

1. To listen to FM, press → P DOWN or → P UP on the MULTI CONTROL repeatedly until "TUNER FM" flashes and press SET.
To listen to AM, press → P DOWN or → P UP on the MULTI CONTROL repeatedly until "TUNER AM" flashes and press SET.
2. Press → P DOWN or → P UP on the MULTI CONTROL repeatedly to select the station to be listened to as a preset channel and press SET.



To use a Cassette Deck as the source:
Press → P DOWN or → P UP on the MULTI CONTROL repeatedly until "TAPE" flashes on the display and press SET.



6. Setting the Volume Level.

Press → P DOWN or → P UP on the MULTI CONTROL to adjust the volume.



7. Press SET.
The DAILY indicator stops flashing and remains lit. The on-time off-time playback source (including the disc number and track number if a CD source is selected), and volume level to 10. VOL → 10: Sets the volume level to 10.
VOL → 15: Sets the volume level to 15.
VOL → 20: Sets the volume level to 20.
VOL → --: Sets the volume to the last volume setting used.

8. Press SET.
A few seconds before the on-time, the Unit automatically turns on the power. When the on-time comes, playback starts using the selected source. A few seconds before the off-time, "OFF" flashes on the display. When the off-time comes, the power is automatically turned off.
■ If a button is pressed when the Daily Timer is operating, playback continues but the timer is canceled.

Before turning off the Unit

■ If the source is a CD, make sure that there is a CD in the selected disc number.
■ If the source is a tape:
■ The tape in the deck corresponding to the Deck indicator mark is played. Make sure that there is a tape in the selected Cassette Deck.
• Check that the tape direction is correct. This is important especially when Reverse Mode is off.
■ See Reverse Mode on if you want to play both sides of the tape.
■ Select the Sound Mode if you want to listen using a Sound Mode effect.

To change the Daily Timer setting

To change the settings for the Daily Timer, repeat the setting procedure from the beginning.

Turning the Daily Timer On and Off
Once the Daily Time has been set it will be activated at the same time every day until the setting is turned off.

To turn the Daily Timer off: press TIMER/CLOCK until "DAILY" appears on the display. Press CANCEL/DEMO. "OFF" appears on the display and the DAILY indicator goes out.

To turn the Daily Timer on again: press TIMER/CLOCK until "DAILY" appears on the display, then press SET. The Timer on-time, off-time, playback source (including the disc number and track number if a CD source is selected), and volume level appear on the display, and the DAILY indicator lights up.

CAUTION: If the Unit is unplugged, or a power failure occurs, the timer setting will be erased in a few days. If the settings are erased in this way, reset the timer settings.

Setting the Recording Timer

With the Recording Timer you can make a tape of a radio broadcast automatically whether or not you are home. For the timer to work correctly, you need to make sure of the following: in addition to setting the time for the Tuner and Cassette Deck to come on:
 ■ You can set the Recording Timer whether the Unit is on or off.
 ■ The tape you want to record onto must be in Deck B.

Procedure for Setting the Recording Timer

1. Press TIMER/CLOCK repeatedly until "REC" appears on the display.

The REC indicator flashes on the display.

- Each time you press the button, the timer setting indication changes as follows:
DAILY → **ON TIME** flashes → **REC** → **ON TIME** flashes → Click setting → Cancelled

- (current source) → back to the beginning
Note: If the clock has not been set, even if TIMER/CLOCK is pressed, you cannot select the Recording Timer.

2. Press TIMER/CLOCK again.

After "ON TIME" flashes for 2 seconds, it switches to the time setting display.


3. Set the time you want the Unit to be turned on.

Press **↔ P. DOWN** or **↔ P. UP** on the MULTI CONTROL to adjust the hours and press SET. Then press **↔ P. DOWN** or **↔ P. UP** to adjust the minutes and press SET.

4. Set the time you want the Unit to be turned off.

Press **↔ P. DOWN** or **↔ P. UP** on the MULTI CONTROL to adjust the hours and press SET. Then press **↔ P. DOWN** or **↔ P. UP** to adjust the minutes and press SET.

5. Select the Recording band.

Press **↔ P. DOWN** or **↔ P. UP** on the MULTI CONTROL to select "TUNER FM" or "TUNER AM" and press SET.

6. Select the preset channel for the station to be recorded.

Press **↔ P. DOWN** or **↔ P. UP** on the MULTI CONTROL to select

7. Press SET.

The REC indicator stops flashing and remains lit. The on-time, off-time, and Recording band ("TUNER FM" or "TUNER AM") appear on the display.
 Turn the power off if you made the timer settings with the power turned on.

- A few seconds before the on-time for the recording, the Unit automatically turns on the power. When the on-time comes, recording starts using the selected source. A few seconds before the off-time, "OFF" flashes on the display. When the off-time comes, the power is automatically turned off.

Before the timer starts

- Check that tape direction is correct. This is important especially when Reverse Mode is off.
- Set Reverse Mode on if you want to record on both sides of the tape.
- The volume level is automatically set to 0 when Recording Timer starts.

It is very easy, and can be very disappointing, to forget to put in a tape, or accidentally leave a tape in Deck B you don't want recorded over. Although this happens to almost everyone at one time or another, we hope it won't happen to you!

To change the Recording Timer setting

Repeat the setting procedure from the beginning.

Turning the Recording Timer On and Off

Once the Recording Timer has been used, the setting is maintained but the Timer is set to off. To turn the Recording Timer off before the timer starts, press TIMER/CLOCK repeatedly until "REC" appears on the display, then press CANCEL/DEMO. "OFF" appears on the display and the REC indicator goes out.

To record at the same time again, press TIMER/CLOCK repeatedly until "REC" appears on the display, then press SET. The on-time, off-time, and Recording band ("TUNER FM" or "TUNER AM") appear on the display, and the REC indicator lights up.

CAUTION: If the Unit is unplugged, or a power failure occurs, the timer setting will be erased in a few days. If the settings are erased in this way, reset the timer settings.

Setting the Sleep Timer

Use the Sleep Timer to turn the Unit off after a certain number of minutes, when it is playing. By setting this timer, you can fall asleep to music and know your Unit will turn off by itself rather than play all night.
 ■ You can only set the Sleep Timer when the Unit is on and a source is playing.

To set the SLEEP Timer, follow this procedure:

- With the Unit on and a source playing, press SLEEP on the Remote Control.

"SLEEP" appears on the display.

2. Set the length of time you want the source to play before shutting off.

- Each time you press this button while the SLEEP indicator is flashing, it changes the number of minutes shown on the display in this sequence:
10 → **20** → **30** → **60** → **90** → **120** → Cancelled → (back to the beginning)

When the number of minutes you want shows on the display, just wait 5 seconds until the indicator stops flashing, and remains lit.
 The Unit is now set to turn off after the number of minutes you set.

To change the Sleep Timer setting

Press SLEEP until the number of minutes you want appears on the display.

To cancel the Sleep Timer setting

Press SLEEP until the SLEEP indicator goes out on the display.
 Turning off the Unit also cancels the Sleep Timer.


Timer Priority

Since each timer can be set independently, you may wonder what happens if the setting overlap. Here are the priorities for each timer:


■ The Recording Timer always has priority. This means that:

- If another timer is set to come on during a time when the Recording Timer is operating, the other timer just will not come on at all, so you will always get the entire program on tape.
- If the Recording Timer is set to come on while another timer is operating, the other timer will shut off 10 seconds before the Recording Timer is set to turn on, and the Recording Timer will take over.
- If the Sleep Timer is set while the Daily Timer is set to turn on, and the Recording Timer will take over.
- However, if the Daily Timer is set to come while the Sleep Timer is operating, the Daily Timer will take over.

Example 1



Example 2



English

Care and Maintenance

Compact Discs

Handle your compact discs, cassette tapes, and Cassette Deck carefully, and they will last a long time.

- If the tape is loose in its cassette, take up the slack by inserting a pencil in one of the reels and rotating.
- If the tape is loose, it may get stretched, cut, or caught in the cassette.
- Do not touch the tape surface.



- Remove the CD from the case by holding it at the edges while pressing the center hole lightly.
- Do not touch the shiny surface of the CD, or bend the CD.
- Put the CD back in its case after use to prevent warping.
- Be careful not to scratch the surface of the CD when placing it back in the case.
- Avoid exposure to direct sunlight, temperature extremes, and moisture.



- A dirty CD may not play correctly. If a CD does become dirty, wipe it with a soft cloth in a straight line from center to edge.
- CAUTION: Do not use any solvent (for example, conventional record cleaner, spray thinner, benzine, etc.) to clean a CD.**

Moisture Condensation

Moisture may condense on the lens inside the Unit in the following cases:

- After starting the heating in the room.
- In a damp room.
- If the Unit is brought directly from a cold to a warm place.

Should this occur, the Unit may malfunction. In this case, leave the Unit turned on for a few hours until the moisture evaporates, unplug the AC power cord, and then plug it in again.

General Notes

In general, you will have the best performance by keeping your tapes, CDs, and the mechanism clean.


- Store tapes and CDs in their cases, and keep them in cabinets or on shelves.
- Keep the Cassette Deck's tape doors and the CD tray's closed when not in use.

- If the heads become magnetized, the Unit will produce noise or lose high frequencies.
- To demagnetize the heads, turn off the Unit, and use a head demagnetizer (available at electronics and record shops).

Cassette Tapes

If the tape is loose in its cassette, take up the slack by inserting a pencil in one of the reels and rotating.


- If the tape is loose, it may get stretched, cut, or caught in the cassette.
- Do not touch the tape surface.



- Handle your compact discs, cassette tapes, and Cassette Deck carefully, and they will last a long time.
- If the tape is loose in its cassette, take up the slack by inserting a pencil in one of the reels and rotating.
- If the tape is loose, it may get stretched, cut, or caught in the cassette.
- Do not touch the tape surface.

- Remove the CD from the case by holding it at the edges while pressing the center hole lightly.
- Do not touch the shiny surface of the CD, or bend the CD.
- Put the CD back in its case after use to prevent warping.
- Be careful not to scratch the surface of the CD when placing it back in the case.
- Avoid exposure to direct sunlight, temperature extremes, and moisture.

- A dirty CD may not play correctly. If a CD does become dirty, wipe it with a soft cloth in a straight line from center to edge.
- CAUTION: Do not use any solvent (for example, conventional record cleaner, spray thinner, benzine, etc.) to clean a CD.**



Heads

Capstans

Pinch-rollers

Cassette Deck

- If the heads, capstans, and pinch-rollers of the Cassette Deck become dirty, the following will occur:

- Loss of sound quality
- Discontinuous sound
- Fading
- Incomplete erasure
- Difficulty recording
- Clean the heads, capstans, and pinch-rollers using a cotton swab moistened with alcohol.

- If the heads, capstans, and pinch-rollers become dirty, the Unit will malfunction. In this case, leave the Unit turned on for a few hours until the moisture evaporates, unplug the AC power cord, and then plug it in again.

Troubleshooting

- If you are having a problem with your System, check this list for a possible solution before calling for service.
- If you cannot solve the problem from the hints given here, or the Unit has been physically damaged, call a qualified person, such as your dealer, for service.

Symptom	Possible Cause	Action
No sound is heard.	Connections are incorrect, or loose.	Check all connections and make corrections. (See pages 4 - 6.)
Unable to record.	Cassette record protect tabs are removed.	Cover holes on back edge of cassette with tape.
Poor radio reception	<ul style="list-style-type: none"> The antenna is disconnected. The AM Loop Antenna is too close to the Unit. The FM Wire Antenna is not properly extended and positioned. 	<ul style="list-style-type: none"> Reconnect the antenna securely. Change the position and direction of the AM Loop Antenna. Extend FM Wire Antenna to the best reception position.
The CD skips.	The CD is dirty or scratched.	Clean or replace the CD.
Unable to operate the Remote Control.	<ul style="list-style-type: none"> Remove the obstruction. Replace the batteries. 	
The main AC power cord is not plugged in.	Plug in the AC power plug.	
The CD is upside down.	Put the CD in with the label side up.	
Operations are disabled.	The built-in microprocessor has malfunctioned due to external electrical interference.	Unplug the Unit then plug it back in.
The cassette door cannot be opened.	During tape playing, the power cord was unplugged.	Plug in the power cord, press CDL , and then press ▲ .

Specifications

English


Amplifier Section	
Output Power IEC 208-3/DIN Front	4.5 watts per channel, min. RMS, both channels driven into 6 ohms at 1 kHz with no more than 0.9% total harmonic distortion.
Output Power IEC 208-3/DIN Center	2.5 watts, min. RMS, driven into 8 ohms at 1 kHz with no more than 0.9% total harmonic distortion.
Output Power IEC 208-3/DIN Rear	12.5 watts per channel, min. RMS, both channels driven into 16 ohms at 1 kHz with no more than 1.5% total harmonic distortion.
Input Sensitivity/Impedance (1 kHz)	
AUX	.340 mV/50 kohms
Speaker terminals -	6 - 16 ohms
Cassette Deck Section	
Frequency Response	50 - 14,000 Hz
Type II (CrO ₂)	50 - 14,000 Hz
Type I (NORMAL)	50 - 14,000 Hz
Wow And Flutter	0.15% (WRMS)
CD Automatic Changer Section	
CD Capacity	3 discs
Dynamic Range	85 dB
Signal-To-Noise Ratio	90 dB
Wow And Flutter	Unmeasurable
Tuner Section	
FM Tuner	97.5 - 108.0 MHz
Tuning Range	
AM Tuner	
Tuning Range	
MW	522 - 1,629 kHz
LW	144 - 288 kHz
Dimensions	265 x 315 x 240 mm (W/H/D), 10 7/16 x 12 7/16 x 9 13/16 inches
Mass	9.1 kg (19.8 lbs.)
Accessories	
AM/MW/LW Loop Antenna	(1)
Remote Control	(1)
Baluns (RF SUM, YAA 15F)	(2)
FM Wire Antenna	(1)
Power Specifications	
Power Requirements	AC 230 V ~, 50 Hz
Power Consumption	160 watts 12 watts (in Standby mode)

Design and specifications are subject to change without notice.

Description of Major ICs

■ UPD780206GF-039 (IC801) : System control micon

1. Terminal Layout




2. Pin Function

No.	Symbol	I/O	Function	No.	Symbol	I/O	Function
1	VDD	-	Power supply.	33	SPIDTI	I	SPI DATA analog signal input.
2	SPICSB	O	SPI IC chip select signal output.	34	AVDD	-	Power supply for AD converter.
3	SPIA	O	SPI IC control-A.	35	AVREF	-	A/D REF voltage.
4	SPIB	O	SPI IC control-B.	36	REMIN	I	Remote control signal input.
5	PHOTOA	I	Tape A mechanism running detection.	37	MPX	I	MPX IN (Stereo INDI.)
6	PHOTOB	I	Tape B mechanism running detection.	38	OSDCK/RDCK	I/O	OSD clock output or RDS clock input.
7	MSI	I	Music scan input.	39	PRT	I	Protector input.
8	SPIC	O	SPI IC control-C	40	VSS	-	Connect to GND.
9	BEAT	O	Beat cut output (TUNER).	41	INH	I	Inhibit signal input (Back up).
10	RESET	I	System reset signal.	42	HPHONE	I	Headphone input.
11	X2	O	Main clock 4.19MHz.	43	OSDDA/RSDA	I/O	OSD data output or RDS data input.
12	X1	I	Main clock 4.19MHz.	44	PROSACK	O	Prologic/SA Bass/EXT IC clock.
13		-	Non connect.	45	PROSADA	O	Prologic/SA Bass/EXT IC data.
14	XT2	-	Sub clock 32.76kHz.	46	VDD	-	Power supply.
15	XT1	-	Sub clock 32.76kHz.	47	FVOLDA	O	Front VOL data output to IC401.
16	VDD	-	Power supply.	48	VOLCK	O	Clock signal output to IC401.
17	CK	O	Serial clock signal output to IC304 IC303,IC802,IC2.	49	RVOLDA	O	Rear VOL data output.
18	DATA	I/O	Serial data signal output to IC304 IC303,IC802,IC2.	50	OSDOFF	I	OSD OFF.
19	POUT	O	Power ON/Standy.	51	SLCCE	O	Chipenable signal output to IC303,IC304.
20	VC3RESET	O	Reset signal output to IC251.	52	TUCE	O	Chip enable signal to Tuner (IC2).
21	MRDY	I	Ready signal from IC251.	53	PROCE	O	Chip enable signal to prologic.
22	KCLK	I	Clock signal from IC251.	54	SABCE	O	Chip enable signal to SA Bass.
23	KCMND	O	Command to IC251.	55	OSDCE	O	Chip enable signal to OSD.
24	MSTAT	I	VC3 MSTAT.	56	DSPCE	O	Chip enable signal to DSP.
25	AVSS	-	Connect to GND.	57	EXTCE	O	Chip enable signal to EXT(IC802).
26	KEY1	I	Key matrix signal input.	58	SMUTE	O	System mute output.
27	KEY2	I	Key matrix signal input.	59	VOLU+	I	Rotary encoder VOL +
28	KEY3	I	Key matrix signal input.	60	VOLU-	I	Rotary encoder VOL -
30	SLCKEY1	I	SLC Key input	61~78	S1~S18	O	FL segment control signal.
31	SLCKEY2	I	SLC Key input	79	VLOAD	-	Power supply.
32	SLCKEY3	I	SLC Key input	80~91	S19~S30	O	FL segment control signal.
				92~100	G9~G1	O	FL grid control signal.

■ LA2786 (IC501) : Dolby Pro Logic Surround Signal Processor

1. Terminal Layout




2. Pin Functions


Pin No	Symbol	I/O	Function	Pin No	Symbol	I/O	Function
1	NS-BPF1	--	Capacitor for spectrum in noise sequencer	22	VCS-1	--	Capacitor for time constant (in log differential area)
2	NS-BPF2	--	Capacitor for spectrum in noise sequencer	23	VCS-2	--	Capacitor for time constant (in log differential area)
3	VREF	--	Analog reference voltage	24	VCS-TH	--	Capacitor for time constant (in log differential area)
4	S-DC-OUT	--	Capacitor for DC-cut Sch	25	L+R RECT	--	Capacitor for Center Channel detection
5	C-DC-OUT	--	Capacitor for DC-cut Cch	26	DC-CUT	--	Capacitor for DC-cut at detection circuit
6	L-DC-OUT	--	Capacitor for DC-cut Lch	27	L-R RECT	--	Capacitor for Surround channel detection
7	R-DC-OUT	--	Capacitor for DC-cut Rch	28	DC-CUT	--	Capacitor for DC-cut at detection circuit
8	VREF BUFFER	--	VREF low impedance	29	R-BPF3	--	LPF,HPF for Lch Right channel control circuit
9	L-IN	I	Left channel signal input	30	R-BPF2	--	LPF,HPF for Lch Right channel control circuit
10	R-IN	I	Ground	31	R-BPF1	--	LPF,HPF for Lch Right channel control circuit
11	GND	--	LPF,HPF for Lch control	32	C-TRIM DC-CUT	--	Capacitor for DC-cut Center Channel
12	L-BPF1	--	LPF,HPF Left channel control circuit	33	C-MODECAP8	--	Capacitor for Center Channel output low pass filter
13	L-BPF2	--	LPF,HPF Left channel control circuit	34	C-OUT	O	Center signal output
14	L-BPF3	--	LPF,HPF Left channel detection	35	S-OUT	O	Surround signal output
15	DC-CUT	--	Capacitor for DC-cut at detection circuit	36	R-OUT	O	Right channel signal output
16	R RECT	--	Capacitor Right channel detection	37	L-OUT	O	Left channel signal output
17	DC-CUT	--	Capacitor for DC-cut at detection circuit	38	Vcc	--	Power supply
18	L RECT	--	Capacitor for Left channel detection	39	OSC	--	Oscillation for noise sequencer and auto balance
19	VLR-TH	--	Capacitor for time constant (in log differential area)	40	STB	I	Strobe signal input
20	VLR-2	--	Capacitor for time constant (in log differential area)	41	DATA	I	Serial interface data input
21	VLR-1	--	Capacitor for time constant (in log differential area)	42	CLK	I	Serial interface clock

■ LV1016 (IC541) : Dolby Surround Passive Decoder

1. Terminal Layout




2. Block Diagram



■ BU9253AS (IC201) : Echo Mixing

1. Block Diagram




2. Pin Function


Pin No.	Symbol	I/O	Function
1	GND	-	Ground pin
2	ECHO VR Echo	I	Echo level control
3	NC1	-	Non connection
4	BIAS	-	Analog part DC bias
5	DAINT IN	I	DA side Integrator input
6	DAINT OUT	O	DA side integrator output
7	DALPF IN	I	DA side LPF input
8	DALPF OUT	O	DA side LPF output
9	MIX OUT	O	Mix AMP input pin for original tone
10	MIX IN	I	Mix AMP input pin for original tone
11	ADLPF IN	I	AD side LPF input
12	ADLPF OUT	O	AD side LPF output
13	ADINT OUT	O	AD side Integrator output
14	ADINT IN	I	AD side integrator input
15	VCC	-	VCC pin
16	NC2	-	Non connection
17	MUTE	I	Mute control
18	CR	-	CR pin for Oscillator

■ MN35510 (IC651) : DIGITAL SERVO&DIGITAL SIGNAL PROCESSER

1. Terminal Layout




2. Block Diagram




■ MN35510 (IC651) : DIGITAL SERVO&DIGITAL SIGNAL PROCESSER

1. Terminal Layout




2. Block Diagram



3. Description

Pin No.	symbol	I/O	Description	Pin No.	symbol	I/O	Description
1	BCLK	O	Not used	41	TES	O	Tracking error shunt signal output(H:shunt)
2	LRCK	O	Not used	42	PLAY	-	Not used
3	SRDATA	O	Not used	43	WVEL	-	Not used
4	DVDD1	-	Power supply (Digital)	44	ARF	I	RF signal input
5	DVSS1	-	Connected to GND	45	IREF	I	Reference current input pin
6	TX	O	Digital audio interface output	46	DRF	I	Bias pin for DSL
7	MCLK	I	μ com command clock signal input (Data is latched at signal's rising point)	47	DSLF	I/O	Loop filter pin for DSL
8	MDATA	I	μ com command data input	48	PLLF	I/O	Loop filter pin for PLL
9	MLD	I	μ com command load signal input	49	VCOF	-	Not used
10	SENSE	O	Sence signal output	50	AVDD2	-	Power supply(Analog)
11	FLOCK	O	Focus lock signal output Active :Low	51	AVSS2	-	Connected to GND(Analog)
12	TLOCK	O	Tracking lock signal output Active :Low	52	EFM	-	Not used
13	BLKCK	O	sub-code·block·clock signal output	53	PCK	-	Not used
14	SQCK	I	Outside clock for sub-code Q resister input	54	PDO	-	Not used
15	SUBQ	O	Sub-code Q -code output	55	SUBC	-	Not used
16	DMUTE	-	Connected to GND	56	SBCK	-	Not used
17	STATUS	O	Status signal (CRC,CUE,CLVS,TTSTOP,ECLV,SQOK)	57	VSS	-	Connected to GND(for X'tal oscillation circuit)
18	RST	I	Reset signal input (L:Reset)	58	XI	I	Input of 16.9344MHz X'tal oscillation circuit
19	SMCK	-	Not used	59	X2	O	Output of X'tal oscillation circuit
20	PMCK	-	Not used	60	VDD	-	Power supply(for X'tal cscillation circuit)
21	TRV	O	Traverse enforced output	61	BYTCK	-	Not used
22	TVD	O	Traverse drive output	62	CLDCK	-	Not used
23	PC	-	Not used	63	FLAG	-	Not used
24	ECM	O	Spindle motor drive signal (Enforced mode output) 3-State	64	IPPLAG	-	Not used
25	ECS	O	Spindle motor drive signal (Servo error signal output)	65	FLAG	-	Not used
26	KICK	O	Kick pulse output	66	CLVS	-	Not used
27	TRD	O	Tracking drive output	67	CRC	-	Not used
28	FOD	O	Focus drive output	68	DEMPH	-	Not used
29	VREF	I	Reference voltage input pin for D/A output block (TVD,FOD,FBA,TBAL)	69	RESY	-	Not used
30	FBAL	O	Focus Balance adjust signal output	70	IOSEL	-	pull up
31	TBAL	O	Tracking Balance adjust signal output	71	TEST	-	pull up
32	FE	I	Focus error signal input(Analog input)	72	AVDD1	-	Power supply(Digital)
33	TE	I	Tracking error signal input(Analog input)	73	OUT L	O	Lch audio output
34	RF ENV	I	RF envelope signal input(Analog input)	74	AVSS1	-	Connected to GND
35	VDET	I	Vibration detect signal input(H:detect)	75	OUT R	O	Rch audio output
36	OFT	I	Off track signal input(H:off track)	76	RSEL	-	pull up
37	TRCRS	I	Track cross signal input	77	CSEL	-	Connected to GND
38	RFDET	I	RF detect signal input(L:detect)	78	PSEL	-	Connected to GND
39	BDO	I	BDO input pin(L:detect)	79	MSEL	-	Connected to GND
40	LDON	O	Laser ON signal output(H:on)	80	SSEL	-	Pull up

■ BA6897FP (IC801) : 4channel driver




3. Functions

Pin No.	Symbol	I/O	Functions and operations
1	PD	I	APC amp input terminal
2	LD	O	APC amp output terminal
3	LD ON	I	APC ON/OFF control terminal
4	LDP	--	Connect to ground
5	VCC	--	Power supply
6	RF-	I	Inverse input pin for RF amp
7	RF OUT	O	RFamp output
8	RF IN	I	RF input
9	C.AGC	I/O	Connecting pin of AGC loop filter
10	ARF	O	RF output
11	C.ENV	I/O	A capacitor is connected to this terminal to detect the envelope of RF signal
12	C.EA	I/O	A capacitor is connected to this terminal to detect the envelope of RF signal
13	CS BDO	I/O	A capacitor is connected to detect the lower envelope of RF signal
14	BDO	O	BDO output pin
15	CS BRT	I/O	A capacitor is connected to detect the lower envelope of RF signal
16	OFTR	O	Of-track status signal output
17	/NRFDET	O	RF detection signal output
18	GND	--	Ground
19	ENV	O	Envelope output
20	VREF	O	Reference voltage output
21	LD OFF	--	Connect to ground
22	VDET	O	Vibration detection signal output
23	TE BPF	I	Input pin of tracking error through BPF
24	CROSS	O	Tracking error cross output
25	TE OUT	O	Tracking error signal output
26	TE-	I	Inverse input pin for tracking error amp
27	FE OUT	O	Output pin of focus error
28	FE-	I	Inverse input pin for focus error amp
29	FBAL	I	Focus balance control
30	TBAL	I	Tracking balance control
31	PDFR	I/O	F I-V amp gain control
32	PDER	I/O	E I-V amp gain control
33	PDF	I	I-V amp input
34	PDE	I	I-V amp input
35	PD BD	I	I-V amp input
36	PD AC	I	I-V amp input

■ TA8409S (IC851.852) : CD Changer Motor Driver

1. Block Diagram




2. Function

INPUT		OUTPUT		MODE
IN1	IN2	OUT1	OUT2	MOTOR
0	0	∞	∞	STOP
1	0	H	L	CW/CCW
0	1	L	H	CCW/CW
1	1	L	L	BRAKE

■ TA2057N (IC1) : FM/AM IF AMP & Detector

1. Block Diagrams



2. Pin Function

Pin No.	I/O	Symbol	Function	Pin No.	I/O	Symbol	Function
1	I	AM RF	AMRF signal input	13	O	Lch OUT	Output Lch
2		AM S.SENS		14	O	VCO	Voltage controlled terminal
3		FM S.SENS		15	O	LPF2	When voltage of terminal is MONO at "H" and ST at "L"
4	-	AM OSC	AM local oscillation circuit	16	O	LPF1	When voltage of terminal is AM at "H" and FM at "L"
5	O	AM OSC OUT	AM local oscillation signal output	17	I	MPX IN	Multi plex signal input
6	-	VCC	Power supply	18	O	AM OUT	AM detection signal output
7	I	AGC	AGC voltage input terminal	19	O	FM OUT	FM detection signal output
8	-	GND	Connect to GND	20	I	FM QUAD	Bypass to FMIF
9	O	IF OUT	IF REQ signal output to IC2	21	I	AM IF IN	Input of AMIF signal
10	O	TU IND	Indicator drive output when tuning	22	-	Vst	Fixed voltage output terminal
11	O	ST IND	"H"mono . "L"stereo	23	O	AM MIX OUT	Output terminal for AM mixer
12	O	Rch OUT	Output Rch	24	I	FM IF IN	Input of FMIF signal


CA-D702T/D752TR

■ LC72136N (IC2) : PLL Frequency synthesizer LSI

1. Layout

XT	1	22	XT
FM/AM	2	21	GND
CE	3	20	LPFOUT
DI	4	19	LPFIN
CLOCK	5	18	PD
DO	6	17	VCC
FM/ST/VCO	7	16	FMIN
AM/FM	8	15	AMIN
	9	14	POLAR
	10	13	IFCONT
SDIN	11	12	IFIN

2. Block



3. Function

Pin No.	Symbol	I/O	Function	Pin No.	Symbol	I/O	Function
1	XT	I	X'tal oscillator connect (75KHz)	12	IFIN	I	IF counter signal input
2	FM/AM	O	LOW:FM mode	13	IFCONT	O	IF signal output
3	CE	I	When data output/input for 4pin(input) and 6pin(output): H	14	POLAR	O	FM High Band:Low FM Low Band(Auto):High (Mono):Low
4	DI	I	Input for receive the serial data from controller	15	AMIN	I	AM Local OSC signal output
5	CLOCK	I	Sync signal input use	16	FMIN	I	FM Local OSC signal input
6	DO	O	Data output for Controller Output port	17	VCC	-	Power supply(VDD=4.5~5.5V) When power ON:Reset circuit move
7	FM/ST/VCO	O	"Low": MW mode	18	PD	O	PLL charge pump output(H: Local OSC frequency Height than Reference frequency. L: Low Agreement: Height impedance)
8	AM/FM	O	Not use	19	LPFIN	I	Input for active lowpassfilter of PLL
9		-	Not use	20	LPFOUT	O	Output for active lowpassfilter of PLL
10		-	Input/output port	21	GND	-	Connected to GND
11	SDIN	I/O	Data input/output	22	XT	I	X'tal oscillator(75KHz)

■ BU1923 (IC4) : RDS Detector


1.Terminal Layout

QUAL	1	16	CL
DA	2	15	TS7
VREF	3	14	XO
MUX	4	13	XI
VDD	5	12	VDD
GND	6	11	GND
CIN	7	10	GND
OUT	8	9	GND


2.Pin Functiont

Pin No	Symbol	I/O	Function
1	QUAL	--	Non connection
2	DA	O	RDS data output
3	VREF	O	Reference voltage output
4	MUX	I	Multiplex signal input
5	VDD	--	+5Vsupply voltage for analog
6	GND	--	Ground for analog part(0V)
7	CIN	I	Subcarrier outputof reconstruction filter
8	OUT	O	Ground for digital part(0V)
9	GND	--	Ground for digital part(0V)
10	GND	--	Ground for digital part(0V)
11	GND	--	Ground for digital part(0V)
12	VDD	--	+5Vsupply voltage for digital part
13	XI	I	Oscilator input
14	XO	O	Oscilator output
15	TS7	--	Non connection
16	CL	O	RDS clock output


3.Block Diagram



■ BA15218 (IC7, IC402, IC403, IC405, IC407, IC562) : Dual Ope Amp




■ BA15218N (IC202) : Dual Ope Amp



■ LA2650 (IC406) : SA BASS

1. Terminal Layout / Block diagram




■ TC4052BP (IC404) : Multiplexer

0Y	1	16	VDD
2Y	2	15	2X
Y-OUT	3	14	1X
3Y	4	13	X-OUT
1Y	5	12	0X
INH	6	11	3X
VEE	7	10	A
VSS	8	9	B

INHIBIT	B	A	X-OUT	Y-OUT
L	L	L	0X	0X
L	L	H	1X	1X
L	H	L	2X	2X
L	H	H	3X	3X
L	L	L	-	-
L	L	H	-	-
L	H	L	-	-
L	H	H	-	-
H	*	*	NONE	NONE

FL Tube

Grid assignment 7G



Anode connection

	9G	8G	7G	6G	5G,4G	3G	2G	1G
P1	B1	B15	<u>1</u>	S3	2a	2a	2a	STEREO
P2	B2	B16	<u>2</u>	S4	2h	2h	2h	PROLOGIC
P3	B3	B17	<u>3</u>	S5	2j	2j	2j	
P4	B4	B18	<u>4</u>	S6	2k	2k	2k	
P5	B5	B19	<u>5</u>	S7	2b	2b	2b	3CH LOGIC
P6	B6	B20	<u>6</u>	S8	2f	2f	2f	REC
P7	B7	B21	<u>7</u>	CD	2m	2m	2m	
P8	-	-	<u>8</u>	d	2g	2g	2g	SLEEP
P9	-	B29	<u>9</u>	e	2c	2c	2c	DAILY
P10	-	B30	<u>10</u>	c	2e	2e	2e	SOUND MODE
P11	-	B31	<u>11</u>	g	2r	2r	2r	
P12	-	B32	<u>12</u>	b	2p	2p	2p	
P13	-	B33	RANDOM	a	2n	2n	2n	
P14	-	B34	BEST HIT	-	2d	2d	2d	kHz
P15	-	B35	REPEAT	-	-	col	-	MHz

	9G	8G	7G	6G	5G,4G	3G	2G	1G
P16	-	-	-	-	-	Dp	-	(REC)
P17	B8	B22	<u>13J</u>	-	1a	1a	1a	TA
P18	B9	B23	<u>14J</u>	-	1h	1h	1h	R-D-S
P19	B10	B24	<u>15J</u>	-	1j	1j	1j	EON
P20	B11	B25	<u>16J</u>	-	1k	1k	1k	NEWS
P21	B12	B26	<u>ALL</u>	-	1b	1b	1b	INFO
P22	B13	B27	<u>1</u>	-	1f	1f	1f	C (TA)
P23	B14	B28	<u>CD</u>	-	1m	1m	1m	(INFO) D
P24	S2	S1	<u>PROGRAM</u>	-	1g	1g	1g	(C) D
P25	-	-	-	-	1c	1c	1c	⇒ ←
P26	-	-	-	-	1e	1e	1e	▶
P27	-	-	-	-	1r	1r	1r	◀
P28	-	-	-	-	1p	1p	1p	(A)
P29	-	-	-	-	1n	1n	1n	(B)
P30	-	-	-	-	1d	1d	1d	MONO

Pin connection

NOTE 1) F1,F2

Filament

2) NP

2) NF No pi
3) NX No ex

3) NX No extend p
4) RL Datum Line

4) DL Data
5) 1G~9G Grid

6) Field of vision is a m

6) Field of Vision is a

Disassembly Procedures

■ Removal of the Metal Cover

1. Remove the six screws A fastening the metal cover to the rear panel of the main unit.
2. Remove the two screws B fastening the metal cover to the side panel of the main unit.
3. Spread both side of the metal cover outward and remove from the back panel by lifting upward.




Fig 1




Fig 2

■ Removal of the CD Changer Mechanism Assembly

1. Remove the metal cover
2. Remove the two screws C fastening the CD changer mechanism assembly to the rear panel of the main unit. (See Fig.1)
3. Remove the two screws D fastening the CD changer mechanism assembly to the top panel of the main unit.
4. Disconnect the card wire connected from the CD changer mechanism assembly to connectors CN410 on the main amplifier board on the right side of the main unit.
5. Expand a rear panel outside, back of CD changer mechanism is lifted and detached.




Fig 3

■ Removal of the Front Panel Assembly

1. Remove the metal cover.
2. Remove the CD changer mechanism assembly.
3. Remove the four screws E fastening the front panel assembly to the side of the main unit.
4. Use a screwdriver, etc., to disengage clips ④ and ⑤ from the side panels of the main unit.
5. Disconnect the wires connected from the front panel assembly to connectors CN411, CN412 and CN413 on the main amplifier board.
6. Disconnect the wires CN915 and CN007 on the power amplifier board.
8. Disconnect connector CN414 on the Main P. C. Board
9. Remove the plastic rivet ⑥ fastening the main P. C. Board and front panel assembly.
10. Remove the front panel assembly.




Fig 4




Fig 5




Fig 6




Fig 7 CN007

■ Removal of the Rear Panel Assembly

1. Remove the metal cover.
2. Remove the CD changer mechanism assembly.
3. Remove seven screws F fastening the rear panel.
4. Remove two screws G fastening the rear cover.
5. Remove two screws H fastening the voltage selector of the rear panel.
6. Remove one screw I fastening the pin jack of the rear panel.
7. Remove three screws J fastening the heat sink of the rear panel.
8. Use a screwdriver, etc., to disengage the two engagements bottom chassis clips ④ and ⑤ from the bottom part of the side panels of the rear panel assembly.




Fig 8

F
G

Voltage selector

H

F

F

I




Fig 9

J
J
J

■ Removal of the Main Amplifier Board

1. Remove the rear panel.
2. Remove one screw K fastening the main amplifier board and bottom chassis to the side panel of the main unit.
3. Disconnect the main amplifier board CN415 and CN006 from the power amplifier board.




Fig 10

K

④




Fig 11

e

■ Remove of the Power Transformer

1. Remove the metal cover.
2. Remove the CD changer mechanism assembly.
3. Remove the rear panel .
4. Remove the four screws L fastening the power transformer.
5. Disconnect the connector CN111 and CN009 on the power amplifier board.




Fig 12

■ Removal of the Front Panel

1. Remove the metal cover.
2. Remove the CD changer mechanism assembly.
3. Remove the front panel assembly.
4. Remove the volume knob and nut on the front panel assembly.
5. Remove the six screws M fastening the stay bracket inside the front panel assembly.
6. Remove the eleven screws N fastening the system CPU board.
7. Disconnect the card wires protruding from connector CN803 on the system CPU board.




Fig 13

■ Removal of the Cassette Mechanism Assembly.

1. Remove the metal cover.
2. Remove the CD traverse mechanism assembly.
3. Remove the front panel assembly.
4. Remove the eight screws O fastening the cassette mechanism assembly to the inside of the front panel assembly.
5. Disconnect the card wires from connectors CN305 and CN306 on the head amplifier & mechanism control board.




Fig 14

«CD Changer Mechanism Type:VC3 Section»

■ Removing the CD Servo control board (See Fig.1)

1. Remove the metal cover.
2. Remove the CD changer mechanism assembly.
3. From bottom side the CD changer mechanism assembly, remove the two screws 1 retaining the CD servo control board.
4. Absorb the four soldered positions "M" of the right and left motors with a soldering absorber.
5. Pull out the earth wire on the CD changer mechanism assembly.
6. The two screws A is removed and C.B.holder is detached.
7. Disconnect the connector CN854 on the CD servo control board.
8. Disconnect the card wire CN601 and the connector CN801 on the CD servo control board.

■ Removing the CD tray assembly (See Fig.2~4)

1. Remove the front panel assembly.
2. Remove the CD changer mechanism assembly.
3. Remove the CD Servo control board.
4. From the T.bracket section "B" and clamper base section "C", remove both of the edges fixing the rod(See Fig.2 and 3).
5. Remove the screw 2 retaining the Disc stopper
(See Fig.3).
6. Remove the three screws 3 retaining the T.bracket
(See Fig.3).
7. Remove the screws 4 retaining the clamper assembly
(See Fig.3).
8. From the left side face of the chassis assembly, remove the one screw 5 retaining both of the return spring and lock lever(See Fig. 4).
9. By removing the pawl at the section "D" fixing the return spring, dismount the return spring(See Fig.4).
10. Remove the three lock levers(See Fig.4).




Fig.1




Fig.2




Fig.3




Fig.4

11. Check whether the lifter unit stopper has been caught into the hole at the section "E" of CD tray assembly as shown in Fig.5.
 12. Make sure that the driver unit elevator is positioned as shown in Fig.6 from the second or fifth hole on the left side face of the CD changer mechanism assembly.
- [Caution]** In case the driver unit elevator is not at above position, set the elevator to the position as shown in Fig.7 by manually turning the pulley gear as shown in Fig.8.
13. Manually turn the motor pulley in the clockwise direction until the lifter unit stopper is lowered from the section "E" of CD tray assembly(See Fig.8).
 14. Pull out all of the three stages of CD tray assembly in the arrow direction "F" until these stages stop (See Fig.6).
 15. At the position where the CD tray assembly has stopped, pull out the CD tray assembly while pressing the two pawls "G and G'" on the back side of CD tray assembly(See Fig.9). In this case, it is easy to pull out the assembly when it is pulled out first from the stage CD tray assembly.




Fig.5





Fig.6



Drive unit of elevator




Fig.8




Fig.9

■ Removing the CD loading mechanism assembly(See Fig.10)

1. While turning the cams R1 and R2 assembly in the arrow direction "H" , align the shaft "I" of the CD loading mechanism assembly to the position shown in Fig.10.
2. Remove the four screws 6 retaining the CD loading mechanism assembly.

■ Removing the CD traverse mechanism (See Fig.11 and 12)

1. For dismounting only the CD traverse mechanism without removing the CD loading mechanism assembly, align the shaft "J" of the CD loading mechanism assembly to the position shown Fig.11 while turning the cam R1 and R2 assembly in the arrow direction "K" .
2. By raising the CD loading mechanism assembly in the arrow direction "L" , remove the assembly from the lifter unit




Fig.10




Fig.11




Fig.12

■ Removing the CD pick unit (See Fig.13)

1. Move the cam gear in the arrow direction a . Then, the CD pickup unit will be moved in the arrow direction b .
2. According to the above step, shift the CD pickup unit to the center position.
3. While pressing the stopper retaining the shaft in the arrow direction c , pull out the shaft in the arrow direction d .
4. After dismounting the shaft from the CD pickup unit, remove the CD pickup unit




Fig.13

■ Removing the cam unit

(See Fig.14 ~17)

1. Remove the CD loading mechanism assembly.
2. While turning the cam gear L, align the pawl "N" position of the drive unit to the notch position(Fig.16) on the cam gear L.
3. Pull out the drive unit and cylinder gear(See Fig.17).
4. While turning the cam gear L, align the pawl "O" position of the select lever to the notch position(Fig.18) on the cam gear L.
5. Remove the four screws 9 retaining the cam unit(cam gear L and cams R1/R2 assembly)(See Fig.18).




Fig.14




Fig.15




Fig.16




Fig.17

■ Removing the actuator motor and belt (See Fig.18~21)

1. Remove the two screws 10 retaining the gear bracket (See Fig.19).
2. While pressing the pawl "P" fixing the gear bracket in the arrow direction, remove the gear bracket (See Fig.19).
3. From the notch "Q section" on the chassis assembly fixing the edge of gear bracket, remove and take out the gear bracket(See Fig. 20).
4. Remove the belts respectively from the right and left actuator motor pulleys and pulley gears(See Fig. 19).
5. After turning over the chassis assembly, remove the actuator motor while spreading the four pawls "R" fixing the right and left actuator motors in the arrow direction(See Fig. 21).

[Note] When the chassis assembly is turned over under the conditions wherein the gear bracket and belt have been removed, then the pulley gear as well as the gear, etc. constituting the gear unit can possibly be separated to pieces. In such a case, assemble these parts by referring to the assembly and configuration diagram in Fig. 22.




Fig.18




Fig.19




Fig.20

Assembly and Configuration Diagram




Fig.21

■ Removing the cams R1/R2 assembly and cam gear L(See Fig.22)

1. Remove the slit washer fixing the cams R1 and R2 assembly.
2. By removing the two pawls "S" fixing the cam R1, separate R2 from R1.
3. Remove the slit washer fixing the cam gear L.
4. Pull out the cam gear L from the C.G. base assembly.

■ Removing the C.G. base assembly (See Fig.22 and 23)

Remove the three screws 11 retaining the C.G. base assembly.

[Caution] To reassemble the cylinder gear, etc. with the cam unit (cam gear and cans R1/R2 assembly), gear unit and drive unit, align the position of the pawl "N" on the drive unit to that of the notch on the cam gear L. Then, make sure that the gear unit is engaged by turning the cam gear L (See Fig. 24).




Fig.22




Fig.23




< Cassette Mechanism Section >

■ Removing the Playback, Recording and Eraser Heads

1. While shifting the trigger arms seen on the right side of the head mount in the arrow direction, turn the flywheel R in counterclockwise direction until the head mount has gone out with a click (See Fig 1).
2. When the flywheel R is rotated in counterclockwise direction, the playback head will be turned in counterclockwise direction from the position in Fig 2 to that in Fig 3.
3. At this position, disconnect the flexible P.C.board (outgoing from the playback head) from the connector CN301 on the head amp. and mechanism control P.C. board.
4. After dismounting the FPC holder, remove the flexible P.C.board.
5. Remove the flexible P.C.board from the chassis base.
6. Remove the spring ① from behind the playback head.
7. Loosen the reversing azimuth screw retaining the playback head.
8. Take out the playback head from the front of the head mount.
9. The recording and eraser heads should also be removed similarly according to Steps 1~8 above.


● Reassembling the Playback, Recording and Eraser Heads

1. Reassemble the playback head from the front of the head mount to the position as shown in Fig 3.
2. Fix the reversing azimuth screw.
3. Set the spring a from behind the playback head.
4. Attach the flexible P.C.board to the chassis base, and fix it with the FPC holder as shown in Fig 3.
5. The recording and eraser heads should also be reassembled similarly according to Steps 1~4 above.



■ Removing the head Amp.and Mechanism Control P.C.Board (See Fig 4)




1. Remove the cassette mechanism assembly.
2. After turning over the cassette mechanism assembly, remove the five screws ① retaining the head amp. and mechanism control P.C. board
3. Disconnect the connectors CN303 and CN304 on the P.C. Board and the connectors CN1 on both the right and left side reel pulse P.C. Boards.
4. When necessary, remove the 4pin parallel wire soldered to the main motor



■ Removing the Capstan Motor Assembly


1. Remove the six screws ② retaining capstan motor assembly (See Fig 5).
2. While raising the capstan motor, remove the capstan belts A and B respectively from the motor pulley (See Fig 6).

Caution 1: Be sure to handle the capstan belts so carefully that these belts will not be stained by grease and other foreign matter. Moreover, these belts should be hand while referring to the capstan belt hanging method.





■Removing the Capstan Motor (See Fig 8)

From the joint bracket, remove the two screws③ retaining the capstan motor.




■Removing the Flywheel (See Fig 9.10)

1. Remove the head amp. and mechanism control P.C.Board.
2. Remove the capstan motor assembly.
3. After turning over the cassette mechanism, remove the slit washers ④ and ⑤ fixing the capstan shafts R and L, and pull out the flywheels R and L respectively from behind the cassette mechanism.




■Removing the Reel Pulse P.C.Board and Solenoid (See Fig 11)

1. Remove the five pawls (⑥ ⑦ ⑧ ⑨ ⑩) retaining the reel pulse P.C.Board.
2. From the surface of the reel pulse P.C.Board parts, remove the two pawls ⑪ and ⑫ retaining the solenoid.



Flow of Functional Operation Until TOC Read



Maintenance of Laser Pickup Replacement of Laser Pickup


(1) Cleaning the pick up lens

Befor you replace the pick up, please try to clean the lens with a alcohol soaked cotton swab.

(2) Life of the laser diode (Fig.1)

When the life of the laser diode has expired, the following symptoms wil appear.

- (1) The level of RF output (EFM output:amplitude of eye pattern) will below.



(Fig.1)

(3) Semi-fixed resistor on the APC PC board

The semi-fixed resistor on the APC printed circuit board which is attached to the pickup is used to adjust the laser power. Since this adjustment should be performed to match the characteristics of the whole optical block, do not touch the semi-fixed resistor.

If the laser power is lower than the specified value, the laser diode is almost worn out, and the laser pickup should be replaced.

If the semi-fixed resistor is adjusted while the pickup is functioning normally, the laser pickup may be damaged due to excessive current.

Turn off the power switch and,disconnect the power cord from the ac outlet.

Replace the pickup with a normal one.(Refer to " Pickup Removal" on the previous page)

Plug the power cord in, and turn the power on. At this time,check that the laser emits for about 3seconds and the objective lens moves up and down.
Note: Do not observe the laser beam directly.

Play a disc.

Check the eye-pattern at TP1.

Finish.

Adjustment Procedures

■ Measurement Instruments Required for Adjustment

1. Low frequency oscillator,
This oscillator should have a capacity to output 0dBs to 600Ω at an oscillation frequency of 50Hz-20kHz.
2. Attenuator impedance : 600Ω
3. Electronic voltmeter
4. Frequency counter
5. Wow flutter meter
6. Test tape
VT712 : For Tape speed and wow flutter (3kHz)
VT724 : For Reference level (1kHz)
TMT7036 : For Head angle(10kHz),Play back frequency characteristics(1kHz),and dubbing frequency characteristics(63,1,10kHz)
Because of frequency-mixed tape with 63,1k,10k and 14kHz(250nWb/m -24dB).
Use this tape together with a filter.
7. Blank tape
TAPE I : AC-225, TAPE II : AC-514
8. Torque gauge : For play and back tension
Forward ; TW2111A, Reverse ; TW2121A
Fast Forward and Rewind ; TW2231A
9. Test disc
: CTS-1000(12cm),GRG-1211(8cm)
10. Jitter meter

■ Measurement Conditions

Power supply voltage : AC110-240V(50Hz) for U,A group
: 220V(60Hz) for UP
: 120V(60Hz) for J,C
Reference output : Speaker 0.775V/6 Ω
: Headphone 0.0775V/32 Ω
Measurement
output terminal : Speaker out
:TP101(Mesuring for TUNER/DECK/CD)

Radio input signal
AM modulation frequency : 400Hz
Modulation factor : 30%
FM modulation frequency : 400Hz
Frequency displacement : 22.5kHz


Standard measurement positions of volume and switch
Sound mode : Off
SA-Bass : Off
Main VOL. : 0 Minimum
KARAOKE : OFF (U,A group only)
ECHO : OFF (U,A group only)
Travers mecha set position : Disc 1

Precautions for Measurement


1. Apply 30pF and 33kΩ to the IF sweeper output side and 0.082μ F and 100kΩ in series to the sweeper input side.
2. The IF sweeper output level should be made as low as possible within the adjustable range.
3. Since the IF sweeper is a fixed device, there is no need to adjust this sweeper.
4. Since a ceramic oscillator is used, there is no need to perform any MPX adjustment.
5. Since a fixed coil is used, there is no need to adjust the FM tracking.
6. The input and output earth systems are separated.
In case of simultaneously measuring the voltage in both of the input and output systems with an electronic voltmeter for two channels, therefore, the earth should be connected particularly.
7. In the case of BTL connection amplifier, the minus terminal of speaker is not for earthing. Therefore, be sure not to connect any other earth terminal to this terminal. This system is of an OTL system.

■Arrangement of Adjusting Positions


Cassette mechanism section (Mechanism A section)



Cassette mechanism section (Back side)



Cassette Mechanism Unit Section



■ Tape Recorder Section

Items	Measurement conditions	Measurement method	Standard values	Adjusting positions
Confirmation of head angle	Test tape :TMT7036(10kHz) Measurement output terminal :Speaker terminal Speaker R (Load resistor:3Ω) :Headphone terminal	1.Playback the test tape TMT7036(10kHz). 2.With the playback mechanism or recording & playback mechanism, adjust the head azimuth screw so that the forward and reverse output levels become maximum. After adjustment, lock the head azimuth at least by half a turn. 3.In either case, this adjustment should be performed in both the forward and reverse directions with the head azimuth screw.	Maximum output	Adjust the head azimuth screw only when the head has been changed.
Confirmation of tape speed	Test tape :VTT712(3kHz) or TMT7036(3kHz) Measurement output terminal :Headphone terminal	<Constant speed> Adjust VR301 so that the frequency counter reading becomes $3,010\text{Hz} \pm 15\text{Hz}$ when playing back the test tape VTT712(3kHz) with the playback mechanism or playback and recording mechanism after ending forward winding of the tape.	Tape speed of decks (A and B) : $3,010\text{Hz} \pm 15\text{Hz}$	VR301

■ Reference Values for Confirmation items

Items	Measurement conditions	Measurement method	Standard values	Adjusting positions
Double tape speed	Test tape :TMT7036(10kHz) Measurement output terminal :Speaker terminal Speaker R (Load resistance:3Ω) measurement output terminal :Headphone terminal	After setting to the double speed motor, confirm that the frequency counter reading becomes $4,800+400/-300\text{Hz}$ when the test tape VTT712 (3kHz) has been play back with the playback mechanism.	$4,800+400/-300\text{Hz}$	Playback mechanism side
Difference between the forward and reverse speed. P.mecha and R/P mecha speed		When the test tape VTT712(3kHz) has been played back with the playback mechanism or recording and playback mechanism at the beginning of forward winding, the frequency counter reading of the difference between both of the mechanisms should be 6.0Hz or less.	60Hz or less	Both the playback and recording & playback mechanism
Wow & flutter	Test tape :TMT7036(10kHz) Measurement output terminal :Headphone terminal	When the test tape VTT712(3kHz) has been played back with the playback mechanism or recording and playback mechanism at the beginning of forward winding the frequency counter reading of wow & flutter should be 0.25% or less(WRMS).	0.25% or less (WRMS)	Both the playback and recording & playback mechanism


■ Electrical Performance

Items	Measurement conditions	Measurement method	Standard values	Adjusting positions
Adjustment of recording bias current (Reference value)	*Mode : Forward or reverse mode *Recording mode *Test tape :AC-514 and AC-225 Measurement output terminal :Both recording and headphone terminals	1.With the recording and playback mechanism, load the test tapes(AC-514 to TYP II and AC-225 to TYP I),and set the mechanism to the recording and pausing conditions in advance. 2.After connecting 100Ω in series to the recorder head,measure the bias current with a valve voltmeter at both of the terminals. 3.After resetting the [PAUSE] mode,start recording. At this time,adjust VR101 for LcH and VR201 for RcH so that the recording bias current values become $4.0\mu A$ (TYP I) and $4.20\mu A$ (TYP II).	AC-225 : $4.20\mu A$ AC-514 : $4.0\mu A$	LcH :VR101 RcH :VR201
Adjustment of recording and playback frequency characteristics	Reference frequency :1kHz and 10kHz (REF:-20dB) Test tape :TYP II AC-514 Measurement input terminal :OSC IN	1.With the recording and playback mechanism,load the test tape(AC-514 to TYP II),and set the mechanism to the recording and pausing condition in advance. 2.While repetitively inputting the reference frequency signal of 1kHz and 10kHz from OSC IN, record and playback the test tape. 3.While recording and playing back the test tape in TYP II ,adjust VR101 for LcH and VR201 for RcH so that the output deviation between 1kHz and 10kHz becomes $-1dB\pm 2dB$.	Output deviation between 1kHz and 10kHz : $-1dB\pm 2dB$	LcH :VR101 RcH :VR201

■ Reference Values for Electrical Function Confirmation Items

Items	Measurement conditions	Measurement method	Standard values	Adjusting positions
Recording bias frequency	*Recording and playback side forward or reverse *Test tape :TYP II AC-514 *Measurement terminal BIAS TP on P.C.board	1.While changing over to and from BIAS 1 and 2, confirm that the frequency is changed. 2.With the recording and playback mechanism, load the test tape (AC-514 to TYP II),and set the mechanism to the recording and pausing conditions in advance. 3.Confirm that the BIAS TP frequency on the P.C.board is $100kHz\pm 6kHz$.	$100kHz\pm 6kHz$	
Eraser current (Reference value)	*Recording and playback side forward or reverse *Recording mode *Test tape :AC-514 and AC-225 Measurement terminal Both of the eraser head	1.With the recording and playback mechanism, load the test tapes(AC-514 to TYP II and AC-225 to TYP I),and set the mechanism to the recording and pausing condition in advance. 2.After setting to the recording conditions,connect $1M\Omega$ in series to the eraser head on the recording and playback mechanism side,and measure the eraser current from both of the eraser terminal.	TYP II : $120mA$ TYP I : $75mA$	


■ Block Diagrams




CA-D702T/D752TR


MEMO


■ Power Primary Section for J/C and B/E/EE/EN







■ Power Primary Section for U/UB/UA/US/UT/UX/A and UP






■ Mic Amp. Section for only CA-D702TU / A





■ FL / System Control Section



MARK		MODEL	VERSION	R992	R993	R990	R991	S982	S983	S984	S985	S963	O13/VG11	O120/D921	R829
MX-D402T	J-C		1BK	3BK	220K	3BK	NONE	NONE	NONE						
	U		1BK	5BK	220K	3BK	NONE	NONE	NONE	NONE	NONE	USED	USED	USED	USED
	UR		1BK	NONE	220K	3BK	NONE	NONE	NONE	NONE	NONE	USED	USED	USED	USED
	A		1BK	5BK	220K	3BK	NONE	NONE	NONE	NONE	NONE	USED	USED	USED	USED
CA-D452TR/D432TR	B/EVEN		1BK	6BK	220K	82K	USED	USED	USED	USED	NONE	NONE	NONE	NONE	NONE
	E		6BK	1BK	220K	82K	USED	USED	USED	USED	NONE	NONE	NONE	NONE	NONE
MX-D502T	J-C		1BK	2BK	47K	3BK	NONE	NONE	NONE	NONE	USED	NONE	NONE	NONE	NONE
	UL/PLA5/UT/UX		1BK	6BK	47K	3BK	NONE	NONE	NONE	NONE	USED	USED	USED	USED	USED
	UR		1BK	NONE	47K	3BK	NONE	NONE	NONE	NONE	USED	USED	USED	USED	USED
CA-D702T	A		1BK	6BK	47K	3BK	NONE	NONE	NONE	NONE	USED	USED	USED	USED	USED
	EVEN/EN		1BK	6BK	47K	62K	USED	USED	USED	USED	USED	NONE	NONE	NONE	NONE
	E		6BK	1BK	47K	92K	USED	USED	USED	USED	USED	NONE	NONE	NONE	NONE
CA-D752TR	EVEN		1BK	6BK	47K	62K	USED	USED	USED	USED	NONE	NONE	NONE	NONE	NONE
	E		6BK	1BK	47K	92K	USED	USED	USED	USED	NONE	NONE	NONE	NONE	NONE
CA-MX0230			6BK	6BK	220K	62K	NONE	NONE	NONE						

A



B

C

D

E

CA-D702T/D752TR



NOTES

1. VOLTAGES ARE DETERMINED WITH A DIGITAL VOLTMETER OR OSCILLOSCOPE WITHOUT INPUT GND-CONDITION ---- TAKE IN HOLE
2. UNLESS OTHERWISE SPECIFIED:
ALL RESISTORS ARE 1% METAL-OHM RESISTOR.
ALL RESISTANCE VALUES ARE IN MΩ.
ALL CAPACITORS ARE LEADLESS CAPACITOR OR MEAN CAPACITOR.
ALL INDUCTANCES ARE IN HENRIES.
ALL INDUCTANCE VALUES ARE IN HENRIES.
ALL DIODES ARE 1N4148.

E


E


G

H

1

■ Input / Source Selector Section







Input Signal
Front Signal
Rear Signal
Center Signal

* MARK		Q USED X NONE					
FUNC	SYMBOL	W-DRAFT		CA-5700T		MA-5750TR	
		J	C	U, U, U, U, U, U	A	B, B, B, B, B, B	E
2007	R4237-R4301	X	X	D	D	X	X
	C433-C440	X	X	D	D	X	X
2008	I4040	D	C	D	D	C	D
	R4239-R4303	D	D	D	D	D	D
2009	C441-C442	D	C	D	D	D	D
	G4011-G4021	D	D	D	D	D	D
2010	G4151-G4162	X	X	X	X	X	X
2011	R4433-R4444	X	X	O	O	X	X
2012	R4451-R4453	A, 7K	A, 7K	B, 7K	B, 7K	A, 7K	A, 7K
2013	R4571-R4581	S, EX	S, EX	Z, EX	Z, EX	Z, EX	Z, EX
	R4582-R4585	L, EX	L, EX	L, EX	L, EX	L, EX	L, EX
2014	C4811	D	O	X	X	X	X
	C5811	X	X	X	X	D	X
2015	D-011MF	D-011MF	D-011MF	X	X	D-011	X
	D3014	O	X	X	X	X	X
2016	H4401	X	D	O	O	D	O
	R302	X	X	X	X	D	O
2017	C4531-C4532	X	X	X	X	D	X
	C4814	100P	100P	100P	100P	D, 100P	100P
2018	L4002	O	O	D	D	O	SHORT
	L4013	O	O	O	O	O	SHORT
2019	L4014	SHORT	SHORT	SHORT	SHORT	O	O
	L4015	SHORT	SHORT	SHORT	SHORT	O	SHORT
R372		1/4W UNF. L, 100		1/4W FUSE BIE PROTECTOR			
C4118-C4119		O	O	O	O	O	X

■ Audio Output Section




CA-D702T/D752TR




- Front Signal
- Rear Signal
- Center Signal

 Parts are safety assurance parts.
When replacing those parts make
sure to use the specified one.

CD Section





DON'T USE

FROM CN410 OF
FMC-021-1
(SHEET /11)

DON'T USE

CD SIGNAL

EMW10729

E


F

G

H

I

■ Tape Section




NOTES:

1. VOLTAGES ARE DC-MEASURED WITH A DIGITAL VOLT METER
ON GND REFERENCE WITHOUT INPUT SIGNAL. 1 IS INVERT MODE
2. UNLESS OTHERWISE SPECIFIED
- ALL RESISTANCE VALUES ARE IN OHMS.
- ALL CAPACITORS ARE POLYMER CAPACITORS.
- ALL CAPACITANCE VALUES ARE IN μF OR pF .
- ALL INDUCTANCE VALUES ARE IN nH .
- ALL C-CAPACITORS ARE SHOWN IN THE FORM OF CAPACITANCE $\text{uF}/\text{RATED VOLTAGE}$ (V).
- POLYIMIDE CAPACITOR

TABLE 3-DIGITAL TRISTATE


Ref. No.	DESCRIPTION	Ref. No.	DESCRIPTION
IC101	IC101	C101	100
IC102	IC102	C102	100
IC103	IC103	C103	100


CA-D702T/D752TR



■ FM MPX Detector Section for only CA-D752TREE

FROM CN420 OF FMC-012-1
[TUNER SECTION]






Main Signal

FMB-012-7

■ Tuner Section for only CA-D702TU / UB / UP / US / UT / UX / A



A


B

C

D

E

CA-D702T/D752TR



Tr No.	Q1	Q6	Q16
PIN NO.	E C B	E C B	E C B
FM 87.5MHz NO SIGNAL	0 0.3 0.8	0.8 0 9.7	0 1.0 3.5 1.6
AM 52.2kHz NO SIGNAL	0 0 0	0 0 9.7	1.0 3.5 1.6
Tr No.	Q2	Q3	Q4
PIN NO.	E C B	E C B	E C B
AM 52.2kHz NO SIGNAL	2.0 2.0 0.1	0 0 0.7	0 0 0.7
AM 144kHz NO SIGNAL	2.0 2.0 2.0	0 0 0.1	0 0 0.1

E


F

G

H

I

■ Tuner Section for only CA-D752TRE / EN / B



	CONDITION PIN NO	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24		
IC1	FM NO SIGNAL	2.0	0.5	0	2.0	5.2	5.2	0	0	0.2	5.2	5.2	1.0	1.0	4.6	3.8	3.8	1.4	0	1.3	1.1	2.0	2.0	5.2	2.0		
	FM 60dB STEREO	2.0	0.5	0	2.0	5.2	5.2	1.3	0	0.2	5.0	5.2	0	0	3.0	1.0	4.5	4.3	3.9	1.4	0	1.2	1.1	2.0	2.0	5.2	2.0
	AM NO SIGNAL	2.0	0.5	0	2.0	5.0	5.2	0	0	0.2	5.2	5.2	1.0	1.0	4.8	2.2	0	1.4	3.4	1.5	1.6	2.0	2.0	5.2	2.0		
IC2	FM NO SIGNAL	2.7	0	0	4.9	4.9	4.9	3.8	3.0	2.0	4.1	5.2	0	0	0	2.6	5.2	1.0	1.0	3.7	0	2.7					

A


B

C

D

E


P1
FM 87.5
AM 52.0
P2
AM 52.0
AM 144



TR NO.	Q1			Q6			Q16		
PIN NO.	E	C	B	E	C	B	E	C	B
FM 87.5MHz NO SIGNAL	0	0.3	0.8	9.8	9.7	0	1.0	3.5	1.6
AM 522kHz NO SIGNAL	0	0	0	0.6	0	0.7	1.0	3.5	1.6
TR NO.	Q2			Q3			Q4		
PIN NO.	E	C	B	E	C	B	E	C	B
AM 522kHz NO SIGNAL	2.0	2.0	0.1	0	0	0.7	0	0	0.7
AM 144kHz NO SIGNAL	2.0	2.0	2.0	0	0	0.1	0	0	0.1

E F G H I

■ Tuner Section for only CA-D752TREE



CONDITION PIN NO.	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
IC1: FM NO SIGNAL	0.0	0.3	0	0.0	0.3	0.3	0	0	0.3	0.3	0.2	0.1	1.0	4.6	3.0	3.0	1.4	0	1.3	1.1	2.0	2.0	0.2	2.0
IC1: FM 2000 STEREO	0.0	0.3	0	2.0	0.3	0.3	0.1	0	0.3	0.5	0	0.1	0.1	0.1	4.1	3.9	1.4	0	0.3	1.1	0.1	3.0	3.2	0.1
IC1: AM NO SIGNAL	2.0	0	0.5	0	2.0	0.0	0.3	0	0	0.2	0.3	0.2	1.0	1.9	4.8	2.2	0	1.4	1.5	1.6	3.1	3.0	1.2	3.1
IC1: FM NO SIGNAL	0.7	0	0	4.9	4.9	4.9	3.9	3.6	2.0	4.1	4.2	0	0	0	0	3.6	5.2	1.0	1.0	3.7	0	2.7		

TR 10	FM 10
FM 87.5MHz	
AM 525kHz N	
TR 8K	
FM 525kHz N	
AM 14.4kHz N	

A


B

C

D

E

CA-D702T/D752TR




TR NO.	Q1			Q2			Q3			Q4		
PIN NO.	E	C	B	E	C	B	E	C	B	E	C	B
FM 87.5MHz NO SIGNAL	0	0.3	0.8	9.3	5.7	0						
AM 520KHz NO SIGNAL	0	0	0	9.8	0	9.7						
TR NO.	Q2			Q3			Q4					
PIN NO.	E	C	B	E	C	B	E	C	B	E	C	B
AM 520KHz NO SIGNAL	2.0	2.0	0.1	0	0	0.7	0	0	0.7			
AM 144KHz NO SIGNAL	2.0	2.0	2.0	0	0	0.1	0	0	0.1			


FM Signal

AM Signal

Printed Circuit Board

Main Board





E


F

G


H

I


■ Power Amplifier Board




CA-D702T/D752TR



System Control Operation Switch Board





E


F

G


H

I

■ CD Servo Changer Mechanism Control Board




CA-D702T/D752TR




■ Head Amplifier Mechanism Control Board & Reelpulse Board


■ Head Amplifier Mechanism Control Board




■ ReelPulse Board




A B C D E



■ CD Tray Select Board & Cam Switch Board

CA-D702T/D752TR

■ Cam Switch Board



E

F

G

H

I

PARTS LIST

[CA-D702T/D752TR]

1. Those parts can not be sent as a rule that has not printed or be displayed 「—」 on the parts list.
2. The printed circuit board will be not sent as a rule.
3. **⚠** Parts are safety assurance parts. When replacing those parts, make sure to use to specified one.
4. All printed circuit boards and its assemblies are not available as service parts.

Area Suffix	
CA-D702T	
U	Other Areas
UT	Taiwan
US	Singapore
UB	Hong Kong
UP	Korea
UX	Saudi arabia
A	Austraria
CA-D752TR	
B	U.K
E	Continental Europe
EN	Northen Europe
EE	Eastern Europe


- Contents -

Exploded View of General Assembly and Parts List -----	3- 3
Exploded View of CD Changer Mechanism and Parts List -----	3- 5
Exploded View of CD Mechanism and Parts List -----	3- 7
Exploded View Cassette Mechanism and Parts List-----	3- 8
Electrical Parts List -----	3-10
Power Supply & Amplifier P.C.B. -----	3-10
Pre Amplifier & Tuner P.C.B. -----	3-13
System Micon & Operation P.C.B. -----	3-18
CD Servo Control P.C.B. -----	3-22
CD Select Switch P.C.B. -----	3-23
Head Amp & Mechanism Control P.C.B.-----	3-24
Reel Pulse P.C.B. -----	3-25
Reel Pulse P.C.B. -----	3-25
Packing Materials and Accessories Parts List -----	3-26

CA-D702T/D752TR

General Exploded View and Parts List

Block No. M 1 1



A


B

C

D

E

M 1 M M



E

F

G

H

I

BLOCK NO. M1M1M1M1

A	REF.	PARTS NO.	PARTS NAME	REMARKS	QTY	SUFFIX	CLR
	1	GV10001-005AKP	FRONT PANEL		1		
	2	E406971-001SM	JVC MARK		1		
	3	GV40003-001AKP	STBY. INDICATOR		1		
	4	GV20009-002AKP	CD BUTTON		1		
	5	E75896-001	SPACER		2		
	6	GV30008-002AKP	DISC BUTTON	ATTACH TO CD BT	1		
	7	GV30010-004AKP	POWER BUTTON		1		
	8	GV20006-001AKP	SOUND BUTTON		1		
	9	GV30009-002BKP	CONTROL BUTTON	CA-D752TR	1		
		GV30009-002BKP	CONTROL BUTTON	CA-D702T	1		
	10	GV30018-003BKP	SEARCH BTN.ASSY		1		
	11	SDSF2608Z	SCREW	SWITCH BOARD	5		
	12	SDSF2608Z	SCREW	ONLY CA-D702T	1		
	13	GV30016-002AKP	PUSH BUTTON		1		
	14	SDSF2608Z	SCREW	MICOM BOARD	4		
	15	GV30017-002AKP	PUSH BUTTON		1		
	16	GV30003-001AKP	STAY BRACKET		1		
	17	SDSF2608Z	SCREW		7		
	18	GV40001-001AKP	H.P BRACKET		1		
	19	FMYH4004-001	PLASTIC RIVET	MAIN BOARD&BKT.	1		
	20	GV30013-001AKP	SOURCE BUTTON		1		
	21	GV40004-001AKP	MIC BRACKET		1		
	22	GV30012-001AKP	RDS BUTTON	ONLY CA-D752TR	1		
	23	GV20001-004AKP	CASS HOLDER (L)		1		
	24	GV20002-004AKP	CASS HOLDER (R)		1		
	25	GV20003-001AKP	CASS LENS (L)		1		
	26	GV20004-001AKP	CASS LENS (R)		1		
	27	GV30014-005AKP	EJECT BUTTON(A)		1		
	28	GV30015-005AKP	EJECT BUTTON(B)		1		
	29	FMKW4009-001	HOLDER SPRING A		1		
	30	FMKW4010-001	HOLDER SPRING B		1		
	31	FMKW4011-001	SPRING	FOR EJECT LEVER	1		
	32	FMKS3002-002KP	EJECT LEVER(A)		1		
	33	FMKS3003-002KP	EJECT LEVER(B)		1		
	34	VYH7779-00B	DUMPER ASS'Y		2		
	35	VKY4180-001	CASSETTE SPRING		4		
	36	FMKL4012-003	EJECT SAFETY(A)		1		
	37	FMKL4013-001	EJECT SAFETY(B)		1		
	38	FMKW4007-001	SPRING (A)	EJECT SAFETY A	1		
	39	FMKW4008-001	SPRING (B)	EJECT SAFETY B	1		
	40	-----	CASSETTE MECHA		1		
	41	FMKL2002-001	HOLDER BRACKET		1		
	42	SBSG3010Z	T.SCREW	F.P.TO H.BRKT.	2		
	43	SBSG3010Z	T.SCREW	F.P.TO CHS.BASE	2		
	44	SBSG3010Z	T.SCREW	MECHA & H.BRKT.	4		
	45	SBSF3010Z	SCREW	MECHA & F.PANEL	4		
	46	-----	CHENGER MECHA		1		
	47	GV30022-001A	PROTECT SHEET		1		
	57	E309662-001	DISC STOPPER		1		
	58	SBSF3008Z	SCREW	FOR DISC STOPPE	1		
	61	GV10003-001AKP	CHASSIS BASE		1		
	62	E75896-006	FELT SPACER		2		
	63	GV30006-001AKP	HEAT SINK		1		
	65	SBSG3014CC	T.SCREW		6		
	66	E406969-002SM	LEAF SPRING		1		


BLOCK NO. M1MM

REF.	PARTS NO.	PARTS NAME	REMARKS	Q'TY	SUFFIX	CLR
	67 FMKL4007-001 68 FMPK4004-001 69 FMPK4003-001 70 E65389-002 71 E409015-001SM	BRACKET MICA SHEET MICA SHEET SPECIAL SCREW SHIELD PLATE	FOR POWER IC	2 1 2 4 1		
	72 GBSG3008CC 73 QMPK090-205-JN QMPK090-205-JN QMP7520-200 QMP5530-0085BS	T.SCREW POWER CORD POWER CORD POWER CORD POWER CORD	M.BOARD & C.BAS CA-D702T CA-D752TR CA-D702T CA-D702T	2 1 1 1 1	U,US E,EE,EN UT,UX UB	
	74 QMPN090-200-JC QMPG020-244-JC EMP7000-200 79 QHS3771-108 VKZ4001-110	POWER CORD POWER CORD POWER CORD CORD STOPPER WIRE HOLDER	CA-D752TR CA-D702T CA-D702T	1 1 1	B A UP	
	80 QQTO157-002 QQTO157-003 82 QMF51E2-1R25 QMF51E2-1R25 QMF51E2-2R5	POWER TRANSF POWER TRANS FUSE FUSE FUSE	T001 CA-D752TR T001 CA-D702T F001 CA-D752TR F001 CA-D702T F001 CA-D702T	1 1 1 1 1		
	83 QMF51E2-2R5 84 QMF51E2-1R25 85 QMF51E2-3R15J1 89 ZSC4467/OPY/-F1	FUSE FUSE FUSE TRANSISTOR	F001 CA-D702T F003 CA-D702T F101 F102 Q757	1 1 1 1	US,UX,UT	
	90 2SA1694/OPY/-F1 91 GV10004-016AKP GV10004-017AKP GV10004-018AKP GV10004-014AKP	TRANSISTOR REAR PANEL REAR PANEL REAR PANEL REAR PANEL	Q758 CA-D702T CA-D752TR CA-D752TR CA-D702T	1 1 1 1 1	UT B,E,EN EE A,U,US,UX,UB	
	92 GV10004-015AKP E207356-001SM 94 SBSG3008Z 95 E73273-003 96 E73273-003	REAR PANEL REAR COVER T.SCREW SPECIAL SCREW SPECIAL SCREW	CA-D702T C3 & STAY BRKT.	1 2 15 6	UP	
	97 E73273-003 98 GV10002-008A(S) 99 SBSB3006M 100 E209153-004SMKP 101 E209155-003SMKP	SPECIAL SCREW METAL COVER T.SCREW CD FITTING CD FITTING	CA-D702T DISC 1 DISC 2	2 1 2 1 1		
	102 E209157-004SMKP 103 E310080-231SMKP 104 GV20005-007AKP GV20005-008AKP 105 E408765-005SMKP	CD FITTING M.VOL.KNOB WINDOW SCREEN WINDOW SCREEN MIC KNOB	DISC 3 CA-D752T CA-D702T CA-D602T	1 1 1 1		
	106 VWF1211-15TTB 107 VWF1220-10TTB 108 VWF1216-10TTB 109 VWF1212-25TTB 110 VWF1210-20TTB	CARD WIRE CARD WIRE CARD WIRE TAF CARD CARD WIRE	FMB-SLC FMB-MAIN FMB-MAIN FMB-FMH MAIN-SLC	1 1 1 1 1		
	111 VWF1019-20TTA 114 GV20007-005AKP GV20007-006AKP	CARD WIRE ORNAMENT ORNAMENT	MAIN-VC3 CA-D752T CA-D702T	1 1 1		

CD Changer Mechanism and Parts List

Block No. M 2 M M

VC3-1M



■ Parts List

Block No. M2MM


▲	Item	Parts Number	Parts Name	Q'ty	Description	Area
	1	VKS1144-003	CHASSIS BASE	1		
	2	VKS3698-003	TRAY GUIDE	2		
	3	VKS5532-003	GEAR	2		
	4	VKB3000-164	DRIVE BELT	2		
	5	VKS5505-003	GEAR	2		
	6	VKS5506-002	GEAR	3		
	7	VKS5507-002	GEAR	1		
	8	VKS5508-002	GEAR	1		
	9	VKS5510-003	SELECT LEVER	1		
	10	VKH5769-001	GEAR STUD	1		
	11	VKS5511-002	GEAR	1		
	12	VKW5155-003	COMPRESS SPRING	1	SELECT GEAR	
	13	VKM3846-002	GEAR BRACKET	1		
	14	VKS5509-002MM	CYLINDER GEAR	1		
	15	MSN5D257A-SA2	DC MOTOR	2		
	16	QYSPSPD2616Z	SCREW	2	DC MOTOR ASS'Y	
	18	VKM3825-00AMM	GEAR BASE	1		
	19	VKZ3172-00ASS	CAM SWITCH (R)	1		
	20	VKZ3173-00ASS	CAM SWITCH (L)	1		
	21	QYSPST2606Z	SCREW	4		
	22	VKS2263-002MM	DRIVING CAM	1		
	23	VKS2264-002MM	DRIVING CAM	1		
	24	VKS2265-002MM	SUB GEAR	1		
	25	WDL316050MM	SLIT WASHER	2		
	27	QYSBSF2608Z	TAPPING SCREW	16		
	28	VKS3702-00FMM	DRIVE UNIT	1		
	29	VKS2247-004	MECHA HOLDER	1		
	30	VKL7767-00B	MECHA BRACKET	1		
	31	QYSBSF2606Z	SCREW	2	BRACKET	
	32	VKM3860-00A	MECHA HOLDER	1		
	33	VKL7802-00C	MECHA HOLDER	1		
	34	QYSDST2604Z	SCREW	3		
	35	VKL7810-00A	LIFTER	1		
	36	VKL7811-00A	LIFTER	1		
	37	VKL7812-00A	LIFTER	1		
	38	VKL2732-002	LIFTER BASE	1		
	39	VKM3857-001	LIFTER BRACKET	1		
	41	WDL266035-2	SLIT WASHER	1		
	43	VKS5514-002MM	ROCK LEVER	3		
	44	VKY3133-002MM	RETURN SPRING	1		
	46	VKY3134-003MM	SPRING	1		
	47	VKS2252-00E	TRAY ASS'Y	3		
	48	VKS2250-003	TRAY BRACKET	1		
	49	VKS5515-002	TRAY STOPPER	1		
	50	VKW5156-004	TORSION SPRING	1		
	51	VKS3703-00FMMKP	CLAMPER ASS'Y	1		
	62	FMYH4003-002	INSULATOR	2		
	63	FMYH4003-001	INSULATOR	2		
	65	—	CD MECHA ASS'Y	1		
	69	OGB2021L1-10	CONNECT TERMINAL	1	CN805	
	71	VKW5187-001	ROD	1		
	72	VYSA1R2-033	SPACER	1	EWS176-008	
	73	LE30611-001A	P. W. B. HOLDER	1	CD P. W. B.	
	74	QYSBSF3008Z	SCREW	2	HOLDER	
	75	QUQ110-1509AJ	FLAT WIRE	1		
	76	EWS176-008	FLAT WIRE	1		

CD Mechanism Ass'y and Parts List

■ Grease Point

Block No. M3MM

No. EXL-M6



■ CD Mechanism Assembly Parts List

Item	Parts Number	Parts Name	Q'ty	Description	Area
1	EPB-002PK	MECHA. BASE ASSY	1		
2	OPTIMA-150S	OPTICAL PICK UP	1		
3	E407782-001	CD SHAFT	1		
4	E307746-001	CD RACK	1		
5	EPB-003A	MECHA GEAR	1		
6	SDSP2003N	SCREW	4		
7	E406750-001	PINION GEAR	1		
8	EPB309173A	TURN TABLE	1		
9	E406784-001	FEED MOTOR	1	Use the No.11 P.C.Board	
	MDN-4RA3ETA-1	FEED MOTOR	1	Use the No.12 P.C.Board	
10	E406783-001	SPINDLE MOTOR	1		
11	EMW10190-001 (S)	P. C. BOARD	1		
12	EMW10190-221 (S)	P. C. BOARD	1		
13	ESB1100-005	LEAF SWITCH	1		
14	E75832-001	SCREW	1		
15	EMV5109-006B	CONN. TERMINAL	1		
16	SDFS2006Z	SCREW	1		

A

B


C

D

E

Cassette Mechanism & Parts List

Block No. M 4 M M



■ Parts List (Cassette Mechanism Ass'y)

Block No. M4MM

▲	Item	Parts Number	Parts Name	Q'ty	Description	Area
	1	VKS1165-00F	CHASSIS BASE ASS'Y	2		
	2	VKH5786-002	SHAFT	2		
	3	VKS5603-00C	MAIN PULLY	1		
	4	VKS3785-001MM	F. F/REW ARM	2		
	5	VKW5284-002	SWING SPRING	2		
	6	VKS2278-001	TRIGGER ARM	2		
	7	VKW5301-001	SPRING	2		
	8	VKW5266-001	ELEVATOR SPRING	2		
	9	WDL214025	WASHER	2		
	10	VKF3205-00B	FLY WHEEL	2		
	11	WDL183425	WASHER	2		
	12	VKF3207-00B	FLY WHEEL	2		
	13	WDL173525-6	WASHER	2		
	14	VGP2401-00A	SOLENOID	2		
	15	VKB3000-182	CAPSTAN BELT	2		
	16	MSI-5U2LWA	DC MOTOR	1		
	17	VKR4761-001	MOTOR PULLY	1		
	18	QYSPSP2604Z	SCREW	2		
	19	VKM3907-001	JOINT BRACKET	1		
	20	QYSBSF2608Z	TAPPING SCREW	6		
	21	VGH0424-037	ERASE HEAD	1		
	22	VGH0425-544	R/P HEAD	1		
	23	VKW5302-001	HEAD SPRING	2		
	24	VKZ4730-001	SPECIAL SCREW	4		
	25	VKS2279-00C	HEAD MOUNT ASS'Y	1		
	26	VKW5299-001	P. ROLLER SPRING	2		
	27	VKS2277-005	DIRECTION LEVER	2		
	28	VKP4233-00A	PINCH ROLLER	4		
	29	VKW5285-001	RETURN SPRING	2		
	30	VKS3786-00E	CLUTCH ASS'Y	2		
	31	VKS2275-00C	HEAD MOUNT ASS'Y	1		
	32	VKW5300-001	P. ROLLER SPRING	2		
	33	VKS1167-001	HEAD MOUNT BASE	2		
	34	VKS2274-002	REEL GEAR	4		
	35	VKM3906-002	PLAY LEVER	2		
	36	VKW5286-002	BASE SPRING	4		
	37	VKS5559-001	IDLER GEAR	2		
	38	VKY3149-001	CASSETTE SPRING	2		
	39	VKW5279-001	HEAD SPRING	2		
	40	VKW5280-001	HEAD SPRING	2		
	41	VKW5296-001	SPRING	2		
	42	VKS5560-001	IDLER GEAR	2		
	43	VKS1166-003	CONTROL CAM	2		
	44	VKS5577-001	TAPE HOLDER	2		
	45	QYSBSF2608Z	TAPPING SCREW	5	P. C. B.	
	46	VKR4749-001KP	IDLE PULLY	2		
	47	QYSBSF2006Z	SPRING	2		
	48	LV40450-001A	SPRING	2		
	50	VKS5603-00C	MAIN PULLY	1		
		VKS5603-00D	MAIN PULLY	1	#74501~	

■ Electric Parts List (Power Supply & Amplifier P.C.B.)

BLOCK NO. 01111111

A REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX	BLOCK NO. 01111111	BLOCK NO. 01111111
C001	QFV82AJ-104	M.CAPA. I.M	.10MF 5% 100V		C722 QTE1V06-106Z	E CAPACITOR
C002	QFV82AJ-104	M.CAPA. I.M	.10MF 5% 100V		C726 QET41EM-106	E CAPACITOR
C003	QFV82AJ-104	M.CAPA. I.M	.10MF 5% 100V		C729 QET41CM-476	4.7MF 20% 16V
C004	QE20360-56B	E.CAPA.	.5600MF		C730 QFLC1HJ-1032M	M CAPACITOR
C005	QE20360-56B	E.CAPA.	.5600MF		C739 QFLC1HJ-1032M	.010MF 5% 50V
C011	QFV41HJ-1042M	TF CAPACITOR	.10MF 5% 50V		C751 QCY31HK-2722	C.CAPA. I.M
C012	QFV41HJ-1042M	TF CAPACITOR	.10MF 5% 50V		C752 QCY31HK-2722	C.CAPA. I.M
C013	QFV41HJ-1042M	TF CAPACITOR	.10MF 5% 50V		C753 QCY31HK-4722	C.CAPA. I.M
C014	QETM1VM-338	E CAPACITOR	.3300MF 20% 35V		C754 QFV41HJ-105	4.700PF 10% 50V
C015	QETM1VM-338	E CAPACITOR	.3300MF 20% 35V		C755 QFV41HJ-105	4.700PF 10% 50V
C016	QET41VM-107	E CAPACITOR	.100MF 20% 35V		C756 QFV41HJ-105	4.700PF 10% 50V
C017	QETN1JM-4762	E CAPACITOR	.47MF 20% 63V		C757 QCXB1CM-152Y	C CAPACITOR
C018	QET41HM-226	E CAPACITOR	.22MF 20% 50V		C758 QCXB1CM-152Y	C CAPACITOR
C020	QET41HM-103Y	E CAPACITOR	.010MF 30% 16V		C781 QETN1HM-225Z	E CAPACITOR
C021	QET41HM-475	E CAPACITOR	.47MF 20% 50V		C782 QCBB1HK-101Y	2.2MF 20% 50V
C022	QET41HM-475	E CAPACITOR	.47MF 20% 50V		C783 QCBB1HK-101Y	2.2MF 20% 50V
C023	QET41HM-225	E CAPACITOR	.47MF 20% 50V		C784 QCBB1HK-101Y	100PF 10% 50V
C024	QET41HM-105	E CAPACITOR	.10MF 20% 50V		C785 QCBB1HK-181Y	C CAPACITOR
C025	QET41HM-105	E CAPACITOR	.10MF 20% 50V		C786 QCBB1HK-181Y	C CAPACITOR
C031	QCVB1CN-103Y	C CAPACITOR	.010MF 30% 16V		C787 QET41EM-476	E CAPACITOR
C032	QETN1EM-2262	E CAPACITOR	.22MF 20% 25V		C788 QET41EM-476	E CAPACITOR
C033	QFV41HJ-224	E CAPACITOR	.010MF 20% 50V		C789 QCS11HJ-100	C CAPACITOR
C034	QFLC1HJ-1032M	M CAPACITOR	.22MF 20% 25V		C790 QCS11HJ-100	C CAPACITOR
C038	QFLC1HJ-2232M	M CAPACITOR	.010MF 30% 16V		C791 QET41HM-226	E CAPACITOR
C039	QFLC1HJ-2232M	M CAPACITOR	.22MF 20% 25V		C792 QET41HM-226	E CAPACITOR
C045	QET41EM-476	E CAPACITOR	.47MF 20% 25V		C793 QFV41HJ-1042M	E CAPACITOR
C050	QETN1EM-2262	E CAPACITOR	.22MF 20% 25V		C794 QFV41HJ-1042M	E CAPACITOR
C061	QCF11HP-103	C CAPACITOR	.010MF +80% -20%		C795 QFV41HJ-1042M	E CAPACITOR
C062	QETN1EM-2262	E CAPACITOR	.22MF 20% 25V		C796 QFV41HJ-1042M	E CAPACITOR
C066	QETN1EM-2262	E CAPACITOR	.010MF 20% 25V		A D001 1N5402M-20	D10DE
C067	QCF11HP-103	C CAPACITOR	.010MF +80% -20%		A D002 1N5402M-20	D10DE
C068	QETN1EM-2262	E CAPACITOR	.22MF 20% 25V		A D003 1N5402M-20	D10DE
C069	QETN1EM-2262	E CAPACITOR	.22MF 20% 25V		A D004 1N5402M-20	D10DE
C070	QCF11HP-103	C CAPACITOR	.010MF +80% -20%		A D015 30DF2FC	D10DE
C071	QETN1EM-2262	E CAPACITOR	.22MF 20% 25V		A D016 30DF2FC	D10DE
C072	QETN1EM-2262	E CAPACITOR	.22MF 20% 25V		A D017 1SR35-100	SI DIODE
C073	QCF11HP-103	C CAPACITOR	.010MF +80% -20%		A D018 1SR35-100	SI DIODE
C074	QETN1EM-2262	E CAPACITOR	.22MF 20% 25V		A D019 MT230JC	ZENER DIODE
C703	QCBB1HK-101Y	C CAPACITOR	.100PF 10% 50V		D020 UZ6-2BSA	Z-DIODE 10M
C704	QCBB1HK-101Y	C CAPACITOR	.100PF 10% 50V		D021 MT25-1B	ZENER DIODE
C705	QCBB1HK-181Y	C CAPACITOR	.180PF 10% 50V		D022 ISS133-T2	D10DE
C706	QCBB1HK-181Y	C CAPACITOR	.180PF 10% 50V		D023 ISS133-T2	Z-DIODE 1-M
C707	QET41EM-476	E CAPACITOR	.47MF 20% 25V		D024 ISS133-T2	ZENER DIODE
C708	QET41EM-476	E CAPACITOR	.47MF 20% 25V		D025 ISS133-T2	D10DE
C709	QCS11HJ-101Y	C CAPACITOR	.10PF 5% 50V		A D027 1SR35-100	SI DIODE
C710	QCS11HJ-100	C CAPACITOR	.10PF 5% 50V		A D030 MT211JA	Z-DIODE 1-M
C711	QET41HM-226	E CAPACITOR	.22MF 20% 50V		D060 MT25-1B	ZENER DIODE
C712	QET41HM-226	E CAPACITOR	.22MF 20% 50V		D061 MT211JC	ZENER DIODE
C713	QFV41HJ-1042M	TF CAPACITOR	.10MF 5% 50V		D062 MT26-8JC	ZENER DIODE
C714	QFV41HJ-1042M	TF CAPACITOR	.10MF 5% 50V		D065 MT28-2JC	ZENER DIODE
C715	QFV41HJ-1042M	TF CAPACITOR	.10MF 5% 50V		D066 MT213JC	ZENER DIODE
C721	QTE1V06-106Z	E.CAPA. I.M			D067 MT213JC	ZENER DIODE

BLOCK NO. 011111				BLOCK NO. 011111				
REF.	PARTS NO.	PARTS NAME	REMARKS	REF.	PARTS NO.	PARTS NAME	REMARKS	
			SUFFIX				SUFFIX	
D068	MT213JC	ZENER DIODE		Q736	2SD2144S(CW)	TRANSISTOR		
D069	MT213JC	ZENER DIODE		Q737	KRA111M-T	D.T.R.I.M		
D070	MT213JC	ZENER DIODE		Q751	2SC1685	TR.I.M		
D703	1SS133-T2	DIODE		Q752	2SA935(RS)	TR.I.M		
D704	1SS133-T2	DIODE		Q753	2SC1685	TR.I.M		
D719	1SS133-T2	DIODE	SHORT TEST	Q754	2SA935(RS)	TR.I.M		
D720	1SS133-T2	DIODE		Q755	2SA935(Y)	TR.I.M		
D728	1SS133-T2	DIODE		Q756	2SC225(Y)	TR.I.M		
D751	1SS133-T2	DIODE		Q781	2SA1038(R,S)	TR.I.M		
D752	1SS133-T2	DIODE		Q782	2SA1038(R,S)	TR.I.M		
D753	1SS133-T2	DIODE		R003	QRD161J-332	C RESISTOR	3.3K 5% 1/4W	
D754	1SS133-T2	DIODE		R004	QRD161J-223	C RESISTOR	22K 5% 1/4W	
D755	1SS133-T2	DIODE		R005	QRD161J-104	C RESISTOR	100K 5% 1/4W	
D756	1SS133-T2	DIODE		A	R006	QR20077-4R7X	C RESISTOR	4.7 1/0W
D757	MT23.9JB	Z DIODE		R007	QR20077-4R7X	F RESISTOR	4.7 1/0W	
D758	MT23.9JB	Z DIODE		R008	QRD161J-103	C RESISTOR	10K 5% 1/4W	
D759	1SS133-T2	DIODE		R009	QRD161J-103	C RESISTOR	10K 5% 1/4W	
D760	1SS133-T2	DIODE		R010	QRD161J-772	C RESISTOR	4.7K 5% 1/4W	
D789	1SS133-T2	DIODE		R011	QRD161J-472	C RESISTOR	4.7K 5% 1/4W	
D790	1SS133-T2	DIODE		R012	QRD161J-683	C RESISTOR	100K 5% 1/4W	
L001	VQ200-8-009	INDUCTOR		R013	QRD161J-103	C RESISTOR	10K 5% 1/4W	
L701	EQL0011-R45J1	INDUCTOR		A	R030	QRD144CJ-4R7SX	C RESISTOR	4.7 5% 1/4W
L702	EQL0011-R45J1	INDUCTOR		R031	QRD161J-681	C RESISTOR	680 5% 1/4W	
L781	EQL0011-R45J1	INDUCTOR		R038	QRD144CJ-4R7SX	C RESISTOR	CA-D752TR	
L782	EQL0011-R45J1	INDUCTOR		R039	QRD144CJ-4R7SX	C RESISTOR	CA-D752TR	
Q001	2SB1187(F,G)	TRANSISTOR	X*	R040	QRK126J-271X	C RESISTOR	CA-D02T	
Q003	DTC114YSA-T	TRANSISTOR	D.T.R.I.M	R041	QRD12CJ-331SX	C RESISTOR	CA-D752TR	
Q004	DTC114YSA-T	TRANSISTOR	D.T.R.I.M	R042	QRD12CJ-331SX	C RESISTOR	330 5% 1/2W	
Q005	DTC114YS	TRANSISTOR	TR.I.M	R043	QRD12CJ-331SX	C RESISTOR	2.2K 5% 1/4W	
Q030	2SD2061/EF/	TRANSISTOR	TR.*	R044	QRD12CJ-331SX	C RESISTOR	CA-D02T	
Q040	2SC945A	TRANSISTOR		R045	QRD12CJ-331SX	C RESISTOR	330 5% 1/2W	
Q041	2SC945A	TRANSISTOR		R046	QRD161J-222	C RESISTOR	2.2K 5% 1/4W	
Q049	2SD2061/EF/	TRANSISTOR		R047	QRD161J-222	C RESISTOR	2.2K 5% 1/4W	
Q061	2SC945A	TRANSISTOR		R062	QRD161J-331	C RESISTOR	CA-D52TR	
Q062	2SC945A	TRANSISTOR		R063	QRD161J-331	C RESISTOR	330 5% 1/2W	
Q065	2SD2061/EF/	TRANSISTOR	TR.I.M	R064	QRD161J-122	C RESISTOR	1.2K 5% 1/4W	
Q066	2SD2061/EF/	TRANSISTOR	TR.I.M	R065	QRD161J-561	C RESISTOR	560 5% 1/4W	
Q067	2SA935S(RS)	TRANSISTOR		R066	QRD161J-561	C RESISTOR	560 5% 1/4W	
Q068	2SC945A	TRANSISTOR		R067	QRD161J-122	C RESISTOR	1.2K 5% 1/4W	
Q069	2SD2061/EF/	TRANSISTOR		R068	QRD161J-331	C RESISTOR	330 5% 1/4W	
Q070	2SC945A	TRANSISTOR	X*	R071	QRD161J-122	C RESISTOR	4.7 5% 1/4W	
Q071	2SB1187(F,G)	TRANSISTOR	X*	R072	QRD167J-4R7	C RESISTOR	4.7 5% 1/4W	
Q072	2SA935S(RS)	TRANSISTOR	TR.I.M	R074	QRZ9021-220	FUSI.RESISTOR	22 1/0W	
Q073	KRA104M-T	TRANSISTOR	D.T.R.I.M	R075	QRZ9021-220	FUSI.RESISTOR	22 1/0W	
Q074	DTC144ESA-T	TRANSISTOR	D.T.R.I.M	R076	QRD161J-221	C RESISTOR	220 5% 1/4W	
Q075	KRC104M-T	TRANSISTOR	D.T.R.I.M	R077	QRD161J-681	C RESISTOR	680 5% 1/4W	
Q076	DTA144ES	TRANSISTOR	TR.I.M	R078	QRD161J-182	C RESISTOR	1.8K 5% 1/4W	
Q701	2SA1038(R,S)	TRANSISTOR	TR.I.M	R081	QRD161J-272	C RESISTOR	2.7K 5% 1/4W	
Q702	2SA1038(R,S)	TRANSISTOR	TR.I.M	R082	QRD167J-562	C RESISTOR	5.6K 5% 1/4W	
Q726	2SC2359S(SE/-T)	TRANSISTOR		R083	QRG010D-150X	OMF RESISTOR	15.5K 1/1W	
Q727	2SA1038(R,S)	TRANSISTOR	TR.I.M	R084	QRD161J-272	C RESISTOR	2.7K 5% 1/4W	
Q728	2SC1740S(RS/-T)	TRANSISTOR		R085	QRD167J-562	C RESISTOR	5.6K 5% 1/4W	
Q733	2SD2144S(CW)	TRANSISTOR		R086	QRD161J-103	C RESISTOR	10K 5% 1/4W	
Q734	2SD2144S(CW)	TRANSISTOR						
Q735	2SD2144S(CW)	TRANSISTOR						

BLOCK NO. ①1111111111

A	REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX	A	REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
R087	GRD161J-103	C RESISTOR	10K 5% 1/4W			R750	GRD161J-471	C RESISTOR	470 5% 1/4W		
R090	GRD161J-102	C RESISTOR	FMB REQUEST			R751	GRD161J-223	C RESISTOR	22K 5% 1/4W		
R091	GRD161J-102	C RESISTOR	FMB REQUEST			R752	GRD161J-223	C RESISTOR	22K 5% 1/4W		
R092	GRD161J-102	C RESISTOR	FMB REQUEST			R753	GRD161J-222	C RESISTOR	2.2K 5% 1/4W		
R093	GRD161J-102	C RESISTOR	FMB REQUEST			R754	GRD161J-222	C RESISTOR	2.2K 5% 1/4W		
R094	GRD161J-103	C RESISTOR	10K 5% 1/4W			R755	GRD161J-221	C RESISTOR	220 5% 1/4W		
R100	GRD161J-104	C RESISTOR	CA-D702T			R756	GRD161J-221	C RESISTOR	220 5% 1/4W		
R102	GRD161J-103	BUS WIRE 1/M	CA-D702T			R757	GRD161J-223	C RESISTOR	22K 5% 1/4W		
R701	GRD14CJ-100SX	UNF.C.RES. 1.M	10 5% 1/4W			R758	GRD161J-223	C RESISTOR	22K 5% 1/4W		
R702	GRD14CJ-100SX	UNF.C.RES. 1.M	10 5% 1/4W			R759	GRD167J-682	C RESISTOR	6.8K 5% 1/4W		
R703	GRD161J-563	C RESISTOR	56K 5% 1/4W			R760	GRD167J-682	C RESISTOR	6.8K 5% 1/4W		
R704	GRD161J-563	C RESISTOR	56K 5% 1/4W			R761	GRD161J-222	C RESISTOR	2.2K 5% 1/4W		
R705	GRD14CJ-182SX	UNF.C.RES. 1.M	1.8K 5% 1/4W			R762	GRD161J-222	C RESISTOR	2.2K 5% 1/4W		
R706	GRD14CJ-182SX	UNF.C.RES. 1.M	1.8K 5% 1/4W			R763	GRD161J-223	C RESISTOR	22K 5% 1/4W		
R707	GRD161J-563	C RESISTOR	56K 5% 1/4W			R764	GRD161J-223	C RESISTOR	22K 5% 1/4W		
R708	GRD161J-563	C RESISTOR	56K 5% 1/4W			R765	GRG010J-182X	OMF RESISTOR	1.8K 5% 1/1W		
R709	GRX014J-R22	UNF.MF.RES. 1.M	5% 1/1W			R766	GRG01DJ-182X	OMF RESISTOR	1.8K 5% 1/1W		
R710	GRY014J-R22	UNF.MF.RES. 1.M	5% 1/1W			R767	GRD14CJ-681SX	UNF.C.RES 1 M	680 5% 1/4W		
R711	GRX014J-R22	UNF.MF.RES. 1.M	5% 1/1W			R768	GRD14CJ-681SX	UNF.C.RES 1 M	680 5% 1/4W		
R712	GRX014J-R22	UNF.MF.RES. 1.M	5% 1/1W			R769	GRD14CJ-821SX	C RESISTOR	820 5% 1/4W		
R713	GRD14CJ-100SX	UNF.C.RES. 1.M	10 5% 1/4W			R770	GRD14CJ-821SX	C RESISTOR	820 5% 1/4W		
R714	GRD14CJ-100SX	UNF.C.RES. 1.M	10 5% 1/4W			R771	GRD161J-821	C RESISTOR	820 5% 1/4W		
R715	GRD14CJ-100SX	UNF.C.RES. 1.M	10 5% 1/4W			R772	GRD161J-821	C RESISTOR	820 5% 1/4W		
R716	GRD14CJ-100SX	UNF.C.RES. 1.M	10 5% 1/4W			R773	GRD14CJ-101SX	UF RESISTOR	100 5% 1/4W		
R717	GRD161J-122	C RESISTOR	1.2K 5% 1/4W			R774	GRD14CJ-101SX	UF RESISTOR	100 5% 1/4W		
R718	GRD161J-122	C RESISTOR	1.2K 5% 1/4W			R775	GRD161J-471	C RESISTOR	470 5% 1/4W		
R719	GRD161J-223	C RESISTOR	22K 5% 1/4W			R776	GRD161J-471	C RESISTOR	470 5% 1/4W		
R720	GRD161J-223	C RESISTOR	22K 5% 1/4W			R777	GRD14CJ-4R7SX	C RESISTOR	4.7 5% 1/4W		
R721	GRD161J-103	C RESISTOR	10K 5% 1/4W			R778	GRD14CJ-4R7SX	C RESISTOR	4.7 5% 1/4W		
R722	GRD161J-103	C RESISTOR	10K 5% 1/4W			R779	GRD161J-222	C RESISTOR	2.2K 5% 1/4W		
R723	GRD161J-473	C RESISTOR	47K 5% 1/4W			R780	GRD161J-222	C RESISTOR	2.2K 5% 1/4W		
R724	GRD161J-473	C RESISTOR	47K 5% 1/4W			R781	GRD14CJ-100SX	UNF.C.RES. 1 M	10 5% 1/4W		
R725	GRD161J-823	C RESISTOR	82K 5% 1/4W			R782	GRD14CJ-100SX	UNF.C.RES. 1 M	10 5% 1/4W		
R726	GRD161J-104	C RESISTOR	100K 5% 1/4W			R783	GRD161J-563	C RESISTOR	56K 5% 1/4W		
R727	GRD161J-104	C RESISTOR	100K 5% 1/4W			R784	GRD161J-563	C RESISTOR	56K 5% 1/4W		
R728	GRD161J-103	C RESISTOR	10K 5% 1/4W			R785	GRD14CJ-100SX	UNF.C.RES. 1 M	10 5% 1/4W		
R729	GRD161J-104	C RESISTOR	10K 5% 1/4W			R786	GRD14CJ-182SX	UNF.C.RES. 1 M	1.8K 5% 1/4W		
R730	GRD161J-103	C RESISTOR	10K 5% 1/4W			R787	GRD161J-563	C RESISTOR	56K 5% 1/4W		
R731	GR141J-183Y	C RESISTOR	18K 5% 1/4W			R788	GRD161J-563	C RESISTOR	56K 5% 1/4W		
R732	GR141J-183Y	CARBON RESISTOR	18K 5% 1/4W			R789	GRX014J-R22	UNF.MF.RES. 1 M	5% 1/1W		
R733	GRD161J-472	C RESISTOR	4.7K 5% 1/4W			R790	GRX014J-R22	UNF.MF.RES. 1 M	5% 1/1W		
R734	GRD161J-472	C RESISTOR	4.7K 5% 1/4W			R791	GRX014J-R22	UNF.MF.RES. 1 M	5% 1/1W		
R735	GRD161J-472	C RESISTOR	4.7K 5% 1/4W			R792	GRX014J-R22	UNF.MF.RES. 1 M	5% 1/1W		
R736	GRD161J-472	C RESISTOR	4.7K 5% 1/4W			R793	GRD14CJ-100SX	UNF.C.RES. 1 M	10 5% 1/4W		
R739	GRG01DJ-821X	OMF RESISTOR	820 5% 1/1W			R794	GRD14CJ-100SX	UNF.C.RES. 1 M	10 5% 1/4W		
R740	GRG01DJ-821X	OMF RESISTOR	820 5% 1/1W			R795	GRD14CJ-100SX	UNF.C.RES. 1 M	10 5% 1/4W		
R741	GRD161J-473	C RESISTOR	4.7K 5% 1/4W			R796	GRD14CJ-100SX	UNF.C.RES. 1 M	10 5% 1/4W		
R742	GRD161J-473	C RESISTOR	4.7K 5% 1/4W			R797	GRD161J-122	C RESISTOR	1.2K 5% 1/4W		
R743	GRD161J-223	C RESISTOR	22K 5% 1/4W			R798	GRD161J-122	C RESISTOR	1.2K 5% 1/4W		
R744	GRD161J-223	C RESISTOR	22K 5% 1/4W			S001	QSW0524-001	VOLTAGE SW	CA-D02T		
R745	GRD161J-103	C RESISTOR	10K 5% 1/4W			CN002	EMV163-011	CONNECTOR	TO FMH-014-3 RE		
R746	GRD161J-103	C RESISTOR	10K 5% 1/4W			CN003	EMV163-011	CONNECTOR	TO FMH-014-4 FR		
R747	GRD161J-823	C RESISTOR	PROTECT			CN004	EMV7163-005	CONNECTOR	TO FMH-014-5 R /		
R748	GRD161J-104	C RESISTOR	PROTECT			CN005	EMV7163-011	CONNECTOR	TO SPK BOARD		
R749	GRD161J-471	C RESISTOR	4.7 5% 1/4W			CN006	EMV5163-010R	CONNECTOR	TO FMC (MAIN)		

■ Electric Parts List (Pre Amplifier & Tuner P.C. B.)

BLOCK NO. 01111111

A	REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX	REF.	PARTS NO.	PARTS NAME	REMARKS	BLOCK NO. 02111111
CN007	QGF1201C3-12	VMCO32-012	TO FMB (MICOM)			C 1	QCC11EM-223V	C CAPACITOR	.022MF 20% 25V	
CN009	EMV5138-005	CONNECTOR	TO TRANS			C 3	QCC11EM-473V	C CAPACITOR	.04MF 20% 25V	
CN012	EMV5163-011R	CONNECTOR	TO FMH-014-2			C 4	QCVB1CN-103Y	C CAPACITOR	.01MF 30% 16V	
CN013	EMV5163-011R	CONNECTOR	TO FMH-014-2			C 5	GETN1CM-4762	E CAPACITOR	CA-D702T	
CN014	EMV5163-005R	CONNECTOR	SKT WIRE			C 5	GETN1AM-1072	AL E. CAPACITOR	CA-D752TR	
CN019	FWS285-202V	SOCRET I.M	TO TRANS			C 8	QCS11HJ-150	C CAPACITOR	CA-D52T	
CN111	EMV7145-004Z	CONNECTOR	TO CONN. BOARD			C 12	QCSB1H-150Y	C CAPACITOR	CA-D52TR	
CN703	EMV5163-007R	CONNECTOR	TO CONN. BOARD			C 12	QCSB1H-100Y	CER. CAPACITOR-S	CA-D702T	
CN915	EMV5163-006R	CONNECTOR	TO H/PHONE FW			C 13	QCVB1CN-103Y	C CAPACITOR	EXCECTCA-752 EE	
EP001	EM24001-0022	IM EARTH PLATE	TO GND CHASSIS			C 16	QFV41HJ-1042M	C CAPACITOR	CA-D52TR	
FT011	EMG7331-0032	FUSE CLIP	F001 LIVE FUSE			C 18	QCBB1HK-471Y	C CAPACITOR	EE	
FT012	EMG7331-0032	FUSE CLIP	F001 LIVE FUSE			C 19	QCBB1HK-471Y	C CAPACITOR	EE	
FT031	EMG7331-0032	FUSE CLIP	CA-D702T			C 21	QCC11EM-473V	C CAPACITOR	470PF 10% 50V	
FT032	EMG7331-0032	FUSE CLIP	CA-D702T			C 30	QEK61CM-476	C CAPACITOR	470PF 20% 25V	
FT511	EMG7331-0032	FUSE CLIP	F101 SEC FUSE			C 31	QCS31HJ-3902	C CAPACITOR	47MF 20% 16V	
FT512	EMG7331-0032	FUSE CLIP	F101 SEC FUSE			C 31	QCSB1HJ-330Y	CER. CAPACITOR	CA-D52TR	
FT521	EMG7331-0032	FUSE CLIP	F102 SEC FUSE			C 32	QGCB1HK-102	C CAPACITOR	B,E,EN	
FT522	EMG7331-0032	FUSE CLIP	F102 SEC FUSE			C 33	QCK61AM-1072M	C CAPACITOR	470PF 10% 50V	
FW101	EWR34D-14LSV	EF WIRE				C 34	QCS11HJ-150	C CAPACITOR	100MF 20% 10V	
IC701	ICD7294	I.C.				C 35	QCVB1CN-103Y	C CAPACITOR	15PF 5% 50V	
IC702	ICD7294	I.C.				C 36	QEK41CH-106	E CAPACITOR	100MF 30% 16V	
IC781	ICD7295	IC				C 37	QCVB1CN-103Y	C CAPACITOR	100MF 30% 16V	
IC782	ICD7295	IC				C 38	QCC11EM-473V	C CAPACITOR	47MF 20% 25V	
R 098	GRD161J-104	C RESISTOR	CA-D702T			C 39	QCC11EM-473V	C CAPACITOR	47MF 20% 25V	
R 099	GRD161J-104	C RESISTOR	CA-D702T			C 40	QCVB1CN-103Y	C CAPACITOR	47MF 30% 16V	
TB001	EM24001-0022	TAB I.M				C 41	QEK41HM-104	E CAPACITOR	10MF 20% 50V	
TB002	EM24001-0022	TAB I.M				C 42	QEK41HM-474	E CAPACITOR	47MF 20% 50V	
▲ TH002	QAD0095-4R7Z	POSTSOR 1.M				C 43	QEK61HM-3352N	E CAPACITOR	CA-D52TR	
W 003	QWE884-18R	WIRE	CA-D702T			C 44	QCSB1HJ-680Y	AL E. CAPACITOR	B,E,EN	
W 004	QWE883-18R	WIRE	CA-D702T			C 44	QCBB1HK-221Y	C CAPACITOR	CA-D52TR	
W 005	QWE881-14R	WIRE	CA-D702T			C 45	QEK61EM-1062N	E CAPACITOR	CA-D72TR	
W 008	QWE886-18R	WIRE	CA-D702T			C 45	QEK61HM-3352N	E CAPACITOR	CA-D702T	
W 009	QWE888-18R	S.WIRE	CA-D702T			C 46	QCC11EM-223V	C CAPACITOR	0.22MF 20% 25V	
W 059	QWE880-07RR	WIRE	CA-D702T	UP		C 47	QCVB1CN-103Y	C CAPACITOR	0.10MF 30% 16V	
						C 49	QFLC1HJ-3932M	M CAPACITOR	CA-D702T	
						C 50	QFLC1HJ-3932M	M CAPACITOR	CA-D702T	
						C 51	QEK41HM-2232M	M CAPACITOR	CA-D702T	
						C 52	QEK41HM-105	E CAPACITOR	1.0MF 20% 50V	
						C 53	QCGB1HK-102	C CAPACITOR	CA-D52TR	
						C 54	QEK61HM-3352N	E CAPACITOR	1.0MF 20% 50V	
						C 55	QCS11HJ-120	C CAPACITOR	CA-D52TR	
						C 56	QCS11HJ-120	C CAPACITOR	100MF 20% 10V	
						C 60	QEK61AM-1072M	E CAPACITOR	100MF 20% 10V	
						C 61	QCS11HJ-120	C CAPACITOR	12PF 5% 50V	
						C 62	QCS11HJ-120	C CAPACITOR	12PF 5% 50V	
						C 63	QCC11EM-473V	C CAPACITOR	100MF 10% 50V	
						C 65	QCGB1HK-102	C CAPACITOR	150PF 10% 50V	
						C 66	QCBB1HK-151Y	C CAPACITOR	150PF 10% 50V	
						C 67	QCBB1HK-151Y	C CAPACITOR	150PF 10% 50V	
						C 68	QCBB1HK-101Y	C CAPACITOR	EXCEPICA-0722EE	
						C 69	QFV41HJ-105	T.F. CAPA. 1.M	1.0MF 5% 50V	
						C 70	QCXB1CM-392Y	C CAPACITOR	3900PF 20% 16V	
						C 71	QET41CM-476	E CAPACITOR	47MF 20% 16V	
						C 72	QCGB1HK-102	C CAPACITOR	1000PF 10% 50V	

BLOCK NO. 02					
REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX	
C427	QFLC1HJ-2232M	M CAPACITOR	.022MF 5% 50V		
C428	QFLC1HJ-2232M	M CAPACITOR	.022MF 5% 50V		
C429	QFLM1HJ-5622	M CAPACITOR	.022MF 5% 50V		
C430	QFLM1HJ-5622	M CAPACITOR	.022MF 5% 50V		
C431	QETCLHM-2252M	E.CAPA. I.M	.560PF 5% 50V		
C432	QETCLHM-2252M	E.CAPA. I.M	.560PF 5% 50V		
C433	EETB1HM-105E	E.CAPA. I.M	2.2MF 20% 50V		
C434	EETB1HM-105E	E.CAPA. I.M	2.2MF 20% 50V		
C435	EETB1EM-106E	E.CAPA. I.M			
C436	EETB1EM-106E	E.CAPA. I.M			
C439	QETCLHM-2247	E.CAPA. I.M	CA-D702T		
C440	EETB1EM-106E	E.CAPA. I.M	CA-D702T		
C441	EETB1EM-106E	E.CAPA. I.M			
C442	EETB1EM-106E	E.CAPA. I.M			
C445	QCBB1HK-101Y	C CAPACITOR	100PF 10% 50V		
C446	QCBB1HK-101Y	C CAPACITOR	100PF 10% 50V		
C447	EETB1EM-106E	E.CAPA. I.M			
C448	EETB1EM-106E	E.CAPA. I.M			
C454	QCBB1HK-101Y	C CAPACITOR	100PF 10% 50V		
C457	EETB1EM-106E	E.CAPA. I.M			
C458	EETB1EM-106E	E.CAPA. I.M			
C459	QFLM1HJ-3532Z	M CAPACITOR	.033MF 5% 50V		
C460	EETB1HM-755E	E.CAPA. I.M			
C461	QETB1HM-474N	E.CAPA. I.M	.47MF 20% 50V		
C462	QFLC1HJ-3932M	M CAPACITOR	.039MF 5% 50V		
C463	QETB1HM-474N	E.CAPA. I.M	.47MF 20% 50V		
C465	QFLC1HJ-3932M	M CAPACITOR	.039MF 5% 50V		
C466	QFLC1HJ-4732M	M CAPACITOR	.047MF 5% 50V		
C467	EETB1HM-105E	E.CAPA. I.M			
C468	QETCLHM-4762M	E.CAPA. I.M	.47MF 20% 25V		
C469	QCBB1HK-101Y	C CAPACITOR	EXCEPT CA-D752EE		
C470	QCBB1HK-101Y	C CAPACITOR	EXCEPT CA-D752EE		
C471	QCBB1HK-101Y	C CAPACITOR	100PF 10% 50V		
C472	QCBB1HK-101Y	C CAPACITOR	100PF 10% 50V		
C473	QETCLHM-4762M	E.CAPA. I.M	.47MF 20% 25V		
C474	QETCLHM-4762M	E.CAPA. I.M	.47MF 20% 25V		
C475	QTE1V06-106Z	E.CAPA. I.M			
C476	QTE1V06-106Z	E.CAPA. I.M			
C477	EETB1HM-4735E	E.CAPA. I.M			
C484	QCBB1HK-101Y	C CAPACITOR	100PF 10% 50V		
C489	QET4ICM-476	E CAPACITOR	4.7MF 20% 16V		
C490	QET4ICM-476	E CAPACITOR	4.7MF 20% 16V		
C493	QFV41HJ-1042M	TF CAPACITOR	.10MF 5% 50V		
C494	QFV41HJ-1042M	TF CAPACITOR	.10MF 5% 50V		
C495	QFV41HJ-1042M	TF CAPACITOR	.10MF 5% 50V		
C496	QFV41HJ-1042M	TF CAPACITOR	.10MF 5% 50V		
C501	EETB1EM-106E	E.CAPA. I.M			
C502	EETB1EM-106E	E.CAPA. I.M			
C503	QFLC1HJ-2232M	M CAPACITOR	.022MF 5% 50V		
C504	QFLC1HJ-4732M	M CAPACITOR	.047MF 5% 50V		
C505	QET4AM-227	E CAPACITOR	220MF 20% 10V		
C506	EETB1EM-106E	E.CAPA. I.M			
C507	EETB1EM-106E	E.CAPA. I.M			
C508	EETB1EM-106E	E.CAPA. I.M			
C509	EETB1EM-106E	E.CAPA. I.M			

A	REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
C 80	QCCBEBHK-820Y	C CAPACITOR	CA-D752TR		
C 81	QCCS11HJ-470	C CAPACITOR	CA-D752TR		
C 82	EETC1CM-1027JC	E CAPACITOR	CA-D752TR		
C 83	QCC11EM-473V	C CAPACITOR	CA-D752TR		
C 84	QETC1HM-2252M	E CAPA. I.M	CA-D752TR		
C 85	QCBB1HK-331Y	C CAPACITOR	CA-D752TR		
C 86	QCBB1HK-561Y	C CAPACITOR	CA-D752TR		
C 87	QCGB1HK-102	C CAPACITOR	CA-D752TR		
C 88	QCGB1CN-103Y	C CAPACITOR	CA-D752TR		
C 90	QCS11HJ-100	C CAPACITOR	CA-D752TR		
C 98	QCS11HJ-103Y	C CAPACITOR	CA-D752TR	B,E,EN	
CF 1	VCF213B-108Z	C FILTER	CA-D702T		
CF 1	VCFM3B-106	C FILTER	CA-D752TR		
CF 2	VCF213B-108Z	C FILTER	CA-D702T		
CF 2	QAXD403-001	C FILTER	CA-D752TR		
C360	QFV41HJ-1042M	TF CAPACITOR	.10MF 5% 50V		
C361	QFV41HJ-1042M	TF CAPACITOR	.10MF 5% 50V		
C365	QET14CM-227	E CAPACITOR	.220MF 20% 16V		
C366	QET14AM-108	E CAPACITOR	.1000MF 20% 10V		
C372	ETB1AH-475E	E.CAPA. I.M			
C373	QCVB1CN-103Y	C CAPACITOR	.010MF 30% 16V		
C380	QFV41HJ-1042M	TF CAPACITOR	.10MF 5% 50V		
C381	QFV41HJ-1042M	TF CAPACITOR	.10MF 5% 50V		
C382	QFV41HJ-1042M	TF CAPACITOR	.10MF 5% 50V		
C383	QFV41HJ-1042M	TF CAPACITOR	.10MF 5% 50V		
C383	QETC1FM-4762M	E CAPACITOR	.4MF 20% 25V		
C385	ETB1HM-103E	E.CAPA. I.M			
C386	QCBB1HK-681Y	C CAPACITOR	680PF 10% 50V		
C387	QLFC1HJ-1532M	M CAPACITOR	.015MF 5% 50V		
C388	QCXB1CM-182Y	C CAPACITOR	1800PF 20% 16V		
C389	QCS11HJ-330	C CAPACITOR	33PF 5% 50V		
C390	QFV41HJ-1042M	TF CAPACITOR	.10MF 5% 50V		
C398	QFV71HJ-103	TF CAPACITOR	CA-D702T		
C399	QFV71HJ-103	TF CAPACITOR	CA-D702T		
C401	QFLM1HJ-2222	M CAPACITOR	2200PF 5% 50V		
C402	QFLMHJ-2222	M CAPACITOR	2200PF 5% 50V		
C403	QFLMHJ-1022	M CAPACITOR	1000PF 5% 50V		
C404	QFLMHJ-1022	M CAPACITOR	1000PF 5% 50V		
C407	QTE1106-1062	E.CAPA. I.M			
C408	QTE1106-1062	E.CAPA. I.M			
C411	EETB1EM-106E	E.CAPA. I.M			
C412	EETB1EM-106E	E.CAPA. I.M			
C413	QCBB1HK-471Y	C CAPACITOR	470F 10% 50V		
C414	QCBB1HK-471Y	C CAPACITOR	470F 10% 50V		
C415	EETB1EM-106E	E.CAPA. I.M			
C416	EETB1EM-106E	E.CAPA. I.M			
C417	EETB1EM-106E	E.CAPA. I.M			
C418	QETC1HM-2252M	E.CAPA. I.M	2.2MF 20% 50V		
C419	EETB1EM-106E	E.CAPA. I.M			
C420	QET41AM-227	E CAPACITOR	220MF 20% 10V		
C421	QFV41HJ-1042M	TF CAPACITOR	.10MF 5% 50V		
C422	QFV41HJ-1042M	TF CAPACITOR	.10MF 5% 50V		
C423	QFV41HJ-1042M	TF CAPACITOR	.10MF 5% 50V		
C424	QFV41HJ-1042M	TF CAPACITOR	.10MF 5% 50V		
C425	QFCH1J-1832M	M CAPACITOR	.018MF 5% 50V		
C426	QFCH1J-1832M	M CAPACITOR	.018MF 5% 50V		

BLOCK N.O. 02111111

A	REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX	BLOCK N.O. 02111111
C510	QET41AM-227	E CAPACITOR	220MF 20% 10V			
C511	QFV41HJ-1042M	TF CAPACITOR	.10MF 5% 50V		D 1 ISS133-T2	DIODE
C512	QFV41HJ-1042M	TF CAPACITOR	.10MF 5% 50V		D 2 ISS133-T2	DIODE
C513	QFV41HJ-1042M	TF CAPACITOR	.10MF 5% 50V		D 3 ISS133-T2	DIODE
C514	QFV41HJ-1042M	TF CAPACITOR	.10MF 5% 50V		D 4 ISS133-T2	DIODE
C515	QETB1HM-474N	E CAPACITOR	.10MF 5% 50V		D301 ISR35-100	SI DIODE
C516	QETB1HM-474N	E.CAPA. I.M	.47MF 20% 50V		D302 MT23 9JB	Z DIODE
C517	QETB1HM-475E	E.CAPA. I.M	.47MF 20% 50V		D303 ISS133-T2	DIODE
C518	QETB1HM-475E	E.CAPA. I.M	.47MF 20% 50V		D304 ISR35-100	SI DIODE
C519	QETB1HM-474N	E.CAPA. I.M	.47MF 20% 50V		D305 ISS133-T2	DIODE
C520	QETB1HM-474N	E.CAPA. I.M	.47MF 20% 50V		D306 ISS133-T2	DIODE
C521	QETB1HM-475E	E.CAPA. I.M	.47MF 20% 50V		D307 ISS133-T2	DIODE
C522	QETB1HM-475E	E.CAPA. I.M	.47MF 20% 50V		D401 MT25 .1B	ZENER DIODE
C523	QFV81HJ-154	TF CAPACITOR	.15MF 5% 50V		D402 MT25 .1B	ZENER DIODE
C524	QFV81HJ-154	TF CAPACITOR	.15MF 5% 50V		D403 ISR35-100	SI DIODE
C525	QETN1HM-3355Z	E CAPACITOR	3.3MF 20% 50V		D481 ISS133-T2	DIODE
C526	QETN1HM-3355Z	E CAPACITOR	3.3MF 20% 50V		J 1 EMB41YY-302K	ANT TERMINAL
C527	QFV81HJ-154	TF CAPACITOR	.15MF 5% 50V		J 1 FMMB10YY-401K	ANT TERMINAL
C528	QFV81HJ-154	TF CAPACITOR	.15MF 5% 50V		J401 EMN00TV-222AJ2	PIN JACK
C529	QFV41HJ-474	CAPACITOR	.47MF 5% 50V		L QGR0884-001	COIL BLOCK
C530	QETC1EM-4762M	E.CAPA. I.M	.47MF 20% 50V		L 1 VQZ0098-002	COIL BLOCK
C531	QET41CM-227	E CAPACITOR	220MF 20% 16V		L 4 VQP0018-221	INDUCTOR
C532	QCBB1HK-681Y	C CAPACITOR	680PF 10% 50V		L 5 EQL4007-101	INDUCTOR
C533	QCBB1HK-101Y	C CAPACITOR	100PF 10% 50V		L 10 VQZ0069-002S	TRAP COIL
C535	QCBB1HK-561Y	C CAPACITOR	560PF 10% 50V		L 11 VQP0018-R7	INDUCTOR
C541	QETC1HM-2252M	E.CAPA. I.M	2.2MF 20% 50V		L 12 VQP0018-330	INDUCTOR
C543	QF11HJ-473	C CAPACITOR	.047MF +80:-80%		L401 D1R1M-0002	INDUCTOR
C544	QETB1HM-474N	E.CAPA. I.M	.47MF 20% 50V		L402 VQZ0048-009	INDUCTOR
C545	QETB1HM-474N	E.CAPA. I.M	.47MF 20% 50V		L403 VQZ0048-009	INDUCTOR
C546	QFLM1HJ-8232	M CAPACITOR	.082MF 5% 50V		L405 VQZ0048-009	INDUCTOR
C547	QCY41HK-332	C CAPACITOR	3300PF 10% 50V		Q 1 2SC1923	TR TAPE
C548	QFLM1HJ-8232	M CAPACITOR	.08MF 5% 50V		Q 2 DIA114YS	D.T.R.I.M
C549	QET41AM-227	E CAPACITOR	220MF 20% 10V		Q 3 2SC2785	TRANSISTOR
C550	QCFF11HK-473	C CAPACITOR	.047MF +80:-20%		Q 4 2SC2785	TRANSISTOR
C551	QCS11HJ-300	C CAPACITOR	X.TAL		Q 6 DTA114YS	D.T.R.I.M
C552	QCS11HJ-300	C CAPACITOR	X.TAL		Q 14 2SA1175	TRANSISTOR
C553	EETB1EM-106E	E.CAPA. I.M	SIGNAL OUT		Q 16 2SC2785	TRANSISTOR
C554	EETB1EM-106E	E.CAPA. I.M	SIGNAL OUT		Q301 2SD2144S(VW)	TRANSISTOR
C555	QCBB1HK-101Y	C CAPACITOR	EXCEPCA-D752EE		Q302 2SD2144S(VW)	TRANSISTOR
C556	QCBB1HK-101Y	C CAPACITOR	EXCEPCA-D752EE		Q304 2SA1175	TRANSISTOR
C561	QETC1HM-2252M	E.CAPA. I.M	CENTER/REAR IN		Q305 2SC2785	TRANSISTOR
C562	QETC1HM-2252M	E.CAPA. I.M	CENTER/REAR IN		Q306 2SC2785	TRANSISTOR
C563	EETB1HM-105E	E.CAPA. I.M	CENTER/REAR OUT		Q307 2SC2785	TRANSISTOR
C564	EETB1HM-105E	E.CAPA. I.M	CENTER/REAR OUT		Q308 DTC144TS-T	D.T.R.I.M
C565	EETB1EM-106E	E.CAPA. I.M	100PF 10% 50V		Q401 2SD2144S(VW)	TRANSISTOR
C566	QCBB1HK-101Y	C CAPACITOR	100PF 10% 50V		Q402 2SD2144S(VW)	TRANSISTOR
C567	QCBB1HK-101Y	C CAPACITOR	100PF 10% 50V		Q403 KRA102M-T	D.T.R.I.M
C568	QCBB1HK-101Y	C CAPACITOR	100PF 10% 50V		Q501 2SD2144S(VW)	TRANSISTOR
C569	EETB1EM-106E	E.CAPA. I.M	100PF 10% 50V		Q502 2SD2144S(VW)	TRANSISTOR
C570	EETB1EM-106E	C CAPACITOR	.010MF 30% 16V		R 1 QRD161J-102	C RESISTOR
C581	GCVB1CN-103Y	C CAPACITOR	.010MF 30% 16V		R 2 QRD161J-181	C RESISTOR
C582	GCVB1CN-103Y	T CAPACITOR	.010MF 30% 16V		A R 2 QRD161J-821	C RESISTOR
C584	GFFV71HJ-103	T CAPACITOR	CA-D702T		R 3 QRD161J-121	C RESISTOR
C585	GGB1HK-102	C CAPACITOR	CA-D702T		R 3 QRD161J-501	C RESISTOR
C586	GGB1HK-102	C CAPACITOR	CA-D702T		R 3 QRD161J-560	C RESISTOR
C586	EETB1EM-106E	E.CAPA. I.M	CA-D702T			

BLOCK NO. 02 [1111]

A	REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX	A	REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
R 3	GRD161J-560	C RESISTOR	CA-D752TR		EE	R 82	GRD161J-102	C RESISTOR	CA-D752TR		
R 10	GRD161J-102	C RESISTOR	CA-D702T			R 83	GRD161J-102	C RESISTOR	CA-D72TR		
R 11	GRD161J-152	C RESISTOR	CA-D752TR	1.0K 5% 1/4W		R 84	GRD161J-103	C RESISTOR	CA-D72TR		
R 12	GRD161J-102	C RESISTOR	CA-D752TR	100K 5% 1/4W		R 91	GRD161J-103	C RESISTOR	CA-D752TR		
R 13	GRD161J-104	C RESISTOR	CA-D752TR	330 5% 1/4W		R 100	GRD161J-103	C RESISTOR	10K 5% 1/4W		
R 15	GRD161J-103	C RESISTOR	CA-D752TR	220K 5% 1/4W		R 101	GRD161J-103	C RESISTOR	10K 5% 1/4W		
R 16	GRD161J-103	C RESISTOR	CA-D752TR	330 5% 1/4W		R 102	GRD161J-103	C RESISTOR	10K 5% 1/4W		
R 20	GRD161J-331	C RESISTOR	CA-D752TR	330 5% 1/4W		R 103	GRD161J-512	C RESISTOR	CA-D752TR		
R 21	GRD161J-224	C RESISTOR	CA-D702T	330 5% 1/4W		R 103	GRD161J-222	C RESISTOR	CA-D702T		
R 22	GRD161J-331	C RESISTOR	CA-D702T	270 5% 1/4W		R 104	GRD161J-222	C RESISTOR	CA-D702T		
R 23	GRD161J-270	C RESISTOR	CA-D702T	CA-D702T		R 105	GRD161J-1R0	C RESISTOR	1.0 5% 1/4W		
R 24	GRD161J-271	C RESISTOR	CA-D702T	CA-D702T		R 360	GRD161J-222	C RESISTOR	2.2K 5% 1/4W		
R 25	GRD161J-273	C RESISTOR	CA-D752TR	CA-D752TR		R 362	GRD161J-221	C RESISTOR	CA-D752T		
R 26	GRD161J-273	C RESISTOR	CA-D752TR	CA-D752TR		R 370	GRD161J-102	C RESISTOR	1.0K 5% 1/4W		
R 27	GRD161J-223	C RESISTOR	CA-D702T	CA-D702T		R 371	GRD161J-103	C RESISTOR	10K 5% 1/4W		
R 29	GRD161J-473	C RESISTOR	CA-D702T	CA-D702T		R 372	GRD161J-103	C RESISTOR	10K 5% 1/4W		
R 30	GRD161J-103	C RESISTOR	CA-D702T	CA-D702T		R 373	GRD20077-70	C RESISTOR	4.7K 5% 1/4W		
R 31	GRD161J-103	C RESISTOR	CA-D702T	CA-D702T		R 375	GRD161J-331	C RESISTOR	330 5% 1/4W		
R 32	GRD161J-273	C RESISTOR	CA-D752TR	CA-D752TR		R 377	GRD161J-103	C RESISTOR	100K 5% 1/4W		
R 33	GRD161J-560	C RESISTOR	CA-D702T	CA-D702T		R 378	GRD161J-104	C RESISTOR	100K 5% 1/4W		
R 34	GRD161J-222	C RESISTOR	CA-D702T	CA-D702T		R 383	GRD161J-472	C RESISTOR	4.7K 5% 1/4W		
R 35	GRD161J-222	C RESISTOR	CA-D702T	CA-D702T		R 384	GRD161J-472	C RESISTOR	4.7K 5% 1/4W		
R 36	GRD161J-103	C RESISTOR	CA-D702T	CA-D702T		R 386	GRD161J-104	C RESISTOR	100K 5% 1/4W		
R 37	GRD167J-562	C RESISTOR	CA-D752TR	CA-D752TR		R 387	GRD161J-473	C RESISTOR	4.7K 5% 1/4W		
R 38	GRD161J-392	C RESISTOR	CA-D752TR	CA-D752TR		R 388	GRD161J-220	C RESISTOR	22.5% 5% 1/4W		
R 39	GRD161J-392	C RESISTOR	CA-D752TR	CA-D752TR		R 389	GRD161J-225	C RESISTOR	2.2M 5% 1/4W		
R 42	GRD161J-102	C RESISTOR	CA-D752TR	CA-D752TR		R 401	GRD161J-222	C RESISTOR	2.2K 5% 1/4W		
R 43	GRD161J-102	C RESISTOR	CA-D752TR	CA-D752TR		R 402	GRD161J-222	C RESISTOR	2.2K 5% 1/4W		
R 44	GRD161J-102	C RESISTOR	CA-D752TR	CA-D752TR		R 403	GRD161J-222	C RESISTOR	2.2K 5% 1/4W		
R 45	GRD161J-102	C RESISTOR	CA-D752TR	CA-D752TR		R 404	GRD161J-222	C RESISTOR	2.2K 5% 1/4W		
R 46	GRD161J-563	C RESISTOR	CA-D752TR	CA-D752TR		R 405	GRD161J-102	C RESISTOR	1.0K 5% 1/4W		
R 47	GRD161J-103	C RESISTOR	CA-D752TR	CA-D752TR		R 406	GRD161J-102	C RESISTOR	1.0K 5% 1/4W		
R 48	GRD161J-331	C RESISTOR	CA-D752TR	CA-D752TR		R 407	GRD167J-562	C RESISTOR	5.6K 5% 1/4W		
R 49	GRD161J-102	C RESISTOR	CA-D752TR	CA-D752TR		R 408	GRD167J-562	C RESISTOR	5.6K 5% 1/4W		
R 52	GRD161J-472	C RESISTOR	CA-D752TR	CA-D752TR		R 413	GRD161J-123	C RESISTOR	12K 5% 1/4W		
R 54	GRD161J-472	C RESISTOR	CA-D752TR	CA-D752TR		R 414	GRD161J-123	C RESISTOR	12K 5% 1/4W		
R 55	GRD161J-182	C RESISTOR	CA-D752TR	CA-D752TR		R 415	GRD161J-823	C RESISTOR	82K 5% 1/4W		
R 56	GRD167J-332	C RESISTOR	CA-D752TR	CA-D752TR		R 416	GRD161J-823	C RESISTOR	82K 5% 1/4W		
R 57	GRD161J-102	C RESISTOR	CA-D752TR	CA-D752TR		R 417	GRD167J-562	C RESISTOR	5.6K 5% 1/4W		
R 60	GRD161J-102	C RESISTOR	CA-D752TR	CA-D752TR		R 418	GRD167J-562	C RESISTOR	5.6K 5% 1/4W		
R 61	GRD161J-102	C RESISTOR	CA-D752TR	CA-D752TR		R 419	GRD161J-123	C RESISTOR	12K 5% 1/4W		
R 64	GRD161J-473	C RESISTOR	CA-D752TR	CA-D752TR		R 420	GRD161J-772	C RESISTOR	2.7K 5% 1/4W		
R 65	GRD161J-222	C RESISTOR	CA-D752TR	CA-D752TR		R 421	GRD161J-804	C RESISTOR	2.7K 5% 1/4W		
R 66	GRD161J-222	C RESISTOR	CA-D752TR	CA-D752TR		R 422	GRD161J-104	C RESISTOR	100K 5% 1/4W		
R 69	GRD161J-103	C RESISTOR	CA-D752TR	CA-D752TR		R 423	GRD161J-103Y	C RESISTOR	5.6K 5% 1/4W		
R 70	GRD161J-393	C RESISTOR	CA-D752TR	CA-D752TR		R 424	GRD161J-153	C RESISTOR	5.6K 5% 1/4W		
R 71	GRD161J-823	C RESISTOR	CA-D752TR	CA-D752TR		R 425	GRD161J-153	C RESISTOR	5.6K 5% 1/4W		
R 72	GRD161J-122	C RESISTOR	CA-D752TR	CA-D752TR		R 426	GRD161J-303Y	C RESISTOR	5.6K 5% 1/4W		
R 73	GRD161J-222	C RESISTOR	CA-D752TR	CA-D752TR		R 427	GRD161J-153	C RESISTOR	5.6K 5% 1/4W		
R 74	GRD167J-332	C RESISTOR	CA-D752TR	CA-D752TR		R 428	GRD161J-104	C RESISTOR	CA-D702T		
R 75	GRD161J-822	C RESISTOR	CA-D752TR	CA-D752TR		R 429	GRD161J-152	C RESISTOR	CA-D702T		
R 76	GRD161J-102	C RESISTOR	CA-D752TR	CA-D752TR		R 430	GRD161J-152	C RESISTOR	1.5K 5% 1/4W		
R 80	GRD161J-222	C RESISTOR	CA-D752TR	CA-D752TR		R 433	GRD167J-62	C RESISTOR	5.6K 5% 1/4W		
						R 434	GRD167J-262	C RESISTOR	5.6K 5% 1/4W		

BLOCK NO. 0211111

BLOCK NO. 0211111

A	REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX	A	REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
R435	GRD161J-822	C RESISTOR	8.2K 5% 1/4W			R565	GRD161J-162	C RESISTOR	1.6K 5% 1/4W		
R436	GRD161J-472	C RESISTOR	4.7K 5% 1/4W			R566	GRD161J-162	C RESISTOR	1.6K 5% 1/4W		
R437	GRD161J-472	C RESISTOR	4.7K 5% 1/4W			R567	GRD161J-104	C RESISTOR	100K 5% 1/4W		
R438	GRD161J-472	C RESISTOR	4.7K 5% 1/4W			R568	GRD161J-104	C RESISTOR	100K 5% 1/4W		
R439	GRD161J-432	C RESISTOR	4.3K 5% 1/4W			R569	GRD161J-221	C RESISTOR	220 5% 1/4W		
R440	GRD161J-432	C RESISTOR	4.3K 5% 1/4W			R570	GRD161J-221	C RESISTOR	220 5% 1/4W		
R441	GRD161J-104	C RESISTOR	100K 5% 1/4W			R571	GRD161J-103	C RESISTOR	10K 5% 1/4W		
R442	GRD161J-104	C RESISTOR	100K 5% 1/4W			R572	GRD161J-103	C RESISTOR	10K 5% 1/4W		
R443	GRD167J-113	C RESISTOR	CA-D702T			R573	GRD161J-103	C RESISTOR	10K 5% 1/4W		
R444	GRD167J-113	C RESISTOR	CA-D702T			R574	GRD161J-103	C RESISTOR	SIGNAL IN		
R445	GRD161J-303Y	C RESISTOR	30K 5% 1/4W			R575	GRD161J-103	C RESISTOR	10K 5% 1/4W		
R446	GRD161J-303Y	C RESISTOR	30K 5% 1/4W			R576	GRD161J-102	C RESISTOR	1.0K 5% 1/4W		
R447	GRD161J-153	C RESISTOR	15K 5% 1/4W			R577	GRD161J-102	C RESISTOR	1.0K 5% 1/4W		
R450	GRD161J-224	C RESISTOR	220K 5% 1/4W			R578	GRD161J-103	C RESISTOR	10K 5% 1/4W		
R453	GRD161J-104	C RESISTOR	100K 5% 1/4W			R579	GRD161J-102	C RESISTOR	1.0K 5% 1/4W		
R454	GRD161J-104	C RESISTOR	100K 5% 1/4W			R580	GRD161J-103	C RESISTOR	10K 5% 1/4W		
R455	GRD161J-103	C RESISTOR	10K 5% 1/4W			R581	GRD161J-102	C RESISTOR	1.0K 5% 1/4W		
R456	GRD161J-103	C RESISTOR	10K 5% 1/4W			R582	GRD161J-102	C RESISTOR	1.0K 5% 1/4W		
R457	GRD167J-562	C RESISTOR	5.6K 5% 1/4W			R583	GRD161J-102	C RESISTOR	1.0K 5% 1/4W		
R458	GRD161J-752	C RESISTOR	7.5K 5% 1/4W			R584	GRD161J-102	C RESISTOR	1.0K 5% 1/4W		
R459	GRD161J-472	C RESISTOR	4.7K 5% 1/4W			R585	GRD161J-102	C RESISTOR	1.0K 5% 1/4W		
R460	GRD161J-472	C RESISTOR	4.7K 5% 1/4W			R586	GRD161J-103	C RESISTOR	10K 5% 1/4W		
R461	GRD161J-221	C RESISTOR	220 5% 1/4W			R587	GRD161J-102	C RESISTOR	1.0K 5% 1/4W		
R462	GRD161J-222	C RESISTOR	2.2K 5% 1/4W			R588	GRD161J-103	C RESISTOR	10K 5% 1/4W		
R463	GRD161J-103	C RESISTOR	10K 5% 1/4W			R589	GRD161J-102	C RESISTOR	1.0K 5% 1/4W		
R464	GRD161J-103	C RESISTOR	10K 5% 1/4W			R590	GRD161J-223	C RESISTOR	22K 5% 1/4W		
R465	GRD161J-102	C RESISTOR	1.0K 5% 1/4W			R591	GRD161J-223	C RESISTOR	22K 5% 1/4W		
R469	GRD161J-221	C RESISTOR	220 5% 1/4W			R592	GRD161J-102	C RESISTOR	1.0K 5% 1/4W		
R470	GRD161J-221	C RESISTOR	220 5% 1/4W			R594	GRD161J-102	C RESISTOR	1.0K 5% 1/4W		
R471	GRD161J-103	C RESISTOR	10K 5% 1/4W			R595	GRD161J-181	C RESISTOR	180 5% 1/4W		
R472	GRD161J-103	C RESISTOR	10K 5% 1/4W			R597	GRD161J-222	C RESISTOR	4.7K 5% 1/4W		
R473	GRD161J-102	C RESISTOR	10K 5% 1/4W			R599	GRD161J-222	C RESISTOR	2.2K 5% 1/4W		
R493	GRD161J-203	C RESISTOR	20K 5% 1/4W			R600	VQT7A21-113	IFT			
R494	GRD161J-203	C RESISTOR	20K 5% 1/4W			TU 1	QAU0034-001	FRONT END			
R497	GRD161J-104	C RESISTOR	100K 5% 1/4W			X 1	GAX0402-001	CRYSTAL			
R498	GRD161J-104	C RESISTOR	10K 5% 1/4W			X 2	VCX5057-001	CRYSTAL			
R501	GRD161J-102	C RESISTOR	10K 5% 1/4W			X 541	ECXP8R0-0012	RESONATOR 1.M			
R502	GRD161J-102	C RESISTOR	1.0M 5% 1/4W			CF 3	VCF122Z-1152	C FILTER			
R542	GRD161J-393	C RESISTOR	39K 5% 1/4W			CF 4	CMU-4-56405	CERLA LOCK			
R543	GRD161J-102	C RESISTOR	1.0K 5% 1/4W			CN410	EMV7171-119	CONNECTOR	MAIN-VC3		
R544	GRD161J-102	C RESISTOR	20K 5% 1/4W			CN411	GFF1201C5-20	FFC/FPCC CONNE	FMB-MAIN		
R546	GRD161J-473	C RESISTOR	47K 5% 1/4W			CN412	VMCO332-010V	CONNECTOR	MAIN-SUC		
R547	GRD161J-473	C RESISTOR	47K 5% 1/4W			CN414	VMC1204-016V	FFC/FPCC CONNE	FMB-MAIN		
R548	GRD161J-563	C RESISTOR	56K 5% 1/4W			CN415	EMV7145-0042	SOCKET 1.M	CA-D72T		
R553	GRD161J-104	C RESISTOR	100K 5% 1/4W			CN416	QGB25101-10	CONNECTOR	MAIN-C.BRD		
R554	GRD161J-104	C RESISTOR	100K 5% 1/4W			CN420	EMV7163-009	SOCKET 1.M	CA-D72TR		
R555	GRD161J-102	C RESISTOR	1.0K 5% 1/4W			CN430	EMV7145-0032	GRAND TERMINAL			
R556	GRD161J-102	C RESISTOR	1.0K 5% 1/4W			EP001	E409182-001SM				
R561	GRD161J-473	C RESISTOR	47K 5% 1/4W			IC 1	TA2057N				
R562	GRD161J-473	C RESISTOR	47K 5% 1/4W			IC 2	LC72136N				
R563	GRD161J-103	C RESISTOR	10K 5% 1/4W			IC 4	BU1923				
R564	GRD161J-103	C RESISTOR	10K 5% 1/4W			IC 401	TDA7439				
						IC 403	BA15218				
						IC 403	BA15218	KARAOKE			

■ Electric Parts List (System Micon & Operation Switch P.C.B.)

BLOCK NO. ② ③ ④ ⑤ ⑥ ⑦						BLOCK NO. ⑧ ⑨ ⑩ ⑪ ⑫ ⑬					
Α REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX		Α REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX	
IC404	TC40528P	IC				C 100	EETB1HM-105E	E-CAPA. I.M	CA-D752TR	EE	
IC405	BA15218	IC				C 101	EETC1HM-3352E	E-CAPACITOR	CA-D752TR	EE	
IC406	LA2650	IC				C 103	QFLC1HJ-1032M	M CAPACITOR	CA-D752TR	EE	
IC407	BA15218	IC				C 104	QFLC1HJ-1032M	M CAPACITOR	CA-D752TR	EE	
IC501	LA2786	IC				C 105	QCBB1HK-271Y	C CAPACITOR	CA-D752TR	EE	
IC541	LV1016	IC				C 106	QCBB1HK-271Y	C CAPACITOR	CA-D752TR	EE	
IC542	BA38355	IC				C 107	EETB1HM-475E	E-CAPA. I.M	CA-D752TR	EE	
IC561	DA7439	IC				C 108	EETB1HM-475E	E-CAPA. I.M	CA-D752TR	EE	
IC562	BA15218	IC				C 109	QCXB1CM-222Y	C CAPACITOR	CA-D752TR	EE	
						C 110	QCXB1CM-222Y	C CAPACITOR	CA-D752TR	EE	
						C 111	QET41AM-226	E CAPACITOR	CA-D752TR	EE	
						C 112	QFLM1HJ-822Z	M CAPACITOR	CA-D752TR	EE	
						C 113	QFLC1HJ-1032M	M CAPACITOR	CA-D752TR	EE	
						C 114	QFLC1HJ-1032M	M CAPACITOR	CA-D752TR	EE	
						C 115	EETB1HM-105E	E-CAPA. I.M	CA-D752TR	EE	
						C 116	GETC1HM-2252M	E-CAPA. I.M	CA-D752TR	EE	
						C 117	QETC1HM-2252M	E-CAPA. I.M	CA-D752TR	EE	
						C 118	EETC1HM-3352E	E-CAPACITOR	CA-D752TR	EE	
						C 201	EETB1HM-475E	E-CAPA. I.M	CA-D702T		
						C 202	EETB1AM-107E	E-CAPA. I.M	CA-D702T		
						C 203	QFV41HJ-1042M	TF CAPACITOR	CA-D702T		
						C 204	QCBB1HK-101Y	C CAPACITOR	CA-D702T		
						C 205	QCVB1CN-103Y	C CAPACITOR	CA-D702T		
						C 206	QCXB1CM-72Y	C CAPACITOR	CA-D702T		
						C 207	EETC1HM-2262E	E-CAPA. I.M	CA-D702T		
						C 208	QCVB1CN-103Y	C CAPACITOR	CA-D702T		
						C 209	QCXB1CM-732Y	C CAPACITOR	CA-D702T		
						C 210	QFV41HJ-474	CAPACITOR	CA-D702T		
						C 211	QCVB1CN-103Y	C CAPACITOR	CA-D702T		
						C 212	QETC1HM-2252M	E-CAPA. I.M	CA-D702T		
						C 223	QCVB1CN-103Y	C CAPACITOR	CA-D702T		
						C 224	QCVB1CN-103Y	C CAPACITOR	CA-D702T		
						C 225	QET41HM-105	E-CAPA. I.M	CA-D702T		
						C 226	QCBB1HK-101Y	C CAPACITOR	CA-D702T		
						C 227	QETC1HM-062M	E-CAPA. I.M	CA-D702T		
						C 228	QCBB1HK-151Y	C CAPACITOR	CA-D702T		
						C 229	QCBB1HK-161Y	C CAPACITOR	CA-D702T		
						C 230	GETC1HM-2252M	E-CAPA. I.M	CA-D702T		
						C 231	QCGB1HK-102	C CAPACITOR	CA-D702T		
						C 232	QCGB1HK-102	C CAPACITOR	CA-D702T		
						C 233	QCGB1HK-102	C CAPACITOR	CA-D702T		
						C 234	QCVB1CN-103Y	C CAPACITOR	CA-D702T		
						C 235	QFLC1HJ-1032M	M CAPACITOR	CA-D702T		
						C 801	QCGB1HK-102	C CAPACITOR	1000PF 10% 50V		
						C 802	QCGB1HK-102	C CAPACITOR	1000PF 10% 50V		
						C 803	QCS11HJ-220	C CAPACITOR	22PF 5% 50V		
						C 804	QCS11HJ-220	C CAPACITOR	22PF 5% 50V		
						C 805	QCS31HJ-390Z	C CAPACITOR	39PF 5% 50V		
						C 806	QCS31HJ-390Z	C CAPACITOR	39PF 5% 50V		
						C 807	QCS11HJ-220	C CAPACITOR	22PF 5% 50V		
						C 808	GCS11HJ-220	E-CAPA. I.M	220MF 20% 6.3V		
						C 809	QEKG0JM-227ZM	E-CAPACITOR	220MF 20% 6.3V		
						C 810	QEKG0JM-227	E-CAPACITOR	220MF 20% 10V		
						C 811	QER41AM-227N	E-CAPA. I.M	220MF 20% 10V		
						C 812	QCGB1HK-102	C CAPACITOR	1000PF 10% 50V		

BLOCK NO. ② ③ ④ ⑤ ⑥ ⑦						BLOCK NO. ⑧ ⑨ ⑩ ⑪ ⑫ ⑬					
Α REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX		Α REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX	
IC404	TC40528P	IC				C 100	EETB1HM-105E	E-CAPA. I.M	CA-D752TR	EE	
IC405	BA15218	IC				C 101	EETC1HM-3352E	E-CAPACITOR	CA-D752TR	EE	
IC406	LA2650	IC				C 103	QFLC1HJ-1032M	M CAPACITOR	CA-D752TR	EE	
IC407	BA15218	IC				C 104	QFLC1HJ-1032M	M CAPACITOR	CA-D752TR	EE	
IC501	LA2786	IC				C 105	QCBB1HK-271Y	C CAPACITOR	CA-D752TR	EE	
IC541	LV1016	IC				C 106	QCBB1HK-271Y	C CAPACITOR	CA-D752TR	EE	
IC542	BA38355	IC				C 107	EETB1HM-475E	E-CAPA. I.M	CA-D752TR	EE	
IC561	DA7439	IC				C 108	EETB1HM-475E	E-CAPA. I.M	CA-D752TR	EE	
IC562	BA15218	IC				C 109	QCXB1CM-222Y	C CAPACITOR	CA-D752TR	EE	
						C 110	QCXB1CM-222Y	C CAPACITOR	CA-D752TR	EE	
						C 111	QET41AM-226	E CAPACITOR	CA-D752TR	EE	
						C 112	QFLM1HJ-822Z	M CAPACITOR	CA-D752TR	EE	
						C 113	QFLC1HJ-1032M	M CAPACITOR	CA-D752TR	EE	
						C 114	QFLC1HJ-1032M	M CAPACITOR	CA-D752TR	EE	
						C 115	EETB1HM-105E	E-CAPA. I.M	CA-D752TR	EE	
						C 116	GETC1HM-2252M	E-CAPA. I.M	CA-D752TR	EE	
						C 117	QETC1HM-2252M	E-CAPA. I.M	CA-D752TR	EE	
						C 118	EETC1HM-3352E	E-CAPACITOR	CA-D752TR	EE	
						C 201	EETB1HM-475E	E-CAPA. I.M	CA-D702T		
						C 202	EETB1AM-107E	E-CAPA. I.M	CA-D702T		
						C 203	QFV41HJ-1042M	TF CAPACITOR	CA-D702T		
						C 204	QCBB1HK-101Y	C CAPACITOR	CA-D702T		
						C 205	QCVB1CN-103Y	C CAPACITOR	CA-D702T		
						C 206	QCXB1CM-72Y	C CAPACITOR	CA-D702T		
						C 207	EETC1HM-2262E	E-CAPA. I.M	CA-D702T		
						C 208	QCVB1CN-103Y	C CAPACITOR	CA-D702T		
						C 209	QCXB1CM-732Y	C CAPACITOR	CA-D702T		
						C 210	QFV41HJ-474	CAPACITOR	CA-D702T		
						C 211	QCVB1CN-103Y	C CAPACITOR	CA-D702T		
						C 212	QETC1HM-2252M	E-CAPA. I.M	CA-D702T		
						C 223	QCVB1CN-103Y	C CAPACITOR	CA-D702T		
						C 224	QCVB1CN-103Y	C CAPACITOR	CA-D702T		
						C 225	QET41HM-105	E-CAPA. I.M	CA-D702T		
						C 226	QCBB1HK-101Y	C CAPACITOR	CA-D702T		
						C 227	QETC1HM-062M	E-CAPA. I.M	CA-D702T		
						C 228	QCBB1HK-151Y	C CAPACITOR	CA-D702T		
						C 229	QCBB1HK-161Y	C CAPACITOR	CA-D702T		
						C 230	GETC1HM-2252M	E-CAPA. I.M	CA-D702T		
						C 231	QCGB1HK-102	C CAPACITOR	CA-D702T		
						C 232	QCGB1HK-102	C CAPACITOR	CA-D702T		
						C 233	QCGB1HK-102	C CAPACITOR	CA-D702T		
						C 234	QCVB1CN-103Y	C CAPACITOR	CA-D702T		
						C 235	QFLC1HJ-1032M	M CAPACITOR	CA-D702T		
						C 801	QCGB1HK-102	C CAPACITOR	1000PF 10% 50V		
						C 802	QCGB1HK-102	C CAPACITOR	1000PF 10% 50V		
						C 803	QCS11HJ-220	C CAPACITOR	22PF 5% 50V		
						C 804	QCS11HJ-220	C CAPACITOR	22PF 5% 50V		
						C 805	QCS31HJ-390Z	C CAPACITOR	39PF 5% 50V		
						C 806	QCS31HJ-390Z	C CAPACITOR	39PF 5% 50V		
						C 807	QCS11HJ-220	C CAPACITOR	39PF 5% 50V		
						C 808	GCS11HJ-220	E-CAPA. I.M	220MF 20% 6.3V		
						C 809	QEKG0JM-227ZM	E-CAPACITOR	220MF 20% 6.3V		
						C 810	QEKG0JM-227	E-CAPACITOR	220MF 20% 10V		
						C 811	QER41AM-227N	E-CAPA. I.M	220MF 20% 10V		
						C 812	QCGB1HK-102	C CAPACITOR	1000PF 10% 50V		

BLOCK NO. 031111

A	REF.	PARTS NO.	PART'S NAME	REMARKS	SUFFIX	A	REF.	PARTS NO.	PART'S NAME	REMARKS	SUFFIX
C	814	QCBBIHK-221Y	C CAPACITOR	220PF 10% 50V		D	910	SLR-342MCA47	LED 1.M		
C	815	QCBBIHK-221Y	C CAPACITOR	220PF 10% 50V		D	911	SLR-342MCA47	LED 1.M		
C	816	QFV71HJ-124ZM	TF CAPACITOR	.12MF 5% 50V		D	912	SLR-342MCA47	LED 1.M		
C	821	QETN1HM-226Z	E CAPACITOR	22MF 20% 50V		D	913	SLR-342MCA47	LED 1.M		
C	822	QETN1HM-226Z	E CAPACITOR	22MF 20% 10V	B,E,EN	D	914	SLR-342MCA47	LED 1.M		
C	840	QFLBIHJ-222	M CAPACITOR	CA-D752TR		D	915	SLR-342MCA47	LED 1.M		
C	841	QCGB1HK-102	C CAPACITOR	1000PF 10% 50V		D	916	SLR-342MCA47	LED 1.M		
C	842	QCXB1CM-222Y	C CAPACITOR	2200PF 20% 16V		D	917	SLR-342MCA47	LED 1.M		
C	843	QCGB1HK-102	C CAPACITOR	1000PF 10% 50V		D	918	SLR-342MCA47	LED 1.M		
C	844	QCGB1HK-102	C CAPACITOR	1000PF 10% 50V		D	919	ISS133-12	DIODE		
C	844	QCGB1HK-102	C CAPACITOR	CA-D752TR	EE	D	920	ISS133-12	DIODE	CA-D702T	
C	845	QCGB1HK-102	C CAPACITOR	CA-D752TR	EE	D	921	ISS133-12	DIODE	CA-D702T	
C	845	QCGB1HK-102	C CAPACITOR	CA-D702T		D	1041	ISS133-12	DIODE	CA-D702T	
C	900	QCVB1CN-103Y	C CAPACITOR	.010MF 30X 16V		D	1042	ISS133-12	DIODE	CA-D702T	
C	901	QCVB1CN-103Y	C CAPACITOR	CA-D702T		FL HOL	GV30005-001AKP	FL HOLDER			
C	902	QCGB1HK-102	C CAPACITOR	CA-D752TR		FL SPA	E3400-0-39	FELT SPACER			
C	903	QER501M-476	E.CAPA. I.M	1000PF 10% 50V		FW801	GLF0040-001	FL TUBE			
CNO15	EMV5163-01R	CONNECTOR	47MF 20% 6.3V			FW202	EWR35D-11LSV				
CN421	EMV5163-009R	CONNECTOR	CA-D752TR	EE		FW411	EWR370-10LS	FLAT WIRE			
CN713	EMV7163-007	CONNECTOR	MAIN AMP SURROUND AMP			FW801	VWSC06-093K3K	EF FLAT WIRE			
CN714	EMV7163-006	CONNECTOR	FFC/EPC CONNE			FW802	WWS06-093K3K	EF FLAT WIRE			
CN801	QGF1201F3-20	CONNECTOR	E.CAPA. I.M			FW851	EWR34D-25LS	FLAT WIRE	H-PONE WIRE		
CN802	VMCO163-R16	CONNECTOR	CONNECTOR			IC	6	BUL66BC	CA-D732TR		
CN803	EMV7160-011	CONNECTOR	VMCO33D-R12			IC	7	BA15218	CA-D732TR		
C	1050	QCVB1CN-103Y	C CAPACITOR	.010MF 30% 16V		IC	201	UPD780206GGF-039	IC		
A	1052	QFLC1HJ-104ZM	TF CAPACITOR	CA-D752TR	B,E,EN	IC	202	GNS0080-001	IR DETECT UNIT		
A	1053	QCVB1CM-222Y	C CAPACITOR	CA-D752TR	B,E,EN	J	81	EMB10T-401AJ3	SPK. TERMINAL		
C	1054	QCVB1CM-222Y	C CAPACITOR	2200PF 20% 16V		J	83	QNN0197-001	PIN JACK		
C	1055	QFLC1HJ-3932M	M CAPACITOR	CA-D752TR		J	201	GNS0080-001	6.3 JACK	CA-D702T	
C	1056	QFLC1HJ-3932M	M CAPACITOR	.039MF 5% 50V		J	202	GNS0080-001	6.3 JACK	CA-D702T	
C	1057	QCFB1HZ-223	C CAPACITOR	.022MF +80:-20% 50V		J	850	GNS0032-001	JACK	HEAD PHONE	
C	1058	QCFB1HZ-223	C CAPACITOR	.022MF +80:-20% 50V		J	900	GNS0032-001	ROTARY ENCODER		
C	1059	QFLC1HJ-3932M	M CAPACITOR	.039MF 5% 50V		L	100	QGR0522-001	COIL	CA-D732TR	EE
D	100	MA700	ZENER DIODE	CA-D752TR	EE	L	801	QAL29BJ-0002	INDUCTOR		
D	101	MA700	ZENER DIODE	CA-D752TR	EE	L	802	VQP0026-4702	INDUCTOR		
D	110	SS133	SI DIODE	CA-D752TR	EE	L	803	VQP0018-470	INDUCTOR		
D	111	SS133	SI DIODE	CA-D752TR	EE	L	804	VQP0026-4702	INDUCTOR		
D	200	MT25.18	ZENER DIODE	CA-D702T		L	805	VQP0026-4702	INDUCTOR		
D	801	SS133-12	DIODE	CA-D752TR	EE	L	807	VQZ0048-009	INDUCTOR		
D	802	SS119-02	SI DIODE	CA-D752TR	EE	L	840	VQZ0048-009	INDUCTOR		
D	803	SS119-02	SI DIODE	CA-D752TR	EE	L	841	VQP0018-470	INDUCTOR		
D	804	SS119-02	SI DIODE	CA-D752TR	EE	L	842	VQP0018-470	INDUCTOR		
D	805	ISS133-12	DIODE	CA-D752TR	EE	PW	3	FMWE350-124KNT	TRANSISTOR		
D	806	SLR-342MCA47	LED 1.M	CA-D722TR	EE	Q	100	2SC2785	D-TR.1.M		
D	807	SLR-342MCA47	LED 1.M	CA-D722TR	EE	Q	101	DTC144ESA-T	TRANSISTOR		
D	808	SLR-342MCA47	LED 1.M	CA-D722TR	EE	Q	102	2SC2785	D-TRANSLISTOR		
D	809	SLR-342MCA47	LED 1.M	CA-D722TR	EE	Q	200	DTC144ESA-T	TRANSISTOR		
D	810	SLR-342MCA47	LED 1.M	CA-D722TR	EE	Q	801	2SC2668(C)	TRANSISTOR		
D	811	SLR-342MCA47	LED 1.M	CA-D722TR	EE	Q	802	2SC2668(C)	TRANSISTOR		
D	812	SLR-342MCA47	LED 1.M	CA-D722TR	EE	Q	803	DTA114ES	D-TRANSLISTOR		
D	813	SLR-342MCA47	LED 1.M	CA-D722TR	EE	Q	804	DTC114ESA-T	D-TRANSLISTOR		
D	820	ISS133-12	DIODE	CA-D722TR	EE	Q	805	DTC114ESA-T	D-TRANSLISTOR		

A.	REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX	BLOCK NO. 03111111
Q	806	DTC114ESA-T	D. TRANSISTOR			
Q	807	DTC114ESA-T	D. TRANSISTOR			
Q	808	DTC114ESA-T	D. TRANSISTOR			
Q	809	2SC2785	TRANSISTOR			
Q	810	DTC114TSA-T	D.T.R.I.M			
Q	811	DTC114ESA-T	D.T.R.I.M			
Q	910	DTC114ESA-T	D. TRANSISTOR			
Q	911	DTC114ESA-T	D. TRANSISTOR			
Q	912	DTC114ESA-T	D. TRANSISTOR			
Q	914	DTC114ESA-T	D. TRANSISTOR			
Q	916	DTC114ESA-T	D. TRANSISTOR			
R	100	GRD161J-822	C RESISTOR	CA-D752TR	EE	
R	101	GRD161J-563	C RESISTOR	CA-D752TR	EE	
R	102	GRD161J-103	C RESISTOR	CA-D752TR	EE	
R	103	GRD161J-563	C RESISTOR	CA-D752TR	EE	
R	104	GRD161J-682	C RESISTOR	CA-D752TR	EE	
R	105	GRD161J-184	C RESISTOR	CA-D752TR	EE	
R	106	GRD161J-224	C RESISTOR	CA-D752TR	EE	
R	107	GRD161J-513	C RESISTOR	CA-D752TR	EE	
R	109	GRD161J-224	C RESISTOR	CA-D752TR	EE	
R	110	GRD161J-224	C RESISTOR	CA-D752TR	EE	
R	111	GRD161J-223	C RESISTOR	CA-D752TR	EE	
R	112	GRD161J-123	C RESISTOR	CA-D752TR	EE	
R	113	GRD161J-103	C RESISTOR	CA-D752TR	EE	
R	114	GRD161J-103	C RESISTOR	CA-D752TR	EE	
R	115	GRD161J-103	C RESISTOR	CA-D752TR	EE	
R	116	GRD161J-333	C RESISTOR	CA-D752TR	EE	
R	117	GRD161J-473	C RESISTOR	CA-D752TR	EE	
R	118	GRD161J-473	C RESISTOR	CA-D752TR	EE	
R	200	GRD161J-472	C RESISTOR	CA-D702T		
R	201	GRD161J-472	C RESISTOR	CA-D702T		
R	210	GRD161J-123	C RESISTOR	CA-D702T		
R	211	GRD161J-333	C RESISTOR	CA-D702T		
R	212	GRD161J-333	C RESISTOR	CA-D702T		
R	213	GRD161J-103	C RESISTOR	CA-D702T		
R	214	GRD161J-203	C RESISTOR	CA-D702T		
R	215	GRD161J-822	C RESISTOR	CA-D702T		
R	216	GRD161J-203	C RESISTOR	CA-D702T		
R	217	GRD161J-153	C RESISTOR	CA-D702T		
R	218	GRD161J-103	C RESISTOR	CA-D702T		
R	219	GRD161J-472	C RESISTOR	CA-D702T		
R	220	GRD161J-392	C RESISTOR	CA-D702T		
R	224	GRD161J-221	C RESISTOR	CA-D702T		
R	225	GRD161J-103	C RESISTOR	CA-D702T		
R	226	GRD161J-203	C RESISTOR	CA-D702T		
R	227	GRD161J-102	C RESISTOR	CA-D702T		
R	228	GRD161J-331	C RESISTOR	CA-D702T		
R	230	GRD161J-104	C RESISTOR	CA-D702T		
R	234	GRD161J-104	C RESISTOR	CA-D702T		
R	236	GRD161J-221	C RESISTOR	CA-D702T		
R	239	GRD161J-152	C RESISTOR	CA-D702T		
R	240	GRD161J-391	C RESISTOR	CA-D702T		
R	241	GRD161J-823	C RESISTOR	CA-D702T		
R	801	GRD161J-103	C RESISTOR	10K 5% 1/4W		
R	802	GRD161J-103	C RESISTOR	10K 5% 1/4W		
R	803	GRD161J-472	C RESISTOR	4.7K 5% 1/4W		

A.	REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX	BLOCK NO. 03111111
R	802	GRD161J-472	C RESISTOR			
R	805	GRD161J-105	C RESISTOR	1.0M 5% 1/4W		
R	806	GRD161J-224	C RESISTOR	220K 5% 1/4W		
R	807	GRD161J-201	C.RES. I.M	200 5% 1/4W		
R	808	GRD161J-201	C.RES. I.M	200 5% 1/4W		
R	809	GRD161J-201	C.RES. I.M	200 5% 1/4W		
R	810	GRD161J-201	C.RES. I.M	200 5% 1/4W		
R	811	GRD161J-201	C.RES. I.M	200 5% 1/4W		
R	812	GRD161J-201	C.RES. I.M	200 5% 1/4W		
R	813	GRD161J-201	C.RES. I.M	200 5% 1/4W		
R	815	GRD161J-331	C RESISTOR	120 5% 1/4W		
R	816	GRD161J-121	C RESISTOR	1.0K 5% 1/4W		
R	817	GRD161J-102	C RESISTOR	1.0K 5% 1/4W		
R	818	GRD161J-102	C RESISTOR	1.0K 5% 1/4W		
R	819	GRD161J-102	C RESISTOR	1.0K 5% 1/4W		
R	820	GRD161J-102	C RESISTOR	1.0K 5% 1/4W		
R	821	GRD161J-472	C RESISTOR	4.7K 5% 1/4W		
R	822	GRD161J-103	C RESISTOR	10K 5% 1/4W		
R	823	GRD161J-103	C RESISTOR	10K 5% 1/4W		
R	824	GRD161J-103	C RESISTOR	10K 5% 1/4W		
R	827	GRD161J-563	C RESISTOR	56K 5% 1/4W		
R	828	GRD161J-154	C RESISTOR	150K 5% 1/4W		
R	829	GRD161J-103	C RESISTOR	CA-D02 T		
R	847	GRD161J-102	C RESISTOR	1.0K 5% 1/4W		
R	848	GRD161J-102	C RESISTOR	1.0K 5% 1/4W		
R	850	GRD161J-102	C RESISTOR	1.0K 5% 1/4W		
R	857	GRD161J-102	C RESISTOR	1.0K 5% 1/4W		
R	860	GRD161J-104	C RESISTOR	100K 5% 1/4W		
R	861	GRD161J-104	C RESISTOR	100K 5% 1/4W		
R	862	GRD161J-102	C RESISTOR	1.0K 5% 1/4W		
R	863	GRD161J-104	C RESISTOR	100K 5% 1/4W		
R	864	GRD161J-102	C RESISTOR	1.0K 5% 1/4W		
R	865	GRD161J-102	C RESISTOR	1.0K 5% 1/4W		
R	866	GRD161J-104	C RESISTOR	100K 5% 1/4W		
R	867	GRD161J-104	C RESISTOR	100K 5% 1/4W		
R	868	GRD161J-104	C RESISTOR	100K 5% 1/4W		
R	872	GRD161J-102	C RESISTOR	10K 5% 1/4W		
R	874	GRD161J-103	C RESISTOR	10K 5% 1/4W		
R	875	GRD161J-103	C RESISTOR	10K 5% 1/4W		
R	877	GRD161J-563	C RESISTOR	56K 5% 1/4W		
R	878	GRD161J-103	C RESISTOR	10K 5% 1/4W		
R	879	GRD161J-103	C RESISTOR	10K 5% 1/4W		
R	880	GRD161J-103	C RESISTOR	10K 5% 1/4W		
R	881	GRD161J-104	C RESISTOR	100K 5% 1/4W		
R	882	GRD161J-103	C RESISTOR	10K 5% 1/4W		
R	883	GRD161J-103	C RESISTOR	10K 5% 1/4W		
R	884	GRD161J-103	C RESISTOR	10K 5% 1/4W		
R	885	GRD161J-103	C RESISTOR	10K 5% 1/4W		
R	886	GRD161J-224	C RESISTOR	220K 5% 1/4W		
R	887	GRD161J-563	C RESISTOR	56K 5% 1/4W		
R	900	GRD161J-103	C RESISTOR	10K 5% 1/4W		
R	901	GRD161J-103	C RESISTOR	10K 5% 1/4W		
R	910	GRD161J-201	C.RES. I.M	200 5% 1/4W		
R	911	GRD161J-201	C.RES. I.M	200 5% 1/4W		
R	912	GRD161J-201	C.RES. I.M	200 5% 1/4W		

REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX	BLOCK NO. 03111111
R 913	QRD161J-201	C.RES. I.M	200 5X 1/4W		
R 914	GRD161J-201	C.RES. I.M	200 5X 1/4W		
R 915	GRD161J-201	C.RES. I.M	200 5X 1/4W		
R 916	GRD161J-201	C.RES. I.M	200 5X 1/4W		
R 917	GRD161J-201	C.RES. I.M	200 5X 1/4W		
R 951	GRD161J-102	C.RESISTOR	1.0K 5X 1/4W		
R 952	GRD161J-102	C.RESISTOR	1.0K 5X 1/4W		
R 953	GRD161J-122	C.RESISTOR	1.0K 5X 1/4W		
R 954	GRD161J-152	C.RESISTOR	1.2K 5X 1/4W		
R 955	GRD161J-222	C.RESISTOR	1.5K 5X 1/4W		
R 956	GRD161J-272	C.RESISTOR	2.2K 5X 1/4W		
R 957	GRD161J-392	C.RESISTOR	3.9K 5X 1/4W		
R 958	GRD167J-562	C.RESISTOR	5.6K 5X 1/4W		
R 959	GRD161J-103	C.RESISTOR	10K 5X 1/4W		
R 960	GRE141J-183Y	C.RESISTOR	18K 5X 1/4W		
R 961	GRD161J-102	C.RESISTOR	1.0K 5X 1/4W		
R 962	GRD161J-102	C.RESISTOR	1.0K 5X 1/4W		
R 963	GRD167J-562	C.RESISTOR	5.6K 5X 1/4W		
R 964	GRD161J-103	C.RESISTOR	10K 5X 1/4W		
R 965	GRD161J-122	C.RESISTOR	1.2K 5X 1/4W		
R 966	GRD161J-152	C.RESISTOR	1.5K 5X 1/4W		
R 967	GRD161J-222	C.RESISTOR	2.2K 5X 1/4W		
R 968	GRD161J-772	C.RESISTOR	2.7K 5X 1/4W		
R 969	GRD161J-392	C.RESISTOR	3.9K 5X 1/4W		
R 970	GRD161J-102	C.RESISTOR	1.0K 5X 1/4W		
R 971	GRD161J-102	C.RESISTOR	1.0K 5X 1/4W		
R 972	GRD161J-122	C.RESISTOR	1.2K 5X 1/4W		
R 973	GRD161J-152	C.RESISTOR	1.5K 5X 1/4W		
R 974	GRD161J-222	C.RESISTOR	2.2K 5X 1/4W		
R 975	GRD161J-272	C.RESISTOR	2.7K 5X 1/4W		
R 976	GRD161J-392	C.RESISTOR	3.9K 5X 1/4W		
R 977	GRD161J-562	C.RESISTOR	5.6K 5X 1/4W		
R 978	GRD167J-103	C.RESISTOR	10K 5X 1/4W		
R 979	GRD161J-102	C.RESISTOR	1.0K 5X 1/4W		
R 980	GRD161J-102	C.RESISTOR	1.0K 5X 1/4W		
R 981	GRD161J-122	C.RESISTOR	1.2K 5X 1/4W		
R 982	GRD161J-152	C.RESISTOR	1.5K 5X 1/4W		
R 983	GRD161J-222	C.RESISTOR	2.2K 5X 1/4W		
R 984	GRD161J-272	C.RESISTOR	2.7K 5X 1/4W		
R 985	GRD161J-392	C.RESISTOR	3.9K 5X 1/4W		
R 990	GRD161J-673	C.RESISTOR	4.70K 5X 1/4W		
R 991	GRD161J-823	C.RESISTOR	1.5K 5X 1/4W		
R 992	GRE141J-183Y	C.RESISTOR	2.2K 5X 1/4W		
R 993	GRE141J-183Y	C.RESISTOR	18K 5X 1/4W		
RAB01	GRB169J-104	R.NETWORK	100K 5X 1/6W		
RAB02	GRB169J-104	R.NETWORK	100K 5X 1/6W		
RY 1	ESK7D24-212J4	RELAY			
RY 2	ESK7D24-212J4	C.RESISTOR			
A R1051	QRD14CJ-4R7SX	C.RESISTOR			
A R1052	QRD14CJ-4R7SX	C.RESISTOR			
S 951	QSM0674-0012	TACT SW			
S 952	QSM0674-0012	TACT SW			
S 953	QSM0674-0012	TACT SW			
S 954	QSM0674-0012	TACT SW			

REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX	BLOCK NO. 03111111
S 955	QSM0674-0012	TACT SW			
S 956	QSM0674-0012	TACT SW			
S 957	QSM0674-0012	TACT SW			
S 958	QSM0674-0012	TACT SW			
S 959	QSM0674-0012	TACT SW			
S 960	QSM0674-0012	TACT SW			
S 961	QSM0674-0012	TACT SW			
S 962	QSM0674-0012	TACT SW			
S 963	QSM0674-0012	TACT SW			
S 964	QSM0674-0012	TACT SW			
S 965	QSM0674-0012	TACT SW			
S 966	QSM0674-0012	TACT SW			
S 967	QSM0674-0012	TACT SW			
S 968	QSM0674-0012	TACT SW			
S 969	QSM0674-0012	TACT SW			
S 970	QSM0674-0012	TACT SW			
S 971	QSM0674-0012	TACT SW			
S 972	QSM0674-0012	TACT SW			
S 973	QSM0674-0012	TACT SW			
S 974	QSM0674-0012	TACT SW			
S 975	QSM0674-0012	TACT SW			
S 976	QSM0674-0012	TACT SW			
S 977	QSM0674-0012	TACT SW			
S 978	QSM0674-0012	TACT SW			
S 979	QSM0674-0012	TACT SW			
S 980	QSM0674-0012	TACT SW			
S 981	QSM0674-0012	TACT SW			
S 982	QSM0674-0012	TACT SW			
S 983	QSM0674-0012	TACT SW			
S 984	QSM0674-0012	TACT SW			
S 985	QSM0674-0012	TACT SW			
SP801	VY7653-0001	IC HOLDER			
VR100	QVA601-103A	V. RES. 1.M			
X 800	QV60045-B54	V. RESISTOR			
X 801	QAX010-0012	CERA LOCK			
X 802	QAX0601-0001	CRYSTAL			

CA-D702T/D752TR

■Electrical Parts List(CD Servo Control P.C.B.)

A	Item	Parts Number	Description	Area
		I.C.S		
IC251	UPD78055GCA28	I.C.		
IC601	AN8806SB	IC(MONO-ANA)		
IC651	MN35510	IC(DIGI-MOS)		
IC801	BA6897FP-W	IC(MONO-ANA)		
IC851	TA8409S	IC(MONO-ANA)		
IC852	TA8409S	IC(MONO-ANA)		
		TRANSISTORS		
Q291	2SB1057/EF/-T	SI TRANSISTOR		
Q631	2SA1037AK/RS/-X	SI TRANSISTOR		
Q842	DTA144ES-T	DIGI TRANSISTOR		
		CAPACITORS		
C251	NCS21HJ-100X	10PF 50V CER. C		
C252	NCS21HJ-100X	10PF 50V CER. C		
C253	NCB21EK-104X	0.1MF 25V CER. C		
C254	QERF1AM-476Z	47MF 10V AL. E. C		
C281	NCB21HK-223X	0.022MF 50V CER. C		
C291	QERF1AM-476Z	47MF 10V AL. E. C		
C601	NCB21HK-102X	1000PF 50V CER. C		
C602	NCB21HK-102X	1000PF 50V CER. C		
C603	NCB21HK-223X	0.022MF 50V CER. C		
C604	NCB21HK-223X	0.022MF 50V CER. C		
C605	NCS21HJ-271X	270PF 50V CER. C		
C606	NCS21HJ-470X	47PF 50V CER. C		
C607	NCB21HK-223X	0.022MF 50V CER. C		
C608	NCB21HK-223X	0.022MF 50V CER. C		
C609	NCB21HK-102X	1000PF 50V CER. C		
C610	NCB21EK-104X	0.1MF 25V CER. C		
C611	NCB21EK-104X	0.1MF 25V CER. C		
C612	QER41HM-105	1MF 50V AL. E. C		
C613	NCS21HJ-101X	100PF 50V CER. C		
C614	NCB21HK-273X	0.027MF 50V CER. C		
C615	NCB21HK-472X	4700PF 50V CER. C		
C616	NCB21HK-103X	0.01MF 50V CER. C		
C617	NCS21HJ-331X	330PF 50V CER. C		
C621	NCB21EK-104X	0.1MF 25V CER. C		
C623	NCF21CZ-105X	1MF 16V CER. C		
C624	QER41AM-107	100MF 10V AL. E. C		
C631	QER41CM-106	10MF 16V AL. E. C		
C632	NCF21CZ-105X	1MF 16V CER. C		
C633	NCB21HK-223X	0.022MF 50V CER. C		
C651	NCS21HJ-120X	12PF 50V CER. C		
C652	NCS21HJ-150X	15PF 50V CER. C		
C653	NCB21EK-104X	0.1MF 25V CER. C		
C654	NCB21HK-223X	0.022MF 50V CER. C		
C655	QER41AM-227	220MF 10V AL. E. C		
C656	NCB21EK-104X	0.1MF 25V CER. C		
C657	NCB21HK-222X	2200PF 50V CER. C		
C658	NCB21HK-222X	2200PF 50V CER. C		
C661	NCB21EK-104X	0.1MF 25V CER. C		
C662	QER41AM-107	100MF 10V AL. E. C		
C663	NCB21EK-104X	0.1MF 25V CER. C		
C664	NCB21HK-223X	0.022MF 50V CER. C		
C665	NCB21HK-223X	0.022MF 50V CER. C		
C666	NCS21HJ-471X	470PF 50V CER. C		
C667	NCF21CZ-105X	1MF 16V CER. C		
C668	NCB21HK-473X	0.047MF 50V CER. C		
C671	NCB21EK-104X	0.1MF 25V CER. C		
C672	QER41AM-107	100MF 10V AL. E. C		
C801	NCB21HK-103X	0.01MF 50V CER. C		
C802	NCB21HK-103X	0.01MF 50V CER. C		
C811	NCS21HJ-101X	100PF 50V CER. C		
C812	NCS21HJ-101X	100PF 50V CER. C		
C813	NCS21HJ-101X	100PF 50V CER. C		
C814	NCS21HJ-101X	100PF 50V CER. C		
C821	NCF21CZ-105X	100PF 50V CER. C		

A	Item	Parts Number	Description	Area
C822	QER41AM-227	220MF 10V AL. E. C		
C851	QER41CM-106	10MF 16V AL. E. C		
C852	QER41CM-106	10MF 16V AL. E. C		
C855	NCB21EK-104X	0.1MF 25V CER. C		
C859	NCF21CZ-105X	1MF 16V CER. C		
C860	NCF21CZ-105X	1MF 16V CER. C		
		RESISTORS		
R251	NRSA02J-102X	M. G. RESISITOR		
R252	NRSA02J-102X	M. G. RESISITOR		
R253	NRSA02J-102X	M. G. RESISITOR		
R254	NRSA02J-102X	M. G. RESISITOR		
R255	NRSA02J-102X	M. G. RESISITOR		
R256	NRSA02J-102X	M. G. RESISITOR		
R257	NRSA02J-102X	M. G. RESISITOR		
R258	NRSA02J-102X	M. G. RESISITOR		
R259	NRSA02J-101X	M. G. RESISITOR		
R260	NRSA02J-102X	M. G. RESISITOR		
R261	NRSA02J-102X	M. G. RESISITOR		
R262	NRSA02J-102X	M. G. RESISITOR		
R263	NRSA02J-102X	M. G. RESISITOR		
R264	NRSA02J-102X	M. G. RESISITOR		
R265	NRSA02J-223X	M. G. RESISITOR		
R266	NRSA02J-102X	M. G. RESISITOR		
R267	NRSA02J-102X	M. G. RESISITOR		
R268	NRSA02J-102X	M. G. RESISITOR		
R269	NRSA02J-102X	M. G. RESISITOR		
R270	NRSA02J-223X	M. G. RESISITOR		
R271	NRSA02J-223X	M. G. RESISITOR		
R272	NRSA02J-223X	M. G. RESISITOR		
R273	NRSA02J-223X	M. G. RESISITOR		
R274	NRSA02J-102X	M. G. RESISITOR		
R275	NRSA02J-102X	M. G. RESISITOR		
R276	NRSA02J-102X	M. G. RESISITOR		
R277	NRSA02J-102X	M. G. RESISITOR		
R278	NRSA02J-102X	M. G. RESISITOR		
R279	NRSA02J-102X	M. G. RESISITOR		
R281	NRSA02J-102X	M. G. RESISITOR		
R282	NRSA02J-102X	M. G. RESISITOR		
R283	NRSA02J-102X	M. G. RESISITOR		
R284	NRSA02J-102X	M. G. RESISITOR		
R285	NRSA02J-102X	M. G. RESISITOR		
R286	NRSA02J-102X	M. G. RESISITOR		
R287	NRSA02J-102X	M. G. RESISITOR		
R288	NRSA02J-102X	M. G. RESISITOR		
R289	NRSA02J-223X	M. G. RESISITOR		
R291	NRSA02J-122X	M. G. RESISITOR		
R292	NRSA02J-103X	M. G. RESISITOR		
R293	NRSA02J-102X	M. G. RESISITOR		
R601	NRSA02J-274X	M. G. RESISITOR		
R602	NRSA02J-154X	M. G. RESISITOR		
R603	NRSA02J-273X	M. G. RESISITOR		
R604	NRSA02J-114X	M. G. RESISITOR		
R605	NRSA02J-104X	M. G. RESISITOR		
R606	NRSA02J-473X	M. G. RESISITOR		
R607	NRSA02J-822X	M. G. RESISITOR		
R611	NRSA02J-123X	M. G. RESISITOR		
R612	NRSA02J-125X	M. G. RESISITOR		
R631	NRSA02J-2R2X	M. G. RESISITOR		
R632	NRSA02J-100X	M. G. RESISITOR		
R634	NRSA02J-120X	M. G. RESISITOR		
R635	NRSA02J-121X	M. G. RESISITOR		
R636	NRSA02J-910X	M. G. RESISITOR		
R651	NRSA02J-271X	M. G. RESISITOR		
R652	NRSA02J-220X	M. G. RESISITOR		
R657	NRSA02J-102X	M. G. RESISITOR		
R658	NRSA02J-102X	M. G. RESISITOR		

■ Electrical Parts List (CD Servo Control P.C.B.)

Item	Parts Number	Description	Area
R661	NRSA02J-220X	M. G. RESISITOR	
R662	NRSA02J-471X	M. G. RESISITOR	
R663	NRSA02J-124X	M. G. RESISITOR	
R665	NRSA02J-683X	M. G. RESISITOR	
R666	NRSA02J-155X	M. G. RESISITOR	
R667	NRSA02J-562X	M. G. RESISITOR	
R671	NRSA02J-102X	M. G. RESISITOR	
R672	NRSA02J-102X	M. G. RESISITOR	
R673	NRSA02J-102X	M. G. RESISITOR	
R674	NRSA02J-101X	M. G. RESISITOR	
R675	NRSA02J-102X	M. G. RESISITOR	
R676	NRSA02J-102X	M. G. RESISITOR	
R677	NRSA02J-102X	M. G. RESISITOR	
R678	NRSA02J-102X	M. G. RESISITOR	
R679	NRSA02J-102X	M. G. RESISITOR	
R680	NRSA02J-102X	M. G. RESISITOR	
R681	NRSA02J-102X	M. G. RESISITOR	
R682	NRSA02J-102X	M. G. RESISITOR	
R683	NRSA02J-102X	M. G. RESISITOR	
R684	NRSA02J-271X	M. G. RESISITOR	
R685	NRSA02J-102X	M. G. RESISITOR	
R686	NRSA02J-101X	M. G. RESISITOR	
R687	NRSA02J-102X	M. G. RESISITOR	
R688	NRSA02J-101X	M. G. RESISITOR	
R689	NRSA02J-102X	M. G. RESISITOR	
R690	NRSA02J-101X	M. G. RESISITOR	
R691	NRSA02J-101X	M. G. RESISITOR	
R692	NRSA02J-101X	M. G. RESISITOR	
R693	NRSA02J-471X	M. G. RESISITOR	
R694	NRSA02J-102X	M. G. RESISITOR	
R801	NRSA02J-182X	M. G. RESISITOR	
R802	NRSA02J-472X	M. G. RESISITOR	
R803	NRSA02J-222X	M. G. RESISITOR	
R804	NRSA02J-683X	M. G. RESISITOR	
R805	NRSA02J-822X	M. G. RESISITOR	
R806	NRSA02J-223X	M. G. RESISITOR	
R807	NRSA02J-222X	M. G. RESISITOR	
R808	NRSA02J-223X	M. G. RESISITOR	
R811	NRSA02J-473X	M. G. RESISITOR	
R831	NRSA02J-151X	M. G. RESISITOR	
R832	NRSA02J-103X	M. G. RESISITOR	
R842	NRSA02J-473X	M. G. RESISITOR	
R851	NRSA02J-102X	M. G. RESISITOR	
R852	NRSA02J-102X	M. G. RESISITOR	
R853	NRSA02J-102X	M. G. RESISITOR	
R854	NRSA02J-102X	M. G. RESISITOR	
R855	NRSA02J-102X	M. G. RESISITOR	
R856	NRSA02J-102X	M. G. RESISITOR	
R859	NRSA02J-181X	M. G. RESISITOR	
R861	NRSA02J-102X	M. G. RESISITOR	
R862	NRSA02J-102X	M. G. RESISITOR	
R863	NRSA02J-102X	M. G. RESISITOR	
R864	NRSA02J-102X	M. G. RESISITOR	
R865	NRSA02J-102X	M. G. RESISITOR	
R866	NRSA02J-102X	M. G. RESISITOR	
R871	NRSA02J-223X	M. G. RESISITOR	
R872	NRSA02J-223X	M. G. RESISITOR	
R873	NRSA02J-223X	M. G. RESISITOR	
R874	NRSA02J-223X	M. G. RESISITOR	
R875	NRSA02J-223X	M. G. RESISITOR	
R876	NRSA02J-223X	M. G. RESISITOR	
R880	NRSA02J-102X	M. G. RESISITOR	
R881	NRSA02J-102X	M. G. RESISITOR	
R882	NRSA02J-102X	M. G. RESISITOR	
R883	NRSA02J-102X	M. G. RESISITOR	
R884	NRSA02J-102X	M. G. RESISITOR	

Item	Parts Number	Description	Area
R885	NRSA02J-102X	M. G. RESISITOR	
R886	NRSA02J-102X	M. G. RESISITOR	
R887	NRSA02J-102X	M. G. RESISITOR	
R890	NRSA02J-223X	M. G. RESISITOR	
R891	NRSA02J-223X	M. G. RESISITOR	
R892	NRSA02J-223X	M. G. RESISITOR	
R893	NRSA02J-223X	M. G. RESISITOR	
R894	NRSA02J-223X	M. G. RESISITOR	
R895	NRSA02J-223X	M. G. RESISITOR	
R896	NRSA02J-223X	M. G. RESISITOR	
R897	NRSA02J-223X	M. G. RESISITOR	
	OTHERS		
L851	QOL01BK-100Z	INDUCTOR	
L853	QOL01BK-100Z	INDUCTOR	
L854	QOL01BK-100Z	INDUCTOR	
X251	QAX0360-001Z	CRYSTAL	
X651	QAX0413-001Z	CRYSTAL	
CN151	QGF1016F1-15	CONNECT TERMINAL	
CN152	QGA2001F1-12	CONNECT TERMINAL	
CN601	QGF1016F1-15	CONNECT TERMINAL	
CN651	QGF1016F1-19	CONNECT TERMINAL	
CN652	QGF1016F1-05	CONNECT TERMINAL	
CN653	QGF1016F1-13	CONNECT TERMINAL	
CN801	QGA2001C1-06	CONNECTOR	
CN851	QGD2503F1-03	CONNECT TERMINAL	
CN854	QGB2016K1-07	CONNECT TERMINAL	
CN855	QGG2002M4-10	CONNECT TERMINAL	

■ Electrical Parts List (CD Select Switch P.C.B.)

Item	Parts Number	Description	Area
	OTHERS		
CN804	QGB2016J1-07	CONNECT TERMINAL	
CN805	QGB2021L1-10	CONNECT TERMINAL	
SW 1	QSW0507-001	LEVER SWITCH	
SW 2	QSW0507-001	LEVER SWITCH	
SW 3	QSW0507-001	LEVER SWITCH	
SW 4	QSW0507-001	LEVER SWITCH	
SW 5	QSW0507-001	LEVER SWITCH	
SW 6	QSW0507-001	LEVER SWITCH	

CA-D702T/D752TR

■Electrical Parts List (Head Amp & Mechanism Control P.C.B.)

Item	Parts Number	Description	Area
	I. C.S		
IC301	BA3126N	IC(MONO-ANA)	
IC302	AN7345K	IC(M)	
IC303	BU4094BCF-X	IC(M)	
IC304	BU4094BCF-X	IC(M)	
	DIODES		
D301	MA704A-X	SI DIODE	
D302	HSM2838C-W	DIODE	
D307	HZM5.1NB2-X	ZEMER DIODE	
D308	HZM5.1NB2-X	ZEMER DIODE	
D309	MA704A-X	ZEMER DIODE	
	TRANSISTORS		
Q101	DTC114TKA-X	DIGITAL TRANSISTOR	
Q102	DTC144TKA-X	DIGITAL TRANSISTOR	
Q103	DTC144EKA-X	DIGITAL TRANSISTOR	
Q104	DTC114TKA-X	DIGITAL TRANSISTOR	
Q105	2SC2001/LK/-T	SI TRANSISTOR	
Q201	DTC114TKA-X	DIGITAL TRANSISTOR	
Q202	DTC144TKA-X	DIGITAL TRANSISTOR	
Q203	DTC144EKA-X	DIGITAL TRANSISTOR	
Q204	DTC114TKA-X	DIGITAL TRANSISTOR	
Q205	2SC2001/LK/-T	SI TRANSISTOR	
Q301	DTC144TKA-X	DIGITAL TRANSISTOR	
Q302	2SC2001/LK/-T	DIGITAL TRANSISTOR	
Q303	2SC2001/LK/-T	DIGITAL TRANSISTOR	
Q304	2SC2001/LK/-T	DIGITAL TRANSISTOR	
Q305	2SC2001/LK/-T	DIGITAL TRANSISTOR	
Q306	2SC2412K/RS/-X	SI TRANSISTOR	
Q307	2SC2412K/RS/-X	SI TRANSISTOR	
Q308	2SC2412K/RS/-X	SI TRANSISTOR	
Q309	2SC2412K RS/-X	SI TRANSISTOR	
Q312	2SB562/C/-T	SI TRANSISTOR	
Q313	2SC2412K/RS/-X	SI TRANSISTOR	
Q314	2SB562/C/-T	SI TRANSISTOR	
Q315	2SC2412K/RS/-X	SI TRANSISTOR	
Q316	2SA952/LK/-T	SI TRANSISTOR	
Q317	DTC124EKA-X	SI TRANSISTOR	
Q318	DTA144EKA-X	DIGITAL TRANSISTOR	
Q319	DTC144EKA-X	DIGITAL TRANSISTOR	
Q320	DTC144EKA-X	DIGITAL TRANSISTOR	
Q321	DTC144EKA-X	DIGITAL TRANSISTOR	
Q322	DTC144EKA-X	DIGITAL TRANSISTOR	
Q323	2SC2412K/RS/-X	SI TRANSISTOR	
	CAPACITORS		
C101	NCS21HJ-561X	560PF 50V CER. C	
C102	NCS21HJ-331X	330PF 50V CER. C	
C103	NCS21HJ-561X	560PF 50V CER. C	
C104	NCS21HJ-221X	220PF 50V CER. C	
C105	QEK40JM-227	220MF 6.3V AL E.C	
C106	NCB21HK-333X	0.033MF 50V CER. C	
C107	QEK41EM-475	4.7MF 25V AL. E.C	
C108	NCB21HK-393X	0.039MF 50V CER. C	
C109	NCB21HK-563X	0.056MF 50V CER. C	
C110	NCS21HJ-221X	220PF 50V CER. C	
C111	QEK41HM-104	0.1MF 50V AL. E.C	
C112	QEK41CM-106	10MF 16V AL. E.C	
C113	NCB21HK-332X	3300PF 50V CER. C	
C114	QEK41EM-475	4.7MF 25V AL. E.C	
C115	NCB21HK-153X	0.015MF 50V CER. C	
C116	NCB21HK-822X	8200PF 50V CER. C	
C117	NCB21HK-223X	0.022MF 50V CER. C	
C118	NCB21HK-103X	0.01MF 50V CER. C	
C119	NCB21HK-563X	0.056MF 50V CER. C	
C120	NCS21HJ-330X	33PF 50V CER. C	
C201	NCS21HJ-561X	560PF 50V CER. C	
C202	NCS21HJ-331X	330PF 50V CER. C	

Item	Parts Number	Description	Area
C203	NCS21HJ-561X	560PF 50V CER. C	
C204	NCS21HJ-221X	220PF 50V CER. C	
C205	QEK40JM-227	220MF 6.3V AL. E.C	
C206	NCB21HK-333X	0.033MF 50V CER. C	
C207	QEK41EM-475	4.7MF 25V AL. E.C	
C208	NCB21HK-393X	0.039MF 50V CER. C	
C209	NCB21HK-563X	0.056MF 50V CER. C	
C210	NCS21HJ-221X	220PF 50V CER. C	
C211	QEK41HM-104	0.1MF 50V AL. E.C	
C212	QEK41CM-106	10MF 16V AL. E.C	
C213	NCB21HK-332X	3300PF 50V CER. C	
C214	QEK41EM-475	4.7MF 25V AL. E.C	
C215	NCB21HK-153X	0.015MF 50V CER. C	
C216	NCB21HK-822X	8200PF 50V CER. C	
C217	NCB21HK-223X	0.022MF 50V CER. C	
C218	NCB21HK-103X	0.01MF 50V CER. C	
C219	NCB21HK-563X	0.056MF 50V CER. C	
C220	NCS21HJ-330X	33PF 50V CER. C	
C301	QEK41CM-106	10MF 16V AL. E.C	
C302	QEK41CM-476	47MF 16V AL. E.C	
C303	QEK41CM-226	22MF 16V AL. E.C	
C304	QEK41EM-475	4.7MF 25V AL. E.C	
C305	NCB21HK-393X	0.039MF 50V CER. C	
C306	QEK40JM-227	220MF 6.3V AL. E.C	
C308	NCB21HK-562X	5600PF 50V CER. C	
C309	NCB21HK-562X	5600PF 50V CER. C	
C310	NCB21HK-223X	0.022MF 50V CER. C	
C311	NCB21HK-682X	6800PF 50V CER. C	
C313	QEJK1AM-107Z	100MF 10V AL. E.C	
C314	QCZ0205-155	1.5MF 25V CER. C	
C315	QCZ0205-155	1.5MF 25V CER. C	
C316	QFG32AJ-103Z	0.01MF 100V CER. C	
C318	NCB21HK-103X	0.01MF 50V CER. C	
C319	QFG32AJ-821Z	820PF 100V CER. C	
C321	NCB21HK-103X	0.01MF 50V CER. C	
C322	QFG32AJ-152Z	1500PF 100V CER. C	
C327	QEK41CM-476	47MF 16V AL. E.C	
C328	NCS21HJ-151X	150PF 50V CER. C	
C329	NCS21HJ-151X	150PF 50V CER. C	
C330	NCS21HJ-151X	150PF 50V CER. C	
C332	NCS21HJ-151X	150PF 50V CER. C	
C335	NCB21HK-103X	0.01MF 50V CER. C	
C336	NCB21HK-103X	0.01MF 50V CER. C	
C337	NCB21HK-103X	0.01MF 50V CER. C	
C338	NCB21HK-103X	0.01MF 50V CER. C	
C339	QEK41CM-476	47MF 16V AL. E.C	
C340	NCB21HK-103X	0.01MF 50V CER. C	
C341	QEJK1AM-107Z	100MF 10V AL. E.C	
C342	QEK41EM-475	4.7MF 25V AL. E.C	
C343	QE41CM-106	10MF 16V AL. E.C	
C344	NCB21HK-472X	4700PF 50V CER. C	
C345	NCS21HJ-331X	330PF 50V CER. C	
	RESISTORS		
R102	NRSA02J-102X	M. G. RESISTOR	
R103	NRSA02J-183X	M. G. RESISTOR	
R105	NRSA02J-220X	M. G. RESISTOR	
R106	NRSA02J-392X	M. G. RESISTOR	
R107	NRSA02J-123X	M. G. RESISTOR	
R108	NRSA02J-222X	M. G. RESISTOR	
R109	NRSA02J-152X	M. G. RESISTOR	
R110	NRSA02J-152X	M. G. RESISTOR	
R111	NRSA02J-562X	M. G. RESISTOR	
R112	NRSA02J-122X	M. G. RESISTOR	
R113	NRSA02J-271X	M. G. RESISTOR	
R114	NRSA02J-391X	M. G. RESISTOR	
R115	NRSA02J-332X	M. G. RESISTOR	

■ Electrical Parts List (Head Amp & Mechanism Control P. C. B.)

A	Item	Parts Number	Description	Area
R116	NRSA02J-182X	M. G. RESISTOR		
R117	NRSA02J-332X	M. G. RESISTOR		
R118	NRSA02J-152X	M. G. RESISTOR		
R119	NRSA02J-203X	M. G. RESISTOR		
R120	NRSA02J-102X	M. G. RESISTOR		
R121	NRSA02J-122X	M. G. RESISTOR		
R202	NRSA02J-102X	M. G. RESISTOR		
R203	NRSA02J-183X	M. G. RESISTOR		
R205	NRSA02J-220X	M. G. RESISTOR		
R206	NRSA02J-392X	M. G. RESISTOR		
R207	NRSA02J-123X	M. G. RESISTOR		
R208	NRSA02J-222X	M. G. RESISTOR		
R209	NRSA02J-152X	M. G. RESISTOR		
R210	NRSA02J-152X	M. G. RESISTOR		
R211	NRSA02J-562X	M. G. RESISTOR		
R212	NRSA02J-122X	M. G. RESISTOR		
R213	NRSA02J-271X	M. G. RESISTOR		
R214	NRSA02J-391X	M. G. RESISTOR		
R215	NRSA02J-332X	M. G. RESISTOR		
R216	NRSA02J-182X	M. G. RESISTOR		
R217	NRSA02J-332X	M. G. RESISTOR		
R218	NRSA02J-152X	M. G. RESISTOR		
R219	NRSA02J-203X	M. G. RESISTOR		
R220	NRSA02J-102X	M. G. RESISTOR		
R221	NRSA02J-122X	M. G. RESISTOR		
R301	NRS181J-221X	M. G. RESISTOR		
R302	NRS181J-101X	M. G. RESISTOR		
R304	NRSA02J-393X	M. G. RESISTOR		
R305	NRSA02J-103X	M. G. RESISTOR		
R306	NRSA02J-103X	M. G. RESISTOR		
R307	NRSA02J-103X	M. G. RESISTOR		
R308	NRSA02J-152X	M. G. RESISTOR		
R309	NRSA02J-152X	M. G. RESISTOR		
R310	NRS181J-820X	M. G. RESISTOR		
R311	NRS181J-820X	M. G. RESISTOR		
R313	NRSA02J-3R3NY	M. G. RESISTOR		
R314	NRSA02J-223X	M. G. RESISTOR		
R315	NRSA02J-100X	M. G. RESISTOR		
R316	NRSA02J-223X	M. G. RESISTOR		
R317	NRSA02J-100X	M. G. RESISTOR		
R318	NRSA02J-123X	M. G. RESISTOR		
R319	NRSA02J-152X	M. G. RESISTOR		
R321	NRSA02J-123X	M. G. RESISTOR		
R322	NRSA02J-152X	M. G. RESISTOR		
R327	NRSA02J-474X	M. G. RESISTOR		
R328	NRSA02J-222X	M. G. RESISTOR		
R329	NRSA02J-222X	M. G. RESISTOR		
R330	NRSA02J-0R0X	M. G. RESISTOR		
R335	NRSA02J-222X	M. G. RESISTOR		
R336	NRSA02J-392X	M. G. RESISTOR		
R338	NRSA02J-222X	M. G. RESISTOR		
R339	NRSA02J-222X	M. G. RESISTOR		
R341	NRSA02J-222X	M. G. RESISTOR		
R343	NRSA02J-0R0X	M. G. RESISTOR		
R345	NRSA02J-222X	M. G. RESISTOR		
R346	NRSA02J-0R0X	M. G. RESISTOR		
R347	NRSA02J-392X	M. G. RESISTOR		
R348	NRSA02J-222X	M. G. RESISTOR		
R350	NRSA02J-472X	M. G. RESISTOR		
R351	NRSA02J-151X	M. G. RESISTOR		
R353	NRSA02J-472X	M. G. RESISTOR		
R354	NRSA02J-151X	M. G. RESISTOR		
R355	NRSA02J-332X	M. G. RESISTOR		
R356	NRSA02J-103X	M. G. RESISTOR		
R357	NRSA02J-103X	M. G. RESISTOR		
R358	NRSA02J-123X	M. G. RESISTOR		

A	Item	Parts Number	Description	Area
R359	NRSA02J-123X	M. G. RESISTOR		
R360	NRSA02J-433NY	M. G. RESISTOR		
R361	NRSA02J-183X	M. G. RESISTOR		
R362	NRSA02J-123X	M. G. RESISTOR		
R363	NRSA02J-183X	M. G. RESISTOR		
R364	NRSA02J-433NY	M. G. RESISTOR		
R365	NRSA02J-203X	M. G. RESISTOR		
R366	NRSA02J-123X	M. G. RESISTOR		
R367	NRSA02J-102X	M. G. RESISTOR		
R368	NRSA02J-391X	M. G. RESISTOR		
R369	NRSA02J-391X	M. G. RESISTOR		
R371	NRS181J-222X	M. G. RESISTOR		
R374	NRSA02J-912X	M. G. RESISTOR		
R375	NRSA02J-683X	M. G. RESISTOR		
R376	NRS181J-6R8X	M. G. RESISTOR		
VR101	QVP0008-503Z	50K V. RESISITOR		
VR201	QVP0008-503Z	50K V. RESISITOR		
VR301	QVP0008-103Z	10K V. RESISITOR		
	OTHERS			
L301	QQR0620-001	OSC COIL		
L303	QQL01BK-100Z	INDUCTOR		
CN301	QGF1205F1-06	CONNECTOR		
CN302	QGF1205F1-06	CONNECTOR		
CN303	QGB2011M1-10	CONNECTOR		
CN304	QGB2011M1-10	CONNECTOR		
CN305	QGF1205F1-10	CONNECTOR		
CN306	QGF1205F1-11	CONNECTOR		
WIRE	VWS304-10A13K	FLAT WIRE		

■ Electrical Parts List (Reel Pulse P. C. B)


A	Item	Parts Number	Description	Area
	I. C. S			
IC 1	SG-105F3-BB.C	IC(PH SENSOR)		
	DIODES			
D 1	1SR139-100-T2	SI DIODE		
	OTHERS			
P 1	QNZ0104-001	PIN		
CN 1	QGB2011L1-10	PIN PLUG		
SW 2	MXS00220MVLO	CASSETTE SWITCH		
SW 4	MXS00220MVLO	CASSETTE SWITCH		
SW 6	QSW0507-001	LEVER SWITCH		

■ Electrical Parts List (Reel Pulse P. C. B)

A	Item	Parts Number	Description	Area
	I. C. S			
IC 1	SG-105F3-BB.C	IC(PH SENSOR)		
	DIODES			
D 1	1SR139-100-T2	SI DIODE		
	OTHERS			
P 1	QNZ0104-001	PIN		
CN 1	QGB2011L1-10	PIN PLUG		
SW 1	MXS00220MVLO	CASSETTE SWITCH		
SW 2	MXS00220MVLO	CASSETTE SWITCH		
SW 4	MXS00220MVLO	CASSETTE SWITCH		
SW 5	MXS00220MVLO	CASSETTE SWITCH		
SW 6	QSW0507-001	LEVER SWITCH		

Packing Materials and Accessories Parts List

Block No. **M** **5** **M** **M**




■ Accessories Parts List

BLOCK NO. M6MM₁₁₁₁

△	REF.	PARTS NO.	PARTS NAME	REMARKS	QTY	SUFFIX	CLR
	A 1	GVTO004-006A GVTO004-009A GVTO004-003A GVTO004-004A GVTO004-003A	INST.BOOK INST.BOOK INST.BOOK INST.BOOK INST.BOOK	CA-D752TR CA-D752TR CA-D702T CA-D702T CA-D702T	1 1 1 1 1	E EE U,UB,US UP UT,UX	
	A 2	GVTO004-007A GVTO004-005A GVTO004-008A BT-56001-1 BT-56004-5	INST.BOOK INST.BOOK INST.BOOK WARRANTY CARD W.CARD	CA-D752TR CA-D702T CA-D752TR CA-D702T CA-D702T	1 1 1 1 1	EN A B A UP	
	A 4 A 5 A 6 A 7	BT-54008-1 ENZ2202-001 VMZ0139-001 QAL0014-001 EWP201-011	WARRANTY CARD AC PLUG ADAPTER CONTHI PLUG AM LOOP ANT B. IN ANT	CA-D752TR CA-D702T CA-D702T	1 1 1	U,US UT,UX	
	A 8 A 10 A 11	RM-SED702TXUKP RM-SED752TRU R6SPTT/2STS E309758-002	REMOCON W.LESS REMOCON BATTERY POLY BAG	CA-D702T CA-D752TR	1 1 2 1		

CA-D752T
CA-D752TR



JVC

VICTOR COMPANY OF JAPAN, LIMITED

AUDIO DIVISION, 10-1, 1Chome, Ohwatari-machi, Maebashi-city, 371-8543, Japan

(No.20700)

 Printed in Japan
9806 (O)