

JVC

SERVICE MANUAL

MICRO COMPONENT SYSTEM

UX-A3 A/C/J/U



**COMPACT
DISC
DIGITAL AUDIO**

Area suffix

- | | |
|---------|-------------|
| A | Australia |
| C | Canada |
| J | U.S.A. |
| U | Other Areas |

Contents

Page	Page		
1 Safety Precautions	2	8 Main Adjustments	44
2 Safety Precautions about JX-A3	3	9 Block Diagram	51
3 Features	5	10 Wiring Connections	53
4 Specifications	5	11 Standard Schematic Diagram	54
5 Instructions (Extract)	6	12 Electrical Parts List	66
6 Location of Main Parts	28	13 Illustration of Packing and Parts List	75
7 Removal of Main Parts and Parts List	30	14 Accessories	Back Cover

〒103 東京都中央区日本橋本町4-6
日本ビクター株式会社
サービス部 部品管理課

1 Safety Precautions

1. The design of this product contains special hardware and many circuits and components specially for safety purposes. For continued protection, no changes should be made to the original design unless authorized in writing by the manufacturer. Replacement parts must be identical to those used in the original circuits. Service should be performed by qualified personnel only.
2. Alterations of the design or circuitry of the product should not be made. Any design alterations of the product should not be made. Any design alterations or additions will void the manufacturer's warranty and will further relieve the manufacturer or responsibility for personal injury or property damage resulting therefrom.
3. Many electrical and mechanical parts in the product have special safety-related characteristics. These characteristics are often not evident from visual inspection nor can the protection afforded by them necessarily be obtained by using replacement components rated for higher voltage, wattage, etc. Replacement parts which have these special safety characteristics are identified in the Parts List of Service Manual. Electrical components having such features are identified by (Δ) on the schematic diagram and Parts List in Service Manual. The use of a substitute replacement which does not have the same safety characteristics as the recommended replacement part shown in the Parts List in Service Manual may create shock, fire, or other hazards.
4. The leads in the products are routed and dressed with ties, clamps, tubings, barriers and the like to be separated from live parts, high temperature parts, moving parts and/or sharp edges for the prevention of electric shock and fire hazard.
When service is required, the original lead routing and dress should be observed, and it should be confirmed that they have been returned to normal, after re-assembling.
5. Leakage current check (Electrical shock hazard testing)

After re-assembling the product, always perform an isolation check on the exposed metal parts of the product (antenna terminals, knobs, metal cabinet, screw heads, headphone jack, control shafts, etc.) to be sure the product is safe to operate without danger of electrical shock.

Do not use a line isolation transformer during this check.




- Plug the AC line cord directly into the AC outlet. Using a "Leakage Current Tester", measure the leakage current from each exposed metal part of the cabinet, particularly any exposed metal part having a return path to the chassis, to a known good earth ground. Any leakage current must not exceed 0.5 mA AC (r.m.s.).
- Alternate check method

Plug the AC line cord directly into the AC outlet. Use an AC voltmeter having 1,000 ohms per volt or more sensitivity in the following manner. Connect a $1,500 \Omega$ 10 W resistor paralleled by a $0.15 \mu\text{F}$ AC-type capacitor between an exposed metal part and a known good earth ground.

Measure the AC voltage across the resistor with the AC voltmeter.

Move the resistor connection to each exposed metal part, particularly any exposed metal part having a return path to the chassis, and measure the AC voltage across the resistor. Now, reverse the plug in the AC outlet and repeat each measurement. Any voltage measured must not exceed 0.75 V AC (r.m.s.).

This corresponds to 0.5 mA AC (r.m.s.).



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.


The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

2 Safety Precautions about UX-A3

IMPORTANT FOR LASER PRODUCTS (For U.S.A. only)

1. CLASS 1 LASER PRODUCT
2. **DANGER:** Invisible laser radiation when open and interlock failed or defeated. Avoid direct exposure to beam.
3. CAUTION: Do not open the rear cover. There are no user serviceable parts inside the unit; leave all servicing to qualified service personnel.
4. CAUTION: The compact disc player uses invisible laser radiation and is equipped with safety switches which prevent the emission of radiation when the CD door is open. It is dangerous to defeat the safety switches.
5. CAUTION: Use of controls for adjustments and the performance of procedures other than those specified herein may result in exposure to hazardous radiation.
6. CAUTION: The laser is able to function, if safety switches are out of function. The laser light is invisible, avoid exposure, do not disassemble the laser unit, but replace the complete unit.


Cassette deck/amplifier section



NAME/RATING PLATE

IDENTIFICATION LABEL AND CERTIFICATION LABEL

CD player/tuner section



Product complies with DHHS Rules 21 CFR Subchapter J in effect at date of manufacture.


MANUFACTURED

*1

US JVC CORP.
41 SLATER DRIVE
ELMWOOD PARK,
N.J. 07407
MANUFACTURED
AT *2
MADE IN SINGAPORE

Notes:

- * 1 The date of manufacture.
- * 2 The ID code of manufacturing plant.



Full Fusereplacement Marking

Graphic symbol mark




should be read as follows:

FUSE CAUTION


**F951 : FOR CONTINUED PROTECTION
AGAINST RISK OF FIRE, REPLACE
ONLY WITH SAME TYPE 600 - MA,
250 - V FUSE.**

**F952 : FOR CONTINUED PROTECTION
F953 AGAINST RISK OF FIRE, REPLACE
ONLY WITH SAME TYPE 5 - A,
125 - V FUSES.**

■ CD, Receiver Sections



■ Tape Deck Power Amplifier Section



■ Important Management Points Regarding Safety

(Item demanding special safety precautions ... UX-A3 C/J)

Ref. No.	Description
1	Make sure that the parts number of the power transformer is No. 71H301HDL (UX-A3 J). Make sure that the setscrew is free from any looseness.
2	Strain relief is "4N-4", which must be fitted by the specific HEYCO tool and secures the power cord tightly.
3	The patterns of the primary circuit and adjacent circuits of printed circuit board should be free from round soldering protrusion in order to secure sufficient creeping distance.
4	Coloring to indicate polarity of power cords is as shown in figure. Attachment plug indicator: (S) KP-10W Cord: SPT1
5	Wires, etc. must be firmly clamped or fixed at the positions indicated in the above diagram so as not to contact with live parts, movable parts, heated parts and sharp edge parts.

Ref. No.	Description
6	Since heat is generated from the following parts, these parts should no be located adjacent to the electrolytic capacitor, etc. Tape Deck sections: D952, ICA05, ICA06 Power Transformer CD, Receiver sections: QF07, QF08, IC503 Heat sink
7	Coloring to indicate polarity of power transformer wires is as shown in figure.
8	C. Resistor 2.2 M must be used for R951 and R7.
9	Primary wires of power transformer must be kept away from D952 more than 3 mm.
10	Bent type must be used for C955.
11	Concerning the fuse caution, letter or graphic indication must be confirmed.

3 Features


1. Disc-size micro component system consisting of 4 units, designed for stacked or side-by-side installation
 - Consists of 4 units; a cassette deck/amplifier and a CD player/tuner, plus a pair of speakers.
2. Newly-developed Active Hyper-Bass circuit for low-frequency sound reproduction
 - The cut-off frequency is controlled by a level identification circuit to reinforce low-frequency sound.
3. 24-Key remote control unit opens and closes the motor-driven CD door, in addition to the usual CD and tuner operations
 - Remote control controls power on/off switching, volume control, Active Hyper-Bass on/off switching and a variety of editing functions.
4. Green-colored large backlit LCD (Liquid Crystal Display)
 - Display includes 15-tune program chart, function mode, etc.
5. Multi-function CD player
 - Capable of auto-edit recording and programmed play.
6. U-Turn auto-reverse mechanism with Dolby® B NR
 - Auto tape select mechanism.
 - Metal (type IV) and CrO₂ (type II) tape can be played back for superior tone quality.
 - CrO₂ (type II) tape recording capability.
7. 2-Band digital synthesizer tuner with 30-station (15 FM and 15 AM) preset capability
 - Seek/manual tuning.

8. Timer/clock function

- Timer on/off with preset volume function.
- Wake-up volume setting with 5 different levels.
- Sleep timer can be set for up to 120 minutes.
- * Dolby noise reduction manufactured under license from Dolby Laboratories Licensing Corporation. "Dolby" and the double-D symbol are trademarks of Dolby Laboratories Licensing Corporation.

• Active Hyper-Bass circuit

Generally, since low-frequency sound is not reproduced satisfactorily by small speakers, a bass-boost circuit is used to reinforce low-frequency sound. However, if the volume is turned up with bass-boost reinforcement, low-frequency sound is easily saturated which results in distortion. As shown in the diagram, the Active Hyper-Bass circuit incorporates a control circuit in which the cut-off frequency of low-frequency sound is varied in the bass-boost circuit, with the cut-off frequency controlled by instructions from a level identification circuit. With these circuits, when the volume increases, low-frequencies are sharply attenuated, which prevents distortion caused by the saturation of low frequencies.



4 Specifications

Compact disc player section

Type	: Compact disc player
Signal detection	: Non-contact optical pickup
Number of channels	: 2 channels
Frequency range	: 20 Hz – 20,000 Hz
Dynamic range	: 76 dB
Signal-to-noise ratio	: 76 dB
Total harmonic distortion	: 0.1 %
Wow & flutter	: Less than measurable limit

Radio section

Frequency ranges	: FM 87.5 – 108 MHz AM 530 – 1,710 kHz
Antennas	: Loop antenna for AM External antenna terminal for FM (75 ohms)

Tape deck section

Track system	: 4-track 2-channel stereo
Motor	: Electronic governor DC motor for capstan
Heads	: Hard permalloy head for recording/playback, 2 gap ferrite head for erasure (Combination head)
Frequency response	: 50 – 15,000 Hz (with metal tape)
Wow and flutter	: 0.16 % (WRMS)
Fast wind time	: Approx. 120 sec (C-60 cassette)

Speaker section (each unit)

Speaker (Impedance)	: 10 cm x 1 (8 Ω),
Dimensions	: 160(W) x 250(H) x 202.5(D) mm (6-5/16" x 9-7/8" x 8")
Weight	: Approx. 2.1 kg (4.6 lbs)

General



Power output	: 9 watts per channel, min. RMS, at 8 ohms from 90 Hz to 20 kHz with no more than 10 % total harmonic distortion (UX-A3J) Max. 27 W (13.5 W + 13.5 W) at 8 Ω (UX-A3C)
Output jacks	: Speaker x 2 (matching impedance 8 Ω – 16 Ω) Headphones (0 – 30 mW/32 Ω) (matching impedance 16 Ω – 1 kΩ)
Power supply	: AC 120/230 V, 50/60 Hz, (UX-A3J) AC 120 V, 60 Hz, (UX-A3C) Ext. DC 12 V (car battery via optional CA-R120 car adapter)
Power consumption	: 55 W (with POWER SW ON) 4 W (with POWER SW STANDBY)
Dimensions	: 458(W) x 258(H) x 212(D) mm (18-1/16" x 10-3/16" x 8-3/8") including knobs
Weight	: Approx. 8.7 kg (19.2 lbs)
Accessories provided	: Remote control unit (RM-RXUA3) Battery "AAA" x 2 (for the remote control) FM feeder antenna x 1 Loop antenna x 1 Speaker cord x 2

Design and specifications are subject to change without notice.

5 Instructions (Extract)

NAMES OF PARTS AND THEIR FUNCTIONS


CD player/General section



- ① POWER button
Press to switch the power on or off.
- ② REMOTE SENSOR section
- ③ Display window
 - ① Function/Track number display
 - ② RANDOM playback indicator
 - ③ Playback time display
 - ④ EDIT recording mode indicator
 - ⑤ SIDE A/B indicator
 - ⑥ Music calendar display
 - ⑦ INTRO scan indicator
 - ⑧ Repeat playback indicator
 - ⑨ PROGRAM mode indicator
 - ⑩ OVER indicator
- ④ CD door
- ⑤ Active Hyper-Bass indicator



- ⑥ Power STANDBY indicator
- ⑦ CD door OPEN/CLOSE button (▲)
- ⑧ CD operation buttons
 - PLAY/PAUSE button (▶■):
Press to play a disc and to stop temporarily.
 - STOP/CLEAR button (■):
Press to stop playing a disc and to cancel programmed playback.
This also sets the CD mode.
- ⑨ TREBLE•BASS controls
- ⑩ ACTIVE HYPER-BASS button
- ⑪ VOLUME control
- ⑫ CD search buttons (DOWN ←, UP →)
Press to locate the beginning of tunes and to start forward and reverse search operations.

Tuner/Deck section



- ① Display window
 ① Band indicator (FM/AM)
 ② Radio frequency display
 ③ MONO indicator
 ④ STEREO indicator
 ⑤ Preset station display
 ⑥ Tape direction indicator (◀, ▶)
 This indicator remains lit even in the CD and tuner modes.
 ⑦ Tape mode display
 ⑧ Recording indicator (REC)
 ⑨ DOLBY NR indicator (DOLBY NR)
- ② TUNER/BAND button
 • Press to select the tuner mode.
 • Press to select the band (FM/AM).
- ③ FM MODE button
- ④ TUNING button (UP/DOWN)
- ⑤ Cassette holder
- ⑥ REVERSE MODE switch
 ▶ : For single-side recording or playback
 ▶◀ : For both-sides recording or playback
 ▶◀◀ : For continuous play

- ⑦ DIRECTION switch
 Press to change the direction of tape travel.
- ⑧ DOLBY NR button
 Set to ON (—) when recording or playing back tapes using the noise reduction system.
- ⑨ PHONES jack (3.5 mm dia. stereo mini plug)
 Connect headphones (impedance 16 Ω - 1 kΩ) to this jack. The speakers are automatically switched off when headphones are connected.
- ⑩ Cassette operation buttons
 - REC : Press this button with the PLAY button to start recording.
 - PLAY : Press to play the tape.
 - ◀◀ : Press to fast wind the tape from right to left.
 - ▶▶ : Press to fast wind the tape from left to right.
 - ▲ STOP/EJECT: Press to stop the tape. Pressing this button after the tape stops opens the cassette holder.
 - PAUSE : Press to stop the tape temporarily. Press again to release the pause mode.
- ⑪ VOLTAGE SELECTOR (UX-A3J)

Timer/Clock section

- ① Display window
 - ① Timer mode indicator
 - ② SLEEP indicator
 - ③ Timer indicator (ON/OFF)
 - ④ Time display
- ② TIMER buttons (UP/DOWN)
Set the time or timer setting.
- ③ TIMER button
Set the timer setting or timer ON/OFF (to reset or cancel the timer).

- ④ ENTER button
Register the time or timer setting.
- ⑤ DISPLAY/CLOCK button
Set the time and current time displays.
- ⑥ SLEEP button


REMOTE CONTROL UNIT**Preparation before use**

- **Installing batteries in the remote control unit**
 1. Remove the battery cover from the back of the remote control unit.
 2. Insert two "AAA" size batteries.
 - Insert the batteries with the \oplus and \ominus terminals matching the indication inside the battery compartment.
 3. Replace the cover.
- **Battery replacement**
When the remote control operation becomes unstable or the distance from which remote control is possible becomes shorter, replace the batteries with new ones.

Using the remote control unit


To use the remote control unit, point it at the REMOTE SENSOR and press the buttons gently and firmly. Remote control operation is possible within about 7 m (approx. 23 ft). However, since the remote control range is less when the unit is used at an angle, use directly in front of the REMOTE SENSOR, as much as possible.

Do not expose the REMOTE SENSOR to strong light (direct sunlight or artificial lighting) and make sure that there are no obstacles between the REMOTE SENSOR and the remote control unit.



The following operations can be performed using the remote control unit.

- Check the functions of the operation buttons carefully and operate them correctly.



- 1 ■/CLEAR: Stop/clear button
- 2 CD ▶/■: CD mode/play/pause button
- 3 TUNER/BAND button
- 4 Track (tune) number buttons (No. 1 - No. 10, +10)
Preset station buttons (No. 1 - No. 10, +10)
- 5 SIDE A/B button
- 6 EDIT button
- 7 SHIFT button
- 8 POWER button
- 9 CD search/DOWN and UP button (◀◀, ▶▶)
 - In the CD mode, to scan to the beginning of a tune and to start forward or reverse search.
 - In the tuner mode, to tune to broadcasts.
(Also used to set the time and timer.)
- 10 CD DOOR button (▲)
- 11 VOLUME buttons
 - + : Use to increase the volume.
 - : Use to decrease the volume.
- 12 ACTIVE HYPER-BASS button
- 13 MEMORY button
- 14 CALL button
- 15 INTRO button
- 16 RANDOM button
- 17 REPEAT button

Press this button while the SHIFT button 7 is pressed.

PLAYING COMPACT DISCS



Playing an entire disc ... The following example assumes a compact disc with 12 tunes and a total playing time of 48 minutes 57 seconds.


Operate in the order shown

- ① Set to on.
- ② Set to the CD mode.
 - If the PLAY button of the deck is pressed, press the STOP/EJECT (■/△) button to set to the stop mode.
 - When a CD is first loaded, the total number of tracks (tunes) and total playing time are displayed.
- ③ Press to open the CD door.
- ④ Load a disc with the label side facing up. Press to close the CD door. (The door can be closed by pressing the ▶II button.)
- ⑤ Press to start play.
 - As tunes are played, their track numbers go out one by one.

Note:

When the CD door is closed by pressing the ▶II button, the CD starts as soon as the CD door is closed.

1

**To stop play****To stop in the middle of a disc**

During playback, press the STOP/CLEAR button to stop play.



- The total number of tracks (tunes) and total playing time are displayed.

To stop a disc temporarily

Press the PLAY/PAUSE button to stop play temporarily. When pressed again, play resumes from the point where it was paused.

Cautions:

- To change discs, press the STOP/CLEAR button; check that the disc has stopped rotating completely before unloading it.
- Since a disc cannot be unloaded when the power is set to STANDBY, switch the power on and press the OPEN/CLOSE button to unload the disc.

Notes:

- The following indication may be shown when a disc is dirty or scratched, or when the disc is loaded upside down.
In such a case, check the disc and insert again after cleaning the disc or turning it over.


- Do not use the unit at excessive high or cold temperatures. The recommended temperature range is from 5°C (41°F) to 35°C (95°F).
- After playback, unload the disc and close the CD door.
- If mistracking occurs during play, lower the volume.
- Mistracking may occur if a strong shock is applied to the unit or if it is used in a place subject to vibrations (i.e. in a car travelling on a rough road).

Skip playback

- During playback, it is possible to skip forward to the beginning of the next tune or back to the beginning of the tune being played or the previous tune; when the beginning of the required tune has been located, play starts automatically.


To listen to the next tune ...

Press the **▶▶** button once to skip to the beginning of the next tune.



To listen to the previous tune ...


Press the **◀◀** button to skip to the beginning of the tune being played back and press again to skip to the beginning of the previous tune.



Search playback

(to locate the required position on the disc)


- The required position can be located using fast-forward or reverse search while playing a disc.



- Hold down the button; search play starts slowly and then gradually increases in speed.
- Since low-volume sound (at about one quarter of the normal level) can be heard in the search mode, monitor the sound and release the button when the required position is located.

Direct access playback (using the remote control)

- Pressing any of the track number buttons will start play from the beginning of the designated tune, without having to press the CD **▶/II** button. (This function cannot be used during programmed play.)



- ① Press the **CLEARED** button to set to the CD mode.
 - If the PLAY button of the deck is pressed, press the **STOP/EJECT (■/▲)** button to set to the stop mode.
- ② Designate the required tune using the track number buttons.
 - To designate tune numbers 1 to 10, press the track number button corresponding to the tune (track) number.
 - To designate tune number 11 or higher, press the **+10** button the required number of times, then the track number button. (Example: To designate the 25th tune, press the **+10** button twice, then press track number button 5.)

* **+10** button:





Each time this button is pressed, the number increases by 10. First press this button to set the 10's digit, then press the track number button to set the 1's digit.

• To skip to another tune during play


When the required track number button is pressed, the display shows the designated track number and play starts from the beginning of the designated tune.

Programmed play (using the remote control)

- Up to 20 tunes can be programmed to be played in any required order.
- The total playing time of programmed tunes is displayed (up to 99 minutes, 59 seconds).
- (Example: When programming the 2nd tune to be played first, the 6th tune next, and then the 12th tune.)



The total playback time of programmed tunes is displayed.




- Press the ■/CLEAR button.
- Press the MEMORY button while pressing the SHIFT button to set to the programming mode.
- Press to designate the required track number.
- Designate the remaining tunes by pressing the track number buttons.
- Press the ▶/II button when programming is completed. Programmed playback starts.

To clear the programmed tunes ...

Press the ■/CLEAR button before playing a disc. During programmed playback, press this button twice. When the CD door is opened, programmed tunes are cleared automatically.

To confirm the details of a program...

Press the CALL button while pressing the SHIFT button; the tunes making up the program will be displayed in programmed order.

**Notes:**


1. If the total playing time of the programmed tunes exceeds 99 minutes 59 seconds, the total playing time indication will go out.
2. It is not possible to program more than 20 tunes.

3. When a disc with 16 or more tunes is loaded, the "OVER" indicator will appear.
4. When performing timer playback in the order of "Programmed play", step ⑤ above is not required.

Repeat play (using the remote control)

Press the REPEAT button while pressing the SHIFT button before or during play. A single tune or all the tunes can be repeated.

Whether a single tune or all tunes are to be repeated can be specified. Each time the REPEAT button is pressed while pressing the SHIFT button, the mode will change from a single tune (\curvearrowleft), to all the tunes (\curvearrowleft ALL), to the clear mode, in this order.



- Repeat playback of a single tune (\curvearrowleft)

The tune being played back will be heard repeatedly.



- Repeat playback of all tunes (\curvearrowleft ALL)

When playing back an entire disc or programmed tunes, all tunes or the programmed tunes will be heard repeatedly.

**INTRO scan operation
(using the remote control)**

- Simply press the INTRO scan button while pressing the SHIFT button to play the first 15 seconds of each tune. The operation is released after playing the introductions of all tunes or all programmed tunes.
- If the INTRO scan button is pressed in the middle of a tune while pressing the SHIFT button, the intro scan operation will start from the next tune.
- To release the intro scan mode, press the INTRO scan button again while pressing the SHIFT button and normal playback (or programmed playback) will resume.


**Random playback (using the remote control)**

Press the RANDOM button while pressing the SHIFT button, all tunes on a disc are played once, in random order.



CASSETTE PLAYBACK

Operate in the order shown




- ① Set to on.
- ② Load a cassette with side A facing out.
- ③ Select the direction of tape travel.
- ④ Select the reverse mode (\rightarrow / \leftarrow / \leftrightarrow).
- ⑤ Set the DOLBY NR switch as required.
- ⑥ Press to start playback.

- When the tape is played back with the reverse mode set to the \rightarrow (single side play) or \leftarrow (both side play) mode, the tape stops automatically at the end of tape after playing one side or both sides.

RADIO RECEPTION

Operate in the order shown



- ① Set to on.
- ② Press the TUNER/BAND button; a band and radio frequency will be shown in the display.
 - If the PLAY button of the deck is pressed, press the STOP/EJECT (\blacksquare/\triangle) to set to the stop mode.
- ③ Select the band (FM or AM).
- ④ Tune to the required station.

FM MODE button**AUTO:**

Set to this position when listening to or recording an FM stereo broadcast. The stereo indicator lights when an FM stereo broadcast is received.

MONO:


Set to this position when FM stereo reception is noisy.

- **Seek tuning**

Press the UP or DOWN button for more than one second; the unit enters the seek tuning mode and tunes to higher or lower frequencies, and when the broadcast is received, it stops tuning automatically and the broadcast can be heard.

- **Manual tuning**

Each time the UP or DOWN button is pressed, the unit steps through the current frequency band. Tuning is in steps of 100 kHz for FM and 10 kHz for AM.



Notes:

- When seek tuning to the required station is not possible because it is broadcasting too weak a signal, press the UP or DOWN button momentarily to perform manual tuning.
- When the power is set to STANDBY, or another mode (TAPE or CD) is selected, the last tuned frequency is stored in memory. When the power is switched on again and TUNER/BAND button is pressed, the same station will be heard.

Using the antennas



FM: Connect the provided FM feeder antenna (see page 8).

AM: Adjust the position of AM loop antenna.

Presetting stations (using the remote control unit)

15 stations in each band (FM and AM) can be preset as follows:

- Example (when presetting an FM station broadcasting at 103.5 MHz to preset button "15")



- ① Press the TUNER/BAND button.
- ② Select the FM band using the TUNER/BAND button.
- ③ Tune to the required station.
- ④ Press preset button "+10", then "5" for more than 2 sec. (When "15" blinks in the preset station display, the station has been preset.)


- Repeat the above procedure for each of the other stations, using a different preset button each time.
- Repeat the above procedure for the AM band.

- **To change preset stations**

Perform step ④ above after tuning to the required station.

Notes:

- The previous preset station is erased when a new station is set as the new station's frequency replaces the previous frequency in memory.
- When listening to an AM broadcast, noise may be heard if the remote control is used.
- All preset stations will be erased when the power cord is disconnected or a power failure occurs for more than 24 hours. In such cases, preset them again.


RECORDING

- In recording, the ALC circuit automatically optimizes the recording level; adjustment of the recording level is unnecessary.
- Check that the safety tab on the cassette tape is not broken off.

Notes:

This unit has recording characteristics suitable for normal and CrO₂ tapes. Normal and CrO₂ tapes have different characteristics from metal tapes.

Operate in the order shown



- ① Press to open the CD door
- ② Load a disc and press to close the CD door.
- ③ Set to the CD mode.
 - If the PLAY button of the deck is pressed, press the STOP/EJECT (■/▲) button to set to the stop mode.
- ④ Press the EDIT button once.

The tune numbers recorded on side A appear.




- ⑤ Press the SIDE A/B button.

The tune numbers recorded on side B appear.

**CD edit recording (for CDs with up to 99 tunes)**

- By checking the total playing time of the CD, a microcomputer in the unit automatically calculates the optimum length (recording time) of the tape to be used, displays the required tape length, and divides the tunes on the disc into two groups to be recorded on the two sides of the tape so as to minimize tape waste.



- ⑥ Insert a cassette with a suitable length (recording time) with side A facing out.
 - The tape length can be set from the remote control. (See below.)
- ⑦ Set to the forward direction. (The ▶ indicator lights.)
- ⑧ Set to ▶ mode.
- ⑨ Check that the pause button of the deck has been released, then press the (O) REC button and the PLAY button to start CD edit recording.
 - During edit recording, the leader tape section (approx first 12 sec.) is wound automatically and then recording starts.
 - Engage the recording mode until the end of tape of side B is reached after the CD has finished.
- **To change the tape length (recording time)**
When the EDIT button is pressed with a CD loaded, the tape length required to record the entire disc is displayed (C-46, C-54, C-60, C-74 or C-90). At this time, the displayed tape length can be changed by pressing the track number buttons.

Example: To change to C-50

Press the +10 button four times, and within 10 seconds, press the 10 button.
 When the length of the tape is changed, some of the tunes that were to be recorded on side A may be indicated as to be recorded on side B or vice versa, according to the tape length specified.
 Depending on the tape length specified, some tunes may not be recorded on the tape. Set the tape length (recording time) so that the entire disc can be recorded.

• When editing a disc with 16 to 99 tunes

CD editing can be used to record discs containing up to 99 tunes, however, the music calendar shows only up to 15 tunes.

As the 16th to 99th tunes will not appear in the program chart display (the "OVER" indicator will light), be sure to check the tunes you have recorded after completing editing.

While recording, the track number of the tune being played (and recorded) appears in the display for confirmation.

• Set the DOLBY NR as required. The [DOLBY NR] indicator lights.**Note:**

The optimum sound quality will not be obtained if different DOLBY NR switch settings are used during recording and playback.

Note:

- In CD edit recording, blanks of approx. 4 seconds will automatically be left between tunes on the recorded tape.

When automatic spacing between tunes is not required ...

Perform the following:

1. Press the ▶/II PLAY/PAUSE button of the CD player twice. The CD player enters the pause mode.
2. Press the O REC button with the PLAY button to start recording.

Note:



- Depending on the disc used, blanks of a specified length may be left between tunes.

• After use

Press the STOP/EJECT (■/▲) button to release the CD edit recording mode. (The CD edit recording mode is also released when the CD door is opened.)

Synchronized recording with the CD player

- In this system, the CD player starts playback when the cassette deck enters the recording mode.


Operate in the order shown

- ① Load a disc and close the CD door.
- ② Set to the CD mode.
 - If the PLAY button of the deck is pressed, press the STOP/EJECT (■/▲) button to set to the stop mode.
- ③ Load a cassette with side A facing out. (Wind past the leader tape before starting recording.)
- ④ When programmed playback is required, program the required tunes using the remote control. (See page 27.)
 - Select tunes with a total playing time which does not exceed the tape length.
- ⑤ Set to the forward direction. (The ▶ indicator lights.)
- ⑥ Select the required reverse mode (→ or ←).
- ⑦ Press the O REC button with the PLAY button; synchronized recording will start.


- Non-recorded sections of approx. 4 seconds are automatically left between tunes.
- To stop recording in the middle of a tape, press the STOP/EJECT (■/▲) button of the cassette deck.
- CD complete recording function (synchro recording mode only)**
If the tape is reversed while a CD is being played, recording will be done on the reverse side of the tape as follows:
 - * When less than 10 seconds of the last tune on the forward side of the tape have been recorded, recording on the other side of the tape will start from the beginning of the previous tune.
 - * When more than 10 seconds of the last tune on the forward side of the tape have been recorded, recording on the other side of the tape will start from the beginning of the current tune.

Note:

- During CD edit recording and synchro recording, the SEARCH button does not function.

Recording from the radio**Operate in the order shown**

- Load a cassette with side A facing out.
(Wind past the leader tape before starting recording.)
- Set to the forward direction. (The ▶ indicator lights.)
- Select the required reverse mode (◀ or ▶).
- Press the TUNER/BAND button. Tune to the required station.
- Press the O REC button with the PLAY button.
 - The function switch is locked and its position cannot be changed.



- To stop recording temporarily, press the ■ PAUSE button. To resume recording, press the ■ PAUSE button again.

Note:

The CD door cannot be opened or closed during radio recording.

Erasing

When recording on a pre-recorded tape, the previous recording is automatically erased and only the new material can be heard when the tape is played.

To erase a tape without making a new recording...


Press the PLAY button of the deck to set to the TAPE mode and press the O REC and PLAY buttons together after pressing the stop button.

It should be noted that it may be unlawful to re-record pre-recorded tapes, records, or discs without the consent of the owner of copyright in the sound or video recording, broadcast or cable programme and in any literary, dramatic, musical, or artistic work embodied therein.

CLOCK ADJUSTMENT

Setting the current time (when the UX-A3 is used for the first time)

(Example: to set the clock to PM 1:15.)



- ① Connect the AC power cord; "AM 12:00" will blink in the display.
 - Set to the standby mode; do not press the POWER button.
 - ② Press the DISPLAY/CLOCK button for 2 sec. or more: the hour's digits will blink.
 - ③ Set to PM 1:00 by pressing the TIMER buttons (UP/DOWN).
 - ④ Press the ENTER button; the minute's digits will blink.
 - ⑤ Set to PM 1:15 by pressing the TIMER buttons (UP/DOWN).
 - ⑥ Press the ENTER button; the time will light continuously in the display.
- Each time the hour's digits change from 11 to 12, the display alternates between AM and PM. (12 midnight is indicated as "AM 12:00" and 12 noon is indicated as "PM 12:00".)
 - To set to the nearest second...
Press the ENTER button when you hear the time signal from a TV or radio.

Notes:

- Before performing timer recording or playback, it is necessary to set the current time.
- It is recommended to set the current time with the power switch set to STANDBY so that the current display mode is maintained.
- When the power cord is plugged in again after being disconnected or power is restored after a power failure, clock display will blink or light in the display. Reset the current time.
- Press the DISPLAY/CLOCK to display the current time during CD play, tape play or radio reception. The current time will be displayed for 10 sec. after which the display returns to the previous mode.

TIMER OPERATIONS

Timer recording

- The current time must be set correctly before you set timer recording.
- Make sure that the erase protection tabs of the cassette have not been broken off.

Operations

1. Set the POWER button to ON.
2. Load a cassette.
 - Insert the cassette with the side to be recorded facing out.
 - Set the DIRECTION switch to the forward direction. (The \blacktriangleright indicator lights.)
 - Set the reverse mode button to " \square " or " $\square\triangleleft$ " and set the DOLBY NR button as required.
3. Set the timer start and stop times, then set the required volume, in this order. (Refer to "Setting the timer" on page 47.)
 - Set the timer about a minute before the broadcast to be recorded is scheduled to start.
4. Press the TUNER/BAND button.
 - Tune to the station to be recorded. (Refer to page 33.)
5. Set the POWER button to STANDBY.
6. Press the (O) REC and PLAY buttons of the deck simultaneously.
 - If the DIRECTION switch is pressed before the (O) REC and PLAY buttons are pressed, the (O) REC and PLAY buttons cannot be pressed.

Note:

Timer recording will start at the preset time, the power will not be switched off at the timer-off time during tape operation, but it will be switched off when the tape ends. However, the power cannot be switched off when the reverse mode is set to " $\square\triangleleft$ " or the deck is set in pause mode.

- When timer recording is completed, the timer mode is switched to the "TUNER" (timer reception of broadcast) mode.

To cancel timer operation

Press the TIMER button so that the timer mode indicator (\odot) goes out.

If you do this, timer recording will not start at the timer start time.

Notes:


Once the timer has been set, the start and stop times, etc., are stored in memory. When timer recording or playback is required at different times, the timer must be set again.

- After setting the timer start and stop times, check that the unit is tuned to the required frequency.
- When the power cord is disconnected or there is a power failure, timer settings will be erased from memory. If this happens, set the current time and perform the timer setting again.

Setting the timer

- The current time must be set before the timer can be used.


- ① Press the TIMER button.




- ② Set the start time.

(Example: when the timer start time is set to PM 12:15.)

- ① Adjust the hours.




- ② Adjust the minutes.




- ③ Set the stop time

(Example: when the timer stop time is set to PM 1:15.)

- ① Adjust the hours.





② Adjust the minutes.



- Press to set the timer off time.


④ Set the volume.



- The selected volume is set.

The playback level is determined by the position of VOLUME control.

When the UP button is used to select the volume.



The volume decreases to zero at the timer start time, and the sound fades in. (Volume level 5 is approximately the same as when the VOLUME control is set to its center position.)

- The unit enters the previously engaged mode and timer setting is complete.

● To check the timer setting

1. Press the TIMER button.
2. Press the ENTER button to check the timer mode.
3. When the previously engaged mode is displayed, timer setting has been completed.

Notes:

- When the timer is set incorrectly, perform "Setting the timer" from the beginning.
- When the timer is set, "-:-" in the display is replaced by the input digits.
- When the timer stop time is not set, the timer operates for 2 hours and then the unit is switched off. When the timer is already set, display the timer stop time, change the hours digits to "-:" using the UP button and press the ENTER button.

Timer playback


- Timer playback of tapes, broadcasts and CDs is possible.

Operations

- ① Set the POWER switch to ON.
- ② Set the timer start and stop times, then set the volume, in this order. (Refer to "Setting the timer" on page 47.)
- ③ Select the source sound.

Source sound	Timer mode	Operations
CD play	CD	Load a disc and press the ■ STOP/CLEAR button to set the CD mode.
Tape playback	TAPE	Load a cassette tape and select the tape travel direction.
Radio broadcast	TUNER	Press the TUNER/BAND button to set to the tuner mode and tune to the required frequency.

- Timer playback of a CD is possible in programmed order. (See page 27.)
- The volume can be set to 5 different levels.
- Tune to the required frequency when timer playback of a radio broadcast is to be performed.
- Volume setting and fade-in operation



- When the power is switched on, it is possible to fade in the sound from volume level 0 (zero) to the preset volume.

- ④ Switch the power off.

(When performing the timer playback of tape, press the PLAY button of the deck. Do not press the DIRECTION switch before pressing the PLAY button.)

- Timer playback will start at the timer start time and the power will be switched off at the timer stop time. (Tuner or CD)
The power will not be switched off at the specified time during tape operation and will be switched off at the tape end. However, the power will not be switched off when the reverse mode is set to "CD" or the deck is set to the pause mode.
The unit remains in the same timer mode even after the power is switched off and the same timer function will be repeated at the same time on the following day.

To cancel timer operation

Press the TIMER button so that the timer mode indicator (⌚) disappears. (To set to the timer mode again, press the TIMER button twice so that the timer mode indicator (⌚) appears.)

Notes:

- When the volume setting is set to "Vol -" (volume level is not specified), the timer playback volume is set to that of before setting the timer.
- To stop during timer playback, press the POWER button to switch the unit off.
- In the fade-in mode, the volume gradually increases from zero.


SLEEP OPERATIONS

Use this when you want to fall asleep while listening to a tape, radio broadcast or CD.

- ① Set to the required source.

	Operations
Radio broadcast	Press the TUNER/BAND button to set to the tuner mode and tune to the required frequency.
CD play	Load a disc and press the ▶■■ button to play the disc.
Tape playback	Load a cassette and press the PLAY button to play back the tape.

- ② Press the SLEEP button to set to the sleep time.



30 → 60 → 90 → 120 ↗

Source mode display (Releasing the sleep mode)


- Sleep times of 30, 60, 90 or 120 minutes can be set. When you release the SLEEP button, the source is displayed after 10 sec.
- The sleep operation will start and the power will be switched off after the specified time. (Tuner & CD modes)
The power will not be switched off at the specified time during tape operation and will be switched off at the tape end. However, the power will not be switched off when the reverse mode is set to " ↲ " or the deck is set to the pause mode.
- **Checking the sleep time**
When the SLEEP button is pressed, the remaining sleep time is displayed. If it is pressed again, a new sleep time can be set.
- **To cancel the sleep operation**
Press the POWER button to switch the power off.

CONNECTIONS

- Do not switch the power on until all connections are complete.


Antenna connection and adjustment

- AM loop antenna adjustment



- Keep the loop antenna away from the rear panel of the unit and install it so that the best reception is obtained. (Do not leave the antenna wire in a bundle.)

- FM antenna connections and adjustments




Notes:



- Do not place the loop antenna on a metal desk or near a TV or personal computer.
- Installing an outdoor antenna requires experience; we recommend that you consult an audio dealer.
- Install the antenna cord away from the power and speaker cords as these could generate noise. Install the loop antenna so that it does not touch the rear of the unit.
- Use an outdoor antenna when stable reception cannot be obtained with the provided antenna.

Speaker cord connection

- Use the speaker cords provided to connect the deck/amp and speakers.




Deck/amp unit




Left speaker (rear side)

- Connect the cord from the speaker on the left to the (L) terminals and the cord from the speaker on the right to the (R) terminals.




Speaker cord provided

Right speaker (rear side)




Connect the cord marked with a white line to the (-) terminal.

- The speaker grilles can be removed.
 - When removing (the example shows the left speaker).
 - Insert your fingers at the top and pull towards you.
 - Also pull the bottom towards you.



- Attaching the speaker grille




Match the fittings when attaching the grille.

Notes:


- The polarity with which the two speakers are connected will be the same if the speaker cords marked with a white line are connected to the (-) terminals. If the speakers are connected with reverse polarity, the stereo effect and tone will be degraded.
- The speakers of this unit are not magnetically shielded. When they are placed directly on or adjacent to a TV, the TV's color could be distorted. Install the speakers more than 10 cm away from your TV.
- If the speakers are to be placed away from the main unit, purchase optional speaker cords from an audio store.

System connection


- Connect the flat cable connected to the CD/tuner unit to the deck/amp unit.



- When connecting




- When disconnecting




POWER SUPPLY

A. Connection of AC power cord

- Connect the AC power cord after all other connections have been made.



B. Operation on car battery (DC 12 V)



- First connect the car adapter to the DC IN 12 V jack, not the cigarette lighter socket, because shorting of a plug on the car may cause the fuse to blow out. In addition, be careful not to make a short-circuit between the plugs.
- When using a car battery, be sure to use the specified car adapter (JVC model CA-R120) to prevent mishaps or damage resulting from different polarity design.

Notes:

- When there is a power failure or the AC power cord is disconnected, the timer/clock setting is erased from memory. Reset the clock when the power supply is restored.
- Do not block the ventilation holes of the deck/amp unit so that heat can escape. Do not install the unit in a badly ventilated place.

6 Location of Main Parts

■ Tape Deck • Amplifier Sections




Fig. 6-1




Fig. 6-2

■ CD • Receiver Sections




Fig. 6-3




Fig. 6-4

7 Removal of Main Parts and Parts List

1 2 3 4 5

■ Tape Deck • Amplifier Section (1/2)

BLOCK NO. M1MM




Fig. 7-1

• Tape Deck • Amplifier Section (1/2) Parts List

BLOCK NO. M1MM 111

REF.	PARTS NO.	PARTS NAME	REMARKS	QTY	SUFFIX	CLR
A 1 2 3	ZCUXDA3K-CLB ZCUXDA3K-CH VJC2412-002 SDST3008M VJG1125-012UL	C.DOR ASSY C.HOLDER ASSY TOP COVER SCREW REAR PANEL(D)	REF.27,28,29 REF.23,24 TOP COVER SIDE MIPS	1 1 1 4 1		
4 5	QMP1340-200 SDST3010N	POWER CORD SCREW	AC P. CORD FOR REAR	1 2		
6 7	SDST3010N VYN9189-5121 SBSF3008Z	SCREW NAME PLATE SCREW	TOP COVER REAR REAR MECHA+F.PANEL	2 1 2		
8 9 10 11 12	SDSF2606Z VKL6107-002 VYH7695-001 VKS4965-001 VXP3517-007	SCREW BUTTON BRACKET P.W.B HOLDER BUTTON LEVER BUTTON(REC)	BUTTON BKT POM	4 1 1 6 1		
13 14 15 16 17	VXP3517-008 VXP3517-009 VXP3517-010 VXP3517-011 VXP3517-012	BUTTON(PLAY) BUTTON(REW) BUTTON(FF) BUUTON(STP/EJT) BUTTON(PAUSE)		1 1 1 1 1		
19 20 21 23 24	VJG1124-012UL VXP5134-001 SBST3006Z VKY4180-001 VJT2304-001	FRONT PANEL(D) PUSH BUTTON SCREW CASSETTE SPRING CASSETTE HOLDER	#F DOOR HOLDER ABS	1 1 2 2 1		
25 26 27 28 29	VKW5023-003 VYH5601-001 VJT2305-001 E406971-222 VJT4197-001	DOOR SPRING GEAR DOOR COVER JVC MARK DOOR LENS	SUS T1 J.MARK L=23.5 PVC T0.5 SX2	1 1 1 1 1		
30 31 32 33	VJC3237-001 SBST3006Z SBST3006Z SBST3006Z SBSF3010Z	BOTTOM COVER SCREW SCREW SCREW SCREW	EGC T0.8 TRANS BKT TRANS BKT DOOR HOLDER	1 2 2 2 1		
34	VJF4003-003	FOOT		2		




Fig. 7-2




Fig. 7-3




Fig. 7-4




Fig. 7-5

■ Tape deck and amplifier section

- **Metal Cover ①**

Remove the six screws ② ⑤ retaining the metal cover ①.

- **Tape deck and power supply section**

1. Detach the P.C. board ⑩ holder.
2. Remove the two screws ②1 retaining the front panel, the bottom cover ③0 and the jack holder together.
3. Disconnect the 5-pin connector protruding from connector JW6 on the head amplifier P.C. board installed on the cassette mechanism from the power supply P.C. board connector CN-353.
4. Disconnect the 6-pin and 5-pin connectors from connector CNA02 and connector CN501 of the head amplifier P.C. board installed on the back of the cassette mechanism that protrude from the connectors on the mechanism control P.C. board connector CNA02 and power supply P.C. board connectors JW5 and JW4 on the rear panel of the cassette mechanism.
5. Disassemble the power supply section and the deck section from each other.

■ Cassette Mechanism

1. Disconnect the 7-pin connector protruding from the head from the mechanism control P.C. board connector CNA01.
2. Disconnect mechanism control P.C. board connector CNA03 from head amplifier P.C. board connector CN503.
3. Remove the four screws ⑦ and ⑬ retaining the cassette mechanism.
4. Remove from the knob of the door holder. At the same time, also disconnect connector CN505 of the head amplifier P.C. board and connector CNA05 the power supply switch/headphone jack P.C. board. Move the head amplifier P.C. board to the left.

- **Front panel ⑯**

Remove four screws ⑧ retaining the button bracket ⑨ from the front panel.

- **Rear panel ③**

1. Remove the two screws ⑤ retaining the rear panel ③ from the bottom cover ③0 .
2. Place the power cord ④ off the groove of the rear panel and take out the rear panel.

1 2 3 4 5

■ Tape Deck • Amplifier Section (2/2)

BLOCK NO. M2MM




Fig. 7-6


(No. 1860) 32

• Tape Deck • Amplifier Section (2/2) Parts List

BLOCK NO. M2MM 1111

5

A	REF.	PARTS NO.	PARTS NAME	REMARKS	Q.T.Y	SUFFIX	CLR
	40	SBST3008Z	SCREW	JACK HOLDER+PCB	1		
	41	VMA4528-002	BARRIER	FUSE PCB	1		
	43	QHS3876-162	S.R.BUSHING	POWER CORD	1		
	44	VYH3658-002	TRANS BRACKET	EGC T1	1		
	45	VYH7698-002	JACK HOLDER	EGC T1	1		
	46	SBST3008Z	SCREW	JACK H+TRANS.H	2		
	47	SSSF3008Z	SCREW	JACK HOLDER	1		
	48	VYH7709-001	RADIATION	AL T3	1		
	49	SSST3008Z	SCREW	RADI+T.BKT	2		
	50	SDST3012Z	SCREW		2		
	51	SDST2608Z	SCREW	IC+IC HOLDER	2		
	52	VYH7708-002	IC HOLDER	SPTE TO.5	1		
	53	VTP66T2-12B	POWER TRANSF.		1	A	
		VTP66Z2-12F	POWER TRANSF.		1	J , C	
		VTP66Z2-12G	POWER TRANSF.		1	U	
	54	SBST4006Z	SCREW	TRANS	4		
	55	VMA4553-002	SHIELD PLATE		1		
	56	VYSH105-033	SPACER	12X20 T5 FOR 4	1		
	57	SDST3004Z	SCREW	SHIELD+T.BKT	1		
	58	VYH7696-001	JACK STOPPER	ABS FOR DC JACK	1		
	59	SBSF3008Z	SCREW	JACK HOLDER	1		
	60	VMA4556-001	INSULATOR	PRE PCB	1		
	61	SBST3006Z	SCREW	PRE PCB+BKT	1		
	62	VXQ4112-001	MODE LEVER	ABS	1		
	63	VYH3740-002	MECHA BRACKET	EGC T1	1		
	64	SDST2004Z	SCREW	M.BKT+MECHA	2		
	65	SDST2606Z	SCREW	COLLAR	1		
	66	VKW5022-002	SPRING	SUS	1		
	67	VYH5833-002	COLLAR		1		
	68	VXS3037-001	DIRECTION LEVER	ABS	1		
	69	VYH3736-001	DOOR HOLDER	EGC T1	1		
	70	SBST3006Z	SCREW	MECHA+D.HOLDER	2		
	71	VYH7694-001	REC LEVER	EGC T1	1		
	72	VMA4560-001	SHIELD		1		
	73	VYSS1R5-059	SPACER		1		






Fig. 7-7




Fig. 7-8




Fig. 7-9




Fig. 7-10

• **Radiation 48**

1. Remove the screws 49 and 50 retaining the radiation 48.

• **Jack holder 45 and speaker terminal P.C. board**

1. Remove the screws 47 retaining the speaker terminal P.C. board from the jack holder 45.
2. Disconnect connector CN353 and CN351 connecting the speaker terminal P.C. board and the power amplifier P.C. board.

• **Power trans 53 and trans bracket 44**

1. Remove the four screws 54 retaining the power supply transformer 53 from the transformer bracket 44.
2. Remove the four screws 49 and 50 retaining the heat sink 48 from the transformer bracket and the power IC.

• **Mechacon P.C. board and pre-amplifier P.C. board**

1. Disconnect the connector CNA03 on the pre-amplifier P.C. board from the connector CN503 on the mechacon P.C. board.
2. Disconnect the mechacon P.C. Board from the cassette mechanism.




Fig. 7-11




Fig. 7-12

• CD • Receiver Section (1/2) Parts List

BLOCK NO. M3MM □□□

REF.	PARTS NO.	PARTS NAME	REMARKS	QTY	SUFFIX	CLR
	79 VYH7707-001 80 VJT3311-004 81 VJT2306-003 82 VYH7677-001 83 VYH7313-001R	WIRE HOLDER CD DOOR LENS CD DOOR YOKE MAGNET	PMMA T3 S*3 EGC T0.8 FB3B	1 1 1 1 1		
	84 VYH3726-001 86 VJD1149-004UL 87 SBSF3010Z 88 SBSF3010Z 89 SBSF3006Z	CLAMPER CD CASE SCREW SCREW SCREW	ABS SW PWB+CD CASE	1 1 1 1 1		
	90 MXN-13FB12F 91 VYH7699-001 92 SPSP3004Z 93 VYH3659-001 94 SBSF3010Z	DC MOTOR ASS'Y PULLEY SCREW GEAR BRACKET SCREW	CASSETTE DOOR MOTOR MOTOR+GEAR BKT ABS T2.5 CD CASE+GEAR BK	1 1 2 1 2		
	95 VKZ4001-110 96 VYH7358-001 97 VYH7357-001 98 VYH7356-002 99 VKB3000-144	WIRE CLAMP GEAR(B) GEAR(A) PULLEY BELT	POM POM	2 1 1 1 1		
	100 GBSF3006Z 101 SDST2006M 102 VJD5318-002 103 E75609-002 104 E75609-001	SCREW SCREW PICK COVER INSULATOR INSULATOR	PULLEY+GEAR BKT CD MECHA+P.COVE	1 3 1 1 2		
	105 VYH7297-102 106 SBSF3010Z 107 VND4285-001 108 VJG1137-012UL 109 SBSF3008N	HOLDER SCREW DHHS LABEL REAR PANEL(T) T.SCREW	HOLDER+CD CASE METAL COVER	1 2 1 1 1		
	111 SBSF3008N 112 SDSF3008Z 113 VJC2411-003 114 SDST3006M 115 SBSF3008N	T.SCREW SCREW METAL COVER SCREW T.SCREW	CD+CHASSIS UNIT	1 2 1 4 1		
	116 VJF4003-003 117 SDSF2606Z 118 SBSF3010Z 119 VMA4502-004 120 VYN9189-101	FOOT SCREW SCREW SHIELD SHEET NAME PLATE	CD AMP PWB+CD	4 1 4 1 1		




Fig. 7-13




Fig. 7-14

■ CD and receiver sections

• Metal cover 112

Remove the five screws 113 and 114 retaining the metal cover 112.

• Rear Panel 108

1. Remove the two screws 109 retaining the rear panel 108.

2. As shown in the figure, use a flat-tipped screwdriver and remove the left and right knobs at four places on the chassis 143 that retains the rear panel 108.

• CD player section

1. Remove the two screws 111 retaining the CD player section from the left and right of the chassis 143.

2. Remove the left and right protrusions retaining the CD player section from the chassis, and take out the CD section.

3. Disconnect the card wire protruding from connector CN504 of the CD control P.C. board (board 4F) from connector CNM06 of the microcomputer/LCD display P.C. board (board 3F).

4. Disconnect the 5-pin parallel wire protruding from JW501 of P.C. board 4F from connector CNM05 of P.C. board 3F.

5. Disconnect the connectors protruding at two places of the switch P.C. board retaining the CD case from connector CNM04 of P.C. board 3F.

6. Remove the three screws 117 retaining the CD control P.C. board

7. Remove the connectors protruding at three places on the CD mechanism from connectors CN502, CN503 and CN501 on the CD control P.C. board.

• CD case 86

Remove the screws 87 and 89 retaining the switch P.C. board at two places from the CD case 86.

• Front panel section

1. As shown in the figure, use a flat-tipped screwdriver and remove the left and right knobs at four places that retain the front panel assembly.

2. Remove the screw 116 retaining the lug wire protruding from the front panel assembly from P.C. board 3F.

3. Disconnect the 7-pin connector and 2-pin connector protruding from the front panel assembly from connectors CNM01 and CNM-7 of P.C. board 3F.




Fig. 7-15

1 2 3 4 5

■ CD • Receiver Section (2/2)

BLOCK NO. M4MM




Fig. 7-16

• CD • Receiver Section (2/2) Parts List

BLOCK NO. M4MM □□□

5

▲ REF.	PARTS NO.	PARTS NAME	REMARKS	QTY	SUFFIX	CLR	
	C 124	ZCUXRA3A-FB ZCUXRA3C-FB ZCUXRA3J-FB ZCUXRA3U-FB VJT4196-001	FRONT CABINET FRONT CABINET FRONT CABINET FRONT CABINET LCD LENS	PVC TO.5 S*3	1 1 1 1 1	A C J U	
	125 126 127 128 129	VXL4374-002 VXL4375-004 E406971-222 VJG1123-012UL VXP5132-001	KNOB VOLUME KNOB JVC MARK FRONT PANEL(T) BUTTON(L)	22.5W	2 1 1 1 1		
	130 131 132 133 134	VXP5133-001 VXP5131-002 VXP3418-002 SBSF2610Z VYH7348-002	BUTTON BUTTON(R) PUSH KNOB SCREW VOLUME BRACKET	F.PWB+F.PANEL FRONT PWB	1 1 1 7 1		
	135 136 137 138 139	SBSF2610Z VCCV1001-101 VYTT608-002 VYH3734-002 SBST3006Z	SCREW VR WITH MOTOR LCD FILTER LAMP CASE SCREW	VOLUME BKT+PANE VRVO1 SPTE TO.4 CPU PWB+CHASSIS	1 1 1 1 3		
	140 141 142 143 144	SBST3006Z SBST3006Z VMP0092-001 VYH2269-001 VMA4486-001	SCREW SCREW SYSTEM WIRE ASY CHASSIS SHIELD CASE	TU PWB+CHASSIS FUNC PWB+CHASSI JWF01 EGC TO.8	2 2 1 1 1		
	145 146 147	VYH7734-001 VGL1122-001 EMV7130-017	HEAT SINC LCD WIRE HOLDER	LCM01 SYSTEM WIRE	1 1 1		




Fig. 7-17




Fig. 7-18




Fig. 7-19

• Front panel assembly

1. Disconnect the 5-pin connector protruding from connector JW304 of P.C. board 1F from connector CNV01 of the electric volume control P.C. board.
2. Remove the volume knob.
3. Remove the nut retaining the electric volume control from the front panel assembly.
4. Disconnect the 8-pin connector protruding from connector JWF02 of P.C. board 1F from connector CNT01 of the BASS/TREBLE P.C. board.
5. Remove the screw 135 retaining the BASS/TREBLE volume control P.C. board from the front panel assembly. Remove the BASS/TREBLE knob from the front panel assembly. When replacing the BASS/TREBLE volume control knob, remove the nut retaining the volume control from the volume control bracket 134.

• Operation switch board

Remove the seven screws 133 retaining the operation switch P.C. board.

• 3F P.C. board

1. PROOF Remove the two screws 139 retaining P.C. board 3F from the chassis 143.
2. Disconnect the card wire protruding from connectors CNF02 and CNF01 from connectors CNM03 and CNM02 of P.C. board 3F.

• 2F P.C. board

1. Remove the three screws 140 retaining P.C. board 2F from the chassis 143.
2. Disconnect the 10-pin connector protruding from connector CN1 of P.C. board 2F from connector CNF03.

• 1F P.C. board

Remove the two screws 141 retaining P.C. board 1F from the chassis.

1 2 3 4 5

■ Cassette mechanism Section

BLOCK NO. M5MM




Fig. 7-20

■ Cassette Mechanism Parts List

BLOCK NO. M5MM □□□

▲	REF.	PARTS NO.	PARTS NAME	REMARKS	QTY	SUFFIX	CLR
	A	186509369T	MOTOR ASSY	REF.110,111	1		
	1	186502502T	HEAD PANEL ASSY		1		
	2	18650218T	CHP LEVER		1		
	3	18651441T	E KICK STOPPER		1		
	4	18650211T	SPRING		1		
	5	186502315T	H.BASE ASS'Y		1		
	6	94800000T	LUG		1		
	8	62020605T	HEAD		1		
	9	18650129T	REC S.LEVER (F)		1		
	10	18650130T	REC S.LEVER(R1)		1		
	11	18650131T	REC S.LEVER(R2)		1		
	12	186505502T	T.R.PLATE (R)		1		
	13	186505501T	T.R.PLATE (F)		1		
	14	186505312T	T. ROLLER ASS'Y		2		
	15	186504306T	P.R.ARM(R)ASS'Y		1		
	16	18650228T	COLLAR		2		
	18	186509315T	F.L.M.(R)ASS'Y		1		
	19	186504307T	P.R.ARM(F)ASS'Y		1		
	20	18650420T	P.ROLL.SPRING		1		
	21	18650910T	FLYWHEEL METAL		1		
	22	18650546T	SPRING(F)		1		
	23	18650547T	SPRING(R)		1		
	24	18652205T	CONTROL LEVER		1		
	25	186505310T	REEL ASS'Y (R)		1		
	28	186505311T	REEL ASS'Y (F)		1		
	29	18650532T	SPRING		1		
	30	18651401T	MAIN BASE		1		
	31	18650258T	SPRING		1		
	32	18651471T	SPRING		1		
	33	640101129T	LEAF SWITCH	FOR CLAMP BOTOM LEVER	2		
	34	18651432T	SPRING	BUTTON LEVER	1		
	35	18651455T	SPRING	BUTTON LEVER	1		
	37	18650102T	PACK SPRING		1		
	38	18650120T	FF GEAR		1		
	39	18650421T	SPRING		1		
	40	18650422T	SPRING	P.ARM	1		
	41	18651301T	SLIDE LEVER		1		
	42	18651302T	COLLAR		2		
	43	18651309T	SPRING		1		
	44	186501508ZT	CHASSIS ASS'Y		1		
	45	18652232T	CH SLIDE LEVER		1		
	46	18652236T	SPRING		1		
	47	18652240T	CH COLLAR A		1		
	48	18652241T	CH COLLAR B		1		
	49	18652227T	REC S.LEVER		1		
	50	18651429T	PC STOPPER		1		
	51	186514504ZT	PUSH BUT.ACT.AS		1		
	52	18651463T	SPRING		1		
	53	18651407T	SWITCH CAM		1		
	54	18651428T	RWD LEVER		1		
	55	18651453T	LEVER	REC.BUTTON	1		
	56	18651466T	PLAY BUT.LEVER		1		
	57	18651418T	BUTTON LEVER	REWIND	1		
	58	18651419T	BUTTON LEVER	FF	1		

BLOCK NO. M5MM

A	REF.	PARTS NO.	PARTS NAME	REMARKS	QTY	SUFFIX	CLR
	59	18651420T	BUTTON LEVER	STOP	1		
	60	186514501T	PAUSE BUT.LEVER		1		
	61	18210115T	PAUSE LEVER		1		
	62	18210116T	LEVER SPRING		1		
	63	18210134T	PAUSE STOPPER		1		
	64	18652237T	MODE LEVER		1		
	65	18652261T	SENSING PLATE		1		
	67	18651121T	COLLAR SCREW		5		
	68	186507304T	RF CLUTCH ASS'Y		1		
	69	18001143T	SPRING		1		
	70	18650712T	BELT		1		
	71	18652104T	LIFT SPRING		1		
	72	186521504T	LIFT ARM ASS'Y		1		
	73	18652119T	SPRING		1		
	74	186521503T	M TRIG.ARM(A)AS		1		
	75	18652121T	M GEAR		1		
	76	18652118T	SPRING		1		
	77	18652113T	M TRIG. ARM B		1		
	78	18652259T	CH GEAR		1		
	79	18651701T	P GEAR		1		
	80	18651708T	SPRING		1		
	81	18651604T	COLLAR		1		
	82	186517502T	P TRIG.ARM ASSY		1		
	83	18651709T	RF TRIGGER ARM		1		
	84	18651710T	RF COLLAR		1		
	85	186517501T	P ACT. ARM ASSY		1		
	86	17001613T	SPRING		1		
	87	186511503T	C.GEAR PL. ASSY		1		
	88	18651113T	SPRING		1		
	89	18651112T	SPRING		1		
	90	18651102T	CAM GEAR		1		
	91	18651123T	BELT		1		
	92	18651124T	BELT		1		
	93	18651109T	RF LEVER		1		
	94	18651103T	SENSING PLATE		1		
	95	18651114T	CONTROL LEVER		1		
	96	18651111T	SPRING		1		
	97	18652231T	STOP LEVER		1		
	98	18652229T	FUNCTION		1		
	99	18652235T	SPRING	DOBLE SLIDED	1		
	100	186509359T	CAPSTAN ASS'Y		1		
	101	186509353T	FL GEAR CAP.ASY		1		
	102	18650985T	MAIN BELT		1		
	104	640101114T	LEAF SWITCH		1		
	106	18211280T	SCREW		3		
	107	18201306T	RUBBER CUSHION		3		
	108	18650950T	MOTOR BRACKET		1		
	109	18650233T	RELAY B.PLATE		1		
	110	18650990T	MOTOR PULLEY		1		
	111	MMI-6S2LK	MOTOR	MMI-6S2LK	1		
	112	18650141T	SELECT SW BKT		1		
	113	MSW1432NBKU	LEAF SW		1		
	115	18200917T	BRAKE RUBBER		2		
	116	18651601T	BRAKE ARM		1		

BLOCK NO. M5MM

REF.	PARTS NO.	PARTS NAME	REMARKS	QTY	SUFFIX	CLR
117	18651602T	SPRING		1		
118	18651604T	COLLAR	BRAKE ARM	1		
120	18652115T	SPRING		1		
121	18652226T	REC C.LEVER		1		
122	18652263T	SPRING		1		
123	18652228T	M KICK LEVER		1		
124	18652239T	COLLAR		1		
125	18652266T	COLLAR		1		
126	18400245T	SPRING		1		
127	186522505T	CH LEVER(H)ASSY		1		
128	18652246T	SPRING		1		
129	18652244T	CH LEVER(J)		1		
130	18521711T	SPRING		1		
131	18652245T	CH LEVER(K)		1		
132	18652247T	SPRING		1		
133	18650965T	CORD CLAMPER		1		
134	18651115T	TORSION SPRING		1		
135	18652253T	M SWITCH LEVER		1		
136	18652254T	M SW.LEV.COLLAR		1		
137	18652255T	M SW.LEV.SPRING		1		
138	18650136T	TORSION SP.		1		
139	18650137T	TORSION SPRING		1		
200	90760000T	SCREW	2X3	2		
202	90780000T	ASS'Y SCREW	2X5	1		
203	90860000T	SCREW	2X7	1		
205	91790000T	TAPPING SCREW		1		
206	91810000T	SCREW		2		
207	91780000T	SCREW		1		
210	92190000T	CAP SCREW		1		
212	91150000T	SCREW(M2 X 3)		1		
215	95470000T	SCREW		2		
216	95610000T	MINI SCREW	2X3.5	1		
217	99760000T	CAMERA SCREW	2X5.5	1		
218	98250000T	MINI SCREW	2X5.5	1		
219	95600000T	SPECIAL SCREW	2X4.5	1		
220	99870000T	MINI SCREW	2X8	2		
222	99991802T	SPECIAL SCREW		2		
224	98090000T	CAMERA SCREW	2X3.5	2		
225	98980000T	MINI SCREW	2X8.5	6		
227	99991808T	TH TAP SCREW	2X3.5	1		
228	99991807T	CAMERA SCREW	2.3X5	1		
230	96740000T	TAPPING SCREW	2X6	4		
233	99992001T	CAP SCREW	2X6	2		
235	REE2000X	E.RING	S2.0	5		
236	REE1500X	E.RING	S1.5	1		
237	REE1500X	E.RING	S1.5(BLACK)	2		
238	94970000T	E.RING	S1.5	1		
240	97440000T	P.WASHER	2.1X5X0.4	2		
241	94210000T	P.WASHER	1.2X3X0.25	4		
242	98830000T	P.WASHER	2X3.5X0.2	1		
243	97870000T	P.WASHER	1.55X5X0.5	1		
244	99990011T	WASHER	2.2X3.8X0.13	1		
245	99990308T	POLY. WASHER	1.85X5X0.5	1		
246	97130000T	U WASHER		2		

■ CD Mechanism Section

BLOCK NO. M6MM

A

B

C

D




Fig. 7-21

■ CD Mechanism Parts List

BLOCK NO. M6MM

△	REF.	PARTS NO.	PARTS NAME	REMARKS	QTY	SUFFIX	CLR
	1	E26487-003	C.D. MECHA BASE		1		
	2	OPTIMA-5S	OPTICAL PICK-UP		1		
	3	E74930-003	GUIDE SHAFT		1		
	4	E306282-001	CD RACK		1		
	5	SPSH2050M	SCREW		1		
	6	E406064-002	TURN TABLE		1		
	7	E306275-003	ARM SUPPORT		1		
	8	SDST2005Z	SCREW		1		
	9	E306277-001	JOINT HOLDER		1		
	10	SDST2004Z	SCREW		2		
	11	SE10351-11	SUB GEAR		1		
	11-01	E306276-001	GEAR BASE		1		
	11-02	E75444-001	CAM GEAR		1		
	11-03	E75443-001	DRIVE GEAR		1		
	11-04	E75445-001	CAM GEAR		1		
	11-05	WDM163550	WASHER		1		
	11-06	E75494-003	SHAFT PIN		2		
	11-07	E75494-002	ROLLER SHAFT		1		
	11-08	HKN-3A6RDNV	DC MOTOR	FEED	1		
	11-09	E75493-001	PINION GEAR		1		
	11-10	LPSH1735Z	SCREW		2		
	12	E72713-001	SCREW		2		
	13	E74539-001B	DC MOTOR		1		
	14	E12114-005(S)	PRINTED BOARD		1		
	15	ESB1100-005	LEAF SWITCH		1		
	16	EMV5109-006B	CONN. TERMINAL		2		
	17	E75832-001	SPECIAL SCREW		1		
	18	SDSP2003N	SCREW		2		

1 2 3 4 5

■ Speaker System Section (Left Side): BLOCK NO. M7MM




Fig. 7-22

■ Speaker System Section (Left Side):

BLOCK NO. M7MM

REF.	PARTS NO.	PARTS NAME	REMARKS	QTY	SUFFIX	CLR
1	DH903-LUX-A3 DH903-RUX-A3	GRILL ASSEMBLY GRILL ASSEMBLY	LEFT RIGHT	1 1		
2	DH429-4C-638	CATCH BLACK	L,R	6		
3	DH401-LUX-A3 DH401-RUX-A3	FRONT PANEL(L) FRONT PANEL (R)	LEFT RIGHT	1 1		
4	SDSA4012M	WOOD SCREW 4*12	L,R	8		
5	DH429-UX-A3	PACKING	L,R	2		
6	DH430-UX-A3	PACKING	L,R	2		
7	DH505-LUX-A3 DH505-RUX-A3	SPEAKER BOX WOOD BOX(R)	LEFT RIGHT	1 1		
8	DH610-UX-A3	NAME PLATE	L,R	2		
9	VGS1001-012	SPEAKER	L,R	2		
10	DH190-UX-1A	CORD ASS'Y	L,R	2		

■ Speaker System




Fig. 7-23




Fig. 7-24

Note: Front panel and speaker box are provided together with as an assembly for servicing. They won't be supplied individually.

■ Speaker box

1. Remove the grill assembly (1) by hand (Fig. 7-23)
2. Stand the speaker box (7) upside down as shown in Fig. 7-24.
3. Insert an ordinary (-) screwdriver into the right hole shown in Fig. 7-24 and Fig. 7-25 and push the bottom end of the catch black (2) upside.

Note: Since high power adhesive is used to glue the boss of the front panel and the speaker box together, apply a constant force for a long time to separate them from each other.

If it is intended to do in a short time, the boss of the front panel will be damaged.




Fig. 7-25




Fig. 7-26

4. Insert an ordinary (-) screwdriver into the left hole shown in Fig. 7-26 and set its edge just under the small projection. Keeping this position, slowly turn the screwdriver to push the front panel gently upward with care as described in the above note.
5. When there is a gap between the front panel and the speaker box, insert something like a UM-3 battery into it as shown in Fig. 7-26.
6. Next, insert an acrylic plate of 1 mm thick or so into the gap aiming at the center boss on the left side of the front panel.
7. In order to prevent the front panel from damage, insert an ordinary screwdriver between the front panel and the acrylic plate as shown in Fig. 7-26, then lift the front panel upward using the front baffle plate as a fulcrum.
8. Repeat the above steps 4 through 7 aiming at different bosses to remove the front panel.
9. For removing the speaker unit, remove four screws ④ for the full range speaker ⑨.




Fig. 7-27

8 Main Adjustment

■ Equipment and Measuring Instrument used for Adjustment

- Electronic voltmeter
- Audio frequency oscillator
- Attenuator
- Wow-flutter meter
- Frequency counter

Standard signal generator
Torque testing cassette gauge CTG-N
Alignment tape
Measuring tape: Normal ... TS-8 (UR)
Chrome ... AC513
VTT702 (8 kHz)

■ Condition for Measurement: Tuner Sections

Supply voltage : AC 120/230 V (50/60 Hz) UX-A3J
AC 120 V (60 Hz) UX-A3C
AC 127/230 V (50/60 Hz) UX-A3U
AC 240 V (50/60 Hz) UX-A3A

**Applied voltage
of the Tuner :** 5.6 V DC
Connect a 47Ω resistor in series with the power supply.

Reference output: Speaker; 50 mW (0.63 V)/8 Ω
Headphone: 0.06 V/32 Ω

Reference input: TPIN - 11 dBs
Input signal : (AM) Modulation frequency; 400 Hz, 30%
 (FM) Modulation frequency; 400 Hz,
 22.5 kHz dev.

Set position of
Volume & Switch : BASS/TREBLE; to Center
FM; Stereo
TIMER; OFF
Active Hyper Bass; OFF

Attentive point

Connection of IF sweeper

Connect a 30 pF capacitor and a 33 k Ω resistor in series with the sweeper's output and a 0.082 μ F capacitor and a 100 k Ω resistor in parallel to the input.

IF sweeper's output level: Set at the lowest level that will allow adjustment.

FM MPX adjustment

For this adjustment, connect a 100 k Ω resistor in series with the frequency counter's input.

■ Location of Adjustment (Tuner P.C. Board View)











Fig. 8-1

■ Main Adjustment: Tuner Section

Item	Measuring Conditions and Main Adjustment	Standard Value	Adjust
FM IF adjustment	<p>The unit should not usually require adjustment. Follow the steps below when adjustment is necessary.</p> <p><Conditions></p> <ol style="list-style-type: none"> 1. Radio band : FM position 2. Frequency of sweep generator: 10.7 MHz 3. Tuning dial setting: Low end 4. Signal input: Positive side to TP5 5. Measuring point: Positive side to TP6 Negative side to TP7  <p style="text-align: center;">Fig. 8-2</p> <p><Adjustment></p> <ol style="list-style-type: none"> 1. Disconnect CF3 to change waveform from S-Curve to single peak of the waveform. 2. Turn T1 to shape waveform so that it peaks in the center (10.7 MHz) of the waveform and is symmetrical in both sides. 3. Connect at CF3 again and confirm that waveform returns to the original. 		T1
AM IF adjustment	<p>The unit should not usually require adjustment. Follow the steps below when adjustment is necessary.</p> <p><Conditions></p> <ol style="list-style-type: none"> 1. Radio band: AM position 2. Frequency of signal generator: 450 kHz 3. Tuning dial setting: Low end 4. Signal input: Bar antenna or positive side to TP3 5. Measuring point: Headphone jack or Positive side to TP6 Negative side to TP7  <p style="text-align: center;">Fig. 8-4</p> <p><Adjustment></p> <ol style="list-style-type: none"> 1. Adjust T2 obtain symmetrical curve and maximum amplitude. 2. On the AM IF Circuit in case where IF filter was used solid units there is unnecessary for IF turning and IF character depend upon the ceramic filter unit. 		T2

**Fig. 8-5**

Item	Measuring Conditions and Main Adjustment	Standard Value	Adjust
AM tracking adjustment (UX-A3C/J)	<p><Conditions></p> <ol style="list-style-type: none"> 1. Radio band: AM position 2. Signal input: Loop antenna 3. Frequency of signal generator: 600 kHz (Tuning dial setting: low end) 1500 kHz (Tuning dial setting: high end) 4. Measuring point: Headphone jack  <p style="text-align: center;">Fig. 8-6</p> <p><Adjustment></p> <ol style="list-style-type: none"> 1. Receive lower frequency 600 kHz at maximum variable capacitor position. 2. Adjust L3 so that output level becomes maximum. 3. Receive upper frequency tracking lower frequency 1500 kHz at minimum variable capacitor position. 4. Adjust TC2 so that output level becomes maximum. 5. Repeat the above step 1,2 through 3,4. 		L3 TC2
AM tracking adjustment (UX-A3A/U)	<p>The unit should not usually require adjustment. Follow the steps below when adjustment is necessary.</p> <p><Conditions></p> <ol style="list-style-type: none"> 1. Radio band: AM position 2. Signal input: Loop antenna 3. Frequency of signal generator: 531 kHz (Tuning dial setting: 531 kHz) 1602 kHz (Tuning dial setting: 1602 kHz) 4. Measuring point: Headphone jack  <p style="text-align: center;">Fig. 8-8</p> <p><Adjustment></p> <ol style="list-style-type: none"> 1. Receive lower frequency 531 kHz and adjust L3 so that output level becomes maximum. 2. Receive tracking upper frequency 1602 kHz and adjust TC2 so that output level becomes maximum. 8. Repeat the above step 1. through 2. so that output becomes maximum. 		L3 TC2

Item	Measuring Conditions and Main Adjustment	Standard Value	Adjust
FM tracking adjustment (UX-A3 J/C) only	<p><Conditions></p> <ol style="list-style-type: none"> 1. Radio band: FM position 2. Signal input: 75Ω unbalance Positive side to TP1 Negative side to TP2 3. Frequency of signal generator: 88 MHz (Tuning dial setting: 90 MHz) 106 MHz (Tuning dial setting: 106 MHz) 4. Measuring point: Headphone jack  <p style="text-align: center;">Fig. 8-10</p>		
FM tracking adjustment (UX-A3 A/U) only	<p><Adjustment></p> <p>Receive tracking lower frequency 88 MHz and adjust L1 so that output level becomes maximum.</p> <p><Conditions></p> <ol style="list-style-type: none"> 1. Radio band: FM 2. Signal input: 75Ω unbalance Positive side to TP1 Negative side to TP2 3. Frequency of signal generator: 87.5 MHz (Tuning dial setting: low end) 108.0 MHz (Tuning dial setting: high end) 88 MHz (Tuning dial setting: 88 MHz) 106 MHz (Tuning dial setting: 106 MHz) 4. Measuring point: Headphone jack  <p style="text-align: center;">Fig. 8-11</p>	L1	
	<p><Adjustment></p> <ol style="list-style-type: none"> 1. Receive lower frequency 87.5 MHz at maximum variable capacitor position. 2. Adjust L1 so that output level becomes maximum. 3. Adjust L1 to obtain 5.2 ± 0.02 V at TP9. 4. Receive upper frequency 108 MHz at minimum variable capacitor position. 5. Adjust L2 so that output level becomes maximum. 6. Receive tracking lower frequency 88 MHz and adjust L2 so that output level becomes maximum. 7. Receive tracking upper frequency 106 MHz so that output level becomes maximum. 8. Repeat the above step 6 so that output becomes maximum. 		L1 L2



Item	Measuring Conditions and Main Adjustment	Standard Value	Adjust
FM MPX confirmation	<p><Conditions></p> <ol style="list-style-type: none"> 1. Radio band: FM position 2. Signal input: 75Ω unbalance Positive side to TP1 Negative side to TP2 3. Frequency of signal generator: 98 MHz 4. Output level of signal generator: $60 \text{ dB}\mu\text{V}$ <p><Confirmation> Comfirm that stereo operation and frsequecy separation meat the specifications.</p>	$19 \pm 0.1 \text{ kHz}$	—

■ Main Adjustment: Mechanism and Amplifier Sections

Item	Measuring Conditions and Main Adjustment	Standard Value	Adjust
Head azimuth adjustment	<p><Conditions></p> <ol style="list-style-type: none"> 1. Mode : PLAY 2. Test tape : VTT703 (10 kHz) 3. Measuring point : Headphone <p><Adjustment></p> <ol style="list-style-type: none"> 1. Connect an electronic voltmeter to the speaker terminal. 2. Playback the test tape VTT702. 3. Adjust the head azimuth with screw until the reading of the electronic voltmeter becomes – 2 dB from the peak. 4. Adjust to peak between FWD/REV within – 3 dB from the peak. 	– 2 dB from the peak	—
Tape speed and wow-flutter confirmation	<p><Conditions></p> <ol style="list-style-type: none"> 1. Mode : PLAY, Normal speed 2. Test tape : VTT712 at tape end 3. measuring point : Headphone jack <p><Confirmation></p> <ol style="list-style-type: none"> 1. Connect a wow-flutter meter to speaker terminal. 2. Playback the test tape VTT712 at tape end. 3. Confirme so that is obtained within 2940~3090 Hz at normal speed. 4. Check to see if reading of the meter is less than 0.45% (JIS RMS). 	Normal Speed : 2940~3090 Hz Wow-flutter : less than 0.45% (JIS RMS)	—
Playback frequency response confirmation	<p><Conditions></p> <p>Test tape : VTT739 Mode : PLAY Measuring point : CNA04 connector on the pre amplifier P.C. board</p> <p><Confirmation></p> <p>Playback the test tape VTT739 difference level against 1 kHz. 1 kHz/63 Hz : $-2 \text{ dB} \pm$ with in 4 dB 1 kHz/12.5 kHz : $0 \text{ dB} \pm$ within 4 dB</p>	1 kHz/63 Hz : $-2 \text{ dB} \pm$ with in 4 dB 1 kHz/12.5 kHz : $0 \text{ dB} \pm$ within 4 dB	—
Recording and playback frequency response adjustment	<p><Conditions></p> <ol style="list-style-type: none"> 1. Test tape : UR(TS8) 2. Measuring point : CNA04 IN 4 PIN (Lch)/5 PIN (Rch) OUT ... 1 PIN (Lch)/2 PIN (Rch) <p><Adjustment></p> <ol style="list-style-type: none"> 1. Refference signal – 11 dB to be applied to CNA04. 2. Adjust the VRA13(Lch) and VRA23(Rch) so that 25 Hz~12.5 kHz frequency response level becomes $0 \pm 1 \text{ dB}$. 	$0 \pm 1 \text{ dB}$	Lch : VRA13 Rch : VRA23

Item	Measuring Conditions and Main Adjustments	Standard Value	Adjust
Playback output level adjustment	<p><Conditions> Measuring point : CNA04 OUT ... 1 PIN (Lch) 2 PIN (Rch)</p> <p><Adjustment> Adjust the VRA11 (Lch) and VRA21 (Rch) so that 1 kHz against monitor level becomes $-11 \text{ dB} \pm 1 \text{ dB}$.</p>	11 dB ± 1 dB	Lch : VRA11 Rch : VRA21
Rec./playback sensitivity adjustment	<p><Conditions></p> <ol style="list-style-type: none"> 1. Mode: REC, PLAY Mechanism B 2. Test tape: UR (TS8) 3. Measuring point: CNA04 IN 4 PIN (Lch)/5 PIN (Rch) OUT ... 1 PIN (Lch)/2 PIN (Rch) <p><Adjustment> Adjust the VRA12 (L ch) and VRA22 (R ch) so that 1 kHz -6 dBs against monitor level becomes $0 \pm 1 \text{ dB}$.</p>	0 ± 1 dB	L ch : VRA11 R ch : VRA22

■ Location of Adjustment



■ Adjust of CD Player Section

Items	Devices Used	Adjustment Method	Adjusting Position
Adjustment of tracking offset	Normal disk oscilloscope	<ol style="list-style-type: none"> 1. Connect the oscilloscope between TP502 (VREF) and TP503 (TE). 2. Connect the terminal ① and ④ of FW501 and apply 10 V to the terminal ② of FW501. 3. Replay (Regenerate) the normal disk. 4. Connect TP504 and TP502 (for shorting). 5. Adjust (the tracking offset waveform with) VR501 so that the DC level of tracking error signal (waveform of oscilloscope) becomes zero. <p style="text-align: center;">Waveform of tracking offset</p>	VR501

Notes

1. Adjust VR501 so that the waveform becomes vertically symmetrical with reference to the zero level.
2. The oscilloscope input should be coupled to DC.

■ Layout Diagram of Adjusting Positions

(CD Control P.C. board View)




Fig. 8-15

9 Block Diagram

■ General Section




Fig. 9-1

■ CD Player Sections




Fig. 9-2

10 Wiring Connections

1


2

3

4

5

■ Tape Deck • Power Amplifier Section



■ CD • Re

Color codes are shown below

1 Brown
2 Red
3 Orange
4 Yellow
5 Green
6 Blue
7 Violet
8 Gray
9 White
0 Black
D Pink
C Light Blue

Fig. 10-1

6

7

8

9

10

■ CD • Receiver Section

are shown below.

- .. Brown
- .. Red
- .. Orange
- .. Yellow
- .. Green
- .. Blue
- .. Violet
- .. Gray
- .. White
- .. Black
- .. Pink
- .. Light Blue




Fig. 10-2

11

Standard Schematic Diagram and Location of Components

1

2

3

9

■ Head Amplifier/Mechacon Circuit: Drawing No. VDH9189-006AV




TABLE 2 DIGITAL T-B LIST




TABLE I * MARK PARTS LIST

REF NO.	VERSION NO.	E/B/V/VX/U	G/SI	J/C
QA306	DA303-	USE	USE	ND USE
CA317	CA322-			
RA323				
L503	BUS WIRE	USE	BUS WIRE	
LA151/251	BUS WIRE	USE	BUS WIRE	
R515	BUS WIRE	BUS WIRE		USE




Fig. 11-1

Location of P.C. Board

5

6

7

8

9

10




Fig. 11-1

- Head Amplifier P.C. Board: Drawing No. VMW1285G




Fig. 11-2

16

17

18

19

20

• Mechacon P.C. Board: Drawing No. VMW1285H




Fig. 11-3

• Headphone P.C. Board: Drawing No. VMW1285E





Fig. 11-4

1 2 3 4 5

■ Power Amplifier • Power Supply Circuit: Drawing No. VDH9189-006AW



5


6

7

8

9


10



VMW1285 A

TABLE 1 * MARK PARTS LIST

MODEL REF	J	U	C
T951	VTP66Z2-12F	VTP66Z2-12G	VTP66A2-12C
F951	QMF51N2-R60J1	QMF51E2-R63J1	QMF51N2-R60J1
F952	QMF0007-5R0J1	QMF51E2-5R0J1	QMF0007-5R0J1
F953	QMF0007-5R0J1	QMF51E2-5R0J1	QMF0007-5R0J1
F954	NO USE	NO USE	NO USE
V1	120V	127V	120V
V2	230V	230V	
R951	QPC121K-225	NO USE	
S951	QSS2325-121	QSS2325-120	
POWER CORD	QMP1340-200	QMP7380-200	QMP1340-200



Tape PB Signal

+B LINE

Fig. 11-5

- Power Amplifier P.C. Board: Drawing No. VMW1285A




Fig. 11-6

- Power Supply-Fuse P.C. Board: Drawing No. VMW1285B




Fig. 11-7

16

17

18

19

20

• Power Supply•Relay P.C. Board: Drawing No. VMW1285D




Fig. 11-8

• Power Supply•Speaker Terminal P.C. Board: Drawing No. VMW1285C





Fig. 11-9

■ CD Control Amplifier Circuit: Drawing No. VDH9189-006CV



NOTES 1 VOLTAGES ARE DC-MEASURED WITH A DIGITAL VOLT METER IN STC
 2 UNLESS OTHERWISE SPECIFIED
 ALL RESISTORS ARE 1/4W ±5% CARBON RESISTOR
 ALL CAPACITORS ARE CERAMIC CAPACITOR OR MYLAR CAPACITOR
 ALL RESISTANCE VALUES ARE IN OHM (Ω)
 ALL CAPACITANCE VALUES ARE IN ATTFIDF=100
 ALL E. CAPACITORS ARE SHOWN IN THE FORM CAP1014C10V1A165
 3 UNLESS OTHERWISE SPECIFIED ALL DIODES ARE HSS1014 OR MA165
 NON-POLARIZED ELECTROLYTIC CAPACITOR
 * 1/4W ±1% CARBON RESISTOR 1R520-576-578-661-682-684-686-688




Fig. 11-10

CD Playback signal (Digital)

CD Playback signal (Analog)

WITH A DIGITAL VOLT METER IN STOP

ED
± 5% CARBON RESISTOR

$\pm 5\%$ CARBON RESISTOR
MIC CAPACITOR OR MYLAR CAPACITOR

AMIC CAPACITOR
ARE IN OHM (Ω)

ARE IN $\#F(P=pF)$

DOWN IN THE FORM CAPACITANCE (AF) /
FOR ALL SIZES ARE LISTED IN THE
TABLES.

ED ALL DIODES ARE HSS104 OR MA16
TROLYXTIC CAPACITORS

TROLYTIC CAPACITOR

TR520: 676, 678, 681, 682, 684, 686, 6

D) 58

57 58

1 2 3 4 5

■ CD Control Amplifier P.C. Board: Drawing No. VMW2307




Fig. 11-11

1 2 3 4 5


LCD Display/Function P.C. Board: Drawing No. VMW2353

Fig. 11-12


**Main Volume P.C. Board
: Drawing No. VMW2353C**

Fig. 11-13



**Tone Volume P.C. Board
: Drawing No. VMW2353B**

Fig. 11-14

■ LCD Display/Function Circuit: Drawing No. VDH9189-00SV




NOTES

1. VOLTAGES ARE DC-MEASURED WITH A DIGITAL VOLT METER
OR OSCILLOSCOPE WITHOUT INPUT SIGNAL.
CONDITION — CD MODE
* () TUNER MODE AM 198KHZ


2. UNLESS OTHERWISE SPECIFIED, RESISTORS ARE 1/8W ±5% CARBON RESISTOR.
ALL RESISTANCE VALUES ARE IN OHMS.
ALL CAPACITORS ARE CERAMIC CAPACITOR OR MYLAR CAPACITOR.
ALL CAPACITANCE VALUES ARE IN μ F (PF).
ALL INDUCTANCE VALUES ARE IN μ H (MH).


ALL E. CAPACITORS ARE SHOWN IN THE FORM OF CAPACITANCE (μ F)/RATED
ALL DIODES ARE MA165 (WITHOUT DM04)

- (C) UNFLAMMABLE CARBON RESISTOR
- (C) METAL FILM RESISTOR
- (C) OXIDE METAL FILM RESISTOR
- (C) ±20% LOW LEAK CURRENT ELECTROLYTIC CAPACITOR
- (C) NON-POLARISED ELECTROLYTIC CAPACITOR
- (C) POLYPROPYLENE CAPACITOR
- (C) POLYSTYROL CAPACITOR



■ Tuner Circuit: Drawing No. VDH9189-006TW





E OF DIGITAL TRANSISTORS ARE SHOWN AS FOLLOWS.

9. LAST NO.
R 58 C 71 Q 13 D 13
BLANK NO.R 11, 12, 14-17, 19, 21-23, 26, 38, 39, 45, 46, 50, 51
C 19, 20, 24-29, 51, 52, 54-58, 67, 68
Q 2-6
D 10, 11

1

2

3

4

5

■ Tuner P.C. Board: Drawing No. VMW2360

A

B

C

D

E

F




Fig. 11-17

1 2 3 4 5

■ Function/LINE amplifier P.C. Board: Drawing No. VMW1283B





Fig. 11-18

■ Function/Line Amplifier Circuit: Drawing No. VDH9189-006BV



NOTES

1. VOLTAGES ARE DC-MEASURED WITH A DIGITAL VOLT METER
OR OSCILLOSCOPE WITHOUT INPUT SIGNAL.
CONDITION — CD MODE

2. UNLESS OTHERWISE SPECIFIED, RESISTORS ARE 1/8W ±5% CARBON RESISTOR.
 ALL RESISTANCE VALUES ARE IN OHMS.
 ALL CAPACITORS ARE CERAMIC CAPACITOR OR MYLAR CAPACITOR.
 ALL CAPACITANCE VALUES ARE IN μ F (PFRP).
 ALL INDUCTANCE VALUES ARE IN μ H (MMHM).
 ALL TIME DELAY VALUES SHOWN IN THE FORM OF CAPACITANCE (μ F)/PATED VOLTAGE (V).
 ALL DIODES ARE 1A 50V.

- (P) UNFLAMMABLE CARBON RESISTOR
- (M) METAL FILM RESISTOR
- (O) OXIDE METAL FILM RESISTOR
- (L) ±20% LOW LEAK CURRENT ELECTROLYTIC CAPACITOR
- (N) NON-POLARISED ELECTROLYTIC CAPACITOR
- (P) POLYPROPYLENE CAPACITOR
- (S) POLYSTYROL CAPACITOR

6

7

8

9

10




Fig. 11-19

+B LINE

(No. 1860) 65

12

Electrical Parts List

■ Pre-Amplifier P.C. Board Parts List

BLOCK NO. 01

A	REF.	PARTS NO.	PARTS NAME	SUFFIX	REMARKS	A	REF.	PARTS NO.	PARTS NAME	SUFFIX	REMARKS
C	501	QETC1AM-1077N	E CAPACITOR	100MF 20% 10V		CA161	QETC1EM-227ZN	E CAPACITOR	220MF 20% 25V		
C	502	QETC1EM-4762N	E CAPACITOR	47MF 20% 25V		CA201	QETC1HM-225ZN	E CAPACITOR	2-2MF 20% 50V		
C	503	QETC1CM-1062N	E CAPACITOR	10MF 20% 16V		CA202	QCB1HK-102Y	C CAPACITOR	1000PF 10% 50V		
C	504	QETC1AM-4762N	E CAPACITOR	47MF 20% 10V		CA203	QETC1HJ-153ZM	TF CAPACITOR	*015MF 5% 50V		
C	505	QETC1HM-225ZN	E CAPACITOR	2.2MF 20% 50V		CA204	QETC1AM-1077N	E CAPACITOR	100MF 20% 10V		
C	506	QETC1AM-1077N	E CAPACITOR	100MF 20% 10V		CA205	QETC1HM-1052N	E CAPACITOR	1-0MF 20% 50V		
C	508	QFLA1HJ-6822M	M CAPACITOR	6800PF 5% 50V		CA206	QETC1HM-474ZN	E CAPACITOR	-47MF 20% 50V		
C	509	QFLA1HJ-6822M	M CAPACITOR	6800PF 5% 50V		CA207	QETC1HM-474ZN	E CAPACITOR	-47MF 20% 50V		
C	510	QFLA1HJ-3322M	M CAPACITOR	3300PF 5% 50V		CA208	QCB1HK-471Y	C CAPACITOR	-470PF 10% 50V		
C	511	QFLA1HJ-3322M	M CAPACITOR	3300PF 5% 50V		CA209	QCB1HK-102Y	C CAPACITOR	1000PF 10% 50V		
C	512	QFV41HJ-13	FILM CAPACITOR	.012MF 5% 50V		CA210	QFV41HJ-224	TF CAPACITOR	-22MF 5% 50V		
C	513	QETC1CM-1062N	E CAPACITOR	10MF 20% 16V		CA211	QETC1HM-225ZN	E CAPACITOR	2-2MF 20% 50V		
C	520	QEK61CM-1072N	E CAPACITOR	100MF 20% 16V		CA212	QETC1EM-475	E CAPACITOR	4-7MF 20% 50V		
C	521	QCVB1CM-103Y	C CAPACITOR	.010MF 20% 16V		CA213	QFV11HJ-153AZM	TF CAPACITOR	*015MF 5% 50V		
C	522	QCVB1CM-103Y	C CAPACITOR	.010MF 20% 16V		CA214	QCB1HK-102Y	C CAPACITOR	1000PF 10% 50V		
A	951	QCF11CM-103Y	C CAPACITOR	.010MF 20% 16V		CA215	QCC31EM-1537V	C CAPACITOR	*015MF 20% 25V		
A	952	QCF11HP-223	C CAPACITOR	.022MF +100/-0%		CA216	QETC1HM-1052N	E CAPACITOR	1-0MF 20% 50V		
A	953	QCF11HP-223	C CAPACITOR	.022MF +100/-0%		CA217	QETC1EM-475	E CAPACITOR	4-7MF 20% 25V		
A	954	QCF11HP-223	C CAPACITOR	.022MF +100/-0%		CA218	QCC11EM-104V	C CAPACITOR	-10MF 20% 25V		
A	955	QETB1EM-68N	E CAPACITOR	.022MF +100/-0%		CA219	QCXB1CM-222Y	C CAPACITOR	2200PF 20% 16V		
CA101	QETC1HM-225ZN	E CAPACITOR	DECUP		CA220	QETC1HM-1052N	E CAPACITOR	1-0MF 20% 50V			
CA102	QCBB1HK-102Y	C CAPACITOR	2-2MF 20% 50V		CA221	QETC1HK-102Y	C CAPACITOR	1000PF 10% 50V			
CA103	QFV11HJ-153AZM	TF CAPACITOR	1000PF 10% 50V		CA222	QCS32HJ-101ZV	C CAPACITOR	1000PF 5% 50V			
CA104	QETC1AM-1077N	E CAPACITOR	100MF 20% 10V		CA223	QCB1HK-331Y	C CAPACITOR	330PF 10% 50V			
CA105	QETC1CM-1052N	E CAPACITOR	1-0MF 20% 50V		CA224	QETC1HM-474ZN	E CAPACITOR	-47MF 20% 50V			
CA106	QETC1HM-474ZN	E CAPACITOR	.47MF 20% 50V		CA225	QCC11EM-473V	C CAPACITOR	*47MF 20% 25V			
CA107	QETC1HM-474ZN	E CAPACITOR	.47MF 20% 50V		CA226	QCB1HK-471Y	C CAPACITOR	*18MF 5% 50V			
CA108	QCBB1HK-471Y	C CAPACITOR	.47MF 20% 50V		CA227	QCB1HK-471Y	C CAPACITOR	470PF 10% 50V			
CA109	QCBB1HK-102Y	C CAPACITOR	1000PF 10% 50V		CA228	QETC1AM-1072N	E CAPACITOR	100MF 20% 10V			
CA110	QFV41HJ-224	TF CAPACITOR	.22MF 5% 50V		CA229	QETC1AM-476Z	E CAPACITOR	47MF 20% 16V			
CA111	QETC1AM-225ZN	E CAPACITOR	2-2MF 20% 50V		CA230	QETC1CM-476Z	E CAPACITOR	47MF 20% 16V			
CA112	QETC1EM-155	E CAPACITOR	4.7MF 20% 25V		CA231	QFV41HJ-224	TF CAPACITOR	*22MF 5% 50V			
CA113	QFV11HJ-153AZM	TF CAPACITOR	.015MF 5% 50V		CA232	QFV41HJ-224	TF CAPACITOR	*22MF 5% 50V			
CA114	QCBB1HK-102Y	C CAPACITOR	1000PF 10% 50V		CA233	QETC1AM-227ZN	E CAPACITOR	220MF 20% 10V			
CA115	QCC31EM-1532V	C CAPACITOR	.015MF 20% 25V		CA234	QETC1EM-227ZN	E CAPACITOR	220MF 20% 25V			
CA116	QETC1HM-475Z	E CAPACITOR	1.0MF 20% 50V		CA235	QETC1AM-476Z	E CAPACITOR	47MF 20% 10V			
CA117	QETC1EM-475	E CAPACITOR	4.7MF 20% 25V		CA236	QETC1HM-475Z	E CAPACITOR	4.7MF 20% 50V			
CA118	QCC11EM-104V	C CAPACITOR	.10MF 20% 25V		CA237	QETC1AM-476Z	E CAPACITOR	4.7MF 20% 50V			
CA119	QCXB1CM-222Y	C CAPACITOR	2200PF 20% 16V		CA238	QETC1AM-1062N	E CAPACITOR	100MF 20% 10V			
CA120	QETC1HM-1052N	E CAPACITOR	.10MF 20% 50V		CA239	QETC1AM-1072N	E CAPACITOR	33MF 20% 10V			
CA121	QCBB1HK-102Y	C CAPACITOR	1000PF 10% 50V		CA240	QETC1CM-1062N	E CAPACITOR	100MF 20% 10V			
CA122	QCS32HJ-112V	C CAPACITOR	100PF 5% 50V		CA241	QETC1AM-476Z	E CAPACITOR	100MF 20% 10V			
CA123	QCBB1HK-331Y	C CAPACITOR	330PF 10% 50V		CA242	QETC1HM-475Z	E CAPACITOR	100MF 20% 10V			
CA124	QETC1HM-474ZN	E CAPACITOR	.33MF 20% 50V		CA243	QETC1AM-1072N	E CAPACITOR	100MF 20% 10V			
CA125	QCC11EM-473V	C CAPACITOR	.047MF 20% 25V		CA244	QETC1AM-1072N	E CAPACITOR	100MF 20% 10V			
CA151	QFV41HJ-184	TF CAPACITOR	.18MF 5% 50V		CA245	QETC1HM-475Z	E CAPACITOR	47MF 20% 10V			
CA152	QCBB1HK-471Y	C CAPACITOR	.470PF 10% 50V		CA246	QFV41HJ-224	TF CAPACITOR	*22MF 5% 50V			
CA153	QETC1AM-1072N	E CAPACITOR	100MF 20% 10V		CA247	QCB1CM-103Y	C CAPACITOR	-010MF 20% 16V			
CA154	QETC1AM-1072N	E CAPACITOR	100MF 20% 10V		CA248	QCB1CM-103Y	C CAPACITOR	-010MF 20% 16V			
CA155	QETC1CM-476Z	E CAPACITOR	.47MF 20% 16V		CA249	QFV71HJ-393ZM	FILM CAPACITOR	-039MF 5% 50V			
CA156	QETC1CM-476Z	E CAPACITOR	.47MF 20% 16V		CA250	QFV71HJ-393ZM	FILM CAPACITOR	-039MF 5% 50V			
CA157	QFV41HJ-224	TF CAPACITOR	.22MF 5% 50V		CA251	QCC11EM-103V	CONNECTOR	-010MF 20% 25V			
CA158	QFV41HJ-224	TF CAPACITOR	.22MF 5% 50V		CA252	QMC0064-007	CONNECTOR				
CA160	QETC1AM-227ZN	E CAPACITOR	.220MF 20% 10V		CA253	TXLL-005-M	CONNECTOR				

BLOCK NO. 0111111				BLOCK NO. 0111111					
A	REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
	CNA03	VMCO156-S10	CONNECTOR	DOLBY T.P		Q 507	2SA952(L,K)	TRANSISTOR	
	CNA04	TXL1-006-M	CONNECTOR			QA151	2SD1302(S,T)	TRANSISTOR	
	CNA05	VMCO156-P07	CONNECTOR			QA152	2SD1302(S,T)	TRANSISTOR	
	CNA06	VMCO156-S12	CONNECTOR			QA251	2SD1302(S,T)	TRANSISTOR	
	CN252	VMCO156-P12	CONNECTOR			QA252	2SD1302(S,T)	TRANSISTOR	
	CN353	TTL25V-008	CONNECTOR			QA303	2SA992(E,F)	TRANSISTOR	
CN501	TXL1-006-M	CONNECTOR				QA305	2SC1845(E-U)	TRANSISTOR	
CN502	TXLP-008-B	CONNECTOR				R 501	QRD161J-223	CARBON RESISTOR	22K 5% 1/6W
CN503	VMCO156-P10	CONNECTOR				R 502	QRD161J-243	CARBON RESISTOR	24K 5% 1/6W
CN505	VMCO156-S07	CONNECTOR				R 503	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W
CN951	VMCO156-P08	CONNECTOR	2ND			R 504	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W
CN952	VMCO156-S08	CONNECTOR	2ND			R 505	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W
CN953	VMCO156-S10	CONNECTOR				R 506	QRD161J-472	CARBON RESISTOR	4.7K 5% 1/6W
CN954	VMCO156-P10	CONNECTOR				R 507	QRD161J-560	CARBON RESISTOR	56 5% 1/6W
CN955	VMZ0076-03A	CONNECTOR	1 ST			R 508	QRD161J-472	CARBON RESISTOR	4.7K 5% 1/6W
D 501	MA700A	S-B.DIODE				R 510	QRD161J-290	CARBON RESISTOR	39 5% 1/6W
D 502	MA165	SI DIODE				R 511	QRD14CJ-180X	UNI-C. RES.-I.M	18 5% 1/4W
D 503	MA165	SI DIODE				R 512	QRD161J-3R3	CARBON RESISTOR	3.3 5% 1/6W
A 951	IN5401F	SI DIODE				R 513	QRD161J-273	CARBON RESISTOR	27K 5% 1/6W
A 952	S5VBL0-4001L15	SI DIODE				R 514	QRD161J-273	CARBON RESISTOR	27K 5% 1/6W
DA101	MA165	SI DIODE				R 515	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W
DA102	MA165	SI DIODE				R 517	QRD161J-472	CARBON RESISTOR	4.7K 5% 1/6W
DA201	MA165	SI DIODE				R 519	QRD161J-183	CARBON RESISTOR	18K 5% 1/6W
DA202	MA165	SI DIODE				R 521	QRD161J-223	CARBON RESISTOR	22K 5% 1/6W
DA301	MA165	SI DIODE				R 522	QRD161J-223	CARBON RESISTOR	22K 5% 1/6W
DA302	MA165	SI DIODE				R 523	QRD161J-471	CARBON RESISTOR	47K 5% 1/6W
DA351	MA700	ZENER DIODE				R 524	QRD161J-223	CARBON RESISTOR	22K 5% 1/6W
DA352	MA700	ZENER DIODE				R 525	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W
DA353	MA165	SI DIODE				R 526	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W
DA354	MA165	SI DIODE				R 527	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W
A F 951	QMF51N2-R60J1	FUSE	1 ST			R 951	QRC121K-225	COMP RESISTOR	2.2M 10% 1/2W
A F 952	QMF0007-5R0J1	FUSE	2 ND			RA101	QRD161J-470	CARBON RESISTOR	47 5% 1/6W
A F 953	QMF0007-5R0J1	FUSE	DC			RA102	QRD161J-224	CARBON RESISTOR	220K 5% 1/6W
A F 954	QMF0007-5R0J1	FUSE	DC			RA103	QRD167J-562	CARBON RESISTOR	5.6K 5% 1/6W
I CA01	UPC1228HA	IC	PB AMP			RA104	QRD161J-392	CARBON RESISTOR	3.9K 5% 1/6W
I CA02	LA3220	IC	REC. AMP			RA105	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W
I CA03	UPC1300HA	IC	HEAD SW			RA107	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W
I CA04	HA12134A	IC	DOLBY			RA108	QRD161J-124	CARBON RESISTOR	120K 5% 1/6W
I CA05	LA4496	IC	L-CH			RA109	QRD161J-153	CARBON RESISTOR	15K 5% 1/6W
I CA06	LA4496	IC	R-CH			RA110	QRD161J-153	CARBON RESISTOR	15K 5% 1/6W
J 351	EMB90YV-401A	SPK.TERMINAL	SPK CONNECT			RA111	QRD161J-221	CARBON RESISTOR	220 5% 1/6W
J 352	EMV17127-017	CONNECTOR	SYSTEM CONNECT			RA112	QRD161J-182	CARBON RESISTOR	1.8K 5% 1/6W
J 353	QMS301C-V01	JACK	HEADPHONE			RA113	QRD161J-151	CARBON RESISTOR	150 5% 1/6W
J 951	QMA431B-V01	DC JACK				RA114	QRD161J-392	CARBON RESISTOR	3.9K 5% 1/6W
L 501	VQH1008-055	Osc COIL(BIAS)				RA115	QRD167J-682	CARBON RESISTOR	6.8K 5% 1/6W
L 502	VQ0028-2212	INDUCTOR				RA116	QRD161J-123	CARBON RESISTOR	12K 5% 1/6W
LA101	VQP0001-183	INDUCTOR				RA117	QRD161J-432	CARBON RESISTOR	4.3K 5% 1/6W
LA102	VQP0001-5621S	INDUCTOR				RA118	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W
LA201	VQP0001-183	INDUCTOR				RA120	QRD161J-512	CARBON RESISTOR	5.1K 5% 1/6W
LA202	VQP0001-5621S	INDUCTOR				RA123	QRD161J-104	CARBON RESISTOR	10K 5% 1/6W
Q 502	2SB56(C)	TRANSISTOR				RA151	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W
Q 503	2SC1740S(R-S)	TRANSISTOR				RA152	QRD161J-392	CARBON RESISTOR	3.9K 5% 1/6W
Q 504	2SC1740S(R-S)	TRANSISTOR				RA153	QRD161J-271	CARBON RESISTOR	270 5% 1/6W
Q 505	2SD1302(S,T)	TRANSISTOR				RA154	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W
Q 506	2SD1302(S,T)	TRANSISTOR				RA155	QRD161J-475	CARBON RESISTOR	4.7M 5% 1/6W

LOCK NO. 01

A	REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
	RA156	QRD161J-475	CARBON RESISTOR	4.7M 5% 1/6W	
	RA157	GRD161J-2R2	CARBON RESISTOR	2.2 5% 1/6W	
	RA158	GRD161J-2R2	CARBON RESISTOR	2.2 5% 1/6W	
	RA160	GRD161J-105	CARBON RESISTOR	1.0M 5% 1/6W	
	RA201	GRD161J-470	CARBON RESISTOR	4.7 5% 1/6W	
	RA202	GRD161J-224	CARBON RESISTOR	220K 5% 1/6W	
	RA203	GRD167J-562	CARBON RESISTOR	5.6K 5% 1/6W	
	RA204	GRD161J-392	CARBON RESISTOR	3.9K 5% 1/6W	
	RA205	GRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
	RA207	GRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
	RA208	GRD161J-124	CARBON RESISTOR	120K 5% 1/6W	
	RA209	GRD161J-153	CARBON RESISTOR	15K 5% 1/6W	
	RA210	GRD161J-153	CARBON RESISTOR	15K 5% 1/6W	
	RA211	GRD161J-221	CARBON RESISTOR	220 5% 1/6W	
	RA212	GRD161J-182	CARBON RESISTOR	1.8K 5% 1/6W	
	RA213	GRD161J-151	CARBON RESISTOR	150 5% 1/6W	
	RA214	QRD161J-392	CARBON RESISTOR	3.9K 5% 1/6W	
	RA215	GRD167J-682	CARBON RESISTOR	6.8K 5% 1/6W	
	RA216	QRD161J-123	CARBON RESISTOR	12K 5% 1/6W	
	RA217	GRD161J-432	CARBON RESISTOR	4.3K 5% 1/6W	
	RA218	GRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
	RA221	GRD161J-512	CARBON RESISTOR	5.1K 5% 1/6W	
	RA223	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W	
	RA254	GRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
	RA252	QRD161J-592	CARBON RESISTOR	3.9K 5% 1/6W	
	RA253	GRD161J-271	CARBON RESISTOR	270 5% 1/6W	
	RA254	GRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
	RA255	GRD161J-475	CARBON RESISTOR	4.7M 5% 1/6W	
	RA256	GRD161J-475	CARBON RESISTOR	4.7M 5% 1/6W	
	RA257	GRD161J-2R2	CARBON RESISTOR	2.2 5% 1/6W	
	RA258	GRD161J-2R2	CARBON RESISTOR	2.2 5% 1/6W	
	RA260	QRD161J-105	CARBON RESISTOR	1.0M 5% 1/6W	
	RA261	GRD161J-151	CARBON RESISTOR	150 5% 1/6W	
	RA301	QRD161J-221	CARBON RESISTOR	220 5% 1/6W	
	RA302	QRD161J-223	CARBON RESISTOR	22K 5% 1/6W	
	RA303	QRD161J-183	CARBON RESISTOR	18K 5% 1/6W	
	RA304	QRD161J-72	CARBON RESISTOR	4.7K 5% 1/6W	
	RA305	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
	RA306	QRD161J-161	C RESISTOR	160 5% 1/6W	
	RA307	QRD161J-473	CARBON RESISTOR	4.7K 5% 1/6W	
	RA308	GRD161J-81	CARBON RESISTOR	180 5% 1/6W	
	RA309	GRD161J-475	CARBON RESISTOR	4.7M 5% 1/6W	
	RA310	GRD161J-475	CARBON RESISTOR	4.7M 5% 1/6W	
	RA312	QRD161J-242	CARBON RESISTOR	2.4K 5% 1/6W	
	RA313	GRD161J-682	CARBON RESISTOR	6.8K 5% 1/6W	
	RA314	QRD161J-473	CARBON RESISTOR	6.7K 5% 1/6W	
	RA315	GRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
	RA316	GRD161J-101	CARBON RESISTOR	100 5% 1/6W	
	RA317	GRD167J-121	CARBON RESISTOR	120 5% 1/6W	
	RA318	QRD161J-223	CARBON RESISTOR	22K 5% 1/6W	
	RA319	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
	RA320	QRD161J-473	CARBON RESISTOR	4.7K 5% 1/6W	
	RA321	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
	RA322	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	

BLOCK NO. 01

CD Control P.C. Board Parts List

BLOCK NO. 02111111

BLOCK NO. 02111111

A	REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX	A	REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
C	502	QETC1AM-476Z	E CAPACITOR	47MF 20% 10V		C	616	QETC1AM-107ZN	E CAPACITOR	100MF 20% 10V	
C	505	QCCB1HK-471Y	C CAPACITOR	470PF 10% 50V		C	617	QETC1AM-107ZN	E CAPACITOR	100MF 20% 10V	
C	506	QCC11EM-223V	C CAPACITOR	.022MF 20% 25V		C	618	QCC11EM-223V	C CAPACITOR	.022MF 20% 25V	
C	507	QCCS11HJ-680	C CAPACITOR	68PF 5% 50V		C	620	QETC1AM-107ZN	E CAPACITOR	100MF 20% 10V	
C	508	QETC1AM-476Z	E CAPACITOR	47MF 20% 10V		C	621	QETC1AM-477ZN	E CAPACITOR	470MF 20% 10V	
C	509	QCS11HJ-680	C CAPACITOR	68PF 5% 50V		C	623	QETC1AM-476ZN	E CAPACITOR	470MF 20% 10V	
C	510	QCCB1HK-2R2Y	C CAPACITOR	2.2PF 10% 50V		C	624	VMC162-010	* * * CONNECTOR		
C	511	QCC11EM-223V	C CAPACITOR	.022MF 20% 25V		F	01	VQZL0048-003	INDUCTOR		
C	512	QCCS11HJ-220	C CAPACITOR	22PF 5% 50V		F	02	VQZL0048-006	EMI FILTER		
C	513	QCCB1HK-820Y	C CAPACITOR	82PF 10% 50V		I	C501	MC13501M	IC		
C	514	QCVB1CM-103Y	C CAPACITOR	.010MF 20% 16V		I	C502	NJN3403D-C	IC		
C	515	QCC11EM-473V	C CAPACITOR	.047MF 20% 25V		I	C503	BAO294	IC		
C	516	QCS11HJ-470	C CAPACITOR	47PF 5% 50V		I	C504	BA6294	IC		
C	517	QCCB1HK-151Y	C CAPACITOR	150PF 10% 50V		I	C505	TC9200BF	IC		
C	518	QCCB1HK-101Y	C CAPACITOR	100PF 10% 50V		I	C506	TC9200BF	IC		
C	519	QCS11HJ-330Y	C CAPACITOR	33PF 5% 50V		I	C605	TD6710AF	IC		
C	520	QCXB1CM-222Y	C CAPACITOR	2200PF 20% 16V		I	C607	TD6710BN	IC		
C	521	QE441CM-476	E CAPACITOR	47MF 20% 16V		Q	501	ZSA1309(RS)	TRANSISTOR		L.P.F
C	522	QCCB1HK-221Y	C CAPACITOR	220PF 10% 50V		Q	503	ZSC311A(QR)	TR.I.M		
C	523	QCCB1HK-222Y	C CAPACITOR	220PF 10% 50V		Q	504	ZSC311A(QR)	TR.I.M		
C	525	GER11EM-473V	E CAPACITOR	4.7MF 20% 25V		Q	505	ZSA1309(RS)	TRANSISTOR		
C	526	GER61AM-476Z	E CAPACITOR	47MF 20% 10V		Q	614	2SD1302(S,T)	TRANSISTOR		
C	527	QEPI1AM-105M	NP CAPACITOR	1.0MF 20% 50V		R	501	QRD161J-184	CARBON RESISTOR	180K 5%	1/6W
C	528	QFV41HJ-123	E CAPACITOR	012MF 5% 50V		R	502	QRD161J-154	CARBON RESISTOR	150K 5%	1/6W
C	529	QFV11HJ-273AZM	TF CAPACITOR	.027MF 5% 50V		R	503	QRD161J-682	CARBON RESISTOR	6.8K 5%	1/6W
C	531	QCVB1CM-822Y	C CAPACITOR	8200PF 20% 16V		R	504	QRD161J-472	CARBON RESISTOR	4.7K 5%	1/6W
C	535	QFV41HJ-224	TF CAPACITOR	.22MF 5% 50V		R	505	QRD161J-102	CARBON RESISTOR	1.0K 5%	1/6W
C	544	QCS11HJ-100	C CAPACITOR	10PF 5% 50V		R	506	QRD161J-681	CARBON RESISTOR	680 5%	1/6W
C	545	QCS11HJ-100	C CAPACITOR	10PF 5% 50V		R	507	QRD161J-104	CARBON RESISTOR	100K 5%	1/6W
C	547	QFV81HJ-473	TF CAPACITOR	.047MF 5% 50V		R	508	QRD161J-273	CARBON RESISTOR	27K 5%	1/6W
C	548	QETC1AM-476Z	E CAPACITOR	47MF 20% 10V		R	509	QRD161J-222	CARBON RESISTOR	2.2K 5%	1/6W
C	549	QCC11EM-473V	C CAPACITOR	.047MF 20% 25V		R	510	QRD161J-103	CARBON RESISTOR	10K 5%	1/6W
C	550	QCCB1HK-331Y	C CAPACITOR	330PF 10% 50V		R	511	QRD161J-103	CARBON RESISTOR	10K 5%	1/6W
C	551	QETC1AM-476Z	E CAPACITOR	47MF 20% 10V		R	512	QRD161J-123	CARBON RESISTOR	12K 5%	1/6W
C	552	QETC1AM-476Z	E CAPACITOR	47MF 20% 10V		R	513	QRD161J-103	CARBON RESISTOR	10K 5%	1/6W
C	553	QCY41HK-122	C CAPACITOR	12000PF 10% 50V		R	514	QRD161J-333	CARBON RESISTOR	33K 5%	1/6W
C	554	GETC1EM-108Z	E CAPACITOR	10MF 20% 25V		R	515	QRD161J-153	CARBON RESISTOR	15K 5%	1/6W
C	555	QCY41HK-122	C CAPACITOR	12000PF 10% 50V		R	516	QRD161J-822	CARBON RESISTOR	8.2K 5%	1/6W
C	556	GETC1AM-476Z	E CAPACITOR	47MF 20% 10V		R	517	QRD161J-152	CARBON RESISTOR	8.2K 5%	1/6W
C	557	QCCB1HK-331Y	C CAPACITOR	330PF 10% 50V		R	519	QRD161J-823	CARBON RESISTOR	82K 5%	1/6W
C	563	QFV41HJ-123	FILM CAPACITOR	.012MF 5% 50V		R	520	QRV141F-3302AY	CMF RESISTOR	33 1%	1/4W
C	587	QCS11HJ-470	C CAPACITOR	47PF 5% 50V		R	521	QRD161J-823	CARBON RESISTOR	82K 5%	1/6W
C	591	QCC11EM-223V	C CAPACITOR	.022MF 20% 25V		R	522	QRD161J-102	CARBON RESISTOR	1.0K 5%	1/6W
C	604	QETC1EM-226Z	E CAPACITOR	22MF 20% 25V		R	523	QRD167J-562	CARBON RESISTOR	10K 5%	1/6W
C	605	QETC1EM-226Z	E CAPACITOR	22MF 20% 25V		R	524	QRD161J-152	CARBON RESISTOR	1.5K 5%	1/6W
C	606	QCXB1CM-562Y	C CAPACITOR	5600PF 20% 16V		R	525	QRD161J-273	CARBON RESISTOR	27K 5%	1/6W
C	607	QCXB1CM-562Y	C CAPACITOR	5600PF 20% 16V		R	526	QRD167J-682	CARBON RESISTOR	6.8K 5%	1/6W
C	608	QCXB1CM-562Y	C CAPACITOR	6800PF 20% 16V		R	527	QRD161J-564	CARBON RESISTOR	560K 5%	1/6W
C	609	QCXB1CM-682Y	C CAPACITOR	6800PF 20% 16V		R	528	QRD161J-153	CARBON RESISTOR	15K 5%	1/6W
C	610	QCS11HJ-680	C CAPACITOR	68PF 5% 50V		R	529	QRD161J-103	CARBON RESISTOR	10K 5%	1/6W
C	611	QCS11HJ-680	C CAPACITOR	68PF 5% 50V		R	530	QRD161J-103	CARBON RESISTOR	10K 5%	1/6W
C	612	QETC1EM-226Z	E CAPACITOR	22MF 20% 25V		R	531	QRD161J-821	CARBON RESISTOR	820 5%	1/6W
C	613	QETC1EM-226Z	E CAPACITOR	22MF 20% 25V		R	532	QRD161J-153	CARBON RESISTOR	15K 5%	1/6W
C	614	QCC11EM-123V	C CAPACITOR	.012MF 20% 25V		R	533	QRD161J-103	CARBON RESISTOR	10K 5%	1/6W
C	615	QCC11EM-123V	C CAPACITOR	.012MF 20% 25V		R	534	QRD161J-821	CARBON RESISTOR	820 5%	1/6W

BLOCK NO. [02]|||||

A. REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX	A. REF.	PARTS NO.	PARTS NAME	REMARKS	BLOCK NO. [02]
R 535	QRD161J-272	CARBON RESISTOR 2.7K 5% 1/6W			R 696	QRD161J-183	CARBON RESISTOR 18K 5% 1/6W		
R 536	QRD161J-104	CARBON RESISTOR 100K 5% 1/6W			R 697	QRV141F-3302AY	CMF RESISTOR 33 1% 1/4W		
R 537	QRD161J-563	CARBON RESISTOR 56K 5% 1/6W			R 698	QRD167J-682	CARBON RESISTOR 6.8K 5% 1/6W		
R 538	QRD161J-153	CARBON RESISTOR 15K 5% 1/6W			A R 699	QRD121J-2R2	CARBON RESISTOR 2.2 5% 1/2W		
R 539	QRD161J-333	CARBON RESISTOR 33K 5% 1/6W			VRS01	QVPA001-503A	V RESISTOR	E/F BALANCE	
R 540	QRD167J-562	CARBON RESISTOR 5.6K 5% 1/6W			X 601	VCX5016-934V	CRYSTAL		
R 541	QRD161J-104	CARBON RESISTOR 100K 5% 1/6W							
R 542	QRD161J-223	CARBON RESISTOR 22K 5% 1/6W							
R 544	QRD161J-392	CARBON RESISTOR 3.9K 5% 1/6W							
R 545	QRD161J-103	CARBON RESISTOR 10K 5% 1/6W							
R 546	QRD161J-104	CARBON RESISTOR 100K 5% 1/6W							
R 547	QRD161J-473	CARBON RESISTOR 47K 5% 1/6W							
R 548	QRD161J-683	CARBON RESISTOR 6.8K 5% 1/6W							
R 549	QRD161J-181	CARBON RESISTOR 180 5% 1/6W							
R 550	QRD161J-103	CARBON RESISTOR 10K 5% 1/6W							
R 559	QRD161J-103	CARBON RESISTOR 10K 5% 1/6W							
R 560	QRD161J-103	CARBON RESISTOR 10K 5% 1/6W							
R 565	QRD161J-683	CARBON RESISTOR 68K 5% 1/6W							
R 566	QRD161J-181	CARBON RESISTOR 180 5% 1/6W							
R 570	QRD161J-103	CARBON RESISTOR 10K 5% 1/6W							
R 573	QRD161J-183	CARBON RESISTOR 18K 5% 1/6W							
R 640	QRD161J-471	CARBON RESISTOR 470 5% 1/6W							
R 641	QRD161J-101	CARBON RESISTOR 100 5% 1/6W							
R 642	QRD161J-102	CARBON RESISTOR 1.0K 5% 1/6W							
R 643	QRD161J-102	CARBON RESISTOR 1.0K 5% 1/6W							
R 645	QRD161J-151	CARBON RESISTOR 150 5% 1/6W							
R 647	QRD161J-102	CARBON RESISTOR 1.0K 5% 1/6W							
R 649	QRD161J-102	CARBON RESISTOR 1.0K 5% 1/6W							
R 660	QRD161J-272	CARBON RESISTOR 2.7K 5% 1/6W							
R 661	QRD161J-272	CARBON RESISTOR 2.7K 5% 1/6W							
R 662	QRD167J-332	CARBON RESISTOR 3.3K 5% 1/6W							
R 663	QRD167J-332	CARBON RESISTOR 3.3K 5% 1/6W							
R 664	QRD161J-103	CARBON RESISTOR 10K 5% 1/6W							
R 665	QRD161J-103	CARBON RESISTOR 10K 5% 1/6W							
R 666	QRD161J-103	CARBON RESISTOR 10K 5% 1/6W							
R 667	QRD161J-103	CARBON RESISTOR 10K 5% 1/6W							
R 668	QRD167J-332	CARBON RESISTOR 3.3K 5% 1/6W							
R 669	QRD167J-332	CARBON RESISTOR 3.3K 5% 1/6W							
R 672	QRD161J-122	CARBON RESISTOR 1.2K 5% 1/6W							
R 673	QRD161J-122	CARBON RESISTOR 1.2K 5% 1/6W							
R 674	QRD161J-104	CARBON RESISTOR 100K 5% 1/6W							
R 675	QRD161J-104	CARBON RESISTOR 100K 5% 1/6W							
R 676	QRV141F-8202AY	CMF RESISTOR 82 1% 1/4W							
R 677	QRD161J-333	CARBON RESISTOR 33K 5% 1/6W							
R 678	QRV141F-3302AY	CMF RESISTOR 33 1% 1/4W							
R 681	QRV141F-8202AY	CMF RESISTOR 82 1% 1/4W							
R 682	QRV141F-3302AY	CMF RESISTOR 33 1% 1/4W							
R 684	QRV141F-8202AY	CMF RESISTOR 82 1% 1/4W							
R 685	QRD161J-473	CARBON RESISTOR 47K 5% 1/6W							
R 686	QRV141F-3302AY	CMF RESISTOR 33 1% 1/4W							
R 687	QRD161J-103	CARBON RESISTOR 10K 5% 1/6W							
R 688	QRD161J-103	CARBON RESISTOR 10K 5% 1/6W							
R 691	QRV141F-8202AY	CMF RESISTOR 82 1% 1/4W							
R 692	QRD161J-823	CARBON RESISTOR 82K 5% 1/6W							
R 695	QRV141F-8202AY	CMF RESISTOR 82 1% 1/4W							

■ Tuner P.C. Board Parts List

BLOCK NO. [3] [] []

REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX	REMARKS
BP 01	VBP4M3B-005	BP FILTER			
C 001	QCS11HJ-200	C CAPACITOR	20PF 5% 50V		
C 002	QCBB1HK-102Y	C CAPACITOR	1000PF 10% 50V		
C 003	QCBB1HJ-130Y	C CAPACITOR	13PF 5% 50V		
C 004	QCT05UJ-100	C CAPACITOR	10PF 5% 50V		
C 005	QCT05UJ-180	C CAPACITOR	18PF 5% 50V		
C 006	QCVB1CN-103Y	C CAPACITOR	.010MF 30% 16V		
C 007	QCT30CH-200Y	C CAPACITOR	20PF 5% 50V		
C 008	QCVB1CN-103Y	C CAPACITOR	.010MF 30% 16V		
C 009	QCT05UJ-100	C CAPACITOR	10PF 5% 50V		
C 010	QCT30CH-22Y	C CAPACITOR	2.2PF 5% 50V		
C 011	QCVB1CN-103Y	C CAPACITOR	.010MF 30% 16V		
C 012	QCBB1HK-151Y	C CAPACITOR	150PF 10% 50V		
C 013	QCC11EM-223V	C CAPACITOR	.022MF 20% 25V		
C 014	QCBB1HK-102Y	C CAPACITOR	1000PF 10% 50V		
C 015	QCBB1HK-151Y	C CAPACITOR	150PF 10% 50V		
C 016	QCVB1CN-103Y	C CAPACITOR	.010MF 30% 16V		
C 017	QCBB1HK-102Y	C CAPACITOR	1000PF 10% 50V		
C 018	QCVB1CN-103Y	C CAPACITOR	.010MF 30% 16V		
C 021	QCC11EM-473V	C CAPACITOR	.047MF 20% 25V		
C 022	QFP31HG-4312M	PP CAPACITOR	430PF 2% 50V		
C 023	QCT05UJ-150	C CAPACITOR	15PF 5% 50V		
C 030	QCVB1CN-103Y	C CAPACITOR	.010MF 30% 16V		
C 031	QCVB1CN-103Y	C CAPACITOR	.010MF 30% 16V		
C 032	QCVB1CN-103Y	C CAPACITOR	.010MF 30% 16V		
C 033	QEK61AM-1072M	E CAPACITOR	100MF 20% 10V		
C 034	QCC31EM-3332V	C CAPACITOR	.033MF 20% 25V		
C 035	QCC11EM-473V	C CAPACITOR	.047MF 20% 25V		
C 036	QEK41EM-475	E CAPACITOR	4.7MF 20% 25V		
C 037	QCVB1CN-103Y	C CAPACITOR	.010MF 30% 16V		
C 038	QCBB1HK-102Y	C CAPACITOR	1000PF 10% 50V		
C 039	QCC11EM-473V	C CAPACITOR	.047MF 20% 25V		
C 040	QEK41HM-335	E CAPACITOR	3.3MF 20% 50V		
C 041	QEK41HM-335	E CAPACITOR	3.3MF 20% 50V		
C 042	QCXB1CM-152Y	C CAPACITOR	1500PF 20% 16V		
C 043	QCVB1CN-103Y	C CAPACITOR	.010MF 30% 16V		
C 044	QEK41HM-104	E CAPACITOR	.010MF 20% 50V		
C 045	QEK41HM-474	E CAPACITOR	.47MF 20% 50V		
C 046	QEK41CM-106	E CAPACITOR	10MF 20% 16V		
C 047	QCC11EK-1532V	C CAPACITOR	.015MF 10% 25V		
C 048	QCC11EK-1532V	C CAPACITOR	.015MF 10% 25V		
C 049	QEK41HM-105	E CAPACITOR	1.0MF 20% 50V		
C 050	QEK41HM-105	E CAPACITOR	1.0MF 20% 50V		
C 053	QCBB1HK-150	C CAPACITOR	1000PF 10% 50V		
C 059	QCBB1HK-102Y	C CAPACITOR	1000PF 10% 50V		
C 060	QCBB1HK-102Y	C CAPACITOR	100MF 20% 10V		
C 061	QEK61AM-1072M	E CAPACITOR	13PF 5% 50V		
C 062	QCBB1HJ-130Y	C CAPACITOR	.047MF 20% 25V		
C 063	QCC11EM-473V	C CAPACITOR	27PF 5% 50V		
C 064	QCS11HJ-270	C CAPACITOR			
C 065	QCBB1HK-151Y	C CAPACITOR	150PF 10% 50V		
C 066	QCBB1HK-151Y	C CAPACITOR	150PF 10% 50V		
C 067	QCBB1HK-151Y	C CAPACITOR	2200PF 20% 16V		
C 069	QCVB1CM-222Y	C CAPACITOR	2.2MF 20% 50V		
C 070	QEK41HM-225	E CAPACITOR			

REF.	PARTS NO.	PARTS NAME	SUFFIX	REMARKS	REMARKS	SUFFIX
C 071	QEK41HM-335	E CAPACITOR		3.3MF 20%	50V	
CF 01	VCF2L3B-105	C FILTER				
CF 02	VCF2L3B-105	C FILTER				
CF 03	VCF1Z2Z-105Z	C FILTER				
CF 04	CSB456F18	CERLOCK				
CN 01	TXLP-010-B	CONNECTOR				
D 001	KV1350NT	VARI CAP				
D 002	KV1350NT	VARI CAP				
D 003	KV1350NT	VARI CAP				
D 004	KV1350NT	VARI CAP				
D 005	MA165	SI DIODE				
D 006	MA165	SI DIODE				
D 007	MA165	SI DIODE				
D 008	KV1550NTA	VARI CAP				
D 009	KV1550NTA	VARI CAP				
D 012	MA165	SI DIODE				
D 013	MA165	SI DIODE				
D 014	MA165	SI DIODE				
IC 01	TA7358P(N)	IC				
IC 02	TA8132AN	IC				
IC 03	TC9216P	IC				
J 001	EMB90YV-401K	SPK. TERMINAL				
L 001	VQF1B20-017	OSC COIL				
L 002	VQF1B12-004	RF COIL	(MW)			
L 003	VQZ003-010	RF COIL	(MW)			
L 004	VQM7U0C-4404	OSC COIL	(MW)			
L 007	VQP025L-4R7Y	INDUCTOR				
L 008	VQP025L-221Y	INDUCTOR				
L 009	VQP025L-4R7Y	INDUCTOR				
L 010	VQP025L-4R7Y	INDUCTOR				
L 011	VQP025L-4R7Y	INDUCTOR				
Q 001	2SC1921(0)	TRANSISTOR				
Q 007	2SC2835(E)	TRANSISTOR				
Q 008	DTC14YS	TR. I. M.				
Q 009	DTA14YS	TRANSISTOR				
Q 010	DTA14YS	TRANSISTOR				
Q 011	DTA14YS	TRANSISTOR				
Q 012	2SC3311(R,S)	TRANSISTOR				
Q 013	2SC3311(R,S)	TRANSISTOR				
R 001	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W			
R 002	QRD161J-473	CARBON RESISTOR	47K 5% 1/6W			
R 003	QRD157J-4R7	CARBON RESISTOR	4.7% 5% 1/6W			
R 004	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W			
R 005	QRD161J-823	CARBON RESISTOR	82K 5% 1/6W			
R 006	QRD161J-101	CARBON RESISTOR	100K 5% 1/6W			
R 007	QRC121K-225	COMP. RESISTOR	2.2M 10% 1/2W			
R 008	QRD161J-101	CARBON RESISTOR	100 5% 1/6W			
R 009	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W			
R 010	QRD161J-101	CARBON RESISTOR	100 5% 1/6W			
R 013	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W			
R 01	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W			
R 020	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W			
R 024	QRD161J-331	C RESISTOR	330 5% 1/6W			
R 025	QRD161J-394	C RESISTOR	390K 5% 1/6W			
R 026	QRD161J-100	CARBON RESISTOR	10 5% 1/6W			

■ Function/Display P.C. Board Parts List

LOCK NO. 03

A	REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX X
	R 027	GRD161J-331	CARBON RESISTOR	330 5% 1/6W	
	R 029	GRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
	R 030	GRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
	R 031	GRD161J-563	CARBON RESISTOR	56K 5% 1/6W	
	R 032	GRD161J-223	CARBON RESISTOR	22K 5% 1/6W	
	R 033	GRD161J-472	CARBON RESISTOR	4.7K 5% 1/6W	
	R 034	GRD161J-822	CARBON RESISTOR	8.2K 5% 1/6W	
	R 035	GRD161J-822	CARBON RESISTOR	8.2K 5% 1/6W	
	R 036	GRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
	R 037	GRD161J-560	CARBON RESISTOR	56.5% 1/6W	
	R 040	GRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
	R 041	GRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
	R 042	GRD161J-222	CARBON RESISTOR	2.7K 5% 1/6W	
	R 043	GRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
	R 044	GRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
	R 047	GRD161J-562	CARBON RESISTOR	56K 5% 1/6W	
	R 048	GRD161J-331	CARBON RESISTOR	330 5% 1/6W	
	R 049	GRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
	R 052	GRD161J-472	CARBON RESISTOR	4.7K 5% 1/6W	
	R 053	GRD161J-771	CARBON RESISTOR	470 5% 1/6W	
	R 054	GRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
	R 055	GRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
	R 056	GRD167J-332	CARBON RESISTOR	3.3K 5% 1/6W	
	R 057	GRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
	R 058	GRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
T	001	VQT7F12-110	IFT	FM IF	
T	002	VQT7A21-107	IFT	MW RF	
TC	002	QAT3722-200ZM	T CAPACITOR		
X	001	V472124-A0	CRYSTAL		

A	REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
CF 01	QEK41EM-315	E CAPACITOR	3-3MF 20% 25V		
CF 02	QEK41CM-476	E CAPACITOR	4.7MF 20% 16V		
CF 03	QEK41CM-336	E CAPACITOR	3.3MF 20% 16V		
CF 04	QEK41CM-476	E CAPACITOR	4.7MF 20% 16V		
CF 05	QEK41CM-336	E CAPACITOR	3.3MF 20% 16V		
CF 06	QEK41CM-476	E CAPACITOR	4.7MF 20% 16V		
CF 07	QEK41HM-105	E CAPACITOR	1.0MF 20% 50V		
CF 08	QFV81HJ-683	TF CAPACITOR	.068MF 5% 50V		
CF 09	QFV81HJ-683	TF CAPACITOR	.068MF 5% 50V		
CF 10	QFV81HJ-683	TF CAPACITOR	.068MF 5% 50V		
CF 11	QCB1HK-102Y	C CAPACITOR	1000PF 10% 50V		
CF 12	QCVB1CM-103Y	C CAPACITOR	.010MF 20% 16V		
CF 13	QEK41CM-476	C CAPACITOR	4.7MF 20% 16V		
CF 15	QEK41HM-225	E CAPACITOR	2.2MF 20% 50V		
CF 16	QCB1HK-102Y	C CAPACITOR	1000PF 10% 50V		
CF 17	QEKB1AM-107ZM	E CAPACITOR	100MF 20% 10V		
CF 18	QCB1HK-102Y	C CAPACITOR	1000PF 10% 50V		
CF 19	QEK41CM-476	E CAPACITOR	4.7MF 20% 16V		
CF 20	QEK41CM-476	E CAPACITOR	4.7MF 20% 16V		
CF 22	QCVB1CM-103Y	C CAPACITOR	.010MF 20% 16V		
CF 23	QCVB1CM-103Y	C CAPACITOR	.010MF 20% 16V		
CF 24	QCVB1CM-103Y	C CAPACITOR	.010MF 20% 16V		
CF101	QEK41HM-105	E CAPACITOR	1.0MF 20% 50V		
CF102	QEK41CM-106	E CAPACITOR	1.0MF 20% 16V		
CF103	QEK41HM-105	E CAPACITOR	1.0MF 20% 50V		
CF104	QCXB1CM-562Y	C CAPACITOR	5600PF 20% 16V		
CF105	QCS11HJ-330	C CAPACITOR	33PF 5% 50V		
CF106	QFV81HJ-224	TF CAPACITOR	.22MF 5% 50V		
CF107	QFV81HJ-683	E CAPACITOR	.068MF 5% 50V		
CF108	QEK41HM-105	E CAPACITOR	1.0MF 20% 50V		
CF109	QEK41EM-75	E CAPACITOR	4.7MF 20% 25V		
CF111	QEK41HM-105	E CAPACITOR	1.0MF 20% 50V		
CF112	QCS11HJ-330	C CAPACITOR	33PF 5% 50V		
CF113	QEK41CM-226	E CAPACITOR	22MF 20% 16V		
CF114	QFV81HJ-333	E CAPACITOR	.033MF 5% 50V		
CF116	QCB1HK-151Y	C CAPACITOR	150PF 10% 50V		
CF117	QCS11HJ-330	C CAPACITOR	33PF 5% 50V		
CF201	QEK41HM-105	E CAPACITOR	1.0MF 20% 50V		
CF202	QEK41CM-106	E CAPACITOR	10MF 20% 16V		
CF203	QEK41HM-105	E CAPACITOR	1.0MF 20% 50V		
CF204	QCXB1CM-562Y	C CAPACITOR	5600PF 20% 16V		
CF205	QCS11HJ-330	C CAPACITOR	33PF 5% 50V		
CF206	QFV81HJ-224	TF CAPACITOR	.22MF 5% 50V		
CF207	QFV81HJ-683	E CAPACITOR	.068MF 5% 50V		
CF208	QEK41HM-105	E CAPACITOR	1.0MF 20% 50V		
CF209	QEK41EM-475	E CAPACITOR	4.7MF 20% 25V		
CF211	QEK41HM-105	E CAPACITOR	1.0MF 20% 50V		
CF212	QCS11HJ-330	C CAPACITOR	33PF 5% 50V		
CF213	QEK41CM-226	E CAPACITOR	22MF 20% 16V		
CF214	QFV81HJ-333	TF CAPACITOR	.033MF 5% 50V		
CF216	QCB1HK-151Y	C CAPACITOR	150PF 10% 50V		
CF217	QCS11HJ-330	C CAPACITOR	33PF 5% 50V		
CM 01	VCE0056-479Z	SUPER CAP.			
CM 02	QCB1HK-102Y	C CAPACITOR	1000PF 10% 50V		
CM 03	QET1AM-107ZN	E CAPACITOR	100MF 20% 10V		
CM 04	QCXB1HK-102Y	C CAPACITOR	1000PF 10% 50V		

BLOCK NO. [REDACTED]

BLOCK NO. [REDACTED]

A	REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX	
CM	05	QCT30CH-150Y	C CAPACITOR	15PF 5% 50V		
CM	06	QCT30CH-150Y	C CAPACITOR	15PF 5% 50V		TRANSISTOR
CM	07	QCS11HJ-560	C CAPACITOR	56PF 5% 50V		TRANSISTOR
CM	08	QCS11HJ-680	C CAPACITOR	68PF 5% 50V		TRANSISTOR
CM	09	QCS11HJ-180	C CAPACITOR	18PF 5% 50V		TRANSISTOR
CM	10	QCS11HJ-180	C CAPACITOR	18PF 5% 50V		TRANSISTOR
CM	11	QETC1HM-474Z	E CAPACITOR	E CAP 0.01		TRANSISTOR
CM	12	QCVB1CM-103Y	C CAPACITOR	150P		TRANSISTOR
CM	14	QCVB1CM-103Y	C CAPACITOR	0.01		TR
CM	15	QCVB1CM-103Y	C CAPACITOR	0.01		TRANSISTOR
CM	17	QETC1AM-107Z	E CAPACITOR	E CAP 100/10		TRANSISTOR
CM	24	QETC1AM-107Z	E CAPACITOR	M.VOL		TRANSISTOR
CM	26	QEKOJM-107Z	E CAPACITOR	100MF 20% 6.3V		TRANSISTOR
CM	27	QETC1CM-226Z	E CAPACITOR	22MF 20% 16V		TRANSISTOR
CM	28	QETC1HM-225Z	E CAPACITOR	2.2MF 20% 50V		TRANSISTOR
CM	29	QCT30CH-160Y	C CAPACITOR	16PF 5% 50V		FET
CNF01		VMC0162-R13	CONNECTOR			
CNF02		VMC162-R13	CONNECTOR			
CNM01		TXLP-007-B	CONNECTOR			
CNM02		VMC0162-R13	CONNECTOR			
CNM03		VMC0162-R13	CONNECTOR			
CNM04		TXLP-006-B	CONNECTOR			
CNM05		VMC0107-005	CONNECTOR			
CNM06		VMC0162-010	CONNECTOR			
CNM07		TTL25V-002	CONNECTOR	M.VOL		
DF	01	MA165	SI DIODE			
DF	03	MA165	SI DIODE			
DF	04	MA406	ZENNER DIODE			
DF	05	MA165	SI DIODE			
DF	06	MA165	SI DIODE			
DF	07	MA165	SI DIODE			
DF	08	MA4062 (M)	Z DIODE			
DF	09	MA4062 (H) TA	Z DIODE			
DF	10	MA165	SI DIODE			
DM	02	MA165	SI DIODE			
DM	04	11E1	SI DIODE			
DM	05	MA165	SI DIODE			
ICF01		VC4380L	IC			
ICF02		XRA15218N	IC			
ICF03		VC4380L	IC			
ICF04		VC4380LD	IC			
ICM01		HD404629A17FS	IC	UCOM (CTL)		
ICM04		VCR020-002	C NETWORK	CD.Door		
ICM06		BA6208A	IC	M.VOL		
LF	01	VQP025K-4R7Y	INDUCTOR			
LM	01	VQP025K-221Y	INDUCTOR			
LM	02	VQP025K-221Y	INDUCTOR			
LM	05	VQP025K-221Y	INDUCTOR			
LM	06	VQP025K-221Y	INDUCTOR			
LM	07	VQD0048-009	INDUCTOR			
PLM01		VG0P028-100Z	P.LAMP			
QF	01	UN4111	TRANSISTOR	BACK LIGHT		
QF	02	2SSB262(C)	TRANSISTOR			

A	REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX		SURFX
CM	05	QCT30CH-150Y	C CAPACITOR	15PF 5% 50V			TRANSISTOR
CM	06	QCT30CH-150Y	C CAPACITOR	15PF 5% 50V			TRANSISTOR
CM	07	QCS11HJ-560	C CAPACITOR	56PF 5% 50V			TRANSISTOR
CM	08	QCS11HJ-680	C CAPACITOR	68PF 5% 50V			TRANSISTOR
CM	09	QCS11HJ-180	C CAPACITOR	18PF 5% 50V			TRANSISTOR
CM	10	QCS11HJ-180	C CAPACITOR	18PF 5% 50V			TRANSISTOR
CM	11	QETC1HM-474Z	E CAPACITOR	0.01			TRANSISTOR
CM	12	QCVB1CM-103Y	C CAPACITOR	150P			TRANSISTOR
CM	14	QCVB1CM-103Y	C CAPACITOR	0.01			TR
CM	15	QCVB1CM-103Y	C CAPACITOR	0.01			TRANSISTOR
CM	17	QETC1AM-107Z	E CAPACITOR	E CAP 100/10			TRANSISTOR
CM	24	QETC1AM-107Z	E CAPACITOR	M.VOL			TRANSISTOR
CM	26	QEKOJM-107Z	E CAPACITOR	100MF 20% 6.3V			TRANSISTOR
CM	27	QETC1CM-226Z	E CAPACITOR	22MF 20% 16V			TRANSISTOR
CM	28	QETC1HM-225Z	E CAPACITOR	2.2MF 20% 50V			TRANSISTOR
CM	29	QCT30CH-160Y	C CAPACITOR	16PF 5% 50V			FET
CNF01		VMC0162-R13	CONNECTOR				
CNF02		VMC162-R13	CONNECTOR				
CNM01		TXLP-007-B	CONNECTOR				
CNM02		VMC0162-R13	CONNECTOR				
CNM03		VMC0162-R13	CONNECTOR				
CNM04		TXLP-006-B	CONNECTOR				
CNM05		VMC0107-005	CONNECTOR				
CNM06		VMC0162-010	CONNECTOR				
CNM07		TTL25V-002	CONNECTOR	M.VOL			
DF	01	MA165	SI DIODE				
DF	03	MA165	SI DIODE				
DF	04	MA406	ZENNER DIODE				
DF	05	MA165	SI DIODE				
DF	06	MA165	SI DIODE				
DF	07	MA165	SI DIODE				
DF	08	MA4062 (M)	Z DIODE				
DF	09	MA4062 (H) TA	Z DIODE				
DF	10	MA165	SI DIODE				
DM	02	MA165	SI DIODE				
DM	04	11E1	SI DIODE				
DM	05	MA165	SI DIODE				
ICF01		VC4380L	IC				
ICF02		XRA15218N	IC				
ICF03		VC4380L	IC				
ICF04		VC4380LD	IC				
ICM01		HD404629A17FS	IC	UCOM (CTL)			
ICM04		VCR020-002	C NETWORK	CD.Door			
ICM06		BA6208A	IC	M.VOL			
LF	01	VQP025K-4R7Y	INDUCTOR				
LM	01	VQP025K-221Y	INDUCTOR				
LM	02	VQP025K-221Y	INDUCTOR				
LM	05	VQP025K-221Y	INDUCTOR				
LM	06	VQP025K-221Y	INDUCTOR				
LM	07	VQD0048-009	INDUCTOR				
PLM01		VG0P028-100Z	P.LAMP				
QF	01	UN4111	TRANSISTOR	BACK LIGHT			
QF	02	2SSB262(C)	TRANSISTOR				

BLOCK NO. 04111111

BLOCK NO. 04111111


A	REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX	A. REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
	RF 30	QRD161J-223	CARBON RESISTOR	22K 5% 1/6W		RF213	QRD161J-123	CARBON RESISTOR	12K 5% 1/6W	
	RF 31	QRD161J-473	CARBON RESISTOR	4.7K 5% 1/6W		RF214	QRD161J-273	CARBON RESISTOR	27K 5% 1/6W	
	RF 32	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W		RF215	QRD161J-123	CARBON RESISTOR	12K 5% 1/6W	
	RF 33	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W		RF216	QRD161J-562	CARBON RESISTOR	5.6K 5% 1/6W	
	RF 34	QRD12CJ-4705X	C. RESISTOR	4.7 5% 1/2W		RF217	QRD161J-152	CARBON RESISTOR	1.5K 5% 1/6W	
	RF 35	QRD161J-472	CARBON RESISTOR	4.7K 5% 1/6W		RF218	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W	
	RF 36	QRD161J-101	CARBON RESISTOR	100 5% 1/6W		RF219	QRD167J-562	CARBON RESISTOR	5.6K 5% 1/6W	
	RF 39	QRD161J-101	CARBON RESISTOR	100 5% 1/6W		RF220	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
	RF 40	QRD161J-101	CARBON RESISTOR	100 5% 1/6W		RF221	QRD161J-683	CARBON RESISTOR	6.8K 5% 1/6W	
	RF 41	QRD161J-4722	CARBON RESISTOR	4.7K 5% 1/6W		RF222	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
	RF 42	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W		RF224	QRD161J-153	CARBON RESISTOR	15K 5% 1/6W	
	RF 43	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W		RF225	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
	RF 44	QRD161J-2R2	CARBON RESISTOR	2.2 5% 1/6W		RF226	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W	
	RF 53	QRD161J-100	CARBON RESISTOR	10 5% 1/6W		RF230	QRD161J-105	CARBON RESISTOR	1.0M 5% 1/6W	
	RF 54	QRD161J-100	CARBON RESISTOR	10 5% 1/6W		RF231	QRD161J-470	CARBON RESISTOR	4.7 5% 1/6W	
	RF101	QRD161J-683	CARBON RESISTOR	68K 5% 1/6W		RF232	QRD161J-334	CARBON RESISTOR	330K 5% 1/6W	
	RF103	QRD161J-333	CARBON RESISTOR	33K 5% 1/6W		RF233	QRD161J-621	CARBON RESISTOR	620 5% 1/6W	
	RF104	QRD161J-472	CARBON RESISTOR	4.7K 5% 1/6W		RF235	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W	
	RF106	QRD161J-472	CARBON RESISTOR	4.7K 5% 1/6W		RF236	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
	RF107	QRD161J-682	CARBON RESISTOR	6.8K 5% 1/6W		RF237	QRD161J-224	CARBON RESISTOR	220K 5% 1/6W	
	RF108	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W		RM 01	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
	RF109	QRD161J-123	CARBON RESISTOR	12K 5% 1/6W		RM 03	QRD161J-681	CARBON RESISTOR	680 5% 1/6W	
	RF110	QRD161J-823	CARBON RESISTOR	82K 5% 1/6W		RM 04	QRD161J-681	CARBON RESISTOR	680 5% 1/6W	
	RF111	QRD161J-221	CARBON RESISTOR	220 5% 1/6W		RM 05	QRD161J-331	CARBON RESISTOR	330 5% 1/6W	
	RF112	QRD161J-472	CARBON RESISTOR	4.7K 5% 1/6W		RM 07	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
	RF113	QRD161J-123	CARBON RESISTOR	12K 5% 1/6W		RM 08	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
	RF114	QRD161J-223	CARBON RESISTOR	27K 5% 1/6W		RM 09	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
	RF115	QRD161J-123	CARBON RESISTOR	12K 5% 1/6W		RM 10	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
	RF116	QRD167J-562	CARBON RESISTOR	5.6K 5% 1/6W		RM 11	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
	RF117	QRD161J-152	CARBON RESISTOR	1.5K 5% 1/6W		RM 13	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
	RF118	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W		RM 15	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
	RF119	QRD167J-562	CARBON RESISTOR	5.6K 5% 1/6W		RM 16	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
	RF120	QRD161J-222	CARBON RESISTOR	2.2 5% 1/6W		RM 19	QRD161J-223	CARBON RESISTOR	22K 5% 1/6W	
	RF121	QRD161J-683	CARBON RESISTOR	68K 5% 1/6W		RM 20	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
	RF122	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W		RM 21	QRD161J-223	CARBON RESISTOR	22K 5% 1/6W	
	RF124	QRD161J-153	CARBON RESISTOR	15K 5% 1/6W		RM 24	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
	RF128	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W		RM 25	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
	RF129	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W		RM 26	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
	RF130	QRD161J-105	CARBON RESISTOR	1.0M 5% 1/6W		RM 27	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
	RF131	QRD161J-470	CARBON RESISTOR	4.7 5% 1/6W		RM 28	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
	RF132	QRD161J-334	CARBON RESISTOR	330K 5% 1/6W		RM 29	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
	RF133	QRD161J-621	CARBON RESISTOR	620 5% 1/6W		RM 30	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
	RF135	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W		RM 31	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
	RF136	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W		RM 32	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
	RF137	QRD161J-224	CARBON RESISTOR	220K 5% 1/6W		RM 33	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
	RF201	QRD161J-683	CARBON RESISTOR	68K 5% 1/6W		RM 34	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
	RF203	QRD161J-333	CARBON RESISTOR	33K 5% 1/6W		RM 35	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	
	RF204	QRD161J-472	CARBON RESISTOR	4.7K 5% 1/6W		RM 36	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
	RF205	QRD161J-103	CARBON RESISTOR	12K 5% 1/6W		RM 37	QRD161J-103	CARBON RESISTOR	2.2K 5% 1/6W	
	RF209	QRD161J-123	CARBON RESISTOR	12K 5% 1/6W		RM 38	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
	RF210	QRD161J-823	CARBON RESISTOR	82K 5% 1/6W		RM 40	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
	RF211	QRD161J-221	CARBON RESISTOR	220 5% 1/6W		RM 42	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
	RF212	QRD161J-472	CARBON RESISTOR	4.7K 5% 1/6W		RM 43	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
						RM 45	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W	

■ Operation Switch P.C. Board Parts List BLOCK NO. 05111111

A	REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX	A	REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
	RM 46	QRD161J-102	CARBON RESISTOR 1.0K 5% 1/6W				CNC01	TXLP-002-B	CONNECTOR		
	RM 47	QRD161J-103	CARBON RESISTOR 10K 5% 1/6W				CNT01	TXLP-008-B	CONNECTOR		
	RM 49	QRD161J-473	CARBON RESISTOR 7K 5% 1/6W				CNV01	TXLP-005-B	CONNECTOR		
	RM 50	QRD161J-472	CARBON RESISTOR LM07				CS 01	QCBBAHK-151Y	C CAPACITOR	150PF 10% 50V	
	RM 52	QRD161J-4R7	CARBON RESISTOR M.VOL				DS 01	GL3PR8	L.E.D.		
	RM 53	QRD161J-103	CARBON RESISTOR M.VOL				DS 02	GL3PR8	SI DIODE		
	RM 54	QRD161J-222	CARBON RESISTOR M.VOL				DS 03	MA165	L.E.D.		
	RM 55	QRD161J-222	CARBON RESISTOR 2.2K 5% 1/6W				RS 03	QRD161J-392	CARBON RESISTOR	3.9K 5% 1/6W	
	RM 57	QRD161J-222	CARBON RESISTOR 2.2K 5% 1/6W				RS 04	QRD167J-682	CARBON RESISTOR	6.8K 5% 1/6W	
	RM 58	QRD161J-105	CARBON RESISTOR 1.0M 5% 1/6W				RS 05	QRD161J-123	CARBON RESISTOR	12K 5% 1/6W	
	RM 59	QRD161J-103	CARBON RESISTOR 10K 5% 1/6W				RS 06	QRD161J-393	CARBON RESISTOR	39K 5% 1/6W	
	RM 60	QRD161J-473	CARBON RESISTOR 4.7K 5% 1/6W				RS 07	QRD161J-152	CARBON RESISTOR	1.5K 5% 1/6W	
	RM 62	QRD161J-222	CARBON RESISTOR 2.2K 5% 1/6W				RS 08	QRD161J-272	CARBON RESISTOR	2.7K 5% 1/6W	
	RM 63	QRD161J-102	CARBON RESISTOR 1.0K 5% 1/6W				RS 09	QRD161J-392	CARBON RESISTOR	6.8K 5% 1/6W	
	RM 64	QRD161J-222	CARBON RESISTOR 2.2K 5% 1/6W				RS 10	QRD167J-682	CARBON RESISTOR	12K 5% 1/6W	
	RM 65	QRD161J-222	CARBON RESISTOR 2.2K 5% 1/6W				RS 11	QRD161J-123	CARBON RESISTOR	39K 5% 1/6W	
	RM 66	QRD161J-473	CARBON RESISTOR 4.7K 5% 1/6W				RS 12	QRD161J-393	CARBON RESISTOR	1.5K 5% 1/6W	
	RM 67	QRD161J-183	CARBON RESISTOR 18K 5% 1/6W				RS 13	QRD167J-332	CARBON RESISTOR	2.7K 5% 1/6W	
	RM 68	QRD161J-683	CARBON RESISTOR 68K 5% 1/6W				RS 15	QRD161J-561	CARBON RESISTOR	560 5% 1/6W	
	RM 69	QRD161J-103	CARBON RESISTOR 10K 5% 1/6W				RS 16	QRD161J-561	CARBON RESISTOR	560 5% 1/6W	
	RM 70	QRD161J-223	CARBON RESISTOR 22K 5% 1/6W				RS 17	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	
	RM 71	QRD161J-102	CARBON RESISTOR 1.0K 5% 1/6W				SC 01	QSPPK21-V01	PUSH SWITCH		
	RM 72	QRD161J-102	CARBON RESISTOR 1.0K 5% 1/6W				SC 02	QSPPK21-V01	PUSH SWITCH		
	RM 73	QRD161J-103	CARBON RESISTOR 10K 5% 1/6W				SS 01	QS04H11-V02Z	TACT SW		
	RM 74	QRD161J-102	CARBON RESISTOR 1.0K 5% 1/6W				SS 02	QS04H11-V02Z	TACT SW		
	RM 75	QRD161J-103	CARBON RESISTOR 10K 5% 1/6W				SS 03	QS04H11-V02Z	TACT SW		
	RM 76	QRD161J-153	CARBON RESISTOR 15K 5% 1/6W				SS 04	QS04H11-V02Z	TACT SW		
	RM 77	QRD161J-3R9	C RESISTOR 3.9 5% 1/6W				SS 05	QS04H11-V02Z	TACT SW		
	RM 79	QRD161J-124	CARBON RESISTOR 120K 5% 1/6W				SS 06	QS04H11-V02Z	TACT SW		
	RM 80	QRD161J-102	CARBON RESISTOR 1.0K 5% 1/6W				SS 07	QS04H11-V02Z	TACT SW		
	RM 81	QRD161J-332	CARBON RESISTOR 3.3K 5% 1/6W				SS 08	QS04H11-V02Z	TACT SW		
	TF 01	EQF0101-002	DOLBY FILTER				SS 09	QS04H11-V02Z	TACT SW		
	XM 01	VX5000-001	CRYSTAL				SS 10	QS04H11-V02Z	TACT SW		
	XM 02	CSA4.19MG93	CERA LOCK				SS 11	QS04H11-V02Z	TACT SW		
							SS 12	QS04H11-V02Z	TACT SW		
							SS 13	QS04H11-V02Z	TACT SW		
							VRT01	VCV1001-110	BASS VR		
							VRT02	VCV1001-110	TREBLE VR		

BLOCK NO. 04111111

A	REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX	A	REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
	RM 46	QRD161J-102	CARBON RESISTOR 1.0K 5% 1/6W				RM 47	QRD161J-103	CARBON RESISTOR 10K 5% 1/6W		
	RM 49	QRD161J-473	CARBON RESISTOR 7K 5% 1/6W				RM 50	QRD161J-472	CARBON RESISTOR LM07		
	RM 52	QRD161J-4R7	CARBON RESISTOR M.VOL				RM 53	QRD161J-103	CARBON RESISTOR 1.0M 5% 1/6W		
	RM 55	QRD161J-222	CARBON RESISTOR M.VOL				RM 57	QRD161J-222	CARBON RESISTOR 2.2K 5% 1/6W		
	RM 58	QRD161J-105	CARBON RESISTOR 1.0M 5% 1/6W				RM 59	QRD161J-103	CARBON RESISTOR 10K 5% 1/6W		
	RM 60	QRD161J-473	CARBON RESISTOR 4.7K 5% 1/6W				RM 62	QRD161J-222	CARBON RESISTOR 2.2K 5% 1/6W		
	RM 62	QRD161J-222	CARBON RESISTOR 2.2K 5% 1/6W				RM 63	QRD161J-102	CARBON RESISTOR 1.0K 5% 1/6W		
	RM 64	QRD161J-222	CARBON RESISTOR 2.2K 5% 1/6W				RM 65	QRD161J-222	CARBON RESISTOR 2.2K 5% 1/6W		
	RM 66	QRD161J-473	CARBON RESISTOR 4.7K 5% 1/6W				RM 67	QRD161J-183	CARBON RESISTOR 18K 5% 1/6W		
	RM 68	QRD161J-683	CARBON RESISTOR 68K 5% 1/6W				RM 69	QRD161J-103	CARBON RESISTOR 10K 5% 1/6W		
	RM 70	QRD161J-223	CARBON RESISTOR 22K 5% 1/6W				RM 71	QRD161J-102	CARBON RESISTOR 1.0K 5% 1/6W		
	RM 72	QRD161J-102	CARBON RESISTOR 1.0K 5% 1/6W				RM 73	QRD161J-103	CARBON RESISTOR 10K 5% 1/6W		
	RM 74	QRD161J-102	CARBON RESISTOR 1.0K 5% 1/6W				RM 75	QRD161J-103	CARBON RESISTOR 10K 5% 1/6W		
	RM 76	QRD161J-153	CARBON RESISTOR 15K 5% 1/6W				RM 77	QRD161J-3R9	C RESISTOR 3.9 5% 1/6W		
	RM 79	QRD161J-124	CARBON RESISTOR 120K 5% 1/6W				RM 80	QRD161J-102	CARBON RESISTOR 1.0K 5% 1/6W		
	RM 81	QRD161J-332	CARBON RESISTOR 3.3K 5% 1/6W				RM 81	QRD161J-103	CARBON RESISTOR 1.0K 5% 1/6W		
	TF 01	EQF0101-002	DOLBY FILTER				TF 01	EQF0101-002	DOLBY FILTER		
	XM 01	VX5000-001	CRYSTAL				XM 01	VX5000-001	CRYSTAL		
	XM 02	CSA4.19MG93	CERA LOCK				XM 02	CSA4.19MG93	CERA LOCK		

13**Illustration of Packing and Parts List**BLOCK NO. **M8MM M9MM****Fig. 13-1****■ Packing Parts List**BLOCK NO. **M8MM**

A	REF.	PARTS NO.	PARTS NAME	REMARKS	Q'TY	SUFFIX	CLR
	P 1	VPC9189-001	CARTON		1		
	P 2	VPH1598-001	CUSHION		1		
	P 3	VPH1598-002	CUSHION		1		
	P 4	VPH1599-001	CUSHION		1		
	P 5	VPH1599-002	CUSHION		1		
	P 6	DH404-UX-A3	PORYFOAM		1		
	P 7	VPE3005-065	POLY BAG		1		
		VPE3005-065	POLY BAG	300 X 510	1		
	P 8	VPK4002-009	SHEET	300*510	1		
	P 9	DH434-PC-X1000	CUSHION MAT BAG		4		
	P 10	VPE3005-042	POLY BAG	AM LOOP ANT.	1		
	P 11	VPE3005-007	POLY BAG	INST. WARRANTY	1		
	P 12	QPGA010-03003	POLY.BAG	ACCESSORY	1		
	P 13	VND3044-001	SERIAL TICKET		1	A, U	
		VND3044-006	SERIAL TICKET		1	C	
	P 14	VND3044-002	SERIAL TICKET		2	J	
	P 15	VND3070-044	UPC CODE LABEL		1		
	P 16	E66416-003	ENVELOPE		1	J	
		VPK3001-003	SHEET	WARRANTY CARD 470*210	1		

14 Accessories

■ Accessories Parts List

BLOCK NO. M9MM

REF.	PARTS NO.	PARTS NAME	REMARKS	QTY	SUFFIX	CLR
A 1	VNN9189-111S	INSTRUCTIONS	ENGL, SPAN, ARAB	1	A, U	
	VNN9189-611S	INSTRUCTIONS	ENGL, SPAN, FREN	1	C, J	
A 2	BT-20025K	WARRANTY CARD		1	C	
	BT-20122	WARRANTY CARD		1	A	
	BT-20122-1-A	WARRANTY CARD		1	A	
	BT20071A	SVC CENTER LIST		1	C	
	BT-20044G	SAFETY INST.		1	J	
A 3	BT-20137	SERVICE NETWORK		1	J	
A 4	BT-20047F	WARRANTY CARD		1	J	
A 5	EQB4001-015	AM LOOP ANT		1		
A 6	VMP0093-002	SPEAKER CORD		2		
A 7	R03BPA-2ST	BATTERY	FOR REMOCON	2		
A 8	V04062-001	CONTCH.PLUG		1	U	
A 9	VGR0013-001	REMOCON UNIT	RM-RX1001	1		
A 10	EWP502-001	FM ANTENNA		1		

VICTOR COMPANY OF JAPAN, LIMITED
 PERSONAL AUDIO PRODUCTS DIVISION 10-1, 1-chome, Ohwatari-machi, Maebashi-city, Japan