


JVC

SERVICE MANUAL

MICRO COMPONENT SYSTEM

UX -T3 A/US/U



COMPACT
disc
DIGITAL AUDIO

Area Suffix

A	Australia
US	Singapore
U	Other Areas

Contents

1. Safety Precautions.....	Page 2	10. Block Diagram	55
2. Safety Precaution about UX - T3.....	3	11. Wiring Connections	56
3. Main Features.....	6	12. IC Block Diagram	57
4. Specifications.....	6	13. Standard Schematic Diagram	63
5. Instructions	7	14. Location of P.C. Board Parts.....	68
6. Location of Main Parts.....	33	15. Electrical Parts List.....	73
7. Removal of Main Parts	36	16. Analytic Drawing and Parts List	84
8. Main Adjustment.....	45	17. Illustration of Packing and Parts List	90
9. Troubleshooting (CDPart)	50	18. Accessories	91

1. Safety Precautions


1. The design of this product contains special hardware and many circuits and components specially for safety purposes. For continued protection, no changes should be made to the original design unless authorized in writing by the manufacturer. Replacement parts must be identical to those used in the original circuits. Service should be performed by qualified personnel only.
2. Alterations of the design or circuitry of the product should not be made. Any design alterations of the product should not be made. Any design alterations or additions will void the manufacturer's warranty and will further relieve the manufacturer of responsibility for personal injury or property damage resulting therefrom.
3. Many electrical and mechanical parts in the products have special safety — related characteristics. These characteristics are often not evident from visual inspection nor can the protection afforded by them necessarily be obtained by using replacement components rated for higher voltage, wattage, etc. Replacement parts which have these special safety characteristics are identified in the Parts List of Service Manual. Electrical components having such features are identified by shading on the schematic and by (Δ) on the Parts List in the Service Manual. The use of a substitute replacement which does not have the same safety characteristics as the recommended replacement part shown in the Parts List of Service Manual may create shock, fire, or other hazards.
4. The leads in the products are routed and dressed with ties, clamps , tubings, barriers and the like to be separated from live parts, high temperature parts, moving parts and /or sharp edges for the prevention of electric shock and fire hazard. When service is required, the original lead routing and dress should be observed, and it should be confirmed that they have been returned to normal, after reassembling.
5. Leakage current check (Electrical shock hazard testing)

After reassembling the product, always perform an isolation check on the exposed metal parts of the product (antenna terminals, knobs, metal cabinet, screw heads, headphone jack, control shafts, etc.) to be sure the product is safe to operate without danger of electrical shock. Do not use a line isolation transformer during this check.

- Plug the AC line cord directly into the AC outlet. Using a "Leakage current tester", measure the leakage current from each exposed metal part of the cabinet, particularly any exposed metal part having a return path to the chassis, to a known good earth ground. Any leakage current must not exceed 0.5mA AC(r.m.s.).

• Alternate check method

Plug the AC line cord directly into the AC outlet. Use an AC voltmeter having, 1,000 ohms per volt or more sensitivity in the following manner. Connect a 1,500 ohms 10W resistor paralleled by a $0.15 \mu F$ AC type capacitor between an exposed metal part and a known good earth ground. Measure the AC voltage across the resistor with the AC voltmeter. Move the resistor connection to each exposed metal part, particularly any exposed metal part having a return path to the chassis, and measure the AC voltage across the resistor. Now, reverse the plug in the AC outlet and repeat each measurement. Any voltage measured must not exceed 0.75V AC(r.m.s.). This corresponds to 0.5mA AC(r.m.s.).



Warning



1. This equipment has been designed and manufactured to meet international safety standards.
2. It is the legal responsibility of the repairer to ensure that these safety standards are maintained.
3. Repairs must be made in accordance with the relevant safety standards.
4. It is essential that safety critical components are replaced by approved parts.
5. If mains voltage selector is provided, check setting for local voltage.

2. Safety Precaution about UX-T3

IMPORTANT FOR LASER PRODUCTS PRECAUTIONS (Australia/Singapore only)

1. CLASS 1 LASER PRODUCT
2. **DANGER:** Invisible laser radiation when open and interlock failed or defeated. Avoid direct exposure to beam.
3. **CAUTION:** Do not open the rear cover. There are no user serviceable parts inside the unit; leave all servicing to qualified service personnel.
4. **CAUTION:** The compact disc player uses invisible laser radiation and is equipped with safety switches which prevent the emission of radiation when the CD holder is open. It is dangerous to defeat the safety switches.
5. **CAUTION:** Use of controls for adjustments and the performance of procedures other than those specified herein may result in exposure to hazardous radiation.
6. **CAUTION:** The laser is able to function, if safety switches out of function. The laser light is invisible, avoid exposure, do not disassemble the laser unit, but replace the complete unit.


IDENTIFICATION LABEL AND CERTIFICATION LABEL







The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.



DANGER: Invisible laser radiation when open and interlock failed or defeated. AVOID DIRECT EXPOSURE TO BEAM. (e)	ADVARSEL: Usynlig laserstråling ved åpning, når sikkerhetslås/bryder er ute av funktion. Undgå direkte utsættelse for strålen. (d)	VARNING: Osynlig laserstråling när denna del är öppnad och spärren är urkopplad. Beträkta ej strålen. (s)	VARO: Avataessa ja suojauslukitus ohjettessa olet alttiina näkymättömälle lasersäteilylle. Älä katso sääteen. (f)
---	---	--	--



■ Important management points regarding safety(Item demanding special safety precautions)

1. Power transformer marking :VTP66G2 – 12E (UX – T3 US/U)

:VTP66T2 – 12F (UX – T3 A)

2. Concerning the AC socket, the next marking must be confirmed and to avoid print circuit board pattern damage.

The AC socket must not float from print circuit board.

•Marking HSC1466

3. Concerning the primary terminal and the adjacent secondary terminal on the print circuit board to provide proper creeping and spatial distance, solder must not protrude from soldering round.

4. Before installation confirm the fuse capacity indication, (\odot)and (\heartsuit)marks on the fuse holder. (A/US only)

Before installation confirm the fuse capacity indication, (UL)and (CSA)marks on the fuse holder. (U only)

REF.NO	Capacity and mark	Indication on P.C.board	Version
F901	T500mA	T500mA	A
F901	800mA/250V	800mA/250V	A/US/U
F902	T5A	T5A	A/US/U
F903	T54A	T5A	A/US/U

5. Wires must be clamped or secured at the locations shown in the figure so that the wire do not touch to live parts, moving part , hot part, or sharp edges.

6. The single wire on the P.C. board must be fixed with spacer or bond.

7. Following parts are controlled as the heated parts. confirm that the flammable parts are lifted up .

• IC: (ICA91), ICA31, IC502 •Transistor: (QA951) •Resistor : RA351, •Diode : D901~D904

8. Confirm the indication " HXW0353 "on the voltage selection switch. (UX – T3 US/U),

3. Main features

1. Disc-size micro component system consisting of 3 units
2. Active Hyper-Bass PRO circuit for low-frequency sound reproduction
3. One touch operation (IllumiMagic COMPU PLAY)
 - When a source button (CD, tape, tuner or AUX) is pressed, the unit's power is turned on and initiates the playback even when the power is set to STANDBY.
4. 32-key remote control unit opens and closes the motor-driven CD tray, and operates the usual CD, cassette deck and tuner functions
5. Multi-function CD player
 - Programmed Play/Repeat play/Random Play/Intro Scan.
6. U-Turn auto-reverse full-logic mechanism with Dolby® B NR
 - Auto tape select mechanism.
 - Metal (type IV) and CrO₂ (type II) tape can be played back for superior tone quality.
 - CrO₂ (type II) tape recording capability.
 - Music scan in forward or reverse direction.
7. 3-Band digital synthesizer tuner with 45-station (15 FM, 15 AM and 15 SW) preset capability
 - Seek/manual tuning.
 - Auto preset tuning.
8. Timer/Clock function
 - Timer on/off with preset volume function.
 - Sleep timer can be set for up to 120 minutes.
9. Microphone mixing facility

* Dolby noise reduction manufactured under license from Dolby Laboratories Licensing Corporation. "Dolby" and the double-D symbol  are trademarks of Dolby Laboratories Licensing Corporation.

4. Specifications

Compact disc player section

Type	: Compact disc player
Signal detection	: Non-contact optical pickup
Number of channels	: 2 channels
Frequency range	: 20 Hz - 20,000 Hz
Dynamic range	: 90 dB
Signal-to-noise ratio	: 90 dB
Total harmonic distortion	: 0.01 %
Wow & flutter	: Less than measurable limit

Radio section

Frequency ranges	: FM: 87.5 - 108 MHz AM: 531 - 1,602 kHz (with channel space mode set to AM 9 kHz) AM: 530 - 1,710 kHz (with channel space mode set to AM 10 kHz) SW: 2.3 - 21.85 MHz
Antennas	: Loop antenna for AM/SW (2.3 - 6.995 MHz) External antenna terminal for FM (75 ohms)/SW (7 - 21.85 MHz)

Tape deck section

Track system	: 4-track 2-channel stereo
Motor	: Electronic governor DC motor (capstan x 1, reel x 1)
Heads	: Hard permalloy head for recording/playback, 2 gap ferrite head for erasure (Combination head)
Frequency response	: 50 - 15,000 Hz (with CrO ₂ tape)
Wow and flutter	: 0.09 % (WRMS)
Fast wind time	: Approx. 120 sec (C-60 cassette)

Speaker section (each unit)

Speaker (Impedance)	: 10 cm x 1 (8 Ω)
Dimensions	: 151 (W) x 238 (H) x 224 (D) mm
Weight	: Approx. 2.1 kg

General

Power output	: Max. 28 W (14 W + 14 W) at 8 Ω
Input jacks	: AUX IN (300 mV/100 kΩ) MIC (3.5 mm dia. mini plug) (Matching Impedance: 200 Ω - 2kΩ)
Output jacks	: Speaker x 2 (matching impedance 8 Ω - 16 Ω) Headphones (0 - 30 mW/32 Ω) (matching impedance 16 Ω - 1 kΩ)
Power supply	: AC 240 V, 50 Hz (UX-T3A) AC 110/127/230 V, 50/60 Hz (UX-T3U/US/UT) Ext. DC 12 V (car battery via optional CA-R120E car adapter)
Power consumption	: 30 W (with POWER SW ON) (UX-T3A/U/US) 52 W (with POWER SW ON) (UX-T3 UT) 3.5 W (with POWER SW STANDBY)
Dimensions	: 459 (W) x 239 (H) x 259 (D) mm including knobs
Weight	: Approx. 8.1 kg
Accessories provided	: Power cord x 1 Remote control unit (RM-RXUT3) x 1 Battery "R6" x 2 (for the remote control) Feeder antenna x 1 Loop antenna stand x 1 AC plug adapter x 1 (UX-T3U/US/UT)

Design and specifications are subject to change without notice.

5. Instructions



**COMPACT
disc
DIGITAL AUDIO**

Thank you for purchasing this JVC product. Please read these instructions carefully before starting operation to be sure to obtain optimum performance and a longer service life from the unit.

Enhorabuena por la compra de este producto JVC. Lea detenidamente este manual de instrucciones antes de poner en funcionamiento la unidad a fin de obtener un óptimo rendimiento y mayor vida útil.

承蒙您選購JVC公司的產品，謹致感謝。在使用之前，請仔細閱讀本使用說明書，以獲得理想的使用效果和更長的使用壽命。

CONTENTS

Features	2
Safety precautions	3
Handling precautions	4
Connections	6
Power supply	8
Names of parts and their functions	9
Remote control unit	12
Switching the power on/off	15
Volume, tone and other controls	18
Concerning compact discs	19
Playing compact discs	20
Cassette tape	26
Cassette playback	27
Radio reception	29
Recording	33
Microphone mixing	37
Clock/timer adjustment	38
Timer operations	42
Sleep operations	46
Maintenance	48
Troubleshooting	49
Specifications	50

WARNING:
TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK,
DO NOT EXPOSE THIS APPLIANCE TO RAIN OR
MOISTURE.

INDICE

Características	2
Precauciones de seguridad	3
Precauciones de manipulación	4
Conecciones	6
Alimentación	8
Nombrado de las partes y sus funciones	9
Unidad de control remoto	12
Conexión/desconexión de la alimentación	15
Volumen, tono y otros controles	18
En cuanto a los compact disc	19
Reproducción de compact disc	20
Cassette	26
Reproducción de cassettes	27
Radio recepción	29
Grabación	33
Mezclado de micrófono	37
Ajuste del reloj/temporizador	38
Funcionamiento del temporizador	42
Funcionamiento del temporizador de desconexión	46
Mantenimiento	48
Detección de problemas	49
Especificaciones	50

ADVERTENCIA:
PARA EVITAR RIESGOS DE INCENDIOS O
ELECTROCUCIONES, NO EXPONGA ESTE APARATO A
LA LLUVIA O A LA HUMEDAD.

特點介紹	2
安全須知	3
使用須知	4
連接	6
電源	8
各部件的名稱以及功能	9
遙控器	12
電源的接通與斷開	15
音量、音調及其他控制	18
有關CD唱片	19
CD唱片的放音	20
卡式錄音帶	26
卡式錄音帶的放音	27
無線電廣播的接收	29
錄音	33
麥克風混聲	37
時鐘／定時器的調節	38
定時器的使用	42
睡眠定時	46
保養	48
故障的檢查與排除	49
規格	50




The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated 'dangerous voltage' within the products enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

警告：
為了防止火災以及觸電，請勿讓本機淋雨受潮。

**IMPORTANT FOR LASER PRODUCTS
(For SINGAPORE/AUSTRALIA only)**
PRECAUTIONS

1. CLASS 1 LASER PRODUCT
2. **DANGER:** Invisible laser radiation when open and interlock failed or defeated. Avoid direct exposure to beam.
3. **CAUTION:** Do not open the rear cover. There are no user serviceable parts inside the unit; leave all servicing to qualified service personnel.
4. **CAUTION:** The compact disc player uses invisible laser radiation and is equipped with safety switches which prevent the emission of radiation when the CD tray is open. It is dangerous to defeat the safety switches.
5. **CAUTION:** Use of controls for adjustments and the performance of procedures other than those specified herein may result in exposure to hazardous radiation.

REPRODUCTION OF LABELS AND THEIR LOCATION
**FEATURES****CARACTERISTICAS****特點介紹**

1. Disc-size micro component system consisting of 3 units
2. Active Hyper-Bass PRO circuit for low-frequency sound reproduction
3. One touch operation (IllumiMagic COMPU PLAY)
 - When a source button (CD, tape, tuner or AUX) is pressed, the unit's power is turned on and initiates the playback even when the power is set to STANDBY.
4. 32-key remote control unit opens and closes the motor-driven CD tray, and operates the usual CD, cassette deck and tuner functions
5. Multi-function CD player
 - Programmed Play/Repeat play/Random Play/Intro Scan.
6. U-Turn auto-reverse full-logic mechanism with Dolby® B NR
 - Auto tape select mechanism.
 - Metal (type IV) and CrO₂ (type II) tape can be played back for superior tone quality.
 - CrO₂ (type II) tape recording capability.
 - Music scan in forward or reverse direction.
7. 3-Band digital synthesizer tuner with 45-station (15 FM, 15 AM and 15 SW) preset capability
 - Seek/manual tuning.
 - Auto preset tuning.
8. Timer/Clock function
 - Timer on/off with preset volume function.
 - Sleep timer can be set for up to 120 minutes.
9. Microphone mixing facility
 - Dolby noise reduction manufactured under license from Dolby Laboratories Licensing Corporation. "Dolby" and the double-D symbol are trademarks of Dolby Laboratories Licensing Corporation.

1. Sistema de microcomponentes compuesto por 3 unidades
2. Circuito Active Hyper-Bass PRO para reproducción sonidos de baja frecuencia
3. Operación de un solo toque (IllumiMagic COMPU PLAY)
 - Cuando se presiona un botón de fuente (CD, cinta, sintonizador o AUX) se conecta automáticamente la alimentación de la unidad y se inicia la reproducción, aún cuando la alimentación esté colocada en STANDBY.
4. La unidad de control remoto de 32 teclas abre y cierra el portadisco motorizado de CD y opera el CD, la platina de cinta y las funciones normales del sintonizador
5. Reproductor de CD con múltiples funciones
 - Reproducción programada/repetición de reproducción/reproducción aleatoria/búsqueda de introducción programadas.

1. CD 小型組合音響設備由3個部分組成
2. 再現低頻音響的靈敏超低音 PRO 線路
3. 單獨放音 (靈光 COMPU PLAY)
 - 即使電源鍵被設為“待機 (STANDBY)”，只要您按某個放音源鍵 (CD、錄音帶、調諧器或 AUX)，電源便會接通，並且開始放音。
4. 32鍵遙控器可以打開和關上電動 CD 唱片托盤，並可操作通常的 CD、卡座及調諧器的功能。
5. 多功能 CD 電唱機
 - 程式放音／重複放音／隨意放音／曲頭掃描。

2

6. Mecanismo de lógica total de inversión automática "vueltita en U" con sistema reductor de ruido Dolby® B NR
 - Mecanismo de selección automática de cinta.
 - Apto para grabaciones de cintas metálicas (tipo IV) y cromo (tipo II), para obtener tonos de calidad superior.
 - Apto para grabación de cintas de cromo (tipo II).
 - Búsqueda de música hacia adelante o hacia atrás.
7. Sintonizador sintetizador digital de 3 bandas con capacidad para presintonizar 45 estaciones (15 de FM, 15 de AM y 15 SW)
 - Sintonización por búsqueda/manual.
 - Sintonización ajustada automáticamente.
8. Función de temporizador/reloj
 - Encendido/apagado programables con función de preajuste de volumen.
 - El temporizador de desconexión automática puede ser ajustado a un máximo de 120 minutos.
9. Instalación para mezcla de micrófono
 - Reductor de ruido Dolby fabricado bajo licencia de Dolby Laboratories Licensing Corporation.
 - "Dolby" y el símbolo de la doble D sono marcas de Dolby Laboratories Licensing Corporation.

6. 帶有 Dolby® B NR 的自動換面全邏輯裝置
 - 自動選帶裝置。
 - 金屬錄音帶 (IV型) 以及 CrO₂ (II型) 錄音帶的放音音質極佳。
 - 可以進行 CrO₂ (II型) 錄音帶的錄音。
 - 具有正反兩個方向的樂曲搜尋功能。
 7. 可預設45個電臺 (15個FM、15個AM 以及 15個SW) 的3波段數字聯合調諧器
 - 搜尋／手動調諧。
 - 預設自動調諧。
 8. 定時／時鐘功能
 - 定時開／關功能。
 - 睡眠定時最長可設為120分鐘。
 9. 麥克風混音裝置
- * 杜比噪音減低器係經杜比實驗證明公司授權製造。杜比、DOLBY、及雙 D 標章為杜比實驗證明公司之註冊商標。

SAFETY PRECAUTIONS

- Prevention of Electric Shocks, Fire Hazards and Damage**
1. Even when the POWER button is set to STANDBY, a very small current will flow. To save power and for safety when not using the unit for an extended period of time, disconnect the power cord from the household AC outlet.
 2. Do not handle the power cord with wet hands.
 3. When unplugging from the wall outlet, always grasp and pull the plug, not the power cord.
 4. Consult your nearest dealer when damage, disconnection, or contact failure is found with the cord.
 5. Do not bend the cord sharply, or pull or twist it.
 6. Do not modify the power cord in any manner.

PRECAUCIONES DE SEGURIDAD**安全須知**

- Prevención contra electrochoques, riesgos de incendios y daños.**
1. Aunque el interruptor POWER esté ajustado en STANDBY, circula una pequeña cantidad de corriente. Para ahorrar energía y por seguridad, desconecte el cable de alimentación del tomacorriente cuando no vaya a utilizar la unidad por mucho tiempo.
 2. No toque el cable de alimentación con las manos húmedas.
 3. Al desenchufar el cable del tomacorriente, tire de la clavija y no del cable.
 4. Consulte a su vendedor más cercano cuando descubra una falla, desconexión o falta de contacto en el cable.
 5. No doble, tire o enrosque demasiado el cable.
 6. No efectúe ninguna modificación en el cable.

- 為了預防觸電、火災以及故障
1. 即使將電源鍵(POWER)設於待機位置(STANDBY)，仍然會有極少的電流流動。因此，為了省電與安全起見，當您長期不使用的時候，請將電源線從牆壁上的交流電源插座上拔下來。
 2. 切勿用濕手拔電源線。
 3. 當您要將電源線從牆壁上的電源插座上拔下來時，務請拿住插頭拔，切勿拿住電源線拔。
 4. 如果發現電源線有損傷、脫落或者接觸不良，請與附近的銷售商聯絡。
 5. 切勿過份彎折，或者拉拔，拗曲電源線。
 6. 切勿以任何方式變更電源線。

7. Do not remove screws to disassemble the unit and do not touch anything inside the unit to avoid accidents.
8. Do not insert any metallic objects into the unit.
9. Unplug the power cord when there is a possibility of lightning.
10. If water gets inside the unit, unplug the power cord from the outlet and consult your dealer.
11. Do not block the ventilation holes of the unit so that heat can escape.
12. Do not install the unit in a badly ventilated place.
13. Since this unit uses a motor-driven CD tray, make sure your hand or other object does not obstruct tray movement.

Power button

When the power cord is plugged into an AC outlet, the power indicator lights in red indicating the STANDBY mode. When the power is switched on, the power indicator goes out and the display window lights.

When this unit is plugged into an AC outlet, it consumes a small current to operate the remote control and timer, or to back up the memory of the microprocessor, even when the POWER button is set to STANDBY.

**HANDLING PRECAUTIONS**

Do not use this unit in direct sunlight or leave the unit in closed automobiles (or yachts, etc.) where it would be exposed to high temperatures above 40°C (104°F).

1. Avoid installing in the following places

- Where it could be subject to vibrations.
- Where it is excessively humid, such as in a bathroom.
- Where it could be magnetized by a magnet or speaker.

2. Pay attention to dust

Be sure to close the CD tray so the lens is not contaminated by dust.

3. Condensation

In the following cases, condensation may occur on the lens, in which case the unit may not operate correctly.

- In a room where a heater has just been switched on.
- In a place where there is smoke or high humidity.
- When the unit is moved directly from a cold to a warm room.

In these cases, set the POWER switch to ON and wait 1 or 2 hours before use.

4. Volume setting

Compact discs produce very little noise compared with analog records. When the volume control of an amplifier is adjusted by listening to the noise as is done with analog records, the speakers could be damaged by the sudden increase of output when the music starts. Therefore, turn down the volume before starting and adjust as required while playing a CD.

5. Safety mechanism

This unit incorporates a safety interlock mechanism which switches the laser beam on and off, so that when the disc tray is open, the laser beam stops automatically.

6. Do not place cassette tapes, etc. near the speakers

Since there are magnets in the speakers, do not place tapes or magnetic cards on them as recorded data could be erased.

7. Keep this unit away from your TV

When this unit is used near a TV, the TV picture could be distorted. If this happens, move this unit away from the TV. If this does not correct the situation, avoid using this unit when the TV is turned on.

8. Cleaning the cabinet

If the cabinet gets dirty, wipe it with a soft, dry cloth. Never use benzine or thinner as these could damage the surface finish.

9. When listening with headphones

- Do not listen at high volumes as it could damage your hearing.
- For safety, do not drive while listening to this unit.

7. No saque los tornillos para desarmar la unidad ni toque nada dentro de la misma para evitar accidentes.
8. No introduzca ningún objeto metálico dentro de la unidad.
9. Desenchufe el cable lo antes posible si hay posibilidad de tormentas eléctricas.
10. Si entra agua dentro de la unidad, desenchufe el cable del tomacorriente y consulte a su vendedor.
11. No bloquee los orificios de ventilación de la unidad para que el calor pueda salir.
12. Como esta unidad utiliza un portadisco motorizado de CD, asegúrese de que su mano u otro objeto no obstruyan el movimiento del portadisco.
7. 切勿卸下螺絲拆卸本裝置：切勿觸摸機殼內部的任何部件，以免發生事故。
8. 切勿將任何金屬物件塞入裝置內。
9. 如果有雷電閃光的可能，請拔下電源線。
10. 萬一有水進入了裝置內，請將電源插頭從牆壁上的電源插座上拔下來，並且與銷售商聯絡。
11. 切勿堵塞通氣孔，通氣孔是用來排熱的。切勿將本裝置置於排熱條件差的地方。
12. 由於本機使用的是電動電唱機托盤，所以請小心別讓手指或其它東西妨礙唱盤的運動。

Interruptor de alimentación

Cuando se conecta el cable de alimentación en un tomacorriente de alterna, se enciende el indicador de alimentación rojo indicando el modo STANDBY. Al presionar el interruptor de alimentación, se apaga este indicador y se enciende el display.

Cuando esta unidad está conectada a un tomacorriente de CA, consume una pequeña cantidad de corriente para operar el control remoto y el temporizador, y para la memoria de apoyo del microprocesador, aún cuando el botón POWER esté colocado en STANDBY.

電源鍵鈕

一旦將電源插頭插入市電交流電源插座，紅色的電源指示燈就會點亮，表示裝置處於待機狀態(STANDBY)，當按壓電源鍵紐接通電源以後，電源指示燈就會熄滅，顯示窗則會發亮。

一旦將裝置的電源插頭插入市電交流電源插座，即使電源鍵紐(POWER)設於待機狀態(STANDBY)，仍然會有少量的電流流入，以作為遙控器操作以及定時器、微型電腦記憶裝置的記憶之用。

PRECAUCIONES DE MANIPULACION**使用須知**

切勿在直射陽光下使用本機，或放在溫度高達40°C以上的緊閉的汽車裡(或遊艇中等)使用。

1. 避免放置於下列場所

- 有振動之處。
- 有潮氣之處，諸如浴室之類。
- 接近磁體、揚聲器等有磁場之處。

2. Preste atención al polvo

Asegúrese de cerrar el portadisco de CD de tal manera que la lente no sea contaminada por el polvo.

3. Condensación

En los siguientes casos, puede producirse condensación en la lente y en consecuencia la unidad no funcionará correctamente.

- En una habitación donde se haya encendido un calefactor.
- En un lugar con humo o muy húmedo.
- Cuando la unidad haya sido trasladada directamente de un sitio frío a otro de mayor temperatura.

En estos casos, coloque el interruptor POWER en ON y espere 1 ó 2 horas antes de utilizar la unidad.

4. Regulación del volumen

Los compact disc producen muy poco ruido comparados con los discos analógicos. Cuando se ajusta el control de volumen de un amplificador escuchando el ruido, como en el caso de los discos analógicos, los altavoces pueden resultar dañados por un aumento súbito de la salida al comenzar la música. Por tanto, disminuya el volumen antes de poner en funcionamiento la unidad y regúlelo como guste mientras reproduce el CD.

5. Mecanismo de seguridad

Esta unidad incorpora un mecanismo de enclamamiento de seguridad que comuta el encendido y apagado del rayo láser, de tal manera que cuando se abre el portadisco el rayo láser es apagado automáticamente.

6. No coloque cassettes, etc. cerca de los altavoces

Puesto que los altavoces tienen imanes, no coloque cintas o tarjetas magnéticas sobre los mismos porque podrían borrar los datos grabados.

7. Mantenga esta unidad lejos del televisor

Cuando se utiliza esta unidad cerca de un televisor, es posible que se distorsione la imagen televisiva. Si esto ocurriese, alejela del televisor. Si esto tampoco mejora la situación, evite utilizar la unidad cuando esté encendido el televisor.

8. Limpieza del gabinete

Si se ensucia el gabinete, límpielo con un paño suave y seco. No utilice bencina ni diluyente ya que éstos podrían perjudicar el acabado.

9. Cuando escuche con auriculares

- No escuche con el volumen muy alto porque podrían dañarse sus oídos.
- Por seguridad, no conduzca mientras escucha esta unidad.

2. 注意灰塵

務請關閉CD艙蓋，不要讓灰塵沾污了鏡頭。

3. 結露

於下列情況，鏡頭有可能結露。這時裝置有可能不能正常工作。

- 剛打開取暖器的房間。
- 有煙霧，或者過於潮濕的場所。
- 從寒冷的房間直接移至溫暖的房間。

於上述情況，接通電源以後，先等1至2小時，然後再使用。

4. 音量的調節

與模擬唱片相比，小型唱片產生的噪音極小，如果與聽模擬唱片時一樣以聽噪音來調節音量，那麼揚聲器將會因突然增大的音量而被損壞。因此，在開始放音之前先調低音量，使其適合CD的放音。

5. 安全裝置

本機裝有安全聯鎖裝置，其控制鐳射射線的開／關。當唱片艙蓋打開時，鐳射射線自動關閉。

6. 請勿將卡式錄音帶等物件放置於揚聲器附近

由於揚聲器內有磁體，所以切勿將錄音帶，或者磁卡放置於揚聲器之上，否則所記錄的資料將被消除。

7. 不要讓本機接近電視機

如果在電視機附近使用本機，電視機的畫面會失真。如果發生這種情況，請將本機搬離電視機。如果仍不能改善畫面的失真，則在觀看電視時不要使用本機。

8. 機殼的清潔工作

如果機殼上有污穢，請用柔軟的、乾燥的布擦拭。切勿使用石油精、天然水，這些溶液會損壞表面的精加工。

9. 當使用耳機收聽的時候


- 請勿用高音量聽，這將會損壞您的聽覺功能。
- 為了安全，請勿在駕駛時聽本機。

CONNECTIONS



- Do not switch the power on until all connections are completed.

Antenna connection and adjustment


- AM loop antenna adjustment



- FM/SW antenna connections and adjustments




- Conexiones y ajustes de la antena de FM/SW



Notes:

- Do not place the loop antenna on a metal desk or near a TV or personal computer.
- Installing an outdoor antenna requires experience; we recommend that you consult an audio dealer.
- Install the antenna cord away from the power and speaker cords as these could generate noise. And so keep the loop antenna away from the rear of the unit.

Speaker cord connection



- Left speaker (front side)
Altavoz izquierdo (lado frontal)
左侧揚聲器 (前面)
- Install so that this section is externally positioned.
Instalelo de tal manera que esta sección quede en la parte externa.
將此部份安裝牢固

Notes:


- The polarity connections for the two speakers should be the same, with the black speaker cords connected to the \ominus terminals. If the speakers are connected with reverse polarities, stereo effect and tone will be degraded.
- The speakers of this unit are not magnetically shielded. When they are placed directly on or adjacent to a TV, the TV color could be distorted. Install the speakers more than 10 cm away from your TV.
- Since the speakers sound differently according to where they are placed, carefully place them for optimal effect within the length of the provided speaker cords. It is recommended that the left and right speakers be placed symmetrically in relation to the main unit.
- When connecting the speaker cord, make sure that the wire core, not the insulating cover, is connected to the speaker terminal. Otherwise, sound cannot be heard.

CONEXIONES


- No encienda la unidad hasta haber concluido todas las conexiones.

Conexión y ajuste de la antena

- Ajuste de la antena de cuadro de AM



- Conexiones y ajustes de la antena de FM/SW



連接

- 在所有連接完成之前，請勿接通電源。

天線的連接與調節

- AM環形天線的調節

- Keep the loop antenna away from the rear panel of the unit and install it so that the best reception is obtained. (Do not leave the antenna wire in a bundle.)
- Mantenga la antena de cuadro lejos del panel posterior de la unidad e instálala de tal modo que pueda obtenerse la mejor recepción. (No deje enrollado el cable de la antena.)
- 将環形天線放置於離開裝置背板的地方，這樣可以獲得最好的接收效果。（請勿將天線的導線捆扎起來。）

FM/SW天線的連接與調節

- Use an outdoor antenna when stable reception cannot be obtained with the provided antenna.
- Utilice una antena exterior cuando no pueda obtener una recepción estable con la antena suministrada.
- 如果配備的天線不能獲得穩定的接收效果，請使用室外天線。

- Outdoor FM antenna (option)
- Disconnect the feeder antenna marked * and insert the outdoor FM antenna.
 - Antena exterior de FM (opcional)
 - Desconecte la antena alimentadora marcada con un * e inserte la antena exterior para FM.
 - 室外FM線（選購件）
 - 拔出標有*記號的饋電天線，插入室外FM天線。

6


注：

- 切勿將環形天線放置於金屬桌子上，或者使其接近電視機以及電腦。
- 天線的安裝需要有經驗，我們建議您與音響設備經銷商聯絡。
- 請勿將天線的導線與電源線、揚聲器導線放在一起，這樣會產生噪音。應將環形天線放置於遠離裝置背面的地方。

揚聲器導線的連接

- Connect the cord from the speaker on the left to the (LEFT) terminal and the cord from the speaker on the right to the (RIGHT) terminals.
- Conecte el cable del altavoz de la izquierda a los terminales (LEFT) y el cable del altavoz de la derecha a los terminales (RIGHT).
- 將左側揚聲器的導線插入LEFT端子：將右側揚聲器的導線插入RIGHT端子。


Conexión de cables de altavoces



Notas:

- Las conexiones de polaridad para los dos altavoces deben ser iguales, con los cables negros conectados al terminal \ominus . Si los altavoces están conectados con las polaridades invertidas, el efecto estereofónico y el tono se degradarán.
- Los altavoces de esta unidad están blindados magnéticamente. Cuando se los coloca directamente sobre o adyacentes a un TV, el color de éste puede ser distorsionado. Instale los altavoces a más de 10 cm de distancia de su TV.
- Como los altavoces suenan diferente de acuerdo al lugar donde sean colocados, ubíquelos con precaución para obtener un efecto óptimo dentro de la longitud de los cordones de los mismos. Se recomienda que los altavoces izquierdo y derecho sean colocados simétricamente en relación a la unidad principal.
- Cuando conecta el cordón del altavoz, asegúrese de que el núcleo del cable, y no la cubierta aislante, quede conectado al terminal del altavoz, de lo contrario no se escuchará sonido.


- Left speaker (rear side)
Altavoz izquierdo (lado posterior)
左侧揚聲器 (背面)




注：

- 兩個揚聲器的連接必須極性一致，揚聲器的黑色導線應與負極 \ominus 端子相連。如果揚聲器的極性被連接相反，立體聲效果和音質均會降低。
- 本機的兩個揚聲器都沒有作磁保護，因此，如果直接放置於電視機上，或者靠近電視機，都會使電視機的色彩失真。揚聲器應該放置於離開電視機至少10 cm之處。
- 因為揚聲器的音響效果取決於其位置的不同，故請在揚聲器導線的長度範圍內仔細確定其安放位置，以獲得最佳效果。
- 當您連接揚聲器的導線時，請確認是導線芯而不是絕緣層被連接在揚聲器的端子上，否則將聽不見聲音。

Connection of external audio units




Conexión de unidades externas de audio



外用聲頻裝置的連接

Turntable (with built-in equalizer)
Reproductor de discos (con ecualizador incorporado)
電唱機（帶內裝均衡器）





POWER SUPPLY

A. Operation on household AC

The UX-T3A (for Australia) is not provided with voltage selectors.

- When the UX-T3U/US/UT is used in an area where the supply voltage is different from the preset voltage, reset the voltage selector to the correct position.



- Connect the AC power cord.

Note:

For the UX-T3U/US/UT, the AC plug adapter is provided. If required, use it.

CAUTIONS:

- ONLY USE WITH JVC POWER CORD PROVIDED WITH THIS UNIT TO AVOID MALFUNCTION OR DAMAGE TO THE UNIT.
- BE SURE TO UNPLUG THE POWER CORD FROM THE OUTLET WHEN GOING OUT OR WHEN THE UNIT IS NOT IN USE FOR AN EXTENDED PERIOD OF TIME.

ALIMENTACION

A. Funcionamiento con corriente alterna


El UX-T3A (para Australia) no cuenta con selectores de tensión.

- Cuando use el UX-T3U/US/UT en un área donde la tensión es distinta a la preajustada, vuelva a ajustar el selector de tensión en la posición correcta.

電源

A. 交流電源線的連接

- UX-T3A (澳大利亞用) 不配備電壓選擇器。
- 如果在與預設電壓不同的地方使用 UX-T3U/US/UT，請重新設定電壓，將電壓選擇器設定於正確的位置。



- 連接交流電源線。

注：


- UX-T3U/US/UT 配備有交流電插頭適配器，如果需要可以使用。

注意：

- 請務必使用配備的JVC電源線，以防功能失靈或者損壞設備。
- 出門或者長期不使用本機時，請將電源插頭從電源插座上拔下。

8


B. Operation on car battery (DC 12 V)



- First connect the car adapter to the DC IN 12V jack, not the cigarette lighter socket, because shorting of a plug on the car may cause the fuse to blow out. In addition, be careful not to make a short-circuit between the plugs.
- When using a car battery, be sure to use the specified car adapter (JVC model CA-R120E) to prevent mishaps or damage resulting from different polarity design.


B. Funcionamiento con batería de automóvil (12 V de CC)

Optional exclusive car adapter (JVC model CA-R120E)
Adaptador exclusivo para automóvil opcional
(JVC modelo CA-R120E)
可選專用汽車適配器 (JVC 型 CA-R120E)



- Primero conecte el adaptador al jack DC IN 12V, no al enchufe del encendedor de cigarrillos, porque si pone en cortocircuito una clavija del automóvil, puede quemarse un fusible. Además, tenga cuidado de no producir un cortocircuito entre las clavijas.
- Cuando utilice una batería de automóvil, emplee el adaptador especificado (JVC modelo CA-R120E) para evitar fallas o daños por diferentes tipos de polaridad.

B. 關於汽車電池 (DC 12V) 的操作



② To car's cigarette lighter socket (12 V)
Al enchufe del encendedor de cigarrillos del automóvil (12 V)
接至汽車點煙器插座 (12V)

- 首先將汽車適配器接至DC IN 12V 捲孔，注意勿接至點煙器插座，因為汽車上的捲頭如短路，可能會導致保險絲熔斷。另外，請注意別使捲頭之間出現短路。
- 使用汽車電池時，務請使用所指定的汽車適配器 (JVC 型 CA-R120E)，以防止因不同極性設計而引起的意外事故或損壞。

Note:

- When there is a power failure or the AC power cord is disconnected, the timer/clock setting is erased from memory. Reset the clock when the power supply is restored.

Nota:


- Cuando se produzca un corte de electricidad o se desenchufe el cable de CA, se borrarán de la memoria los ajustes del temporizador/reloj. Reajuste el reloj cuando se restablezca el suministro eléctrico.

注：

- 若停電或電源線被拔下，定時／時鐘設定即被清除，恢復供電後請重新設定時鐘。


NAMES OF PARTS AND THEIR FUNCTIONS

CD player/General section




NOMBRE DE LAS PARTES Y SUS FUNCIONES

Reproductor de CD/sección general




各部件的名稱以及功能

CD唱機／整體部分



- Top panel
- Panel superior
- 天面






- ① Display window**
- ① Function/Track number display
 - ② Play time display
 - ③ Music calendar display
 - ④ Repeat play indicator
 - ⑤ INTRO scan indicator
 - ⑥ RANDOM play indicator
 - ⑦ PROGRAM mode indicator
 - ⑧ OVER indicator
- ② SENSOR section**
- The remote control signal is received in the SENSOR section. Approach this section with your hand to activate IllumiMagic COMPU PLAY.
- ③ CD tray**
- ④ ACTIVE HYPER-BASS PRO button and indicator**
- ⑤ SOUND mode button**
- ⑥ VOLUME buttons**
- + : Use to increase the volume.
- : Use to decrease the volume.
(control range from VOL 0 to VOL 50.)
- ⑦ POWER button and power STANDBY indicator**
- Press to switch the power on or off.
- ⑧ CD tray OPEN/CLOSE button (▲)**
- ⑨ AUX button**
- ⑩ CD operation buttons**
- Stop/CLEAR button (■/CLEAR) : Press to stop playing a disc and to cancel programmed play. This also sets the CD mode.
- Play/Pause button (▷/■) : Press to play a disc and to stop temporarily.
- CD search buttons (◀◀, ▶▶) : Press to locate the beginnings of tunes and to start forward and reverse search operations.
- ⑪ Headphones jack (PHONES) (3.5 mm dia, stereo mini)**
- Connect headphones (impedance 16 Ω to 1 kΩ) to this jack. Speaker sound automatically switches off when the headphones are connected.
- ⑫ MIXING MIC jack**
- ⑬ MIC LEVEL control**

- ① Ventanilla de indicación**
- ① Indicación de la función/número de pista
 - ② Indicación del tiempo de reproducción
 - ③ Indicación del calendario musical
 - ④ Indicador de repetición de reproducción
 - ⑤ Indicador de búsqueda INTRO
 - ⑥ Indicador de reproducción RANDOM
 - ⑦ Indicador de modo PROGRAM
 - ⑧ Indicador OVER
- ② Sección SENSOR**
- La señal de control remoto es recibida en la sección SENSOR. Aproxime la mano a esta sección para activar IllumiMagic COMPU PLAY..
- ③ Portadisco de CD**
- ④ Botón e indicador ACTIVE HYPER-BASS PRO**
- ⑤ Botón de modo de sonido (SOUND)**
- ⑥ Botones VOLUME**
- + : Utilícelo para aumentar el volumen.
- : Utilícelo para reducir el volumen.
(Los límites del control de volumen van de VOL 0 a VOL 50.)
- ⑦ Botón POWER e indicador de alimentación STANDBY**
- Presíñelo para conectar/desconectar la alimentación.
- ⑧ Botón (▲) OPEN/CLOSE del portadisco de CD**
- ⑨ Botón AUX**
- ⑩ Botones de operación del CD**
- Botón de parada/CLEAR (■/CLEAR) : Presíñelo para detener la reproducción de un disco y para cancelar la reproducción programada. Esto también activa el modo de CD.
- Botón (▷/■) de reproducción/pausa : Presíñelo para reproducir un disco y para pararlo temporalmente.
- Botones (◀◀, ▶▶) para búsqueda de CD : Presíñelos para ubicar el principio de las músicas y para iniciar las operaciones de búsqueda hacia adelante y hacia atrás.
- ⑪ Jack (PHONES) para audífonos (3.5 mm. de diá., estéreo y en miniatura)**
- Conecte los audífonos (con impedancia de 16 Ω a 1 kΩ) a este jack. El sonido de los altavoces se apaga automáticamente cuando se conectan los audífonos.
- ⑫ Jack MIXING MIC**
- ⑬ Control MIC LEVEL**

- ① 顯示窗**
- ① 功能／樂曲號顯示
 - ② 播放時間指示
 - ③ 樂曲一覽表顯示
 - ④ 重複放音指示
 - ⑤ 曲頭掃描指示 (INTRO)
 - ⑥ 隨意播放指示 (RANDOM)
 - ⑦ 程序方式指示 (PROGRAM)
 - ⑧ 過量指示 (OVER)
- ② 感應器部件 (SENSOR)**
- 遙控信號是由感應器部件接收，用您的手靠近這各部件就會啓動魔光單獨放音 (COMPRESS PLAY)。
- ③ CD 唱盤**
- ④ 敏感超低頻鍵和指示 (ACTIVE HYPER-BASS PRO)**
- ⑤ 電源方式鍵 (SOUND)**
- ⑥ 音量鍵 (VOLUME)**
- + : 用於增大音量
- : 用於減小音量
(控制範圍從 VOL 0 到 VOL 50.)
- ⑦ 電源鍵 (POWER) 和電源待機指示 (STANDBY)**
- 按此鍵接通或切斷電源。
- ⑧ CD 唱盤開關鍵 (OPEN/CLOSE) (▲)**
- ⑨ 幫助鍵 (AUX)**
- ⑩ CD 操作鍵**
- 停止／取消鍵 (■/CLEAR) :
按此鍵停止唱片的播放，並取消已編序的播放。這也可設定 CD 方式。
- 放音／暫停鍵 (▷/■) :
按此鍵播放唱片並暫時停止播放。
- CD 搜尋鍵 (◀◀, ▶▶) :
按此鍵以搜尋曲頭以及作正向或反向搜尋。
- ⑪ 耳機插孔 (PHONES) (3.5mm 直徑, 立體聲微型插孔)**
- 將耳機 (阻抗16Ω~1kΩ) 插入此孔，插入後，揚聲器聲音自動關閉。
- ⑫ 混音麥克風插孔 (MIXING MIC)**
- ⑬ 麥克風電平控制 (MIC LEVEL)**

10

Tuner/Deck section**Sección del sintonizador/platina****調諧器／卡座部件 (Tuner /Deck)****① 顯示窗**

- ① 波段指示 (FM/AM/SW)
 - ② 無線電頻率顯示
 - ③ 頻道間隔方式顯示
 - ④ 單聲道指示 (MONO)
 - ⑤ 立體聲指示 (STEREO)
 - ⑥ 預調電臺顯示
 - ⑦ 逆向方式指示 (◀◀/▶▶)
 - ⑧ 磁帶方式指示
 - ⑨ 錄音指示 (REC)
 - ⑩ 杜比降噪指示 (DOLBY NR)
- * 關於時鐘／定時器部件，請參照第 38 頁。

② 調諧器鍵 (TUNER)

- 按此鍵以選擇調諧方式。
按此鍵以選擇波段 (FM/AM/SW)。
- ③ 調諧鍵 (TUNING) (大/小) (UP/DOWN)**
- ④ 預調調諧／自動預調鍵 (PRESET TUNING/AUTO PRESET)**

⑤ 逆向 (REV. MODE) 方式開關

- ：單面錄音或放音
：兩面
：連續放音

⑥ 杜比降噪鍵 (DOLBY NR)

- ① Display window**
- ① Band indicator (FM/AM/SW)
 - ② Radio frequency display
 - ③ Channel space mode display
 - ④ MONO indicator
 - ⑤ STEREO indicator
 - ⑥ Preset station display
 - ⑦ Reverse mode indicator (◀◀/▶▶)
 - ⑧ Tape mode display
 - ⑨ Tape direction indicator (◀, ▶)
 - ⑩ Recording indicator (REC)
 - ⑪ DOLBY NR indicator (DOLBY NR)
- * See page 38 for the Clock/Timer section.
- ② TUNER button**
- Press to select the tuner mode.
Press to select the band (FM/AM/SW).
- ③ TUNING buttons (UP/DOWN)**
- ④ PRESET TUNING/AUTO PRESET button**
- ⑤ Reverse (REV.) MODE switch**
- ：For single-side recording or playback
：For both-sides recording or playback
：For continuous play
- ⑥ DOLBY NR button**
- Set to ON when recording or playing back tapes using the noise reduction system.

- ① Ventanilla de indicación**
- ① Indicador de banda (FM/AM/SW)
 - ② Indicación de frecuencia de radio
 - Indicación del modo de canal
 - ③ Indicador de sonido monofónico (MONO)
 - ④ Indicador de sonido estéreo (STEREO)
 - ⑤ Indicación de estación presintonizada
 - ⑥ Indicador de modo reverso (◀◀/▶▶)
 - ⑦ Indicación del modo de cinta
 - ⑧ Indicador de la dirección de la cinta (◀, ▶)
 - ⑨ Indicador de grabación (REC)
 - ⑩ Indicador de reducción de ruido DOLBY NR (DOLBY NR)
- * Para la sección del reloj/temporizador, vea la página 38.
- ② Botón sintonizador (TUNER)**
- Presíñelo para seleccionar el modo de sintonización.
- Presíñelo para seleccionar la banda (FM/AM/SW).
- ③ Botones de sintonización ascendente/descendente (TUNING (UP/DOWN))**
- ④ Botón de presintonización/sintonización automática (PRESET TUNING/AUTO PRESET)**
- ⑤ Interruptor de modo inverso (REV. MODE)**
- ：Para la grabación o reproducción de un solo lado
：Para la grabación o reproducción de ambos lados
：Para la reproducción continua
- ⑥ Botón de reducción de ruido (DOLBY NR)**
- Colóquelo en ON cuando graba o reproduce cintas utilizando el sistema de reducción de ruido.

- ⑦ Cassette operation buttons
 ●/■ : Press to set the unit to the record or record-pause mode.
 SYNCHRO REC : Press to start CD synchro recording.
 □ : Press to play back the tape in the reverse direction.
 ■ : Press to stop the tape.
 This also sets the TAPE mode.
 ▷ : Press to play back the tape in the forward direction.
 ← : Press to fast wind the tape from right to left/Music scan.
 → : Press to fast wind the tape from left to right/Music scan.
- ⑧ Cassette holder

- ⑦ Botones para operación del cassette
 ●/■ : Presiónelo para colocar a la unidad en el modo de grabación o pausa de grabación.
 SYNCHRO REC: Presiónelo para iniciar la grabación sincronizada de CD.
 □ : Presiónelo para reproducir la cinta en sentido inverso.
 ■ : Presiónelo para detener la cinta. También se usa para activar el modo TAPE.
 ▷ : Presiónelo para reproducir la cinta hacia adelante.
 ← : Presiónelo para bobinar rápidamente la cinta de derecha a izquierda/búsqueda de música.
 → : Presiónelo para bobinar rápidamente la cinta de izquierda a derecha/búsqueda de música.
- ⑧ Portacassette

在使用降噪系統來進行錄音或放音時，將此鍵設至“ON”。


- ① 錄音待操作鍵
 ●/■ : 按此鍵將本機設定為錄音或錄音暫停方式。
 SYNCHRO REC (同步錄音) : 按此鍵以開始唱片的同步錄音。
 □ : 按此鍵以逆向放音。
 ■ : 按此鍵以停止走帶。這也設定 TAPE 方式。
 ▷ : 按此鍵以正向放音。
 ← : 按此鍵以從右向左快速繞捲錄音帶／搜尋樂曲。
 → : 按此鍵以從左向右快速繞捲錄音帶／搜尋樂曲。

③ 錄音帶艙

REMOTE CONTROL UNIT

Preparation before use

- **Installing batteries in the remote control unit**
 1. Remove the battery cover from the back of the remote control unit.
 2. Insert two "R6" size batteries.
 • Insert the batteries with the + and - terminals matching the indication inside the battery compartment.



3. Replace the cover.

• **Battery replacement**

When the remote control operation becomes unstable or the distance from which remote control is possible becomes shorter, replace the batteries with new ones.

UNIDAD DE CONTROL REMOTO

Preparación previa

- **Colocación de las pilas en el control remoto**
 1. Saque la tapa de las pilas en la parte posterior del control remoto.
 2. Coloque 2 pilas de tamaño "R6".
 • Coloque las pilas teniendo en cuenta que los terminales + y - coincidan con las indicaciones dentro del compartimiento de las pilas.




3. Vuelva a colocar la tapa.

- **Cambio de las pilas**
 Cuando el funcionamiento del control remoto sea inestable o disminuya la distancia de operación, cambie las pilas por otras nuevas.

遙控器

使用前的準備工作

- 將電池裝入遙控器
 1. 打開遙控器背面的電池艙蓋。
 2. 裝入2節“R6”號電池。
 • 裝入的時候，按照電池艙內所示的方向裝，不要將+/-端子弄錯。



3. 重新蓋上蓋子。

- **電池的更換**
 如果遙控器的操作失靈，或者操作距離變得短了，此時請更換新的電池。

12

Using the remote control unit

To use the remote control unit, point it at the REMOTE SENSOR and press the buttons gently and firmly. Remote control operation is possible within about 7 m (approx. 23 ft). However, since the remote control range is less when the unit is used at an angle, use directly in front of the REMOTE SENSOR, as far as possible. Do not expose the REMOTE SENSOR to strong light (direct sunlight or artificial lighting) and make sure that there are no obstacles between the REMOTE SENSOR and the remote control unit.

The following operations can be performed using the remote control unit.

- Check the functions of the operation buttons carefully and operate them correctly.

Uso de la unidad de control remoto

Cuando utilice esta unidad, diríjala hacia REMOTE SENSOR y presione los botones suave y firmemente. El control remoto es posible dentro de un límite aproximado de 7 m. No obstante, puesto que el alcance disminuye cuando se emplea la unidad desde un ángulo, utilícela en lo posible situándose directamente frente a REMOTE SENSOR. No exponga REMOTE SENSOR a luces intensas (directamente al sol o luces artificiales) y asegúrese que no haya ningún obstáculo entre REMOTE SENSOR y la unidad de control remoto.

Las siguientes operaciones pueden realizarse utilizando la unidad de control remoto.

- **Estudie detenidamente las funciones de los botones de operación y utilícelos correctamente.**


遙控器的使用方法

使用遙控器的時候，將遙控器對準遙控感應器（REMOTE SENSOR），然後慢而確實地按壓鍵鈕。遙控器的操縱距離為7m以內。但是，如果從斜角使用遙控器，其操縱距離便會變得短。因此，使用時應當盡可能從正面對準遙控感應器（REMOTE SENSOR）使用。


請不要將遙控感應器暴露於強光之下（直射太陽光或人工光線），並且要確認在遙控器和遙控感應器之間沒有障礙物。

使用遙控器可做下列各項操縱。

- 仔細檢查各個操縱鍵鈕的功能，並且正確使用它們。



Use the following buttons with the SHIFT button.
 Utilice los siguientes botones conjuntamente con el botón SHIFT.
 使用下列各鍵時要同時按住SHIFT鍵



- ① Track (tune) number buttons (No.1 – No.10, +10)
- ② CD SEARCH/DOWN and UP buttons (◀◀, ▶▶)
 - In the CD mode, scans to the beginning of a tune and starts forward or reverse search.
 - In the tuner mode, tunes to broadcasts.
- ③ Cassette operation buttons

◀◀	: Fast wind (from right to left)/Music scan button
▶▶	: Fast wind (from left to right)/Music scan button
●/II	: Record/Record-pause button
◀	: Play button (reverse direction of tape)
■	: Stop button
▶	: Play button (forward direction of tape)
- ④ SOUND mode button
- ⑤ SHIFT button
- ⑥ POWER button
- ⑦ SLEEP button
- ⑧ AUX button
- ⑨ OPEN/CLOSE button (▲)
- ⑩ CD ▶/II: CD mode/play/pause button
- ⑪ ■/CLEAR: stop/clear button
- ⑫ TUNER/BAND button
- ⑬ ACTIVE HYPER-BASS PRO button
- ⑭ VOLUME buttons (+,-)

Press the following buttons while holding down the SHIFT button ⑤.

- ⑯ PROGRAM button
- ⑰ INTRO button
- ⑱ RANDOM button
- ⑲ SYNCHRO REC button
- ⑳ REPEAT button
- ㉑ STEREO AUTO/MONO button

- ① Botones numéricos de pista (música) (No. 1 – No.10, +10)
- ② Botones (◀◀, ▶▶) de búsqueda ascendente/ descendente de CD (SEARCH, DOWN/UP)
 - Para buscar el comienzo de una canción y para iniciar la búsqueda hacia adelante o hacia atrás en el modo de CD.
 - Para sintonizar las emisiones en el modo de sintonización.
- ③ Botones para la operación del cassette

◀◀	: Botón para bobinar rápidamente la cinta (de derecha a izquierda)/ búsqueda de música.
▶▶	: Botón para bobinar rápidamente la cinta (de izquierda a derecha)/ búsqueda de música.
●/II	: Botón de grabación/pausa de grabación.
◀	: Botón de reproducción (en sentido inverso)
■	: Botón de parada
▶	: Botón de reproducción (hacia adelante)
- ④ Botón de modo SOUND
- ⑤ Botón SHIFT
- ⑥ Botón POWER
- ⑦ Botón SLEEP
- ⑧ Botón AUX
- ⑨ Botón OPEN/CLOSE (▲)
- ⑩ CD ▶/II: Botón de modo /reproducción/pausa de CD
- ⑪ ■/CLEAR: Botón de parada/cancelación
- ⑫ Botón TUNER/BAND
- ⑬ Botón ACTIVE HYPER-BASS PRO
- ⑭ Botones VOLUME (+,-)

Presione los siguientes botones manteniendo presionado el botón ⑤ SHIFT.

- ⑯ Botón PROGRAM
- ⑰ Botón INTRO
- ⑱ Botón RANDOM
- ⑲ Botón SYNCHRO REC
- ⑳ Botón REPEAT
- ㉑ Botón STEREO AUTO/MONO

- ① 樂曲號碼鍵 (1~10, +10)
- ② CD搜尋／正反向鍵 (◀◀, ▶▶)
 - CD方式時、搜尋曲頭及正向搜尋或反向搜尋。
 - 收音方式時、調至電臺。
- ③ 錄音帶操作鍵

◀◀	: 快速卷帶 (從右向左)／搜尋樂曲鍵
▶▶	: 快速卷帶 (從左向右)／搜尋樂曲鍵
●/II	: 錄音／錄音暫停鍵
◀	: 放音鍵 (反向)
■	: 停止鍵
▶	: 放音鍵 (正向)
- ④ 音源方式鍵 (SOUND)
- ⑤ 轉換鍵 (SHIFT)
- ⑥ 電源鍵 (POWER)
- ⑦ 睡眠鍵 (SLEEP)
- ⑧ 幫助鍵 (AUX)
- ⑨ 開／關鍵 (OPEN/CLOSE) (▲)
- ⑩ CD ▶/II: CD方式／放音／暫停鍵
- ⑪ ■/CLEAR: 停止／取消鍵
- ⑫ 調諧器／波段鍵 (TUNER/BAND)
- ⑬ 營敏超低頻鍵 (ACTIVE HYPER-BASS PRO)
- ⑭ 音量鍵 (VOLUME) (+,-)


使用下列各鍵時要同時按住 SHIFT ⑤ 鍵

- ⑯ 程序鍵 (PROGRAM)
- ⑰ 曲頭鍵 (INTRO)
- ⑱ 隨意鍵 (RANDOM)
- ⑲ 同步錄音鍵 (SYNCHRO REC)
- ⑳ 重複鍵 (REPEAT)
- ㉑ 立體聲自動／單聲道鍵 (STEREO AUTO/MONO)

SWITCHING THE POWER ON/OFF

CONEXION/DESCONEXION DE LA ALIMENTACION

電源的接通與斷開



Switching the power on/off

- Switching on:



- Switching off:



Conexión/desconexión de la alimentación

- Conexión:

The indicator goes out.
El indicador se apaga.
指示燈熄滅。

The indicator in the display window lights.
• Se enciende el indicador en la ventanilla de indicación.
• 顯示窗的指示燈亮起。

- Desconexión:

The indicator lights.
Se enciende el indicador.
指示燈點亮。

The indicator in the display window goes out and only the clock is indicated.
• Se apaga el indicador en la ventanilla de indicación y solo permanece la indicación del reloj.
• 顯示窗的指示燈熄滅，只有時鐘的指示燈是點亮的。

- 斷開電源:

One touch operation (COMPU PLAY)

Even when the power is set to STANDBY, pressing the button shown below switches on the power and selects the source.

Operación de un solo toque (COMPU PLAY)

Aun cuando la alimentación esté en STANDBY, el presionar el botón mostrado abajo, conecta la energía y selecciona la fuente.

Function mode modo de función 各項功能	Operations operaciones 操作
	CD (雷射唱片) When this button is pressed with a CD loaded, CD playback begins. Cuando se presiona este botón habiendo un CD colocado, comienza la reproducción del mismo. 裝入CD唱片，按壓此鍵，CD唱片的放音便開始。
or	TAPE (錄音帶) When this button is pressed with a tape loaded, tape playback begins. Cuando se presiona este botón habiendo una cinta colocada, comienza la reproducción de la misma. 裝入錄音帶，按壓此鍵，錄音帶的放音便開始。
	TUNER (調諧器) When this button is pressed, the tuner is engaged. Cuando se presiona este botón, se activa el sintonizador. 按壓此鍵，調諧器便被接通。
	AUX (輔助) A sound source connected to the AUX terminal can be engaged. Es posible activar una fuente de sonido que esté conectada al terminal AUX. 聲源可以連接至輔助端子。

IllumiMagic COMPU PLAY

When approaching the SENSOR section with your hand while the POWER button is set to STANDBY, one touch operation button indicators automatically blink for 10 seconds so that these button indicators can be easily found for sound source selection.

If nothing is done while these indicators blink....
The blinking indicators go out after 10 seconds. Then, after 2 seconds elapse, IllumiMagic COMPU PLAY will be activated again.

IllumiMagic COMPU PLAY

Cuando se aproxima la mano a la sección SENSOR mientras el botón POWER está colocado en STANDBY, los indicadores del botón de operación de un solo toque parpadean automáticamente durante 10 segundos, de tal manera que puedan ser localizados fácilmente para la selección de la fuente de sonido.

Si no se hace nada, mientras estos indicadores parpadean...
Los indicadores parpadeantes se apagan después de transcurridos 10 segundos. Luego, después de una pausa de 2 segundos, se activa nuevamente la función IllumiMagic COMPU PLAY.

電腦控制放音 (COMPU PLAY)

即使電源設於待機 (STANDBY) 方式，按壓下示鍵鈕可接通電源並選擇聲源。

魔光 COMPU PLAY

當電源鍵設為待機 (STANDBY)，您的手靠近感應器 (SENSOR) 部件時，單獨放音鍵指示燈會自動閃爍 10 秒鐘，以便在選擇聲源時容易發現這些鍵指示燈。

如果這些指示燈閃爍時無任何操作.....
指示燈閃爍 10 秒鐘後消失，兩秒鐘後，魔光 COMPU PLAY 將再次啓動。

16

Notes:

- When your hand approaches a point approx. 30 cm from the SENSOR section, the indicators blink.
- Since the sensor detects light reflection, an object other than a hand approaching the sensor can activate IllumiMagic COMPU PLAY. However, operational distance varies depending on the shape or color of object, or brightness of conditions.
- When an object is placed in front of the SENSOR section, the indicator may blink repeatedly. However, this is not a malfunction. Take one of the following measures.
 - Do not place anything in front of the remote SENSOR within a distance of 1 m (3.28 ft).
 - Change the direction of this unit.
 - Relocate this unit.

When the same operation is performed with the POWER button set to ON, one touch operation button indicators light for 10 seconds.

When the indicator blinking (or lighting) is not required....

When the POWER button is set to STANDBY, operate as follows.



Press the POWER button while pressing the SOUND button. "OFF" is shown in the display window.
(Perform the same operations to activate IllumiMagic COMPU PLAY again. "ON" is displayed in the display window.)

Notes:

1. When the CD tray OPEN/CLOSE (▲) button is pressed, the sound source does not switch over, and the CD tray opens or closes.
(When the POWER is switched off with the CD tray open, the CD tray closes, then the POWER switches off.)
2. When switching off the power, be sure to press the POWER button.
3. The COMPU PLAY button on the remote control has the same function as that on the main unit. IllumiMagic COMPU PLAY is activated using the main unit only.
4. If installed in an audio rack, the rack's front glass plate may impede the unit's SENSOR section function so that IllumiMagic COMPU PLAY may not be activated.

Notas:

- Cuando se aproxima la mano hasta aproximadamente 30 cm. de la sección SENSOR, los indicadores parpadean.
- Como el sensor detecta la reflexión de la luz, un objeto cualquiera que no sea la mano aproximado al sensor puede activar la función IllumiMagic COMPU PLAY. Sin embargo, la distancia de operación varía dependiendo de la forma, del color o del brillo del objeto.
- Cuando se coloca un objeto en frente de la sección SENSOR, el indicador puede parpadear repetidamente. Sin embargo esto no es una falla. Tome una de las siguientes medidas.
 - No coloque nada en frente del SENSOR remoto a menos de 1 m. de distancia.
 - Cambie la orientación de esta unidad.
 - Reubicue esta unidad.

Cuando se ejecuta la misma operación con el botón POWER colocado en ON, se encienden durante 10 segundos los indicadores del botón de operación de un solo toque.

Cuando el indicador está parpadeando (encendido), no es necesario...

Al colocar el botón POWER en STANDBY, proceda de la siguiente manera.

Presione el botón SOUND al mismo tiempo que presiona el botón POWER. En el visor de indicación aparecerá "OFF".
(Ejecute las mismas operaciones para activar otra vez la función IllumiMagic COMPU PLAY. El visor de indicación mostrará "ON".)

Notas:

1. Cuando se presiona el botón (▲) OPEN/CLOSE del portadisco de CD, la fuente de sonido no cambia, y el portadisco de CD se abre o se cierra.
(Cuando se desconecta POWER con el portadisco de CD abierto, éste se cierra, y luego se desconecta POWER).
2. Cuando se desconecta la alimentación, asegúrese de presionar el botón POWER.
3. El botón COMPU PLAY del controlador remoto posee la misma función que el de la unidad principal. Solo es posible activar IllumiMagic COMPU PLAY utilizando la unidad principal.
4. Si se lo instala en una platóica de audio, el vidrio frontal de la estantería puede impedir que funcione la sección SENSOR de la unidad, y por consiguiente no se podrá activar IllumiMagic COMPU PLAY.

注意：

- 當您的手離 SENSOR (感應器) 部件大約 30cm 時，指示燈即閃爍。
- 手以外的物體接近感應器能啓動魔光 COMPU PLAY，但動作距離可能因物體之形狀或顏色，或亮度條件而不同。
- 當一個物體被放在 SENSOR (感應器) 部件前面時，指示燈會反復閃爍，這不是故障。請採取下列措施之一。
 - 在 1m 範圍內，請勿將任何物體放置在遙控感應器前面。
 - 變更本機的方向。
 - 重新安置本機。

當電源 (POWER) 鍵設為 ON，而做相同操作時，單獨放音鍵指示燈將亮 10 秒鐘。

當無需指示燈閃爍 (或亮) 時...

將 POWER 鍵設定於 STANDBY 進行下列操作。

按 SOUND 鍵的同時按 POWER 鍵，“OFF”即出現在顯示窗上。
(進行同樣的操作再次啓動魔光 COMPU PLAY，“ON”即出現在顯示窗上。)

注意：

1. 按壓 CD 軀蓋的OPEN/CLOSE (▲) 鍵鈕時，音源不轉換，CD 軀蓋打開或關閉。
(CD 軀蓋打開著而關閉電源時，CD 軀蓋關閉後，電源才關閉。)
2. 要關閉電源時，一定要按壓 POWER 鍵。
3. 遙控器上的 COMPU PLAY 鍵與主機上的具有相同的功能。魔光 COMPU PLAY 僅可用主機上的來啓動。
4. 若將本機安放於音響機架內，機架的前玻璃可能阻礙本機的部位工作，使魔光 COMPU PLAY 不會被啓動。


VOLUME, TONE AND OTHER CONTROLS

VOLUMEN, TONO Y OTROS CONTROLES

音量、音調和其它控制

VOLUME button

- + : Use to increase the volume.
 - : Use to decrease the volume.
- (control range from VOL 0 to VOL 50.)


**ACTIVE HYPER-BASS PRO button**

- ON** : The red indicator of ACTIVE HYPER-BASS PRO button lights. Set to this position when listening to ACTIVE HYPER-BASS PRO sound.
- OFF** : The red indicator of ACTIVE HYPER-BASS PRO button goes out. Set to this position when ACTIVE HYPER-BASS PRO sound is not required.

Sound mode button

This unit has four preset sound modes (BEAT, POP, CLEAR, LIVE). These modes can be selected to enhance the type of music being played.

- Press the SOUND button to select the sound mode.
- Each time the SOUND button is pressed the sound mode changes as follows:

**Sound mode selection****FLAT (No sound effect (flat characteristics)):**

Set to this position when listening to classical music.

BEAT:

Set to this position for music with a heavy beat, such as rock or disco music.

POP:

Set to this position for light music including popular and vocal music.

CLEAR:

Set to this position for crisp and clear sounding music with transparent highs.

LIVE:

Set to this position for the sound of live jazz music.

Botón VOLUME

- + : Utilícelo para aumentar el volumen.
 - : Utilícelo para reducir el volumen.
- (Los límites de control van de VOL 0 a VOL 50.)

Botón ACTIVE HYPER-BASS PRO

- ON** : Se enciende el indicador rojo del botón ACTIVE HYPER-BASS PRO. Colóquelo en esta posición cuando escucha sonido ACTIVE HYPER-BASS PRO.
- OFF** : Se apaga el indicador rojo del botón ACTIVE HYPER-BASS PRO. Colóquelo en esta posición cuando no deseas escuchar sonido ACTIVE HYPER-BASS PRO.

Botón de modo de sonido

Esta unidad posee cuatro modos preprogramados (BEAT, POP, CLEAR, LIVE). Estos modos pueden ser seleccionados para realizar el tipo de música que está siendo reproducida.

- Presione el botón SOUND para seleccionar el modo de sonido.
- Cada vez que se presiona el modo de sonido, este cambia de la siguiente manera:

Selección del modo de sonido

FLAT (Sin efectos de sonido; característica plana): Colóquelo en esta posición cuando escucha música clásica.

BEAT:

Colóquelo en esta posición para música con ritmo pesado tal como rock o música de discoteca.

POP:

Colóquelo en esta posición para música leve incluyendo música popular y vocal.

CLEAR:

Colóquelo en esta posición para música con sonido contrastado y nítido, con altos transparentes.

LIVE:

Colóquelo en esta posición para sonido de música de jazz en vivo.

音量键 (VOLUME)

- + : 用來增大音量。
 - : 用來減小音量。
- (音量範圍從 VOL 0 至 VOL 50)

靈敏超低音鍵

接通：ACTIVE HYPER-BASS PRO 鍵的紅色指示燈點亮，在聽靈敏超低音音響時請設定至該位置。
斷開：ACTIVE HYPER-BASS PRO 鍵的紅色指示燈熄滅，在不需要靈敏超低音音響時設定到該位置。

音源方式鍵

本機具備四種預設均衡模態 (BEAT, POP, CLEAR, LIVE)，這些模態能被選擇來增強放音的音響魅力。

- 按 SOUND 鍵選擇音源方式。
- 每按一次 SOUND 鍵，音源方式變化如下：

音源方式選擇**FLAT (無音響效果 (平坦特性)) :**

聽古典音樂時設定於此位置。

BEAT :

設定於此位置以獲得帶重打擊樂 (如搖滾或的士高) 的音樂。

POP :

設定於此位置以獲得包括通俗音樂及聲樂的輕音樂。

CLEAR :

設定於此位置以獲得清脆、明晰的透明高音。

LIVE :

設定於此位置以獲得現場爵士音樂。

18

CONCERNING COMPACT DISCS

EN CUANTO A LOS COMPACT DISC

有關 CD 唱片

Since dirty, damaged and warped discs may damage the unit, care should be taken of the following:

1. **Usable compact discs**
Use compact discs with the mark shown.
2. **Notes on handling discs**
 - Do not touch the reflective recorded surface.
 - Do not stick anything to or write anything on the label side.
 - Do not bend compact discs.
3. **Storage**
 - After removing a disc from the unit, be sure to put it back in its case.
 - Do not expose discs to direct sunlight, high temperatures from a heater, etc., high humidity, or dust.
4. **Cleaning discs**
Before loading a disc, wipe off any dust, dirt or fingerprints with a soft cloth. Discs should be cleaned by wiping radially, from the center to the edge.
- Never use thinner, benzine, record cleaner or antistatic spray.


Puesto que los discos sucios, alabeados y con defectos pueden dañar la unidad, deben tenerse en cuenta los siguientes puntos:

1. **Compact disc utilizable**
Utilice compact disc con la siguiente marca.
2. **Notas sobre la manipulación de discos**
 - No toque la superficie grabada reflectante.
 - No pegue ni escriba nada sobre el lado del rótulo.
 - No doble el compact disc.
3. **Almacenamiento**
 - Guarde los discos en sus cajas luego de sacarlos del reproductor.
 - No los exponga a la luz solar directa, altas temperaturas de un calefactor, etc., gran humedad o polvo.
4. **Limpieza de discos**
Antes de colocar un disco, límpielo la superficie de polvo, suciedad e impresiones digitales con un paño suave. El disco debe limpiarse de forma radial, desde el centro hacia el borde.
- Nunca utilice diluyente, bencina, limpiadores de discos analógicos o pulverizadores antiestáticos.

- Removing the disc from its storage case and loading it.
- Extracción del disco de su caja y colocación
- 從CD唱片盒中將唱片取出來，裝入唱機的唱片盒中。




- Press the center and lift out.
- Presione el centro y levántelo.
- 按壓中心部位並且將它取出。



- Press to secure the CD.
- Presiónelo para sujetar el CD.
- 按壓唱片，將其放穩。

- Handling
- Manipulación
- 持拿



- Cleaning
- Limpieza
- 拂拭




PLAYING COMPACT DISCS

REPRODUCCION DE COMPACT DISCS

CD唱片的放音

Playing an entire disc ... The following example assumes a compact disc with 12 tunes and a total playing time of 48 minutes 57 seconds.

Operate in the order shown



- ① Press to open the CD tray. (The power is switched on.)
- ② Load a disc with the label side facing up. Press to close the CD tray. (The tray can be closed by pressing the ▶/II button.)
- ③ Press to start play.
- As tunes are played, their track numbers go out one by one.
- ④ Adjust.

• When a CD has been loaded with the power switched off, simply press the ▶/II button to switch on the power and start CD playback.

• 8-cm (3-3/16") compact discs can be used in this unit without an adapter.

Note:

When the CD tray is closed by pressing the ▶/II button, the CD starts as soon as the CD tray is closed.

To stop play

• To stop in the middle of a disc

During playback, press the ■/CLEAR button to stop play.

Reproducción de un disco completo... El siguiente ejemplo considera un compact disc con 12 canciones y un tiempo de reproducción total de 48 minutos, 57 segundos.

Proceda en el orden indicado

- ① Presione para abrir el portadisco de CD. (Se conecta la alimentación).
- ② Coloque un disco con la etiqueta apuntando hacia arriba. Presione para cerrar el portadisco de CD. (El portadisco puede ser cerrado presionando el botón ▶/II).
- ③ Presione para iniciar la reproducción.
- A medida que las canciones son reproducidas, los números de pista se apagan uno por uno.
- ④ Ajuste.


Con esta unidad es posible utilizar compact disc de 8-cm sin necesidad de adaptador.

Nota:

La reproducción se inicia inmediatamente cuando se cierra el portadisco de CD presionando el botón ▶/II.

Para detener la reproducción

- Para detener en la mitad de un disco
- Presione el botón ■/CLEAR para detener la reproducción.



整張CD唱片的放音...

在此所示的例子，假設為一張錄有12樂曲、總放音時間為48分57秒的CD唱片。

根據下面所示順序進行操作

- ① 按此鍵打開CD唱盤（電源業已接通）。
- ② 將唱片標簽朝上放入唱盤，然後關上CD唱盤（按壓 ▶/II 鍵可關閉唱盤）。
- ③ 按鍵開始放音。
- 放樂曲時，樂曲號碼會依次顯示出來。
- ④ 調節。

• 如裝入CD唱盤後關閉了電源，可按壓 ▶/II 鍵接通電源並開始CD放音。

• 本機可以播放8cmCD唱盤，無需適配器。

注：

當按壓 ▶/II 鍵鈕即關閉CD唱盤時，蓋蓋關上的同時，CD唱機開始放音。

停止放音

- 在唱片放音途中停止放音
- 在放音中，按壓 ■/CLEAR 清除鍵鈕即停止放音。

20

• To stop a disc temporarily

Press the ▶/II button to stop play temporarily and the playing time blinks. When pressed again, play resumes from the point where it was paused.

Notes:


- The following indication may be shown when a disc is dirty or scratched, or when the disc is loaded upside down.
- In such a case, check the disc and insert again after cleaning the disc or turning it over.

• Para detener temporalmente un disco

Presione el botón ▶/II para detener el disco temporalmente; el tiempo de reproducción parpadeará. Cuando se lo presiona otra vez, se reiniciará la reproducción en el punto donde fue detenida.

Notas:

- La siguiente indicación puede aparecer cuando el disco está sucio o rayado, o puesto al revés. En tal caso, verifique el disco e insértelo nuevamente después de haberlo limpiado o invertido.



• 暫時停止唱片放音

按壓 ▶/II 鍵鈕即暫時停止放音，放音時間指示閃爍。再按壓一下，放音便從暫停位置重新開始。

注：

- 裝入唱機的唱片髒或有劃痕，或者唱片的面裝反時，下面的指示便會出現。
- 這時，請檢查唱片，在拂拭乾淨或翻轉後再裝入。

• 如CD唱盤裡無唱片，顯示窗裡會有“OPEN”字樣出現，這時按 ▶/II 鍵，則可打開CD唱盤。

• 請勿在酷熱或者嚴寒的環境之中使用。我們所建議的使用溫度為5°C至35°C的範圍以內。

• 待放音結束以後，請取出CD唱片，並且將此唱片放回CD盒子中。

• 如果在放音中發生跳曲，請降低音量。

• 當唱機受到強烈的衝擊或者在有振動的地方使用時，有可能發生跳曲現象（譬如，在行駛於凹凸不平的道路上的汽車中）。

跳越放音

• 在放音中，可以往前跳越至下一樂曲的曲頭或者往後跳越至放音中樂曲的曲頭或者是已經放音的前一支樂曲的曲頭。當您要選聽的樂曲的曲頭被找到後，就會自動開始播放。

跳下一支樂曲...

若要聽下一支樂曲，按壓一下 ►► 鍵鈕便可跳越至下一樂曲的曲頭。

聽前一支樂曲...

若要聽前一支樂曲，按壓一下 ◀◀ 鍵鈕便可跳越至放音中樂曲的曲頭；如果再按壓一次 ◀◀ 鍵鈕便可跳越至前一支樂曲的曲頭。

• When a CD is not loaded in the tray, "OPEN" is displayed and the CD tray opens when the ▶/II button is pressed.

- Do not use the unit at excessive high or low temperatures. The recommended temperature range is from 5°C (41°F) to 35°C (95°F).
- After playback, unload the disc and close the CD tray.
- If mistacking occurs during play, lower the volume.
- Mistacking may occur if a strong shock is applied to the unit or if it is used in a place subject to vibrations (i.e. in a car travelling on a rough road).

Skip playback

- During playback, it is possible to skip forward to the beginning of the next tune or back to the beginning of the tune being played or the previous tune; when the beginning of the required tune has been located, play starts automatically.

To listen to the next tune ...

Press the ►► button once to skip to the beginning of the next tune.

To listen to the previous tune ...

Press the ◀◀ button to skip to the beginning of the tune being played back and press again to skip to the beginning of the previous tune.

Reproducción por salto

- Durante la reproducción, es posible saltar al comienzo de la próxima canción o retroceder al comienzo de la canción que se está reproduciendo o de la canción previa; una vez localizado el comienzo de la canción deseada, la reproducción comienza automáticamente.

Para escuchar la próxima canción...

Presione el botón ►► una vez para saltar al comienzo de la próxima canción.

Para escuchar la canción previa ...

Presione el botón ◀◀ para saltar al comienzo de la canción que se está reproduciendo y presínelo nuevamente para saltar al comienzo de la canción previa.

Search playback (to locate the required position on the disc)

- The required position can be located using fast-forward or reverse search while playing a disc.

Keep pressing for fast-reverse search.
Mantenga presionado para la búsqueda regresiva rápida.
若要倒帶搜尋，可按壓此鍵鈕



Keep pressing for fast-forward search.
Mantenga presionado para la búsqueda progresiva rápida.
若要快進搜尋，可按壓住此鍵鈕

- Hold down the button; search play starts slowly and then gradually increases in speed.
- Since low-volume sound (at about one quarter of the normal level) can be heard in the search mode, monitor the sound and release the button when the required position is located.

Direct access playback (using the remote control unit)

- Pressing any of the track number buttons will start play from the beginning of the designated tune, without your having to press the CD ▶/■ button. (This function cannot be used during programmed play.)


Búsqueda por reproducción (para ubicar la posición deseada en el disco)

- La posición deseada puede ubicarse utilizando la búsqueda progresiva o regresiva rápida durante la reproducción del disco.

- Mantenga presionado el botón; se iniciará lentamente la reproducción, aumentando posteriormente su velocidad en forma gradual.
- Puesto que se puede escuchar un sonido muy bajo (aproximadamente un cuarto del nivel normal) en el modo de búsqueda, monitoree el sonido y suelte el botón cuando localice la posición deseada.

Reproducción por acceso directo (utilizando la unidad de control remoto)

- Presionando cualquier botón de número de pista se iniciará la reproducción desde el comienzo de la canción designada, sin tener que pulsar el botón CD ▶/■. (Esta función no puede emplearse durante la reproducción programada.)



- Press the ■/CLEAR button to set to the CD mode.
- Designate the required tune using the track number buttons.
- To designate tune numbers 1 to 10, press the track number button corresponding to the tune (track) number.

- Presione el botón ■/CLEAR para establecer el modo CD.
- Seleccione la canción deseada usando los botones de número de pista.
- Para seleccionar los números de canciones 1 al 10, presione el botón del número de pista correspondiente al número de la canción (pista).

- To designate tune number 11 or higher, press the +10 button the required number of times, then the track number button. (Example: To designate the 20th tune, press the +10 button once, then press the track number button 10.)
- +10 button:
Each time this button is pressed, the number increases by 10. First press this button to set the 10's digit, then press the track number button to set the 1's digit.
- To skip to another tune during play.**
When the required track number button is pressed, the display shows the designated track number and play starts from the beginning of the designated tune.

- Para seleccionar el número de canción del 11 en adelante, presione el botón +10 el número de veces necesario y luego un botón de número de pista. (Ejemplo: Para seleccionar la canción No. 20, presione el botón +10 una vez, luego presione el botón 10 de número de pista.)

* Botón +10:
Cada vez que se presiona este botón, el número aumenta en incrementos de 10. Púlselo primero para fijar el dígito de las decenas y luego presione el botón de número de pista para fijar el dígito de las unidades.





- Para saltar a otra canción durante la reproducción.**
Cuando se presiona el botón de número de pista deseado, el indicador muestra el número de pista designado y comienza la reproducción desde el comienzo de la canción seleccionada.

Programmed play (using the remote control unit)

- Up to 20 tunes can be programmed to be played in any required order.
The total playing time of programmed tunes is displayed (up to 99 minutes, 59 seconds).
(Example: When programming the 2nd tune to be played first, the 6th tune next, and then the 12th tune, etc.)

Reproducción programada (utilizando la unidad de control remoto)

- Puede programarse la reproducción de hasta 20 canciones en cualquier orden deseado.
Se visualiza el tiempo total de reproducción de las canciones programadas (hasta 99 minutos, 59 segundos).
(Ejemplo: Cuando programe la reproducción de la 2ª canción, la 6ª canción, la 12ª canción, etc., en dicho orden.)



The total playback time of programmed tunes is displayed.
Se visualiza el tiempo de reproducción total de las canciones programadas.
顯示編序樂曲的總放音時間



搜尋放音

(在唱片中搜尋您所需要的某個位置)

- 若要在唱片中搜尋您所需要的某個位置，可以在放音中，用快進搜尋或者倒帶搜尋來進行。

直接放音 (使用遙控器)

- 直接按壓您所要欣賞的樂曲的號碼鍵鈕，便可從曲頭開始播放該曲，而不需要按壓CD ▶/■鍵鈕。此功能不可以在編序放音中使用。

- 按壓 ■/CLEAR鍵鈕，將本音響設備設於CD功能。

- 按壓樂曲的號碼鍵鈕，選擇您欲欣賞的樂曲。
• 根據樂曲號碼，按壓與之相符合的樂曲號碼鍵鈕，以選擇1至10的樂曲號碼

- 若要選擇11以上的樂曲號碼，根據所要選擇的樂曲號碼的數字按壓+10鍵鈕，然後按壓樂曲號碼鍵鈕（譬如，要選擇第20號樂曲，先按壓+10鍵鈕，然後按壓樂曲號碼鍵鈕10）

- * +10鍵鈕：
每按壓一次此鍵鈕，數字便增加10。先按壓此鍵鈕設定十位數，然後按壓樂曲號碼鍵鈕設定個位數

- 在放音中跳越至別的樂曲
只要您按壓了您所希望欣賞的樂曲的號碼鍵鈕，該曲的樂曲號碼便會被顯示出來，並且從該樂曲的曲頭開始放音。


編序放音 (使用遙控器)

- 有20個樂曲可以按照您希望的順序進行編序。
所編序樂曲的總放音時間將被顯示出來（最長為99分59秒）
(譬如：將第2曲編為第1放音曲、第6曲為其次、其後為第12曲等等)

- ① Press the ■/CLEAR button.
- ② Press the PROGRAM button while pressing the SHIFT button to set to the programming mode.
- ③ Press to designate the required track number.
- ④ Designate the remaining tunes by pressing the track number buttons.
- ⑤ Press the ▶/II button when programming is completed. Programmed playback starts.

To confirm the details of a program...

Press the PROGRAM button while pressing the SHIFT button; the tunes making up the program will be displayed in programmed order.



To clear the programmed tunes ...

Press the ■/CLEAR button before playing a disc. During programmed playback, press this button twice. When the CD tray is opened, programmed tunes are cleared automatically.

Notes:

1. If the total playing time of the programmed tunes exceeds 99 minutes 59 seconds, the total playing time indication will go out. In such a case, cancel the program and program tracks (tunes) again.
2. Programming of track (tune) number 21 or more is impossible.
3. When a disc with 16 or more tunes is loaded, the "OVER" indicator will appear.
4. When performing CD synchro recording or timer playback in "Programmed play" order, step ⑤ above is not required.

- ① Presione el botón ■/CLEAR.
- ② Pulse el botón PROGRAM mientras presiona el botón SHIFT para establecer el modo de programación.
- ③ Presione para designar el número de pista deseada.
- ④ Seleccione las canciones restantes presionando los botones de número de pista.
- ⑤ Presione el botón ▶/II cuando finalice la programación. Se iniciará la reproducción programada.

Para confirmar el contenido de una programación ...

Al pulsar el botón PROGRAM mientras presiona el botón SHIFT; se visualizan las canciones que conforman el programa en el orden programado.

- ① 按壓 ■/CLEAR 鍵。
- ② 在按SHIFT鍵的同時，按壓PROGRAM鍵，以設定編序功能。
- ③ 按壓樂曲號碼鍵以選擇您所需要的樂曲的號碼。
- ④ 按壓樂曲號碼鍵以選擇剩餘的樂曲的號碼。
- ⑤ 待編序完成以後，按壓 ▶/II 鍵，編序放音開始。

要確認編序內容...

在按SHIFT鍵的同時，按壓PROGRAM鍵；編序內的樂曲將按編序順序顯示出來。

要取消編序樂曲...

在唱片放音之前，按壓 ■/CLEAR 鍵。如果是在編序放音中，按兩次此鍵。如果CD艙蓋被打開，編序樂曲便被自動取消。

注：


1. 如所指定樂曲的總播放時間大於 99 分 59 秒，其總播放時間指示將顯示出來，這時請取消此指定並重新指定樂曲。
2. 不能進行樂曲號 21 以上的指定。
3. 當裝入一張有 16 首以上樂曲的唱片時，“OVER”字樣的指示會出現在顯示窗裡。
4. 當以“指定放音”編序進行 CD 的同步錄音或定時放音時，無需上述第 ⑤步的操作。

24

Repeat play (using the remote control unit)

Press the REPEAT button while pressing the SHIFT button before or during play. A single tune or all the tunes can be repeated.

Whether a single tune or all tunes are to be repeated can be specified. Each time the REPEAT button is pressed while pressing the SHIFT button, the mode will change from a single tune (◀), to all the tunes (◀ ALL), to the clear mode, in this order.



• Repeat playback of a single tune (◀)

The tune being played back will be heard repeatedly.

• Repeat playback of all tunes (◀ ALL)

When playing back an entire disc or programmed tunes, all tunes or the programmed tunes will be heard repeatedly.

Reproducción repetida (utilizando la unidad de control remoto)

Pulse el botón REPEAT mientras presiona el botón SHIFT antes o durante la reproducción. Puede repetirse una sola canción o todas las canciones.

Puede especificarse la repetición de una canción o todas las canciones. Cada vez que pulse el botón REPEAT, mientras presiona el botón SHIFT, cambiará el modo de una sola canción (◀) a todas las canciones (◀ ALL), a modo de cancelación, en este orden.

重複放音（使用遙控器）

在放音之前、或在放音時按“SHIFT”鍵的同時按REPEAT鍵，就能重複播放單首樂曲或所有樂曲。

可指定單首或所有的樂曲進行重複播放。當按SHIFT鍵的同時每按一次REPEAT鍵，方式會按單首樂曲(◀)→所有樂曲(◀ ALL)→取消的順序變化。

Random playback (using the remote control unit)

Press the RANDOM button while pressing the SHIFT button, all tunes on a disc are played, in random order.

Reproducción aleatoria (utilizando la unidad de control remoto)

Pulse el botón RANDOM mientras presiona el botón SHIFT, se reproducen todas las canciones del disco, en orden aleatorio.

INTRO scan operation (using the remote control unit)

- Simply press the INTRO scan button while pressing the SHIFT button to play the first 15 seconds of each tune. The operation is released after playing the introductions of all tunes or all programmed tunes.

Búsqueda de comienzos (INTRO) (utilizando la unidad de control remoto)

- Simplemente pulse este botón, mientras presiona el botón SHIFT, para reproducir los primeros 15 segundos de cada canción. La búsqueda se cancelará luego de reproducir los comienzos de todas las canciones del disco o de todas las canciones programadas.

隨意放音（使用遙控器）

按SHIFT鍵的同時按RANDOM鍵，唱片上所有樂曲將按隨意順序播放。

曲頭（INTRO）試聽操作（使用遙控器）

- 畫要在按SHIFT鍵的同時按INTRO試聽鍵，便可播放每一樂曲的曲頭15秒鐘。待唱片或編序樂曲內的所有樂曲的曲頭都播放完畢後，此操作即被解除。

- If the INTRO scan button is pressed in the middle of a tune while pressing the SHIFT button, the intro scan operation will start from the next tune.
- To release the intro scan mode, press the INTRO scan button again while pressing the SHIFT button and normal playback (or programmed playback) will resume.

- Si se pulsa el botón INTRO durante una canción mientras presiona el botón SHIFT, la búsqueda de comienzos se iniciará a partir de la siguiente canción.
- Para cancelar el modo de búsqueda de comienzos, pulse nuevamente el botón INTRO mientras presiona el botón SHIFT y se reanudará la reproducción normal (o la reproducción programada).

- 當按SHIFT鍵的同時，如按INTRO（曲頭）掃描鍵（在一首樂曲的中部時），則曲頭掃描操作將從下一首樂曲開始。
- 要解除INTRO（曲頭）試聽模態，按SHIFT鍵的同時再按壓一下INTRO試聽鍵鈕便恢復至普通放音（或者編序放音）。

CASSETTE TAPE

Cassette tape

- Loose tape may cause trouble. With a pencil, gently tighten the tape as shown.
- To prevent recordings from being erased accidentally, remove the tab(s) with a screwdriver. Reseal the slots with adhesive tape to erase and re-record after the tabs have been broken off.

Cassette loading

- Push the ▲ PUSH EJECT section of cassette holder to open the cassette holder.
- Load a cassette as shown.
- Close the cassette holder by pressing it gently. Listen for the click that tells you that you've closed the holder securely.

CASSETTE

Cassette

- Una cinta floja puede causar fallas. Ajústela cuidadosamente con un lápiz, etc., como se muestra en la ilustración.
- Para prevenir el borrado accidental de una grabación, extraiga la(s) lengüeta(s) con un destornillador, etc. Cubra los orificios con cinta adhesiva para borrar y regrabar después de haber sacado las lengüetas.

Colocación de un cassette

- Presione la sección ▲ PUSH EJECT del portacassette para abrir el mismo.
- Coloque un cassette tal como se muestra.
- Cierre el portacassette presionándolo suavemente. Escuchará un "clic" indicando que el portacassette se ha cerrado correctamente.




卡式錄音帶

卡式錄音帶

- 鬆散的錄音帶會引起麻煩的事情。按照下面圖示，用一支鉛筆將錄音帶慢慢繞緊。
- 為預防意外地抹消您所需要的錄音內容，請用螺絲刀將錄音保險片拆掉。當錄音保險片拆掉以後，若要抹銷錄音內容或者重新錄音，可用膠布將開孔封住。

錄音帶的裝入

- 按壓▲PUSH EJECT鍵可以打開錄音帶艙。
- 按照下圖所示裝入錄音帶。
- 輕輕地按壓便可關閉錄音帶艙。當您聽到了“卡塔”聲，就說明錄音帶艙關好了。



26

Note:

If the power is switched off while a tape is running, it may be impossible to remove the cassette. If this happens, switch the power on again before attempting to remove the cassette.

Auto tape select mechanism

This unit has an Auto Tape Select mechanism which distinguishes between different types of tape using holes in the cassette. After the type of tape has been detected, bias and equalization are set to be suitable for the tape.

Cassettes with detection holes:

Metal tape (EQ: 70 µs) Type IV
CrO₂ (chrome) tape (EQ: 70 µs) Type II

Cassettes without detection holes:

Normal tape (EQ: 120 µs) Type I

Nota:

Si apaga la unidad mientras escucha una cinta, será imposible sacar el cassette. En tal caso, encienda nuevamente la unidad para extraer el cassette.

Mecanismo de selección automática de cinta

Esta unidad está dotada de un mecanismo de selección automática de cinta que distingue los diferentes tipos de cintas mediante los orificios del cassette. Luego de haberse detectado el tipo de cinta, se ajustan la polarización y la ecualización adecuadas para la cinta.

Cassettes con orificios de detección:

Cinta de metal (EQ: 70 µs) Tipo IV
Cinta de CrO₂ (cromo) (EQ: 70 µs) Tipo II

Cassettes sin orificios de detección:

Cinta normal (EQ: 120 µs) Tipo I



注：

如果在走帶中切斷電源，則可能無法取出錄音帶。這時請先重新接通電源再取出錄音帶。

自動選帶裝置

本機帶有自動選帶裝置，可以根據卡式錄音帶上的識別孔來識別兩種不同的錄音帶。當其識別出錄音帶的種類時，便會設定適合該錄音帶的偏磁及補償。

• 有識別孔的錄音帶：

金屬錄音帶 (EQ: 70 µs) IV型
CrO₂ (鉻) 錄音帶 (EQ: 70 µs) II型

• 沒有識別孔的錄音帶：

普通錄音帶 (EQ: 120 µs) I型

CASSETTE PLAYBACK


Operate in the order shown

REPRODUCCION DE CASSETTES

Proceda en el orden indicado

卡式錄音帶的放音

按照下列順序操作



27

- ① Load a cassette tape with side A facing out.
- ② Press to start playback. (The power is switched on and the TAPE mode is engaged to start the tape playback.)
- ③ Select the reverse mode (\square / \square / \square).
- ④ Set the DOLBY NR switch as required.
- ⑤ Adjust.
- When a cassette tape is loaded with the power switched off, simply press the \triangleright or \triangleleft button to switch on power and start tape playback.
- When the tape is played back with the reverse mode set to the \square (single side play) or \square (both side play) mode, the tape stops automatically at the end of tape after playing one side or both sides. When the reverse mode is set to the \square (continuous play) mode, the tape continuously plays one side after the other until you stop operation.

Music scan

- The beginning of the current tune or the next tune can be located using the music scan facility.
- ① Press the \triangleright or \triangleleft button for tape playback.
- ② Press the $\blacktriangleright\blacktriangleright$ or $\blacktriangleleft\blacktriangleleft$ button for music scan.

- Coloque un cassette de cinta con el lado A apuntando hacia afuera.
- Presione para iniciar la reproducción. (Se conectará la alimentación, activándose el modo TAPE, para iniciar la reproducción de la cinta).
- Seleccione el modo inverso (\square / \square / \square).
- Ajuste el interruptor DOLBY NR como sea necesario.
- Ajuste.
- Para conectar la alimentación e iniciar la reproducción de la cinta del casete colocado cuando la alimentación está desconectada, simplemente presione el botón \triangleright o el \triangleleft .
- Cuando se reproduce la cinta con el modo de inversión fijado en el modo \square (reproducción de un solo lado) o \square (reproducción de ambos lados), la cinta se detendrá automáticamente al final después de haberse reproducido un lado o ambos. Cuando el modo de inversión está colocado en el modo \square (de reproducción continua), la cinta es reproducida continuamente de ambos lados hasta que usted detenga la operación.

- 將 A 面朝外，裝入一盤卡式錄音帶。
- 按壓鍵鈕以開始放音（接通電源，並且接通錄音機功能，開始錄音帶的放音）。
- 選擇反向功能。（ \square / \square / \square ）
- 根據需要設定杜比降噪開關（DOLBY NR）。
- 調節。

- 在裝上錄音帶以後，僅按壓 \triangleright 或 \triangleleft 鍵鈕，電源就會接通，錄音帶開始放音。
- 如果您選擇了 \square （單面放音）或者 \square （雙面放音）的反向功能，那麼，當單面放音或者雙面放音結束（錄音帶走至終端）以後，便自動停止走帶。當反向方式被設定於 \square （連續放音）方式，錄音帶的雙面則連續播放，直至您停止操作。

Búsqueda musical

- Utilizando esta función de búsqueda musical puede localizarse el comienzo de la canción actual o de la próxima.
- ① Presione el botón \triangleright o \triangleleft para reproducir una cinta.
- ② Presione el botón $\blacktriangleright\blacktriangleright$ o $\blacktriangleleft\blacktriangleleft$ para la búsqueda musical.

樂曲搜尋

- 使用樂曲搜尋功能可以很容易地搜尋到正在放音的樂曲或者下一支樂曲的曲頭。
- ① 按壓 \triangleright 或者 \triangleleft 鍵鈕，以開始錄音帶的放音。
- ② 按壓 $\blacktriangleright\blacktriangleright$ 或者 $\blacktriangleleft\blacktriangleleft$ 鍵鈕，以進行樂曲搜尋。

	<ul style="list-style-type: none"> To the start of the next tune Hacia el comienzo de la próxima melodía. 下一曲的曲頭 	<ul style="list-style-type: none"> To the start of the tune being played back Hacia el comienzo de la melodía reproducida 正在放音的樂曲的曲頭
(Forward (\triangleright) direction playback) (Reproducción en la dirección de avance (\triangleright)) 正向放音 (\triangleright)		
(Reverse (\triangleleft) direction playback) (Reproducción en la dirección inversa (\triangleleft)) 反向放音 (\triangleleft)		

The tape direction indicators blink during music scanning.
Los indicadores de la dirección de la cinta parpadean durante la búsqueda de música.
在樂曲搜尋的過程中，走帶方向的指示燈閃爍。

28

- When music scanning is completed, playback will start automatically.
- To skip two tunes or more, repeat the above steps ② and ③.

- Al finalizar la búsqueda musical, se inicia automáticamente la reproducción.
- Para saltar dos o más melodías, repita los pasos anteriores ② y ③.

Notas:

With the following types of tape, the Music Scan mechanism may not operate correctly. This is not a malfunction; use the Music Scan facility only with suitable tapes.

- Tapes with tunes having long pianissimo passages (very quiet parts) or non-recorded portion during tunes.
- Tapes with short non-recorded sections.
- Tapes with high-level noise or hum between tunes.

DOLBY NR system

- Set DOLBY NR as required. The DOLBY NR indicator lights.

Sistema DOLBY NR

- Active DOLBY NR como deseé. Se encenderá el indicador DOLBY NR.

Nota:

Optimum sound quality will not be obtained if different DOLBY NR switch settings are used during recording and playback.

No es posible obtener una calidad de sonido óptima si se utilizan diferentes ajustes del interruptor DOLBY NR para la grabación y para la reproducción.

- 當樂曲搜尋結束後，便自動開始放音。
- 若要跳越兩曲以上，請重複上述第 ② 與第 ③ 步。

註：

如果您使用的是下列類型的錄音帶，樂曲搜尋裝置有可能不正確地工作。這並非功能失靈，這是因為樂曲搜尋裝置只適用於相應的錄音帶。

- 樂曲中有長的輕音（及輕）過渡部分或者樂曲之間沒有空白間隔的錄音帶。
- 曲間空白間隔短的錄音帶。
- 曲間有很大的噪音或者交流干擾聲的錄音帶。


杜比降噪系統

- 根據需要設定 DOLBY NR,DOLBY NR 指示燈點亮。

註：如果 DOLBY NR（杜比降噪）的設定不合適，無論是錄音或者是放音，都不能得到最佳音質。

RADIO RECEPTION

Operate in the order shown


**RADIORRECEPCION**

Proceda en el orden indicado

STEREO AUTO/MONO button
Botón STEREO AUTO/MONO
立體聲自動／單聲道鍵鈕
(STEREO AUTO/MONO)

無線電廣播的接收

按照下列順序操作



- ① Press the TUNER button.
- The power is switched on and a band and radio frequency will be shown in the display.
- ② Select the band (FM, AM or SW).
- ③ Tune to the required station.
- ④ Adjust.

- ① Presione el botón TUNER.
- Se conectará la alimentación; la banda y frecuencia de radio serán mostradas en la indicación.
- ② Seleccione la banda (FM, AM o SW).
- ③ Sintonice la estación deseada.
- ④ Ajuste.

- ① 按壓 TUNER 鍵鈕。
- 電源便被接通，波段以及廣播頻率被顯示出來。
- ② 選擇波段 (FM、AM、SW)。
- ③ 調諷出您所想聽的電臺。
- ④ 調節。

STEREO AUTO/MONO button

Auto mode:

Set to this position when listening to or recording an FM stereo broadcast. The STEREO indicator lights when the FM stereo broadcast is received.

MONO:

Set to this position when FM stereo reception is noisy. When another station is tuned to in the mono mode, the unit automatically enters Auto mode.

Seek tuning

Press the UP or DOWN button for one second or more; the unit enters the seek tuning mode and tunes to higher or lower frequencies, and when the broadcast is received, it stops tuning automatically and the broadcast can be heard.

Manual tuning

Each time the UP or DOWN button is pressed, the unit steps through the current frequency band. Tuning is in steps of 50 kHz/100 kHz for FM and 9 kHz/10 kHz for AM and 5 kHz for SW.

Botón STEREO AUTO/MONO

modo automático:

Ajuste en esta posición cuando escuche o grabe una radioemisión estereofónica por FM. Se enciende el indicador STEREO cuando se recibe una radioemisión estereofónica.

Sonido monofónico (MONO):

Colóquelo en esta posición cuando la recepción estereofónica de FM tenga ruido. Cuando se sintonice otra estación en el modo monofónico, la unidad ingresa automáticamente en el modo automático.

Sintonización por búsqueda

Presionando el botón UP o DOWN por más de 1 segundo, la unidad se establece en el modo de sintonización por búsqueda sintonizando las frecuencias más altas o más bajas; cuando recibe una radiodifusión, detiene automáticamente la sintonización y se escucha la radiodifusión.

Sintonización manual

Cada vez que presiona el botón UP o DOWN, la unidad avanza a través de la banda actual de frecuencias. La sintonización se realiza en pasos de 50 kHz/100 kHz para FM y 9kHz/10kHz para AM y 5kHz para SW.

立體聲自動／單聲道鍵鈕 (STEREO AUTO/MONO)

自動方式：

若要收聽或者收錄 FM 立體聲廣播，可設於此位置。當收到FM立體聲廣播時，STEREO指示燈便會點亮。

MONO：

FM 立體聲接收噪音過大時，請設定於此位置。當用單聲道方式調入其它的電臺時，本機則自動轉入自動方式。

• 搜尋調諧

按壓UP或者DOWN鍵鈕一秒鐘以上，收音裝置便開始收尋調諧，朝高頻率或者朝低頻率方向調諧。當接收到某個廣播時，便自動停止調諧，這時您就可以收聽這個廣播。

• 手動調諧

每按壓一次UP或者DOWN鍵鈕，便會跳過正在收聽的頻率波段。FM、AM、SW 的跳躍頻寬分別為50kHz/100kHz、9kHz/10kHz、5kHz。

Press to move to lower frequency.
Presione para disminuir la frecuencia.
按壓底鍵鈕以朝低的頻率放向移動

Press to move to higher frequency.
Presione para aumentar la frecuencia.
按壓此鍵鈕以朝高的頻率方向移動

30

Notes:

- When seek tuning to the required station is not possible because it is broadcasting too weak a signal, press the UP or DOWN button momentarily to perform manual tuning.
- When the power is set to STANDBY, or another mode (TAPE or CD) is selected, the last tuned frequency is stored in memory. When the power is switched on again or TUNER button is pressed, the same station will be heard.

Notas:

- Cuando no pueda sintonizar la estación deseada con este método debido a que la señal de difusión es muy débil, presione el botón UP o DOWN temporalmente para realizar una sintonización manual.
- Cuando la unidad está en el modo STANDBY, o se ha seleccionado otro modo (TAPE o CD), la última frecuencia sintonizada es almacenada en memoria. Al encender nuevamente la unidad o presionar el botón TUNER, se escuchará la misma estación.

注:

- 如果由於您所要收聽的廣播的信號極為低弱，使用搜尋調諧功能無法接收到，請小心地按壓 UP 或者 DOWN 鍵鈕，作手動調諧。
- 當將電源鍵設於 STANDBY (待機) 方式，或設於其他方式 (TAPE 或 CD) 時，最後所收聽的電臺的頻率便被儲存於記憶裝置中。當再次接通電源，或按壓 TUNER 鍵鈕時，將會收聽到同一電臺。

Auto preset tuning

This function scans the current band (FM, AM or SW), detecting frequencies used to broadcast signals, and stores the first 15 frequencies in memory automatically.

- Press the AUTO PRESET button for more than 2 seconds. The frequencies of stations broadcasting signals can be preset automatically in the order of increasing frequency.(15 stations in each band (FM, AM or SW).

Presintonización automática

Esta función explora la banda actual (FM, AM o SW), detectando las frecuencias utilizadas para emitir señales y almacena automáticamente las primeras 15 frecuencias en memoria.

- Presione el botón AUTO PRESET por más de 2 segundos. Las frecuencias de las estaciones que difunden señales pueden preajustarse automáticamente en el orden de frecuencias ascendentes. (15 estaciones en cada banda (FM, AM o SW).

自動預設調諧

此功能根據廣播信號的頻率，來搜尋正在播放的波段 (FM、AM以及SW)，並且，自動地將前面的15個電臺頻率儲存在記憶裝置。

- 按壓 AUTO PRESET 鍵鈕 2 秒鐘以上，便會按照頻率的遞增順序，自動地預設電臺廣播信號的頻率 (FM、AM 或 SW 各為 15 個電臺)。

Presetting stations (using the remote control unit)

15 stations in each band (FM, AM or SW) can be preset as follows:

- Example (when presetting an FM station broadcasting at 103.5 MHz to preset button "15")

Presintonización de estaciones (utilizando la unidad de control remoto)

Pueden presintonizarse 15 estaciones en cada banda (FM, AM o SW) del siguiente modo:


- Ejemplo: (cuando preajuste una radioemisora de FM difundiendo a 103.5 MHz en el botón de estación presintonizada '15')

預設電臺

(使用遙控器)

按照下面所示的順序，各波段 (FM、AM以及SW) 可以預設 15 個電臺。

- 例 (將 FM103.5MHz 電臺預設於號碼鍵鈕 "15")



31

- ① Press the TUNER/BAND button.
- ② Select the FM band using the TUNER/BAND button.
- ③ Tune to the required station.
- ④ Press preset button "+10", then "5" for more than 2 sec. (When "15" blinks in the preset station display, the station has been preset.)
- Repeat the above procedure for each of the other stations, using a different preset button each time.
- Repeat the above procedure for the other band.
- To change preset stations
Perform step ① above after tuning to the required station.

Notes:

- The previous preset station is erased when a new station is set as the new station's frequency replaces the previous frequency in memory.
- When listening to an AM broadcast, noise may be heard if the remote control is used.

- All preset stations will be erased when a power failure occurs for more than 24 hours or the power cord is unplugged for more than 24 hours. In such cases, preset the stations again.

- ① Presione el botón TUNER/BAND.
- ② Seleccione la banda de FM utilizando el botón TUNER/BAND.
- ③ Sintonice la estación deseada.
- ④ Presione el botón de estación presintonizada "+10" y luego "5" por más de 2 seg. (Cuando destelle "15" en el indicador de estación presintonizada, la estación ha quedado presintonizada.)
- Repita el procedimiento mencionado para las demás estaciones, utilizando un botón de estación presintonizada diferente cada vez.
- Repita el procedimiento mencionado para las otras bandas.

- Para cambiar las estaciones presintonizadas
Realice el paso ① mencionado después de sintonizar la estación deseada.

Notas:

- Se borrará la estación previa cuando se presintonice una nueva estación ya que la nueva frecuencia reemplaza a la previa en la memoria.
- Cuando sintonice una radiodifusión de AM con el control remoto, es posible que escuche ruido.

- Todas las estaciones presintonizadas serán borradas cuando ocurra un corte de energía de más de 24 horas o cuando se desconecte el cordón de alimentación durante más de 24 horas. En tales casos, presintonice otra vez las estaciones.

- 按壓 TUNER/BAND 鍵。
- 用 TUNER/BAND 鍵選擇 FM 波段。
- 調諧出您所需要的電臺。

● 按壓號碼鍵鈕 "+10"，然後按壓鍵鈕 "5" 2秒鐘以上（如果預設電臺的顯示窗中有 "15" 在閃爍，便說明該電臺已經被預設完畢）。

- 重複上述步驟，按壓所需號碼鍵鈕，預設其它各個電臺。
- 其它波段的預設也與上述步驟相同。

● 若要更改預設電臺

調諧出所需要的電臺以後，作上述第 ④ 步的操作。

註：

- 如果重新預設一個新的電臺，並且將該電臺頻率取代原先儲存於記憶裝置中的電臺頻率，那麼，原先的預設電臺便被取消。
- 在收聽 AM 廣播時，如果使用遙控器，那麼，有可能會有噪音。

- 如果電源線從電源插座脫離或者發生停電超過 24 小時以上，則所有預設電臺將被取消。遇到這種情況，請重新預設。

Preset tuning

- The stations must be preset before this operation can be performed.

(Using the controls of the main unit)

- ① Press the TUNER button.
- ② Select the band (FM, AM or SW) using the TUNER button.
- ③ Press the PRESET TUNING button to select the required preset station.

Sintonización de estaciones presintonizadas

- Deberán presintonizarse las estaciones para poder realizar esta operación.

(Utilizando los controles de la unidad principal)

- ① Presione el botón TUNER.
- ② Seleccione la banda (FM, AM o SW) utilizando el botón TUNER.
- ③ Para seleccionar la estación presintonizada deseada presione el botón PRESET TUNING.

預設調諧

- 必須先預設了各個電臺以後，預設調諧才可以使用。

(使用主機上的控制鍵)

- ① 按壓 TUNER 鍵。
- ② 用 TUNER 鍵選擇波段 (FM、AM 或者 SW)。
- ③ 按壓號碼鍵鈕 (1~10、+10)，選定您欲預設的電臺。
- ④ 按壓 PRESET TUNING 鍵鈕以選擇您所需要的預設電臺。

32

(Using the remote control unit)

- ① Press the TUNER/BAND button.
- ② Select the band (FM, AM or SW) using the TUNER/BAND button.
- ③ Press the required preset station buttons (No.1 ~ No.10, +10).
- The preset station number and frequency corresponding to the button pressed are shown.

(Utilizando la unidad de control remoto)

- ① Presione el botón TUNER/BAND.
- ② Seleccione la banda (FM, AM o SW) utilizando el botón TUNER/BAND.
- ③ Presione los botones de estaciones presintonizadas deseadas (No. 1 ~ No. 10, +10).
- Se visualizará el número de estación presintonizada y la frecuencia correspondiente al botón presionado.

(使用遙控器)

- ① 按壓 TUNER/BAND 鍵。
- ② 用 TUNER/BAND 鍵選擇波段 (FM、AM 或者 SW)。
- ③ 按壓號碼鍵鈕 (1~10、+10)，選定您欲預設的電臺。
- 預設電臺號碼和所按壓的頻率將被顯示出來。

使用天線

FM/SW: Connect the provided feeder antenna (see page 6).
AM: Adjust the position of AM loop antenna.

若要更改頻道間隔方式

本機在出廠的時候，聲道位置功能被設於 (AM-9 kHz)。
如果在北美洲使用本機，請將其設於 (AM-10 kHz) (這可以使AM波段的頻率增加10kHz, FM波段的頻率增加100kHz)。

如何更改 (使用主機)

1. 在按壓 PRESET TUNING 鍵時將 POWER 鍵鈕設為 ON, (AM-9 kHz) 出現在顯示窗裡。
2. 按TUNING (UP/DOWN) 鍵選擇所需方式。每按此鍵一次，顯示則變化如下：AM-9 kHz → AM-10 kHz。
3. 當選擇所需方式後，請按 TUNER 鍵以設定其方式。

Using the antennas

FM/SW: Connect the provided feeder antenna (see page 6).
AM: Adjust the position of AM loop antenna.

To Change the Channel Space Mode

When this unit is shipped, the channel space mode is set to (AM-9 kHz).

Set it to (AM-10 kHz), if the unit is to be used in North or South America. (This enables 10 kHz increment steps in AM frequencies and 100 kHz increment steps in FM frequencies.)

How To Operate (Using the main unit)

1. Set the POWER button to ON while pressing the PRESET TUNING button. (AM-9 kHz) is shown in the display window.
2. Press the TUNING (UP/DOWN) button to select the required mode. Each time the button is pressed, the display will change as follows: AM-9 kHz → AM-10 kHz.
3. When the required mode is selected, press the TUNER button to set the mode.

Usos de antenas

FM/SW: Conecte la antena de alimentación de suministrada (Véase la página 6).

AM : Ajuste la posición de la antena de cuadro de AM.

Cambio del modo de espaciamiento entre canales

El modo de espaciamiento entre canales está fijado en (AM-9 kHz) en fábrica.

Ajústelo en (AM-10 kHz) si utiliza la unidad en América del Norte o del Sur. (Esto le permite pasos con incrementos de 10 kHz en frecuencias de AM y con incrementos de 100 kHz para las frecuencias de FM.)

Cómo realizar el cambio (Utilizando la unidad principal)

1. Coloque el botón POWER en ON mientras presiona el botón PRESET TUNING. Aparece (AM-9 kHz) en el display.
2. Presione el botón TUNING (UP/DOWN) para seleccionar el modo requerido. Cada vez que presiona el botón, el display cambia como sigue: AM-9 kHz → AM-10 kHz.
3. Cuando aparezca el modo requerido, presione el botón TUNER para fijarlo.

RECORDING

- In recording, the ALC circuit automatically optimizes the recording level; adjustment of the recording level is unnecessary.
- Check that the safety tab on the cassette tape is not broken off.

GRABACION

- Al efectuar una grabación, el circuito ALC (control automático de nivel) optimiza automáticamente el nivel de grabación; por lo tanto no es necesario ajustar el nivel de grabación.
- Verifique que el cassette tenga su lengüeta de seguridad.

錄音

- 錄音的時候，ALC 電路會自動選擇最合適的錄音電頻，您無須調節錄音電頻。
- 檢查卡式錄音帶上的錄音保險片是否在。按照下列所示順序操作。

Note:
This unit has recording characteristics suitable for normal and CrO₂ tapes. Normal and CrO₂ tapes have different characteristics from metal tape.


Nota:
Esta unidad tiene características de grabación adecuadas para las cintas normales y de cromo. Estas cintas tienen diferentes características que las de metal.

註:
本機具有適用於普通錄音帶和CrO₂錄音帶的錄音特性。普通錄音帶和CrO₂錄音帶的錄音特性與金屬帶是不同的。

Synchronized recording with the CD player

- In this system, the CD player starts playback when the cassette deck enters the recording mode.

Operate in the order shown




- Load a disc and close the CD tray. (The power is switched on.)
- Set to the CD mode.
- Load a cassette with side A facing out. (Wind past the leader tape before starting recording.)
- Select the required reverse mode (or).
- Set the DOLBY NR switch as required.
- When programmed playback is required, program the required tunes using the remote control. (See page 23.)
 - Select tunes with a total playing time which does not exceed the tape length.
- Press the SYNCHRO REC button; synchronized recording will start.

Grabación sincronizada con el reproductor de CD

- En este sistema, el reproductor de CD comenzará la reproducción cuando la platina de cassette se establezca en el modo de grabación.

Proceda en el orden indicado



- Coloque un disco y cierre la puerta del CD. (Se conecta la alimentación).
- Ajuste en el modo CD.
- Coloque un cassette con el lado A hacia afuera. (Bobine hasta pasar la cinta de guía antes de comenzar la grabación.)
- Seleccione el modo de inversión requerido (o).
- Coloque el interruptor DOLBY NR como deseé.
- Cuando se requiera efectuar una reproducción programada, programe las canciones deseadas utilizando el control remoto. (Véase la página 23.)
 - Seleccione las canciones que posean un tiempo de reproducción total que no exceda la duración de la cinta.
- Presione el botón SYNCHRO REC; comenzará la grabación sincronizada.

- Recording starts in the forward direction and CD play starts automatically.
- When the CD player has played the disc or programmed tunes, the deck stops automatically.
- Non-recorded sections of approx. 4 seconds are automatically left between tunes.
- To stop recording in the middle, press the ■/CLEAR button of the CD player. The cassette deck also stops after 4 seconds.

- Notes:**
- During synchro recording, the ▶/II and SEARCH (◀, ▶) buttons do not function.
 - During synchro recording, IllumiMagic COMPU PLAY does not function.

CD complete recording function (Synchro recording mode only)

- If the tape is reversed while a CD is being played, recording will be done on the reverse side of the tape as follows:
- When less than 10 seconds of the last tune on the forward side of the tape have been recorded, recording on the other side of the tape will start from the beginning of the previous tune.
 - When more than 10 seconds of the last tune on the forward side of the tape have been recorded, recording on the other side of the tape will start from the beginning of the current tune.

When automatic spacing between tunes is not required ...

- Perform the following.
- Press the ▶/II button of the CD player twice. The CD player enters the pause mode.
 - Press the SYNCHRO REC button to start recording.

Note:

- Depending on the disc used, blanks of a specified length may be left between tunes.

To record an entire disc in the tune order of the CD

After the operations in steps ① - ④ above, press the ▶/II button of the CD player after the ●/II and ▶ buttons have been pressed.

- La grabación comenzará en la dirección de avance y automáticamente se reproducirá el CD.
- Cuando el reproductor de CD haya reproducido el disco o las canciones programadas, la platina se detendrá automáticamente.
- Se dejarán automáticamente secciones no grabadas de aprox. 4 segundos entre las canciones.
- Para detener la grabación en la mitad, presione el botón ■/CLEAR del reproductor de CD. La platina de cassette también se detendrá después de transcurridos 4 segundos.

- Notas:**
- Durante la grabación sincronizada, no funcionarán los botones ▶/II y SEARCH (◀, ▶).
 - Durante la grabación sincronizada, IllumiMagic COMPU PLAY no funciona.

Función de grabación completa de CD (Solamente en el modo de grabación sincronizada)

Si la cinta se invierte mientras se reproduce un CD, la grabación continuará en el lado inverso de la cinta de acuerdo con lo siguiente:

- Cuando se hayan grabado menos de 10 segundos de la última canción en el lado de avance de la cinta, la grabación sobre el otro lado de la cinta comenzará desde el principio de la canción previa.
- Cuando se hayan grabado más de 10 segundos de la última canción en el lado de avance de la cinta, la grabación sobre el otro lado de la cinta comenzará desde el principio de la canción actual.

Cuando no deseé el espacioamiento automático entre las canciones ...

Realice lo siguiente.

- Presione dos veces el botón ▶/II del reproductor de CD. El reproductor de CD se establecerá en el modo de pausa.
- Presione el botón SYNCHRO REC para comenzar la grabación.

Nota:

Dependiendo del disco utilizado, podrán dejarse espacios de duración especificada entre las canciones.


Para grabar todas las canciones en el mismo orden que están en el CD

Después de finalizar los procedimientos de los pasos ① - ④ mencionados, presione el botón ▶/II del reproductor de CD luego de presionar los botones ●/II y ▶.

用 CD 唱機進行同步錄音

- 在該系統中，當卡式座進入錄音狀態時，CD 唱機便開始放音。

請按照下列步驟進行操作



- 裝入一張唱片並關閉 CD 唱片（電源已接通）。
- 設定於 CD 方式
- 裝入一盤卡式錄音帶，讓其 A 面朝外（在開始錄音之前，將錄音帶導入部份繞捲過去）。
- 選擇您要的反向功能 (或)
- 根據需要設定杜比降噪 (DOLBY NR) 開關。
- 若需要編序放音，請使用遙控器編序（參照 P.23）。
- 根據不超過磁帶長度的總播放時間來選擇樂曲。
- 按 SYNCHRO REC 鍵，開始同步錄音。

- 錄音以正向走帶開始，並且自動開始 CD 放音。
- 當 CD 唱機結束唱片放音或者編序放音以後，卡式座便自動停止。
- 在樂曲之間會自動留出約4秒鐘左右的空白處。
- 若要在錄音中途停止錄音，按壓 CD 唱機上的 ■/CLEAR 鍵即可。卡座亦將在4秒後停止錄音。

註：

同步錄音時，▶/II 和 SEARCH (◀, ▶) 鍵不起作用。
同步錄音時，魔光 COMPU PLAY 不起作用。

CD 完整錄音功能（僅於同步錄音）

如果，在CD唱機放音中錄音帶換了面，那麼，樂曲將按照下述情況與方法被錄製在換了面的一面上：

- 如果，第一面上所錄的最後樂曲所錄不滿10秒鐘，那麼，第二面上的錄音將從前一首樂曲的曲頭開始。
- 如果，第一面上所錄的最後樂曲所錄超過10秒鐘，那麼，第二面上的錄音將從該樂曲的曲頭開始。

如果不需要樂曲間的自動間隔...

執行下列步驟

- 按兩次 CD 唱機的 ▶/II 鍵。CD 唱機進入暫停狀態。
- 按 SYNCHRO REC 鍵以開始錄音。


註：

- 根據使用的唱片，樂曲之間可能留有一定的間隔。

- 按照 CD 唱片上的樂曲順序錄製整盤 CD 唱片
首先完成上述①至④步的操作，然後，在按壓了●/II 和 ▶ 鍵以後，按壓 CD 唱機上的 ▶/II 鍵鍵。

Recording from the radio or an external source connected to the AUX terminals

Operate in the order shown



- ① Load a cassette with side A facing out.
(Wind past the leader tape before starting recording.)
- ② Select the source to be recorded.
TUNER: Press the TUNER button. Tune to the required station.
- AUX: Press the AUX button.
- ③ Select the required reverse mode (or).
- ④ Set the DOLBY NR switch as required.
- ⑤ Press the ●/II button (recording-pause mode).
 - The tape direction indicator () blinks.
 - The function switch is locked and its position cannot be changed.
- ⑥ Press to start recording.
- To stop recording temporarily, press the ●/II button. To resume recording, press the > or < button corresponding to the tape direction indicator which is blinking.


Erasing

When recording on a pre-recorded tape, the previous recording is automatically erased and only the new material can be heard when the tape is played.
To erase a tape without making a new recording...
Press the ■ (stop) button to set to the TAPE mode, then perform recording.

It may be unlawful to record or playback copyrighted material without the consent of the copyright owner.

Grabación de una radiodifusión o de una fuente externa conectada a los terminales AUX

Proceda en el orden indicado



- ① Coloque un cassette con el lado A hacia afuera.
(Bobine hasta pasar la cinta de guía antes de comenzar la grabación.)
- ② Seleccione la fuente a grabarse.
TUNER: Presione el botón TUNER. Sintonice la estación deseada.
AUX: Presione el botón AUX.
- ③ Seleccione el modo de inversión requerido (or).
- ④ Coloque el interruptor DOLBY NR como deseé.
- ⑤ Presione el botón ●/II (modo de pausa de grabación).
 - El indicador de la dirección de la cinta () parpadea.
 - El comutador de función se encará y no se podrá cambiar su posición.
- ⑥ Presione para comenzar la grabación.
- Para detener temporalmente la grabación, presione el botón ●/II. Para continuar con la misma, presione el botón > o < correspondiente al indicador de dirección de la cinta que esté destellando.

Borrado

Cuando grabe en una cinta pregrabada, la grabación previa se borra automáticamente y sólo el nuevo material grabado podrá escucharse cuando se reproduzca la cinta.
Para borrar una cinta sin efectuar una nueva grabación...
Presione el botón ■ (parada) para ajustar en el modo TAPE, luego realice la grabación.

Es ilegal grabar o reproducir materiales con derechos registrados sin la autorización del propietario.

無線電廣播或（連接於輔助（AUX）端子的）外部聲源的錄音

請按照下列步驟進行操作

① 裝入一盤卡式錄音帶，讓其 A 面朝外（在開始錄音之前，將錄音帶導入部份繞捲過去）。

② 選擇要錄音的聲源

調諧器：按 TUNER 鍵，調諧出所需的電臺。

輔助：按輔助（AUX）鍵。

③ 選擇所需的反向方式（ 或 ）

④ 根據需要設定杜比降噪（DOLBY NR）開關。

⑤ 按壓●/II鍵（錄音暫停方式）。

• 走帶方向指示燈（ ）閃爍。

• 功能開關便被鎖定，此位置無法改變。

⑥ 按相應的鍵開始錄音。

• 若要暫時停止錄音，按壓●/II鍵。若要重新恢復錄音，根據閃爍的走帶方向指示燈所示，按壓>或者<鍵紐。

抹音

在錄過的錄音帶上錄音，原來的聲音會被自動抹掉，再放音時只會聽到新錄的聲音。

若要不錄音而抹去原來的聲音：

按■（停止）鍵以設定 TAPE 方式，然後進行錄音。

未經版權所有者的許可而錄帶或播放受版權法保護的音響資料，可能會觸犯法規。

MICROPHONE MIXING


MEZCLADO DE MICROFONO

麥克風混聲

Microphone sound can be mixed with the source sound.


El sonido del micrófono puede ser mezclado con la fuente de sonido.

麥克風的聲音可以與聲源的聲音混合起來。




MICROPHONE (optional)
Micrófono (opcional)
麥克風（選購件）

3.5 mm diameter mini plug
Conector en miniatura de 3,5 mm. de diámetro
直徑 3.5mm 微型插頭



CD playback begins.
Inicio de la reproducción del CD.
CD 放音開始



- Example of microphone mixing with CD sound

Operations

- ① Connect a microphone with a mini plug to the MIXING MIC jack. (If there is a switch on the microphone, switch it on.)
- ② Select the source sound (CD/TAPE/TUNER/AUX).
 - Play back the source sound selected.
- ③ Adjust the MIC LEVEL control and main VOLUME controls.

To record the mixed sound

In order to record this mixed sound onto a tape in the deck, press the ●/II button to engage the record standby mode after the above procedure, then press the < or > button.

Notes:

- Use the microphone as far away the set as possible. When the microphone is to near the speakers, howling may occur.
- Disconnect the microphone from the MIXING MIC jack after use.

Operaciones

- ① Conecte el micrófono con el jack MIXING MIC utilizando un conector en miniatura. (Si el micrófono tiene un interruptor, colóquelo en ON).
- ② Seleccione la fuente de sonido (CD/TAPE/TUNER/AUX).
 - Reproduzca la fuente de sonido seleccionada.
- ③ Ajuste los controles principales MIC LEVEL y VOLUME.

Grabación de un sonido mezclado

Para grabar el sonido mezclado en una cinta de la platina, presione el botón ●/II para activar el modo de pausa de grabación después de efectuar el procedimiento de arriba y luego presione el botón < o >

Notas:

- Utilice el micrófono lo más lejos posible de la unidad. Cuando el micrófono está cerca de los altavoces pueden producirse aullidos.
- Después de utilizarlo, desconecte el micrófono del jack MIXING MIC.

操作

- ① 將麥克風用微型插頭連接於 MIXING MIC (麥克風混音) 插孔 (如果麥克風上面有開關，請打開開關)。

- ② 選擇聲源 (CD/TAPE/TUNER/AUX)。

- 播放您所選擇的聲源。

- ③ 調節 MIC LEVEL 旋鈕與主機上的 VOLUME 鍵。

- 若要錄音混和聲音

若要將混合聲音錄音於卡式座中的錄音帶上，待上述步驟完成以後，請按壓●/II鍵使其進入錄音待機狀態，然後，按壓<或者>鍵。

註:

- 使用麥克風的時候，盡可能離設備遠一點，如果離揚聲器太近，會引起嘯聲。
- 使用結束後，請將麥克風的插頭從 MIXING MIC (混聲麥克風) 微型插孔中拔出。

CLOCK/TIMER ADJUSTMENT


AJUSTE DEL RELOJ/TEMPORIZADOR

時鐘／定時器的調節


Names of parts in the clock/time section, and their functions:

Nombre de las partes de la sección del reloj/temporizador y sus funciones:


時鐘／定時器的各部件的名稱以及功能



- ① Timer mode indicator
- ② SLEEP indicator
- ③ Timer indicator (ON/OFF)
- ④ Time display
- ⑤ TIMER button and indicator
- ⑥ CLOCK button
 - Use this button to switch the function and time display.
- ⑦ DOWN/UP buttons
- ⑧ ENTER button
- ⑨ SLEEP button



- ① Indicador del modo de temporización
- ② Indicador SLEEP
- ③ Indicador del temporizador (ON/OFF)
- ④ Indicador de la hora
- ⑤ Botón e indicador TIMER
- ⑥ Botón CLOCK
 - Utilice este botón para comutar la indicación de función y de hora.
- ⑦ Botones DOWN/UP
- ⑧ Botón ENTER
- ⑨ Botón SLEEP




- ① 定時器方式指示燈
- ② SLEEP 指示燈
- ③ 定時器指示燈 (ON/OFF)
- ④ 時間顯示
- ⑤ TIMER 鍵和指示燈
- ⑥ CLOCK 鍵
 - 使用此鍵來切換功能和時間顯示。
- ⑦ DOWN/UP 鍵
- ⑧ ENTER 鍵
- ⑨ SLEEP 鍵

38

**Setting the current time
(when the unit is used for the first time)**

(Example: to set the clock to 13:15.)




Fijación de la hora (Cuando se utiliza esta unidad por primera vez)

(Ejemplo: para ajustar el reloj a las 13:15)

**設定現在的時間
(當第一次使用本機時)**

(譬如：將時鐘設定為 13:15)。

Within the 2 minutes.
Dentro de los 2 minutos.
在 2 分鐘之內。



Within the 2 minutes.
Dentro de los 2 minutos.
在 2 分鐘之內。



ENTER PRESET TUNING
AUTO PRESET

- ① Connect the AC power cord; "0:00" will blink in the display.
- ② Press the CLOCK button for 2 seconds or more.
- ③ Set to 13:15 by pressing the UP/DOWN buttons. (When the buttons are kept pressed, the minute and hour indication changes continuously.)
- ④ Press the ENTER button; the time will light in the display.

- To set to the nearest second...
Press the ENTER button when you hear the time signal from a TV or radio.

Notes:

- Before performing timer recording or playback, it is necessary to set the current time.
- It is recommended to set the current time with the power switch set to STANDBY so that the current display mode is maintained.
- When power is restored after a power failure or the power cord is plugged in again after being disconnected, "0:00" will blink in the display. Set the current time again.

- ① Conecte el cordón de CA; en el visor parpadeará "0:00".
- ② Presione el botón CLOCK durante 2 segundos o más.
- ③ Ajustelo a las 13:15 presionando los botones UP/DOWN. (Si se mantienen presionados los botones, la indicación de los minutos y de las horas cambia continuamente).
- ④ Presione el botón ENTER; la hora se iluminará en el visor.

- Para fijar los segundos en forma más exacta...
Presione el botón ENTER al escuchar la señal horaria de la televisión o la radio.

Notas:

- Antes de realizar una grabación o reproducción con temporizador, es necesario ajustar la hora actual.
- Se recomienda ajustar la hora actual con el interruptor de alimentación en STANDBY para mantener el modo de indicación actual.
- Cuando se restaura la energía o cuando se enchuta el cordón eléctrico después de haberlo desconectado, "0:00" parpadeará en el visor. Ajuste otra vez la hora correcta.

- ① 連接交流電源線，“0:00”在顯示窗中閃爍。
- ② 按住 CLOCK 鍵 2 秒鐘以上。
- ③ 按住 UP/DOWN 鍵，已設定 13:15 (如一直按住這些鍵，分鐘和小時顯示會連續改變)。
- ④ 按 ENTER 鍵，時間會在顯示窗中點亮。

- 如果要將時間設定得盡可能準確...
當您聽到電視機或者電臺報時音時，按壓 ENTER 鍵即可。

註:


- 在進行定時錄音或者定時放音之前，必須先設定現在時間。
- 建議在設定現在時間的時候，將電源鍵鈕設為 STANDBY (待機)，這樣可以保留住顯示窗的顯示。
- 電源線脫離插座以後再將其插入，或者停電以後再恢復供電，“0:00”將會在顯示窗中閃爍或者亮著。若遇此情況，請重新設定現在時間。

Setting the timer

- The current time must be set before the timer can be used.
- Press the TIMER button. (The (①) indicator lights and the red indicator of TIMER button also lights.)



② Press the ENTER button.

**Ajuste del temporizador**



- La hora actual debe ajustarse antes de utilizar el temporizador.
- Presione el botón TIMER. (Se encenderá el indicador (①) y el indicador rojo del botón TIMER)

② Presione el botón ENTER.



**設定定時器**

- 只有先設定了現在時間，定時器才可以使用。
- 按 TIMER 鍵 (① 指示燈點亮，TIMER 鍵的紅色指示燈也點亮)。


- ③ Set the timer start time.
(Example: when the timer is set to 12:15.)




- ③ Ajuste la hora de activación del temporizador.
(Ejemplo: cuando se ajusta el temporizador a las 12:15)




③ 按 ENTER 鍵。




- ④ Set the stop time.
(Example: When the timer stop time is set to 13:15.)





- ④ Ajuste la hora de parada.
(Ejemplo: cuando se ajusta la hora de desconexión del temporizador a las 13:15).




- ④ 設定停止時間
(譬如，設定停止時間為 13:15)。




- ⑤ Select the timer mode.
• The selected timer mode is shown in the display.



- ⑤ Seleccione el modo de temporizador.
• El modo de temporización seleccionado aparece en el visor.



- ⑤ 選擇定時器功能。



When the UP button is pressed to select the timer mode, the mode changes from TUNER (timer reception of a broadcast), TUNER/REC (timer recording of a broadcast), CD (timer playback of a CD), to TAPE (timer playback of a tape), in this order.




Cuando se presiona el botón UP para seleccionar el modo de temporizador, el modo cambia de TUNER (recepción por temporizador de una radiodifusión), a TUNER/REC (grabación por temporizador de una radiodifusión), a CD (reproducción de un CD con temporizador), TAPE (reproducción de una cinta con temporizador), en este orden.

如果按壓 UP 鍵來選擇定時器功能，那麼其順序為：
TUNER（廣播接收的定時）以及 TUNER/REC（無線電廣播的定時錄音）、CD（CD 的定時放音）、TAPE（錄音帶的定時放音）。


- ⑥ Set the volume.

- ⑥ Ajuste el volumen.

- ⑥ 設定音量。



When the UP button is used to select the volume.
Cuando se use el botón UP para seleccionar el volumen.
當用 UP 鍵選擇音量。



- ⑥ The selected volume is set.
• Se fija el volumen deseado.
• 所選擇的音量被設定。

- The unit enters the previously engaged mode and timer setting is completed. (The (①) indicator lights and the red indicator of TIMER button also lights.)
- La unidad ingresa en el modo previamente activado y queda completado el ajuste del temporizador. (Se enciende el indicador (①) y el indicador rojo del botón TIMER).
- 本機進入前一個操作狀態，定時器設定完畢 ((①)指示燈及定時鍵紅色指示燈亮起)。

- When the volume setting is set to "VOL -" (volume level is not specified), the timer playback volume is at the level used before setting the timer.
- The volume decreases to zero at the timer start time, and the sound fades in.

- Cuando se ajusta el volumen en "VOL -" (no se especifica el nivel de volumen), el volumen de la reproducción por temporizador permanece al nivel usado antes de ajustar el temporizador.
- El volumen se reduce hasta cero en el momento de activación del temporizador, y el sonido aumenta gradualmente.

- 當音量設定在 "VOL -" (未指定音量電平) 時，其定時放音的音量為上次設定定時時的音量。
- 在定時開始時，音量減至零，然後聲音逐漸增強。

- To confirm the timer setting
 - Press the TIMER button. (The (O) indicator lights and the red indicator of TIMER button also lights.)
 - Each time the ENTER button is pressed, the timer setting can be confirmed.
 - When the previous engaged mode is displayed, timer setting is completed.

Note:

- When the timer is set incorrectly or the correct mode is not selected, perform "Setting the timer" from the beginning.

- Para verificar el ajuste del temporizador
 - Presione el botón TIMER. (Se encenderá el indicador (O) y el indicador rojo del botón TIMER).
 - El ajuste del temporizador puede ser confirmado al presionar el botón ENTER.
 - Cuando aparece la indicación del modo previamente activado, el ajuste del temporizador está completado.

Nota:

- Cuando se ajuste el temporizador incorrectamente o cuando no se seleccione el modo correcto, realice el "ajuste del temporizador" desde el principio.


- 若要檢查定時器的設定
 - 按TIMER鍵(O指示燈點亮,TIMER鍵的紅色指示燈也點亮)。
 - 每按一次ENTER鍵,就能檢查定時器的設定。
 - 一旦顯示先前所定的工作狀態,就表示定時器的設定已經完成。

註:

- 如果定時器的設定有錯或者所選功能有錯,請從頭開始進行“定時器的設定”。

TIMER OPERATIONS**FUNCIONAMIENTO DEL TEMPORIZADOR****定時器的使用****Timer recording of broadcast**


- The current time must be set correctly before you set timer recording.
- Make sure that the erase protection tabs of the cassette have not been broken off.

Operations

- Set the POWER button to ON.
- Load a cassette.
- Insert the cassette with the side to be recorded facing out.
- Set the reverse mode button to "➡" or "⬅" and set the DOLBY NR button as required.

Grabación de una emisión con temporizador


- La hora actual deberá estar correctamente fijada antes de ajustar una grabación con temporizador.
- Asegúrese de que el casete tenga intactas las lengüetas de protección contra borrados.

Operaciones

- Coloque el botón POWER en ON.
- Coloque un cassette.
- Inserte el cassette con el lado a grabarse hacia afuera.
- Fije el selector de modo de inversión en "➡" o "⬅" y luego ajuste el botón DOLBY NR como se requiera.

無線電廣播的定時錄音

- 在您設定定時錄音之前,必須先正確設定現在的時間。
- 確認一下錄音帶上的防誤消的錄音保險片是否在。

操作

- Set the timer start and stop times, set the timer recording mode, then set the required volume, in this order. (Refer to "Setting the timer" on page 40.)
- Set the timer about a minute before the broadcast to be recorded is scheduled to start.
- Tune to the station to be recorded. (Refer to page 29.)
- Set the POWER button to STANDBY.

- Timer recording will start at preset start time and the power will be switched off at preset stop time. (The timer mode is then released.)

- To cancel timer operation
Press the TIMER button so that the timer mode indicator (O) goes out. (The red indicator of TIMER button goes out.)

If you do this, timer recording will not start at the timer start time.

Notes:

Once the timer has been set, the start and stop times, etc., are stored in memory. When timer recording or playback is required at different times, the timer must be set again.

- After setting the timer start and stop times, check that the unit is tuned to the required frequency.
- When the power cord is disconnected or there is a power failure, timer settings will be erased from memory. If this happens, set the current time and perform the timer setting again.

- Fije la hora de comienzo y fin del temporizador, ajuste también el modo de grabación con temporizador, luego el volumen deseado, en este orden. (Refiérase a "Ajuste del temporizador" en la página 40.)
- Ajuste el temporizador alrededor de un minuto antes de la hora de comienzo de la radiodifusión programada a grabarse.
- Sintonice la estación que desea grabar. (Refiérase a la página 29.)
- Coloque el botón POWER en STANDBY.

- La grabación con temporizador comenzará según la hora fijada de comienzo y la alimentación se desconectará a la hora fijada de finalización. (Luego se desactiva el modo de temporizador).

- Para cancelar el funcionamiento del temporizador
Presione el botón TIMER para que se apague el indicador (O) del modo de temporizador. (Se apaga el indicador rojo del botón TIMER).

Si Vd. hace esto, la grabación con temporizador no comenzará a la hora fijada en el temporizador.

- Notas:**
Una vez que el temporizador ha sido ajustado, las horas de comienzo, finalización, etc., se almacenan en la memoria. Cuando se desea realizar una grabación o reproducción con temporizador a diferentes horas, el temporizador deberá ajustarse nuevamente.
• Después de ajustar la hora de comienzo y finalización en el temporizador, verifique que la unidad esté sintonizada en la frecuencia deseada.
• Cuando se desenchufe el cable de alimentación o cuando se produzca alguna falla eléctrica, se borrarán de la memoria los ajustes del temporizador. Si esto ocurriera, debe ajustar nuevamente la hora actual y el temporizador.

- 首先設定定時器的開始與結束時間,其次設定定時錄音。(請參看第40頁上的“設定定時器”)。

- 將定時器設定得比要錄音的無線電廣播開始時間約早1分鐘。

- 調諧出要錄音的廣播電臺(請參看第29頁)。

- 按POWER鍵鈕,選擇STANDBY(待機)狀態。

- 定時錄音將於預設的開始時間開始,並且電源將於預設的停止時間斷開。(退出定時方式)

- 若取消定時

- 按TIMER鍵以便定時器方式指示燈(O熄滅)(TIMER鍵的紅色指示燈熄滅)。

如果您作了這一項操作,那麼在定時開始的時間裡不會開始定時錄音。

註:

一旦設定了定時器、開始時間、停止時間等便被記憶於記憶裝置中。如果欲在不同的時間進行定時錄音或者定時放音,那麼就需要重新設定定時器。

- 待定時開始與定時停止的時間設定完畢以後,請檢查調諧器是否被設定在需要的廣播頻率上。

- 如果電源線從電源插座脫離或者發生停電,那麼,儲存於記憶裝置中的定時設定將被抹消。如果發生這種情況,請重新設定現在時間並重新作定時設定。

Timer playback


- Timer playback of tapes, broadcasts and CDs is possible.

Operations

- ① Set the POWER switch to ON.
- ② Set the timer start and stop times, set the timer playback mode, then set the volume, in this order. (Refer to "Setting the timer" on page 40.)

Reproducción con temporizador

- Es posible la reproducción de cintas, radioemisiones y CD con temporizador.

Operaciones

- ① Coloque el botón POWER en ON.
- ② Fije la hora de comienzo y finalización del temporizador, fije el modo de reproducción con temporizador, luego ajuste el volumen, en este orden. (Refiérase a "Ajuste del temporizador" de la página 40.)

定时播放

- 可以作錄音帶、無線電廣播以及CD唱片的定時播放。

操作

1 按壓POWER鍵鈕，接通電源。

- ② 首先設定定時器的開始與結束時間，其次設定定時放音。（請參看第40頁上的“設定定時器”）。


Source sound Fuente de sonido 聲源的聲音	Timer mode Modo de temporizador 定時	Operations Operaciones 操作
CD play Reproducción de CD CD 放音	CD CD CD	Load a disc. Coloque un disco. 裝入唱片
Tape playback Reproducción de una cinta 錄音帶放音	TAPE TAPE (cinta) TAPE	Load a cassette tape. Coloque una cinta de cassette. 裝入卡式錄音帶
Broadcast Radioemisión 電臺廣播	TUNER TUNER (Sintonizador) TUNER	Tune to the required station. Sintonice la estación deseada. 調到所需電臺

- Timer playback of a CD is possible in programmed order. (See page 23.)
- The volume can be set to 50 different levels.

- Es posible la reproducción de un CD con temporizador en el orden programado. (Véase la página 23.)
- Puede ajustarse el volumen en 50 niveles diferentes.

- CD唱片的定時放音可以按照編序順序進行（請參看第23頁）。
- 可將音量設定為不同的50種電平。

44



- ③ Switch the power off.

- Timer playback will start at the timer start time and the power will be switched off at the timer stop time. The unit remains in the same timer mode even after the power is switched off and the same timer function will be repeated at the same time on the following day.
- When the power is switched on, it is possible to fade in the sound from volume level 0 (zero) to the preset volume.

To cancel timer operation

- Press the TIMER button so that the timer mode indicator (④) goes out. (The red indicator of TIMER button goes out.)

Notes:

- To stop during timer playback, press the POWER button to switch the unit off.
- In the fade-in mode, the volume gradually increases from zero.

- ④ Apague la unidad.

- La reproducción con temporizador comenzará a la hora de comienzo fijada en el temporizador y se desconectará la alimentación a la hora de finalización fijada. La unidad permanecerá en el mismo modo de temporizador incluso después de apagarse la unidad y se repetirá la misma función de temporizador a la misma hora del siguiente día.
- Cuando se conecta la alimentación, es posible el aumento gradual del sonido desde el nivel cero (0) hasta el nivel preajustado.
- Para cancelar el funcionamiento del temporizador Presione el botón TIMER para que se apague el indicador (④). (Se apaga el indicador rojo del botón TIMER).

Notas:

- 为停止在定时播放中停止播放，请按压POWER键钮，關掉設備。
- 在fade-in模式中，音量将从零逐渐增加。

- ⑤ 按壓電源鍵鈕斷開電源。

- 定時播放將於預設的開始時間開始，並且電源將於預設的停止時間斷開。即使電源斷開以後，該定時設定仍將被儲存於記憶裝置中，第二天將於同樣的時間重複同樣的定時功能。
- 當接通電源時，聲音可能從音量電平0漸次增強至預設的音量。
- 若要取消定時設定
按TIMER鍵以便定時器方式指示燈④熄滅（TIMER鍵的紅色指示燈熄滅）。

註：

- 若要在定時播放中停止播放，請按壓POWER鍵鈕，關掉設備。
- 選擇所需聲源、樂曲（調諧器）或放音（CD唱片或錄音帶）。

SLEEP OPERATIONS**(Using the remote control unit)**

- A. Use this when you want to fall asleep while listening to a tape, broadcast or CD**

- ① Set to the required source and tune (tuner) or play back (CD or tape).
- ② Press the SLEEP button to set the sleep time.



SLEEP is shown in the display.
Se visualiza **SLEEP** en el display.
SLEEP 出現於顯示窗。

- Sleep times of 30, 60, 90 or 120 minutes can be set. When you release the SLEEP button, the source is displayed after 5 sec.

- The sleep operation will start and the power will be switched off after the specified time.

• Checking the sleep time

When the SLEEP button is pressed, the remaining sleep time is displayed. If it is pressed again, a new sleep time can be set.


• To cancel the sleep operation

Press the POWER button to switch the power off or press the SLEEP button until the sleep time indicator disappears.

FUNCIONAMIENTO DEL TEMPORIZADOR DE DESCONEXIÓN**睡眠定时****(Utilizando la unidad de control remoto)**

- A. Utilice esta función cuando desee dormir mientras escucha una cinta, radioemisión o CD**

- ① Ajuste a la fuente requerida y música (sintonizador), o reproduzca (un CD o cinta).
- ② Presione el botón SLEEP para fijar la hora de desconexión.



Source mode display (Releasing the sleep mode)
Visualización del modo de fuente (Cancelación del modo de desconexión)
聲源顯示 (解除睡眠定時)

- Pueden ajustarse tiempos de desconexión de 30, 60, 90 ó 120 minutos. Cuando suelte el botón SLEEP, se visualizará la fuente en 5 seg.

- El temporizador de desconexión comenzará y se desconectará la alimentación cuando finalice el tiempo especificado de desconexión.

• Verificación de la hora de desconexión

Cuando se presiona el botón SLEEP, se visualizará el tiempo restante de desconexión. Si se lo presiona nuevamente, se fijará un nuevo tiempo de desconexión.

• Para cancelar el temporizador de desconexión

Presione el botón POWER para apagar la unidad o presione el botón SLEEP hasta que desaparezca la indicación de desconexión.

(使用遙控器)

- A. 當您欲邊聽錄音或者 CD 唱片、無線電廣播邊進入夢鄉時，可使用此功能。**

- ① 設定您想聽的聲源和曲目或播音（CD或磁帶）。
- ② 按壓 SLEEP 鍵鈕，以設定睡眠時間。

- 睡眠的定時時間有 30 分、60 分、90 分以及 120 分可被選擇。當您按壓 SLEEP 鍵鈕解除了睡眠定時以後，過 5 秒鐘聲源就會被顯示出來。

- 當設定的時間到時，睡眠的定時功能便起作用，電源便被斷開。

• 檢查睡眠定時的時間

按壓 SLEEP 鍵鈕，剩餘的睡眠時間便會被顯示出來。如果再按壓一次該鍵鈕，您就可以重新選擇一個新的睡眠時間。

• 若要取消睡眠定時的設定

按壓 POWER 鍵鈕，斷開電源；或者按壓 SLEEP 鍵鈕，直至睡眠定時的時間顯示消失。

B. To fall asleep while listening to a broadcast, tape or CD and to perform timer playback the following morning

1. Set the timer playback start and stop times. (See the "Setting the timer" on page 40.)
2. Set the timer mode and volume. (See "Setting the timer" on page 40.)
3. Set to the required source (broadcast, tape or CD).
4. Press the SLEEP button to set the sleep time.

B. Para dormirse mientras escucha una radio-emisión, cinta o CD y realizar una reproducción con temporizador a la mañana siguiente

1. Ajuste las horas de comienzo y finalización de la reproducción con temporizador. (Véase "Ajuste del temporizador" en la página 40.)
2. Fije el modo de temporizador y volumen deseado. (Véase "Ajuste del temporizador" en la página 40.)
3. Fije la fuente requerida (Radioemisión, cinta o CD).
4. Presione el botón SLEEP para fijar la hora de desconexión.

B. 如果，您欲邊聽 CD 唱片或者無線電廣播邊進入夢鄉，並且第二天作定時播放


- 1. 設定定時播放的開始時間與停止時間。（請參看第 40 頁上的“設定定時器”）

- 2. 設定定時功能。（請參看第 40 頁上的“設定定時器”）

- 3. 選擇想聽的聲源（電臺廣播、錄音帶或者 CD 唱片）。

- 4. 按壓 SLEEP 鍵鈕，設定睡眠定時時間。

- Any required source can be selected when performing the sleep operation and time playback. For example, • CD play for sleep operation and broadcast reception for timer playback.
 - Tape playback for sleep operation and CD play for timer playback.
- However, when broadcast reception is selected for both sleep operation and timer playback, the station you were listening to at night will be tuned to the following morning.



Source mode display (Releasing sleep mode)
Visualización del modo de fuente (Cancelación del modo de desconexión)
聲源方式指示 (解除睡眠方式)

- Podrá seleccionarse cualquier fuente deseada cuando realice las operaciones de desconexión y reproducción con temporizador. Por ejemplo;

- Reproducción de CD con desconexión y radiorecepción para la reproducción con temporizador.
- Reproducción de una cinta con desconexión y reproducción de CD para la reproducción por temporizador.

- Sin embargo, cuando se seleccione la radiorecepción para ambas operaciones de reproducción con temporizador y de desconexión, la estación que esté escuchando a la noche se sintonizará a la mañana siguiente.


- 睡眠定時以及定時播放的聲源可任意選擇。比如：

- 定時放音 CD 唱片，定時播放電臺廣播。

- 睡眠定時播放錄音，定時播放 CD 唱片。

- 但是，如果睡眠定時以及定時播放的聲源都選擇了電臺廣播，那麼，第二天早晨的電臺就是您當天晚上所聽的電臺。

MAINTENANCE

**Cleaning is important!**

When the tape is running, magnetic powder and dust naturally accumulate on the heads, capstan and pinch roller. When they become too dirty ...

- sound quality deteriorates
- the output sound level drops
- the previous sound is not completely erased
- recording is not performed satisfactorily.

Because of this, you should clean the heads, etc. every 10 hours of use, so that perfect recording is possible.


Cleaning the heads, capstan and pinch roller

Open the cassette holder.

Clean the heads, pinch roller and capstan.

For effective cleaning, use a cleaning kit available from an audio store.

After cleaning, be sure that the cleaning fluid has dried completely before loading a cassette.

**Cautions:**

1. Keep magnets and metallic objects away from the head. If the head becomes magnetized, noise will increase and the tone will deteriorate. Demagnetize the head every 20 - 30 hours of use with a head eraser (available from an audio store). (When demagnetizing the head, the POWER button should be set to STANDBY).
2. Do not use anything other than alcohol for cleaning. Thinner and benzine will damage the rubber pinch roller.

MANTENIMIENTO

保養

La limpieza es importante!

Cuando la cinta se mueve, el polvo magnético y suciedad se acumulan naturalmente en las cabezas, cabrestante y rodillo de presión. Cuando éstos se ensucian demasiado ...

- Se deteriora la calidad del sonido
- Disminuye el nivel de sonido de salida
- El sonido previo no se borra completamente
- No se logran grabaciones satisfactorias

Por ello, deberá limpiar las cabezas, etc., cada 10 horas de uso, para obtener una grabación perfecta.

Limpieza de cabezas, cabrestante y rodillo de presión

Abra el portacassette.

Limpie las cabezas, el rodillo de presión y el cabrestante.

Para una limpieza efectiva, utilice los juegos de limpieza disponibles en cualquier comercio de audio.

Después de la limpieza, asegúrese de que el líquido de limpieza se haya secado completamente antes de colocar un cassette.

清潔工作是極為重要的！

當錄音帶走帶的時候，磁粉、灰塵自然會積蓄在磁頭、主導軸以及壓帶輪上。當這些部件太污穢時...

- 音質低劣
- 音量下降
- 先前所錄的錄音無法完全抹消
- 錄音不理想

因此，每使用 10 個小時您就該清洗磁頭等，這樣，您的錄音就會完美無憾。

清洗磁頭、主導軸以及壓帶輪

打開錄音帶艙。

清洗磁頭、主導軸以及壓帶輪。

音響設備商店有整套清洗工具出售，使用這種清洗工具便能清洗得乾淨。

清洗以後，須待清洗液完全乾了才可裝入錄音帶。

TROUBLESHOOTING



DETECCION DE PROBLEMAS

故障的檢查與排除

Aquel que parece ser una falla no siempre es algo serio. Asegúrese primero ...

並非所有問題都是嚴重的。

首先檢查一下...

- 電源無法接通。
 - * 電源線的插頭是否插好了？
 - * 插頭器沒有聲音。
 - * 是否有耳機插著？

CD唱機部分

- CD 唱機沒有聲音。
 - * 唱片應該朝上的一面是否朝下放了？
 - * 唱片是否污穢了？
 - * 透鏡是否污穢了？
 - * 某些地方的放音有異常。
 - * 唱片是否有劃傷？

卡式座部分

- 放音的聲音極低。
 - * 磁頭是否污穢了？
 - * ●/II鍵紐失靈。
 - * 卡式錄音帶上的防誤消錄音保險片是否被拆掉了？

調諷部分

- 收音有噪音。
 - * 調試天線。

定時器部分

- 定時器不啓動。
 - * 現在時間的設定是否正確？
 - * 定時功能的指示 (○) 是否被顯示出來了？

遙控器

- 遙控器失靈。
 - * 遙控器的電池是否耗盡？
 - * 遙控感應器 (REMOTE SENSOR) 是否受強烈光暉 (直射陽光等)？

註:

若要作重要的錄音，在此之前請務必作一次試錄，以便檢查卡式座等工作狀況是否良好。

What appears to be trouble is not always serious. Make sure first

- Power cannot be turned on.
 - * Is the power cord unplugged?
 - * Are headphones connected?

CD Player Section

- The CD player does not play.
 - * Is the disc upside down?
 - * Is the disc dirty?
 - * Is the lens dirty?
- A certain portion of the disc does not play correctly.
 - * Is the disc scratched?

Cassette Deck Section

- Playback sound is at a very low level.
 - * Is the head dirty?
- The ●/II button does not function.
 - * Have the safety tabs of the cassette been broken off?

Tuner Section

- Reception is noisy.
 - * Try adjusting the antenna.

Timer Section

- Timer operation does not start.
 - * Is the current time set correctly?
 - * Is the timer mode (○) displayed?

Remote Control

- Remote control is impossible.
 - * Are the batteries in the remote control exhausted?
 - * Is the REMOTE SENSOR section exposed to bright light (direct sunlight, etc.)?

Note:
Before making an important recording, be sure to make a test recording first to check that the deck, etc. is working correctly.

SPECIFICATIONS		ESPECIFICACIONES	規格
Compact disc player section		Sección del reproductor de compact disc	CD 唱機部分
Type	Compact disc player	Tipo	Reproductor de compact disc
Signal detection	Non-contact optical pickup	Sistema de detección de señales	Capto óptico sin contacto
Number of channels	2 channels	Número de canales	2 canales
Frequency range	20 Hz ~ 20,000 Hz	Respuesta de frecuencia	20 Hz ~ 20,000 Hz
Dynamic range	90 dB	Gama dinámica	90 dB
Signal-to-noise ratio	90 dB	Relación señal/ruido	90 dB
Total harmonic distortion	0.01 %	Distorsión armónica total	0.01 %
Wow & flutter	Less than measurable limit	Llora y tremolación	Inferior al límite medible
Radio section		Sección de la radio	無線收音機部分
Frequency ranges	FM: 87.5 ~ 108 MHz AM: 531 ~ 1,602 kHz (with channel space mode set to AM 9 kHz) AM: 530 ~ 1,710 kHz (with channel space mode set to AM 10 kHz) SW: 2.3 ~ 21.85 MHz	Gamas de frecuencias	FM: 87.5 ~ 108 MHz AM: 531 ~ 1,602 kHz (con modo de espaciamiento de canales ajustado en AM 9 kHz) AM: 530 ~ 1,710 kHz (con modo de espaciamiento de canales ajustado en AM 10 kHz) SW: 2.3 ~ 21.85 MHz
Antennas	Loop antenna for AM/SW (2.3 ~ 6.995 MHz) External antenna terminal for FM (75 ohms)/SW (7 ~ 21.85 MHz)	Antena	Antena de cuadro para AM/SW (2.3 ~ 6.995 MHz) Terminal de antena exterior para FM (75 Ω)/SW (7 ~ 21.85 MHz)
Tape deck section		Sección de la platina de cassette	卡式座部分
Track system	4-track 2-channel stereo	Sistema de pista	4 pistas, 2 canales estereofónicos
Motor	Electronic governor DC motor (capstan x 1, reel x 1)	Motor	Motor de CC regulado electrónicamente (cabrestante x 1, carrete x 1)
Heads	Hard permalloy head for recording/playback, 2 gap ferrite head for erasure (Combination head)	Cabezas	Cabeza de Permalloy duro para la grabación/reproducción, cabeza de ferrita de doble entrehierro para borrado (Cabeza combinada)
Frequency response	50 ~ 15,000 Hz (with CrO ₂ tape)	Respuesta de frecuencia	50 ~ 15,000 Hz (con cinta CrO ₂)
Wow and flutter	0.09 % (WRMS)	Llora y tremolación	0.09 % (WRMS)
Fast wind time	Approx. 120 sec. (C-60 cassette)	Tiempo de bobinado rápido	Aprox. 120 seg. (Cassette C-60)
Speaker section (each unit)		Sección de altavoces (cada unidad)	揚聲器部分 (均相同)
Speaker (Impedance)	10 cm x 1 (8 Ω)	Altavoz (Impedancia)	10 cm x 1 (8 Ω)
Dimensions	151 (W) x 238 (H) x 224 (D) mm	Dimensiones	151 (An) x 238 (Al) x 224 (Pr) mm
Weight	Approx. 2.1 kg	Peso	Aprox. 2.1 kg
General		Generalidades	總合
Power output	Max. 28 W (14 W + 14 W) at 8 Ω	Potencia de salida	Altavoz x 2 (impedancia de adaptación 8 Ω - 16 Ω)
Input jacks	AUX IN (300 mV/100 kΩ) MIC (3.5 mm dia. mini plug) (Matching Impedance: 200 Ω - 2kΩ)	Terminales de entrada	Auriculares (0.30 mV/100 kΩ) 32 Ω (impedancia de adaptación 16 Ω - 1 kΩ)
Power supply	AC 240 V, 50 Hz (UX-T3A) AC 110/127/230 V, 50/60 Hz (UX-T3U/US/UT)	Alimentación	AC 240 V, 50 Hz (UX-T3A) AC 110/127/230 V, 50/60 Hz (UX-T3U/US/UT)
Power consumption	Ext. DC 12 V (car battery via optional CA-R120E car adapter) 30 W (with POWER SW ON) (UX-T3A/US) 52 W (with POWER SW ON) (UX-T3 UT) 3.5 W (with POWER SW STANDBY)	Consumo	12 V de CC ext. (batería del automóvil vía adaptador para automóvil CA-R120E opcional) 30 W (con interruptor de alimentación activado) (UX-T3A/US) 52 W (con interruptor de alimentación activado) (UX-T3UT) 3.5 W (con interruptor de alimentación en espera)
Dimensions	459 (W) x 239 (H) x 259 (D) mm including knobs	Dimensiones	459 (An) x 239 (Al) x 259 (Pr) mm incluyendo las perillas
Weight	Approx. 8.1 kg	Peso	Aprox. 8.1 kg
Accessories provided	Power cord x 1 Remote control unit (RM-RXUT3) x 1 Battery "R6" x 2 (for the remote control) Feeder antenna x 1 Loop antenna stand x 1 AC plug adapter x 1 (UX-T3U/US/UT)	Accesorios suministrados	Cable de corriente alterna x 1 Unidad de control remoto (RM-RXUT3) x 1 Pila "R6" x 2 (para el control remoto) Antena de alimentación x 1 Soporte de antena de cuadro x 1 Adaptador para enchufe de CA x 1 (UX-T3U/US/UT)
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			
Design and specifications are subject to change without notice.			
Disenyo y especificaciones sujetos a cambios sin aviso.			

6. Location of Main Parts

■ The Internal Part of Unit




Fig. 6-1

■ Chassis Unit Part




Fig. 6-2

■ CD Player Unit




Fig. 6-3






Fig. 6-4

■ Cassette Mechanism Part**Fig. 6-5****■ Front Panel Part****Power source/tray switch board****Fig. 6-6**

7. Removal of Main Parts

■ How to Remove the Upper Cover (Refer to Fig. 7-1~4)

1. Pull out the volume knob from the rear cover.
2. Insert a minus screw driver into the slit on the rear cover and remove the MIC. plate while raising it in the arrow direction.
3. From the back of the body, remove the six screws (**1** × 5 and **2** × 1) retaining the upper cover.
4. From the right and left sides of the body, remove the four screws (**3**) retaining the upper cover.
5. Remove the Screw (**A**) retaining the micjack P.C. board.




Fig. 7-1

■ How to Remove the CD Player Ass'y (Refer to Fig. 7-5)

1. Remove the upper cover (Refer to "How to Remove the Upper cover").
2. From both sides of the body, remove the two screws (**4**) retaining the CD player ass'y.
3. From the connector CN701 on the system micro-computer P.C. board, remove the card wire outgoing from the connector CN854 on the mechanism control P.C. board.
4. From the connector CN702 on the system micro-computer P.C. board, remove the card wire outgoing from the connector CN701 on the key switch P.C. board.
5. Remove the one screw (**5**) retaining the CD player ass'y and main amplifier P.C. board.
6. Remove the two screws (**19**) retaining the heat sink (Refer to Fig. 7-20).
7. Disconnect the connections between the connectors CNA31 and CNA32 on the main amplifier P.C. board and connector CN706 on the system microcomputer P.C. board.




Fig. 7-2




Fig. 7-3

■ How to Remove the Main Amplifier and Power Source P.C. Board (Refer to Fig. 7-5)

1. Remove the upper cover (Refer to "How to Remove the Upper Cover").
2. Remove the CD player ass'y (Refer to "How to Remove the CD Player Ass'y").
3. Remove the two screws (**6**) retaining the front panel ass'y and main amplifier and power source P.C. board as shown in Fig. 7-2.
4. From the connector CNA33 on the main amplifier P.C. board, remove the card wire outgoing from the connector CN345 on the Dolby NR P.C. board.
5. Disengage the engagement (**A**) retaining the main amplifier and power source P.C. board with minus screw driver, etc.




Fig. 7-4

■ How to Remove the Cassette Mechanism Ass'y (Refer to Fig. 7-5)

1. Remove the upper cover (Refer to "How to Remove the Upper Cover").
2. Remove the CD player ass'y (Refer to "How to Remove the CD Player Ass'y").
3. After opening the cassette door, remove it from the cassette holder while pulling the door cover in the arrow direction.
4. Remove the five screws (7) retaining the cassette mechanism ass'y.
5. Draw out the cassette mechanism ass'y from the front panel as the cassette door has been left open.




Fig. 7-5

**■ How to Remove Various P.C. Boards
Mounted on the Front Panel Ass'y**
(Refer to Figs. 7-6 and 7-7)

1. Remove the upper cover (Refer to "How to Remove the Upper Cover").
2. Remove the CD player ass'y (Refer to "How to Remove the CD Player Ass'y").
3. Remove the cassette mechanism ass'y (Refer to "How to Remove the Cassette Mechanism Ass'y").
4. Remove the two screws (8) retaining the power source and CD tray switch P.C. board.
5. Remove the six screws (9) retaining the operation switch P.C. board.
6. Remove the four screws (10) retaining the cassette operation switch P.C. board.

**■ How to Remove the System
Microcomputer P.C. Board**
(Refer to Fig. 7-8)

1. Remove the upper cover (Refer to "How to Remove the Upper Cover").
2. Remove the CD player ass'y (Refer to "How to Remove the CD Player Ass'y").
3. Remove the four screws (11) retaining the system microcomputer P.C. board.
4. From the connector CN703 on the system microcomputer P.C. board, remove the card wire outgoing from the connector CN505 on the loading motor P.C. board.
5. Remove the LED P.C. board, other connectors CN705 and CN707 as necessary.




Fig. 7-6




Fig. 7-7




Fig. 7-8

■ How to Remove the CD Tray (Refer to Figs. 7-9~7-13)

1. Remove the upper cover (Refer to "How to Remove the Upper Cover").
2. Remove the CD player ass'y (Refer to "How to Remove the CD Player Ass'y").
3. Remove the system microcomputer P.C. board (Refer to "How to Remove the System Microcomputer P.C. Board").
4. Remove the CD tray fitting right upward.
5. Remove the two screws (12) playing a role of CD tray stopper, and pull out the CD tray.
6. After removing the four screws (13) retaining the CD clamer base, dismount the base from the loading base while raising it from the rear side.

The tray fitting will be removed when this part is pulled upward.




Fig. 7-9

■ How to Remove the CD Amplifier P.C. board (Refer to Fig. 7-15)

1. Remove the two screws (14) retaining the CD amplifier P.C. board.
2. From the connector CN501 on the CD amplifier P.C. board, remove the card wire outgoing from the CD pickup unit.
3. From the connector CN502 on the CD amplifier P.C. board, remove the connector wire outgoing from the CD motor.




Fig. 7-10

This diagram indicates that **B** has been slid toward the center (The clamaper is open). Under this condition, the tray can be pulled out.





Fig. 7-11



This part can be pulled out when the stopper screws 12 have been removed (If the screws 12 have not been removed, the tray can be pulled out but cannot be dismounted).

Fig. 7-12




Fig. 7-13




Fig. 7-14

■ How to Remove the Main Parts of CD Mechanism (Refer to Figs. 7-15 and 7-16)

1. Remove the upper cover (Refer to "How to Remove the Upper Cover").
2. Remove the CD player ass'y (Refer to "How to Remove the CD Player Ass'y").
3. Remove the system microcomputer P.C. board (Refer to "How to Remove the System Microcomputer P.C. Board").
4. Remove the two screws (15) retaining the loading motor, and dismount the drive belt from the pulley.
5. Remove the two soldered portions on the loading motor P.C. board connecting the loading motor.
6. Turn the loading base over and remove the loading motor P.C. board by opening the three pawls retaining the P.C. board in the arrow direction (A).

■ How to Remove the CD Mechanism (Refer to Figs. 7-17, 7-15 and 7-18)

1. Remove the upper cover (Refer to "How to Remove the Upper Cover").
2. Remove the CD player ass'y (Refer to "How to Remove the CD Player Ass'y").
3. Remove the system microcomputer P.C. board (Refer to "How to Remove the System Microcomputer P.C. Board").
4. Remove the two screws (16) retaining the C.D. mechanism.
5. Dismount the CD mechanism.




Fig. 7-15




Fig. 7-16




Fig. 7-17




Fig. 7-19




Fig. 7-18

■ How to Remove the CD Pickup Unit (Refer to Figs. 7-17, 7-18 and 7-19)

1. Remove the upper cover (Refer to "How to Remove the Upper Cover").
2. Remove the CD player ass'y (Refer to "How to Remove the CD Player Ass'y").
3. Remove the system microcomputer P.C. board (Refer to "How to Remove the System Microcomputer P.C. Board").
4. Remove the one screw (17) retaining the CD chassis.
5. While moving the CD chassis toward the stopper screw, remove the two pawls (D) on the chassis.
6. While moving the shaft stopper in the arrow direction, pull out the pickup shaft.

Reference: At the time reassembly, make sure that the damper rubber groove is engaged with the chassis slit.

■ How to Remove the Power Source P.C. Board (Refer to Fig. 7-20)

1. Remove the upper cover (Refer to "How to Remove the Upper Cover").
2. Remove the CD player ass'y (Refer to "How to Remove the CD Player Ass'y").
3. Remove the system microcomputer P.C. board (Refer to "How to Remove the System Microcomputer P.C. Board").
4. Remove the two connectors CN901 and CN902 outgoing from the amplifier P.C. board.
5. From the connector CN903 on the power source P.C. board, remove the connector wire outgoing from the connector W903 on the amplifier P.C. board.
6. Remove the one screw (18) retaining the AC jack.
7. Remove the power source P.C. board while pulling it right upward.

■ How to Remove the Amplifier P.C. Board (Refer to Fig. 7-21)

1. Remove the upper cover (Refer to "How to Remove the Upper Cover").
 2. Remove the CD player ass'y (Refer to "How to Remove the CD Player Ass'y").
 3. Remove the two screws (19) retaining the heat sink.
- Reference:** For dismantling the power IC, remove the three screws (20) retaining the heat sink.

■ How to Remove the Power source Transformer (Refer to Figs. 5-20 and 5-21)

1. From the connectors CN901 and CN902 on the power source P.C. board, remove the wire outgoing from the power source transformer.
2. Remove the two screws (21) retaining the power source transformer.




Fig. 7-20




Fig. 7-21

■ How to Remove the Dolby NR P.C. Board (Refer to Figs. 7-22 and 7-23)

1. Remove the upper cover (Refer to "How to Remove the Upper Cover").
2. Remove the CD player ass'y (Refer to "How to Remove the CD Player Ass'y").
3. Remove the cassette mechanism ass'y (Refer to "How to Remove the Cassette Mechanism Ass'y").
4. Remove the two screws (22) retaining the Dolby NR P.C. board.
5. While shifting the Dolby NR P.C. board toward the front side, disconnect the connection between the connector CN322 on the equalizer amplifier P.C. board and connector CN342 on the Dolby NR P.C. board as well as that between the connector CN343 on the Dolby NR P.C. board and connector CN851 on the mechanism control P.C. board.

■ How to Remove the Mechanism Control P.C. Board (Refer to Figs. 7-22 and 7-23)

1. Remove the two screws (23) retaining the mechanism control P.C. board.
2. Disconnect the connections between the connectors CN853 and CN852 on the mechanism control P.C. board and connectors CN1 and CN2 on the mechanism P.C. board.
3. Disconnect the connection between the connector CN302 on the equalizer amplifier P.C. board and connector CN855 on the mechanism control P.C. board.

■ How to Remove the Equalizer amplifier P.C. Board and Bias P.C. Board (Refer to Figs. 7-22 and 7-23)

1. From the connector CN301 on the equalizer amplifier P.C. board, remove the flexible P.C. board outgoing from the recording and playback head.
2. Remove the one screw (24) retaining the equalizer amplifier P.C. board.
3. Remove the two protrusions (E) on the cassette mechanism retaining the equalizer amplifier P.C. board.
4. From the P.C. board bracket, remove the two screws (25) retaining the equalizer amplifier P.C. board.
5. Disconnect the connection between the connector CN303 on the equalizer amplifier P.C. board and connector CN321 on the bias P.C. board.
6. From the P.C. board bracket, remove the one screw (26) retaining the bias P.C. board.

■ How to Remove the Cassette Holder (Refer to Fig. 7-24)

1. Remove the cassette door spring from the cassette holder.
 2. While pressing the cassette holder arm to inside, remove the arm from the mechanism bracket (Then the cassette holder and door damper will be removed simultaneously).
- Reference:** For dismounting the mechanism bracket, remove the three screws [(27) x 2 and (28) x 1] retaining the cassette mechanism bracket.




Fig. 7-22




Fig. 7-23




Fig. 7-24

■ How to Remove the Cassette Mechanism

★ The screws and parts are as indicated in the disassembly diagram. For further detail, refer to the analytic drawing on Page 84.

■ Head Mount Ass'y (Refer to Fig. 7-25)

From the chassis base ass'y, remove the three screws (13) retaining the head mount ass'y.

Caution: Whenever the head mount ass'y has been changed, be sure to adjust the azimuth screw (46).

■ Pinch Roller Ass'y (Refer to Fig. 7-26)

1. While spreading the pawl A retaining the right side pinch roller ass'y (27) in the arrow direction, pull out the ass'y upward.
2. While similarly spreading the pawl retaining the left side punch roller ass'y, pull out the ass'y upward.

■ Capstan Motor and Flywheel

(Refer to Figs. 7-27~7-31)

1. Turn over the cassette mechanism ass'y (Refer to Fig. 7-27).
2. From the chassis base, remove the three screws (37) retaining the FM bracket ass'y (Refer to Fig. 7-24).
3. While spreading the two pawls (B and C) retaining the FM bracket ass'y in the arrow direction, remove the ass'y (Refer to Fig. 7-27).
4. Dismount the FM bracket ass'y.
5. From the FM bracket ass'y, remove the two screws (34) retaining the capstan motor (32) (Refer to Fig. 7-28).
6. After dismounting the belt (38), remove the flywheels (19) and (20) (Refer to Figs. 7-29 and 7-30).

Caution: Dismount the belt so carefully that it is not contaminated by oil or other foreign matter. Regarding the belt hanging method, refer to Fig. 7-30.




Fig. 7-25




Fig. 7-26




Fig. 7-27




Fig. 7-28

■ Reel and Actuator Motor Ass'y

(Refer to Figs. 7-31 and 7-32)

1. Remove the four screws (23) and (26) retaining the reel motor (21) and actuator motor (24) ass'y (Refer to Fig. 7-31).
2. To dismount the reel motor, remove the two soldering D from the back side (Refer to Fig. 7-32).
3. To dismount the actuator motor, similarly remove the two soldering E.

■ Leaf Switch P.C. Board

(Refer to Fig. 7-33)

1. From the chassis base, remove the screw (39) retaining the leaf switch P.C. board.
2. While spreading the five pawls (F-J) retaining the leaf switch P.C. board in the arrow direction, take the leaf switch.




Fig. 7-29




Fig. 7-30




Fig. 7-32




Fig. 7-31




Fig. 7-33

8. Main Adjustment

■ Test Instruments required for adjustment

1. Low frequency oscillator
(Frequency range: 50Hz to 20kHz)
(Output : 0 dBs across 600 Ω terminating resistor)
2. Attenuator(Impedance : 600 Ω)
3. Test Tapes
VTT712 For tape speed,wow and flutter measurement
VTT724 For playback output level measurement
VTT736 For playback frequency response check response check
VTT703 For head azimuth adjustment
4. Blank tapes
Normal :AC224
Chrome : AC513
5. Electronic voltmeter,
6. Distortion meter
7. Frequency counter
8. Wow and flutter meter
9. Torque gauge : CTG - K
(Cassette type) For mechanism adjustment

■ Measuring conditions (Amplifier section)

- Supply voltage AC240V (50/60Hz)
(UX - T3A)
AC110~127/220~240V(50/60Hz)
(UX - T3US/U)
- Reference output Speaker 0 dBs (0.775V) / 8 Ω
LINE OUT: - 300mV (- 8.2dBs)/47k Ω
Headphone: - 20 dBs (0.0775V) / 32 Ω
- Reference input level - 28dBs(AUX)
to test point
- Standard test frequency 1kHz
- Output measuring point Speaker terminal
: Dummy load 3 Ω
: Test point CN344
or headphone(32 Ω)

● Standard position of switches

- Active hyper bass switch OFF

- | | |
|----------------|-------|
| SOUND | FLAT |
| NR SWITCH..... | OFF |
| AHB PRO | OFF |
| FUNCTION | RADIO |

● Standard position of controls

- Main volume adjust 0 dBs output (about VOL.29)

● Test remarks

1. Negative side of the input and output terminals of the testing set, shall be isolated from each other. The negative side should not be commonly connected when a 2channel electronic voltmeter is connected.
2. A dummy load shall be connected to the output terminal and the lead wires of dummy load shall be as thick as possible.

■ Measuring condition (Tuner section)

- | | |
|------------------------------------|---|
| Power supply voltage to tuner..... | DC 5.7V |
| Reference output | Speaker : 50mW(0.39 V / 3 Ω)
Headphon : 0.06V/ 32 Ω |
| AM modulation | 400Hz, 30% |
| FM modulation | 400Hz deviation 22.5kHz |


● Standard position of switches and controllers

- | | |
|---------------|--------|
| Function..... | RADIO |
| Mode | STEREO |


● Remarks for alignment

1. Connect 30 pF capacitor and 33 k Ω resistor to the output terminal of the IF sweeper in series while 0.082 μ F capacitor and 100k Ω resistor to the input terminal in series.
2. Set the output level of the IF sweeper as low as adjustable.
3. IF alignment is not necessary for both AM and FM MPX alignment is not necessary either. All IFTs and MPX coil are non-adjusting type.


★ UX-T3 Extention Cables (Parts No. EXTUX10-JIG)




VDM9239-016 (16 PIN connector wire):
For connection between microcomputer P.C. board CN706 and amplifier P.C. board CNA32



VDM9239-008 (8 PIN connector wire):
For connection between microcomputer P.C. board CN708 and amplifier P.C. board CNA31



VWF1207-40TTBX (7 PIN card wire) × 2:
For connection between Dolby P.C. board CN345, amplifier P.C. board and microcomputer P.C. board CN701



VWF1207-40TT (7 PIN card wire):
For connection between microcomputer P.C. board CN707 and CD amplifier P.C. board CN503



VWF1209-40TTB (9 PIN card wire):
For connection between microcomputer P.C. board CN705 and CD amplifier P.C. board CN601



VWF1209-40TTB (10 PIN card wire):
For connection between key switch P.C. board CN710 and microcomputer P.C. board CN702

By using the above extension cables ① ~ ⑥, it is possible to confirm energizing when the unit is disassembled. The positions of the respective cables to be used should be confirmed as indicated in the diagram below:





Fig. 8-1

■ Amplifier Section/Cassette Mechanism Section

Test Tape	Conditions	Adjustment and Confirmation Methods	Stand. value	Adjusting
Adjustment of head azimuth	Test tape : VTT704 (12.5kHz) Measurement output terminals: Speaker terminals L and R speakers (Load resistance: 8 Ω)	① Play the test tape VTT704 (12.5kHz). ② Adjust the head azimuth adjusting screw so that the playback output is within 2dB from the maximum point and the phase difference becomes minimum. After adjustment, lock the head azimuth adjusting screw by half a turn or over. ③ When the above output and phase difference do not comply with the standard values, perform fine adjustment of the head angle with the head azimuth screw.	Within 2dB from maximum point and minimum phase difference	Adjust the angle whenever the head has been changed.
Adjustment of tape speed Confirmation of wow & flatter	Test tape : VTT712 (3kHz) Measurement output terminals: CN344 (TP) terminal or speaker terminals (Load resistance: 8 Ω)	① Adjust VR851 so that the frequency counter reads $3,010 \pm 10\text{Hz}$ when the test tape VTT712 (3kHz) is playback after ending its winding. ② Confirm that wow & flatter is 0.2% or less (JIS WTD).	Tape speed : Within 3,010 ± 10Hz Wow & flatter : 0.2% or less (JIS WTD)	VR851
Adjustment of playback output level	Test tape : VTT727 (400Hz) Measurement output terminals : CN344 (TP) terminal	Adjust VR141 (L) and VR241 (R) so that the CN344 terminal level is $-8\text{dBs} \pm 1\text{dB}$ when the test tape VTT727 has been playback.	$-8\text{dBs} \pm 1\text{dB}$	L:VR141 R:VR241
Confirmation of playback frequency characteristics	Test tape : VTT739 (63Hz, 1kHz and 10kHz) and TMT735 (1 and 12.5kHz) Measurement output terminal : CN344 (TP) terminal	When the test tape VTT739 (1kHz and 63Hz) and TMT735 (1 and 12.5kHz) have been played back, the level deviation should be within $-2 \pm 4\text{ dB}$ in the case of 63Hz and within $0 \pm 3\text{ dB}$ in the case of 12.5kHz with reference to 1kHz.	1k/63Hz : $-2 \pm 4\text{ dB}$ 1k/12.5kHz : $0 \pm 3\text{ dB}$	
Adjustment of bias oscillation frequency	Test tape : AC-244 Measurement output terminal : Secondary circuit of oscillation coil (erasisng)	① Connect the frequency counter to the secondary eraser terminal of L321 (Insert a $1\text{M } \Omega$ resistor in series). ② Load the test tape (AC-244) into the tape deck and set it to the [REC.] and [pause] states. ③ Adjust L321 so that the frequency counter reads $100\text{kHz} \pm 0.2\text{kHz}$ during tape recording.	$:100\text{kHz} \pm 0.2\text{kHz}$	LA321
Adjustment of recording and playback frequency characteristics	Reference frequency : 1.25 and 12.5kHz (REF. level: -20dB) Measurement input terminal: AUX IN Measurement output terminal: TP CN344 Test tape: AC-244	① While repeatedly inputting the reference frequency signals of 1.25 and 12.5kHz to the AUX IN terminal, record the signals to a normal tape. ② Adjust VR121 and VR221 so that the CN344 terminal output deviation between 1.25 and 12.5kHz becomes $-1\text{dB} \pm 1\text{dB}$ when the recorded portion has been playback.	Normal tape : $-1\text{dB} \pm 1\text{dB}$	L:VR121 R:VR221
Adjustment of recording and playback sensitivity	Test tape: AC-224 Measurement input terminal: AUX IN Measurement output terminal: CN344 Reference frequency : 400Hz (REF. level: -20dB)	Adjust VR142 and VR242 so that the (output) level becomes $0 \pm 1\text{dB}$ from the monitor level when a reference frequency of 400Hz and a reference level of -20dB are recorded to and playback from the AUX IN terminal using the test tape AC-224.	$0 \pm 1\text{dB}$	L:VR141 R:VR242



Test Tape	Conditions	Adjustment and Confirmation Methods	Stand. value	Adjusting
Confirmation of Dolby NR effect	Test tape : VTT704 (12.5kHz) Measurement output terminal : CN344 (TP)	Confirm that the output level is lowered by about 4dB when the Dolby NR switch is turned on while playback the test tape VTT704 (12.5kHz).	Drop of output level by 4dB	
Confirmation of line output level	Test tape: VTT727	Confirm that the line output level becomes within $-5\text{dBs} \pm 3\text{dB}$ when the test tape VTT727 (400Hz) is play back.	$-5\text{dBs} \pm 3\text{dB}$	
Recording distortion rate	Test tape: AC-224 Measurement output terminal: CN344 (TP) Measurement input terminal: AUX IN	Confirm that the distortion meter indication is within 5% during recording while applying a reference level of 1kHz to the AUX IN terminal.	Within 5%	
Confirmation of recording S/N ratio	Test tape: AC-224 Measurement output terminal: CN344 (TP) Measurement input terminal: AUX IN	<p>① While applying a reference level of 1kHz to the AUX IN terminal, sample input signal halfway during recording and perform no signal recording.</p> <p>② Confirm that the difference between the playback level of recorded portion and that of no-signal recording portion is 40dB or over.</p>	More than 40dB	





Fig. 8-2

Test Tape	Conditions	Adjustment and Confirmation Methods	Stand. value	Adjusting
Adjustment of tracking offset	Test disk : CTS1000 Oscilloscope	<p>① Connect the oscilloscope between TP503 (hot side) and TP501 (earth side).</p> <p>② Play back the normal disk.</p> <p>③ Tracking error signal will be output for about 3 sec. when TP504 and TP501 are connected (shorted) during playback (A waveform will be output when set to the test mode).</p> <p>④ Adjust VR501 so that the reference DC level of tracking error signal (waveform of oscilloscope) is positioned to the center of the waveform amplitude.</p> <p>⑤ By repeating the above steps ② ~ ④, adjust the VR501 so that the center of the waveform amplitude complies with the reference level.</p> <p>Notes</p> <ol style="list-style-type: none"> 1. After adjustment of VR501, the waveform should be vertically symmetrical to the reference level. 2. The oscilloscope input should be DC-coupled.  <p>Position the center of waveform amplitude to the reference DC level.</p>	Position the center of P-P to the reference DC level.	VR501

★ How to set the CD test mode: Simultaneously press the three buttons: [POWER], [+10] and [◀◀] on the remote controller accessory to UX-T3. Then, all of the LCDs will be turned on when the mode has been set to the [TEST] mode.






Fig. 8-3

9. Troubleshooting (CD Part)


General descriptions of TOC (Table of Contents) readings




■General section




■ Feed section




■ Focus section




■ Spindle motor section



■ Signal processing section



■ Tracking section



10. Block Diagram




Fig. 10-1

11. Wiring Connections

Color codes are shown below.






Fig. 11-1

12. IC Block Diagram


■ IC1. TA2057N: FM - IF/DET/MPX
AM - RG/IF/DET




■ ICA38 BH3854S: Electronic volume




■ ICA91 BA3960: Regulator



■ IC301 UPC1228H: EQ amplifier



■ IC852/IC853 TA8409S: Motor driver (Reel/actuator)



■ IC341 HA12134: Dolby NR




Fig. 12-5


■ IC2 LC72131: PLL

Fig. 12-7


■ IC342 LA3220: Recorder amplifier

Fig. 12-8


■ IC3 TA8124P: AM stereo

Fig. 12-9



■ IC802 BA6208: Tray motor drive

Fig. 12-10

■ ICA31 LA4705: Power amplifier

58 (No.1928)

Fig. 12-11

IC701: MN171603JJP**Description of System Microcomputer Terminals**

No.	Terminal No.	Description of Function	I/O	Active	No.	Terminal No.	Description of Function	I/O	Active
1	NC		-	-	55	STTA	Tape gate array	0	H
2	REQ	Mechanism gate array request input	-	H	56	PERODE	Tuner PLL strobe	0	H
3	AV _{in}	Reference GND potential of AD converter			57	P_OUT	Power source control output	0	H
4	SAFETY 3	Voltage monitor terminal	-		58	S_MUTE	System muting output	0	H
5	KEY 1	Key input to body	-		59	L_MUTE	Tuner and line muting output	0	L
6	KEY 2	Key input to body	-		60	BUS φ		I/O	-
7	KEY 3	Key input to body	-		61	BUS 1	CD bus command/data input/output	I/O	-
8	DR/RST	Tray open/close and rest switch input	-		62	BUS 2		I/O	-
9	SAFETY 2	Voltage monitor terminal	-		63	BUS 3		I/O	-
10	SAFETY 1	Voltage monitor terminal	-		64	CCE	CD bus data chip enable	0	L
11	VERSION	Tuner version setting input	-		65	BUCK	CD bus clock output	0	↑
12	AV _{in}	Reference voltage input to AD converter			66	LED 1	LED control 1 (Remote control cord output)	0	-
13	V _{int}				67	XRST	CD LS1 reset signal output	0	L
	'	LCD drive voltage terminal			68	RST	System reset input	-	L
15	V _{ext}				69	X 1	Sub-clock input: 32.768kHz	-	
16	COM 3	LCD drive output	0	-	70	X 2	Sub-clock output: 32.768kHz	0	
	'				71	V _{ss}	GND terminal	-	
19	COM φ	LCD drive output	0	-	72	Osc 2	Main clock input: 4.194304MHz	0	
20	SEG φ	LCD drive segment output	0	-	73	Osc 1	Main clock output: 4.194304MHz	-	
	'				74	V _{dd}	Power source voltage terminal	-	
45	SEG 25	LCD drive segment output	0	-	75	BEAT	Beat cutting output	0	-
46	NC				76	XKILL	Sub-clock stop output	0	H
47	NC				77	EUP	Backup detection	-	H
48	MT φ	CD tray motor control	0	H	78	+BCTL	A _{remote} remote control power source control	0	H
49	MT 1		0	H	79	LATCH	VOL LSI strobe output	0	H
50	STBY	Standby LED control	0	H	80	SCK	Serial clock output	0	-
51	LED 2	LED control 2	0	H	81	SI	Serial clock input	-	-
52	AHB	AHB LED control	0	H	82	SO	Serial data output	0	-
53	TIMER 1	Timer LED control 1	0	H	83	MUX	Multiplexer/detector input	-	L
54	TIMER 2	Timer LED control 2	0	H	84	REM	Remote control signal input	-	↓


■ IC701: MN171603JJP

Fig. 12-12


■ IC601: TC9284AF

Fig. 12-13

■ IC601: TC9284AF Terminal Description

Terminal No.	Designation of Terminal	I/O	Description of Function	Terminal No.	Designation of Terminal	I/O	Description of Function
1	GNDA	—	Analog ground terminal for R channel DC converter section	31	TGUH 2	0	Tracking servo gain amplifier analog switch output terminal. Normally at "V _{ref} " but at "HIZ" at the time of gain amplifier. Use TGUH1 during normal playback and TGUH2 during double speed playback.
2	RO	O	R channel data forward output terminal	32	TGUH 1	0	
3	ROT	O	R channel data reverse output terminal				
4	VDA	—	DA converter section power source terminal				
5	LO	O	L channel data reverse output terminal	33	NKIC	0	Tracking actuator kick signal output terminal. It is used for kicking when adjusting NKIC _x , NKIC _y and tracking gain. Kicking in outer peripheral direction at "2V _{ref} " and in inner peripheral direction at "L". Normally, this terminal is at "HIZ". Three values (2V _{ref} , HIZ and GNDA) are output.
6	LO	O	L channel data forward output terminal				
7	GNDA	—	Analog ground terminal for L channel DA converter section	34	FMON	0	Feed servo ON/OFF analog switch output terminal. At "HIZ" when the servo is on, but at "V _{ref} " when it is off.
8	TEST3	I	Test terminal. Normally at "H" or open with pull-up resistor				
9	TEST4	I	Test terminal. Normally at "H" or open with pull-up resistor				
10	TEST5	I	Test terminal. Normally at "H" or open with pull-up resistor	35	TEST 1	I	Test terminal. Normally at "H" or open (with pull-up resistor).
11	SBCOK	O	Sub-code Q data CRCC decision result output terminal. At "H" when the decision result is OK.	36	FMFB	0	Feed motor FWD/BWD feed control signal output terminal. In outer peripheral direction at "2V _{ref} " and in inner peripheral direction at "L". Normally, this terminal is at "HIZ". Three values (2V _{ref} , HIZ and GNDA) are output.
12	V _{ee}	—	Digital power source voltage terminal (+5V)				
13	GNDD	—	Digital ground terminal	37	TEST	I	Test terminal. Normally at "H" or open (with pull-up resistor).
14	BUS 0						
15	BUS 1	I/O	Microcomputer interface data input/output terminal (Schmidt input and open drain output with pull-up resistor)	38	DMON	0	Analog switch output terminal for selecting disk motor drive circuit gain. At "HIZ" when the CLV servo is off, but when the servo is on, it is possible to select "HIZ/V _{ref} " by command.
16	BUS 2						
17	BUS 3						
18	CCE	I	Chip enable signal input terminal for microcomputer interface. BUS3-0 are active at the time of "L" (Schmidt input).				
19	BUCK	I	Microcomputer interface clock input terminal (Schmidt input)	39	DMFC	0	Disk motor CLV servo AFC signal output terminal. During motor acceleration DMFK "2V _{ref} ".
20	PFCCK	O	Playback system frame sink signal output terminal				
21	RST	I	Reset signal input terminal. At "L" during resetting (with pull-up resistor)				
22	SUBSYC	O	Sub-code block sink output terminal. "H" at the position of S1 when sub-code sink has been detected.				
23	SUBD	O	Sub-code P-W output terminal	40	DMPC	0	Disk motor CLV servo APC signal output terminal. Three values (2V _{ref} , HIZ and GNDA) are output.
24	CLK	I	Sub-code P-W data readout clock input terminal				
25	V _{ee}	—	Digital power source voltage terminal (+5V)	41	2V _{ref}	—	Reference analog power source terminal (twice the V _{ref} voltage)
26	GNDD	—	Digital ground terminal				
27	DFCT	O	Detect defector signal output terminal. Normally at "HIZ", but at "V _{ref} " whenever any defect is detected.				
28	TEU 2	O	Tracking gain adjusting analog switch output terminal. Normally at "HIZ" but at "V _{ref} " when adjusting tracking gain.				
29	TEU 1	I					
30	TGUL	O	Tracking servo gain amplifier analog switch output terminal. By command, it is possible to select the polarity at the time of gain amplifier and normal playback.				

IC601:TC9284AF

Terminal No.	Designation of Terminal	I/O	Description of Function	Terminal No.	Designation of Terminal	I/O	Description of Function
1	GNDA	—	Analog ground terminal for R channel DC converter section	31	TGUH 2	0	Tracking servo gain amplifier analog switch output terminal. Normally at "V _{ref} " but at "HIZ" at the time of gain amplifier. Use TGUH1 during normal playback and TGUH2 during double speed playback.
2	RO	O	R channel data forward output terminal	32	TGUH 1	0	
3	ROT	O	R channel data reverse output terminal				
4	VDA	—	DA converter section power source terminal				
5	LO	O	L channel data reverse output terminal	33	NKIC	0	Tracking actuator kick signal output terminal. It is used for kicking when adjusting NKIC _x , NKIC _y and tracking gain. Kicking in outer peripheral direction at "2V _{ref} " and in inner peripheral direction at "L". Normally, this terminal is at "HIZ". Three values (2V _{ref} , HIZ and GNDA) are output.
6	LO	O	L channel data forward output terminal				
7	GNDA	—	Analog ground terminal for L channel DA converter section	34	FMON	0	Feed servo ON/OFF analog switch output terminal. At "HIZ" when the servo is on, but at "V _{ref} " when it is off.
8	TEST3	I	Test terminal. Normally at "H" or open with pull-up resistor				
9	TEST4	I	Test terminal. Normally at "H" or open with pull-up resistor				
10	TEST5	I	Test terminal. Normally at "H" or open with pull-up resistor	35	TEST 1	I	Test terminal. Normally at "H" or open (with pull-up resistor).
11	SBCOK	O	Sub-code Q data CRCC decision result output terminal. At "H" when the decision result is OK.	36	FMFB	0	Feed motor FWD/BWD feed control signal output terminal. In outer peripheral direction at "2V _{ref} " and in inner peripheral direction at "L". Normally, this terminal is at "HIZ". Three values (2V _{ref} , HIZ and GNDA) are output.
12	V _{ee}	—	Digital power source voltage terminal (+5V)				
13	GNDD	—	Digital ground terminal	37	TEST	I	Test terminal. Normally at "H" or open (with pull-up resistor).
14	BUS 0						
15	BUS 1	I/O	Microcomputer interface data input/output terminal (Schmidt input and open drain output with pull-up resistor)	38	DMON	0	Analog switch output terminal for selecting disk motor drive circuit gain. At "HIZ" when the CLV servo is off, but when the servo is on, it is possible to select "HIZ/V _{ref} " by command.
16	BUS 2						
17	BUS 3						
18	CCE	I	Chip enable signal input terminal for microcomputer interface. BUS3-0 are active at the time of "L" (Schmidt input).				
19	BUCK	I	Microcomputer interface clock input terminal (Schmidt input)	39	DMFC	0	Disk motor CLV servo AFC signal output terminal. During motor acceleration DMFK "2V _{ref} ".
20	PFCCK	O	Playback system frame sink signal output terminal				
21	RST	I	Reset signal input terminal. At "L" during resetting (with pull-up resistor)				
22	SUBSYC	O	Sub-code block sink output terminal. "H" at the position of S1 when sub-code sink has been detected.				
23	SUBD	O	Sub-code P-W output terminal	40	DMPC	0	Disk motor CLV servo APC signal output terminal. Three values (2V _{ref} , HIZ and GNDA) are output.
24	CLK	I	Sub-code P-W data readout clock input terminal				
25	V _{ee}	—	Digital power source voltage terminal (+5V)	41	2V _{ref}	—	Reference analog power source terminal (twice the V _{ref} voltage)
26	GNDD	—	Digital ground terminal				
27	DFCT	O	Detect defector signal output terminal. Normally at "HIZ", but at "V _{ref} " whenever any defect is detected.				
28	TEU 2	O	Tracking gain adjusting analog switch output terminal. Normally at "HIZ" but at "V _{ref} " when adjusting tracking gain.				
29	TEU 1	I					
30	TGUL	O	Tracking servo gain amplifier analog switch output terminal. By command, it is possible to select the polarity at the time of gain amplifier and normal playback.				

Terminal No.	Designation of Terminal	I/O	Description of Function	Terminal No.	Designation of Terminal	I/O	Description of Function
43	FCSI	O	Focus actuator drive signal (output) terminal during focus search mode. The lens is driven in the distant direction from disk at "V _{ext} ", and in the nearing direction at "L". Normally, it is at "HIZ". Three values (V _{ext} , HIZ and GND) are output.	64	VCOF	O	VCO filter terminal
44	FKIC	O	Focus actuator drive signal output terminal during focus gain adjusting mode. The lens is driven in the distant direction from disk at "V _{ext} ", and in the nearing direction at "L". Normally, it is at "HIZ". Three values (V _{ext} , HIZ and GND) are output.	65	TESTX	-	Test terminal. Normally at "H" or "L". Double speed mode output terminal. "H" is output during normal playback, but "L" is output during double speed playback.
45	FEL 2	O	Focus gain adjusting analog switch output terminal. It is at "V _{ext} " or "HIZ".	66	HIS	O	Digital gland terminal
46	FEL 1	O	Focus error signal input terminal (Analog Input)	67	GND	-	Processor status signal output terminal
47	FEI	I	Focus error signal input terminal for tracking error signal sample hole (Analog Input)	68	SPDA	O	Correction system frame clock (7.35kHz) output terminal.
48	TESH	I	Analog switch input terminal for tracking servo action ON/OFF analog switch output terminal. It is at "V _{ext} " when tracking servo is off (Analog output).	69	COTS	O	Word clock (8.2kHz) output terminal. By microcomputer command, it is possible to select SUBQ, BUFCV and IPF signals.
49	TEOF	O	Tracking servo action ON/OFF analog switch output terminal. It is at "V _{ext} " when tracking servo is off (Analog output).	70	WDCK	O	Processor status signal output terminal. "L" at the time of L channel and "H" at the time of R channel.
50	SBAD	I	Sub-beam adder signal Input terminal (Analog Input)	71	CHCK	O	Channel clock (44.1kHz) output terminal.
51	RFRP	I	RF ripple signal Input terminal (Analog Input)	72	BCK	O	Bit clock (14112MHz) output terminal.
52	V _{ext}	-	Reference analog power source terminal	73	AOUT	O	Audio data output terminal
53	RFI	I	RF signal input terminal (Analog Input)	74	EMPH	O	Emphasis ON/OFF Indicator signal output terminal. At "H" when emphasis is on, but at "L" when it is off.
54	GND	-	Analog gland terminal	75	DOUT	O	Digital output terminal
55	DTSC 2	O	EFM signal reversing output terminal for data slice control	76	TEST 2	-	Test terminal. Normally at "H" or open (with pull-up resistor)
56	MONIT	O	Internal signal monitor output terminal. By command, it is possible to select EFM0, PLCK and LOCK signals. Muting is also possible.	77	V _{ext}	-	Crystal oscillator power source terminal
57	DTSC 1	O	EFM signal forward output terminal for data slice control	78	XI	I	Crystal oscillator connection terminal (Crystal oscillator frequency: 16.934MHz)
58	VDDA	-	Analog power source terminal	79	XO	O	Crystal oscillator ground terminal
59	PDCNT	I	PDO output control terminal. At "L", the PDO terminal is forcedly fixed to "HIZ". Normal output at "H".	80	GNDX	-	Crystal oscillator ground terminal
60	PDO	O	Phase error output terminal between EFM and PLCK signals. Three values (2V _{ext} , HIZ and GND) are output.				TMAX detection result
61	TMAX	O	TMAX detection result output terminal. Three values (2V _{ext} , HIZ and GND) are output.				TMAX output
62	LPFN	I	Low pass filter amplifier reversing input terminal (Analog Input)				"L"
63	LPFO	O	Low pass filter amplifier output terminal (Analog output)				"HIZ"

59	PDCNT	I	Phase error output terminal between EFM and PLCK signals. Three values (2V _{ext} , HIZ and GND) are output.	61	TMAX	O	TMAX detection result output terminal. Three values (2V _{ext} , HIZ and GND) are output.
60	PDO	O					TMAX output
61	TMAX	O					"L"
62	LPFN	I					"2V _{ext} "
63	LPFO	O					"HIZ"

13. Standard Schematic Diagram

1


2

3

4

!

■ Equalizer Amplifier Circuit : Drawing No. VHD9239 - 001PV



6

7

8

9

10




Fig. 13-1

(No.1928) 63





Fig. 13-2



1

2

3


4

5

Mixing Mic Volume Circuit: Drawing No. VDH9239-007AX

NOTES

1. VOLTAGES ARE DC-MEASURED WITH A DIGITAL VOLT METER OR OSCILLOSCOPE WITHOUT INPUT SIGNAL.
CONDITION ---- TAPE PB MODE
2. UNLESS OTHERWISE SPECIFIED
RESISTORS ARE 1/6W $\pm 5\%$ CARBON RESISTOR.
ALL RESISTANCE VALUES ARE IN OHM (Ω).
ALL CAPACITORS ARE CERAMIC CAPACITOR OR MYLAR CAPACITOR.
ALL CAPACITANCE VALUES ARE IN μF ($\text{P}=0\text{F}$).
ALL INDUCTANCE VALUES ARE IN μH ($\text{m}=0\text{H}$).
ALL E. CAPACITORS ARE SHOWN IN THE FORM OF CAPACITANCE (μF) / RATED VOLTAGE (V).



MIC Signal

+B Line

1 2 3 4 5

A

B

C

D

E

F

System Microcomputer Circuit
: Drawing No.
VHD9239-007SV

to page 64
(F/3)

CH431

VMW1355A

FW712

ICB02

BA6206A

LG05

LG05

CB33

100/16

CB37

100/16

SB51

ESS1200-002

OPEN/CLOSE SW

TRAY MOTOR

MNN-EF1LBK

MT1

MTO

MG

BV

MD

1.0V

1.0V

0V

6

7

8

9

10




Fig. 13-3

PRE PW81VMW1354D1 to page 63
CN854 (E/7)



— MIC signal

CD Analog signal

— FM Radio signal

— +B Line

1


2

3

4

1

■ CD Amplifier Circuit : Drawing No. VHD9239-001CV



NOTES 1. VOLTAGES ARE DC-MEASURED WITH A DIGITAL VOLT METER IN PLAYBACK

2. UNLESS OTHERWISE SPECIFIED, RESISTORS ARE 1/6W ±5% CARBON RESISTOR.

2. UNLESS OTHERWISE SPECIFIED, RESISTORS ARE
ALL RESISTANCE VALUES ARE IN OHMΩ).

ALL RESISTANCE VALUES ARE IN OHM'S.
ALL CAPACITORS ARE CERAMIC CAPACITOR OR MYLAR CAPACITOR.

ALL CAPACITANCE VALUES ARE IN μ F ($P = \mu$ pF).
ALL INDUCTANCE VALUES ARE IN μ H ($m = \mu$ mH).

ALL INDUCTANCE VAL.
ALL E. CAPACITORS A.

ALL E. CAPACITORS ARE SHOWN

UNFLAMMABLE CARBON RESISTOR
METAL FILM RESISTOR

(M) METAL FILM RESISTOR
(MO) OXIDE METAL FILM RESISTOR

±20% LOW LEAK CURRENT ECL

NON-POLARISED ELECTROLYTE
POLYACRYLIC ACID CAPACITOR

0501	2SA952(L, K1)
0581	
0591	2SA1309(R-S1) OR 2SA1175(HFE) OR 2SA933S(RS)
D801	MA700A OR RB7210
D691	MA165 OR HSS104TJ OR 1SS254T-77




Fig. 13-4

CD Digital signal

CD Analog signal

+B Line

1 2 3 4 5

Tuner Circuit:
VHD9239-007TW

A


B

C

D

E

F



VMW1358

Condition	PIN NO.	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
IC1	FM NO SIGNAL	2.0-0.6	0.2-0.5	0.5-0.1	0	0	0.5-0.5	0.1-1.1	1.4-2.3	3.6-3.8	3.6-3.8	1.4	0-1.6	1-2.0	2.0-2.5	0-2.0	0-2.0	0-2.0	0-2.0	0-2.0	0-2.0	0-2.0	0-2.0	0-2.0	0-2.0
	FM 50dB STEREO	2.0-0.6	0.2-0.5	0.5-0.4	0.2-0.1	0	0	0	0	0.1-1.1	1.4-2.3	3.6-3.8	3.6-3.8	3.7-4.4	0-1.4	1-2.0	2.0-2.5	0-2.0	0-2.0	0-2.0	0-2.0	0-2.0	0-2.0	0-2.0	0-2.0
	AM NO SIGNAL	2.0-0.5	0.2-0.4	0.5-0.3	0.1	0	0	0.5-0.5	0.1-1.1	1.4-2.3	3.6-3.8	3.6-3.8	1.4	0-1.6	1-2.0	2.0-2.5	0-2.0	0-2.0	0-2.0	0-2.0	0-2.0	0-2.0	0-2.0	0-2.0	0-2.0
IC2	FM NO SIGNAL	2.0-0	0	0.5-0.5	0.5-0.4	0.3-0.2	0	0	0	0	0	0	0.2-0.5	0.1-1.1	1.4-2.3	3.6-3.8	3.6-3.8	1.4	1-2.0	2.0-2.5	0-2.0	0-2.0	0-2.0	0-2.0	0-2.0
	AM 531kHz	5.0-0.5	0.0-0.2	0.4-0.3	0.5-0.4	0.5-0.5	0.2-0.3	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
IC3	SW 2.3MHz	5.0-0.5	0.4-0.7	0.1-0.5	0	0	0.5-0.5	0.4-0.7	0.5-0.5	0.1-1.5	1.5-2.0	2.0-2.5	0.5-0.5	0.1-1.1	1.4-2.3	3.6-3.8	3.6-3.8	1.4	1-2.0	2.0-2.5	0-2.0	0-2.0	0-2.0	0-2.0	0-2.0
IC4	FM NO SIGNAL	0.7	1-5	4-9	1-4	0.5	1-4	4-3	5-6	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	

Tr No.	Q1	Q2	Q4	Q5	Q22
PIN NAME	E C B	E C B	E C B	E C B	E C B
FM 5.0MHz	0.9-1.0	0	0.3-0.6	0.3-0.6	0.0-0.7
AM 531kHz	0	0	0	0	0
Tr No.	Q21	Q24	Q25	Q26	Q27
PIN NAME	E C B	E C B	E C B	E C B	E C B
SW 2.3MHz	2.0-2.2	5.1-4.6	4.6-5.1	2.0-2.0	1.4-2.0
SW 7MHz	2.0-2.0	0	0	0	0




Fig. 13-5

Tr No.	Q12	Q13	Q14	Q15
PIN NAME	E C B	E C B E C B	E C B	E C B
AM 531KHZ	0 0 0.7	0 0 0.2 0.2 0.1 1.4 2.0 2.0 1.4		
SW 2.3MHz	0 4.6 0	0 0.7 2.0 2.0 4.7 7.2 3.2 0.4 4.7		

FM Radio signal
 MW Radio signal
 SW1, SW2 Radio signal

+B Line

(No.1928) 67

14. Location of P. C. Board Parts

1

2

3

△

1




Fig. 14-1

The diagram shows the layout of the VMW1354D circuit board, which consists of two main printed circuit boards (PCBs) labeled VMW1354A and VMW1354D.

VMW1354D (Top Board):

- Mechanism control P.C. board:** Located at the top right, featuring a central IC851 component. Other components include R851, C852, L853, C1, C2, IC852, IC853, and various resistors (R854-R860, R862-R869, R870-R872) and capacitors (C854-C859, C861-C866). Power supply connections are labeled P03 and T03.
- Equalizer amplifier P.C. board:** Located at the bottom left, featuring a central IC301 component. Other components include Q101, R101-R105, C301-C305, IC302, and various resistors (R301-R307, R309-R314) and capacitors (C306-C310, C302, C303, C304, C307, C310).

VMW1354A (Bottom Board):


- Mechanism control P.C. board:** Located at the bottom right, featuring a central IC854 component. Other components include R851, C852, L853, C1, C2, IC852, IC853, and various resistors (R854-R860, R862-R869, R870-R872) and capacitors (C854-C859, C861-C866). Power supply connections are labeled P03 and T03.
- Equalizer amplifier P.C. board:** Located at the bottom left, featuring a central IC301 component. Other components include Q101, R101-R105, C301-C305, IC302, and various resistors (R301-R307, R309-R314) and capacitors (C306-C310, C302, C303, C304, C307, C310).

Annotations indicate the following:

- Mechanism control P. C. board
- Equalizer amplifier P. C. board

1 2 3 4 5

■ Equalizer Amplifier P. C. board: Block No. 02




6

7

8

9

10



← ● Power amplifier
P. C. board

Fig. 14-2

(No.1928) 69

1


2

3

4

1


■ System Microcomputer P. C. board: Block No. 05




- Indicator /Microcomputer P. C. board

6 991956 6

● LCD back light P, C, boar





■ CD Tray Loading Motor P. C. board: Block No. 06





Fig. 14-4

■ CD Operation Switch P. C. board: Block No. 04



- Power open/c switch P. C. b

16

17

18

19

20

A


B

C

D

E

F



1 2 3 4 5

A

B

C

D

E

F

■ CD Amplifier P. C. board: Block No. 03




Fig. 14-6

6

7

8

9

10

■ Cassette Mechanism P. C. Board: Block NO. 07

● Leaf switch P. C. board




Fig. 14-7

● Actuator/Reel Motor P. C. board




Fig. 14-8

15. Electrical Parts List

REF.	PARTS NO.	PART'S NAME	REMARKS	SUFFIX	BLOCK NO. 01	BLOCK NO. 01	BLOCK NO. 01	BLOCK NO. 01	BLOCK NO. 01
C 901	QFLC1HJ-6837M	N.CAPACITOR	-0.68MF 5% 50V		CA332 QET41HM-105	E.CAPACITOR	1.0MF 20% 50V		
C 902	QFLC1HJ-6837M	M.CAPACITOR	-0.68MF 5% 50V		CA333 QFV81HJ-473	FILM CAPACITOR	-0.47MF 5% 50V		
C 903	QFLC1HJ-6837M	M.CAPACITOR	-0.68MF 5% 50V		CA334 QV81HJ-473	FILM CAPACITOR	-0.47MF 5% 50V		
C 904	QFLC1HJ-6837M	M.CAPACITOR	-0.68MF 5% 50V		CA335 QET41HM-105	E.CAPACITOR	1.0MF 20% 50V		
C 905	QFLC1HJ-6837M	M.CAPACITOR	-0.68MF 5% 50V		CA336 QER41CM-106	E.CAPACITOR	1.0MF 20% 16V		
CA101	QCBB1HK-331Y	C.CAPACITOR	330PF 10% 50V		CA340 QCBB1HK-151Y	C.CAPACITOR	150PF 10% 50V		
CA102	QCC11EM-104V	C.CAPACITOR	-1.0MF 20% 25V		CA341 QET41EM-106	E.CAPACITOR	1.0MF 20% 25V		
CA103	QCC11EM-104V	C.CAPACITOR	-1.0MF 20% 25V		CA351 QER41CM-476M	E.CAPACITOR	4.7MF 20% 16V		
CA106	QCE081C-106Z	E.CAPACITOR	-1.0MF 5% 50V		CA352 QER41CM-106	E.CAPACITOR	1.0MF 20% 16V		
CA121	QFV11HJ-104EM	FILM CAPACITOR	-1.0MF 5% 50V		CA371 QER61AM-226ZM	E.CAPACITOR	2.2MF 20% 10V		
CA122	QFV11HJ-104EM	FILM CAPACITOR	-1.0MF 5% 50V		CA372 QER61AM-684ZM	E.CAPACITOR	6.8MF 20% 50V		
CA124	QET41AM-107	E.CAPACITOR	1.0MF 5% 50V		CA373 QER41HM-105VM	E.CAPACITOR	1.0MF 20% 50V		
CA125	VCE081A-226Z	E.CAPACITOR	1.0MF 20% 50V		CA380 QCVB1HK-103Y	E.CAPACITOR	0.10MF 20% 16V		
CA126	QET41HM-105	E.CAPACITOR	1.0MF 5% 50V		CA381 QET41CM-476	E.CAPACITOR	4.7MF 20% 16V		
CA151	QCS11HJ-100	C.CAPACITOR	1.0PF 5% 50V		CA382 QET41AM-107	E.CAPACITOR	1.00MF 20% 10V		
CA152	QER41EM-475VM	E.CAPACITOR	4.7MF 20% 25V		CA383 QET41AM-226	E.CAPACITOR	2.2MF 20% 10V		
CA153	VCE01C-106Z	E.CAPACITOR	2700PF 5% 50V		CA384 QETC1HK-224ZN	E.CAPACITOR	-2.2MF 20% 50V		
CA154	QFLC1H-272	M.CAPA. 1.M	4.7MF 20% 25V		CA385 QET41HM-475	E.CAPACITOR	4.7MF 20% 25V		
CA155	QER41EM-475VM	E.CAPACITOR	1.0MF 20% 16V		CA386 QET41EM-106	E.CAPACITOR	1.0MF 20% 25V		
CA156	QER41CM-106	E.CAPACITOR	1.0MF 20% 50V		CA387 QETC1HK-224ZN	E.CAPACITOR	.22MF 20% 50V		
CA157	QER41HM-105VM	C.CAPACITOR	1.0MF 20% 50V		CA388 QCBB1HK-102Y	C.CAPACITOR	1000PF 10% 50V		
CA161	QCBB1CM-122Y	C.CAPACITOR	1200PF 20% 16V		CA389 QCBB1HK-102Y	C.CAPACITOR	1000PF 10% 50V		
CA162	QCBX1CM-332Y	C.CAPACITOR	3300PF 20% 16V		CA391 QET41EM-107Y	E.CAPACITOR	100MF 20% 25V		
CA183	QFV11HJ-563AZM	FILM CAPACITOR	.056MF 5% 50V		CA392 QET41CM-106	E.CAPACITOR	1.0MF 20% 16V		
CA184	QCBB1HK-471Y	C.CAPACITOR	470PF 10% 50V		CA393 QET41HM-474	E.CAPACITOR	.47MF 20% 50V		
CA201	QCBB1HK-331Y	C.CAPACITOR	330PF 10% 50V		CA394 QET41EM-106	E.CAPACITOR	10MF 20% 25V		
CA202	QCBB1CM-104V	C.CAPACITOR	-1.0MF 20% 25V		CA395 QET41EM-106	E.CAPACITOR	10MF 20% 25V		
CA203	QCC11EM-104V	E.CAPACITOR	-1.0MF 20% 25V		CA396 QFV41HJ-104ZM	FILM CAPACITOR	100MF 10% 50V		
CA206	VCE081C-106Z	E.CAPACITOR	.056MF 5% 50V		CA397 QET41EM-106	E.CAPACITOR	1.0MF 20% 25V		
CA221	QFV11HJ-104ZM	FILM CAPACITOR	-1.0MF 5% 50V		CA398 QET41CM-476	E.CAPACITOR	4.7MF 20% 50V		
CA224	QFV11HJ-104M	E.CAPACITOR	-1.0MF 5% 50V		CA399 QET41EM-106	E.CAPACITOR	10MF 20% 25V		
CA225	VCE081A-226Z	E.CAPACITOR	1.0MF 20% 10V		CA400 QET41AM-107	E.CAPACITOR	4.7MF 20% 10V		
CA226	QET41HM-105	E.CAPACITOR	1.0MF 20% 50V		CA401 QET41CM-476	E.CAPACITOR	4.7MF 20% 16V		
CA251	QCS11HJ-100	C.CAPACITOR	1.0PF 5% 50V		CA402 QET41AM-107	E.CAPACITOR	1.00MF 20% 10V		
CA252	QER41EM-475VM	E.CAPACITOR	4.7MF 20% 25V		CA403 QET41CM-476	E.CAPACITOR	4.7MF 20% 16V		
CA253	VCE081C-106Z	E.CAPACITOR	2700PF 5% 50V		CA404 QETC1AM-337ZN	E.CAPACITOR	3.30MF 20% 10V		
CA254	QFLC1HJ-475YM	E.CAPACITOR	4.7MF 20% 25V		CNA31 VMC0314-S08	CONNECTOR	U-COM		
CA255	QER41EM-475YM	E.CAPACITOR	4.7MF 20% 50V		CNA32 VMC0314-S16	CONNECTOR	U-COM		
CA256	QER41CM-106	E.CAPACITOR	1.0MF 20% 16V		CNA33 VM20076-004A	CONNECTOR	TAPE PRI SEC		
CA257	QER41HM-105VM	E.CAPACITOR	1.0MF 20% 50V		CN902 VM20076-002	CONNECTOR	MAIN		
CA261	QCBX1CM-122Y	C.CAPACITOR	3300PF 20% 16V		D 901 1N5401TM	SI DIODE			
CA262	QCBX1CM-332Y	C.CAPACITOR	.056MF 5% 50V		D 902 1N5401TM	SI DIODE			
CA282	QFV11HJ-563ZM	FILM CAPACITOR	470PF 10% 50V		D 903 1N5401TM	SI DIODE			
CA283	QFV11HJ-563ZM	FILM CAPACITOR	470PF 10% 50V		D 904 1N5401TM	SI DIODE			
CA284	QCBB1HK-471Y	C.CAPACITOR	6800MF 20% 25V		D 905 1N5401TM	SI DIODE			
CA301	QEB1EM-688W	E.CAPACITOR	220MF 20% 10V		DA301 RB721Q	Z-DIODE			
CA303	QET41AM-227	E.CAPACITOR	100MF 20% 16V		DA321 MT74-7JC	Z-DIODE			
CA304	QET41CM-107	E.CAPACITOR	4.7MF 20% 10V		DA331 1SS133	SI DIODE			
CA305	QET41AM-476	E.CAPACITOR	2.2MF 20% 50V		DA332 1SS133	SI DIODE			
CA306	QETC1HM-225Z	E.CAPACITOR	4.7MF 20% 16V		DA333 1SS133	SI DIODE			
CA321	QET41CM-476	E.CAPACITOR	1.0MF 20% 16V		DA334 1SS133	SI DIODE			
CA322	QET41CM-106	E.CAPACITOR	1.0MF 20% 50V		DA371 1SS133	SI DIODE			
CA331	QET41HM-105	E.CAPACITOR	1.0MF 20% 10V		DA372 MT75-1JB	ZENER DIODE			
CA331	QET41HM-105	E.CAPACITOR	1.0MF 20% 50V		DA921 1SS133	SI DIODE			
					DA922 MT79-1JA	ZENER DIODE			
					DA931 MT79-1JA	ZENER DIODE			

BLOCK NO. 01111111

A	REF.	PARTS NO.	PARTS NAME	REMARKS	SURF IX	BLOCK NO. <u>01111111</u>
	DA941	MT226-8JAT-77	ZENER DIODE			
	DA951	MT26-8JB	ZENER DIODE	POWER AMP		
	ICA31	LA4705	IC	AHB AMP		
	ICA32	BA15218N	IC	FUNCTION		
	ICA35	BA15218N	IC	E VOL		
	ICA38	BH3854S	IC	REG		
	ICA91	BA3960	IC			
	ICA92	UPC7808HF	AC SOCKET			
J	901	QMC0263-004BS	FILM CAPACITOR	AUX		
J	902	QMA431B-V01	JACK	SPEAKER		
	JA302	VMJ4024-001	JACK	HEADPHONE		
	JA303	EMB90V-401A	S-TERMIMAL			
	JA304	VMJ4024-001	JACK			
	LA161	EQFO101-010	FILTER			
	LA261	EQFO101-010	FILTER			
	LA361	VQ200-8-007	INDUCTOR			
	QA131	2SC2785	TRANSISTOR			
	QA141	2SC2001(L,K)	TRANSISTOR			
	QA172	2SC2785	TRANSISTOR			
	QA173	2SC2785	TRANSISTOR			
	QA231	2SC2785	TRANSISTOR			
	QA241	2SC2001(L,K)	TRANSISTOR			
	QA272	2SC2785	TRANSISTOR			
	QA273	2SC2785	TRANSISTOR			
	QA341	DTA114-S	TRANSISTOR			
	QA342	DTC114ES	TRANSISTOR			
	QA371	DTA143ES	TRANSISTOR			
	QA372	2SC2785	TRANSISTOR			
	QA941	2SC2785	TRANSISTOR			
	QA942	DTA114YS	TRANSISTOR			
	QA952	2SD882 (P,Q)	TRANSISTOR			
	RA101	GRD161J-2R2	CARBON RESISTOR	2.2 % 1/6W		
	RA102	GRD161J-2R2	CARBON RESISTOR	2.2 % 1/6W		
	RA103	GRD161J-151	CARBON RESISTOR	150 % 1/6W		
	RA104	GRD161J-471	CARBON RESISTOR	470 % 1/6W		
	RA122	GRD161J-154	CARBON RESISTOR	150K % 1/6W		
	RA123	GRD161J-222	CARBON RESISTOR	2.2K % 1/6W		
	RA124	GRD161J-222	CARBON RESISTOR	2.2K % 1/6W		
	RA125	GRD161J-103	CARBON RESISTOR	10K % 1/6W		
	RA127	GRD161J-622	CARBON RESISTOR	6.2K % 1/6W		
	RA128	GRD161J-472	CARBON RESISTOR	4.7K % 1/6W		
	RA129	GRD161J-182	CARBON RESISTOR	1.8K % 1/6W		
	RA131	GRD161J-683	CARBON RESISTOR	68K % 1/6W		
	RA132	GRD161J-683	CARBON RESISTOR	68K % 1/6W		
	RA133	GRD161J-103	CARBON RESISTOR	10K % 1/6W		
	RA134	GRD161J-123	CARBON RESISTOR	12K % 1/6W		
	RA141	GRD161J-222	CARBON RESISTOR	2.2K % 1/6W		
	RA151	GRD161J-154	CARBON RESISTOR	150K % 1/6W		
	RA152	GRD161J-102	CARBON RESISTOR	1.0K % 1/6W		
	RA154	GRD161J-472	CARBON RESISTOR	4.7K % 1/6W		
	RA155	GRD167J-332	CARBON RESISTOR	3.3K % 1/6W		
	RA156	GRD161J-563	CARBON RESISTOR	56K % 1/6W		
	RA163	GRD161J-124	CARBON RESISTOR	120K % 1/6W		
	RA164	GRD161J-153	CARBON RESISTOR	15K % 1/6W		

A	REF.	PARTS NO.	PARTS NAME	SURF IX	BLOCK NO. <u>01111111</u>	S U F F I X
	RA165	GRD161J-823	CARBON RESISTOR	82K % 1/6W		
	RA166	GRD161J-183	CARBON RESISTOR	18K % 1/6W		
	RA167	GRD167J-532	CARBON RESISTOR	3.3K % 1/6W		
	RA168	GRD161J-102	CARBON RESISTOR	1.0K % 1/6W		
	RA169	GRD161J-472	CARBON RESISTOR	4.7K % 1/6W		
	RA170	GRD161J-704	CARBON RESISTOR	100K % 1/6W		
	RA172	GRD161J-272	CARBON RESISTOR	2.7K % 1/6W		
	RA173	GRD161J-472	CARBON RESISTOR	4.7K % 1/6W		
	RA182	GRD161J-302	CARBON RESISTOR	3.0K % 1/6W		
	RA183	GRD161J-472	CARBON RESISTOR	4.7K % 1/6W		
	RA201	GRD161J-2R2	CARBON RESISTOR	2.2 % 1/6W		
	RA202	GRD161J-151	CARBON RESISTOR	150 % 1/6W		
	RA204	GRD161J-471	CARBON RESISTOR	4.7K % 1/6W		
	RA222	GRD161J-154	CARBON RESISTOR	150K % 1/6W		
	RA223	GRD161J-222	CARBON RESISTOR	2.2K % 1/6W		
	RA224	GRD161J-222	CARBON RESISTOR	2.2K % 1/6W		
	RA225	GRD161J-103	CARBON RESISTOR	10K % 1/6W		
	RA227	GRD161J-622	CARBON RESISTOR	6.2K % 1/6W		
	RA228	GRD161J-472	CARBON RESISTOR	4.7K % 1/6W		
	RA229	GRD161J-182	CARBON RESISTOR	1.8K % 1/6W		
	RA231	GRD161J-683	CARBON RESISTOR	68K % 1/6W		
	RA232	GRD161J-683	CARBON RESISTOR	68K % 1/6W		
	RA233	GRD161J-103	CARBON RESISTOR	10K % 1/6W		
	RA234	GRD161J-123	CARBON RESISTOR	12K % 1/6W		
	RA241	GRD161J-222	CARBON RESISTOR	2.2K % 1/6W		
	RA251	GRD161J-154	CARBON RESISTOR	150 % 1/6W		
	RA252	GRD161J-102	CARBON RESISTOR	10K % 1/6W		
	RA254	GRD161J-472	CARBON RESISTOR	4.7K % 1/6W		
	RA255	GRD167J-332	CARBON RESISTOR	3.3K % 1/6W		
	RA256	GRD161J-563	CARBON RESISTOR	56K % 1/6W		
	RA257	GRD161J-124	CARBON RESISTOR	120K % 1/6W		
	RA258	GRD161J-153	CARBON RESISTOR	15K % 1/6W		
	RA264	GRD161J-823	CARBON RESISTOR	82K % 1/6W		
	RA265	GRD161J-183	CARBON RESISTOR	18K % 1/6W		
	RA266	GRD161J-183	CARBON RESISTOR	18K % 1/6W		
	RA267	GRD167J-332	CARBON RESISTOR	3.3K % 1/6W		
	RA268	GRD161J-102	CARBON RESISTOR	1.0K % 1/6W		
	RA269	GRD161J-472	CARBON RESISTOR	4.7K % 1/6W		
	RA270	GRD161J-104	CARBON RESISTOR	100K % 1/6W		
	RA272	GRD161J-272	CARBON RESISTOR	2.7K % 1/6W		
	RA273	GRD161J-472	CARBON RESISTOR	4.7K % 1/6W		
	RA288	GRD161J-302	CARBON RESISTOR	3.0K % 1/6W		
	RA289	GRD161J-472	CARBON RESISTOR	4.7K % 1/6W		
	RA290	GRD161J-104	CARBON RESISTOR	100K % 1/6W		
	RA292	GRD161J-272	CARBON RESISTOR	2.7K % 1/6W		
	RA293	GRD161J-472	CARBON RESISTOR	4.7K % 1/6W		
	RA301	GRD161J-472	CARBON RESISTOR	4.7K % 1/6W		
	RA321	GRD161J-101	CARBON RESISTOR	100K % 1/6W		
	RA322	GRD161J-152	CARBON RESISTOR	1.5K % 1/6W		
	RA323	GRD161J-123	CARBON RESISTOR	12K % 1/6W		
	RA324	GRD161J-224	CARBON RESISTOR	220K % 1/6W		
	RA331	GRD161J-123	CARBON RESISTOR	12K % 1/6W		
	RA332	GRD161J-224	CARBON RESISTOR	220K % 1/6W		
	RA333	GRD161J-683	CARBON RESISTOR	68K % 1/6W		
	RA336	GRD161J-223	CARBON RESISTOR	22K % 1/6W		
	RA341	GRD161J-223	CARBON RESISTOR	22K % 1/6W		
	RA351	GRD161J-101	CARBON RESISTOR	100K % 1/6W		
	RA352	GRD161J-473	CARBON RESISTOR	4.7K % 1/6W		

■ Equalizer Amplifier Board

BLOCK NO. 01

A	REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
	RA353	GRD161J-473	CARBON RESISTOR	47K 5%	1/6W
	RA371	GRD161J-153	CARBON RESISTOR	15K 5%	1/6W
	RA372	GRD161J-103	CARBON RESISTOR	10K 5%	1/6W
	RA373	GRD161J-223	CARBON RESISTOR	22K 5%	1/6W
	RA381	GRD167J-4R7	CARBON RESISTOR	4.7 5%	1/6W
	RA382	GRD161J-22	CARBON RESISTOR	2.2K 5%	1/6W
	RA383	GRD161J-222	CARBON RESISTOR	2.2K 5%	1/6W
	RA384	GRD161J-222	CARBON RESISTOR	2.2K 5%	1/6W
	RA385	GRD161J-102	CARBON RESISTOR	1.0K 5%	1/6W
	RA386	GRD161J-102	CARBON RESISTOR	1.0K 5%	1/6W
	RA921	GRD161J-183	CARBON RESISTOR	18K 5%	1/6W
	RA922	GRD167J-332	CARBON RESISTOR	3.3K 5%	1/6W
	RA923	GRD161J-221	CARBON RESISTOR	220 5%	1/6W
	RA924	GRD161J-332	CARBON RESISTOR	3.3K 5%	1/6W
	RA925	GRD161J-273	CARBON RESISTOR	27K 5%	1/6W
	RA926	GRD161J-223	CARBON RESISTOR	22K 5%	1/6W
	RA927	GRD161J-103	CARBON RESISTOR	10K 5%	1/6W
	RA931	QRZ0077-4R7X	FUSE RESISTOR	4.7 1/0W	
	RA932	QRZ0077-4R7X	FUSE RESISTOR	4.7 1/0W	
	RA942	GRD161J-821	CARBON RESISTOR	820 5%	1/6W
	RA943	GRD161J-103	CARBON RESISTOR	100 5%	1/6W
	RA944	GRD161J-103	CARBON RESISTOR	10K 5%	1/6W
	RA951	GRD161J-101	CARBON RESISTOR	100 5%	1/6W
	RA952	GRD161J-220	CARBON RESISTOR	22 5%	1/6W
	RA953	GRD161J-122	CARBON RESISTOR	1.2K 5%	1/6W
S	901	VWZ0126-002	VOLTAGE SELLCTOR	US_U	

BLOCK NO. 02

A	REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
C	1	VCP0012-105Z	C.CAPACITOR		
C	2	VCPO012-105Z	C.CAPACITOR		
C	101	QEK61AM-107ZM	E.CAPACITOR	100MF 20% 10V	
C	102	QCBB1HK-681Y	E.CAPACITOR	680PF 10% 50V	
C	103	QE41HM-225	E.CAPACITOR	2.2MF 20% 50V	
C	104	QFV71HJ-103	FILM CAPACITOR	.010MF 5% 50V	
C	121	QCBB1HK-102Y	C.CAPACITOR	1000PF 10% 50V	
C	122	QCS11HJ-271	C.CAPACITOR	270PF 5% 50V	
C	123	QCBB1HK-331Y	C.CAPACITOR	330PF 10% 50V	
C	141	QE61AM-334ZM	E.CAPACITOR	.33MF 20% 50V	
C	142	QE41HM-225	E.CAPACITOR	2.2MF 20% 50V	
C	143	QEK41HM-224	E.CAPACITOR	.22MF 20% 50V	
C	144	QE61HM-742ZM	E.CAPACITOR	.47MF 20% 50V	
C	145	QCBB1HK-102Y	E.CAPACITOR	1000PF 10% 50V	
C	146	QE41HM-474	E.CAPACITOR	.47MF 20% 50V	
C	147	QCBB1HK-471Y	C.CAPACITOR	470PF 10% 50V	
C	148	QE41HM-475	E.CAPACITOR	4.7MF 20% 50V	
C	149	QE41HM-474	E.CAPACITOR	.47MF 20% 50V	
C	150	QE41HM-105	E.CAPACITOR	1.0MF 20% 50V	
C	151	QE41HM-475	E.CAPACITOR	4.7MF 20% 50V	
C	152	QCC11EM-104V	C.CAPACITOR	.10MF 20% 25V	
C	153	QE41HM-105VM	E.CAPACITOR	1.0MF 20% 50V	
C	154	QCXB1CM-222Y	C.CAPACITOR	2200PF 20% 16V	
C	155	QCBB1HK-102Y	C.CAPACITOR	1000PF 10% 50V	
C	156	QFV41HJ-153ZM	FILM CAPACITOR	.015MF 5% 50V	
C	157	QFV81HJ-273	FILM CAPACITOR	.02MF 5% 50V	
C	158	QFV41HJ-153ZM	FILM CAPACITOR	.015MF 5% 50V	
C	201	QE61AM-107ZM	E.CAPACITOR	100MF 20% 10V	
C	202	QCBB1HK-681Y	E.CAPACITOR	680PF 10% 50V	
C	203	QE41HM-225	E.CAPACITOR	2.2MF 20% 50V	
C	204	QFV71HJ-103	FILM CAPACITOR	.010MF 5% 50V	
C	221	QCBB1HK-102Y	C.CAPACITOR	1000PF 10% 50V	
C	222	QCBB1HK-331Y	C.CAPACITOR	270PF 5% 50V	
C	241	QE61AM-334ZM	E.CAPACITOR	330PF 10% 50V	
C	242	QE41HM-225	E.CAPACITOR	.33MF 20% 50V	
C	243	QE41HM-224	E.CAPACITOR	2.2MF 20% 50V	
C	244	QE61HM-742ZM	E.CAPACITOR	.47MF 20% 50V	
C	245	QCBB1HK-102Y	E.CAPACITOR	1000PF 10% 50V	
C	246	QE41HM-474	E.CAPACITOR	.47MF 20% 50V	
C	247	QCBB1HK-471Y	C.CAPACITOR	470PF 10% 50V	
C	248	QE41HM-475	E.CAPACITOR	4.7MF 20% 50V	
C	249	QE41HM-474	E.CAPACITOR	.47MF 20% 50V	
C	250	QE41HM-105	E.CAPACITOR	1.0MF 20% 50V	
C	251	QE41HM-475	E.CAPACITOR	4.7MF 20% 50V	
C	252	QCC11EM-104V	C.CAPACITOR	10MF 20% 25V	
C	253	QE41HM-105VM	E.CAPACITOR	1.0MF 20% 50V	
C	254	QCXB1CM-222Y	C.CAPACITOR	2200PF 20% 16V	
C	255	QCBB1HK-102Y	C.CAPACITOR	1000PF 10% 50V	
C	256	QFV41HJ-153ZM	FILM CAPACITOR	.015MF 5% 50V	
C	257	QFV81HJ-273	FILM CAPACITOR	.02MF 5% 50V	
C	258	QFV41HJ-153ZM	FILM CAPACITOR	.015MF 5% 50V	
C	301	QE41HM-226	E.CAPACITOR	22MF 20% 16V	
C	302	QCBB1HK-131Y	C.CAPACITOR	.010MF 20% 16V	
C	303	QE41HM-226	E.CAPACITOR	22MF 20% 16V	

UX – T3 A/US/U

BLOCK NO. 02111111				BLOCK NO. 02111111			
REF.	PART'S NO.	PART'S NAME	REMARKS	REF.	PART'S NO.	PART'S NAME	REMARKS
			SUFFIX				SUFFIX
C 304	QFV7HJ-103	FILM CAPACITOR	.010MF 5% 50V	D 321	ISS133	SI DIODE	
C 305	QFV4HJ-1532M	FILM CAPACITOR	.015MF 5% 50V	D 322	ISS133	SI DIODE	
C 306	QCS1HJ-330	C.CAPACITOR	.33PF 5% 50V	D 323	ISS133	SI DIODE	
C 307	QCXB1CM-182Y	C.CAPACITOR	1800PF 20% 16V	D 851	ISS133	SI DIODE	
C 308	QCBBIHK-681Y	C.CAPACITOR	680PF 10% 50V	IC301	UPC122BHA	IC	
C 310	QEKA1HM-105	E.CAPACITOR	1.0MF 20% 50V	IC302	UPC1330HA	IC	
C 321	QET41CM-476	E.CAPACITOR	4.7MF 20% 16V	IC341	HA12134A	IC	
C 322	QFN41HJ-682	M.CAPACITOR	6800PF 5% 50V	IC342	LA3220	IC	
C 323	QFN81HJ-562	M.CAPACITOR	5600PF 5% 50V	IC851	L794072	IC	
C 324	QFN81HJ-562	M.CAPACITOR	5600PF 5% 50V	IC852	T8409S	IC	
C 325	QFN81HJ-562	M.CAPACITOR	5600PF 5% 50V	IC853	VGP0001-103S	IC	
C 326	QET41CM-476	E.CAPACITOR	4.7MF 20% 16V	L 121	VGP0001-103S	INDUCTOR	
C 328	QFP32AJ-1532M	PP.CAPACITOR	1500PF 5% 50V	L 141	VQP008-562	INDUCTOR	
C 329	QFN81HJ-152	M.CAPACITOR	5600PF 5% 50V	L 221	VQP0001-103S	INDUCTOR	
C 330	QCVB1CM-103Y	C.CAPACITOR	1500PF 5% 50V	L 241	VQP0028-562	INDUCTOR	
C 331	QFN41HJ-332	M.CAPACITOR	3300PF 5% 50V	L 321	VQH1008-055	OSC COIL BIASS	
C 332	QCVB1CM-103Y	C.CAPACITOR	.010MF 20% 16V	L 322	VQP0028-100Z	INDUCTOR	
C 333	QCVB1CM-103Y	C.CAPACITOR	.010MF 20% 16V	L 851	VQP0018-100	INDUCTOR	
C 341	QEKA1CM-106	E.CAPACITOR	.010MF 20% 16V	L 852	VQP0033-100Z	INDUCTOR	
C 342	QEKA1CM-106	E.CAPACITOR	.010MF 20% 16V	L 853	VQP0033-100Z	INDUCTOR	
C 343	QEKA1HM-25	E.CAPACITOR	2.2MF 20% 50V	Q 101	DTC144TS	TRANSISTOR	
C 344	QET41AM-226	E.CAPACITOR	2.2MF 20% 50V	Q 141	2SC2001(L,K)	TRANSISTOR	
C 346	QETC1HM-1Z2N	E.CAPACITOR	10MF 20% 50V	Q 142	2SC2785	TRANSISTOR	
C 347	QEKA1HM-226	E.CAPACITOR	22MF 20% 16V	Q 201	DTC144TS	TRANSISTOR	
C 348	QET41AM-107	E.CAPACITOR	10MF 20% 10V	Q 241	2SC2001(L,K)	TRANSISTOR	
C 349	QET41HM-105	E.CAPACITOR	1.0MF 20% 50V	Q 242	2SC2785	TRANSISTOR	
C 852	QEKG61AM-107ZM	E.CAPACITOR	100MF 20% 10V	Q 243	DTC144TS	TRANSISTOR	
C 853	QCXB1CM-272Y	C.CAPACITOR	2700PF 20% 16V	Q 301	2SC2785	TRANSISTOR	
C 854	QCVB1CM-103Y	C.CAPACITOR	.010MF 20% 16V	Q 302	2SC2785	TRANSISTOR	
C 858	QCVB1CM-103Y	C.CAPACITOR	.010MF 20% 16V	Q 321	2SC2001(L,K)	TRANSISTOR	
C 859	QCS1HJ-470	C.CAPACITOR	4.7PF 5% 50V	Q 322	2SC2001(L,K)	TRANSISTOR	
C 860	QET41AM-108	E.CAPACITOR	1000MF 20% 10V	Q 323	2SC2785	TRANSISTOR	
C 861	QCVB1CM-103Y	C.CAPACITOR	.010MF 20% 16V	Q 324	2SC2001(L,K)	TRANSISTOR	
C 862	QCVB1CM-103Y	C.CAPACITOR	.010MF 20% 16V	Q 325	2SC1845	TRANSISTOR	
C 863	QCVB1CM-103Y	C.CAPACITOR	.010MF 20% 16V	Q 326	2SC2785	TRANSISTOR	
C 865	QCBBIHK-151Y	C.CAPACITOR	150PF 10% 50V	Q 327	2SC1845	TRANSISTOR	
CN301	VMCO163-R06	CONNECTOR		Q 328	2SC2785	TRANSISTOR	
CN302	VMCO289-S10	CONNECTOR		Q 341	DTC144ES	TRANSISTOR	
CN303	VMCO289-S07	CONNECTOR		Q 342	DTC144ES	TRANSISTOR	
CN321	VMCO289-P07	CONNECTOR		Q 343	DTC144TS	TRANSISTOR	
CN322	VMCO289-S05	CONNECTOR		Q 344	DTC144ES	TRANSISTOR	
CN342	VMCO289-P05	CONNECTOR		Q 851	2SA952(L,K)	TRANSISTOR	
CN343	VMCO289-P11	CONNECTOR		Q 852	DTC144ES	TRANSISTOR	
CN344	VMCO041-003	CONNECTOR		Q 853	DTC144ES	TRANSISTOR	
CN345	VMCO163-R07	CONNECTOR	FOR DOLBY CHECK	Q 854	2SA952(L,K)	TRANSISTOR	
CN851	VMCO289-S11	CONNECTOR		R 101	QRD161J-680	CARBON RESISTOR	68 5% 1/6W
CN852	VMCO234-P08	CONNECTOR		R 102	QRD161J-224	CARBON RESISTOR	220K 5% 1/6W
CN853	VMCO234-P11	CONNECTOR		R 103	QRD161J-682	CARBON RESISTOR	6.8K 5% 1/6W
CN854	VMCO163-R07	CONNECTOR		R 104	QRD161J-562	CARBON RESISTOR	5.6K 5% 1/6W
CN855	VMCO289-S10	CONNECTOR		R 105	QRD161J-122	CARBON RESISTOR	1.2K 5% 1/6W
CN855	VMCO289-S10	CONNECTOR		R 121	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W
D 141	ISS133	SI DIODE		R 141	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W
D 142	ISS133	SI DIODE		R 142	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W
D 241	ISS133	SI DIODE		R 143	QRD161J-104	CARBON RESISTOR	10K 5% 1/6W
D 242	ISS133	SI DIODE		R 144	QRD161J-332	CARBON RESISTOR	3.3K 5% 1/6W
D 301	ISS133	SI DIODE		R 145	QRD161J-332	CARBON RESISTOR	3.3K 5% 1/6W

REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX		BLOCK NO. 02 11111
R 146	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W		R 341 QRD161J-103	CARBON RESISTOR 10K 5% 1/6W
R 147	QRD161J-153	CARBON RESISTOR	15K 5% 1/6W		R 342 QRD161J-183	CARBON RESISTOR 18K 5% 1/6W
R 148	QRD161J-153	CARBON RESISTOR	15K 5% 1/6W		R 343 QRD161J-221	CARBON RESISTOR 220 5% 1/6W
R 149	QRD161J-221	CARBON RESISTOR	220 5% 1/6W		R 344 QRD161J-103	CARBON RESISTOR 10K 5% 1/6W
R 150	QRD161J-182	CARBON RESISTOR	1.8K 5% 1/6W		R 345 QRD161J-222	CARBON RESISTOR 2.2K 5% 1/6W
R 151	QRD161J-151	CARBON RESISTOR	150 5% 1/6W		R 346 QRD161J-121	CARBON RESISTOR 120 5% 1/6W
R 152	QRD161J-472	CARBON RESISTOR	4.7K 5% 1/6W		R 348 QRD161J-475	CARBON RESISTOR 4.7M 5% 1/6W
R 153	QRD161J-182	CARBON RESISTOR	1.8K 5% 1/6W		R 349 QRD161J-475	CARBON RESISTOR 4.7M 5% 1/6W
R 154	QRD161J-472	CARBON RESISTOR	4.7K 5% 1/6W		R 350 QRD161J-221	CARBON RESISTOR 220 5% 1/6W
R 155	QRD167J-332	CARBON RESISTOR	3.3K 5% 1/6W		R 351 QRD161J-233	CARBON RESISTOR 22K 5% 1/6W
R 157	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W		R 352 QRD161J-101	CARBON RESISTOR 100 5% 1/6W
R 158	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W		R 851 QRD161J-103	CARBON RESISTOR 10K 5% 1/6W
R 201	QRD161J-680	CARBON RESISTOR	68 5% 1/6W		R 852 QRD161J-684	CARBON RESISTOR 680K 5% 1/6W
R 202	QRD161J-224	CARBON RESISTOR	220K 5% 1/6W		R 853 QRD161J-224	CARBON RESISTOR 220K 5% 1/6W
R 203	QRD167J-682	CARBON RESISTOR	6.8K 5% 1/6W		R 854 QRD161J-392	CARBON RESISTOR 3.9K 5% 1/6W
R 204	QRD167J-562	CARBON RESISTOR	5.6K 5% 1/6W		R 855 QRD161J-471	CARBON RESISTOR 470 5% 1/6W
R 205	QRD161J-122	CARBON RESISTOR	1.2K 5% 1/6W		R 856 QRD161J-471	CARBON RESISTOR 470 5% 1/6W
R 221	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W		R 857 QRD161J-471	CARBON RESISTOR 470 5% 1/6W
R 241	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W		R 858 QRD161J-471	CARBON RESISTOR 470 5% 1/6W
R 242	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W		R 859 QRD161J-473	CARBON RESISTOR 47K 5% 1/6W
R 243	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W		R 860 QRD161J-473	CARBON RESISTOR 47K 5% 1/6W
R 244	QRD167J-332	CARBON RESISTOR	3.3K 5% 1/6W		R 861 QRD161J-203	CARBON RESISTOR 20K 5% 1/6W
R 245	QRD167J-332	CARBON RESISTOR	3.3K 5% 1/6W		R 862 QRD161J-223	CARBON RESISTOR 22K 5% 1/6W
R 246	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W		R 863 QRD161J-151	CARBON RESISTOR 150 5% 1/6W
R 247	QRD161J-153	CARBON RESISTOR	15K 5% 1/6W		R 864 QRD167J-682	CARBON RESISTOR 6.8K 5% 1/6W
R 248	QRD161J-153	CARBON RESISTOR	15K 5% 1/6W		R 865 QRD161J-123	CARBON RESISTOR 12K 5% 1/6W
R 249	QRD161J-221	CARBON RESISTOR	220 5% 1/6W		R 866 QRD161J-563	CARBON RESISTOR 56K 5% 1/6W
R 250	QRD161J-182	CARBON RESISTOR	1.8K 5% 1/6W		R 867 QRL0076-120X	FUSE RESISTOR 12 1/0N
R 251	QRD161J-151	CARBON RESISTOR	150 5% 1/6W		R 868 QRD161J-472	CARBON RESISTOR 220 5% 1/6W
R 252	QRD161J-472	CARBON RESISTOR	4.7K 5% 1/6W		R 869 QRD161J-221	CARBON RESISTOR 220 5% 1/6W
R 253	QRD161J-182	CARBON RESISTOR	1.8K 5% 1/6W		R 870 QRD161J-822	CARBON RESISTOR 8.2K 5% 1/6W
R 254	QRD161J-472	CARBON RESISTOR	4.7K 5% 1/6W		R 871 QRD167J-682	CARBON RESISTOR 6.8K 5% 1/6W
R 255	QRD167J-332	CARBON RESISTOR	3.3K 5% 1/6W		R 872 QRD167J-332	CARBON RESISTOR 3.3K 5% 1/6W
R 257	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W		VR121 QUPA603-10-A	SEMI.V.RESISTOR
R 258	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W		VR141 QUPA603-502AZM	SEMI.V.RESISTOR
R 301	QRD161J-221	CARBON RESISTOR	220 5% 1/6W		VR142 QUPA603-50-A	SEMI.V.RESISTOR
R 302	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W		VR221 QUPA603-10-A	SEMI.V.RESISTOR
R 303	QRD161J-221	CARBON RESISTOR	220 5% 1/6W		VR241 QUPA603-50-AZM	SEMI.V.RESISTOR
R 305	QRD161J-473	CARBON RESISTOR	4.7K 5% 1/6W		VR242 QUPA603-502AZM	SEMI.V.RESISTOR
R 306	QRD161J-225	CARBON RESISTOR	2.2M 5% 1/6W		VR851 QUPA603-103M	SEMI.V.RESISTOR
R 307	QRD161J-121	CARBON RESISTOR	120 5% 1/6W			
R 308	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W			
R 321	QRD161J-273	CARBON RESISTOR	27K 5% 1/6W			
R 322	QRD161J-273	CARBON RESISTOR	27K 5% 1/6W			
R 323	QRD0077-150X	F RESISTOR	15 1/0W			
R 324	QRD161J-3R3	CARBON RESISTOR	3.3 5% 1/6W			
R 325	QRD161J-221	CARBON RESISTOR	220 5% 1/6W			
R 326	QRD161J-472	CARBON RESISTOR	4.7K 5% 1/6W			
R 327	QRD161J-472	CARBON RESISTOR	4.7K 5% 1/6W			
R 328	QRD161J-152	CARBON RESISTOR	1.5K 5% 1/6W			
R 329	QRD161J-223	CARBON RESISTOR	22K 5% 1/6W			
R 330	QRD161J-152	CARBON RESISTOR	1.5K 5% 1/6W			
R 331	QRD161J-223	CARBON RESISTOR	22K 5% 1/6W			
R 332	QRD161J-181	CARBON RESISTOR	180 5% 1/6W			
R 333	QRD161J-181	CARBON RESISTOR	180 5% 1/6W			

■ CD Amplifier Board

BLOCK NO. 03111111

A	REF.	PART'S NO.	PART'S NAME	REMARKS	SUFFIX	A	REF.	PART'S NO.	PART'S NAME	REMARKS	SUFFIX
C 501	QCBBIHK-821Y	C.CAPACITOR	820PF 10% 50V			CN710	VMC0163-R10	CONNECTOR	TO MICON		
C 503	QCVB1CN-103Y	C.CAPACITOR	.010MF 30% 16V			IC501	TAB191F	IC	SERVOLSI		
C 504	QET41CM-106	E.CAPACITOR	10MF 20% 16V			IC502	BA6298FP	IC	POWER DRIVER		
C 511	QCSB1HJ-3R9	C.CAPACITOR	3.9PF 10% 50V			IC601	TC9284AF	IC	1 CHIP PROCESE		
C 512	QCS11HJ-270	C.CAPACITOR	27PF 5% 50V			Q 501	2SA952(CL,K)	TRANSISTOR			
C 513	QFN41HJ-107ZM	M.CAPACITOR	.10MF 5% 50V			Q 581	2SA952(CL,K)	TRANSISTOR			
C 514	QFLC1HJ-473ZM	M.CAPACITOR	4700PF 5% 50V			Q 591	2SA1309(FRS)	TRANSISTOR	5V REGULATOR		
C 521	QCBB1HK-331Y	C.CAPACITOR	330PF 10% 50V			R 501	QRD161J-124	CARBON RESISTOR	120K 5% 1/6W		
C 522	QFV81HJ-154	FILM CAPACITOR	.04MF 5% 50V			R 502	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W		
C 523	QEP1EM-452ZM	NP-E.CAPACITOR	.15MF 5% 50V			R 504	QRD161J-202	CARBON RESISTOR	2.0K 5% 1/6W		
C 524	QETC1AM-336ZM	E.CAPACITOR	4.7MF 20% 25V			R 505	QRD161J-100	CARBON RESISTOR	10.5K 5% 1/6W		
C 529	QETC1AM-822Y	C.CAPACITOR	33MF 20% 10V			R 506	QRD161J-101	CARBON RESISTOR	100 5% 1/6W		
C 531	QCVB1CM-822Y	C.CAPACITOR	8200PF 20% 16V			R 507	QRD161J-120	CARBON RESISTOR	12.5% 1/6W		
C 541	QCBB1HK-101Y	C.CAPACITOR	100PF 10% 50V			R 511	QRD161J-183	CARBON RESISTOR	18K 5% 1/6W		
C 542	QFLC1HJ-103ZM	M.CAPACITOR	.010MF 5% 50V			R 512	QRD161J-192	CARBON RESISTOR	3.9K 5% 1/6W		
C 543	QFLC1HJ-393ZM	NP-E.CAPACITOR	1.0MF 20% 50V			R 513	QRD167J-32	CARBON RESISTOR	3.3K 5% 1/6W		
C 545	QEN61HM-105Z	M.CAPACITOR	.022MF 5% 50V			R 514	QRD161J-472	CARBON RESISTOR	4.7K 5% 1/6W		
C 546	QFLC1HJ-223ZM	M.CAPACITOR	.022MF 5% 50V			R 515	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W		
C 561	QET41AM-476	E.CAPACITOR	4.7MF 20% 10V			R 516	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W		
C 562	QET41HM-475	E.CAPACITOR	4.7MF 20% 50V			R 517	QRD161J-702	CARBON RESISTOR	2.0K 5% 1/6W		
C 581	QET41AM-477	E.CAPACITOR	470MF 20% 10V			R 518	QRD161J-335YT	CARBON RESISTOR	3.3M 5% 1/6W		
C 582	QEKA1CM-476	E.CAPACITOR	4.7MF 20% 16V			R 521	QRD161J-154	CARBON RESISTOR	150K 5% 1/6W		
C 591	VCP0012-105Z	C.CAPACITOR				R 522	QRD161J-392	CARBON RESISTOR	3.9K 5% 1/6W		
C 592	VCP0012-105Z	C.CAPACITOR				R 523	QRD161J-472	CARBON RESISTOR	4.7K 5% 1/6W		
C 593	QC11EM-104V	C.CAPACITOR				R 524	QRD161J-331	CARBON RESISTOR	330 5% 1/6W		
C 599	QEK61AM-107ZM	E.CAPACITOR	100MF 20% 10V			R 525	QRD161J-472	CARBON RESISTOR	4.7K 5% 1/6W		
C 601	QCS11HJ-220	C.CAPACITOR	FOR CRYSTAL			R 529	QRD167J-502	CARBON RESISTOR	5.6K 5% 1/6W		
C 602	QCS11HJ-220	C.CAPACITOR	FOR CRYSTAL			R 531	QRD161J-473	CARBON RESISTOR	4.7K 5% 1/6W		
C 603	QFV41HJ-104ZM	FILM CAPACITOR	-10MF 5% 50V			R 532	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W		
C 604	QC11EM-104V	C.CAPACITOR	-10MF 20% 25V			R 533	QRD161J-153	CARBON RESISTOR	15K 5% 1/6W		
C 605	QC11CN-103Y	C.CAPACITOR	-0.10MF 30% 16V			R 541	QRD161J-123	CARBON RESISTOR	12K 5% 1/6W		
C 606	QC11EM-473V	C.CAPACITOR	-0.10MF 20% 25V			R 542	QRD167J-352	CARBON RESISTOR	3.3K 5% 1/6W		
C 607	QFV41HJ-104ZM	FILM CAPACITOR	-10MF 5% 50V			R 543	QRD161J-473	CARBON RESISTOR	4.7K 5% 1/6W		
C 608	QC11EM-473V	C.CAPACITOR	-0.47MF 20% 25V			R 544	QRD161J-223	CARBON RESISTOR	100K 5% 1/6W		
C 609	QFV41HJ-104ZM	FILM CAPACITOR	-10MF 5% 50V			R 545	QRD161J-103	CARBON RESISTOR	15K 5% 1/6W		
C 611	QC11HJ-101	C.CAPACITOR	-10MF 5% 50V			R 548	QRD161J-153	CARBON RESISTOR	12K 5% 1/6W		
C 612	QFLC1HJ-103ZM	M.CAPACITOR	.010MF 5% 50V			R 549	QRD161J-124	CARBON RESISTOR	820 5% 1/6W		
C 613	QFLC1HJ-103ZM	M.CAPACITOR	.010MF 5% 50V			R 550	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W		
C 614	QFN41HJ-332	M.CAPACITOR	3300PF 5% 50V			R 551	QRD161J-223	CARBON RESISTOR	22K 5% 1/6W		
C 615	QFN41HJ-332	M.CAPACITOR	3300PF 5% 50V			R 552	QRD167J-562	CARBON RESISTOR	5.6K 5% 1/6W		
C 616	QC11EM-103V	C.CAPACITOR	FOR EMC			R 553	QRD161J-821	CARBON RESISTOR	820 5% 1/6W		
C 617	QFV41HJ-101	C.CAPACITOR	100PF 5% 50V			R 554	QRD161J-821	CARBON RESISTOR	820 5% 1/6W		
C 618	QFLC1HJ-103ZM	M.CAPACITOR	.010MF 5% 50V			R 555	QRD161J-392	CARBON RESISTOR	3.9K 5% 1/6W		
C 619	QFV41HJ-104ZM	FILM CAPACITOR	-10MF 5% 50V			R 556	QRD167J-562	CARBON RESISTOR	5.6K 5% 1/6W		
C 620	QFV41HJ-104ZM	FILM CAPACITOR	-10MF 5% 50V			R 561	QRD167J-562	CARBON RESISTOR	5.6K 5% 1/6W		
C 621	QFV41HJ-104ZM	FILM CAPACITOR	-10MF 5% 50V			R 562	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W		
C 622	QFV41HJ-104ZM	FILM CAPACITOR	-10MF 5% 50V			R 563	QRD161J-152	CARBON RESISTOR	1.5K 5% 1/6W		
C 623	QER401M-107	E.CAPACITOR	100MF 20% 6.3V			R 564	QRD167J-332	CARBON RESISTOR	3.3K 5% 1/6W		
C 651	QEKA1AM-107ZM	E.CAPACITOR	100MF 20% 10V			R 559	QRD161J-125	CARBON RESISTOR	1.2M 5% 1/6W		
C 652	QEKA1CM-226	E.CAPACITOR	22MF 20% 16V			R 565	QRD167J-562	CARBON RESISTOR	5.6K 5% 1/6W		
C 661	QCBB1HK-101Y	C.CAPACITOR	100PF 10% 50V			R 566	QRD161J-223	CARBON RESISTOR	27K 5% 1/6W		
C 662	QCBB1HK-101Y	C.CAPACITOR	100PF 10% 50V			R 583	QRD161J-101	CARBON RESISTOR	100 5% 1/6W		
C 663	QCS11HJ-270	C.CAPACITOR	27PF 5% 50V			R 584	QRD161J-331	CARBON RESISTOR	330 5% 1/6W		
C 671	QCBB1HK-101Y	C.CAPACITOR	100PF 10% 50V			R 591	QRD161J-473	CARBON RESISTOR	4.7K 5% 1/6W		
C 672	QCBB1HK-101Y	C.CAPACITOR	100PF 10% 50V			R 611	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W		
C 673	QCS11HJ-270	C.CAPACITOR	27PF 5% 50V			R 612	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W		
CN501	EMV7144-015R	15PIN CONNECTOR	TO PICK UP								
CN502	VMC0075-006N	CONNECTOR	TO CPU								
CN503	VMC0163-R07	CONNECTOR	TO CPU								
CN601	VMC0163-R09	CONNECTOR	TO CPU								

■ CD Operation Switch Board

BLOCK NO. 04111111				BLOCK NO. 03111111			
A	REF.	PARTS NO.	PARTS NAME	SUFFIX	REMARKS		REMARKS
R 613	QRD161J-224	CARBON RESISTOR 220K 5% 1/6W		D 731	SLZ-481C09-T6	LED	TUNER
R 614	QRD161J-473	CARBON RESISTOR 47K 5% 1/6W		D 732	SLZ-481C09-T6	LED	AUX
R 615	QRD161J-225	CARBON RESISTOR 2.2M 5% 1/6W		D 733	SLZ-481C09-T6	LED	CD
R 616	QRD161J-333	CARBON RESISTOR 33K 5% 1/6W		D 734	SLZ-481C09-T6	LED	CD
R 651	QRD161J-820	CARBON RESISTOR 82.5% 1/6W		D 735	SLZ-481C09-T6	LED	CD
R 652	QRD161J-473	CARBON RESISTOR 4.7K 5% 1/6W		D 736	SLZ-981A09-T6	LED	S.BASS
R 653	QRD161J-473	CARBON RESISTOR 47K 5% 1/6W		D 737	SLZ-981A09-T6	LED	TIMER
R 661	QRD161J-473	CARBON RESISTOR 4.7K 5% 1/6W		D 738	SLZ-981A09-T6	LED	TAPE
R 662	QRD161J-473	CARBON RESISTOR 47K 5% 1/6W		D 739	SLZ-481C09-T6	LED	TAPE
R 663	QRD161J-473	CARBON RESISTOR 4.7K 5% 1/6W		D 740	SLZ-481C09-T6	LED	TAPE
R 664	QRD161J-473	CARBON RESISTOR 47K 5% 1/6W		D 741	SLZ-190B16-T1	LED	STANDBY
R 665	QRD161J-223	CARBON RESISTOR 22K 5% 1/6W		R 802	QRD161J-271	CARBON RESISTOR 270 5% 1/6W	
R 666	QRD161J-223	CARBON RESISTOR 22K 5% 1/6W		R 803	QRD161J-820	CARBON RESISTOR 82.5% 1/6W	
R 671	QRD161J-473	CARBON RESISTOR 4.7K 5% 1/6W		R 807	QRD161J-102	CARBON RESISTOR 1.0K 5% 1/6W	
R 672	QRD161J-473	CARBON RESISTOR 47K 5% 1/6W		R 808	QRD161J-102	CARBON RESISTOR 1.0K 5% 1/6W	
R 673	QRD161J-473	CARBON RESISTOR 4.7K 5% 1/6W		R 809	QRD161J-122	CARBON RESISTOR 1.2K 5% 1/6W	
R 674	QRD161J-473	CARBON RESISTOR 47K 5% 1/6W		R 810	QRD161J-152	CARBON RESISTOR 1.5K 5% 1/6W	
R 675	QRD161J-223	CARBON RESISTOR 22K 5% 1/6W		R 811	QRD161J-222	CARBON RESISTOR 2.2K 5% 1/6W	
R 676	QRD161J-223	CARBON RESISTOR 22K 5% 1/6W		R 812	QRD161J-272	CARBON RESISTOR 2.7K 5% 1/6W	
V501	QV23223-154A2	V.RESISTOR	TR OFFSET ADJ	R 813	QRD161J-392	CARBON RESISTOR 3.9K 5% 1/6W	
X 601	CSA16.93MMXZ040T	CERA LOCK	16.9344MHz	R 814	QRD161J-562	CARBON RESISTOR 5.6K 5% 1/6W	
				R 815	QRD161J-103	CARBON RESISTOR 10K 5% 1/6W	
				R 816	QRD161J-102	CARBON RESISTOR 1.0K 5% 1/6W	
				R 817	QRD161J-122	CARBON RESISTOR 1.2K 5% 1/6W	
				R 818	QRD161J-152	CARBON RESISTOR 1.5K 5% 1/6W	
				R 819	QRD161J-222	CARBON RESISTOR 2.2K 5% 1/6W	
				R 820	QRD161J-272	CARBON RESISTOR 2.7K 5% 1/6W	
				R 821	QRD161J-392	CARBON RESISTOR 3.9K 5% 1/6W	
				R 822	QRD161J-102	CARBON RESISTOR 1.0K 5% 1/6W	
				R 823	QRD161J-121	CARBON RESISTOR 120 5% 1/6W	
				R 824	QRD161J-102	CARBON RESISTOR 1.0K 5% 1/6W	
				R 825	QRD161J-122	CARBON RESISTOR 1.2K 5% 1/6W	
				R 826	QRD161J-152	CARBON RESISTOR 1.5K 5% 1/6W	
				R 827	QRD161J-222	CARBON RESISTOR 2.2K 5% 1/6W	
				R 828	QRD161J-272	CARBON RESISTOR 2.7K 5% 1/6W	
				R 829	QRD161J-392	CARBON RESISTOR 3.9K 5% 1/6W	
				R 830	QRD167J-562	CARBON RESISTOR 5.6K 5% 1/6W	
				R 831	QRD161J-103	CARBON RESISTOR 10K 5% 1/6W	
				R 832	QRD161J-122	CARBON RESISTOR 1.0K 5% 1/6W	
				R 833	QRD161J-102	CARBON RESISTOR 1.0K 5% 1/6W	
				R 834	QW124-5-0Y	BUS WIRE	
				S 701	QSQA1A11-V04Z	TACT SWITCH	TUNER
				S 702	QSQA1A11-V04Z	TACT SWITCH	UP
				S 703	QSQA1A11-V04Z	TACT SWITCH	AUX
				S 704	QSQA1A11-V04Z	TACT SWITCH	PLAY/PAUSE
				S 705	QSQA1A11-V04Z	TACT SWITCH	STOP/CLEAR
				S 706	QSQA1A11-V04Z	TACT SWITCH	TIMER
				S 707	QSQA1A11-V04Z	TACT SWITCH	S.BASS
				S 708	QSQA1A11-V04Z	TACT SWITCH	CLOCK
				S 709	QSQA1A11-V04Z	TACT SWITCH	_SOUND
				S 710	QSQA1A11-V04Z	TACT SWITCH	VOL.DOWN
				S 711	QSQA1A11-V04Z	TACT SWITCH	VOL.UP
				S 712	QSQA1A11-V04Z	TACT SWITCH	ENTER
				S 713	QSQA1A11-V04Z	TACT SWITCH	PRESET
				S 714	QSQA1A11-V04Z	TACT SWITCH	DOWN

System Microcomputer Board

A. REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX	BLOCK NO. 05	BLOCK NO. 04	BLOCK NO. 03	BLOCK NO. 02	BLOCK NO. 01	SUFFIX	REMARKS	PARTS NAME	PARTS NO.	A. REF.
S 715	GSQ1A11-V04Z	TACT SWITCH	FF		C 1 VBP4M3B-005	B.PASS FILTER				C 1 QCS11HJ-200	C.CAPACITOR	20PF 5% 50V		BP 1
S 716	GSQ1A11-V04Z	TACT SWITCH	REW		C 2 QCB81HK-102Y	C.CAPACITOR	1000PF 10% 50V			C 3 QCS11HJ-100	C.CAPACITOR	10PF 5% 50V		
S 717	GSQ1A11-V04Z	TACT SWITCH	F.PLAY		C 4 QCS81HK-100	C.CAPACITOR	10PF 5% 50V			C 5 QCSB81HK-4R7Y	C.CAPACITOR	4.7PF 10% 50V		
S 718	GSQ1A11-V04Z	TACT SWITCH	STOP		C 6 QCVB1CN-103Y	C.CAPACITOR	.010MF 30% 16V			C 7 QCS11HJ-200	C.CAPACITOR	.010MF 30% 16V		
S 719	GSQ1A11-V04Z	TACT SWITCH	R.PLAY		C 8 QCVB1CN-103Y	C.CAPACITOR	.010MF 30% 16V			C 9 QCSB81HK-2R2Y	C.CAPACITOR	2.2PF 10% 50V		
S 720	GSQ1A11-V04Z	TACT SWITCH	DOLBY		C 10 QCSB81HK-2R2Y	C.CAPACITOR	.022MF 20% 25V			C 11 QCC11EM-223Y	C.CAPACITOR	1000PF 10% 50V		
S 721	GSQ1A11-V04Z	TACT SWITCH	REV MODE		C 12 QCSB81HK-102Y	C.CAPACITOR	.010MF 30% 16V			C 13 QCC11EM-223Y	C.CAPACITOR	.010MF 30% 16V		
S 722	GSQ1A11-V04Z	TACT SWITCH	REC MODE		C 14 QCVB1CN-103Y	C.CAPACITOR	.010MF 30% 16V			C 15 QCVB1CN-103Y	C.CAPACITOR	.010MF 30% 16V		
S 723	GSQ1A11-V04Z	TACT SWITCH	CD SYNCRO		C 16 QCVB1CN-103Y	C.CAPACITOR	.010MF 30% 16V			C 17 QCVB1CN-103Y	C.CAPACITOR	.010MF 30% 16V		
S 724	GSQ1A11-V04Z	TACT SWITCH	POWER		C 18 QCVB1CN-103Y	C.CAPACITOR	.010MF 30% 16V			C 19 QCC11EM-473Y	C.CAPACITOR	.010MF 30% 16V		
S 725	GSQ1A11-V04Z	TACT SWITCH	OPEN/CLOSE		C 20 QCC11EM-473Y	C.CAPACITOR	.047MF 20% 25V			C 21 QCC11EM-473Y	C.CAPACITOR	.047MF 20% 25V		
					C 22 QCC11EM-473Y	C.CAPACITOR	.047MF 20% 25V			C 23 QCSB81HK-2R7Y	C.CAPACITOR	2.7PF 10% 50V		
					C 24 QCSB81HK-102Y	C.CAPACITOR	1000PF 10% 50V			C 25 QCSB81HK-102Y	C.CAPACITOR	1000PF 10% 50V		
					C 26 QCVB1CN-103Y	C.CAPACITOR	.010MF 30% 16V			C 27 QCVB1CN-103Y	C.CAPACITOR	.010MF 30% 16V		
					C 28 QCB81HK-102Y	C.CAPACITOR	1000PF 10% 50V			C 29 QEK61AM-107ZM	E.CAPACITOR	.047MF 20% 10V		
					C 30 QEK61AM-107ZM	E.CAPACITOR	.010MF 30% 16V			C 31 QCVB1CN-103Y	C.CAPACITOR	10MF 20% 16V		
					C 32 QCB81HK-102Y	C.CAPACITOR	1000PF 10% 50V			C 33 QEK61AM-107ZM	E.CAPACITOR	.047MF 20% 25V		
					C 34 QEK61AM-107ZM	E.CAPACITOR	.010MF 30% 16V			C 35 QCVB1CN-103Y	C.CAPACITOR	.047MF 20% 25V		
					C 36 QEK61CM-106	E.CAPACITOR	10MF 20% 16V			C 37 QCVB1CN-103Y	C.CAPACITOR	.010MF 30% 16V		
					C 38 QEK61CM-106	E.CAPACITOR	10MF 20% 16V			C 38 QCC11EM-473Y	C.CAPACITOR	.047MF 20% 25V		
					C 39 QEK61CM-106	E.CAPACITOR	.010MF 30% 16V			C 39 QCC11EM-473Y	C.CAPACITOR	.047MF 20% 25V		
					C 40 QEK61CM-106	E.CAPACITOR	.010MF 20% 16V			C 40 QEK61CM-106	E.CAPACITOR	.047MF 20% 25V		
					C 41 QEK61HM-104	E.CAPACITOR	.033MF 20% 50V			C 41 QEK61HM-104	E.CAPACITOR	.047MF 20% 50V		
					C 42 QEK61HM-104	E.CAPACITOR	.47MF 20% 50V			C 42 QEK61HM-104	E.CAPACITOR	.47MF 20% 50V		
					C 43 QEK61HM-335ZM	E.CAPACITOR	3.3MF 20% 50V			C 43 QEK61HM-335ZM	E.CAPACITOR	3.3MF 20% 50V		
					C 44 CS11HJ-680	C.CAPACITOR	.68PF 5% 50V			C 44 CS11HJ-680	C.CAPACITOR	.68PF 5% 50V		
					C 45 QEK41CM-106	E.CAPACITOR	1.0MF 20% 16V			C 45 QEK41CM-106	E.CAPACITOR	1.0MF 20% 16V		
					C 46 QCC31EM-333ZY	C.CAPACITOR	.033MF 20% 25V			C 46 QCC31EM-333ZY	C.CAPACITOR	.033MF 20% 25V		
					C 47 QCB81HK-331Y	C.CAPACITOR	330PF 10% 50V			C 47 QCB81HK-331Y	C.CAPACITOR	330PF 10% 50V		
					C 48 QCT30UJ-120Y	C.CAPACITOR	1.2PF 5% 50V			C 48 QCT30UJ-120Y	C.CAPACITOR	1.2PF 5% 50V		
					C 49 QCC31EM-153ZY	C.CAPACITOR	.015MF 20% 25V			C 49 QCC31EM-153ZY	C.CAPACITOR	.015MF 20% 25V		
					C 50 QEK61CM-106	E.CAPACITOR	.015MF 20% 50V			C 50 QEK61CM-106	E.CAPACITOR	.015MF 20% 50V		
					C 51 QEK41HM-105	E.CAPACITOR	1.0MF 20% 50V			C 51 QEK41HM-105	E.CAPACITOR	1.0MF 20% 50V		
					C 52 QEK41HM-105	E.CAPACITOR	1.0MF 20% 50V			C 52 QEK41HM-105	E.CAPACITOR	1.0MF 20% 50V		
					C 60 QCB81HK-102Y	C.CAPACITOR	1000PF 10% 50V			C 60 QCB81HK-102Y	C.CAPACITOR	1000PF 10% 50V		
					C 61 QEK61AM-107ZM	E.CAPACITOR	1000PF 20% 10V			C 61 QEK61AM-107ZM	E.CAPACITOR	1000PF 20% 10V		
					C 62 QCS11HJ-270	C.CAPACITOR	.27PF 5% 50V			C 62 QCS11HJ-270	C.CAPACITOR	.27PF 5% 50V		
					C 64 QCS11HJ-150	C.CAPACITOR	.15PF 5% 50V			C 64 QCS11HJ-150	C.CAPACITOR	.15PF 5% 50V		
					C 65 QCS11HJ-680	C.CAPACITOR	.68PF 5% 50V			C 65 QCS11HJ-680	C.CAPACITOR	.68PF 5% 50V		
					C 69 QEK41HM-105	E.CAPACITOR	1.0MF 20% 50V			C 69 QEK41HM-105	E.CAPACITOR	1.0MF 20% 50V		
					C 70 QCB81CM-222Y	C.CAPACITOR	2200PF 20% 16V			C 70 QCB81CM-222Y	C.CAPACITOR	2200PF 20% 16V		
					C 71 QEK61HM-335ZN	E.CAPACITOR	3.3MF 20% 50V			C 71 QEK61HM-335ZN	E.CAPACITOR	3.3MF 20% 50V		
					C 72 QCB81HK-102Y	C.CAPACITOR	1000PF 10% 50V			C 72 QCB81HK-102Y	C.CAPACITOR	1000PF 10% 50V		
					C 80 QCT30UJ-8R2Y	C.CAPACITOR	8.2PF 5% 50V			C 80 QCT30UJ-8R2Y	C.CAPACITOR	8.2PF 5% 50V		
					C 81 QCY31HK-122Z	C.CAPACITOR	1200PF 10% 50V			C 81 QCY31HK-122Z	C.CAPACITOR	1200PF 10% 50V		
					C 82 QCC11EM-473Y	C.CAPACITOR	.047MF 20% 25V			C 82 QCC11EM-473Y	C.CAPACITOR	.047MF 20% 25V		
					C 83 QCVB1CN-103Y	C.CAPACITOR	.010MF 30% 16V			C 83 QCVB1CN-103Y	C.CAPACITOR	.010MF 30% 16V		
					C 84 QCVB1CN-103Y	C.CAPACITOR	.010MF 30% 16V			C 84 QCVB1CN-103Y	C.CAPACITOR	.010MF 30% 16V		

A	REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX	BLOCK NO. 05111111	BLOCK NO. 05111111	SUFFIX	REMARKS	PARTS NAME	PARTS NO.	REF.
C	86	QCC11EM-473V	C.CAPACITOR	.067MF 20% 25V		D	2	SVC203SPA-AB-AL	VARI CAP			
C	90	QC31HK-682Z	C.CAPACITOR	.6800PF 10% 50V		D	3	I55133	SI DIODE			
C	91	QC31EM-473V	C.CAPACITOR	.067MF 20% 25V		D	4	I55133	SI DIODE			
C	92	QCBB1HK-101Y	C.CAPACITOR	100PF 10% 50V		D	5	I55133	SI DIODE			
C	93	QCS11HJ-100	C.CAPACITOR	10PF 5% 50V		D	6	I55133	SI DIODE			
C	94	QCT300J-120Y	C.CAPACITOR	12PF 5% 50V		D	11	I55133	SI DIODE			
C	96	QCSB1HK-8R2Y	C.CAPACITOR	8.2PF 10% 50V		D	14	I55133	SI DIODE			
C	97	QCSB1HK-6Y	C.CAPACITOR	6.8PF 10% 50V		D	15	I55133	SI DIODE			
C	98	QCSB1UM-1R8Y	C.CAPACITOR	1.8PF 20% 50V		D	20	SVC244-AA	VARI CAP			
C	99	QFLC1HJ-104ZM	M.CAPACITOR	.10MF 5% 50V		D	21	SVC244-AA	VARI CAP			
C	701	VCR0020-002	C.NETWORK			D	701	I55133	SI DIODE			
C	702	QCS11HJ-220	C.CAPACITOR	22PF 5% 50V		D	702	I55133	SI DIODE			
C	703	QCS11HJ-220	C.CAPACITOR	22PF 5% 50V		D	703	I55133	SI DIODE			
C	704	QCS11HJ-470	C.CAPACITOR	4.7PF 5% 50V		D	704	I55133	SI DIODE			
C	705	QCS11HJ-470	C.CAPACITOR	4.7PF 5% 50V		D	705	I55133	SI DIODE			
C	706	QCS11HJ-330	C.CAPACITOR	33PF 5% 50V		D	706	MT28-2JB	ZENER DIODE	US6V		
C	707	QCS11HJ-330	C.CAPACITOR	33PF 5% 50V		D	707	MT28-6JB	ZENER DIODE	BACK UP		
C	708	QCBB1HK-102Y	C.CAPACITOR	1000PF 10% 50V		D	721	SRZ-932C-23-T1	LED	SEKIGAI		
C	709	QCBB1HK-151Y	C.CAPACITOR	150PF 10% 50V		DM301	I55133	SI DIODE				
C	710	QCFB1HZ-104Y	C.CAPACITOR	.10MF +80% -20%		DM302	I55133	SI DIODE				
C	711	QEKA1AM-102ZM	E.CAPACITOR	100MF 20% 10V		IC	1	TA2057N	IC			
C	712	QEKA1CM-106	E.CAPACITOR	10MF 20% 16V		IC	2	LC27131	IC			
C	713	QEKA1HM-105	E.CAPACITOR	1.0MF 20% 50V		IC	3	TCT4HC00AAPP	IC			
C	714	QETM0M-228	E.CAPACITOR	2200MF 20% 6.3V		IC	4	TA7358P	IC			
C	715	QCBB1HK-102Y	C.CAPACITOR	1000PF 10% 50V		ICM31	VC5580L	IC				
C	717	QEKA1CM-76	E.CAPACITOR	4.7MF 20% 16V		IC701	MN71603JJP1	IC				
C	718	QEKA1CM-106	E.CAPACITOR	10MF 20% 16V		IC702	UPC78L06J	IC				
C	719	QFV41HJ-104ZM	FIL CAPACITOR	.10MF 5% 50V		IC703	SBX1790-52	REMOCON SENSOR				
C	720	QCBB1HK-102Y	C.CAPACITOR	1000PF 10% 50V		J	1	EMB10YV-401K	ANT TERMINAL			
C	722	QEKA1HM-105	E.CAPACITOR	1.0MF 20% 50V		JM301	VMB104C-001	JACK				
C	723	QCBB1HK-102Y	C.CAPACITOR	1000PF 10% 50V		L	1	VQFB20-019	OSC COIL	FM OSC		
C	724	QEKA1HM-105	E.CAPACITOR	1.0MF 20% 50V		L	2	VQC1505-002	RF COIL	FM RF		
C	725	QCVB1CN-103Y	C.CAPACITOR	.010MF 30% 16V		L	3	VQG0098-201	COIL BLOCK	MW RF		
C	726	QCVB1CN-103Y	CERAMIC FILTER	.010MF 30% 16V		L	4	VQGP0018-4R7	INDUCTOR			
CF	2	VCF213B-108Z	CERAMIC FILTER			L	5	VQGP0018-220	INDUCTOR			
CF	3	VCF122-115Z	CERAMIC FILTER			L	6	VQSTU01-801	OSC COIL	SW1 OSC		
CF	4	CSB4-6F29	CERA. LOCK			L	7	VQR7002-501	RF COIL	SW2 RF		
CM301	QEKA1CM-226	E.CAPA. I.M	22MF 20% 16V		L	8	VQR7002-501	RF COIL	SW2 OSC			
CM302	QEKA1CM-226	E.CAPA. I.M	22MF 20% 16V		L	12	VQ3047-6	COIL				
CM303	QCBB1HK-221Y	C.CAPACITOR	220PF 10% 50V		L	15	VQ3047-6	COIL				
CM304	QEK61HM-335ZN	E.CAPACITOR	3.3MF 20% 50V		L	701	VQ7004-8-009	INDUCTOR				
CM305	QEKA1HM-474	E.CAPACITOR	.47MF 20% 50V		L	702	VAFP0018-221	INDUCTOR				
CM306	QEKA1CM-336	E.CAPACITOR	33MF 20% 16V		L	703	VQGP0018-4R7	INDUCTOR				
CM307	QEKA1HM-335ZN	E.CAPACITOR	3.3MF 20% 50V		L	704	VQZ0048-009	INDUCTOR				
CN701	VMC0163-R07	CONNECTOR	TO MECHA		LCD01	VGL1144-001	LCD					
CN702	VMCO163-R10	CONNECTOR	TO SW		PLA31	VGT0001-053	LAMP					
CN703	VMCO163-R07	CONNECTOR	TO CD ROADING		PLA32	VGZ0001-053	TRANSISTOR					
CN704	VMCO289-P03	CONNECTOR	TO ITIOSHI		Q	1	2SD2668(0)	TRANSISTOR				
CN705	VMCO163-R09	CONNECTOR	TO CD CTL		Q	4	DTM114YS	TRANSISTOR				
CN706	VMCO14-P16	CONNECTOR	TO AMP1		Q	5	2SA1175	TRANSISTOR				
CN707	VMCO163-R07	CONNECTOR	TO CD AMP		Q	12	2SD1362	TRANSISTOR				
CN708	VMCC314-P08	CONNECTOR	TO AMP2		Q	13	2SC668(0)	TRANSISTOR				
CN709	VMCO289-S03	CONNECTOR	TO MICON		Q	14	2SA1175	TRANSISTOR				
D	1	SVC03SPA-AB-AL	VARI CAP		Q	15	2SA1175	TRANSISTOR				
D	1	SVC03SPA-AB-AL	VARI CAP		Q	21	DTA14TS	TRANSISTOR				

BLOCK NO. 05111111				BLOCK NO. 05111111			
REF.	PARTS NO.	PARTS NAME	REMARKS	REF.	PARTS NO.	PARTS NAME	REMARKS
A			SUFFIX	A			SUFFIX
Q 22	2SC2668(0)	TRANSISTOR		R 45	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W
Q 24	2SD1302	TRANSISTOR		R 46	QRD161J-473	CARBON RESISTOR	47K 5% 1/6W
Q 25	2SA1175	TRANSISTOR		R 47	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W
Q 26	DTA114TS	TRANSISTOR		R 50	QRD161J-102	CARBON RESISTOR	4.7K 5% 1/6W
Q 27	2SC2668(0)	TRANSISTOR		R 52	QRD161J-772	CARBON RESISTOR	4.7K 5% 1/6W
Q 28	2SA1175	TRANSISTOR		R 54	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W
Q 6 701	2SC2668(0)	TRANSISTOR		R 55	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W
Q 702	2SC2668(0)	TRANSISTOR		R 56	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W
Q 703	DTC114TSTP	TRANSISTOR		R 57	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W
Q 704	DTA114ES	TRANSISTOR		R 58	QRD161J-183	CARBON RESISTOR	1.8K 5% 1/6W
Q 705	DTC114YS	TRANSISTOR		R 59	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W
Q 706	2SC2785	TRANSISTOR		R 60	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W
Q 708	2SC2785	TRANSISTOR		R 66	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W
Q 709	DTC114ES	TRANSISTOR	ITIOSHI SEKIGAI DIGI. TRANSISTOR STANDBY	R 67	QRD161J-473	CARBON RESISTOR	4.7K 5% 1/6W
Q 710	DTC114S	DIGI. TRANSISTOR	A.H.B. TIMER1	R 69	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W
Q 711	DTC114ES	DIGI. TRANSISTOR		R 77	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W
Q 712	DTC114TSTP	TRANSISTOR		R 81	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W
Q 714	DTC114TS	TRANSISTOR		R 82	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W
QM301	2SC2785	TRANSISTOR		R 83	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W
QM302	2SC2785	TRANSISTOR		R 84	QRD161J-223	CARBON RESISTOR	2.2K 5% 1/6W
R 1	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W	R 85	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W
R 2	QRD161J-473	CARBON RESISTOR	47K 5% 1/6W	R 86	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W
R 3	QRD161J-4R7	CARBON RESISTOR	4.7 5% 1/6W	R 90	QRD167J-332	CARBON RESISTOR	3.3K 5% 1/6W
R 7	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W	R 91	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W
R 8	QRD161J-821	CARBON RESISTOR	820 5% 1/6W	R 92	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W
R 9	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	R 96	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W
R 10	QRD161J-101	CARBON RESISTOR	100 5% 1/6W	R 97	QRD161J-473	CARBON RESISTOR	47K 5% 1/6W
R 11	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W	R 98	QRD161J-822	CARBON RESISTOR	8.2K 5% 1/6W
R 12	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	R 99	QRD167J-332	CARBON RESISTOR	3.3K 5% 1/6W
R 13	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	R 701	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W
R 14	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	R 702	QRD161J-224	CARBON RESISTOR	220K 5% 1/6W
R 15	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	R 703	QRD161J-681	CARBON RESISTOR	680 5% 1/6W
R 17	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	R 704	QRD161J-822	CARBON RESISTOR	8.2K 5% 1/6W
R 18	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	R 705	QRD161J-822	CARBON RESISTOR	8.2K 5% 1/6W
R 20	QRD161J-331	CARBON RESISTOR	330 5% 1/6W	R 706	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W
R 21	QRD161J-474	CARBON RESISTOR	470 5% 1/6W	R 707	QRD161J-331	CARBON RESISTOR	330 5% 1/6W
R 22	QRD161J-331	CARBON RESISTOR	330 5% 1/6W	R 708	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W
R 23	QRD161J-100	CARBON RESISTOR	10 5% 1/6W	R 709	QRD161J-472	CARBON RESISTOR	4.7K 5% 1/6W
R 24	QRD161J-271	CARBON RESISTOR	270 5% 1/6W	R 710	QRD167J-562	CARBON RESISTOR	5.6K 5% 1/6W
R 25	QRD161J-333	CARBON RESISTOR	33K 5% 1/6W	R 711	QRD161J-473	CARBON RESISTOR	4.7K 5% 1/6W
R 26	QRD161J-393	CARBON RESISTOR	39K 5% 1/6W	R 712	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W
R 27	QRD161J-223	CARBON RESISTOR	22K 5% 1/6W	R 714	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W
R 28	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	R 715	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W
R 30	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	R 716	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W
R 31	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	R 717	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W
R 32	QRD161J-560	CARBON RESISTOR	56 5% 1/6W	R 718	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W
R 33	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	R 719	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W
R 34	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	R 720	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W
R 35	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	R 721	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W
R 36	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W	R 722	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W
R 37	QRD161J-822	CARBON RESISTOR	8.2K 5% 1/6W	R 723	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W
R 38	QRD161J-392	CARBON RESISTOR	3.9K 5% 1/6W	R 724	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W
R 39	QRD161J-392	CARBON RESISTOR	3.9K 5% 1/6W	R 725	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W
R 43	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	R 726	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W
R 44	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W	R 727	QRD161J-913	CARBON RESISTOR	91K 5% 1/6W

BLOCK NO. 05111111				BLOCK NO. 05111111					
A	REF.	PARTS NO.	PART'S NAME	SUFFIX	REMARKS	PARTS NO.	PART'S NAME	REMARKS	SUFFIX
R	728	QRD161J-473	CARBON RESISTOR	4.7K 5% 1/6W		RM312	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W
R	729	QRD161J-683	CARBON RESISTOR	6.8K 5% 1/6W		RM313	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W
R	730	QRD161J-683	CARBON RESISTOR	6.8K 5% 1/6W		RM314	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W
R	731	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W		T	1	VQ77F12-110	IFT
R	732	QRD161J-473	CARBON RESISTOR	4.7K 5% 1/6W		T	2	VQ7TA21-107	IFT
R	733	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W		VRH3	VRH4A-6B-V03M	V-RESISTOR	20K(A)
R	734	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W		X	1	V472124-A0	CRYSTAL
R	735	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W		X	701	VCX500-002	CRYSTAL
R	736	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W		X	702	CSA4.19MG933	CERA LOCK
R	737	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W					
R	738	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W					
R	739	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W					
R	742	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W					
R	743	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W					
R	744	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W					
R	746	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W					
R	747	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W					
R	748	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W					
R	749	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W					
R	750	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W					
R	751	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W					
R	752	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W					
R	753	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W					
R	754	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W					
R	755	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W					
R	756	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W					
R	758	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W					
R	759	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W					
R	760	QRD161J-222	CARBON RESISTOR	BUP					
R	761	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W					
R	762	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W					
R	763	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W					
R	764	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W					
R	765	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W					
R	766	QRD161J-222	CARBON RESISTOR	DATA					
R	767	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W					
R	768	QRD161J-222	CARBON RESISTOR	SAFETY					
R	770	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W					
R	771	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W					
R	801	QRD161J-122	CARBON RESISTOR	1.2K 5% 1/6W					
R	804	QRD161J-391	CARBON RESISTOR	390 5% 1/6W					
R	805	QRD161J-391	CARBON RESISTOR	390 5% 1/6W					
R	M01	QRD161J-221	CARBON RESISTOR	220 5% 1/6W					
R	M02	QRD161J-154	CARBON RESISTOR	150K 5% 1/6W					
R	M03	QRD161J-154	CARBON RESISTOR	1.0K 5% 1/6W					
R	M04	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W					
R	M05	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W					
R	M06	QRD161J-564	CARBON RESISTOR	560K 5% 1/6W					
R	M07	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W					
R	M08	QRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W					
R	M09	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W					
R	M10	QRD161J-103	CARBON RESISTOR	10K 5% 1/6W					
R	M11	QRD161J-224	CARBON RESISTOR	220K 5% 1/6W					

CD Tray Loading Motor Board

BLOCK NO. 06111111				BLOCK NO. 06111111					
A	REF.	PART'S NO.	PART'S NAME	SUFFIX	REMARKS	PART'S NO.	PART'S NAME	REMARKS	SUFFIX
C	831	QEKG1CM-1072N	E.CAPACITOR		100MF 20% 16V	C	831	QEKG1CM-1072N	E.CAPACITOR
C	837	QEKG1CM-1072N	E.CAPACITOR		100MF 20% 16V	C	837	QEKG1CM-1072N	E.CAPACITOR
CN505	VM0261-R07					D	812	1SR35-100	CONN. TERMINAL DIODE
D	812	1SR35-100	CONN. TERMINAL DIODE			I	802	BA6-08A	I.C(MONO-ANA)
L	805	VQP0033-100Z	INDUCTOR			L	806	VQP0033-100Z	INDUCTOR
L	806	VQP0033-100Z	INDUCTOR			S	851	ESS1200-002	LEVER SWITCH
S	851	ESS1200-002	LEVER SWITCH						

Cassette Mechanism Board

BLOCK NO. 07111111				BLOCK NO. 07111111					
A	REF.	PART'S NO.	PART'S NAME	SUFFIX	REMARKS	PART'S NO.	PART'S NAME	REMARKS	SUFFIX
CN	1	VNC0234-T11	CONN. TERMINAL			CN	2	VNC0234-R08	CONN. TERMINAL
S	1	VSH1170-001	LEAF SWITCH			S	2	VSH1170-001	LEAF SWITCH
S	3	VSH1170-001	LEAF SWITCH			S	3	VSH1170-001	LEAF SWITCH
S	4	VSH1170-001	LEAF SWITCH			S	5	VSH1170-001	LEAF SWITCH
S	6	VKS3616-00A	CAM SWITCH			S	6	VKS3616-00A	CAM SWITCH

16. Analytic Drawing and Parts List




Fig. 16-1


■ Cassette Mechanism Parts List

BLOCK NO. M1MM □□□

△	REF.	PARTS NO.	PARTS NAME	REMARKS	QTY	SUFFIX	CLR
	A	VKS3673-00A	HEAD BLOCK	REF.45-47	1		
	B	MSI5B2LW-SA1	CAPSTAN MOTOR	REF.32,33	1		
	C	MSN5D257A-SA1	DC MOTOR	REF.24,25	1		
	1	VKS1126-00B	CHASSIS B ASS'Y		1		
	2	VKS5428-00B	T-UP REEL ASSY		1		
	3	VKW5043-001	B.T. SPRING		1		
	4	VKS3617-002	REEL		1		
	5	VKW5043-001	B.T. SPRING		1		
	6	VKS3627-001	PINCH LEVER		1		
	7	VKS2224-001	CONTROL CAM		1		
	8	VKS5454-001	ACT GEAR(2)		2		
	9	VKS5455-001	ACT GEAR(3)		1		
	10	VKS3655-002	FPC HOLDER		1		
	11	VKM3632-001	HEAD BASE		1		
	13	SDSR2004Z	SCREW		3		
	14	VKZ4708-001	SPECIAL SCREW		1		
	16	VKS5430-00CMM	FR ARM ASY		1		
	19	VKF3184-00H	FLYWHEEL(R)ASS'		1		
	20	VKF3186-00H	FLYWHEEL(L)ASS'		1		
	21	MMN-6F4RA38	D.C.MOTOR	FOR REEL	1		
	22	VKS5432-001	REEL MOT. GEAR		1		
	23	VKZ4705-101	SCREW		2		
	24	MSN-5D257A	D.C.MOTOR		1		
	25	VKS5433-001	ACT.MOTOR GEAR		1		
	26	VKZ4705-102	SCREW		2		
	27	VKP4227-00B	PINCH R.(R) ASY		1		
	28	VKP4229-00B	PINCH R.(L) ASY		1		
	29	VKW5045-003	P.R. SP.(R)	FOR PINCH (R)	1		
	30	VKW5046-003	P.R. SP.(L)	FOR PINCH (L)	1		
	31	VKY4670-001	CASSETTE SPRING		1		
	32	MSI-5B2LW	D.C.MOTOR	FOR CAPSTAN	1		
	33	VKR4364-002	MOTOR PULLEY		1		
	34	SPSP2603Z	SCREW		2		
	35	VKM3636-002	FM. BRACKET		1		
	36	VKS5327-005MM	THRUST PLATE		1		
	37	SDSF2608Z	SCREW		3		
	38	VKB3001-051	BELT		1		
	39	SDST2612Z	SCREW		1		
	40	VKS3616-00A	CAM SW UNIT	S6	1		
	41	DN6851-HI	HALL IC	IC1	1		
	42	VKS3630-001MM	IC HOLDER	IC1	1		
	44	VKS3670-001	TURN OVER GEAR		1		
	45	VKW5126-001	HEAD SPRING		1		
	46	VKZ4629-003	SPECIAL SCREW		2		
	47	VKS3671-001	HEAD MT. COVER		1		
	CN 1	VMC0234-R11	CONNECTOR		1		
	CN 2	VMC0234-R08	CONNECTOR		1		

UX – T3 A/US/U

■ Enclosure Assembly: Block No. M2




6

7

8

9

10



■ Enclosure Assembly Parts List

BLOCK NO. M2MM

A	REF.	PARTS NO.	PARTS NAME	REMARKS	QTY	SUFFIX	CLR
	A	ZCUXT3K-FB	FRONT CABINET	REF.1,14	1		
	B	ZCUXT3K-CHB	CASSETTE HOLDER		1		
	C	ZCUXT3K-CLB	CASSETTE LID		1		
1	VJG1319-001	FRONT PANEL			1		
2	VXP3680-002	PUSH BUTTON(A)			1		
3	VXP3681-002	PUSH BUTTON(B)			1		
4	VXP5281-001	PUSH KNOB(C)			1		
5	VXP5282-001	PUSH KNOB(D)		AUX/TUNER	1		
6	VXP5262-001	PUSH KNOB(E)		POWER/EJECT	1		
7	VXP5284-001	PUSH KNOB(F)		SOUND/CLOCK	1		
8	VJK4434-001	LED LENS			1		
9	VJK4435-001	LED LENS(B)			1		
10	SBSF2610Z	SCREW		FRONT+KNOB,PWB	11		
11	YH3833-003	LAMP CASE			1		
12	SBSF3008Z	SCREW		C.BASE+LCD PWB	4		
13	VYTT627-001	LCD FILTER		FOR LCD	1		
14	VJT4217-003	LCD LENS			1		
15	VYH7907-002	SUPPORT BRACKET		FOR PANEL	2		
16	SBSF3010Z	SCREW		F.PANEL+S.BKT	2		
17	VYH7913-001	CD HOLDER(L)		FOR F.PANEL	1		
18	VYH7913-002	CD HOLDER(R)		FOR F.PANEL	1		
19	VYH3840-00C	DOOR HLDER ASSY			1		
20	VKL5342-003	LOCK CAM(A)			1		
21	VKW3006-073	SPRING			1		
22	REE2000X	E.RING			1		
23	SBSF3008Z	SCREW		F.PANEL+D.HOL	4		
24	VJT2344-003	CASSETTE HOLDER			1		
25	VKY4180-001	CASSETTE SPRING			2		
26	VYH5601-001	GEAR			1		
27	VKW5154-002	DOOR SPRING			1		
28	VJT2348-001	DOOR COVER			1		
29	VJT4206-004	DOOR LENS			1		
30	VKL7293-001	EJECT SAFTY(R)			1		
31	SBSF3010Z	SCREW		FOR EJECT SAFTY	1		
32	VKW5069-002	TORSION SPRING		FOR EJECT SAFTY	1		
33	VKS3655-002	F.P.C. HOLDER			1		
34	SBST3006Z	SCREW		BIAS PWB+PWB BK	1		
35	VYH7910-001	PWB BRACKET			1		
36	SDST2606Z	SCREW		MECHAON PWB+ME-	2		
37	SBST3006Z	SCREW		REC PWB+PWB BKT	2		
38	SBST3006Z	SCREW		PLAY PWB+PWB BK	2		
39	SBST3006Z	SCREW		PLAY PWB+MECHA	1		
40	SBSF3008Z	SCREW		F.PANEL+MECHA	2		
41	SBST3006Z	SCREW		DOOR HOL+MECHA	2		
42	VYH1247-001	BOTTOM CHASSIS			1		
43	SBST4006Z	SCREW		CHASSIS+TRANS	4		
44	VYH3779-002	JACK HOLDER		FOR AC/DC	1		
45	VMA4639-002	BARRIER			1		
46	SBSF3008Z	SCREW		FUSEPWB+JACK HO	2		
47	SBSF3008Z	SCREW		CHASSIS+JACK HO	1		
48	VYH7801-002	IC HOLDER			1		
49	VYH7802-002	RADIATION			1		
50	SBST3012Z	SCREW		IC HOL+RADIATIO	3		
51	SBST3008Z	SCREW		CHASSIS+RADI.	2		
52	VYH1238-001	LOADING BASE			1		
53	MMN-6F1LB8K	MOTOR			1		
54	SPSK2640Z	MINI SCREW			2		
55	E75984-221	MOTOR PULLEY			1		
56	E75950-002	BELT			1		
57	E75985-221	GEAR(1)			1		

BLOCK NO. M2MM

REF.	PARTS NO.	PARTS NAME	REMARKS	QTY	SUFFIX	CLR
	58 E75986-221SS 59 E75987-221SS 60 E307252-331 61 E307162-331 62 E65923-003	GEAR(2) GEAR(3) CAM-PLATE LEVER TAPPING SCREW		1 1 1 1 3		
	63 VYH7787-001 64 SBSF3008Z 65 E307179-332 66 E406871-001 67 E406294-002	SPRING SCREW E.BASE ASS'Y SPRING INSULATOR		1 1 1 2 4		
	68 E60912-005SS 69 E406293-001 70 VYH3680-001 71 VYH7315-005 72 VYH7313-001	SPEED NUT SPECIAL SCREW CLAMPER PAD MAGNET		1 1 1 1 1		
	73 GBSF2606Z 74 VYH2295-001 75 SBSF3008Z 76 SBSF3008Z 77 SBSF3008Z	SCREW CLAMPER BASE SCREW SCREW SCREW	FOR CLAMPER FOR C.BASE+L.BA FOR CD PWB C.BASE+S.BKT	1 1 4 2 2		
	78 SBSF3008Z 79 VYH3764-001 80 VJT3367-001 81 E406971-221 82 VYH1240-001	SCREW CLAMPER PLATE CD FITTING JVC MARK TRAY	C.BASE+MAIN PWB	1 1 1 1 1		
	83 SBSF3008Z 84 SSST3006Z 85 SDSF3012M 86 VJG1307-003 87 SSST3008M	SCREW SCREW SCREW REAR.COVER SCREW	FOR TRAY STOPPE CHASSIS+F.PANEL REAR.COVER REAR.COVER+CHAS	2 2 5 1 5		
	88 VYN9239-M007 VYN9239-M003 89 VND4003-020 VND4003-077 90 VND4003-076	NAME PLATE NAME PLATE FUSE LABEL FUSE LABEL FUSE LABEL	F901 F901 F902	1 1 1 1 1	US,U A US,U A 1	
	91 VXL4431-001 92 SBSF3008Z 93 VYH7944-001 94 VYSA1R4-056 96 VMZ0125-001Z	VOLUME KNOB SCREW MIC PLATE SPACER FUSE CLIP	FOR MIC FOR MIC PWB FOR MIC CN708+CNA31 F902	1 1 1 1 2		
	VMZ0125-001Z VMZ0125-001Z 97 SDST2606Z 98 E406709-001 99 E70891-001	FUSE CLIP FUSE CLIP SCREW CAUTION LABEL CLASS 1 LABEL	F903 F901 DOOR HOL+MECHA	2 2 1	A,US A,US	
	F 901 QMF51N2-R80J1 QMF51E2-R50SBS F 902 QMF51E2-5R0 F 903 QMF51E2-5R0	FUSE FUSE FUSE FUSE	PRI SEC DC	1 1 1 1	US,U A	
	T 901 VTP66G2-12E VTP66T2-12F	POWER TRANS POWER TRANS		1 1	US,U A	

1

2

3

4

5

**■ Analytic Drawing
of CD Mechanism: Block No. M3**


A**B****C****D****E**

Fig. 16-3

■ CD Mechanism Assembly Parts List

BLOCK NO. M3MM

REF.	PARTS NO.	PARTS NAME	REMARKS	QTY	SUFFIX	CLR
1	EPB-002A	MECHA BASE ASSY		1		
2	OPTIMA-6S	OPTICAL PICK-UP		1		
3	E406777-001	GUIDE SHAFT		1		
4	E307746-001	CD RACK		1		
5	SDSF2006Z	SCREW	CD LACK ASSY	1		
6	EPB-003A	MECHA GEAR		1		
7	E75807-301	TURN TABLE		1		
9	SDSP2003N	SCREW		1		
10	E406783-001	DC MOTOR		1		
11	E406784-001SA	DC MOTOR ASSY		1		
12	E75832-001	SPECIAL SCREW		1		
13	EMW10190-001	PRINTED BOARD		1		
14	EMV5109-006B	CONN. TERMINAL		1		
15	ESB1100-005	LEAF SWITCH		1		
16	E407212-001	DAMPER		1		

17. Illustration of Packing and Parts List




Fig. 17-1

■ Packing Parts List

BLOCK NO. M4MM

A	REF.	PARTS NO.	PARTS NAME	REMARKS	QTY	SUFFIX	CLR
P	1	VPE3005-007	POLY BAG	INSTRUCTIONS	1		
P	2	QPGA015-03503	POLY BAG	FOR P.CORD	1		
P	3	VPE3005-042	POLY BAG	FOR AM ANT	1		
P	4	VPE3005-071	POLY BAG	FOR SET	1		
P	5	VPC9239-M101	CARTON		1		
P	6	VPH1660-001	CUSHION(UPPER)		1		
P	7	VPH1660-002	CUSHION(BOTTOM)		1		
P	8	DH404-UX-T10	SIDE CUSHION	FOR SPEAKER	1		
P	9	*****	COMPUTER LABEL		1		

18. Accessories

BLOCK NO. M5MM~~11111~~

A	REF.	PARTS NO.	PARTS NAME	REMARKS	QTY	SUFFIX	CLR
A	1	VNN9239-111M	INSTRUCTIONS		1	A,US,U	
		VNN9239-141M	INSTRUCTIONS		1	US,U	
A	2	BT-56001-1	WARRANTY CARD		1	A	
A	3	BT-56002-1	SERVICE NETWORK		1	A	
A	4	VO4062-001	CONTI.PLUG		1	US,U	
A	5	QMP7530-183	POWER CORD		1	US,U	
A		QMP25D0-183	POWER CORD		1	A	
A	6	VMZ0136-001	B.IN ANTENNA		1		
A	7	VGR0038-006	REMOCON UNIT		1		
A	8	UM-3(DJ)-2PSA	BATTERY	FOR REMOCON	1		
A	10	EQB4001-015	AM LOOP ANT	AM ANT	1		
A	11	UXT3K-SPBOX-L	SPEAKER BOX	L	1		
A	12	UXT3K-SPBOX-R	SPEAKER BOX	R	1		

JVC

VICTOR COMPANY OF JAPAN, LIMITED
AUDIO PRODUCTS DIVISION 10-1, 1-chome, Ohwatari-machi, Maebashi-city, Japan