



Service Bulletin

No.: MZ09-126

Date: November 30, 2009

Model: UD9004

Subject: Software update

Countermeasure is applicable only upon claim from the customer.

Symptom: 1) Unit does not turn on when push the POWER button twice after set the setting of "Power save mode" to "quick mode".

- 2) The unit can not connect to Ethernet with proxy condition.
- 3) When play a disk (BD-R/RE) which is recorded by SHARP BD recorder BD-HDW20, only "katakana (ex. アイウ...)" of a title recorded in BD-R/RE is not displayed.
- 4) The unit is incompatible with D-BOX motion control system.
- 5) During read TOC of the CD, the picture of the composite is distracted.
- 6) After completed "firmware update", following symptom occurs.
- a. The following sentences appear and the network cannot be connected. "Network problem. Make sure that the connection and network setting are correct".
- b. The tray cannot be opened. While pressing the open button, window displays "open/close/loading" very quickly.
- 7) The unit can not play a BD-R which TV program was recorded on by a BD recorder (DMR-BW900: Panasonic). Then unit can display the title of the disc on TOP MENU, but can not play it after choose a title.
- 8) The synchronization of the image of the wallpaper is disturbed when pushing the SOURCE button without an SD card.
- 9) A delete image is reproduced when is recorded in a BD.

Solution: The firmware has been updated.

CONFIDENTIALITY NOTICE:

Updating the firmware.

Please do not use a Proxy for updating in the Network environment! If customer uses the Proxy setting, the unit won't update the firmware properly *For update procedures, please see manual.

*Please do not turn off the Power of the unit during the update operation.

Confirmation of the version:

- 1) Press the "OPEN/CLOSE" button and open the Disc Tray.
- 2) Remove the Disc from the Tray.
- 3) Please confirm! "NO DISC" on the FL Display.
- 4) While pushing the "PLAY" and "OPEN/CLOSE" button, turn on the power of unit.
- 5) Plug in AC CORD.
- 6) The indication of "PLAY" and "PAUSE" will be displayed on FL Display.
- 7) Please confirm! "NO DISC" on the FL Display, and wait 10 seconds.
- 8) Press the buttons on the remote control in the order of "3", "2", "6" and "5".
- 9) The version of the firmware will be indicated on the FL Display.
- 10) The firmware list will also be shown on connected TV (GUI).
- 11) Push the "**UP**" button of cursor button, version of the each firmware will be indicated on the FL Display.

	Name	Version
1	Sys	Ver000102
2	B/E	Ver000110
3	F/E	Ver000107
4	SA	Ver000100 or Ver000200

	Name	Version
5	AD1	Ver000104
6	AD2	Ver000101
7	AS	Ver000200

Serial Number Range:

We will apply the above modification to production models with the following serial numbers.

*******000171 ~