




SERVICE MANUAL

VERTICAL MUSIC CENTER

MODEL X-7



SPECIFICATIONS

TUNER SECTION

FM section

Tuning range 87.5 MHz – 108 MHz

Usable sensitivity (IHF) . . . 2.5 μ V (13.2 dBf)

50 dB quieting sensitivity

MONO 5.5 μ V (20 dBf)

STEREO 55 μ V (40 dBf)

Sensitivity (\pm 40 kHz deviation)

MONO (S/N = 26 dB) . . . 1.8 μ V

STEREO (S/N = 46 dB) . . 35 μ V

Total Harmonic distortion

MONO 0.5 %

STEREO 0.8 %

Image response ratio 45 dB

Signal to noise ratio (IHF)

MONO 77 dB

STEREO 72 dB

Signal to noise ratio (DIN)

MONO 70 dB

STEREO 65 dB

Stereo separation 35 dB at 1 kHz

Frequency response \pm 1 dB, 30 Hz – 15 kHz

MW section

Tuning range 525 kHz – 1,605 kHz

Usable sensitivity (IHF) . . . 300 μ V/m

Sensitivity (S/N = 26 dB) . . 600 μ V/m

Total harmonic distortion . . 1.0 %

Image response ratio 30 dB

LW section

Tuning range 150 kHz – 350 kHz

Sensitivity (S/N = 26 dB) . . . 1 mV/m

Image response ratio 35 dB

AMPLIFIER SECTION

Power output 20 watts 8 ohms, 1 kHz,
5 % THD

Total harmonic distortion . . 0.04 % at 1 kHz at half power

Input sensitivity/impedance

MIC 1.5 mV/10K ohms

AUX 150 mV/25K ohms

Variable loudness control

(VR MAX –30 dB)

LOW 0 ~ +7 dB at 100 Hz

HIGH +7 dB at 10 kHz

TURNTABLE SECTION

Type Vertical linear tracking

Drive system Belt drive

Motor DC servo motor

Platter 30 cm (12") diameter,
Aluminium diecast alloy

Platter speed 33-1/3, 45 rpm

Wow and flutter 0.08 % Wrms

Signal to noise ratio 55 dB (IEC-B), 65 dB (DIN-B)

Tonearm

Type Liner tracking, straight, static
balance

Cartridge Dual magnet type

Tracking force 2.0 gr.

CASSETTE DECK SECTION

Type 4-track, 2-channel stereo
cassette deck

Tape speed 4.75 cm/sec (1-7/8 ips)

Head material

REC/PB Hard permalloy

ERASE Ferrite

Wow and flutter 0.06 % Wrms

Signal to noise ratio

(Weighted Metal tape)

Dolby NR out 56 dB

Dolby NR in 66 dB

Crosstalk

Between channels 35 dB

Between tracks 65 dB

Total harmonic distortion . . 1.0 %

Frequency response

Normal 30 Hz – 15,000 Hz

Special 30 Hz – 16,000 Hz

Metal 30 Hz – 17,000 Hz

GENERAL

Power consumption 110W (IEC nominal)

Dimensions (W x H x D) . . . 415 x 476 x 189 mm
(16-3/8 x 18-3/4 x 7-7/16")

Weight 13.5 kg (29.8 lbs)

Accessories T-shaped FM aerial
Black sheets 17, 30 cm (For
transparent or coloured
records)
AM loop aerial

- "Dolby" and double-D symbol are trademarks of Dolby Laboratories Licensing Corporation. Noise Reduction System manufactured under license from Dolby Laboratories Licensing Corporation.

DISASSEMBLING PROCEDURE

1. How to remove chassis unit

- 1) Remove knobs (TUNING, FUNCTION, VOLUME, TAPE SELECTOR, BASS, TREBLE, BALANCE, and remove cassette cover.
- 2) Remove four screws ① (on both sides) in Fig. 1.
- 3) Pull chassis unit rearward to separate it from the main body. Disconnect lead wire from the player unit.




Fig. 1

2. How to remove cassette mechanism assembly

- 1) Remove chassis unit.
- 2) Remove counter belt on the counter side.
- 3) Disconnect lead wires (J410, 420) of mechanism assembly from PV board.
- 4) Remove five mechanism assembly fixing screws ② (2-3 x 6).
Two of the five screws are used commonly to fix the EJECT knob.




Fig. 2

3. How to disassemble principal parts of mechanism

* In the following description, the mechanism assembly has already been removed from the chassis unit.

3-1 Disassembling of head, pinch roller, reel rest, and play idler.

- 1) Remove cassette holder. (CS ring)




Fig. 3

- 2) Remove pinch roller/panel plate. (CS ring)




Fig. 4

3) Remove reel rest (FEED, TAKE-UP), (PS washer)




Fig. 5

- 4) Remove holder (head holder). (One screw M-2.6 x 10)
- 5) Remove idler spring on the idler side.
- 6) Remove spring (for driving head base).
- 7) Remove head base.
- 8) Remove idler (PLAY IDLER).

Note 1. Take care not to lose the one steel ball between holder and head base and the three steel balls between head base and chassis base.




Fig. 6

3-2 Disassembling of flywheel and belt (MAIN, REEL, AUTO. STOP)

- 1) Remove the RECORD/PLAYBACK lever. (One screw M2.6 x 5)
- 2) Remove REEL belt and MAIN belt.
- 3) Remove flywheel. Remove AUTO. STOP belt at the same time.




Fig. 7

3-3 Disassembling of motor, assist gear, friction pulley, and auto. stop mechanism

- 1) Remove parts as described in above Item 3-2.
- 2) Remove holder L. (Two screws M3 x 5)
- 3) Remove motor. (Two screws M3 x 5, M2.6 x 5)




Fig. 8

- 4) Remove START lever. (E-ring 3φ, 1 pc)




Fig. 9

- 5) Remove assist gear. (E-ring 3, 1 pc)
- 6) Remove friction pulley.
- 7) Remove worm gear. (E-ring 2, 1 pc)
- 8) Remove AUTO. STOP cam.




Fig. 10

4. How to remove dust cover

- 1) Pull two hinge shafts.
- 2) Remove two screws from cap mounting holder.
- 3) Remove hinge mounting screw from dust cover.
- 4) In this state, replace dust cover.




Fig. 11

5. How to remove turntable

- 1) Hold turn table on its circumference by hand and turn 45 adaptor in centre in clockwise direction.
- 2) Turntable holder, 45 adaptor, and spring are removed.
- 3) Remove back lid of the unit (by removing four fixing screws, T2-3 x 12) and hold turntable and flywheel by hand. Then turn turntable counterclockwise to remove it from shaft.

6. How to remove player unit

- 1) Remove four cover fixing screws (T1-3 x 10) below turntable.
- 2) Hold tone arm base with finger and move it towards centre shaft, and stop above where cover wad.




Fig. 12

- 3) Remove five player-unit fixing screws (A and B) in Fig. 13. Player unit can now be removed from cabinet main body.




Fig. 13

7. How to remove tone arm

- 1) Remove player unit according to the procedure in Item 6.
- 2) Remove slit plate attached to arm base in Fig. 14.




Fig. 14

- 3) Remove dial thread from pulley and remove fixing screws (C) in Fig. 15.
- 4) Remove pulley attached to arm base in Fig. D. (E-ring 2.4φ x 2)




Fig. 15

- 5) Remove screw in Fig.16 and remove lifter guide from tone arm.




Fig. 16

- 6) Remove tone arm fixing nut in Fig.17 and disassemble tone arm from tone base.
- 7) Disconnect output lead wire of tone arm from PC board.
- 8) In this state, replace tone arm.
- 9) After replacing tone arm, be sure to carry out adjustment.




Fig. 17

8. How to remove main motor

- 1) Remove back lid of the unit.
- 2) Remove main belt from motor pulley.
- 3) Remove one motor holder mounting screw (M3 x 25).
- 4) Pull motor holder in a direction shown by arrow in Fig. 18.
- 5) Disconnect connector J9 from logic board.
- 6) In this state, replace motor.
- 7) Reverse the above procedure to mount motor holder.




Fig. 18

9 How to remove tuner unit

* Tuner unit can be replaced without removing the chassis unit.

- 1) Pull out TUNING knob.
- 2) Remove four tuner unit fixing screw (1) (T2-3 x 10) from chassis unit rear panel in Fig.
- 3) Pull tuner unit toward yourself and disconnect connector J202 from the tuner board. The tuner unit can be disassembled.




Fig. 19

10. How to replace power IC

- 1) Remove chassis unit according to the procedure in Item 1.
- 2) Remove tuner unit according to the procedure in Item 9.
- 3) Remove three screws (1) (T1-3 x 12), two screws (2) (T2-3 x 8), and six screws (3) (T2-3 x 10) in the rear panel.
- 4) Disconnect lead wire of transformer from PC board.
- 5) In this state, remove rear panel.
- 6) Remove screw fixing power IC to radiation panel.
- 7) Remove two shield plate fixing screws on both sides in the rear of chassis unit.
- 8) Remove soldering of power IC and take out.




Fig. 20

ADJUSTMENT PROCEDURE

TURNTABLE Section

- Before adjustment, remove the back lid from main body and place the player horizontally.

1. STYLUS HEIGHT ADJUSTMENT

- 1) Remove the main turntable belt and the horizontal motor belt. With no record, lift the tone arm base with the finger and move it to the centre of turntable. Press the actuator of REST switch to put the switch into the ON state. (See Fig. 1)




Fig. 1

- 2) With the tone arm up, unlock and turn the cam pin E till the tip of stylus is 8 ± 1 mm above the turntable. In this case, the main body cover is open. (See Fig. 2)
- 3) After adjustment, lock the eccentric pin E with screw and replace the belt removed previously.




Fig. 2

2. VERTICAL ADJUSTMENT OF TONE ARM

- 1) With unit in state of Item 1-(1), allow a thread with small weight to hang from a top surface of set along the tone arm. Put a pin between the arm base and tone arm and set the stylus pressure of tone arm at Og. (See Figs. 3 and 4)
- 2) Loosen the main weight fixing hexagon screw (M3 X 4) with a 1.5 mm hexagonal screwdriver and adjust the main weight till the perpendicularly hung thread becomes parallel to the tone arm.
After adjustment, tighten hexagon screw of main weight.




Fig. 3




Fig. 4

3. ADJUSTMENT OF ARM LIFTER

- 1) Put the player into a state as in 1 (1). Press the LIFT/CUE button to lower the tone arm. Press again the LIFT/CUE button to raise the arm and make sure that the arm rises without tilting to right or left. If the arm tilts to either right or left, allow the arm to lower and adjust a screw of pulley C (Fig. 1) until the tone arm rises and lowers without tilting.

4. ARM LIFT TIMING.

Note: This adjustment should be made with the player detached from the cabinet main body.

- 1) Put the player into a state of 1 (1). With the tone arm raised, turn the pin F to adjust the clearance between the pulley C and pin F (shown in Fig. 1) to 0.5 ± 0.3 mm.

5. ADJUSTING THE LEAD-IN POSITION

- 1) Remove the back of player while keeping other components in the actual operation state.
- 2) Adjust the cam pin G (Fig. 5) so that the stylus lowers correctly in the lead in grooves along the periphery of record (a 12" disc) placed on the turntable when the START button is pressed. Also check 7" operation.




Fig. 5

6. TRACKING SERVO ADJUSTMENT

- 1) This adjustment should be made after the adjustment of 1 to 3. Disconnect connector CON-8 (4 pin) from the main PC board.
- 2) The removed connector CON-8 is wired as shown in Fig. 6. Press pin 1 with a standard screwdriver and pull out the brown wire.




Fig. 6

Adjustment of Recording System

1. Bias frequency

- 1) Setting Connect a frequency counter to Pin 1 (L) or Pin 3 (R) and Pin 2 (GND) of the jack J120.
- 2) Location OSC unit.
- 3) Procedure Adjust OSC unit till the frequency counter reads 85 KHz \pm 0.1 KHz.

Note: Adjust with BEAT CANCEL switch in "N" position.


2. Adjustment of recording current

- 1) Setting With the deck in recording mode, apply a signal of 400Hz, -10 dB. Adjust the RECORD LEVEL control to obtain a -7 dB signal at the output terminal, then lower the input level by 30 dB.
- 2) Test tape AC512 special.
- 3) Location Semi-fixed resistor, VR541 (L), VR641 (L).
- 4) Procedure Adjust, so that the output level during recording and playback of 400 Hz signal becomes equal to that during monitoring.

3. Adjustment of bias current

- 1) Setting Same as in Item 2 above.
- 2) Test tape AC512 special.
- 3) Location Semi-fixed resistor VR561 (L), VR661 (R).
- 4) Procedure Adjust, so that the level difference between 8 KHz and 400 Hz is within \pm 0.5 dB during recording and playback of 400 Hz and 8 KHz signals.


ADJUSTMENT LOCATION DIAGRAM



TAPE DECK MECHANISM Section


1. ADJUSTING THE TAPE SPEED

- 1) Setting — Connect a frequency counter to the output terminal.
- 2) Test tape — MTT-111 (3 kHz)
- 3) Adjustment procedure — Play back the test tape, and insert a standard screwdriver into the motor adjusting hole and adjust till the frequency counter indicates $3000 \pm 10\%$ Hz.



2. ADJUSTING THE HEAD ANGLE


- 1) Setting Set the **PLAY-BACK OUTPUT LEVEL ADJUSTMENT** preset control VR102 (L), VR202 (R) to the max. level.
- 2) Test tape MTT-215C (10k/315Hz, -10 dB, NORMAL)
- 3) Location of adjustment Head angle adjusting screw
- 4) Adjustment procedure Play back the test tape and adjust for maximum output on both channels.



TAPE DECK ELECTRICAL Section

MEASURING INSTRUMENTS AND TEST TAPES

1. Low-frequency oscillator 20 Hz – 20 kHz
2. Variable resistance attenuator 0 – 90 dB, 0.1 or 0.5 dB step
3. AC voltmeter Measuring range of 20 Hz – 200 kHz or more, input impedance more than 100 k Ω , and -60 dB or more
4. Frequency counter
5. Oscilloscope
6. Test tape
 - MTT-111 (3 kHz)
 - MTT-215C (10K/315 Hz, -10dB, NORMAL)
 - MTT-150 (400Hz dolby level)
 - AC-512 (blank)
7. How to connect the instruments.
 - 1) Connect a load resistance 22 k Ω , then the AC voltmeter and oscilloscope to the output terminal of deck.
 - 2) To adjust the recording system, connect the low-frequency oscillator and resistance attenuator to the input terminal of deck.



ADJUSTMENT OF PLAY-BACK SYSTEM

1. ADJUSTING THE PLAY-BACK OUTPUT LEVEL

- 1) Test tape MTT-150 (Dolby level)
- 2) Location of adjustment Preset control VR 501 (L), VR 601 (R)
- 3) Location of detection (+) side of electrolytic capacitor C 523 (L), C 623 (R)
- 4) Adjustment procedure Playback the test tape and adjust until the output level on the (+) side of C523 and C623 becomes 580 mV \pm 0.25 dB.

- 3) Insert the connector CON-8 again into the main PC board.
- 4) Connect the (-) lead of a MItimeter to pin 1 (main body side) of connector CON-8 and connect the (+) side of tester to the brown lead wire disconnected from pin 1. See Fig. 7.
- 5) Put the player into a state as in 1 (1). With the tone arm raised, adjust the cam pin A of Fig. 1 till the meter indicates $10 \pm 1 \mu\text{A}$.
- 6) Allow the tone arm to lower from the state in above (5), and make sure that the meter indication is within $\pm 1 \mu\text{A}$ of the value obtained with the tone arm raised.
- 7) Connect a voltmeter between PIN 1 and GND of main PV board and adjust the preset resistor VR 101 till the voltmeter indicates 3.5V.

7. SERVO MOTOR SPEED ADJUSTMENT

- 1) Place a test record on the turntable and connect a frequency counter to the output terminal of player via an amplifier.
- 2) Remove the back of player and adjust the player speed to 33 rpm.
- 3) Play back 3 KHz of test record and adjust the preset resistor VR 103 for 3020Hz.
- 4) Set the player speed to 45 rpm. Play back as in the case of above (3) and adjust the preset resistor VR 102 till the counter indicates 4070Hz.

ADJUSTMENT LOCATION DIAGRAM




Fig. 7

ADJUSTMENT OF TUNER

● Measuring instruments

- * AM signal oscillator (AM-SG)
- * Stereo modulator
- * Frequency counter
- * AM loop antenna
- * FM signal oscillator (FM-SG)
- * Oscilloscope
- * AC voltmeter

1. FM-RF Adjustment


- 1) Connect the output of FM-SG to an antenna terminal. Take the output from a pin 2 of IC202 and connect it to the AC voltmeter.
- 2) Set the frequency of SG to 87.4 MHz. Tune the pointer of the set to the lowest frequency. Adjust the local oscillator coil L203 so that 87.4 MHz can be received from SG. Adjust so that the AC voltmeter registers the maximum reading.
- 3) Set the SG frequency to 108.3 MHz. Tune the pointer of the set to the highest frequency. Adjust the trimmer capacitor C217 so that 108.3 MHz can be received from SG. Adjust so that the AC voltmeter registers the maximum reading.

- 4) Set the frequency to 88 MHz. Tune the set so that 88 MHz can be received from SG. Adjust tuning coils of L201 and L202 so that the AC voltmeter registers the maximum reading.
- 5) Set the SG frequency to 108 MHz. Tune the set so that 108 MHz can be received from SG. Adjust trimmer capacitors of C202 and C206 so that the AC voltmeter registers the maximum reading.
- 6) Repeat steps 2) through 5).

2. FM-IF, MPX Adjustment

- 1) Connect the DC voltmeter to pins 7 and 10 of IC201. Put the set in a state of not receiving a signal. Adjust T201 so that the voltmeter reads 0 ± 50 mV.
- 2) Set the SG frequency to 98 MHz. The output should be 66 dB, 1 KHz monoral 100% modulation. Tune the set so that 98 MHz can be received from SG. Connect a distortion factor meter to terminals 1 and 2 of J202. Make sure that the distortion factor is below 1%. If the distortion factor exceeds 1%, adjust T201 again.

ADJUSTMENT LOCATION DIAGRAM



3) In the state of above 2), set the modulation to 0%. Connect the frequency counter to a test point TP 1 of IC202. Adjust a semi-solid resistor VR201 so that the frequency counter reads 19 KHz \pm 50 Hz.

3. AM Adjustment


- 1) Connect the output of AM-SG to a loop antenna. Connect the loop antenna attached to the main body to the AM antenna terminal, take the output from pin 12 of IC201, and connect it to the AC voltmeter.
- 2) Set the AM-SG frequency to 520 KHz. Tune pointer to the lowest frequency. Adjust the local oscillator transformer so that 520 KHz can be received from AM-SG.
- 3) Set the AM-SG frequency to 1650 KHz. Tune pointer to the highest frequency. Adjust the local oscillator trimmer C317 so that 1650 KHz can be received from AM-SG.
- 4) Set the AM-SG frequency to 600 KHz. Tune the set so that 600 KHz can be received from AM-SG. Adjust the tuning transformer T301 so that the AC voltmeter registers the maximum reading.

- 5) Set the AM-SG frequency to 1400 KHz. Tune the set so that 1400 KHz can be received from AM-SG. Adjust the trimmer capacitor C302 so that the AC voltmeter registers the maximum reading.
- 6) Repeat steps 2) through 5) several times.

4. Adjustment of LW


- 1) Obtain a state as in the adjustment of MW.
- 2) Set AM-SG frequency at 140 kHz. Tune set indication to the lowest frequency. Adjust the local transformer T304 till 140 kHz can be received from AM-SG. Adjust the tuning transformer T302 so that the max. reading is obtained on an AC voltmeter.
- 3) Set AM-SG frequency to 360 kHz. Tune set indication to the highest frequency. Adjust the trimmer capacitor C319 till 360 kHz is received from AM-SG. Adjust the trimmer capacitor C304 so that the max. reading is obtained on an AC voltmeter.
- 4) Repeat steps 2) and 3) several times.
- 5) Set AM-SG frequency to 140 kHz. Tune so that 140 kHz can be received from AM-SG. Adjust IF transformers T305 and T306 so that the max. reading is obtained on an AC voltmeter.

DIAL CORD STRINGING




INTERNAL DIAGRAMS AND PINOUT OF INTEGRATED CIRCUITS TURNTABLE Section

IC101 : 1320SL OPERATING MODE



Pin No.	2	3	5	6	7	8	14	15	16	17	21	22	23	26	27	28
Arm Rest Position (Power ON)	L	H	L	L			H	L	H	L				L	L	L
Disk Side S203 CUE (Arm : Down)	L	H	L				H	H	H	H				L	H	L
S204 Start : Push Arm : Inward	L	H		L			L	H	H	L				L	H	L
S204 ON Start Arm : Lowering (Lead-In)	H	H	L	L			H	H	H	H				L	H	L
S202 Stop (Play) Arm : Rising	H	H	L	L			H	H	H	H				L	H	L
S202 Stop Arm : Outward (Lead-Out)	L	H	L	L			H	L	H	L				L	H	L
Arm Lift S204 Pushing	L	H		L			L	H	L	L				L	H	L
Arm Lift S202 Pushing	L	H	L	L			H	L	L	L				L	H	L
Auto-End Detection	L	H	L	L			H	H	H	H				L	H	L


IC102 : TC4081BP OPERATING MODE



Pin No.	1	2	3	4	5	6	8	9	10	11	12	13
No Disk S204	L 17 Groove					L H	L		L	L		L
30cm Disk S204 Start	L		L			L H	H					H
17cm Disk S204 Start	H 17 Groove					L H	H			L		L

IC103 : MSA-117RS OPERATING MODE

Mode	Pin No.	1	9	11	14	15	16
LEAD-IN		L	L	H	H	H	L
LEAD-OUT		L	H	L	H	L	H
CUEING (Arm up)		-	-	-	L	-	-
Tracking Servo activated		H	L	L	H	L	L




IC104 : TC4081BP OPERATING MODE

Actual \ Pin No.	1	2	3	4	5	6	8	9	10	11	12	13
Rest Position (Power ON) Cover : Close	L		L	L		L	L		L			H
Rest Position (Power ON) Cover : Open	L		L	L		L	H					H
S203 Cue (Rest Position)	H			L		L	L		L			H
S204 Start	L		L			H	L		L	L		L
S202 Stop	L		L	L		L	H			L		L


IC105 : M5232L

M5232L	1	Vcc		Vcc	S1	S2	S3	S4
	2	VOLTAGE SETPOINT	Icc	9V	OFF	OFF	OFF	—
	3	LOGIC OUTPUT (H.L)	V2	9V	ON	ON	OFF	b
	4	C1	V1	9V	ON	ON	OFF	a
	5	GND	V3	9V	ON	ON	OFF	c
	6	LED DRIVE	V6	6V	ON	OFF	ON	d
	7	Vref CHECK	f	6V	ON	ON	OFF	c
	8	CONSTANT VOLTAGE OUTPUT						





TUNER Section

IC201 : HA12413





IC202 : KB4424A





TAPE DECK Section


IC501 : STK3161





IC502 : TA7629P



IC701 : MPC4559C




IC721/821 : HA1397




BLOCK DIAGRAM


TUNER SECTION




DECK SECTION



TURNTABLE SECTION



WIRING DIAGRAM . . . TURNTABLE Section




NOTE:
The actual colors of wires may differ from those of this diagram.
Wire colors are abbreviated as follows.

BRN Brown	YEL Yellow
PPL Purple	RED Red
GRN Green	GRY Gray
ORG Orange	BLU Blue
WHT White	BLK Black

TAPE DECK, AMP, TUNER Section


SCHMATIC DIAGRAM TURNABLE Section



NOTE:

1. The actual colors of wires may differ from those of this diagram.
Wire colors are abbreviated as follows.
BRN Brown YEL Yellow
PPL Purple RED Red
GRN Green GRY Gray
ORG Orange BLU Blue
WHT White BLK Black
2. Parts symbolized  are very important for safety and performance.
Therefore use by all means designated parts when replacing.

SCHEMATIC DIAGRAM TURNTABLE Section



Signal flow


- Arm horizontal inward movement
- Arm horizontal inward movement stop (lead-in)
- Arm lowering start
- Arm rising start (end detection)
- Arm outward movement

Note

- CR unit
C No code : μF R No code : Ω
P code : pF k code : k Ω
- 1/4W for resistor not specified and voltage withstand at 50V for capacitor without voltage specification.
- Voltage of each part is a value measured in a rest state with a DC 1 M Ω digital voltmeter. Voltage in parentheses is a value with the turntable turning.

4. The circuit diagram shown here is a basic circuit diagram and may be subject to modification of constants due to improvement.


TUNER Section



NOTES.

- C and R unit
C No symbol : μ F
P symbol : pF
Capacitor without voltage display has pressure resistance of 50V. The NP is Nonpolar Capacitors.
 - Voltage for all parts are measured in terms of DC 1M Ω digital voltmeter.
 - The circuit figure shown here is the basic circuit diagram. Please note that changes in dimensions may occur as a result of improvements, etc.
- R No symbol : Ω
K symbol : k Ω
M symbol : MM Ω
Resistance not designated is 1/4 W, J(5%).

TAPE DECK, AMP Section




NOTES:

1. C and R unit
2. Voltage for all parts are measured in terms of DC 1M Ω digital voltmeter.
3. Parts marked with Δ or \square are vital for maintenance of safety and performance. Be sure only designated parts are used for replacement.
4. The circuit figure shown here is the basic circuit diagram. Please note that changes in dimensions may occur as a result of improvements, etc.

Capacitor without voltage display has pressure resistance of 50V. The NP is Nonpolar Capacitors.


Resistance not designated is 1/4 W, J(5%).



AD-5 AMP/DECK P.C.B





Signal flow
 Playback Signal
 Recording Signal

PRINTED CIRCUIT BOARD . . . TURNTABLE Section



TUNER Section

PRINTED CIRCUIT BOARD ... TURNABLE SECTION




TAPE DECK, AMP Section




TURNABLE MECHANISM PARTS LIST

TURNABLE MECHANISM EXPLODED VIEW

2 3 4 5 6 7 8




- 101 3 x 8
- 102 M3 x 4
- 103 Screw-Metal
- 104 M3 x 8
- 105 Screw-Tapping 1 - 4 x 12
- 106 M3 x 10
- 107 Screw-Tapping 1 - 3 x 8
- 108 M3 x 14
- 109 Screw-Metal
- 110 Screw-Tapping
- 111 M3 x 8
- 112 Screw-PC
- 113 Screw-Tapping 1 - 3 x 12
- 114 M8 x 8
- 115 Bolt
- 116 M3 x 28
- 117 Screw-Bind
- 118 Screw-Metal
- 119



TURNTABLE MECHANISM EXPLODED VIEW

TURNTABLE MECHANISM PARTS LIST

TAPE DECK AMP Section




Symbol No.	Parts No.	Description
1	M04179600	Tone Arm Ass'y
2	M07602530	Solenoid
3	M07602640	Lifter (Arm Drive)
4	M04168612	Stylus (3D-47M)
5		Stylus-Cover
6		Holder
7		Spring
8		Plate
9		Arm-Base
10		Pulley
11		Washer
12		Pulley
13		Nut
14	M07469639	Motor (Horizontal)
15	M07602714	Belt (Horizontal)
16	M07602645	Pulley-Ass'y
17		Washer
18		Cushion-Rabber
19		Washer
20		Pulley
21	M07602646	Gear (Horizontal)
22		Washer
23		Spring
24		Lever
25		PCB-Ass'y
26		Base
27		Spring
28		Cushion-Rabber
29	M04179625	Shaft
30		Pin
31		Cushion-Rabber
32		Transistor
33	M04179131	Cover Ass'y
34	M07602381	Micro-Switch
35		Holder
36		Beaming-Ass'y
37		Washer
38		Flywheel
39	M07602713	Belt (Main)
40		Nut-Flange
41	M07556516	ANT-Loop
42	M07556655	Holder-ANT
43		Board-Back
44		Holder
45		PCB
46		Holder
47		PCB-Ass'y
48		Cushion-Rabber
49		Washer
50		Holder
51		Holder
52		Holder
53		Holder
54		Washer
55		Holder
56		Plate
57	M04179204	Knob
58		Spring
59		Cabinet
60		PCB-Ass'y (SW)


Symbol No.	Parts No.	Description
61		Sheet
62	M04179203	Knob
63		Holder
64	M04179205	Knob (Selector)
65	M04179202	Knob (Tuning)
66	M04179201	Knob (Mix, Balance, Treble, Bass, Tape)
67		PCB-Ass'y
68		Clamper
69		Holder
70	M04179620	Platter-Ass'y
71	M04179200	Knob-Ass'y (45 Adaptor)
72	M04179925	Cover
73	M04179206	Knob (Main VR)
74		Holder
75		Cushion-Rabber
76		Caller-Metal
77		Holder
78		Holder
79	M04172550	Motor (Main)
80		Holder
81	M07602656	Holder-Ass'y (Record)
82		Spring-Plate
83		Cover
84		PCB-Ass'y
85		Holder
86	M04179132	Cover (Cassette)
87	M04179130	Cover Ass'y
88	M04179140	Holder Ass'y (Hinge)
89		Spacer
90		Cover
91		Spacer-Rabber
92		Spring
93		Lever
94	M04179632	Pulley (Main Motor)
95		-
96		-
97		-
98		Screw-Metal
99		Screw-Tapping 2 - 3 x 8
100		Screw-Metal
101		Screw-Metal 3 x 8
102		Screw-Bing M2.6 x 4
103		Screw-Metal
104		Screw-Bind M3 x 6
105		Screw-Tapping 1 - 4 x 12
106		Screw M2.3 x 10
107		Screw-Tapping 1 - 3 x 6
108		Screw-Metal M3 x 14
109		Screw-Metal
110		Screw-Tapping
111		Screw-PC M3 x 6
112		Screw-Tapping 1 - 3 x 14
113		Screw-Tapping 1 - 3 x 12
114		Bolt M6 x 8
115		Screw-Bind M3 x 25
116		Screw-Metal
117		Screw-Metal
118		-
119		-

TAPE DECK MECHANISM EXPLODED VIEW

Symbol No.	Parts No.	Description
120	5.0	E-Ring
121	1.5	E-Ring
122	2.4	E-Ring
123	5.0	BE-Ring
124	-	
125		



TAPE DECK MECHANISM EXPLODED VIEW



TAPE DECK MECHANISM PARTS LIST


MAIN CHASSIS PARTS LIST

Symbol No.	Parts No.	Description	Symbol No.
1		Chassis Ass'y	81
2	M04172520	R/P Head	82
3	M04172524	Erase Head	83
4	M04179375	Leaf Switch (Cue/Rev)	84
5	M05230377	Leaf Switch (Triga)	85
6		Cue Lever	86
7	GM	Rec Inter Plart	87
8		Stop Sub Plart	88
9	M05230376	Leaf Switch (Play)	89
10	M05230722	Idler Ass'y	90
11		Pause Arm	91
12	M05230732	Idler Gear	92
13		Protector	93
14		Spring	94
15	M05230378	Leaf switch (Pause)	95
16	M05230378	Leaf switch (Main)	96
17		Head Base	97
18		Head Stand	98
19		Switch Arm	99
20		Spring	100
21		Spring	101
22	M04179760	Pinch Spring	102
23		Holder	103
24		Steel Ball	104
25		Ball Holder	105
26		Washer	106
27		Holder	107
28		Spring	108
29	M04179720	Pinch Arm Ass'y	109
30	M04179700	Supply Reel	110
31	M04179780	Washer	111
32		Spring	112
33	M04179701	Take-up Reel Ass'y	113
34		Spring	114
35		Clutch Plate	115
36		Spring (Eject)	116
37		Lock Plate	117
38		Spring	118
39		Terminal	119
40		Spring	120
41		PAUSE Plate	
42		Spring	
43		REC Plate	
44		REW Plate	
45		Spring	
46		PLAY Plate	
47		FF Plate	
48		Select Arm	
49		Holder	
50		Lock Plate	
51	M04179735	AS Cam Ass'y	
52		Spring	
53		Senser	
54		Washer	
55		Spring	
56		Senser Arm A	
57		Senser Arm B	
58		Senser Arm C	
59		Spring	
60		Spring	

Symbol No.	Parts No.	Description	Symbol No.
61	M04179730	Worm	1
62		Washer	2
63		Stop Lever	3
64		Lock Plate	4
65		Spring	5
66		Select Arm	6
67		Spring	7
68		Slide Plate	8
69		Collar	9
70		Holder Plate Ass'y	10
71	M04179731	Assist Gear	11
72		Spring	12
73		Start Lever A	13
74	M04179768	Tension Ass'y	14
75		Spring	15
76		Lock Plate	16
77		Side Plate	17
78		Side Plate	18
79	M05230756	Flywheel	19
80	M05230730	FM Gear	20
81		Washer	21
82		Spring	22
83	M05230714	Belt (Main)	23
84	M05230716	Belt (Reel)	24
85	M05230715	Belt (AS)	25
86		Motor Bracket	26
87		Holder Ass'y	27
88	M04179148	Cassette Case	28
89		Rec Lever	29
90		Button Holder	30
91		Button Lever	31
92		Inter Plate	32
93		Cam Plate	33
94		Spring	34
95		Spring	35
96		Cassette Holder (Spring)	36
97		SW Plate	37
98		Inter Plate	38
99		Button Lever	39
100		Button Lever	40
101		Release Lever	41
102		Rec Plate	42
103		Collar	43
104	M04179714	Belt (Counter)	44
105		Start Plate B	45
106		Spring	46
107		Holder	47
108		Spring	48
109		Spring	49
110		Spring	50
111	M04179550	Motor Ass'y	51
112		Spring	52
113	M04179679	Damper Ass'y	53
114		Tube	54
115		Eject Ass'y	55
116		Eject Plate	56
117		Spring	57
118		Star Plate	58
119		Plate	59
120		Holder	60

Symbol No.	Parts No.	Description
121		Eject Spring
122		CS Ring
123		CS Ring
124		E Ring 2
125		E Ring 3
126		Screw (M2.6 x 5)
127		Screw (M2.6 x 10)
128		Screw (M3 x 5)
129		Screw (M2.6 x 8)
130		Seme Screw (M2 x 4)
131		F. T-Screw (2.6 x 6)
132		F. T-Screw (3 x 6)
133		Screw (M2 x 11)
134		Seme Screw (M3 x 6)
135		—
136		—
137		Screw (M2 x 5)
138		Spring Washer
139		Washer
140		Lever
141	M04179210	Knob
142	M04179211	Knob

MAIN CHASSIS EXPLODED VIEW



MAIN CHASSIS PARTS LIST

Symbol No.	Parts No.	Description
1		Cover
2	M07602060	Clamper
3	M05209700	Power-Cord
4		Panel-Back
5		Panel-Back
6		Screw 3 x 8
7		T-Screw 1 - 3 x 10
8	M04178500	Trans-Power
9		T-Screw 2 - 4 x 10
10	M04177450	Fuse 1.5A
11	M04179358	SW-Push
12		Holder
13		Spacer-PL
14		Radiator-Ass'y
15		Screw 3 x 6
16		-
17	M04172480	Terminal-Board (Antenna)
18		Shield
19	M04179420	VC-Air
20	M04179359	SW-Push (AM/FM)
21		Lamp
22		Spring
23		Drum
24		Screw-B M3 x 6
25		Screw-B M2.6 x 5
26	M04178200	Knob-Ass'y (AM/FM)
27		-
28	M04177250	Pointer
29		Pulley
30		Holder
31		Holder
32	M04179565	Lamp
33		Panel-Front
34		Tuning-Shaft
35		Nut M10
36		Dial
37		Dial-Cord-Ass'y
38		-
39		-
40	M07573480	Terminal-Board (Speaker)
41	M05225360	SW-Slide (Beat Cancel)
42	M05249435	OSC-Unit
43		Shield
44	M05225360	SW-Slide (Rec/Play)
45	M04179402	VR-W-A50K-30 (Rec VR)
46	M07573480	Terminal-Board
47	M04179366	SW-Rotary (Selector)
48	M04179475	Jack (Mic)
49	M04179400	VR-STD-4 (Bass, Treble, Balance, Mix)
50	M04179367	SW-Rotary (Tape Select)
51	M04179357	SW-Push (Dolby)
52	M04179207	Knob (Dolby)
53	M07607475	Jack (Phones)
54		Screw-Metal 3 x 8
55		Panel-Front
56		Holder-Z
57	M04179208	Knob (Power)
58		Clamper
59	M04179356	SW-Push (Power)
60		Holder

TAPE DECK MECHANISM PARTS LIST

Symbol No.	Parts No.	Description
61	M05240320	LE-Diode (GRN) (Play, Dolby)
62	M04179320	LE-Diode (RED) (Rec, Peak)
63	M04179321	LE-Diode (ORG) (Pause)
64	M04179401	VR-Slide (Volume)
65	M04179365	SW-Rotary
66		Holder-Z
67		Nut M9
68		Holder
69	M04179713	Belt (Counter)
70	M04179710	Counter
71		Holder
72		-
73		-
74		Shield
75		-
76		Mechanism-Ass'y
77	M04177762	Spring-W
78		Link
79		Holder
80	M04179209	Knob (Eject)

PARTS LIST . . . TURNTABLE Section

Symbol No.	Part No.	Description
Diodes		
D1A1	M04179324	SLP146B
D1A2	M04179324	SLP146B
D1A3	M04179324	SLP146B
D1A4	M07297320	SP254FS
D1A5	M04179324	SLP146B
D1A6	M04179325	202C
D101	M07556320	DS442
D102	M07556320	DS442
D103	M07556320	DS442
D104	M07556320	DS442
D105	M07556320	DS442
D106	M07556320	DS442
D107	M07556320	DS442
D108	M07556320	DS442
D109	M07556320	DS442
D110	M07556320	DS442
D111	M07556320	DS442
D112	M07556320	DS442
D114	M07556320	DS442
D115	M07228321	10E1
D116	M07228321	10E1
D117	M07228321	10E1
D118	M05232328	RD12E
D120	M07228321	10E1
D121	M07556320	DS442
D122	M07556320	DS442
ICs		
IC101	M07602311	MP1320SL
IC102	M07602310	TC4081BP
IC103	M07527344	MSA117RS
IC104	M07602310	TC4081BP
IC105	M04179311	M5232L
Transistors		
Q1A1	M07137303	PH101
Q1A2	M07137303	PH101
Q1A3	M07137303	PH101
Q1A4	M07137303	PH101
Q101	M07390303	2SC2603
Q102	M07390303	2SC2603
Q103	M07390304	2SA1115
Q104	M07390304	2SA1115
Q111	M07390303	2SC2603
Q112	M07390303	2SC2603
Q113	M07390303	2SC2603
Q114	M07390303	2SC2603
Q115	M05147312	2SB564
Q116	M07390303	2SC2603
Q117	M07228303	2SD571
Q118	M07390303	2SC2603
Q119	M07139304	2SK68A
Q120	M05147312	2SB564
Q121	M07390303	2SC2603

Symbol No.	Part No.	Description
Q124	M07151310	2SD330
Q125	M07390303	2SC2603
Q126	M07390304	2SA1115
Q127	M07390304	2SA1115
Q128	M07390303	2SC2603
Q129	M07390303	2SC2603
Electrical Parts		
LA1A1	M07374251	LAMP
LA1A1	M07374251	LAMP
LA1A3	M07374251	LAMP
LA1A4	M07297250	LAMP
LA1A5	M07297250	LAMP
LA1A6	M07297250	LAMP
LA1A7	M07297250	LAMP
S1A1	M07445660	SW-PUSH
S1A2	M07445660	SW-PUSH
S1A3	M07445660	SW-PUSH
S1A4	M07445660	SW-PUSH
S1A5	M07445660	SW-PUSH
S1A6	M07445660	SW-PUSH
S1A8	M04179354	SW-PUSH
VR101	M05104360	VR-SEMI-B220K
VR102	M04139436	VR-SEMI-B2.2K
VR103	M04139436	VR-SEMI-B2.2K

TUNER Section

Symbol No.	Part No.	Description
Description		
D201	M04179320	SLP-160C
D202	M04179323	GL-9NP2
D203	M07556320	DS442
D204	M07556320	DS442
D205	M07556320	DS442
D206	M05225320	RD3.0E-B2
D207	M07556320	DS442
D208	M07556320	DS442
D301	M05142320	1S188AM
ICs		
IC201	M05199343	HA-12413
IC202	M04179310	KB-4424A
Transistors		
Q101	M07390303	2SC2603
Q201	M07152303	2SK55
Q202	M04070303	2SC535
Q203	M04066313	2SC461
Q204	M04070304	2SC710
Q205	M07390303	2SC2603
Q206	M07390303	2SC2603
Q207	M07390303	2SC2603
Q208	M07390303	2SC2603
Q209	M07390303	2SC2603
Q210	M07390303	2SC2603
Q211	M07390303	2SC2603
Q212	M07390303	2SC2603
Q213	M07390303	2SC2603
Q214	M07390303	2SC2603
Q215	M07390303	2SC2603
Q216	M07390303	2SC2603
Q217	M07390303	2SC2603
Q301	M04070304	2SC710
Q302	M04070304	2SC710
Electrical Parts		
CF201	M07532445	CERAMIC-FILTER
CF202	M07532445	CERAMIC-FILTER
CF301	M07566445	CERAMIC-FILTER
J201	M04167576	TERMINAL-BOARD
L201	M04179511	COIL-ANT
L202	M04179512	COIL-RF
L203	M04179513	COIL-OSC
PL201	M04179565	LAMP
PL202	M04179565	LAMP
S201	M04179359	SW-PUSH (FM/AM)
S202	M04179359	SW-PUSH (MUTING/MONO)
S203	M04178356	SW-PUSH (MW/LW)
T001	M07632445	FILTER
T201	M04179502	TRANS-IF
T202	M04179445	FILTER

Symbol No.	Part No.	Description
T302	M04178510	COIL-ANT
T303	M04179515	COIL-OSC
T304	M04178511	COIL-OSC
T305	M07566502	TRANS-IF
T306	M04179503	TRANS-IF
VR201	M04179412	VR-SEMI-B10K

TAPE DECK, AMP Section

NOTE: Δ and \square marks components on Parts list have special characteristics to keep safety performance of this unit. When replacing any of these parts, be sure to use only specified parts.

Symbol No.	Part No.	Description
Diodes		
D421	M07556320	DS442
D422	M07556320	DS442
D423	M07556320	DS442
D424	M07556320	DS442
D425	M07556320	DS442
D426	M07556320	DS442
D427	M07556320	DS442
D431	M04179320	SLP160C
D432	M05240320	SLP260C
D433	M04179321	SLP460C
D434	M04179320	SLP160C
D435	M05240320	SLP260C
D451	M07228321	10E1
D901	M04179322	3B4B41-LC1
D902	M05240322	RD15E-B2
D903	M05240322	RD15E-B2
D904	M04179322	3B4B41-LC1
D905	M05240322	RD15E-B2
D906	M05240322	RD15E-B2
ICs		
IC501	M04179312	STK3161B
IC502	M05225314	TA7629P
IC602	M05225314	TA7629P
IC701	M04172311	MPC4559C
IC721	M04172312	HA1397
IC821	M04172312	HA1397
Transistors		
Q411	M07314303	2SC2001
Q421	M07390303	2SC2603
Q422	M07390304	2SA1115
Q441	M07390303	2SC2603
Q442	M07390304	2SA1115
Q471	M07390304	2SA1115
Q472	M07390303	2SC2603
Q491	M07390304	2SA1115
Q492	M07390303	2SC2603
Q531	M07390303	2SC2603
Q541	M07390303	2SC2603
Q542	M07390303	2SC2603
Q631	M07390303	2SC2603
Q641	M07390303	2SC2603
Q642	M07390303	2SC2603
Q701	M07454303	2SD1012
Q702	M07454303	2SD1012
Q801	M07454303	2SD1012
Q802	M07454303	2SD1012
Q901	M07061304	2SD330
Q902	M04179300	2SK163
Q903	M07061304	2SD330
Q904	M07228303	2SD571
Q905	M07228303	2SD571

Symbol No.	Part No.	Description
Electrical Parts		
C941	M04180430	C-CERAMIC-400V 0.0047 Δ
C942	M07554430	C-CERAMIC-400V 0.0047 Δ
F901	M05195490	FUSE 630mA-SEMCO Δ
F901	M07337490	FUSE 500mA-SEMCO Δ
FL521	M05240445	(DENMARK, SWEDEN only) FILTER (MPX)
FL621	M05240445	FILTER (MPX)
J471	M04179475	JACK (MIC)
J701	M04172480	TERMINAL-BOARD (IN)
J702	M07573480	TERMINAL-BOARD (SPEAKERS)
J703	M07607475	JACK (PHONES)
L541	M05209420	COIL-22mH (TRAP)
L542	M05237510	COIL-4.7mH (PEAKING)
L641	M05209420	COIL-22mH (TRAP)
L642	M05237510	COIL-4.7mH (PEAKING)
L701	M04179510	COIL-0.7mH
L801	M04179510	COIL-0.7mH
R413	M07113411	R-FUSE 1/2W 47-K Δ
S410	M04179367	SW-ROTARY (TAPE SELECT)
S420	M04179357	SW-PUSH (DOLBY)
S430	M05194431	SW-SLIDE (REC/PLAY)
S440	M05225360	SW-SLIDE (BEET CANCEL)
S701	M04179365	SW-ROTARY (FANCTION)
S901	M04178358	SW-PUSH (POWER) Δ
T901	M04178500	TRANS-POWER Δ
VR501	M05250411	VR-SEMI-B33K (PB LEVEL)
VR521	M04179402	VR-W-A50K-30 (REC LEVEL)
VR621		
VR541	M04179411	VR-SEMI-B68K (REC CURRENT)
VR561	M05245411	VR-SEMI-B100K (BIAS CURRENT)
VR641	M04179411	VR-SEMI-B68K (REC CURRENT)
VR661	M05245411	VR-SEMI-B100K (BIAS CURRENT)
VR715		
VR815		
VR716		
VR717	M04179400	VR-STD-4 (MIX, BAL, LOW, HIGH)
VR817		
VR718		
VR818		
VR719	M04179401	VR-SLIDE-3BM250K (VOLUME)
VR819		
VR601	M05250411	VR-SEMI-B33K (PB LEVEL)
Packing		
201	M04179910	CUSHION MOLD (SET)
202	M04179920	PACKING BAG
203	M04178900	PACKING BOX
204	M04179911	CUSHION (PLATTER)
	M04178940	INSTRUCTION BOOKLET
	M04178945	CARD (GUARANTEE)
	M04057540	ANTENNA (FM)

PACKING INSTRUCTIONS

TAPE DECK AMP Section

NOTE

