




Nakamichi

MR-2

2 Head Professional
Cassette Deck



3. TEST TAPES AND GAUGES

- (1) 400 Hz Level Tape (DA09005B)
- (2) 1 kHz Track Alignment Tape (DA09007B)
- (3) 15 kHz Azimuth Tape (DA09004B)
- (4) 3 kHz Speed and Wow/Flutter Tape (DA09006C)
- (5) 10 kHz PB Frequency Response Tape (DA09003B)
- (6) 15 kHz PB Frequency Response Tape (DA09002B)
- (7) 20 kHz PB Frequency Response Tape (DA09001B)
- (8) Tape Travelling Cassette (DA09027B)
- (9) Reference EXII Tape (DA09102A) for Normal Position
- (10) Reference SX Tape (DA09103A) for High Position
- (11) Reference ZX Tape (DA09100A) for Metal Position
- (12) Head Alignment Gauge (DA09092A)
- (13) Torque Gauge FWD Play (DA09082A)
- (14) Torque Gauge F.F./Rew. (DA09084A)

4. MECHANICAL ADJUSTMENTS

4.1. Tape Guide Height Check for Record/Playback Head and Erase Head

With use of a Head Alignment Gauge, tape guide height check for the Record/Playback and Erase Heads shall be made, wherein a small block shall be pushed straight down to the base while in use of the Head Alignment Gauge. Refer to Fig. 4.1.

- (1) **Record/Playback Head Tape Guide Height**
 - (a) Load the base of the Head Alignment Gauge carefully and set the cassette deck in Play mode.
 - (b) Place the small block of the Head Alignment Gauge on the base.
 - (c) Slide the small block against the tape guide of the Record/Playback Head, and check to insure that the block is accepted by the tape guide.
 - (d) If not, loosen the screw and insert a shim (either 30 μm (OC80048A), 60 μm (OC80038A), or 100 μm (OC80039A)) to raise the Record/Playback Head, then tighten and apply a quantity of lock tight paint to the screw.
- (2) **Erase Head Tape Guide Height**
 - (a) Load the base of the Head Alignment Gauge carefully and set the cassette deck in Play mode.
 - (b) Place the small block of the Head Alignment Gauge on the base.
 - (c) Slide the small block against the tape guide of the Erase Head, and check whether the block is accepted by the tape guide.

4.2. Head Base Stroke Check

Refer to Fig. 4.2.

- (1) Load the base of the Head Alignment Gauge carefully, then push the base toward the Record/Playback Head to eliminate the clearance between the reference pin and the base.
- (2) Set the cassette deck in Play mode.
- (3) Place the small block of the Head Alignment Gauge on the base.
- (4) Contact the small block with the Record/Playback Head surface and the Erase Head surface, and check whether the end of the small block is located within the specified tolerance as shown in Fig. 4.2.

4.3. Record/Playback Head Azimuth Alignment and Height Check

Refer to Fig. 4.1.

- (1) Connect a VTVM to the Output Jacks.
- (2) Load a 15 kHz Azimuth Tape and set the cassette deck in Play mode.
- (3) Turn the Azimuth Alignment Screw until the outputs of both channels become maximum.
- (4) Load a 1 kHz Track Alignment Tape and set the cassette deck in Play mode.
- (5) Check to insure that the readings of both channels on the VTVM are below -25 dB.
If not, replacement of the Record/Playback Head will be required.
- (6) Apply a quantity of lock tight paint to the Azimuth Alignment Screw.




Fig. 4.1




Fig. 4.2

4.4. Tape Travelling Check

Load a Tape Travelling Cassette and set the cassette deck in Play mode to check the followings:

- (1) After more than 2 seconds, the fluctuation of the tape travelling on the Record/Playback Head is small.
- (2) Tape is in contact with the head sufficiently.
- (3) Tape waving is small on the heads and pressure roller.

4.5. Eject Damper Adjustment

Refer to Fig. 4.3. Load a cassette tape and with opening and closing the Cassette Case Ass'y, adjust the speed of damper action by the Damper Adjustment Screw.

- CCW: Damper moves fast;
CW: Damper moves slowly.

4.6. Reel Motor Speed Adjustment in Play Mode

- (1) To warm-up the cassette deck, load a C-60 cassette tape and play it back for more than four minutes.
- (2) Load a torque gauge FWD Play (DA09082A) or equivalent and set the cassette deck in Play mode.
- (3) Adjust VR601 on the Main P.C.B. Ass'y to obtain exactly 50 g-cm on the torque gauge.

4.7. Tape Speed Adjustment

- (1) Set the Pitch Control on the Front Panel to its mechanical center position.
- (2) Connect a frequency counter to the Output Jacks.
- (3) Load a 3 kHz Speed and Wow/Flutter Tape and play it back.
- (4) Adjust VR603 on the Pitch Control P.C.B. Ass'y to obtain 3,000 Hz \pm 15 Hz on the frequency counter.

4.8. Lubrication

The tape transport is of a lubrication-free type mechanism. When the following parts are replaced, apply the specified lubricant.

- (1) Molykote (R) Grease (X5-6020)
Cam Motor Pulley
Thrust portion on the Capstan Shaft
- (2) FLOIL GB-TS-1
Washer between Reel Hub Ass'y and Back Tension Spring
- (3) Diamond Oil (EP56)
Reel Hub Shaft
- (4) Anderol 456
Capstan Shaft

Note: We suggest that you use the above specified lubricant or equivalent type.

The company dealing in the above lubricant is as follows:

- (a) Molykote (R) Grease (X5-6020)
Dowcorning Co., Ltd., 1-15-1 Nishishinbashi, Minato-ku, Tokyo, Japan
- (b) FLOIL GB-TS-1
Kanto Chemicals Co., Ltd., 2-7 Kanda Sakuma-cho, Chiyoda-ku, Tokyo, Japan
- (c) Diamond Oil (EP-56)
Mitsubishi Oil Co., Ltd., 1-2-4 Toranomom, Minato-ku, Tokyo, Japan
- (d) Anderol 456
Toyo Kokusai Oil Co., Ltd., 3-3-5 Hatchobori, Chuo-ku, Tokyo, Japan




Fig. 4.3

5. PARTS LOCATION FOR ELECTRICAL ADJUSTMENT




Fig. 5

6. ELECTRICAL ADJUSTMENTS

- Notes: 1. Electrical adjustment should be performed after mechanical adjustment is completed.
 2. Before adjustment, set the Bias Tune control and the Pitch control on the Front Panel to their mechanical center positions.

6.1. Adjustment Instructions

STEP	ITEM	SIGNAL SOURCE	OUTPUT CONNECTION	MODE	ADJUSTMENT	REMARKS
1	Tape Speed Adjustment	3 kHz Speed and Wow/Flutter Tape	Frequency Counter to Output Jacks	Playback Eq. - 70 μ s	Pitch Control P.C.B. VR603	Adjust VR603 to obtain 3 kHz \pm 15 Hz on the frequency counter.
2	Meter Level Calibration	400 Hz to Input Jacks	VTVM to TP101 TP201 on Main P.C.B.	Record, Pause	Main P.C.B. VR108 VR208	<ol style="list-style-type: none"> 1. Set the Output Level control to max. 2. Feed in 400 Hz and adjust the Input Level controls to obtain 350 mV -0.6 dB on the VTVM. 3. Adjust VR108 (VR208) so that the 0 dB segment of the level meter starts illuminating. 4. Adjust the Input Level controls to obtain 35 mV on the VTVM, and check to insure that the segment for -20 dB lights up.
3	MPX Filter Adjustment	19 kHz \pm 100 Hz to Input Jacks	VTVM to Output Jacks	Record, Pause MPX - OFF/ON	Main P.C.B. L105 L205	<ol style="list-style-type: none"> 1. Set the Output Level control to max. Adjust the Input Level controls to obtain 0 dBV (1 V) on the VTVM. 2. Set the MPX Filter switch to ON and adjust L105 (L205) to obtain minimum reading on the VTVM (the minimum reading will be less than -30 dBV (31.6 mV)).
4	Record/Playback Head Azimuth Alignment	15 kHz Azimuth Tape	VTVM to Output Jacks	Playback Eq. - 70 μ s Dolby NR - OFF MPX - OFF	Record/Playback Head Azimuth Alignment Screw	Adjust the Record/Playback Head Azimuth Alignment Screw to obtain maximum readings for both channels on the VTVM.
5	Playback Level Calibration	400 Hz Level Tape	VTVM to TP101, TP201 on Main P.C.B.	Same as above	Main P.C.B. VR101 VR201	Adjust VR101 (VR201) to obtain 350 mV on the VTVM.
6	Playback Frequency Response Adjustment	400 Hz Level Tape 10 kHz PB Frequency Response Tape 15 kHz PB Frequency Response Tape 20 kHz PB Frequency Response Tape	VTVM to Output Jacks	Same as above	Main P.C.B. R110 R210 R195 R295	<ol style="list-style-type: none"> 1. Load a 400 Hz level tape and play it back. Adjust the Output Level control to a certain level (for example 0 dBV (1 V)). 2. Load 10 kHz, 15 kHz and 20 kHz PB frequency response tapes and play them back. Adjust the record/playback head azimuth screw to obtain maximum readings for both channels on the VTVM with each tape. Check that the playback levels are within the following ranges: For IEC/Nakamichi Standard: 10 kHz: -20 dB -2 to +2 dB 15 kHz: -20 dB -2 to +3 dB 20 kHz: -20 dB -2 to +4 dB For IEC March 1981 Standard: 10 kHz: -20 dB -2.5 to +1.5 dB 15 kHz: -20 dB -4.5 to +0.5 dB 20 kHz: -20 dB -6 to 0 dB (to be continued)

STEP	ITEM	SIGNAL SOURCE	OUTPUT CONNECTION	MODE	ADJUSTMENT	REMARKS
						<p>If the level for the 20 kHz tape is insufficient, adjust it by referring to "Playback Frequency Response Adjustment" in item 6.2.</p> <p>3. Conduct step 4 "Record/Playback Head Azimuth Alignment".</p>
7	Bias Oscillation Frequency Adjustment	None	Frequency Counter to CN2-2 on Tape Switch P.C.B.	Record, Pause Tape - Metal Eq. - 70 μ s Dolby NR - MPX - OFF	Tape Switch P.C.B. T301	Adjust T301 to obtain 105 kHz \pm 1 kHz on the frequency counter.
8	Record Amplifier Equalizer Adjustment	21 kHz (-20 dBV) to Input Jacks	VTVM to TP102, TP202 on Main P.C.B.	Same as above	Main P.C.B. L102 L202	<ol style="list-style-type: none"> Short the bias cut points indicated in Fig. 5 with a clip to stop bias oscillation. Adjust L102 (L202) to obtain peak reading at 21 kHz on the VTVM. Remove the clip.
9	Bias Trap Adjustment (Record Amp.)	None (remove input signals)	VTVM to TP103, TP203 on Main P.C.B.	Same as above	Main P.C.B. L103 L203	Adjust L103 (L203) to obtain minimum reading on the VTVM.
10	Record Level Calibration and Recording Bias Current Adjustment	400 Hz (0 dBV) and 15 kHz (-20 dBV) to Input Jacks	VTVM and Distortion Meter to Output Jacks	Record and Playback Tape - Metal/High/Normal Eq. - 70 μ s (Metal/High) 120 μ s (Normal) Dolby NR - OFF MPX - OFF	Main P.C.B. (Level) Metal: VR102 VR202 High: VR103 VR203 Normal: VR104 VR204 Tape Switch P.C.B. (Bias) Metal: VR105 VR205 High: VR106 VR206 Normal: VR107 VR207	Adjustment should be made in the order of Metal, High and Normal. <ol style="list-style-type: none"> Set the Bias Tune Control to its mechanical center position. Set the Output Level control to max. Load a reference ZX tape, reference SX tape and reference EXII tape. Set the cassette deck in Record/Pause mode. Feed in 400 Hz and adjust the Input Level controls to obtain 0 dBV (1 V) on the VTVM, and record, rewind and play it back. Adjust VR102 (VR202) for ZX tape, VR103 (VR203) for SX tape and VR104 (VR204) for EXII tape so that the playback output levels are 0 dBV (1 V) on the VTVM. Feed in 15 kHz (-20 dBV: 100 mV) and record, rewind and play it back. Adjust VR105 (VR205) for ZX tape, VR106 (VR206) for SX tape and VR107 (VR207) for EXII tape so that the playback output levels are -20 dBV (100 mV) on the VTVM. Repeat above 5 and 6 two or three times to obtain optimum performance. Feed in 400 Hz (0 dBV: 1 V) and record, rewind and play it back. Check to insure whether the total harmonic distortion is less than 1.0% for ZX and EXII tapes and 1.2% for SX tape. If the total harmonic distortion exceeds the specified value, repeat above steps till satisfactory results are obtained.

8. MOUNTING DIAGRAMS AND PARTS LIST

Notes: 1. Mounting diagram shows a dip side view of the printed circuit board.

2. Diode is 1SS53, 1S1555, or 1SS176 unless otherwise specified.

3. Following transistors are interchangeable with each other.

a. 2SA733, 2SA608SP, 2SA1048, 2SA1175

b. 2SC945, 2SC536SP, 2SC2458, 2SC2785

4. Abbreviation for part name:

TR — Transistor, SiD — Silicon Diode, GD — Germanium Diode, ZD — Zener Diode

RK — Carbon Resistor, RM — Metal Film Resistor, RF — Fail Safe Type Resistor, RW — Wire Wound Resistor

CE — Electrolytic Capacitor, CM — Mylar Capacitor, CC — Ceramic Capacitor, CP — PP Capacitor,

CF — Film Capacitor

8.1. Power Switch P.C.B. Ass'y




Fig. 8.1

8.2. Shut-off P.C.B. Ass'y




Fig. 8.2

8.3. LED P.C.B. Ass'y




Fig. 8.3

8.4. Timer Switch P.C.B. Ass'y




Fig. 8.4

8.6. Pitch Control P.C.B. Ass'y




Fig. 8.6

8.5. Headphone Volume P.C.B. Ass'y




Fig. 8.5

Schematic Ref. No.	Part No.	Description	Schematic Ref. No.	Part No.	Description	Schematic Ref. No.	Part No.	Description
	BA05230A	Power Switch P.C.B. Ass'y (U.S.A. & Canada)		CA80011A	Shut-off P.C.B. Ass'y		BA06122A	Headphone Volume P.C.B. Ass'y
	BA06067A	Power Switch P.C.B. Ass'y (Australia & Others)	Q601	OC80047A	Shut-off P.C.B. TR 2SC2812		OB60202A	Headphone Volume P.C.B.
	BA05229A	Power Switch P.C.B. Ass'y (Europe)	Q602	OB06388A	Photo Reflector NJL5141	VR302	OB30020A	Volume 50K(A)x2
			R601,603	OB09840A	RK 680 Leadless		OJ04842C	Pitch Control Holder (1)
			R602	OB09841A	RK 18K Leadless			
SW1	OB02573D	Power Switch P.C.B.		BA06131A	LED P.C.B. Ass'y		BA06124A	Pitch Control P.C.B. Ass'y
M2	OB70002A	Power Switch		OB60342A	LED P.C.B.		OB60337A	Pitch Control P.C.B. IC μ PD4066BC
	OB08342A	Spark Killer (U.S.A. & Canada)	LED302	OB06333A	LED (Red)		OB06144A	Pitch Control Volume 2K(B)
M2	OB08955A	Spark Killer (Australia & Others)	FC21	OB81065A	TLR124A Wire Mate 2P	IC604	OB30057A	Pitch Control Volume 2K(B)
M2	OB08445A	Spark Killer (Europe)	FC21	OB82116B	Ribbon Cable 2P	VR603	OB32043A	Semi VR 4.7K
	OB90059A	Spark Killer Cover (Europe) (1)		BA06128A	Timer Switch P.C.B. Ass'y	R663,664	OB05698A	RK 1.5K 1/4W J
	OJ04763A	Power Switch Holder (1)		OB60332A	Timer Switch P.C.B.	R665	OB09725A	RK 100K 1/6W J
	OE00612A	M3x6 @Pan (2A) (2)	R662	OB07437A	RK 2.7K 1/6W J	R666	OB09588A	RK 2.4K 1/4W J
	OE00752A	Eyelet 2x3 (2)	SW603	OB82126B	Slide Switch 2-3	CN6	OB81366A	2P-S Post
			FC9		Ribbon Cable 4P	CN7	OB08971A	3P-S Post

8.7. 6P Pin Jack P.C.B. Ass'y




Fig. 8.7

8.8. Remote Socket P.C.B. Ass'y




Fig. 8.8

8.9. 1/4" Jack Input P.C.B. Ass'y




Fig. 8.9

8.10. 1/4" Jack Output P.C.B. Ass'y




Fig. 8.10

8.11. Dolby NR Switch P.C.B. Ass'y




Fig. 8.11

Schematic Ref. No.	Part No.	Description	Schematic Ref. No.	Part No.	Description	Schematic Ref. No.	Part No.	Description
FC16	BA06115A	6P Pin Jack P.C.B. Ass'y	D711,712 713,714 715,716 VR301 R164,264 FC22/23 RM33/RV31	OB06398A	SiD 1SS176	R150,250	BA06120A	1/4" Jack Input P.C.B. Ass'y
	OB60333A	6P Pin Jack P.C.B.		OB30058A	Volume 10K (A)x2		OB60334A	1/4" Jack Input P.C.B.
	OB82591A	Ribbon Cable 3P		OB22289A	RM 3.48K 1/6W F		OB22365A	RM 16.2K 1/6W F
	OB81538A	6P Pin Jack (1)		OB81395A	7P-JP Connector		OB02348A	3P-JP Connector (1)
	BA06082A	Earth Lug Ass'y (1)		OB81010A	Dip Mate 3P (2)		OB81539A	Phone Jack (1)
	OB81010A	Dip Mate 3P (2)	OB81479A	8P DIN Socket	OB81010A	Dip Mate 3P (1)		
	BA06123A	Remote Socket P.C.B. Ass'y	OJ05159A	Remote Socket Holder (1)				
	OB60336A	Remote Socket P.C.B.						

Schematic Ref. No.	Part No.	Description	Schematic Ref. No.	Part No.	Description
	BA06121A	1/4" Jack Output P.C.B. Ass'y		BA06114A	Control Switch P.C.B. Ass'y
	OB60335A	1/4" Jack Output P.C.B.		OB60331A	Control Switch P.C.B.
IC306	OB06146A	IC NJM4558DD	Q702	OB10039A	TR 2SC1740S (S,E)
Q109,209	OB06299A	TR 2SC2878	Q703	OB10003A	TR 2SA1345
R155,255	OB09677A	RK 1K 1/6W J	Q704	OB10007A	TR 2SC3399
R156,256	OB09727A	RK 120K 1/6W J	Q705	OB10026A	TR 2SA933S (Q,R,S)
R157,257	OB22343A	RM 10K 1/6W F		OB06181A	SiD 1SS53
R158,258	OB22321A	RM 6.34K 1/6W F	D701,702	OB06398A	SiD 1SS176
R159,259	OB09701A	RK 10K 1/6W J	D707,708		
R160,260	OB09685A	RK 2.2K 1/6W J	709		
R161,261	OB09697A	RK 6.8K 1/6W J	LED701	OB06334A	LED (Green) TLG124A
R169,269	OB09725A	RK 100K 1/6W J	703,704	OB06333A	LED (Red) TLR124A
R343,344	OB09729A	RK 150K 1/6W J	LED702		
C155,255	OB01405A	CE 1μ 50V	705,706	OB09657A	RK 150 1/6W J
C156,256	OB01836A	CE 47μ 10V	R718,719	OB09667A	RK 390 1/6W J
C157,257	OB01412A	CE 10μ 16V	R720	OB09663A	RK 270 1/6W J
324			R721	OB09693A	RK 4.7K 1/6W J
	OB02348A	3P-JP Connector	R722	OB09677A	RK 1K 1/6W J
	OB81010A	Dip Mate 3P (1)	R723,725	OB01888A	RK 10K 1/4W J
	OB82119B	Ribbon Cable 3P (2)	R724	OB05557A	CM 0.015μ 50V J
			C703	OB70004A	Touch Switch 4.3mm
	OB81539A	Phone Jack (1)	SW701-708	QJ04747B	LED Reflector (6)
	BA06112A	Dolby NR Switch P.C.B. Ass'y		BA06113A	Tape Switch P.C.B. Ass'y
	OB60330A	Dolby NR Switch P.C.B.		OB60339A	Tape Switch P.C.B.
VR303	OB30016A	Volume 100K (A)x2	Q304	OB60609A	TR 2SB564 (L,M)
R151,251	OB01888A	RK 10K 1/4W J	T301	OB51232A	Bias Osc. Unit
R341	OB01682A	RK 6.8K 1/4W J	VR105,106	OB32009A	Semi VR 22K
R361,362	OB09677A	RK 1K 1/6W J	205,206		
SW305,306	OB70027A	Push Switch 2-Key	VR107,207	OB32010A	Semi VR 47K
FC1,DM30	OB81010A	Dip Mate 3P	R138,238	OB09653A	RK 100 1/6W J
DS31			R139,239	OB09695A	RK 5.6K 1/6W J
FC20/21	OB02349A	4P-JP Connector (1)	351,352		
	BA06130A	Volume P.C.B. Ass'y	353		
	OB60341A	Volume P.C.B.	R140,240	OB09707A	RK 18K 1/6W J
LED301	OB06333A	LED (Red) TLR124A	R197,297	OB09705A	RK 15K 1/6W J
			R317	OB09263A	RK 12K 1/4W J
VR110,210	OB31002A	Slide Volume 100K (A)	R318	OB09831A	RF 22 1W J
R172,272	OB09719A	RK 56K 1/6W J	R350	OB09837A	RF 10 1W J
C171,271	OB09282A	CC 100P 50V K	C118,218	OB41219A	CP 560P 100V J
SW601,602	OB07462A	Push Switch	C305	OB01403A	CE 47μ 16V
Cds301	OB06325B	Photocoupler MCD7214F	C306	OB09828A	CP 8200P 100V J
			C327	OB41223A	CP 820P 100V J
FC8	OB81011A	Dip Mate 4P	C330,331	OB05796A	CM 0.047μ 50V J
VM25/26			332		
FC17/JP32:	OB81012A	Dip Mate 5P	C333,334	OB09187A	CE 1μ 16V (BP)
FC20	OB81002A	Dip Mate 2P	SW301,302	OB70072A	Push Switch 5-Key (1)
	BA06129A	Indicator P.C.B. Ass'y	303,304		
	OB60340A	Indicator P.C.B.	CN2	OB81051A	2P-S Post
IC301	OB06369A	IC TA7612AP	SD29	OB81010A	Dip Mate 3P
IC701	OB11031A	IC TL092	FC2	OB81011A	Dip Mate 4P
Q701	OB06013A	TR 2SA733 (P,Q)	SM27/28		
ZD701,702	OB06191A	ZD 2.7V RD2.7E	FC5	OB81012A	Dip Mate 5P
D301,302	OB06181A	SiD 1SS53		QJ04768B	Earth Plate A (1)
D703,704	OB06398A	SiD 1SS176			
705,706					
R301	OB01888A	RK 10K 1/4W J			
R302	OB01887A	RK 5.6K 1/4W J			
R303	OB01857A	RK 1K 1/4W J			
R304	OB09797A	RK 120 1/4W J			
R305-314	OB09681A	RK 1.5K 1/6W J (10)			
R701	OB09677A	RK 1K 1/6W J			
R702,703	OB09725A	RK 100K 1/6W J			
704,709					
711,715					
R705	OB09709A	RK 22K 1/6W J			
R706	OB09685A	RK 2.2K 1/6W J			
R707	OB09701A	RK 10K 1/6W J			
R712	OB09749A	RK 1M 1/6W J			
R713,714	OB09737A	RK 330K 1/6W J			
R716	OB09717A	RK 47K 1/6W J			
R717	OB09713A	RK 33K 1/6W J			
C301	OB09281A	CC 150P 50V K			
C701	OB09868A	CF 0.1μ 50V J			
C702	OB09163A	CE 10μ 16V (BP)			
FC3/12	OB81012A	Dip Mate 5P			
FC6/17,16	OB81011A	Dip Mate 4P			
FC18/19	OB02356A	12P-JP Connector			

8.12. Volume P.C.B. Ass'y




Fig. 8.12

8.14. Control Switch P.C.B. Ass'y






Fig. 8.14




MAIN BUS A324

0000349



() IEC March 1981 Standard



Rec. + Play -6V
 Rec. + Play +12V

Line Mute

(4)

REMOTE SOCKET P.C.B. (1/2)

1/4 JACK OUTPUT P.C.B. (2/2)

DOLBY NR SWITCH P.C.B. (2/2)

E.g.

Rec. +10.7V
 Rec. +0.2V

Rec. Mute

Headphone

HEADPHONE VOLUME P.C.B.

Headphone Level

Line Mute

Rec.

Rec. 1

Rec. 2

PB Amp. Mute

Rec. Mute

to Pitch Ctrl

to Pitch Ctrl

to Pitch Ctrl

to Pitch Ctrl

to Pitch Ctrl

to Pitch Ctrl

to Pitch Ctrl

to Pitch Ctrl

to Pitch Ctrl

to Pitch Ctrl

to Pitch Ctrl

to Pitch Ctrl

to Pitch Ctrl

to Pitch Ctrl

to Pitch Ctrl

to Pitch Ctrl


to Pitch Ctrl


to Pitch Ctrl

to Pitch Ctrl

to Pitch Ctrl






to Pitch Ctrl








Cam Switch Operation


Mode	Cam Switch			Reel Motor
	Cam(0)	Cam(1)	Cam(2)	
Stop	ON	ON	OFF	OFF
Play	ON	OFF	ON	FWD
Pause	OFF	ON	ON	OFF
F.F./Rev.	ON	OFF	OFF	FWD/REV





- Notes: 1. Table of wire colors
- | | | | |
|--------------|--------------|--------------|-------------|
| BRN - Brown | YEL - Yellow | VIO - Violet | BLK - Black |
| RED - Red | GRN - Green | GRY - Gray | |
| ORN - Orange | BLU - Blue | WHT - White | |

2. Component side view of the P.C.B. is illustrated unless otherwise specified.



the P.C.B. is specified.

Fig. 10.1