

Service Manual

Portable Stereo CD System

Radio Cassette

RX-DS303

COMPACT
disc
DIGITAL AUDIO


Colour

(K) Black Type

Areas

Suffix for Model No.	Area	Colour
(EB)	Great Britain	(K)
(EG)	Europe	

TAPE DECK: RX-FD55 MECHANISM SERIES (AR300)
TRAVERSE DECK: RX-DT55 MECHANISM SERIES (S0DD110)

■ SPECIFICATIONS

General:

Power Requirement: AC; 230~240 V, 50 Hz
 Battery; 15 V (10 R20/LR20, UM-1 batteries)
 Memory Back-up for Computer/
 Clock; 6 V (4 R6/LR6, UM-3 batteries)

Power Consumption: 43 W
 Power Output: 45 W...PMPO
 Speaker: 10 cm PM Dynamic speaker 2.7Ω
 Input: MIX MIC; 5 mV/200~600Ω Ø3.5
 Output: HEADPHONES; 32Ω, Ø3.5
 Dimensions: 398 (W)×223 (H)×218 (D) mm
 Weight: 5.0 kg without batteries

Disc Player Section:

Sampling Frequency: 44.1 kHz
 D-A Conversion: 16-bit linear
 Beam Source: Semiconductor laser (wavelength 780 nm)
 No. of Channels: 2 channels, stereo
 Frequency Range: 20~20,000 Hz (+1/-2 dB)
 Wow and Flutter: Less than possible measurement data
 D/A Converter: MASH (1 BIT)

Radio Section:

Frequency Range: FM; 87.5~108 MHz
 LW; 144~288 kHz
 MW; 522~1611 kHz
 Intermediate Frequency: FM; 10.7 MHz
 AM (LW/MW); 459 kHz
 Sensitivity: FM; 9 dBμ/50 mW output
 MW; 37 dBμ/50 mW output
 LW; 39 dBμ/50 mW output

Tape Deck Section:

Frequency Range: 60~16,000 Hz (with normal tape)
 Recording System: AC bias, AC erase
 Tape Speed: 4.8 cm/s
 Monitor System: Variable sound monitor
 Track System: 4-track 2-channel stereo recording and playback

Notes:

- Weights and dimensions shown are approximate.
- Design and specifications are subject to change without notice.

Panasonic

■ CONTENTS

	Page
●PRECAUTION OF LASER DIODE	2
●LOCATION OF CONTROLS	3~7
●HANDLING PRECAUTIONS FOR TRAVERSE DECK	8
●DISASSEMBLY INSTRUCTIONS	8~16
●SCHEMATIC DIAGRAM	17~27
●CIRCUIT BOARD DIAGRAM	28~32
●WIRING CONNECTION DIAGRAM	33, 34
●OUTLINE OF THE DIGITAL SERVO	35
●WIRING CONNECTION PROCEDURES FOR USE DURING CHECKING AND ADJUSTMENT OF THE PCBs.	35~37

	Page
●MEASUREMENTS AND ADJUSTMENTS	37~40
●FUNCTION OF IC TERMINALS	41~45
●LCD	46
●BLOCK DIAGRAM	47~52
●TROUBLESHOOTING GUIDE	53, 54
●REPLACEMENT PARTS LIST	55~62, 67
●MECHANISM PARTS LOCATION	63, 64
●CABINET PARTS LOCATION	65, 66

CAUTION:

THIS PRODUCT UTILIZES A LASER.

USE OF CONTROLS OR ADJUSTMENTS OR PERFORMANCE OF PROCEDURES OTHER THAN THOSE SPECIFIED HEREIN MAY RESULT IN HAZARDOUS RADIATION EXPOSURE.

■ PRECAUTION OF LASER DIODE

CAUTION: This product utilizes a laser diode with the unit turned "on", invisible laser radiation is emitted from the pick up lens.

Wave length: 780 nm

Maximum output radiation power from pick up: 100 μ W/VDE

Laser radiation from the pick up lens is safety level, but be sure the followings:

1. Do not disassemble the optical pick up unit, since radiation from exposed laser diode is dangerous.
2. Do not adjust the variable resistor on the pickup unit. It was already adjusted.
3. Do not look at the focus lens using optical instruments.
4. Recommend not to look at pick up lens for a long time.


ACHTUNG: Dieses produkt enthält eine laserdioden. Im eingeschalteten zustand wird unsichtbare laserstrahlung von der lasereinheit abgestrahlt.

Wellenlänge: 780 nm

Maximale strehlungsleistung der lasereinheit: 100 μ W/VDE

Die strahlung an der lasereinheit ist ungefährlich, wenn folgende punkte beachtet werden:

1. Die lasereinheit nicht zerlegen, da die strahlung an der freigelegten laserdioden gefährlich ist.
2. Den werksseitig justierten einstellregler der lasereinheit nicht verstellen.
3. Nicht mit optischen instrumenten in die fokussierlinse blicken.
4. Nicht über längere zeit in die fokussierlinse blicken.



VORSICHT-Unsichtbare
Laserstrahlung, wenn
Abdeckung geöffnet und
Sicherheitsverriegelung
überbrückt. Nicht dem
Strahl aussetzen.

(Im Inneren des Gerätes)

DANGER-Invisible laser
radiation when open
and interlock defeated.
**AVOID DIRECT EX-
POSURE TO BEAM.**

(Inside of product)

**CLASS 1
LASER PRODUCT**

**ADVARSEL: USYNLIG LASERSTRÅLING
VED ÅBNING, NÅR SIKKERHEDSAF-
BRYDERE ER UDE AF FUNKTION.
UNDGÅ UDSÆTTELSE FOR STRÅLING.**

(Indersiden af apparatet)

**VARO! Avattaessa ja
suojalukitus ohitettaes-
sa olet alttiina
näkyvättömälle
lasersäteilylle.
Älä katso säteeseen.**


**LUOKAN 1 LASERLAITE
KLASS 1 LASER APPARAT**

**WARNING! Osynlig
laserstråling når
denna del är öppnad
och spårren är
urkopplad.
Betrakta ej strålen.**

LOCATION OF CONTROLS


The functions indicated by the numbers with a black background (for example 7) can also be activated from the remote control transmitter.
(See page 6.)

CD/GENERAL CONTROLS



- ① **Display section**
 - A: CD mode indicator (Cd)
 - B: Track display
 - C: Playing time display
 - D: Volume level display (VOLUME)
 - E: Program indicator (PROGRAM)
 - F: Random indicator (RANDOM)
 - G: Music matrix
 - H: Over mark indicator (▷)
 - I: Repeat indicator (◁)
- ② **Speakers (10 cm, 2.7Ω)**
- ③ **Operation/battery check/AC connection indicator (OPR/BATT STANDBY)**
The indicator lights up green when the unit is turned on. It functions as a battery check indicator when the unit is operated on batteries. When the AC mains supply is used, it functions as an AC connection indicator. (The indicator colour changes to red when the unit is turned off.)
- ④ **Remote control sensor**
- ⑤ **Compact disc holder**
- ⑥ **CD eject button (▲ CD EJECT)**
- ⑦ **Operation switch (OPERATION)**
- ⑧ **Skip/search buttons (◀ / ▶ / ⏮ / ⏭ / ⏪ / ⏩ / +)**
- ⑨ **CD mode/stop button (CD/□)**
Press this button to listen to a CD or to stop CD play.
- ⑩ **Play button (▷)**
Press this button to start disc play.
- ⑪ **Volume level control (VOLUME)**
- ⑫ **Tone control switch (TONE)**

TUNER CONTROLS



13 Display section

A: Band indicator (FM/MW/LW)

B: Frequency display

C: Program indicator (PROGRAM)

D: Channel number indicators (1-10)

E: Tuning indicator (TUNED)

F: Stereo indicator (STEREO)

G: Monaural indicator (MONO)

This indicator appears when the unit is set to monaural reception by pressing the FM mode/beep proof button on the remote control transmitter.


14 Tuning buttons (- / < / > / +)

15 Tuner/band button (TUNER/BAND)

Press this button to select the desired radio band.

DECK CONTROLS

16



16 Display section

A: Tape mode indicator (TAPE)

B: Tape counter

C: Recording indicator (REC)

D: Fast forward/rewind indicators (<< >>)

E: Running indicator

F: Reverse side playback/recording indicator (<)

G: Reverse mode indicator (< >)

H: Forward side playback/recording indicator (>)

I: Auto tape level setting indicator (ATLS)

17 Tape mode/stop button (TAPE/□)

Press this button to listen to a tape or stop tape play.

18 Rec-pause button (● II)

19 Forward-side playback button (>)

Press this button to begin playback (or recording) from the forward side of the tape.

20 Reverse-side playback button (<)

Press this button to begin playback (or recording) from the reverse side of the tape.

21 Cassette compartment cover


22 Fast buttons (<< >>)

Press one of these buttons to fast forward or rewind the tape.


23 Eject button (▲)

24 Automatic tape level setting button (ATLS)

Press this button to begin recording from a CD.



TIMER CONTROLS



25 Display section

- A: Timer ON indicator (ON)
 B: Timer play indicator (TIMER)
 C: Timer recording indicator (TIMER-REC)
 D: Timer OFF indicator (OFF)
 E: Sleep timer indicator (SLEEP)
 F: Timer display

26 Timer button (TIMER)

Press this button to select the desired timer mode (timer-play, timer-recording) and cancel the timer mode.

27 Time adjust button (ADJUST)


Press this button to adjust the time.

28 Timer check button (CHECK)

Press this button to check the preset timer mode (preset time and source).

29 Time set buttons (—/10/10/10/10/+)

REAR PANEL



- 30 Mixing microphone jack (MIX MIC) (Ø3.5, 200~600Ω)
 31 Headphones jack (PHONES) (Ø3.5, 32Ω)
 32 Handle
 33 Telescopic antenna
 34 AC socket (AC IN~)
 35 Battery compartment cover

REMOTE CONTROL OPERATION

■ Operations

The following operations can be performed using the remote control transmitter.

They are identical to the operations performed using the main unit controls.

● Operation Switch

Operation OFF when the unit is powered by dry batteries.

Operation ON/OFF when the unit is powered by an AC main supply.


The "OFF" position as same function as "BATT. STAND-BY" position on the main unit.

● CD operation

Selection of CD mode, sequential play, program play, direct access play, random play, repeat play, skip play, search play, program clear, pause, stop.

● The receiving angle is approx. 60° (30° in each of the left, right, up, and down directions).

● The maximum usable distance is about 7 m when the remote control transmitter is aimed directly at the remote control sensor.



36 Sleep timer button (SLEEP)

Press this button when you wish to fall asleep while listening to music.

37 Display button (DISPLAY)

Press this button when you wish to check the present time while listening to CD, radio or tape play.

38 FM mode/beat proof button (FM MODE/B.P)

The function of this button changes according to the selected radio band.

AM: Beat proof (for recording from the AM radio)

FM: MONO/STEREO

39 Cancel button (CANCEL)

40 Random button (RANDOM)

Press this button to let the microcomputer make a random selection of the sequence.

41 Repeat button (REPEAT)

Press this button to activate the repeat mode.

42 Tape counter reset button (COUNTER RESET)

43 Reverse mode select button (REVERSE MODE)

● Radio operations

Selection of tuner mode, band switching, preset tuning, FM mode selection/beat proof.

● Tape operation

Selection of tape mode, forward-side playback, reverse-side playback, stop, fast forward, rewind, recording pause, recording.

● Others

Sleep ON/OFF, display selection.

● Volume control

Volume up/down.

44 CD pause button (II)

Press this button to stop the disc play temporarily.

45 Program button (PROGRAM)

Press this button for programmed CD play and for preset memory of the tuner.

46 Numeric buttons (1-10/0, +10)

These buttons are used to specify the CD tracks (1-10/0, +10), and select the preset memory channel of the tuner (1-10/0).

Note:

Please refer to "LOCATION OF CONTROLS" (on pages 3-5) section for the controls not described above.

■ HANDLING PRECAUTIONS FOR TRAVERSE DECK

So, be careful of electrostatic breakdown during repair of the traverse deck (optical pickup).

1. Do not subject the traverse deck (optical pickup) to static electricity as it is extremely sensitive to electrical shock.
2. To prevent the breakdown of the laser diode, an anti-static shorting pin is inserted into the flexible board (FPC board). When removing or connecting the short pin, finish the job in as short time as possible.
3. Take care not to apply excessive stress to the flexible board (FPC board).
4. Do not turn the variable resistor (laser power adjustment). It has already been adjusted.


1. **Human body grounding**
Use the anti-static wrist strap to discharge the static electricity from your body.
2. **Work table grounding**
Put a conductive material (sheet) or steel sheet on the area where the traverse deck (optical pickup) is placed, and ground the sheet.

Caution: The static electricity of your clothes will not be grounded through the wrist strap. So, take care not to let your clothes touch the traverse deck (optical pickup).


3. Press one of the time set buttons to display 20, then press the time adjust button to finish setting the time. The display will change to the previous display. Note that the minute "0" display appears following "59" but that the hour display is not changed.

■ DISASSEMBLY INSTRUCTIONS

Ref. No. 1	Removal of the Front Cabinet
Procedure 1	















1. Remove the battery cover.
2. Remove screws ❶~❸.












3. Press the cassette eject button to open the cassette compartment cover.
4. Remove the front cabinet in the direction indicated by the arrow.





5. Disconnect connector CP604.





Ref. No. 2 Removal of the Mechanism	Ref. No. 13 Removal of the Amplifier P.C.B.
Procedure 1→2  1. Remove screws ①~④.	Procedure 1→3→7→11→13  2. Pull out the mechanism. 3. Disconnect connectors CP302 and CP303.
Ref. No. 3 Removal of the Top Cabinet	Ref. No. 15 Removal of Battery P.C.B. (A)
Procedure 1→3  1. Raise the handle. 2. Remove screws ① and ②. 3. Press the CD eject button to open the CD cover. 4. Remove the two screws (③ and ④). 5. Close the CD cover and remove the top cabinet in the direction indicated by the arrow.	Procedure 1→3→4→5  •Unhook the eight prongs.
Ref. No. 4 Removal of the Operation Control P.C.B.	Ref. No. 5 Removal of the Operation Buttons
Procedure 1→3→4  1. Disconnect connector CM801. 2. Unhook the eight prongs.	Procedure 1→3→4→5  •Unhook the eight prongs.





Ref. No. 6 Removal of the Handle	Ref. No. 7 Removal of the CD Unit
Procedure 1→3→6  •Unhook the prongs in the directions indicated by arrows ① and then remove the handle in the direction indicated by arrow ②.	Procedure 1→3→7  1. Disconnect connector CS605. 2. Remove screws ①~④.
Ref. No. 8 Removal of the CD P.C.B.	Ref. No. 11 Removal of the Center Block
Procedure 1→3→7→8  1. Remove screws ① and ②. 2. Unhook the two prongs in the directions indicated by the arrows.	Procedure 1→3→10→11  3. Disconnect connectors CS701, CP702, and CP703. (After disconnecting CS701, attach a short-circuit pin to the flexible P.C.B.; refer to page 8 for details.)
Ref. No. 9 Removal of the Traverse Unit	Ref. No. 12 Removal of the Main P.C.B.
Procedure 1→3→7→9  1. Use needle-nosed pliers to remove the pins as shown. (If the pins are broken, replace them.)	Procedure 1→2→3→7→10→11→12  2. Remove the traverse unit from the chassis.

Ref. No. 10	Removal of the Tuner P.C.B.	
Procedure 1→10	 1. Pull out the tuner P.C.B. in the direction indicated by the arrow.	 2. Disconnect connectors CP1 and CP3.
Ref. No. 11	Removal of the Center Block	
Procedure 1→3→10→11	 1. Remove screws ①~④. 2. Disconnect connector CP901.  3. Remove the speaker output connector P.C.B. in the direction indicated by arrow ①. 4. Remove the center block in the direction indicated by arrow ②.	
Ref. No. 12	Removal of the Main P.C.B.	
Procedure 1→2→3→7→ 10→11→12	 1. Disconnect connector CM801. 2. Remove screws ①~④.  3. Detach the parallel cables from their attachments. 4. Remove the main P.C.B. in the direction indicated by the arrows.	


Ref. No. 13	Removal of the Amplifier P.C.B.	Ref. No. 14	Removal of the Power P.C.B.
Procedure 1→3→7→ 11→13	 1. Detach the parallel cables from their attachments. 2. Press the two prongs in the directions indicated by arrows ① and remove the amplifier P.C.B. in the direction indicated by arrow ②.	Procedure 1→14	 1. Disconnect connectors CP901 and CP902. 2. Remove screws ①~⑤.
Ref. No. 15	Removal of Battery P.C.B. (A)	Ref. No. 16	Removal of Battery P.C.B. (B)
Procedure 1→15	 1. Disconnect connector CP902.	Procedure 1→16	 •While pressing the prong in the direction indicated by arrow ①, remove battery P.C.B. (B) in the direction indicated by arrow ②.

Ref. No. 17	Removal of Battery P.C.B. (C)	Ref. No. 18	Removal of the Back-up Battery P.C.B.
Procedure 1→2→17	 ●While pressing the prong in the direction indicated by arrow ①, remove battery P.C.B. (C) in the direction indicated by arrow ②.	Procedure 1→2→18	 ●While pressing the prong in the direction indicated by arrow ①, remove the back-up battery P.C.B. in the direction indicated by arrow ②.
Ref. No. 19	Removal of the Mechanism Control P.C.B.	 1. Disconnect connectors CP301 and J971. 2. Remove the soldering from the motor wires. 3. Remove screws ①. 4. Detach the P.C.B. from the two bosses. 5. Move the P.C.B. to detach it from the hooks.	
Ref. No. 20	Removal of the CD Cover	 1. Detach the rib in the direction indicated by arrow ①. 2. Remove the CD cover in the direction indicated by arrow ②.	


Ref. No. 21	Removal of the Disc Holder	Ref. No. 22	Disassembly of the Disc Holder
Procedure 21	 1. Press the CD eject button to open the CD cover. 2. Slide the disc holder in the direction indicated by arrow ① and remove it in the direction indicated by arrow ②.	Procedure 21→22	 1. Unhook the three prongs in the directions indicated by the arrows. 2. Disassemble the disc holder into the three parts shown above.
Ref. No. 23	Removal of the CD Eject Button	Ref. No. 24	Removal of the CD Eject Lever
Procedure 1→3→23	 1. Unhook the three prongs in the directions indicated by arrows ①. 2. Remove the CD eject button in the direction indicated by arrow ②.	Procedure 1→3→24	 1. Unhook the two prongs in the directions indicated by arrows ①. 2. Remove the CD eject lever in the direction indicated by arrow ②.

Ref. No. 25 Removal of the CD Cover Detection Button	Ref. No. 26 Removal of the Cassette Holder
Procedure 1→3→25  1. Unhook the two prongs in the directions indicated by arrows ①. 2. Remove the CD cover detection button in the direction indicated by arrow ②.	Procedure 1→26  ●Detach the ribs in the direction indicated by the arrows.
Ref. No. 27 Removal of the Speakers	
Procedure 1→27  ●Remove screws ①~⑧.	
Ref. No. 28 Removal of the Cassette Eject Lever	
Procedure 1→28  ●Remove the cassette eject lever by moving it in the directions indicated by arrows ①, ②, and ③, in that order.	


●Installation of the Cassette Holder



●Installation of the CD Cover



●If the tape has become entangled



CHROMATIC DIAGRAM



IAGRAM • TUNER AND CD CIRCUIT

■ SCHEMATIC DIAGRAM

Notes:

- S601 : CD cover open/close detect switch.
- S801 : Timer switch. (TIMER)
- S802 : Tone control switch. (TONE)
- S803 : CD skip/search switch. (←/▶◀◀/▶▶▶)
- S804 : CD skip/search switch. (▶▶/▶▶▶ / +)
- S805 : Time adjust switch. (ADJUST)
- S806 : Timer check switch. (CHECK)
- S807 : Volume level control switch. (– VOLUME)
- S808 : Volume level control switch. (VOLUME +)
- S809 : Operation switch (OPERATION)
- S810 : Tuner/Band switch. (TUNER/BAND)
- S811 : CD mode/stop switch. (CD/■)
- S812 : CD play switch. (▶)
- S813 : Tape fast rewind switch. (◀◀)
- S814 : Tape reverse-side playback switch. (◀)
- S815 : Tape mode/stop switch. (TAPE/■)
- S816 : Tape forward-side playback switch. (▶)
- S817 : Tape fast forward switch. (▶▶▶)
- S818 : Rec-pause switch. (●|||)
- S819 : Automatic tape level setting switch. (ATLS)
- S901 : AC/DC select switch.
- S1001 : Laser on/off switch.
(for Mechanism control/Mechanism circuit)
- S971 : Mode detect switch.
- S972 : Cassette tape insertion detect switch.
- S973 : Record prevention tab detect switch. (REV)
- S974 : Record prevention tab detect switch. (FWD)
- S975 : No connect.
- S976 : No connect.
- VR301 : Tape speed adjustment VR.

General

- DC voltage measurements are taken with electronics voltmeter.
The negative terminal of the battery provides negative meter connection point.

No mark...TAPE PLAYBACK

「...TUNER (())...CD []...REC

[]...REC

Measurement instructions

LW/MW	: 74
EM	: 60


FM : 600
TAPE : 315

CD : 1 kHz

... ..


ogy.

100





WIRING CONNECTION DIAGRAM




OUTLINE OF THE DIGITAL SERVO


- The servo circuit used in the CD section employs a newly developed digital servo system in place of the analog servo system which was used in previous models.
- For an outline of this new digital servo, refer to pages 43 and 44 of Service Manual RX-DT505 (EB) (EG), Order No. AD9204111C2.

WIRING CONNECTION PROCEDURES FOR USE DURING CHECKING AND ADJUSTMENT OF THE PCBs

- To obtain audio output during checking and adjustment of the PCBs, prepare a jig as shown below and obtain the audio output via the headphone jack.




- To obtain audio output through the speakers without using a headphones jack output jig, connect as shown below.



Checking and adjustment of the tuner P.C.B.

- Use Ref. No. 1 of the disassembly instructions (see page 8) to remove the front cabinet.




- Pull out the tuner P.C.B.

- Disconnect connector CP3.


- Position as shown in the diagram above.

Checking and adjustment of the tape deck P.C.B.

- Use Ref. No. 1 of the disassembly instructions (see page 8) to remove the front cabinet.



- Remove screws ①~④.
- Pull out the mechanism.




- Position as shown in the diagram above.


Checking and adjustment of the CD P.C.B.

- The extension cables shown below are needed to check and adjust the CD P.C.B.


- Extension cable kit model No.: RFKZ0009 (one set of two extension cables)




- Use Ref. No. 3 of the disassembly instructions (see page 9) to remove the top cabinet.
- Use Ref. No. 6 of the disassembly instructions (see page 10) to remove the handle.



- Remove screws ①~④.




- Connect extension cable RFKZ0009 to connector CP701.



Checking of the main P.C.B.


- Use Ref. No. 4 of the disassembly instructions (see page 9) to remove the operation P.C.B.
- Use Ref. No. 12 of the disassembly instructions (see page 11) to remove the main P.C.B.



- Raise the main control P.C.B.
 - Connect the operation P.C.B.
 - Connect the power supply connector to the power P.C.B.
- Now the main P.C.B. can be checked.

●Checking of the amplifier P.C.B.

1. Use Ref. No. 11 of the disassembly instructions (see page 11) to remove the center block.



2. Turn the center block over and place it upside down.
3. Connect the power supply connector to the power P.C.B.
●Now the amplifier P.C.B. can be checked.

MEASUREMENTS AND ADJUSTMENTS

<TUNER SECTION>

●ALIGNMENT INSTRUCTION

READ CAREFULLY BEFORE ATTEMPTING ALIGNMENT	
●Set power source voltage to 15 V DC. ●Set power switch to ON. ●Set function switch to TUNER/AM.	●Set volume control to -12 dB. ●Output of signal generator should be no higher than necessary to obtain an output reading.

●MW-RF ALIGNMENT (The parts other than the ones listed below are aligned at the factory before they are supplied. Therefore, alignment of those parts is unnecessary when used for replacement.)

SIGNAL GENERATOR or SWEEP GENERATOR		RADIO DIAL SETTING	INDICATOR (ELECTRONIC VOLTMETER or OSCILLOSCOPE)	ADJUSTMENT (Refer to Fig. 1.)	REMARKS
CONNECTIONS	FREQUENCY				
Fashion a loop of several turns of wire and radiate a signal into the loop ant. of receiver.	594 kHz	Tune to signal	Headphones Jack (32Ω) (Fabricate the plug as shown in Page 35 and then connect the lead wires of the plug to the measuring instrument.)	(*1) L5-1 (MW ANT Coil)	Adjust for maximum output. Adjust L5-1 by moving coil along the ferrite core.
"	1503 kHz	"	"	CT1 (MW ANT Trimmer)	Adjust for maximum output.

(*1) Fix antenna coil with wax after completing alignment.

●LW-RF ALIGNMENT

SIGNAL GENERATOR or SWEEP GENERATOR		RADIO DIAL SETTING	INDICATOR (ELECTRONIC VOLTMETER or OSCILLOSCOPE)	ADJUSTMENT (Refer to Fig. 1.)	REMARKS
CONNECTIONS	FREQUENCY				
Fashion a loop of several turns of wire and radiate a signal into the loop ant. of receiver.	162 kHz	Tune to signal	Headphones Jack (32Ω) (Fabricate the plug as shown in Page 35 and then connect the lead wires of the plug to the measuring instrument.)	(*2) L5-2 (LW ANT Coil)	Adjust for maximum output. Adjust L5-2 moving coil along the ferrite core.
"	270 kHz	"	"	CT2 (LW ANT Trimmer)	Adjust for maximum output.

(*2) Fix antenna coil with wax after completing alignment.

<CASSETTE DECK SECTION>

●ALIGNMENT INSTRUCTION

READ CAREFULLY BEFORE ATTEMPTING ALIGNMENT	
●Set power source voltage to 15 V DC. ●Set power switch to ON. ●Set function switch to TAPE.	●Set volume control to -12 dB. ●Output of signal generator should be no higher than necessary to obtain an output reading.

●HEAD AZIMUTH ALIGNMENT

TEST TAPE	INDICATOR (ELECTRONIC VOLTMETER or OSCILLOSCOPE)	ADJUSTMENT	SPECIFICATION	REMARKS
QZZCFM (8 kHz, -20 dB)	Headphones Jack (32Ω) (Fabricate the plug shown in Page 35 and then connect the lead wires of the plug to the measuring instrument.)	Azimuth Screw (Refer to Fig. 2.)	Maximum output.	1. Playback mode. 2. Adjust for maximum output.

●TAPE SPEED ALIGNMENT

TEST TAPE	INDICATOR (FREQUENCY COUNTER)	ADJUSTMENT	SPECIFICATION	REMARKS
QZZCWAT (3 kHz, -10 dB)	Headphones Jack (32Ω) (Fabricate the plug shown in Page 35 and then connect the lead wires of the plug to the measuring instrument.)	VR301 (Refer to Fig. 3.)	3000±20 Hz	1. Playback mode. 2. Adjust VR301, for 3000±20 Hz reading on frequency counter.

●RECORD BIAS CHECK

TEST TAPE	INDICATOR (ELECTRONIC VOLTMETER or OSCILLOSCOPE)	ADJUSTMENT	SPECIFICATION	REMARKS
Use Normal tape	TP6 ... (+) TP4 ... (-) (Refer to Fig. 4.)	—	12±1 mV	●Record mode

●ALIGNMENT POINT

●Please refer to Circuit Board and Wiring Connection Diagram for test point locations.




Fig. 1




Fig. 2





Fig. 3



Keep these cords short. (Line capacitance: 3 pF or less)

●In order not to influence the bias oscillation, divide the voltage with 1 MΩ and 1 kΩ resistors, and measure the voltage across the 1 kΩ resistor.

Fig. 4

<CD SECTION>

Caution:

- It is very dangerous to look at or touch the laser beam. (Laser radiation is invisible.)
- With the unit turned "on", laser radiation is emitted from the pickup lens.
- Avoid exposure to the laser beam, especially when performing adjustments.

Measuring Instruments and Special Tools

●Test disc

1. Playability test disc (SZZP1054C)
2. Uneven test disc (SZZP1056C)

- Allen wrench (M2.0) (SZZP1101C)
- Oscilloscope

(1) MECHANICAL ADJUSTMENT


- When the traverse deck is replaced, making adjustments is not necessary. (The traverse deck ass'y is already adjusted.)
- Make adjustments to improve playability when the traverse deck has not been replaced. Make the electrical adjustments first.

1. Connect the oscilloscope's CH. 1 probe across **TP702** (+) and **TP703** (V-REF) on the Servo P.C.B.

Oscilloscope setting:

VOLT 200 mV
 SWEEP 0.5 μ sec
 Input coupling AC

2. Switch the player power **ON**, and play track 19 on the test disc (SZZP1056C).
3. Leave the player in Play mode and place it as shown in the figure on the right.
4. Alternately adjust the two mechanical adjusting screws with the 2.0 mm allen wrench (SZZP1101C) until the RF signal amplitude variation on the oscilloscope is minimized. (Shown in Fig. 6)
5. After completing the adjustment, lock the **mechanical adjustments** with lock paint (RZZOL01).



A Minimize the variation of amplitude.


(2) BEST EYE (PD BALANCE) ADJUSTMENT

1. Connect the oscilloscope's CH. 1 probe across **TP702** (+) and **TP703** (V-REF) on the Servo P.C.B.

Oscilloscope setting:

VOLT 200 mV
 SWEEP 0.5 μ sec
 Input coupling AC

2. Switch the player power **ON**, and play the 1 kHz (track 1) on test disc (SZZP1054C).
3. Adjust **VR701** until the RF signal eye pattern amplitude is maximized.



B Maximize the amplitude

(3) CHECK OF PLAY OPERATION AFTER ADJUSTMENT***Checking Skip Search**

1. Play an ordinary musical program disc.
2. Press the skip button to check for normal skip search operation (in both the forward and reverse directions).

***Checking Manual Search**


1. Play an ordinary musical program disc.
2. Press the manual search button to check for smooth manual search operations at either low or high speed (in both the forward and reverse directions).

***Checking Playability**

1. Play the 0.7 mm black dot and the 0.7 mm wedge on the test disc (SZZP1054C) and verify that no sound skip or noise occurs.
2. Play the middle tracks of the uneven test disc and verify that no sound skip or noise occurs.

●ALIGNMENT POINT

- Please refer to Circuit Board and Wiring Connection Diagram for test point locations.



FUNCTION OF IC TERMINALS

•IC601 (MND2410RUK2)

Pin No.	Mark	I/O Division	Function
1	VDD	I	+5 V
2	OSC1	O	Clock output (4 MHz)
3	OSC2	I	Clock input (4 MHz)
4	VSS	—	GND
5	XI	I	Clock input (32 kHz)
6	XO	O	Clock output (32 kHz)
7	VREF-	—	AD converter reference voltage (GND)
8	ADIN7	I	AD converter signal input (Tape deck switch)
9	ADIN6	I	AD converter signal input (Tape deck switch)
10	M/ST	O	FM mode select signal output (L: STEREO H: MONO)
11	MBP1	O	Beat proof control signal output
12	MBP2		
13 15	ADIN2 ADIN0	I	AD converter signal input (Operation control switch)
16	VREF+	I	AD converter reference voltage (VDD)
17	TONE1	O	Tone control signal output
18	TONE2		
19	BEEP	O	Beep signal output
20	PWM	O	Electric volume control signal output
21	MKDATA	O	Deck control data output
22	MKCLK	O	Deck control clock output
23	LOUDNESS	O	Audio signal control output
24	NC	—	—
25	PLL CL	O	PLL tuner clock signal output
26	POWER CONT	O	Power supply circuit control
27	MUTE A	O	Muting control signal output
28	PLL CE	O	PLL tuner strove signal output
29	NC	—	—
30	PLL DI	O	PLL tuner control data signal output
31	REMOCON IN	I	Remote control signal input
32	BLKCK	I	Sub code block clock input

Pin No.	Mark	I/O Division	Function
33	STATUS	I	CD status signal input
34	CD RESET	I	CD reset signal input
35	RST	I	System reset signal input
36	MLD	O	CD signal process strove signal input
37	MDATA	O	CD signal process data input
38	MCLK	O	CD signal process clock signal input
39	CLDCK	O	CD sub-code clock output
40	SUBQ	I	CD sub-code data input
41	—	—	—
42	SYNC	—	—
43	CM	—	—
44	TLOCK	I	CD tracking signal input
45	FLOCK	I	CD focus lock signal input
46	CD REST SW	I	Rest switch signal input
47	CD OPEN SW	I	Disc tray open detection switch signal input
48	CD CLOSE SW	I	Disc tray close detection switch signal input
49	SENSE	I	CD sense signal input
50	REM STBY	I	Remote control sensor power control
51	POWER DET	I	Power detection signal input
52 55	—	—	—
56	DMUTE	O	Muting control signal output
57	TAPE H	O	Function signal output (TAPE: H)
58	CD H	O	Function signal output (CD: H)
59	TUH	O	Function signal output (TUNER: H)
60	STLED	I	FM stereo signal input
61	TUNE	I	Tuning signal input
62	DES1	—	—
63	DES2		
64 93	SEG29 SEG0	O	LCD segment signal output
94 97	COM3 COM0	O	LCD common signal output
98 100	VLC3 VLC1	I	LCD bias reference voltage input

•IC303 (BU2040F)

Pin No.	Mark	I/O Division	Function
1	GND	—	GND
2	DATA	I	Deck control data input
3	CLK	I	Deck control clock input
4	BP3	—	—
5	NC	—	—
6	DMT.H	O	Deck muting control signal output
7	BP2	O	Beat proof control signal output
8	DMT	O	Deck muting control signal output

•IC701 (AN8800SCE2)

Pin No.	Mark	I/O Division	Function
1	LDG	I	+5 V input
2	LDP	—	—
3	LD	O	Laser power control output
4	LPD	I	Laser power monitor input
5	GND	—	Ground terminal
6	LDON	I	Laser power control input
7	AMPI	I	RF signal input
8	AMPO	O	RF signal output
9	RFIN	I	RF signal input
10	RFEQ	—	Ground
11	C.AGC	I	AGC detecting capacitor input
12	ARF	O	RF signal output
13	C.SBDO	I	Dropout detecting capacitor input
14	RFDET	O	RF detections signal output
15	BDO	O	Black dropout detection output
16	VCC	I	Power supply (+5 V input)
17	SDO	O	System dropont detection output
18	VAD+	O	A/D converter reference voltage output
19	VREF	O	Reference voltage output
20	VAD-	O	A/D converter reference voltage output
21	OFTR	O	Off track detection output

Pin No.	Mark	I/O Division	Function
9	NC	—	—
10	NC	—	—
11	REC L	O	Recording control signal output
12	MOTOR	O	Motor control signal output
13	REC L	O	Recording control signal output
14	PL	O	Plunger control signal output
15	PL	O	Plunger control signal output
16	VDD	I	+5 V

Pin No.	Mark	I/O Division	Function
22	PLAY	I	Play signal input
23	WVEL	I	High speed signal input
24	TES	I	Tracking error signal input
25	PTO	—	—
26	PTI	I	Traverse speed detection signal input
27	PBO	—	—
28	POT	I	Position detecting buffer input
29	CROSS	O	Tracking error cross detection output
30	TE	O	Tracking error output
31	TEBAL	I	Tracking error gain detecting filter input
32	TBAL	I	Tracking balance adjustment
33	VDET	O	Vibration detection signal output
34	FE	O	Focus error output
35	FBAL2	I	Focus balance adjustment
36	FBAL2		
37	VCC	I	Power supply (+5 V input)
38	GND	—	Ground
39	PDBD	I	Photo detector current input
40	PDA	I	
41	PDB	I	
42	PDAD	I	

●IC702 (TCA0372DM2R)

Pin No.	Mark	I/O Division	Function
1	GND	—	GND
2	NC	—	—
3	VOUT1	O	Spindle motor control
4	VCC	I	+7.5 V
5	VOUT2	O	Spindle motor control
6	NC	—	GND
7	NC	—	GND
8	GND	—	GND

●IC703 (AN8377N): Motor Drive

Pin No.	Mark	I/O Division	Function
1	PVCC	I	Driver power supply (+8.9 input)
2	VCC	I	Power supply (+8.9 V input)
3	TB	O	External transistor base driving output
4	VMON	O	Voltage output
5	TVDI	I	Traverse error signal input
6	TDI	I	Focus error signal input
7	FDI	I	Tracking error signal input
8	VREF	I	Reference voltage input

●IC705 (MN6475A-T1)

Pin No.	Mark	I/O Division	Function
1	LRCK	I	Clock input
2	BCLK	I	Serial data bit clock input
3	SRDATA	I	Serial data input
4	COT1	—	Ground
5	COT2		
6	TEST		
7	VDD	I	Power supply (+5 V input)
8	X2	—	Clock (f=33.8688 MHz)
9	X1		
10	VSS	—	Ground
11	AVDDL	I	Power supply (+5 V input)
12	OUT.L	O	AF signal output (Lch)

Pin No.	Mark	I/O Division	Function
9	GND	—	GND
10	NC	—	GND
11	-VIN2	I	Spindle motor control
12	+VIN2	I	Spindle motor control
13	+VIN1	I	Spindle motor control
14	-VIN1	I	Spindle motor control
15	NC	—	GND
16	GND	—	GND

Pin no.	Mark	I/O Division	Function
9	FD+	O	Non-inverting output of focus driver
10	FD-	O	Inverting output of focus driver
11	TD+	O	Non-inverting output of tracking driver
12	TD-	O	Inverting output of tracking driver
13	TVD+	O	Inverting output of traverse driver
14	TVD-	O	Non-inverting output of traverse driver
15	RESET	O	Reset signal output
16	PC	I	PC input (connect to GND)

Pin No.	Mark	I/O Division	Function
13	AVSS.L	—	Ground
14	AVSS.R	—	Ground
15	OUT.R	O	AF signal output (Rch)
16	AVDD.R	I	Power supply input
17	/RST	I	Reset signal input
18	PWM	—	—
19	TP	—	Ground
20	WVEL	I	High speed status signal input
21	DEMPH	I	De-emphasis signal input
22	CSEL	I	+5 V input
23	192FS	—	—
24	768FS	O	Clock output (f=16.9344 MHz)

●IC704 (MN6650A)

Pin No.	Mark	I/O Division	Function
1	TES	O	Tracking error signal output
2	PLAY	O	Play signal output
3	/RFDET	I	RF detection signal input
4	DO	I	Dropout signal input
5	OFT	I	Off track signal input
6	ARF	I	RF signal input
7	WVEL	O	High speed status signal output
8	PBO	I	Potension buffer signal input
9	TE	I	Tracking error signal input
10	FE	I	Focus error signal input
11	VR2	I	A/D reference voltage input
12	VR1	I	A/D reference voltage input
13	LDON	O	Laser power control signal output
14	VSS	—	Ground
15	AVSS	—	Ground
16	AVDD	I	Power supply (+5 V input)
17	VDD	I	Power supply (+5 V input)
18	TRV	O	Traverse servo control output
19	TVD	O	Traverse drive output
20	FOD	O	Focus drive output
21	TRD	O	Tracking drive output
22	KICK	O	Track kick signal output

Pin No.	Mark	I/O Division	Function
23	/TEST	I	+5 V input
24	VSS	—	Ground
25	CLVS	I	Spindle servo signal input
26	/TRON	O	Tracking servo signal output
27	MDATA	I	Command data input
28	MCLK	I	Command clock signal input
29	MLD	I	Command load signal input
30	SENSE	O	Sense signal output
31	/FLOCK	O	Focus servo signal output
32	/TLOCK	I	Tracking servo signal output
33	/RST	I	Reset signal input (L: Reset)
34	XI	I	Clock input (fXI=16.9344 MHz)
35	TO	—	Open
36	T1		
37	T2		
38	T3	—	Ground
39	T4		
40	T5		
41	T6	—	Ground
42	VDET		
43	TBAL	O	Tracking balance adjustment output
44	TRCRS	I	Track cross signal input


•IC706 (MN6626)

Pin No.	Mark	I/O Division	Function
1	AVSS	—	Ground
2	IREF	I	Reference current input
3	ARF	I	RF signal input
4	DRF	I	DSL bias input
5	DSL F	O	DSL loop filter
6	PLL F	I	PLL loop filter
7	AVDD	I	Power supply (+5 V input)
8	RSEL	I	+5 V input
9	TBUS7	—	Test terminal (Ground)
16	TBUS0	—	
17	FLAG	—	
18	IPFLAG	—	
19	FCLK	—	
20	BTYCK	—	
21	WDCK	—	
22	/RST	I	
23	TX	O	
24	LDG	—	
25	RDG	—	
26	SRDATA	O	
27	SCK	O	Serial bit clock output
28	LRCK	O	Clock output
29	XCK	O	Clock output (f= 16.9344 MHz)
30	PMCK	—	
31	CSEL	I	
32	PSEL	—	Ground
33	×1	I	Clock input (f= 16.9344 MHz)
34	×2	—	
35	VSS	—	


Pin No.	Mark	I/O Division	Function
36	SUBQ	O	Sub-code (Q data) output
37	SQCK	I	Sub-code (Q data) clock input f= 7.3 kHz
38	/CLDCK	—	
39	BLKCK	O	
40	DEMPH	O	De-emphasis ON signal output
41	MEMPH	I	Enphasis signal input
42	MLD	I	Command load signal input
43	MCLK	I	Command clock signal input
44	MDATA	I	Command data input
45	DMUTE	I	Muting control signal input
46	SMCK	O	Clock output (f= 4.2336 MHz)
47	STAT	O	Status signal output
48	CRC	—	
49	SUBC	—	
50	SBCK	I	Clock for sub-code serial output
51	/TRON	I	Tracking servo ON signal input
52	CLVS	O	Spindle servo signal output
53	PC	—	
54	ECM	O	
55	ECS	O	Spindle motor control signal output
56	VDD	I	Power supply (+5 V input)
57	/TEST	I	+5 V input
58	SSEL	I	+5 V input
59	MSEL	—	
60	RESY	—	
61	DO	I	Drop out signal input
62	EFM	—	
63	PCK		
64	PDO		

■ LCD


•SEGMENT




•COMMON



BLOCK DIAGRAM




BLOCK DIAGRAM



TROUBLESHOOTING GUIDE (CD SECTION)

REPLACEMENT PARTS LIST



REPLACEMENT PARTS LIST

Notes: *Important safety notice:
Components identified by Δ mark have special characteristics important for safety.
Furthermore, special parts which have purposes of fire-retardant (resistors), high-quality sound (capacitors), low-noise (resistors), etc. are used.
When replacing any of components, be sure to use only manufacturer's specified parts shown in the parts list.
*The parenthesized indications in the Remarks columns specify the areas. (Refer to the cover page for area.)
Parts without these indications can be used for all areas.
*Warning: This product uses a diode. Refer to caution statements on page 2.


TROUBLESHOOTING GUIDE (CD SECTION)

Ref. No.	Part No.	Part Name & Description	Remarks	Ref. No.	Part No.	Part Name & Description	Remarks
		INTEGRATED CIRCUIT(S)		Q304	2SD965Q	TRANSISTOR	
				Q305-308	2SC3311R	TRANSISTOR	
				Q309	UN4217TA	TRANSISTOR	
IC1	RV1TA7358FT	I. C, FM FRONT END		Q310-312	2SC3311R	TRANSISTOR	
IC2	TA8132AFET	I. C, FM/AM IF AMP		Q313	2SB1030QRSTA	TRANSISTOR	
IC3	LM7001	I. C, PLL SYNTHESIZER		Q314	UN4216-S	TRANSISTOR	
IC301	BA7755	I. C, R/P SELECT		Q316, 317	UN411FTA	TRANSISTOR	
IC302	TA8142AP	I. C, P. B EQ/REC AMP		Q401	2SC3312RTA	TRANSISTOR	
IC303	BU2040F	I. C, SYSTEM CONTROL		Q402	2SD1450RTA	TRANSISTOR	
IC601	MND2410RUK2	I. C, SYSTEM CONTROL		Q403	2SC3311R	TRANSISTOR	
IC602	S8053HNB-T	I. C, RESET		Q404, 405	2SJ40CDTA	TRANSISTOR	
IC603	MC14052BCP	I. C, INPUT SELECTOR		Q501	2SC3312RTA	TRANSISTOR	
IC604	M51132L	I. C, ATTENUATOR		Q502	2SD1450RTA	TRANSISTOR	
IC605	BA3930	I. C, POWER SUPPLY CONTROL		Q503	2SC3311R	TRANSISTOR	
IC606	AN7135	I. C, POWER AMP.		Q504, 505	2SJ40CDTA	TRANSISTOR	
IC607	S81250PGT	I. C, REGULATOR		Q601	2SC3312RTA	TRANSISTOR	
IC701	AN8800SCE2	I. C, SERVO AMP		Q602, 603	2SC3311R	TRANSISTOR	
IC702	TCA0372DM2R	I. C, SPINDLE MOTOR DRIVE		Q604	RVTDTA144EST	TRANSISTOR	
IC703	AN8377N	I. C, TRAVERSE MOTOR DRIVE		Q611	2SC3311R	TRANSISTOR	
IC704	MN6650A	I. C, DIGITAL SERVO PROCESS		Q612	RVTDTA143XST	TRANSISTOR	
IC705	MN6475A-T1	I. C, DIGITAL FILTER		Q613	RVTDTA144EST	TRANSISTOR	
IC706	MN6626	I. C, DIGITAL SIGNAL PROCESS		Q614	RVTDTA143XST	TRANSISTOR	
IC971	DN6851ALB	I. C, HALL		Q617	RVTDTA143XST	TRANSISTOR	
		TRANSISTOR(S)		Q618, 619	RVTDTA144EST	TRANSISTOR	
				Q620	RVTDTA14SET	TRANSISTOR	
				Q621	2SC3311R	TRANSISTOR	
Q1, 2	2SC3313B	TRANSISTOR		Q622	2SB1357T114E	TRANSISTOR	
Q3	2SC2786LTA	TRANSISTOR		Q623	2SC3311R	TRANSISTOR	
Q4	2SC3311R	TRANSISTOR		Q624	RVTDTA14YST	TRANSISTOR	
Q5, 6	RVTDTA143XST	TRANSISTOR		Q701	2SB709S	TRANSISTOR	
Q7-9	2SC3311R	TRANSISTOR		Q1001	RVTDTA143XST	TRANSISTOR	
Q10	2SC3311R	TRANSISTOR				DIODE(S)	
Q11, 12	2SA1309R	TRANSISTOR					
Q13, 14	2SC3311R	TRANSISTOR		D1, 2	1SV147T4MATU	DIODE	
Q15	RVTDTA143XST	TRANSISTOR		D3	MA4051MTA	DIODE	
Q18	2SK381CTA	TRANSISTOR		D4	RVDKV1235ZB	DIODE	
Q19	RVTDTA141TST	TRANSISTOR		D5	MA4130M	DIODE	
Q20	RVTDTA143XST	TRANSISTOR		D6	MA165	DIODE	
Q101, 102	2SJ40CDTA	TRANSISTOR		D10	MA165	DIODE	
Q104	2SC3311R	TRANSISTOR		D301	MA165	DIODE	
Q105	2SD1450RTA	TRANSISTOR		D302	RVDMT24R7BTA	DIODE	
Q201, 202	2SJ40CDTA	TRANSISTOR		D303	MA165	DIODE	
Q204	2SC3311R	TRANSISTOR		D601	MA165	DIODE	
Q205	2SD1450RTA	TRANSISTOR		D602	MA4051MTA	DIODE	
Q301, 302	2SC3311AR	TRANSISTOR		D603-605	MA165	DIODE	
Q303	2SD1450RTA	TRANSISTOR					

Ref. No.	Part No.	Part Name & Description	Remarks	Ref. No.	Part No.	Part Name & Description	Remarks
D606, 607	RVDMT28R2BTA	DIODE				FILTER(S)	
D608	MA4100MTA	DIODE					
D609	MA723TA	DIODE		CF1, 2	RLFFETMLA02D	CERAMIC FILTER	
D610	MA4100MTA	DIODE		CF3	RLFDFTA01D	CERAMIC FILTER	
D611	MA165	DIODE				OSCILLATOR(S)	
D701	MA110TW	DIODE					
D802	LN173WP38	LED					
D803	RVDMT26R8BTA	DIODE		X1	RSXZ456KM01	OSCILLATOR	
D901-904	1N5402B-M21	DIODE		X2	RSXC7M20S03	OSCILLATOR	
D906	1SS293TPE4	DIODE		X601	RSXD32K7S03	OSCILLATOR	
D971	RVD1SS133TA	DIODE		X602	RVBCSA3R9MGT	OSCILLATOR	
		VARIABLE RESISTOR(S)		X701	RSXZ33M8M01T	OSCILLATOR	
						FUSE(S)	
VR301	RVNCC73B1T-A	V. R, TAPE SPEED ADJ.					
VR701	EVNDXAA00B14	V. R, BEST EYE ADJ.					
		COMPONENT COMBINATION(S)		F901 Δ	XBA2C31TBOU	FUSE, T3, 15A	
						SWITCH(ES)	
Z1	RXABPWB6A	COMPONENT COMBINATION					
Z301, 302	EXBF6L306SYV	COMPONENT COMBINATION		S601	RSH1A012-U	SW, COVER OPEN/CLOSE	
Z601	RAT0007	BUZZER		S701	SSHD5-E	SW, REST	
Z602	RSL5066-L	LCD		S801	EVQ21405R	SW, TIMER	
Z801	RCDGPIU50XG	REMOTE SENSOR		S802	EVQ21405R	SW, TONE	
		COIL(S)		S803	EVQ21405R	SW, CD SKIP -	
				S804	EVQ21405R	SW, CD SKIP +	
				S805	EVQ21405R	SW, ADJUST	
				S806	EVQ21405R	SW, CHECK	
L3	RLQZP4R7KT-Y	COIL		S807	EVQ21405R	SW, VOLUME -	
L4	RL02B001-T	COIL		S808	EVQ21405R	SW, VOLUME +	
L5	RLV6C001-0	COIL		S809	EVQ21405R	SW, OPERATION	
L7	RL09B18-M	COIL		S810	EVQ21405R	SW, TUNER/BAND	
L8, 9	RLQZP221KT-Y	COIL		S811	EVQ21405R	SW, CD STOP	
L12	RL01B001-T	COIL		S812	EVQ21405R	SW, CD PLAY	
L15	RLQZP221KT-Y	COIL		S813	EVQ21405R	SW, TAPE REW	
L17	RLQZP4R7KT-Y	COIL		S814	EVQ21405R	SW, TAPE REV PLAY	
L301	RL08C002M-T	COIL		S815	EVQ21405R	SW, TAPE STOP	
L302, 303	RLQZB470KT-D	COIL		S816	EVQ21405R	SW, TAPE FWD PLAY	
L601	RL1500050T-Y	COIL		S817	EVQ21405R	SW, TAPE FF	
L602-604	ELEXT2R2KA9	COIL		S818	EVQ21405R	SW, REC STANDBY	
L606	ELEXT101KA9	COIL		S819	EVQ21405R	SW, ATLS	
L607	ELEXT2R2KA9	COIL		S901 Δ	RJJ1SE01-H	SW, AC/DC (JK901)	
L613-615	ELEXT2R2KA9	COIL		S971	RSH1A89ZC-U	SW, MODE DETECT	
L901, 902Δ	RLQZB1R8KT-D	COIL		S972	RSH1A90YC-U	SW, HALF DETECT	
L1001-1006	RL1500050T-Y	COIL		S973	RSH1A90YC-U	SW, R. REC INH.	
L1007-1010	ELEXT2R2KA9	COIL		S974	RSH1A90YC-U	SW, F. REC INH.	
		TRANSFORMER(S)		S975	RSH1A90YC-U	SW, NOT USED	
				S976	RSH1A90YC-U	SW, NOT USED	
T1	RL12B007-T	TRANSFORMER		S1001	RSH1A012-U	SW, LASER ON/OFF	
T901 Δ	RTP1U1B001-C	POWER TRANSFORMER					

TROUBLESHOOTING GUIDE (CD SECTION)

REPLACEMENT PARTS LIST



REPLACEMENT PARTS LIST

Notes:

*Important safety notice:
Components identified by Δ mark have special characteristics important for safety.
Furthermore, special parts which have purposes of fire-retardant (resistors), high-quality sound (capacitors), low-noise (resistors), etc. are used.
When replacing any of components, be sure to use only manufacturer's specified parts shown in the parts list.
*The parenthesized indications in the Remarks columns specify the areas. (Refer to the cover page for area.)
Parts without these indications can be used for all areas.
*Warning: This product uses a diode. Refer to caution statements on page 2.

Ref. No.	Part No.	Part Name & Description	Remarks	Ref. No.	Part No.	Part Name & Description	Remarks
		INTEGRATED CIRCUIT(S)					
IC1	RVITA7358FT	I. C. FM FRONT END		Q304	2SD965Q	TRANSISTOR	
IC2	TA8132AFET	I. C. FM/AM IF AMP		Q305-308	2SC3311R	TRANSISTOR	
IC3	LM7001	I. C. PLL SYNTHESIZER		Q309	UN4217TA	TRANSISTOR	
IC301	BA7755	I. C. R/P SELECT		Q310-312	2SC3311R	TRANSISTOR	
IC302	TA8142AP	I. C. P. B EQ/REC AMP		Q313	2SB1030QRSTA	TRANSISTOR	
IC303	BU2040F	I. C. SYSTEM CONTROL		Q314	UN4216-S	TRANSISTOR	
IC601	MND2410RUK2	I. C. SYSTEM CONTROL		Q316, 317	UN411FTA	TRANSISTOR	
IC602	S8053HNB-T	I. C. RESET		Q401	2SC3312RTA	TRANSISTOR	
IC603	MC14052BCP	I. C. INPUT SELECTOR		Q402	2SD1450RTA	TRANSISTOR	
IC604	MS1132L	I. C. ATTENUATOR		Q403	2SC3311R	TRANSISTOR	
IC605	BA3930	I. C. POWER SUPPLY CONTROL		Q404, 405	2SJ40CDTA	TRANSISTOR	
IC606	AN7135	I. C. POWER AMP		Q501	2SC3312RTA	TRANSISTOR	
IC607	S81250PGT	I. C. REGULATOR		Q502	2SD1450RTA	TRANSISTOR	
IC701	AN8800SCE2	I. C. SERVO AMP		Q503	2SC3311R	TRANSISTOR	
IC702	TCA0372DM2R	I. C. SPINDLE MOTOR DRIVE		Q504, 505	2SJ40CDTA	TRANSISTOR	
IC703	AN8377N	I. C. TRAVERSE MOTOR DRIVE		Q601	2SC3312RTA	TRANSISTOR	
IC704	MN6650A	I. C. DIGITAL SERVO PROCESS		Q602, 603	2SC3311R	TRANSISTOR	
IC705	MN6475A-T1	I. C. DIGITAL FILTER		Q604	RVTDTIC144EST	TRANSISTOR	
IC706	MN6626	I. C. DIGITAL SIGNAL PROCESS		Q611	2SC3311R	TRANSISTOR	
IC971	DN6851ALB	I. C. HALL		Q612	RVTDTA143XST	TRANSISTOR	
		TRANSISTOR(S)		Q613	RVTDTIC144EST	TRANSISTOR	
				Q614	RVTDTIC143XST	TRANSISTOR	
				Q617	RVTDTA143XST	TRANSISTOR	
				Q618, 619	RVTDTIC144EST	TRANSISTOR	
				Q620	RVTDTA114SET	TRANSISTOR	
Q1, 2	2SC3313B	TRANSISTOR		Q621	2SC3311R	TRANSISTOR	
Q3	2SC2786LTA	TRANSISTOR		Q622	2SB1357T114E	TRANSISTOR	
Q4	2SC3311R	TRANSISTOR		Q623	2SC3311R	TRANSISTOR	
Q5, 6	RVTDTA143XST	TRANSISTOR		Q624	RVTDTIC114YST	TRANSISTOR	
Q7-9	2SC3311R	TRANSISTOR		Q701	2SB709S	TRANSISTOR	
Q10	2SC3311R	TRANSISTOR		Q1001	RVTDTIC143XST	TRANSISTOR	
Q11, 12	2SA1309R	TRANSISTOR				DIODE (S)	
Q13, 14	2SC3311R	TRANSISTOR					
Q15	RVTDTA143XST	TRANSISTOR		D1, 2	1SV147T4MATU	DIODE	
Q18	2SK381CTA	TRANSISTOR		D3	MA4051MTA	DIODE	
Q19	RVTDTIC114TST	TRANSISTOR		D4	RVDKV12352B	DIODE	
Q20	RVTDTA143XST	TRANSISTOR		D5	MA4130M	DIODE	
Q101, 102	2SJ40CDTA	TRANSISTOR		D6	MA165	DIODE	
Q104	2SC3311R	TRANSISTOR		D10	MA165	DIODE	
Q105	2SD1450RTA	TRANSISTOR		D301	MA165	DIODE	
Q201, 202	2SJ40CDTA	TRANSISTOR		D302	RVDMTZ4R7BTA	DIODE	
Q204	2SC3311R	TRANSISTOR		D303	MA165	DIODE	
Q205	2SD1450RTA	TRANSISTOR		D601	MA165	DIODE	
Q301, 302	2SC3311AR	TRANSISTOR		D602	MA4051MTA	DIODE	
Q303	2SD1450RTA	TRANSISTOR		D603-605	MA165	DIODE	

Ref. No.	Part No.	Part Name & Description	Remarks	Ref. No.	Part No.	Part Name & Description	Remarks
D606, 607	RVDMTZ8R2BTA	DIODE					
D608	MA4100MTA	DIODE				FILTER(S)	
D609	MA723TA	DIODE					
D610	MA4100MTA	DIODE		CF1, 2	RLFFETMLA02D	CERAMIC FILTER	
D611	MA165	DIODE		CF3	RLFDFTA01D	CERAMIC FILTER	
D701	MA110TW	DIODE				OSCILLATOR (S)	
D802	LN173WP38	LED					
D803	RVDMTZ6R8BTA	DIODE		X1	RSXZ456KM01	OSCILLATOR	
D901-904	1N5402B-M21	DIODE		X2	RSXC7M20S03	OSCILLATOR	
D906	1SS293TPE4	DIODE		X601	RSXD32K7S03	OSCILLATOR	
D971	RVD1SS133TA	DIODE		X602	RVBCSA3R9MGT	OSCILLATOR	
		VARIABLE RESISTOR(S)		X701	RSXZ33M8M01T	OSCILLATOR	
						FUSE (S)	
VR301	RVNCC73B1T-A	V. R. TAPE SPEED ADJ.					
VR701	EVNDXAA00B14	V. R. BEST EYE ADJ.		F901 Δ	XBA2C31TBOU	FUSE, T3. 15A	
		COMPONENT COMBINATION (S)				SWITCH (ES)	
Z1	RXABPWB6A	COMPONENT COMBINATION					
Z301, 302	EXBF6L306SYV	COMPONENT COMBINATION		S601	RSH1A012-U	SW. COVER OPEN/CLOSE	
Z601	RAT0007	BUZZER		S701	SSH05-E	SW. REST	
Z602	RSL5066-L	LCD		S801	EVQ21405R	SW. TIMER	
Z801	RCDGP1U50XG	REMOTE SENSOR		S802	EVQ21405R	SW. TONE	
		COIL (S)		S803	EVQ21405R	SW. CD SKIP -	
L3	RLQZP4R7KT-Y	COIL		S804	EVQ21405R	SW. CD SKIP +	
L4	RL02B001-T	COIL		S805	EVQ21405R	SW. ADJUST	
L5	RLV6C001-0	COIL		S806	EVQ21405R	SW. CHECK	
L7	RL09B18-M	COIL		S807	EVQ21405R	SW. VOLUME -	
L8, 9	RLQZP221KT-Y	COIL		S808	EVQ21405R	SW. VOLUME +	
L12	RL01B001-T	COIL		S809	EVQ21405R	SW. OPERATION	
L15	RLQZP221KT-Y	COIL		S810	EVQ21405R	SW. TUNER/BAND	
L17	RLQZP4R7KT-Y	COIL		S811	EVQ21405R	SW. CD STOP	
L301	RL08C002M-T	COIL		S812	EVQ21405R	SW. CD PLAY	
L302, 303	RLQZB470KT-D	COIL		S813	EVQ21405R	SW. TAPE REW	
L601	RL1500050T-Y	COIL		S814	EVQ21405R	SW. TAPE REV PLAY	
L602-604	ELEXT2R2KA9	COIL		S815	EVQ21405R	SW. TAPE STOP	
L606	ELEXT101KA9	COIL		S816	EVQ21405R	SW. TAPE FWD PLAY	
L607	ELEXT2R2KA9	COIL		S817	EVQ21405R	SW. TAPE FF	
L613-615	ELEXT2R2KA9	COIL		S818	EVQ21405R	SW. REC STANDBY	
L901, 902 Δ	RLQZB1R8KT-D	COIL		S819	EVQ21405R	SW. ATLS	
L1001-1006	RL1500050T-Y	COIL		S901 Δ	RJJ1SE01-H	SW. AC/DC (JK901)	
L1007-1010	ELEXT2R2KA9	COIL		S971	RSH1A892C-U	SW. MODE DETECT	
		TRANSFORMER (S)		S972	RSH1A90YC-U	SW. HALF DETECT	
				S973	RSH1A90YC-U	SW. R. REC INH.	
				S974	RSH1A90YC-U	SW. F. REC INH.	
				S975	RSH1A90YC-U	SW. NOT USED	
				S976	RSH1A90YC-U	SW. NOT USED	
T1	RL12B007-T	TRANSFORMER		S1001	RSH1A012-U	SW. LASER ON/OFF	
T901 Δ	RTP1U1B001-C	POWER TRANSFORMER					

Ref. No.	Part No.	Part Name & Description	Remarks
		CONNECTOR	
CM801	RJS8T7ZA	CONNECTOR (8P)	
CP1	RJP12G18ZA	CONNECTOR (12P)	
CP3	RJP2G17ZA	CONNECTOR (2P)	
CP301	RJP5G18ZA	CONNECTOR (5P)	
CP302	SJTD1013	CONNECTOR (10P)	
CP303	RJP9G18ZA	CONNECTOR (9P)	
CP604	RJP4G4YA	CONNECTOR (4P)	
CP701, 702	RJP2G17ZA	CONNECTOR (2P)	
CP703	RJP4G17ZA	CONNECTOR (4P)	
CP901	RJP4G9YA	CONNECTOR (4P)	
CP902	RJP3G9YA	CONNECTOR (3P)	
CS605	RJS1A6823	CONNECTOR (23P)	
CS701	RJU035T016-1	CONNECTOR (16P)	
CS702	RJS1A6723-1Q	CONNECTOR (23P)	
J971	RJS10T7ZA	CONNECTOR (10P)	
		TRIMMER	
CT1	RCV10AF1T-S	TRIMMER CAPACITOR	
CT2	ECRLA020E53R	TRIMMER CAPACITOR	
		FUSE HOLDER	
FH901 Δ	EYF52BC	FUSE HOLDER	
FH902 Δ	EYF52BC	FUSE HOLDER	
		IC PROTECTOR	
IP601	SRUN5T	IC PROTECTOR	
IP602	SRUN15T	IC PROTECTOR	
		JACK	
JK601	RJJ1D25ZA-C	JACK, MIX MIC	
JK602	RJJD7S2YA-C	JACK, HEADPHONES	
JK901 Δ	RJJ1SE01-H	JACK, AC IN(S901)	

Notes : * Capacity value are in microfarads (uF) unless specified otherwise, P=Pico-farads (pF) F=Farads (F)
 * Resistance values are in ohms, unless specified otherwise, 1K=1,000 (OHM) , 1M=1,000k (OHM)


Ref. No.	Part No.	Values & Remarks	Ref. No.	Part No.	Values & Remarks	Ref. No.	Part No.	Values & Remarks
		RESISTORS						
R1-3	ERDS2TJ104	1/4W 100K	R111	ERDS2TJ822	1/4W 8.2K	R417	ERDS2TJ222	1/4W 2.2K
R4	ERDS2TJ470	1/4W 47	R112	ERDS2TJ470	1/4W 47	R418	ERDS2TJ221	1/4W 220
R5	ERDS2TJ151	1/4W 150	R113	ERDS2TJ472	1/4W 4.7K	R419	ERDS2TJ222	1/4W 2.2K
R6	ERDS2TJ331	1/4W 330	R201	ERDS2TJ474	1/4W 470K	R420	ERDS2TJ1R0	1/4W 1.0
R7	ERDS2TJ391	1/4W 390	R202	ERDS2TJ123	1/4W 12K	R421	ERDS2TJ333	1/4W 33K
R8	ERDS2TJ274	1/4W 270K	R203	ERDS2TJ820	1/4W 82	R501	ERDS2TJ683	1/4W 68K
R9	ERDS2TJ105T	1/4W 1M	R204	ERDS2TJ681	1/4W 680	R502	ERDS2TJ123	1/4W 12K
R10	ERDS2TJ561	1/4W 560	R205	ERDS2TJ822	1/4W 8.2K	R503	ERDS2TJ393	1/4W 39K
R11	ERDS2TJ330	1/4W 33	R207	ERDS2TJ334	1/4W 330K	R504	ERDS2TJ563	1/4W 56K
R12	ERDS2TJ104	1/4W 100K	R208	ERDS2TJ822	1/4W 8.2K	R506	ERDS2TJ682T	1/4W 6.8K
R13	ERDS2TJ470	1/4W 47	R209	ERDS2TJ123	1/4W 12K	R507	ERDS2TJ684	1/4W 680K
R15	ERDS2TJ391	1/4W 390	R210	ERDS2TJ272T	1/4W 2.7K	R508	ERDS2TJ122	1/4W 1.2K
R16	ERDS2TJ683	1/4W 68K	R211	ERDS2TJ822	1/4W 8.2K	R509, 510	ERDS2TJ153	1/4W 15K
R17	ERDS2TJ104	1/4W 100K	R212	ERDS2TJ470	1/4W 47	R511	ERDS2TJ272T	1/4W 2.7K
R18	ERDS2TJ103	1/4W 10K	R213	ERDS2TJ472	1/4W 4.7K	R512	ERDS2TJ181T	1/4W 180
R20	ERDS2TJ222	1/4W 2.2K	R301	ERDS2TJ474	1/4W 470K	R513, 514	ERDS2TJ183T	1/4W 18K
R21	ERDS2TJ562	1/4W 5.6K	R302	ERDS2TJ104	1/4W 100K	R515	ERDS2TJ683	1/4W 68K
R22	ERDS2TJ473	1/4W 47K	R303	ERDS2TJ103	1/4W 10K	R516	ERDS2TJ1R2	1/4W 1.2
R23	ERDS2TJ102	1/4W 1K	R304-306	ERDS2TJ102	1/4W 1K	R517	ERDS2TJ222	1/4W 2.2K
R24	ERDS2TJ223	1/4W 22K	R307	ERDS2TJ221	1/4W 220	R518	ERDS2TJ221	1/4W 220
R25	ERDS2TJ103	1/4W 10K	R308	ERDS2TJ2R7T	1/4W 2.7	R519	ERDS2TJ222	1/4W 2.2K
R27	ERDS2TJ151	1/4W 150	R309	ERDS2TJ123	1/4W 12K	R520	ERDS2TJ1R0	1/4W 1.0
R28, 29	ERDS2TJ471	1/4W 470	R310	ERDS2TJ472	1/4W 4.7K	R521	ERDS2TJ333	1/4W 33K
R30	ERDS2TJ104	1/4W 100K	R311	ERDS2TJ4R7T	1/4W 4.7	R601	ERDS2TJ102	1/4W 1K
R31	ERDS2TJ222	1/4W 2.2K	R312	ERDS2TJ103	1/4W 10K	R602	ERDS2TJ101	1/4W 100
R32	ERDS2TJ473	1/4W 47K	R313	ERDS2TJ472	1/4W 4.7K	R603	ERDS2TJ180T	1/4W 18
R33-38	ERDS2TJ103	1/4W 10K	R314	ERDS2TJ392T	1/4W 3.9K	R604, 605	ERDS2TJ221	1/4W 220
R39	ERDS2TJ102	1/4W 1K	R315	ERDS2TJ472	1/4W 4.7K	R606, 607	ERDS2TJ682T	1/4W 6.8K
R40	ERDS2TJ223	1/4W 22K	R318-322	ERDS2TJ473	1/4W 47K	R608	ERDS2TJ124T	1/4W 120K
R50, 51	ERDS2TJ103	1/4W 10K	R323	ERDS2TJ102	1/4W 1K	R609	ERDS2TJ222	1/4W 2.2K
R52	ERDS2TJ102	1/4W 1K	R324, 325	ERDS2TJ104	1/4W 100K	R610	ERDS2TJ104	1/4W 100K
R55	ERDS2TJ103	1/4W 10K	R326, 327	ERDS2TJ102	1/4W 1K	R611	ERDS2TJ333	1/4W 33K
R56	ERDS2TJ222	1/4W 2.2K	R328	ERDS2TJ101	1/4W 100	R612, 613	ERDS2TJ823T	1/4W 82K
R60	ERDS2TJ104	1/4W 100K	R329	ERDS2TJ335T	1/4W 3.3M	R614	ERDS2TJ104	1/4W 100K
R61	ERDS2TJ103	1/4W 10K	R332	ERDS2TJ223	1/4W 22K	R615	ERDS2TJ102	1/4W 1K
R62, 63	ERDS2TJ681	1/4W 680	R333	ERDS2TJ102	1/4W 1K	R616	ERDS2TJ105T	1/4W 1M
R71	ERDS2TJ274	1/4W 270K	R401	ERDS2TJ683	1/4W 68K	R617	ERDS2TJ106T	1/4W 10M
R101	ERDS2TJ474	1/4W 470K	R402	ERDS2TJ123	1/4W 12K	R618	ERDS2TJ224T	1/4W 220K
R102	ERDS2TJ123	1/4W 12K	R403	ERDS2TJ393	1/4W 39K	R619	ERDS2TJ103	1/4W 10K
R103	ERDS2TJ820	1/4W 82	R404	ERDS2TJ563	1/4W 56K	R620-622	ERDS2TJ153	1/4W 15K
R104	ERDS2TJ681	1/4W 680	R406	ERDS2TJ682T	1/4W 6.8K	R623	ERDS2TJ333	1/4W 33K
R105	ERDS2TJ822	1/4W 8.2K	R407	ERDS2TJ684	1/4W 680K	R624, 625	ERDS2TJ472	1/4W 4.7K
R107	ERDS2TJ334	1/4W 330K	R408	ERDS2TJ122	1/4W 1.2K	R626	ERDS2TJ104	1/4W 100K
R108	ERDS2TJ822	1/4W 8.2K	R409, 410	ERDS2TJ153	1/4W 15K	R631	ERDS2TJ104	1/4W 100K
R109	ERDS2TJ123	1/4W 12K	R411	ERDS2TJ272T	1/4W 2.7K	R632	ERDS2TJ221	1/4W 220
R110	ERDS2TJ272T	1/4W 2.7K	R412	ERDS2TJ181T	1/4W 180	R637	ERDS2TJ104	1/4W 100K
			R413, 414	ERDS2TJ183T	1/4W 18K	R639	ERDS2TJ104	1/4W 100K
			R415	ERDS2TJ683	1/4W 68K	R640	ERDS2TJ103	1/4W 10K
			R416	ERDS2TJ1R2	1/4W 1.2	R641	ERDS2TJ821	1/4W 820

Ref. No.	Part No.	Values & Remarks	Ref. No.	Part No.	Values & Remarks	Ref. No.	Part No.	Values & Remarks
R642	ERDS2TJ103	1/4W 10K	R726	ERJ6GEYJ102A	1/10W 1K	C10	ECBT1H2R2KC5	50V 2. 2P
R643	ERDS2TJ822	1/4W 8. 2K	R729, 730	ERJ6GEYJ102A	1/10W 1K	C11, 12	ECBT1H102KB5	50V 1000P
R644	ERDS2TJ474	1/4W 470K	R731	ERJ8GEYJ470V	1/8W 47	C14, 15	ECBT1H102KB5	50V 1000P
R645	ERDS2TJ222	1/4W 2. 2K	R732	ERJ6GEYJ562V	1/10W 5. 6K	C18	ECBT1H150JC5	50V 15P
R648, 649	ERDS2TJ473	1/4W 47K	R733	ERJ6GEYJ332V	1/10W 3. 3K	C19	ECBT1H100JC5	50V 10P
R650	ERDS2TJ103	1/4W 10K	R734	ERJ6GEYJ562V	1/10W 5. 6K	C20	ECFR1C473MR	16V 0. 047U
R651	ERDS2TJ473	1/4W 47K	R735	ERJ6GEYJ222V	1/10W 2. 2K	C23	ECEA1HN010	50V 1U
R652	ERDS2TJ333	1/4W 33K	R736	ERJ6GEYJ682V	1/10W 6. 8K	C24	ECBT1C103MS5	16V 0. 01U
R653	ERDS2TJ472	1/4W 4. 7K	R737-739	ERJ6GEYJ562V	1/10W 5. 6K	C25	ECFR1C223MR	16V 0. 022U
R654-657	ERDS2TJ103	1/4W 10K	R741-743	ERJ6GEYJ102A	1/10W 1K	C26	ECEA1CU101	16V 100U
R659	ERDS2TJ472	1/4W 4. 7K	R744	ERJ6GEYJ393V	1/10W 39K	C27	ECBT1C103MS5	16V 0. 01U
R660	ERDS2TJ103	1/4W 10K	R745, 746	ERJ6GEYJ102A	1/10W 1K	C29	ECEA1HU010	50V 1U
R661	ERDS2TJ473	1/4W 47K	R747	ERJ6GEYJ473V	1/10W 47K	C30	ECBT1H270J5	50V 27P
R662	ERDS2TJ433	1/4W 43K	R748	ERJ8GEYJ180V	1/8W 18	C31	ECEA1AU470	10V 47U
R663	ERDS2TJ1R5T	1/4W 1. 5	R749	ERJ6GEYJ101V	1/10W 100	C32	ECFR1C223MR	16V 0. 022U
R664	ERDS2TJ221	1/4W 220	R801	ERDS2TJ101	1/4W 100	C33, 34	ECEA1CU100	16V 10U
R665	ERDS2TJ152	1/4W 1. 5K	R802	ERDS2TJ152	1/4W 1. 5K	C35	ECFR1C223MR	16V 0. 022U
R666	ERDS2TJ223	1/4W 22K	R803	ERDS2TJ222	1/4W 2. 2K	C36	ECBT1H331KB5	50V 330P
R667	ERDS2TJ103	1/4W 10K	R804	ERDS2TJ272T	1/4W 2. 7K	C37	ECFR1C683MR	16V 0. 068U
R669	ERDS2TJ102	1/4W 1K	R805	ERDS2TJ392T	1/4W 3. 9K	C38, 39	ECFR1C823MR	16V 0. 082U
R670	ERDS2TJ221	1/4W 220	R806	ERDS2TJ562	1/4W 5. 6K	C40, 41	ECFR1C123MR	16V 0. 012U
R675	ERDS2TJ334	1/4W 330K	R807	ERDS2TJ822	1/4W 8. 2K	C44	ECBT1H330J5	50V 33P
R676, 677	ERDS2TJ472	1/4W 4. 7K	R808	ERDS2TJ153	1/4W 15K	C45	ECFR1C223MR	16V 0. 022U
R678	ERDS2TJ102	1/4W 1K	R809	ERDS2TJ333	1/4W 33K	C46	ECEA0JU101B	6. 3V 100U
R679-687	ERDS2TJ472	1/4W 4. 7K	R810	ERDS2TJ152	1/4W 1. 5K	C47	ECFR1C223MR	16V 0. 022U
R688	ERDS2TJ470	1/4W 4. 7K	R811	ERDS2TJ222	1/4W 2. 2K	C48	ECEA1CU100	16V 10U
R689	ERDS2TJ182	1/4W 1. 8K	R812	ERDS2TJ272T	1/4W 2. 7K	C49	ECBT1H270J5	50V 27P
R690	ERDS2TJ221	1/4W 220	R813	ERDS2TJ392T	1/4W 3. 9K	C50	ECBT1H300J5	50V 30P
R691	ERDS2TJ472	1/4W 4. 7K	R814	ERDS2TJ562	1/4W 5. 6K	C51	ECBT1H102KB5	50V 1000P
R699	ERDS1FVJ680T	1/2W 68	R815	ERDS2TJ822	1/4W 8. 2K	C52	ECEA1EU3R3	25V 3. 3U
R701	ERJ6GEYJ100	1/10W 10	R816	ERDS2TJ153	1/4W 15K	C53	ECEA1HU010	50V 1U
R702	ERJ6GEYJ471V	1/10W 470	R817	ERDS2TJ333	1/4W 33K	C62	ECFR1C103MR	16V 0. 01U
R703	ERJ6GEYJ102A	1/10W 1K	R818	ERDS2TJ823T	1/4W 82K	C63	ECBT1H150JC5	50V 15P
R704	ERJ6GEYJ103V	1/10W 10K	R901	ERDS2TJ681	1/4W 680	C64, 65	ECFR1C223MR	16V 0. 022U
R706	ERJ6GEYJ473V	1/10W 47K	R1001	ERDS2TJ681	1/4W 680	C66	ECBT1H102KB5	50V 1000P
R707	ERJ6GEYJ222V	1/10W 2. 2K	R1003-1005	ERDS2TJ104	1/4W 100K	C67	ECBT1H471KB5	50V 470P
R708	ERJ6GEYJ683V	1/10W 68K				C69	ECBT1C332MR5	16V 3300P
R709	ERJ6GEYJ122V	1/10W 1. 2K			CHIP JUMPER	C71	ECBT1H102KB5	50V 1000P
R710	ERJ6GEYJ182V	1/10W 1. 8K				C72	ECBT1H331KB5	50V 330P
R711	ERJ6GEYJ473V	1/10W 47K	RJ701	ERJ6GEY0R00A	1/10W 0	C73	ECFR1C223MR	16V 0. 022U
R712	ERJ6GEYJ471V	1/10W 470	RJ703-710	ERJ6GEY0R00A	1/10W 0	C74	ECBT1H470J5	50V 47P
R714	ERJ6GEYJ473V	1/10W 47K				C77	ECBT1H181KB5	50V 180P
R715	ERJ6GEYJ223V	1/10W 22K			CAPACITORS	C78	ECBT1H331KB5	50V 330P
R716	ERJ6GEYJ104V	1/10W 100K				C82	ECBT1C103MS5	16V 0. 01U
R717	ERJ6GEYJ682V	1/10W 6. 8K	C1	ECBT1H180JC5	50V 18P	C83	ECFR1C104MR	16V 0. 1U
R718	ERJ6GEYJ223V	1/10W 22K	C2	ECBT1H102KB5	50V 1000P	C101	ECBT1H101KB5	50V 100P
R719	ERJ6GEYJ123V	1/10W 12K	C3	ECBT1H330J5	50V 33P	C102	ECBT1C122KR5	16V 1200P
R720	ERJ6GEYJ273V	1/10W 27K	C4	ECBT1H102KB5	50V 1000P	C103	ECEA0JU330	6. 3V 33U
R721	ERJ6GEYJ823	1/10W 82K	C5	ECBT1C103MS5	16V 0. 01U	C104	ECBT1H331KB5	50V 330P
R722	ERJ6GEYJ102A	1/10W 1K	C6, 7	ECBT1H181KB5	50V 180P	C105	ECFR1C153KR	16V 0. 015U
R723, 724	ERJ6GEYJ104V	1/10W 100K	C8	ECBT1H102KB5	50V 1000P	C106	ECEA1EK4R7	25V 4. 7U
R725	ERJ6GEYJ471V	1/10W 470	C9	ECBT1H47K5	50V 4. 7P	C107	ECEA1HK010B	50V 1U

Ref. No.	Part No.	Values & Remarks	Ref. No.	Part No.	Values & Remarks	Ref. No.	Part No.	Values & Remarks
C108	ECEA0JU470B	6. 3V 47U	C419	ECBT1H102KB5	50V 1000P	C651	ECEA1EU332	25V 3300U
C109, 110	ECBT1H221KB5	50V 220P	C501	ECFR1C473MR	16V 0. 047U	C652	ECEA1CU101	16V 100U
C111	ECEA1EK4R7	25V 4. 7U	C502	ECBT1H101KB5	50V 100P	C653, 654	ECBT1H561KB5	50V 560P
C112	ECBT1C152MR5	16V 1500P	C503	ECEA1HK010B	50V 1U	C655	ECBT1C103MS5	16V 0. 01U
C113, 114	ECBT1H102KB5	50V 1000P	C504	ECEA1H47K5	50V 0. 47U	C656	ECEA0JU221	6. 3V 220U
C115	ECBT1H101KB5	50V 100P	C506	ECEA1H47K5B	50V 0. 15U	C657	ECBT1H331KB5	50V 330P
C201	ECBT1H101KB5	50V 100P	C508	ECKR1H222MD5	50V 2200P	C701	ECEA0JKA220	6. 3V 22U
C202	ECBT1C122KR5	16V 1200P	C509	ECBT1C122MR5	16V 1200P	C702	ECEA0JKA470	6. 3V 47U
C203	ECEA0JU330	6. 3V 33U	C510	ECBT1H102KB5	50V 1000P	C703	ECEA0JKA101	6. 3V 100U
C204	ECBT1H331KB5	50V 330P	C511, 512	ECEA1HK010B	50V 1U	C709	ECUZ1C224KBM	16V 0. 22U
C205	ECFR1C153KR	16V 0. 015U	C513	ECBT1H471KB5	50V 470P	C710	ECUZ1C104MBM	16V 0. 1U
C206	ECEA1EK4R7	25V 4. 7U	C514	ECEA0JU101B	6. 3V 100U	C711	ECUW1E103MBN	25V 0. 01U
C207	ECEA1HK010B	50V 1U	C515	ECEA1AU101	10V 100U	C713	ECEA1CSN47R1	16V 4. 7U
C208	ECEA0JU470B	6. 3V 47U	C516	ECEA1AM222E	10V 2200U	C714	ECEA1HKS010	50V 1U
C209, 210	ECBT1H221KB5	50V 220P	C517	ECQM1H224JZ	50V 0. 22U	C715	ECUE1H472KBN	50V 4700P
C211	ECEA1EK4R7	25V 4. 7U	C518	ECBT1H101KB5	50V 100P	C716	ECUE1C473KBN	16V 0. 047U
C212	ECBT1C152MR5	16V 1500P	C519	ECBT1H102KB5	50V 1000P	C717	ECUE1H681KBN	50V 680P
C213, 214	ECBT1H102KB5	50V 1000P	C601	ECEA1HK010B	50V 1U	C718	ECEA1AKS101	10V 100U
C215	ECBT1H101KB5	50V 100P	C602	ECBT1H101KB5	50V 100P	C719	ECUW1E103MBN	25V 0. 01U
C301	ECEA1HKNR47B	50V 0. 47U	C603	ECEA1AU101	10V 100U	C720	ECUE1E153MBN	25V 0. 015U
C302, 303	ECBT1C103MS5	16V 0. 01U	C604	ECEA1HK010B	50V 1U	C721	ECUW1E103MBN	25V 0. 01U
C304	ECQS2B272KZW	100V 2700P	C605-607	ECBT1H102KB5	50V 1000P	C722	ECEA0JKA470	6. 3V 47U
C305	ECQP2A152JZT	100V 1500P	C608	ECEA0JK101	6. 3V 100U	C723	ECUZ1C104MBM	16V 0. 1U
C306	ECQP2A392JZT	100V 3900P	C609	ECBT1H102KB5	50V 1000P	C724	ECUV1E333MBN	25V 0. 033U
C307	ECEA1HK010B	50V 1U	C610	ECEA1H47R2	50V 2. 2U	C725	ECUW1E103MBN	25V 0. 01U
C308	ECEA1AU101	10V 100U	C611	ECBT1H820KB5	50V 82P	C726	ECUE1H471KBN	50V 470P
C309	ECQV1H473JZ3	50V 0. 047U	C612	ECBT1H101KB5	50V 100P	C727	ECEA0JKA470	6. 3V 47U
C310, 311	ECBT1H102KB5	50V 1000P	C613	ECBT1H470J5	50V 47P	C728, 729	ECUZ1C104MBM	16V 0. 1U
C312, 313	ECKR1H102KBD	50V 1000P	C614	ECBT1H101KB5	50V 100P	C730	ECUZ1C224KBM	16V 0. 22U
C314	ECBT1C103MS5	16V 0. 01U	C616	ECBT1C103MS5	16V 0. 01U	C731	ECEA0JKA331	6. 3V 330U
C315	ECEA1CU101	16V 100U	C618	ECBT1C103MS5	16V 0. 01U	C732	ECUE1H102MBN	50V 1000P
C316	ECEA0JU101B	6. 3V 100U	C619	ECBT1H180JC5	50V 18P	C733	ECEA0JKA101	6. 3V 100U
C317, 318	ECBT1H471KB5	50V 470P	C620	ECBT1H220JC5	50V 22P	C734	ECUE1E223MBN	25V 0. 022U
C319	ECEA1AU221	10V 220U	C621	ECEA0JKA470	6. 3V 47U	C735	ECUZ1C224KBM	16V 0. 22U
C320	ECEA1EK3R3B	25V 3. 3U	C622	ECBT1C103MS5	16V 0. 01U	C737	ECUZ1C224KBM	16V 0. 22U
C321	ECEA0JK220B	6. 3V 22U	C623	ECEA1AU101	10V 100U	C738	ECEA0JKA101	6. 3V 100U
C322	ECEA0JU101B	6. 3V 100U	C624	ECEA1HK010B	50V 1U	C739	ECUW1E103MBN	25V 0. 01U
C401	ECFR1C473MR	16V 0. 047U	C625	ECEA1AU220B	10V 22U	C740	ECUE1H472MBN	50V 4700P
C402	ECBT1H101KB5	50V 100P	C627	ECEA0JK220B	6. 3V 22U	C741	ECUZ1C224KBM	16V 0. 22U
C403	ECEA1HK010B	50V 1U	C628	ECEA1CK100B	16V 10U	C742	ECUZ1C104MBM	16V 0. 1U
C404	ECEA1H47K5	50V 0. 47U	C629, 630	ECEA1EK4R7	25V 4. 7U	C743	ECEA0JKA331	6. 3V 330U
C406	ECEA1H47K5B	50V 0. 15U	C635, 636	ECBT1H561KB5	50V 560P	C744, 745	ECUE1H102KBN	50V 1000P
C408	ECKR1H222MD5	50V 2200P	C637	ECEA1HK010B	50V 1U	C746	ECEA0JKA101	6. 3V 100U
C409	ECBT1C122MR5	16V 1200P	C638	ECEA1EK4R7	25V 4. 7U	C747	ECUZ1C104MBM	16V 0. 1U
C410	ECBT1H102KB5	50V 1000P	C639	ECEA1AU101	10V 100U	C748	ECEA1HKS010	50V 1U
C411, 412	ECEA1HK010B	50V 1U	C640	ECEA1AU221	10V 220U	C749	ECUW1E103MBN	25V 0. 01U
C413	ECBT1H471KB5	50V 470P	C641	ECEA0JU221	6. 3V 220U	C750	ECUE1H050DCN	50V 5P
C414	ECEA0JK101	6. 3V 100U	C642-645	ECEA1CK100B	16V 10U	C751	ECUZ1C224KBM	16V 0. 22U
C415	ECEA1AK101	10V 100U	C646	ECBT1H471KB5	50V 470P	C752	ECUZ1C104MBM	16V 0. 1U
C416	ECEA1AM222E	10V 2200U	C647	ECEA1CU470	16V 47U	C753, 754	ECEA1HKS010	50V 1U
C417	ECQM1H224JZ	50V 0. 22U	C648	ECBT1C103MS5	16V 0. 01U	C755	ECUZ1C104MBM	16V 0. 1U
C418	ECBT1H101KB5	50V 100P	C650	ECEA1CU331	16V 330U	C756, 757	ECUE1H050DCN	50V 5P


Ref. No.	Part No.	Part Name & Description	Remarks	Ref. No.	Part No.	Part Name & Description	Remarks
		CASSETTE DECK		245	RDV108ZA	BELT	
201	RXQ007-2	HEAD ASS' Y		249	RMG0102-1	RUBBER	
202	RUA793ZF	CHASSIS		250	RNL180ZB	LEVER	
203	RZLAR300A	LEVER ASS' Y		251	REX0294-1	CABLE ASS' Y	
203A	RJW143ZA	SPRING		261	XTW2+6L	SCREW	
204	1UB0089ZA	ARM		262	XTW2+8L	SCREW	
204A	RJW148ZA	SPRING		263	XTN26+7J	SCREW	
205	1DM0018ZB	REEL TABLE ASS' Y		264	RHE5203ZA	SCREW	
206	1DM0017ZB	REEL TABLE ASS' Y		265	XTW2+8S	SCREW	
207	RML0069-1	LEVER		266	XYC2+JF16	SCREW	
208	RDG5772ZC	GEAR		267	RHD2600Z	SCREW	
209	RUB508ZB	LEVER		268	RJS10T7ZA	CONNECTOR (J971)	
210	RUB506ZB	LEVER					
211	1UB0088ZB	PINCH ROLLER					
211A	RJW141ZA	SPRING					
212	1UB0087ZB	PINCH ROLLER					
212A	RJW140ZC	SPRING					
214	RNL1ZC	ARM					
215	RUB503ZD	LEVER					
216	RFKRAA0320	CHASSIS ASS' Y					
217	RJW142ZA	SPRING					
218	RUD105ZA	SPRING					
220	RJW139ZA	SPRING					
221	RFKPAA0309	MOTOR ASS' Y					
222	1UE0015ZB	PLUNGER					
223	RUB428ZE	SHAFT					
224	RUL1030YB	PLATE					
225	RMD5014ZB	SPACER					
226	RDG5927ZG	GEAR					
227	1DM0037ZB	FLYWHEEL ASS' Y					
227A	RNW139ZA	WASHER					
228	1DM0038ZB	FLYWHEEL ASS' Y					
228A	RJW141ZA	WASHER					
229	1DG0006ZB	GEAR					
230	RUB513ZD	LEVER					
231	1UB0091Z	LEVER					
231A	RJW146ZA	SPRING					
232	1DR0011ZB	PULLEY ASS' Y					
233	RDV90ZB	BELT					
234	RDG5769ZA	GEAR					
235	RJQ111ZB	SPRING					
236	RJW145ZA	SPRING					
237	1UB0090ZA	ROD					
237A	RUB512ZB	ROD					
238	RDG5773ZA	GEAR					
239	RJQ112ZA	SPRING					
240	RUS609ZC	SPRING					
241	RUB514Z	LEVER					
242	RJW147ZA	SPRING					
243	RUB515ZA	LEVER					
244	RUB509ZA	LEVER					

MECHANISM PARTS LOCATION



CABINET PARTS LOCATION

MECHANISM PARTS LOCATION



Ref. No.	Part No.	Part Name & Description	Remarks	Ref. No.	Part No.	Part Name & Description	Remarks
		CABINET PARTS		49-2	RMQ0152	MAGNET HOLDER	
				49-3	RHM245ZA	MAGNET	
				49-4	RFKNXDS55N-K	DISC CLAMPER	
1	RMK0160	CHASSIS		50	RFKXDS303EG	FRONT CABINET ASS'Y	
2	XTN26+6B	SCREW		51	RFKLXDS303BK	CASSETTE HOLDER ASS'Y	
3	XTV3+12G	SCREW		51-1	RUS757ZA	SPRING	
4	RKK3472B-7E	BATTERY COVER		52	XTV26+6G	SCREW	
5	XTN3+12GFZ	SCREW		53	RMK0105	CHASSIS	
6	XTV3+60G	SCREW		54	SODD110Z	TRAVERSE DECK	
7	REE0265	F. P. C.		54-1	SHGD112	RUBBER	
8	RJC5112B	BATTERY TERMINAL		54-2	SHGD113-1	RUBBER	
9	RJC7512A	BATTERY TERMINAL		54-3	RDV0014	BELT	
10	RMA0069A-1	ANGLE		55	RMS0123-1	PIN	
11	RMA0592	ANGLE		56	RFKFXDS303EA	BATTERY P. C. B. (A)	
12	XTV3+6F	SCREW		57	RFKFXDS303EB	BATTERY P. C. B. (B)	
13	RMN0171	HOLDER		58	RFKFXDS303EC	BATTERY P. C. B. (C)	
15	XTV3+10F	SCREW		59	RFKFXDS303ED	BATTERY P. C. B. (D)	
16	XAM75S140G	LUMP (LAMP601)		60	SNSD38	SCREW	
19	RGU0717-K	BUTTON				PACKING MATERIAL	
20	RMK0159	CHASSIS					
21	EAS10P497B	SPEAKER		P1	RPG1281	GIFT BOX	
22	REX0422	SPEAKER CABLE ASS'Y		P2	RPN0595	PAD ASS'Y	
23	RGU0719-K	CASSETTE EJECT BUTTON		P3	RPH0087	PROTECTION COVER	
24	RML0250	EJECT LEVER (A)					
25	RML0251	EJECT LEVER (B)				ACCESSORIES	
26	RDG57822B	GEAR					
27	RJW1702B	SPRING		A1	RAK-RX320W	REMOTE CONTROLLER	
28	RGQ0089-K	LEVER		A2 △	RJA0019-1K	POWER CORD, AC	(EG)
29	RGU0718-K	CD EJECT BUTTON		A2 △	SJA193	POWER CORD, AC	(EB)
30	RKQ0103-K1	UPPER CABINET		A3	RQT1577-G	INSTRUCTION MANUAL	(EB)
31	RMB0243	SPRING		A3	RFKXDS303EG	INSTRUCTION MANUAL ASS'Y	(EG)
32	RME0025-2	SPRING					
33	RML0114	CD EJECT LEVER					
34	XEARR225CA-Y	TELESCOPIC ANTENNA					
35	XYN3+F12FY	SCREW					
36	REX0427-1	CABLE ASS'Y (W902)	(2P)				
37	REX0423Y	CABLE ASS'Y (CW1)	(12P)				
38	REX0424Y	CABLE ASS'Y (CW302)	(10P)				
39	REX0425Y	CABLE ASS'Y (CW303)	(9P)				
40	REX0426	CABLE ASS'Y (CW901)	(4P)				
41	RWJ1108100QQ	FLAT CABLE (PW801)	(8P)				
42	RWJ1112130QQ	FLAT CABLE (PW601)	(12P)				
43	RWJ1112130QQ	FLAT CABLE (PW602)	(12P)				
44	RWJ5004300QQ	FLAT CABLE (PW603)	(4P)				
45	RWJ1110075QQ	FLAT CABLE (PW301)	(10P)				
46	RWJ4704125KR	FLAT CABLE (W305)	(4P)				
47	RFKXDS303EG	REAR CABINET ASS'Y	(EG)				
47	RFKXDS303EB	REAR CABINET ASS'Y	(EB)				
47-1	REX0428	TERMINAL ASS'Y					
48	RFKNXDS303AK	HANDLE					
49	RFKLXDS303EG	CD COVER ASS'Y					
49-1	RYF0066	DISC CLAMPER					

Service Manual

Radio Cassette

RX-DS303

Portable Stereo CD System


Supplement

Colour

(K) ... Black Type

Area

Suffix for Model No.	Area	Colour
(EB)	Great Britain.	(K)
(EG)	Germany, Italy and Continental Europe.	

Please file and use this supplement manual together with the service manual and simplified manual for Model No. RX-DS303, Order No. AD9206188C2.

Note: This supplement is intended to provide additional information or corrections to the existing service manual for model No. RX-DS303.
Be sure to update your service manual for future reference.

CORRECTION

■ REPLACEMENT PARTS LIST (on page 62.)

Ref. No.	Change of Part Number		Part Name & Description	Remarks
	Original	➡ Supplement		
CASSETTE DECK				
213	—	RUB507ZD	LEVER	Addition
219	—	RUW144ZA	SPRING	Addition

Panasonic

Service Manual

Radio Cassette

RX-DS303

Supplement

Portable Stereo CD System

Colour

(K) Black Type
(W) White Type

● Please file and use this Service Manual together with the service manual for Model No. RX-DS303 Order No. AD9206188C2 and AD9304106S2 (Supplement).

Areas

Suffix for Model No.	Area	Colour
(EB)	Great Britain	(K) (W)
(EG)	Europe	

■ CD Unit Update

- The CD unit used in Model RX-DS303 has been modified for improved operation in mid-production.
- This supplement includes the following information regarding the modified CD unit:
 1. Printed Circuit board diagram
 2. Schematic diagram
 3. Troubleshooting guide
 4. Block diagram
 5. Measurements and adjustments
 6. Function of IC terminals
 7. Replacement parts list

■ How to Identify the Units with Modified CD Unit

The units with a modified CD unit can be identified by their serial number suffix label affixed to the back side. A serial number consists of ten alphanumeric characters:

○○○○○○○○○○

e.g.) AD1E A 23456




AD1E B 23456

Suffix

Units with the following serial number suffix after "B" or later have a modified CD unit.

■ Serial Number Label

Serial number label




● This service manual supplement is only to be used for units with a modified CD unit.


Panasonic

PRINTED CIRCUIT BOARD DIAGRAM

B CD P.C.B. (REP1391A-N)



Note: This printed circuit board diagram is shown as viewed from the foil pattern side.




Included in this supplement are the CD PCB's foil pattern drawing and schematic diagram for the modified CD unit.

Other foil pattern drawings and schematic diagrams are not affected by the modification.


■ TROUBLESHOOTING GUIDE



■ TROUBLESHOOTING GUIDE



■ BLOCK DIAGRAM



NEW DIGITAL SERVO CIRCUIT

This model employs a new digital servo circuit. Compared to the old digital servo circuit, the following points have been improved.

1. **Reduced operated noise**
Loading mechanism 2-level speed reducer

2. **Reduced access time**
[(old) 2.9 seconds→(new) 1.9 seconds]
Change of traverse gear
3. **Improved vibration resistance**
Rubber and spring 2-level floating mechanism
[fo= 50 Hz (old)→20 Hz (new)]

4. **Reduced number of parts**
Use of a single super IC tip
3 chips (MN6626, MN6650, MN6475) are reduced to a single chip (MN66271RA)

MEASUREMENTS AND ADJUSTMENTS

Caution:

●It is very dangerous to look at or touch the laser beam. (Laser radiation is invisible.)
With the unit turned "on", laser radiation is emitted from the pickup lens.
Avoid exposure to the laser beam, especially when performing adjustments.

The conventional CD P.C.B. requires manual adjustment for items (1) through (7) listed below:

- (1) Best eye pattern (PD balance)

(5) Tracking gain
- (2) Focus offset

(6) Tracking balance
- (3) Tracking offset

(7) Angle of elevation
- (4) Focus gain

On the modified CD P.C.B., a servo processor IC (IC702: MN66271RA) automatically adjusts items (2) through (6) out of the seven items listed above. Auto adjustment is performed when:

- 1) a CD is loaded or replaced.

2) the unit is turned on with a CD loaded in the drive.
- *The auto adjustment is reset each time the CD unit is turned off.

●Preparation
After setting up the unit for adjustment, temporarily switch it off, switch it on again.
(This is necessary for the automatic adjustment procedure with the CD unit placed on its side.)




Fig. 1

Fig. 2

Measuring Instruments and Special Tools

- Test disc
1. Playability test disc (SZZP1054C)
2. Uneven test disc (SZZP1056C)
- Allen wrench (M2.0) (SZZP1101C)
●Oscilloscope


(1) MECHANICAL ADJUSTMENT

- When the traverse deck is replaced, making adjustments is not necessary. (The traverse deck ass'y is already adjusted.)
- Make adjustments to improve playability when the traverse deck has not been replaced. Make the electrical adjustments first.

1. Connect the oscilloscope's CH. 1 probe across **TJ701** (+) and **TJ702** (VREF) on the Servo P.C.B.
- Oscilloscope setting:

VOLT 200 mV
SWEEP 0.5 μ sec
Input coupling AC

2. Switch the player power ON, and play track 19 on the test disc (SZZP1056C).
3. Leave the player in Play mode and place it as shown in the figure on the right.
4. Alternately adjust the two mechanical adjusting screws with the 2.0 mm allen wrench (SZZP1101C) until the RF signal amplitude on the oscilloscope is maximize. (Shown in Fig. 2)
5. After completing the adjustment, lock the **mechanical adjustments** with lock paint (RZZ0L01).




A Maximize the amplitude.

(2) BEST EYE (PD BALANCE) ADJUSTMENT

1. Connect the oscilloscope's CH. 1 probe across **TJ701** (+) and **TJ702** (VREF) on the Servo P.C.B.
- Oscilloscope setting:

VOLT 200 mV
SWEEP 0.5 μ sec
Input coupling AC

2. Switch the player power ON, and play the 1 kHz (track 1) on test disc (SZZP1054C).
3. Adjust VR701 until the RF signal eye pattern amplitude is maximized. (Shown in Fig. 1)



B Maximize the amplitude.

(3) CHECK OF PLAY OPERATION AFTER ADJUSTMENT

●Checking Skip Search

1. Play an ordinary musical program disc.
2. Press the skip button to check for normal skip search operation (in both the forward and reverse directions).

●Checking Manual Search

1. Play an ordinary musical program disc.
2. Press the manual search button to check for smooth manual search operations at either low or high speed (in both the forward and reverse directions).

●Checking Playability

1. Play the 0.7 mm black dot and the 0.7 mm wedge on the test disc (SZZP1054C) and verify that no sound skip or noise occurs.
2. Play the middle tracks of the uneven test disc and verify that no sound skip or noise occurs.

FUNCTION OF IC TERMINALS

●IC701 (AN8802SCE1V)

Pin No.	Terminal Name	I/O	Function
1	PDAD	I	PD A channel signal input with delay
2	PDA	I	PD A channel signal input without delay
3	LPD	I	Laser PD connection
4	LD	O	Power supply for LD driving
5	AMPI	I	RF amplifier input
6	Vcc	I	Power supply connection
7	AMPO	O	RF amplifier output (no use, open)
8	CAGC	I	AGC loop filter connection
9	ARF	O	RF AGC output
10	CENV	I	Capacitor connection for RF detection
11	CEA	I	Capacitor connection for HPF amplifier
12	GND	—	Ground connection
13	LDON	I	ON/OFF input of LD APC ("H": ON, "L": OFF)
14	TES	I	Tracking error shunt signal input ("H": shunt)
15	PLAY	I	Play signal input ("H": PLAY)
16	WVEL	I	WVEL control
17	BDO	O	BDO output
18	/RFDET	O	NRFDET output
19	CROSS	O	CROSS output
20	OFTR	O	OFTR output
21	VDET	O	VDET output
22	ENV	O	ENV output
23	TEBPF	I	Vibration detection input
24	TE	O	Tracking error output
25	FE	O	Focus error output
26	PTO	O	Potential amplifier output (no use, open)
27	PTI	I	Potential amplifier inversion input (no use, open)
28	TBAL	I	Tracking balance input
29	FBAL	I	Focus balance input
30	VREF	O	VREF output
31	PDB	I	PD B channel signal input without delay
32	PDBD	I	PD B channel signal input with delay

●IC702 (MN66271RA)

Pin No.	Terminal Name	I/O	Function
1	BCLK	O	Bit clock output for serial data (no used, open)
2	LRCK	O	L/R identification signal output (no use, open)
3	SRDATA	O	Serial data output (no used, open)
4	DVcc1	I	Power supply input (for digital circuit)
5	DVss1	—	GND (for digital circuit)
6	TX	O	Digital audio interface signal output
7	MCLK	I	Microprocessor command clock signal input (Latches data at first transition)
8	MDATA	I	Microprocessor command data signal input
9	MLD	I	Microprocessor command load signal input
10	SENSE	O	Sence signal output (OFT, FESL, MAGEND, NAJEND, POSAD, SFG)
11	/FLOCK	O	Focus servo feeding signal output ("L": Feed)
12	/TLOCK	O	Tracking servo feeding signal output ("L": Feed)
13	BLKCK	O	Sub-code block clock signal output (fBLKCK= 75 Hz during normal playback)
14	SQCK	I	External clock signal input for sub-code Q register
15	SUBQ	O	Sub-code Q code output
16	DMUTE	I	Muting input ("H": Mute)
17	STAT	O	Status signal output (CRC, CUE, CLVS, TTSTVP, FCLV, SQCK)
18	/RST	I	Reset input
19	SMCK	O	1/2-divided clock signal of crystal oscillating at MSEL="H" (fSMCK= 8.4672 MHz) 1/4-divided clock signal of crystal oscillating at MSEL="L" (fSMCK= 4.2336 MHz)
20	PMCK	O	1/192-divided clock signal of crystal oscillating (fPMCK= 88.2 KHz) (no use, open)
21	TRV	O	Traverse forced feed output
22	TVD	O	Traverse drive output
23	PC	O	Spindle motor ON signal output ("L": ON)
24	ECM	O	Spindle motor drive signal output (forced mode output)
25	ECS	O	Spindle motor drive signal output (servo error signal output)
26	KICK	O	Kick pulse output
27	TRD	O	Tracking drive output
28	FOD	O	Focus drive output

Pin No.	Terminal Name	I/O	Function
29	VREF	I	D/A (drive) output (TVD, ECS, TRD, FOD, FBAL, TBAL) Reference voltage input
30	FBAL	O	Focus balance adjustment output (no use, open)
31	TBAL	O	Tracking balance adjustment output
32	FE	I	Focus error signal input (analog input)
33	TE	I	Tracking error signal input (analog input)
34	RFENV	I	RF envelope signal input
35	VDET	I	Vibration detection signal input ("H": detection)
36	OFT	I	Off-track signal input ("H": off track)
37	TRCRS	I	Track cross signal input
38	/RFDET	I	RF detection signal input ("L": detection)
39	BDO	I	Dropout signal input ("H": Dropout)
40	LDON	O	Laser on signal output ("H": ON)
41	TES	O	Tracking error shunt signal output ("H": shunt)
42	PLAY	O	Play signal out ("H": PLAY)
43	WVEL	O	Double speed status signal output ("H": Double speed)
44	ARF	I	RF signal input
45	IREF	I	Reference current input
46	DRF	I	DSL bias (no use, open)
47	DSLIF	I/O	DSL loop filter
48	PLLIF	I/O	PLL loop filter
49	VCOF	I/O	VCO loop filter (no use, open)
50	AVDD2	I	Power supply input (for analog circuit)
51	AVSS2	—	GND (for analog circuit)
52	EFM	O	EFM signal output (not use, open)
53	PCK	O	PLL extraction clock output (fPCK=4.321 MHz during normal playback) (no use, open)
54	PDO	O	Phase comparison signal of EFM and PCK signals (no use, open)
55	SUBC	O	Sub-code serial data output (no use, open)
56	SBCK	I	Clock input for sub-code serial data (no use, GND)
57	Vss	—	GND
58	X1	I	Crystal oscillating circuit input (f=16.9344 MHz)
59	X2	O	Crystal oscillation circuit output (f=16.9344 MHz)
60	VDD	I	Power supply input (for oscillating circuit)
61	BYTCK	O	Byte clock output (no use, open)

Pin No.	Terminal Name	I/O	Function
62	/CLDCK	O	Sub-code frame clock signal output (fCLDCK=7.35 kHz during normal playback) (no use, open)
63	FCLK	O	Crystal frame clock signal output (fFCLK=7.35 kHz, double=14.7 kHz) (no use, open)
64	PFLAG	O	Interpolation flag output ("H": Interpolation) (no use, open)
65	FLAG	O	Flage output (no use, open)
66	CLVS	O	Spindle servo phase synchronizing signal output ("H": CLV, "L": rough servo) (no use, open)
67	CRC	O	Sub-code CRC checked output ("H": OK, "L": NG) (no use, open)
68	DEMPH	O	De-emphasis ON signal output ("H": ON) (no use, open)
69	RESY	O	Frame resynchronizing signal output (no use, open)
70	/RST2	I	Reset input through MASH circuit ("L": Reset)
71	/TEST	I	Test input
72	AVDD1	I	Power supply input (for analog circuit)
73	OUTL	O	Left channel audio signal output
74	AVSS1	—	GND
75	OUTR	O	Right channel audio signal output
76	RSEL	I	RF signal polarity assignment input (at "H" level, RSEL="H"; at "L" level, RSEL=L)
77	CSEL	I	Crystal oscillating frequency designation input ("L": 16.9344 MHz, "H": 33/8688 MHz)
78	PSEL	I	Test input (normally, "L") (no use, GND)
79	MSEL	I	Output frequency switching for SMCK terminal "H": SMCK=8.4672 MHz "L": SMCK=4.2336 MHz (no use, GND)
80	SSEL	I	Output mode switching of SUBQ terminal ("H": Q code buffer mode)

●IC703 (AN8389SE1)

Pin No.	Terminal Name	I/O	Function	Pin No.	Terminal Name	I/O	Function
1	Vcc	I	Power supply	13	PVCC1	I	Power supply (1) for driver
2	VREF	I	VREF input	14	PGND1	—	Ground connection (1) for driver
3	IN4	I	Motor driver (4) input	15	D1—	O	Motor driver (1) reverse-action output
4	IN3	I	Motor driver (3) input	16	D1+	O	Motor driver (1) forward-action output
5	GND	—	Ground connection	17	D2—	O	Motor driver (2) reverse-action output
6	NC	—	No connection (GND)	18	D2+	O	Motor driver (2) forward-action output
7	NRESET	I	Reset input	19	D3—	O	Motor driver (3) reverse-action output
8	GND	—	Ground connection	20	D3+	O	Motor driver (3) forward-action output
9	IN2	I	Motor driver (2) input	21	D4—	O	Motor driver (4) reverse-action output
10	PC2	I	PC2 (power cut) input	22	D4+	O	Motor driver (4) forward-action output
11	IN1	I	Motor driver (1) input	23	PGND2	—	Ground connection (2) for driver
12	PC1	I	PC1 (power cut) input (no use, GND)	24	PVCC2	I	Power supply (2) for driver

■ REPLACEMENT PARTS LIST

Notes: *Important safety notice:

Components identified by Δ mark have special characteristics important for safety.

Furthermore, special parts which have purposes of fire-retardant (resistors), high-quality sound (capacitors), low-noise (resistors), etc. are used.

When replacing any of components, be sure to use only manufacturer's specified parts shown in the parts list.

*The parenthesized indications in the Remarks columns specify the areas. (Refer to the cover page for area.)

Parts without these indications can be used for all areas.

Ref. No.	Part Number		Description	Remarks
	RX-DS303 (Original)	 RX-DS303 (Supplement)		
CABINET PARTS				
54	S0DD110Z	RAE0111Z	TRAVERSE DECK	

Ref. No.	Part No.	Part Name & Description	Remarks	Ref. No.	Part No.	Part Name & Description	Remarks
		INTEGRATED CIRCUIT(S)				SWITCH	
IC701	AN8802SCE1V	I. C, SERVO AMP		S701	RSM0006-P	SW, REST	
IC702	MN66271RA	I. C, SERVO PROCESSOR				CONNECTOR(S)	
IC703	AN8389SE1	I. C, MOTOR DRIVE					
		TRANSISTOR		CN701	RJU035T016-1	SOCKET(16P)	
				CN702	RJS1A6723-1Q	SOCKET(23P)	
Q701	2SB709S	TRANSISTOR				TEST JUMPER(S)	
		VARIABLE RESISTOR		TJ701	RRJ8GET001H	TEST JUMPER	
VR701	EVNDXAA00B14	V. R, BEST EYE ADJ		TJ702	RRJ8GET001H	TEST JUMPER	
		OSCILLATOR					
X701	RSXZ16M9M02T	CRYSTAL					

Notes : * Capacity values are in microfarads (uF) unless specified otherwise, P=Pico-farads (pF) F=Farads (F)
* Resistance values are in ohms, unless specified otherwise, 1K=1,000 (OHM) , 1M=1,000k (OHM)

Ref. No.	Part No.	Values & Remarks	Ref. No.	Part No.	Values & Remarks	Ref. No.	Part No.	Values & Remarks
		RESISTORS	C706	ECUE1H101JCN	50V 100P	RJ710	ERJ8GEYOR00A	1/10W 0
			C708	ECUE1H472KBN	50V 4700P	RJ711	ERJ8GEYOR00A	1/10W 0
			C709	ECUE1C473KBN	16V 0.047U	RJ712	ERJ8GEYOR00A	1/10W 0
R701	ERJ6GEYJ100	1/10W 10	C710	ECUE1H152KBN	50V 1500P	RJ713	ERJ8GEYOR00A	1/10W 0
R702	ERJ6GEYJ471V	1/10W 470	C711	ECUZ1E104MBN	25V 0.1U	RJ714	ERJ8GEYOR00A	1/10W 0
R703	ERJ6GEYJ823	1/10W 82K	C712	ECUZ1E104MBN	25V 0.1U	RJ715	ERJ8GEYOR00A	1/10W 0
R704	ERJ6GEYJ102A	1/10W 1K	C713	ECUV1C104MBM	16V 0.1U	RJ716	ERJ8GEYOR00A	1/10W 0
R705	ERJ6GEYJ103V	1/10W 10K	C714	ECEA0JKA101I	6.3V 100U	RJ717	ERJ8GEYOR00A	1/10W 0
R706	ERJ6GEYJ102A	1/10W 1K	C715	ECEA0JKA470I	6.3V 47U	RJ721	ERJ6GEYOR00A	1/10W 0
R707	ERJ6GEYJ473V	1/10W 47K	C716	ECUE1H561KBN	50V 560P	RJ722	ERJ6GEYOR00A	1/10W 0
R708	ERJ6GEYJ224V	1/10W 220K	C717	ECUZ1E104MBN	25V 0.1U	RJ724	ERJ6GEYOR00A	1/10W 0
R709	ERJ6GEYJ683V	1/10W 68K	C718	ECUV1C224KBM	16V 0.22U	RJ725	ERJ6GEYOR00A	1/10W 0
R711	ERJ6GEYJ154V	1/10W 150K	C719	ECUV1C224KBM	16V 0.22U	RJ726	ERJ6GEYOR00A	1/10W 0
R712	ERJ6GEYJ471V	1/10W 470	C721	ECUE1H100DCN	50V 10P			
R714	ERJ6GEYOR00A	1/10W 0.00	C722	ECUE1H100DCN	50V 10P			
R717	ERJ6GEYJ102A	1/10W 1K	C723	ECEA1AKA221I	10V 220U			
R718	ERJ6GEYJ102A	1/10W 1K	C724	ECUV1C104MBM	16V 0.1U			
R719	ERJ6GEYJ102A	1/10W 1K	C725	ECUE1H102KBN	50V 1000P			
R720	ERJ6GEYJ102A	1/10W 1K	C726	ECUE1H102KBN	50V 1000P			
R721	ERJ8GEYJ101V	1/10W 100	C727	ECEA1HKA010I	50V 1U			
R722	ERJ6GEYJ473V	1/10W 47K	C728	ECEA1HKA010I	50V 1U			
R723	ERJ6GEYJ182V	1/10W 1.8K	C730	ECUZ1E104MBN	25V 0.1U			
R724	ERJ6GEYJ333V	1/10W 33K	C731	ECA05SD151I	6.3V 150U			
R725	ERJ6GEYJ472V	1/10W 4.7K	C732	ECA05SD151I	6.3V 150U			
R726	ERJ6GEYJ473V	1/10W 47K	C733	ECUZ1E104MBN	25V 0.1U			
R727	ERJ6GEYJ103V	1/10W 10K	C734	ECEA1AKA221I	10V 220U			
R728	ERJ6GEYJ392V	1/10W 3.9K	C735	ECUZNE104MBN	25V 0.1U			
R730	ERJ6GEYJ331V	1/10W 330K	C736	ECUZNE104MBN	25V 0.1U			
R731	ERJ6GEYJ392V	1/10W 3.9K	C737	ECUZNE104MBN	25V 0.1U			
R734	ERJ6GEYJ101V	1/10W 100	C738	ECUV1C154KBN	16V 0.15U			
R735	ERJ6GEYJ101V	1/10W 100	C742	ECUV1E273KBN	25V 0.027U			
R736	ERJ6GEYJ101V	1/10W 100	C743	ECUZNE104MBN	25V 0.1U			
R738	ERJ6GEYJ223V	1/10W 22K	C744	ECUE1E822KBN	25V 8200P			
R739	ERJ6GEYJ681V	1/10W 680	C745	ECUE1C473MBN	16V 0.047U			
R741	ERJ6GEYJ562V	1/10W 5.6K	C746	ECUE1H050DCN	50V 5P			
R742	ERJ6GEYJ562V	1/10W 5.6K	C747	ECUE1H222KBN	50V 2200P			
R743	ERJ6GEYJ562V	1/10W 5.6K	C748	ECUV1H271KBM	50V 270P			
R744	ERJ6GEYJ103V	1/10W 10K						
R745	ERJ6GEYJ155V	1/10W 1.5M			CHIP JUMPERS			
R746	ERJ8GEYJ103V	1/8W 10K	RJ701	ERJ8GEYOR00A	1/10W 0			
R747	ERJ6GEYJ473V	1/10W 47K	RJ702	ERJ8GEYOR00A	1/10W 0			
		CAPACITORS	RJ703	ERJ8GEYOR00A	1/10W 0			
			RJ704	ERJ8GEYOR00A	1/10W 0			
C701	ECEA0JKA220	6.3V 22U	RJ705	ERJ8GEYOR00A	1/10W 0			
C702	ECEA1HKA010I	50V 1U	RJ706	ERJ8GEYOR00A	1/10W 0			
C703	ECEA0JKA101I	6.3V 100U	RJ707	ERJ8GEYOR00A	1/10W 0			
C704	ECUZ1E104MBN	25V 0.1U	RJ708	ERJ8GEYOR00A	1/10W 0			
C705	ECEA1HKA010I	50V 1U	RJ709	ERJ8GEYOR00A	1/10W 0			