

Service Manual

Portable Stereo CD System

Radio Cassette



* **MASH**
multi-stage noise shaping

RX-DS35

Colour

(K) Black Type



TAPE DECK: AR300 MECHANISM SERIES
TRAVERSE DECK: RAE0113Z MECHANISM SERIES

Areas

Suffix for Model No.	Area	Colour
(EB)	Great Britain	(K)
(EG)	Europe and Germany	

■ SPECIFICATIONS

General:

Power Requirement: AC; 230~240 V, 50 Hz
 Battery; 12 V (Eight R20/LR20, UM-1 batteries)
 Memory Back-up for Computer/Clock;
 6 V (Four R6/LR6, UM-3 batteries)

Power Consumption: 40 W (AC only)
 Power Output: 40 W (PMPO)
 Speaker: 10 cm PM Dynamic speaker
 2.7Ω

Input: MIX MIC; 5 mV, 200~600Ω, Ø3.5
 Output: HEADPHONES; 32Ω, Ø3.5
 Dimensions: 450 (W)×187 (H)×266 (D) mm
 Weight: 4.4 kg without batteries

CD Player:

Sampling Frequency: 44.1 kHz
 Decoding: 16-bit linear
 Beam Source: Semiconductor laser
 (wavelength 780 nm)

No. of Channels: 2 channels, stereo
 Frequency Range: 20~20,000 Hz (+1/-2 dB)
 Dynamic Range: 78.0 dB
 S/N Ratio: 76.5 dB
 Wow and Flutter: Less than possible measurement data
 D/A Converter: MASH (1 bit DAC)

Radio:

Frequency Range: FM; 87.5~108.0 MHz (50 kHz step)
 LW; 144~288 kHz (9 kHz step)
 MW; 522~1611 kHz (9 kHz step)

Intermediate Frequency: FM; 10.7 MHz
 LW/MW; 459 kHz

Sensitivity: FM; 3.1 μV/0.5 mW H.P. output
 (-3 dB Limit Sens.)
 LW; 158 μV/m/0.5 mW H.P. output
 (Max.)
 MW; 141 μV/m/0.5 mW H.P. output
 (Max.)

Tape Recorder:

Frequency Range: Normal; 40~16,000 Hz
 Recording System: AC bias, AC erase
 Tape Speed: 4.8 cm/s
 Monitor System: Variable sound monitor
 Track System: 4-track 2-channel stereo recording and playback

***MASH is a trademark of NTT.**

Notes:

1. Weights and dimensions shown are approximate.
2. Design and specifications are subject to change without notice.

Panasonic

Contents

	Page
●Precaution of Laser Diode	2
●Caution for AC Mains Lead	3
●Location of Controls	4
●Common Operations	5
●Concerning the Remote Control	6
●Setting the Clock	6
●Using Microphone/Headphones	7
●Self-diagnosis Guide	8
●Handling Precautions for Traverse Deck	9
●Disassembly Instructions	9~18
●Schematic Diagram	19~28
●Printed Circuit Board Diagram	29~34
●Wiring Connection Diagram	35, 36
●Troubleshooting Guide	37, 38

	Page
●Self Check Function	39
●Preparations for Check and Adjustment of P.C.B.	40~42
●Measurements and Adjustments	42~45
●Function of IC Terminals	46~49
●Block Diagram	50~55
●Replacement Parts List	56~62, 67
●Packaging	61
●Mechanism Parts Location	63, 64
●Cabinet Parts Location	65, 66

CAUTION:

THIS PRODUCT UTILIZES A LASER.

USE OF CONTROLS OR ADJUSTMENTS OR PERFORMANCE OF PROCEDURES OTHER THAN THOSE SPECIFIED HEREIN MAY RESULT IN HAZARDOUS RADIATION EXPOSURE.

Precaution of Laser Diode

CAUTION: This product utilizes a laser diode with the unit turned "on", invisible laser radiation is emitted from the pick up lens.

Wave length: 780 nm

Maximum output radiation power from pick up: 100 μ W/VDE

Laser radiation from the pick up lens is safety level, but be sure the followings:

1. Do not disassemble the optical pick up unit, since radiation from exposed laser diode is dangerous.
2. Do not adjust the variable resistor on the pickup unit. It was already adjusted.
3. Do not look at the focus lens using optical instruments.
4. Recommend not to look at pick up lens for a long time.



ACHTUNG: Dieses produkt enthält eine laserdioden. Im eingeschalteten zustand wird unsichtbare laserstrahlung von der lasereinheit abgestrahlt.

Wellenlänge: 780 nm

Maximale strahlungsleistung der lasereinheit: 100 μ W/VDE

Die strahlung an der lasereinheit ist ungefährlich, wenn folgende punkte beachtet werden:

1. Die lasereinheit nicht zerlegen, da die strahlung an der freigelegten laserdioden gefährlich ist.
2. Den werksseitig justierten einstellregler der lasereinheit nicht verstellen.
3. Nicht mit optischen instrumenten in die fokussierlinse blicken.
4. Nicht über längere zeit in die fokussierlinse blicken.



VORSICHT- Unsichtbare
Laserstrahlung, wenn
Abdeckung geöffnet.
Nicht dem Strahl
aussetzen.

DANGER- Invisible
laser radiation when
open.
AVOID DIRECT EX-
POSURE TO BEAM.

VARO! Avettaessa ja
suojakitus ohitettaessa
olet alttiina näkymätön
laser säteilylle.
Älä katso säteeseen.

VARNING! Osynlig
laserstrålning när denna
del är öppnad och
spärren är urkopplad.
Betrakta ej strålen.

ADVARSEL: USYNLIG LASERSTRÅLING
VED ÅBNING, NÅR SIKKERHEDSAF-
BRYDERE ER UDE AF FUNKTION.
UNDGÅ UDSÆTTELSE FOR STRÅLING.

ADVERSEL! Usynlig
laserstrålning når deksel
åpnes og sikkerhedsaf-
brytes. Unngå
eksponering for strålen.

■ Caution for AC Mains Lead [for (EB) area]

For your safety, please read the following text carefully.

This appliance is supplied with a moulded three pin mains plug for your safety and convenience.

A 5-ampere fuse is fitted in this plug.

Should the fuse need to be replaced please ensure that the replacement fuse has a rating of 5-ampere and that it is approved by ASTA or BSI to BS1362.


Check for the ASTA mark  or the BSI mark  on the body of the fuse.

If the plug contains a removable fuse cover you must ensure that it is refitted when the fuse is replaced.

If you lose the fuse cover the plug must not be used until a replacement cover is obtained.


A replacement fuse cover can be purchased from your local dealer.

The wire which is coloured BROWN must be connected to the terminal in the plug which is marked with the letter L or coloured RED.

Under no circumstances should either of these wires be connected to the earth terminal of the three pin plug, marked with the letter E or the Earth Symbol .


Before use

Remove the connector cover as follows.




How to replace the fuse

1. Remove the fuse cover with a screwdriver.



2. Replace the fuse and attach the fuse cover.



CAUTION!

IF THE FITTED MOULDED PLUG IS UNSUITABLE FOR THE SOCKET OUTLET IN YOUR HOME THEN THE FUSE SHOULD BE REMOVED AND THE PLUG CUT OFF AND DISPOSED OF SAFELY.

THERE IS A DANGER OF SEVERE ELECTRICAL SHOCK IF THE CUT OFF PLUG IS INSERTED INTO ANY 13-AMPERE SOCKET.

If a new plug is to be fitted please observe the wiring code as shown below.

If in any doubt please consult a qualified electrician.

IMPORTANT

The wires in this mains lead are coloured in accordance with the following code:


Blue: Neutral

Brown: Live

As the colours of the wires in the mains lead of this appliance may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows:

The wire which is coloured BLUE must be connected to the terminal in the plug which is marked with the letter N or coloured BLACK.

■ Location of Controls



No.	Name
-----	------

Common controls

- ① **Power "STDBY ⏻ (AC)/ON" switch [POWER, STDBY ⏻ (AC)/ON]**
Press to switch the unit from on to standby mode or vice versa. In standby mode, the unit is still consuming a small amount of power.

- ② **Preset equalizer button (PRESET EQ)**

- ③ **Power/battery check/standby indicator (POWER/BATT, STANDBY ⏻)**
The indicator lights green when the unit is turned on. When the AC mains is used, it functions as an AC connection indicator. (The indicator colour changes to red when the unit is turned off.)
When the unit is operated on batteries, it functions as a battery check indicator.

- ④ **Remote control signal sensor (SENSOR)**

- ⑤ **Time set buttons (TIME SET)**

- ⑥ **Time adjust button (ADJUST)**

- ⑦ **Time check button (TIME CHECK)**

- ⑧ **Timer button (TIMER)**


- ⑨ **Volume buttons (VOLUME)**

Radio controls

- ⑩ **Band select button (BAND)**

- ⑪ **Tuning buttons (TUNING/CD)**

- ⑫ **Preset tuning button (PRESET TUNING)**



No.	Name
-----	------

CD controls

- ⑬ **CD lid**

- ⑭ **Easy CD recording button (EASY CD REC)**

- ⑮ **Skip/Search buttons (-/⏮, +/⏭)**

- ⑯ **Memory button (MEMORY)**

- ⑰ **Play/pause button (▶/⏸ PLAY/PAUSE)**

- ⑱ **Stop/clear button (■ STOP/CLEAR)**

- ⑲ **CD lid open button (▲ CD)**

Tape controls

- ⑳ **Stop button (■ STOP)**

- ㉑ **Rec pause button (● ⏸)**

- ㉒ **Play/direction button (◀▶ PLAY/DIR)**

- ㉓ **Rewind/Fast forward button (REW, FF)**

- ㉔ **Tape lid**


- ㉕ **Tape lid open button (▲)**

Colors used for the lettering of the button names:

The lettering used for the names of the buttons is color-coded according to function.


CD: Green
Tape: Blue
Radio: Yellow
Recording: Red

Common Operations



To open the operation panel

Press in the direction of the arrow.



Turning the power on



Press POWER.

Press it again to turn the unit off.


Using POWER on the remote control:

The power can be turned on and off while the unit is being powered by a household AC outlet.

Beep tone heard during operation

When one of the function buttons is pressed, one beep is heard to verify that the button has been properly operated. When one of the buttons has been pressed in error, two beeps are heard as a warning.

If you prefer not to have the beep tone function (Main unit only)




While holding PRESET EQ down while the unit is off, press POWER.

The "BEEP" display appears first followed by "OFF".

To use the beep tone function, repeat the same operation while the unit is off.

(The "BEEP" display appears first followed by "ON".)

Adjusting the volume



Press – VOLUME + to adjust the volume to the desired level.

The volume level can be adjusted from "— dB" (lowest) to "0 dB" (highest).

The volume can be adjusted even when the power is off (only when using AC power).

One-touch play

(Only when the unit is powered by a household AC outlet)

If a CD or tape is installed, pressing a single button from the unit-off state will automatically turn on the power and start play.

To listen to a CD:

Press ►/|| PLAY/PAUSE.

To listen to a tape:

Press ◀▶ PLAY/DIR.

To listen to the radio:

Press BAND.

(Main unit only)

Press PRESET TUNING.


For your reference:

- The same operations can be executed using the remote control.
- Even when the unit is powered by batteries, play can be started simply by pressing one of the above buttons provided that the power-on state has been established.

■ Concerning the Remote Control

Battery installation

Insert two R03 (UM-4, not included) batteries as illustrated.



Insert the batteries in the correct polarities (+, -).

To remove the batteries, pull out the + side of battery No.1.


Battery life

The battery life is about one year.

Although the battery life varies depending on how often the device is used, the batteries should be replaced about once every year on the average.

The batteries should be replaced if commands from the remote control transmitter do not operate the unit even when transmitter is held close to the front panel.

Remote control unit's operation range



How to use the remote control unit properly


- Do not place obstacles between the remote control signal sensor and remote control unit.
- Do not expose the remote control signal sensor to direct sunlight or to the bright light of an inverter fluorescent light.
- Take care to keep the remote control signal sensor and the transmission window free from dust.

To prevent malfunctioning of the remote control unit:

- Do not disassemble or reconstruct the unit.
- Do not place heavy objects on top of it.
- Do not leave it where it will be exposed to direct sunlight.
- Do not spill beverages or other liquids over it.

■ Setting the Clock

The clock has a 24-hour display.



Example: Setting the clock to 16:20;

1



Press POWER.

(This switches on the power.)


2



Press TIME CHECK to display the present time.

→ Timer on/off time ———
Original display ← Present time ←


(The display changes each time the button is pressed.)




3



Press ADJUST.




4




Set the clock.

- (Setting the hour)
Press TIME SET to display the hour (16).



Press ADJUST.

- (Setting the minute)
Press TIME SET to display the minute (20).




Press ADJUST.

(The clock now starts operating, and the display returns to its original status.)


■ Using Microphone/Headphones

Karaoke



1. Lower the volume and connect the microphone (optional accessory).
2. Start playing a CD or tape or turn on the radio.
3. Start karaoke singing and adjust the volume.


Recording karaoke sound with accompaniment from a CD



1. Lower the volume and connect the microphone.
2. Insert the CD and press ■ STOP/CLEAR.
3. Load the tape.
4. Select the mode using REV MODE on the remote control.
5. Press ● II.
6. Press ►/II PLAY/PAUSE and start the karaoke.

Play and recording start.

Recording the sound through the microphone



1. Lower the volume and connect the microphone.
2. Press ■ STOP.
3. Load the tape.
4. Select the mode using REV MODE on the remote control.
5. Press ● II.
6. Press ◀▶ PLAY/DIR.

Recording starts.


For your reference:

- To record, have the leader tape wound up first.
- Disconnect the microphone when it is not going to be used.
- If howling (a prolonged wailing noise) occurs while the microphone is used, use the microphone further away from the speakers or turn down the volume.

Note

When karaoke singing with accompaniment from a CD, sound is heard only while the CD is playing. No sound is heard in the stop or pause mode.


Listening to sound with headphones



Lower the volume and connect the headphones (not included).

Avoid listening for prolonged periods of time to prevent hearing damage.

■ Self-diagnosis Guide

Indicating Procedure	Indicating Position
<p>To indicate Self-Diagnostic Function (For H and F only; U is indicated automatically.)</p> <ol style="list-style-type: none"> 1. Open the cassette holder. 2. Pressing the TAPE [STOP] button, press the [FF] button simultaneously. (Keep pushing both buttons for about 2 seconds till a beep is heard.) 3. There appears "T" at the left end of the LCD indication section. 4. Insert a cassette tape, either A or B side of which has the erase preventing piece folded. Then close the cassette holder. (NOTE: The tape has to be taken up nearly halfway.) 5. Press the [FF] button for fast forwarding for about 5 seconds, then press the TAPE [STOP] button and take out the cassette tape. 6. Insert a cassette tape, both A and B sides of which have the erase preventing pieces respectively, and close the cassette holder. (NOTE: The tape has to be taken up by fast forwarding for about 10 seconds.) 7. Pressing the [REW] button rewinds the tape for 3 ~ 5 seconds till it stops automatically. 8. Pressing the TAPE [STOP] button makes an error indication appear. In case of doubled failures, the indication changes at each push of the TAPE [STOP] button. 9. If there is nothing unusual, the counter indication takes the place. <p>To resume Ordinary Indication Press the [POWER] button to turn off power supply. To have the indication appear again, take the above-stated steps 1 and 2.</p> <p>NOTE: Errors are memorized. To clear the memory after correction of fault, disconnect batteries and AC power source, and reset the device by pressing the [POWER] button continuously for 5 seconds or longer.</p>	 <p>Push the [POWER] button</p> <p>TAPE [STOP] button</p> <p>[REW] [FF]</p> <p>Self-Diagnostic Function Indication</p> <p>(Example)</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="border: 1px solid black; padding: 5px; text-align: center;">U 0 1</div> <div style="border: 1px solid black; padding: 5px; text-align: center;">T F 0 1</div> </div>

Indication Text

Symbol	Trouble	Remedy
U 01	When the unit is operated on batteries, power supply ceases soon after the [POWER] button is set to ON.	It is due to consumption of batteries. Replace the batteries with new ones.
U 02	Setting the [POWER] button to ON causes no supply of power.	Check the power plug (AC), or insert batteries (DC).
H 01	Irregular action of cassette mechanism. (Example) Pressing the FWD PLAY button results in REW PLAY action.	The cassette mechanism mode switch and plunger are defective. (Check and replace them.)
H 02	No recording can be made, or the unit is placed in the recording mode though the erase preventing piece has been broken.	The erase preventing switch contacts improperly, or there is a shortcircuit. (Check and replace the switch.)
H 03	Pressing the [PLAY] button fails to play the tape. Pressing the [PLAY] button causes the motor to rotate though no cassette tape is in.	The cassette half detect switch contacts improperly, or there is a shortcircuit. (Check and replace the switch.)
F 01	When the [PLAY] button is pressed, the tape runs a little and stops soon.	The hall IC is defective and, as the result, reel pulse is out of order. (Check and replace the IC.)
F 15	When CD [PLAY] button is pressed at POWER OFF condition or at any mode set other than CD, start of play delays (about 8 seconds or thereabout).	CD mechanism's optical pickup rest switch contacts improperly. (Check and replace the switch.)



■ Handling Precautions for Traverse Deck

The laser diode in the traverse deck (optical pickup) may break down due to potential difference caused by static electricity of clothes or human body.

So, be careful of electrostatic breakdown during repair of the traverse deck (optical pickup).

● Handling of traverse deck (optical pickup)

1. Do not subject the traverse deck (optical pickup) to static electricity as it is extremely sensitive to electrical shock.
2. To prevent the breakdown of the laser diode, an anti-static shorting pin is inserted into the flexible board (FPC board).
When removing or connecting the shorting pin, finish the job in as short time as possible.
3. Take care not to apply excessive stress to the flexible board (FPC board).
4. Do not turn the variable resistor (laser power adjustment). It has already been adjusted.





● Grounding for electrostatic breakdown prevention

1. Human body grounding
Use the anti-static wrist strap to discharge the static electricity from your body.
2. Work table grounding
Put a conductive material (sheet) or steel sheet on the area where the traverse deck (optical pickup) is placed, and ground the sheet.




Caution:







The static electricity of your clothes will not be grounded through the wrist strap. So, take care not to let your clothes touch the traverse deck (optical pickup).








■ Disassembly Instructions

Ref. No. 1	Removal of the Handle
Procedure 1	
<p>1. Remove 2 screws (①, ②).</p>	
<p>2. Remove the handle in the direction of the arrow.</p>	


Ref. No. 2 Procedure 1→2	Removal of the Front Cabinet	 <ol style="list-style-type: none"> 1. Remove the battery cover. 2. Remove 6 screws (1~6). 3. Press the cassette tape eject button and open the cassette compartment cover. 4. Remove the front cabinet in the direction of the arrow.
Ref. No. 3 Procedure 1→2→3	Removal of the Mechanism	Ref. No. 4 Procedure 1→2→3→4  <ol style="list-style-type: none"> 1. Disconnect 2 connectors (CP301, J971). 2. Unsolder 4 motor terminals. 3. Remove the screw (1). 4. Release 2 bosses. 5. Release 2 hooks by moving the mechanism control P.C.B.
Ref. No. 5 Procedure 1→2→5	Removal of the Upper Cabinet	 <ol style="list-style-type: none"> 1. Remove 2 screws (1, 2). 2. Press the CD eject button and open the CD cover. 3. Remove 2 screws (3, 4). 4. Lift up the upper cabinet in the direction of the arrow.

Ref. No. 6	Removal of the Operation Button	Ref. No. 7	Removal of the Operation P.C.B.
Procedure 1→2→5→6	 <p>•Release 11 claws.</p>	Procedure 1→2→5→6→7	 <ol style="list-style-type: none"> 1. Disconnect the connector (CS801). 2. Lift up the operation P.C.B. and release 2 bosses in the direction of the arrow.
Ref. No. 8	Removal of the CD Unit	Ref. No. 9	Removal of the P.C.B. Unit
Procedure 1→2→5→8	 <ol style="list-style-type: none"> 1. Disconnect the connector (CS7021). 2. Remove 4 screws (①~④). 	Procedure 1→2→3→5→9	 <ol style="list-style-type: none"> 1. Disconnect the connector (CP902). 2. Remove 2 screws (①, ②). 3. Remove the P.C.B. unit in the direction of the arrow.
Ref. No. 10	Removal of the Tuner P.C.B.		
Procedure 1→2→3→5 →9→10	 <ol style="list-style-type: none"> 1. Disconnect the connector (CS1). 	 <ol style="list-style-type: none"> 2. Remove 3 screws (①~③). 3. Remove the antenna terminal. 4. Release 3 claws. 	

<div>Ref. No. 11</div> <div>Procedure 1→2→3→5 →9→11</div>	<div>Removal of the Connection P.C.B.</div> <div></div> <div><div>1. Remove the screw (1).</div><div>2. Push the claw in the direction of the arrow 1 and remove the P.C.B. holder in the direction of the arrow 2.</div><div>3. Release 2 claws.</div></div>	<div></div>
<div>Ref. No. 12</div> <div>Procedure 1→2→3→5 →9→11→12</div>	<div>Removal of the Main P.C.B.</div> <div></div> <div><div>1. Disconnect 3 connector (CS1, CS801, CS7021).</div><div>2. Remove 4 screws (1~4).</div><div>3. Release 4 claws and remove the main P.C.B. in the direction of the arrow.</div></div>	
<div>Ref. No. 13</div> <div>Procedure 1→2→13</div>	<div>Removal of the Power P.C.B.</div> <div></div> <div><div>1. Disconnect 2 connector (CP901, CP902).</div><div>2. Remove 6 screws (1~6).</div><div>3. Pull out the power P.C.B. in the direction of the arrow.</div></div>	<div>Ref. No. 14</div> <div>Procedure 1→2→3→14</div> <div></div> <div><div>• Remove the back-up battery P.C.B. in the direction of the arrow 2 with pulling the claw in the direction of the arrow 1.</div></div>


Ref. No.
15

Removal of the Battery P.C.B.

Procedure
1→2→15

CP901


1. Disconnect the connector (CP901).



2. Remove the P.C.B. in the direction of the arrow ② with pushing the claw in the direction of the arrow ①.



Ref. No.
16

Removal of the CD P.C.B.

Procedure
1→2→5→8→16Traverse motor
terminals (2 points)Spindle motor
terminals (2 points)

1. Remove 3 screws (①~③).
2. Unsolder 2 spindle motor terminals.
3. Unsolder 2 traverse motor terminals.

※Slide the top of the connector in the direction of the arrow ① and disconnect the flexible cable in the direction of the arrow ②.




CN701

CD P.C.B.










4. Disconnect the connector (CN701).







Flexible P.C.B.









Shorting pin

Note: insert the shorting pin into the flexible cable for optical pickup.
(Refer to "HANDLING PRECAUTIONS FOR TRAVERSE DECK" on page 5.)

<div>Ref. No. 17</div>	<div>Removal of the Traverse Deck</div>		
<div>Procedure 1→2→5→8 →16→17</div>	<div><div><div>1. Widen the boss using a regular screwdriver.</div><div></div></div><div><div>2. Pull out the pin in the direction of the arrow.</div><div></div></div></div> <div></div> <div><div>1. Remove 2 pins.</div><div>2. Remove the traverse deck in the direction of the arrow with releasing the claw. Note: Since 3 springs can be also removed together with the traverse deck, be careful not to lose them.</div></div>		
<div>Ref. No. 18</div>	<div>Removal of the CD Eject Button</div>	<div>Ref. No. 19</div>	<div>Removal of the CD Eject lever</div>
<div>Procedure 1→2→5→18</div>	<div></div> <div><div><div><div>1. Release 3 claws in the direction of the arrow ①.</div><div></div></div><div><div>2. Remove the CD eject button in the direction of the arrow ②.</div><div></div></div></div></div>	<div>Procedure 1→2→5→18 →19</div>	<div></div> <div><div><div><div>1. Release 2 claws in the direction of the arrow ①.</div><div></div></div><div><div>2. Remove the CD eject lever in the direction of the arrow ②.</div><div></div></div></div></div>



Ref. No. 20	Removal of the CD Holder Open/Close Detect Button	Ref. No. 21	Removal of the Button Cover
Procedure 1→2→5→20	 <ol style="list-style-type: none"> 1. Release 2 claws in the direction of the arrow ①. 2. Remove the CD open/close detect button in the direction of the arrow ②. 	Procedure 1→2→5→21	 <ol style="list-style-type: none"> 1. Open the button cover. 2. Remove the button cover in the direction of the arrow.
Ref. No. 22	Removal of the CD Cover		
Procedure 1→2→5→22	 <ol style="list-style-type: none"> 1. Open the CD cover and release the rib in the direction of the arrow ①. 	 <ol style="list-style-type: none"> 2. Remove the CD cover in the direction of the arrow ②. 	
Ref. No. 23	Removal of the Disc holder		
Procedure 23	 <ol style="list-style-type: none"> 1. Press the CD eject button and open the CD cover. 	 <ol style="list-style-type: none"> 2. Remove the disc holder in the direction of the arrow ② with sliding the disc holder in the direction of the arrow ①. 	

<div>Ref. No. 24</div> <div>Procedure 23→24</div>	<div>Removal of the Magnet</div> <div></div> <div>1. Release 3 claws in the direction of the arrows. 2. The disc holder is disassembled as shown in the right figure.</div>	<div>Ref. No. 25</div> <div>Procedure 1→2→25</div>	<div>Removal of the Speaker</div> <div></div> <div>1. Remove 8 screws (1~8). 2. Unsolder 4 speaker terminals.</div>
<div>Ref. No. 26</div> <div>Procedure 1→2→26</div>	<div>Removal of the Speaker Connector</div> <div></div> <div>• Remove the screw (1).</div>	<div>Ref. No. 27</div> <div>Procedure 1→2→27</div>	<div>Removal of the LCD Panel</div> <div></div> <div>1. Remove 2 screws (1, 2). 2. Remove the LCD panel with pushing the claw in the direction of the arrows.</div>
<div>Ref. No. 28</div> <div>Procedure 1→2→28</div>	<div>Removal of the Cassette Compartment Cover</div> <div></div> <div>• Release 2 ribs in the direction of the arrows.</div>	<div>Ref. No. 29</div> <div>Procedure 1→2→28→29</div>	<div>Removal of the Cassette Eject Button</div> <div></div> <div>• Remove the cassette eject button in the direction of the arrow 2 with pushing the claw in the direction of the arrow 1.</div>

Ref. No.
30



Removal of the Cassette Eject lever

Procedure
1→2→28→30




- Remove the cassette eject lever in the direction of the arrow ② with pushing the claws in the direction of the arrow ①.

■ INSTALLATION OF THE CASSETTE COMPARTMENT COVER




1. Install the spring.




Cassette compartment
cover

2. Fit the spring of the cassette compartment cover into the groove of the cabinet.

■ INSTALLATION OF THE CD COVER




1. Install the spring to the CD cover.



2. Install the CD cover to the top panel in the order of the ① arrows through ③.

■ MEASURE FOR TAPE TROUBLE




- If a cassette tape can not be removed from the deck since it is caught by the capstan or pinch roller insert a thin driver into the holes in the bottom side of this unit and remove the winded tape with rotating the motor pulley in the direction of the arrow.

■ INSTALLATION OF CD P.C.B.

1. When installing CD P.C.B., move the optical pickup to the more external side than the mark (▲).
(When the optical pickup is not moved, the switch (S701) on the CD P.C.B. may be broken.)
2. Connect the flexible cable to the connector (CN701).
3. Install the CD P.C.B. to the traverse unit with 3 screws (①~③).
4. Solder 2 traverse motor terminals and 2 spindle motor terminals.


Note: ● Insert the flexible cable into the connector and lock securely.

● After installing the motor with screws, solder each motor terminal.




Schematic Diagram • Tuner circuit (Parts list on pages 56~61)

B TUNER CIRCUIT





- DC voltage measurements are taken with electronics voltmeter. The negative terminal of the battery provides negative meter connection point.


- **Important safety notice**
Components identified by  mark have special characteristics important for safety. When replacing any of these components, use only manufacturer's specified parts.

- 20 -






C



D

**Notes:**

<CD circuit>

•S701 : Rest switch

<Mechanism control circuit>

•S971 : Mode detect switch

•S972 : Cassette tape insertion detect switch

•S973 : Reverse side record prevention tab detect switch

•S974 : Forward side record prevention tab detect switch

•VR301 : Tape speed adjustment VR

•DC voltage measurements are taken with electronics voltmeter.
The negative terminal of the battery provides negative meter connection point.

No mark...TAPE PLAYBACK

[]...TUNER

(())...CD

[]...RECORD

•Important safety notice

Components identified by Δ mark have special characteristics important for safety. When replacing any of these components, use only manufacturer's specified parts.

•This schematic diagram may be modified at any time with the development of new technology.

: CD Signal Line

: Record Signal Line

: Tape Playback Signal Line

: +B Line



SUPPLY CONT. / E.VOLUME / BASS / TREBLE / POWER AMP / REGULATOR)






15

16


17

18

19



8 R20/LR20 (UM-1)
ES=12V



Notes:

- S601 : CD cover open/close detect switch
- S801 : Power switch (POWER)
- S802 : Tape function/stop switch (STOP)
- S803 : Tuner function/band select switch (BAND)
- S804 : Preset tuning switch (PRESET TUNING)
- S805 : Time set/tuning/CD skip switch (+/▶▶)
- S806 : CD play/pause switch (PLAY/PAUSE)
- S807 : Time check switch (TIME CHECK)
- S808 : Timer set switch (TIMER)
- S809 : Volume down switch (VOLUME -)
- S810 : Volume up switch (VOLUME +)
- S811 : Preset EQ switch (PRESET EQ)
- S812 : Easy recording switch (EASY REC)
- S813 : Tape play/direction switch (PLAY/DIR)
- S814 : Record pause switch (●||)
- S815 : Tape rewind switch (REW)
- S816 : Tape fast forward switch (FF)
- S817 : Time set/tuning/CD skip switch (-/◀◀)
- S818 : Adjust/memory switch (ADJUST/MEMORY)
- S819 : CD stop/clear switch (STOP/CLEAR)
- S901 : AC/DC select switch in "DC" position
- S1001 : Laser on/off switch

•Battery current:

Vol. min...198 mA (FM)	Vol. max...1110 mA (FM)
183 mA (MW/LW)	840 mA (MW/LW)
264 mA (TAPE)	1220 mA (TAPE)
380 mA (CD)	1410 mA (CD)

Measurement instruction

MW/LW:	74 dB/m, 30% Mod.
FM:	60 dB, 30% Mod.
TAPE:	315 Hz, 0 dB
CD:	1 kHz, 0 dB

•DC voltage measurements are taken with electronics voltmeter.

The negative terminal of the battery provides negative meter connection point.

No mark...TAPE PLAYBACK. []...TUNER (())...CD

•Important safety notice

Components identified by Δ mark have special characteristics important for safety.




When replacing any of these components, use only manufacturer's specified parts.

•This schematic diagram may be modified at any time with the development of new technology.

- \Rightarrow : FM Signal Line
- $\square\square\square$: Record Signal Line
- \Rightarrow : Tape Playback Signal Line
- \Rightarrow : CD Signal Line
- \Rightarrow : Mic Signal Line
- \Rightarrow : Main Signal Line
- \Rightarrow : +B Line


MECHANISM CONTROL P.C.

5 16 17 18 19




TA7358FMATEL	8 Pin	XLU2616F-E1	18Pin
		LA1831MSATEL	24Pin
		TA8184FMATEL	24Pin
		AN8802SCE1V	32Pin


AN8389SE1




MN66271RA	80Pin
MND2410REAH1	100Pin




TA8142AP





BA3936




AN7135



BA7755

S-806H-T
S81350HG

DN6851ALB




2SC2786LTA
2SC3311AIRTA
2SC3311R
2SC3311AR
2SC3312RTA
2SC3313B


2SD1450RTA
UN411FTA
UN4111
UN4116
UN421FTA
UN421LTA

UN4211
UN4213
UN4214TA



2SJ164QTA



2SB1398QTA




2SB709S



MA165
RVD1SS133TA

MA4051-L
MA4056MTA
MA4130M


RVDMTZ4R7BTA
RVDMTZ8R2BTA
RVDMTZ6R8BTA




RL203M11


KV1360NT
KV1583BMTL


LN170WAL3CF







■ Wiring Connection Diagram





Troubleshooting Guide (CD section)





Self Check Function

The self check function is equipped with this unit, and the condition of the unit can be checked using this function.

Use this function before or after repair.

SETTING OF SELF CHECK FUNCTION

1. Connect the AC power cord of this unit to an AC outlet and turn the unit on.
2. Press the numeric keys "4" and then "7" on the remote controller while holding down the tape stop (STOP) button on this unit. The LCD indicators will appear as refer to Fig. 1.
(This display indicates the self check mode is ON.)




Fig. 1

CHECK OF MALFUNCTION OF SWITCHES (TACT SWITCH)

1. Press the numeric key "3" on the remote controller.
2. All indicators on the LCD will disappear.
3. When the tact switches except POWER switch are pressed in sequence the corresponding indicators will appear on the LCD as shown in Table 1 and Fig. 2.

Note: Do not press POWER switch. If the switch is pressed, the unit is turned off and self check mode is cancelled.

4. When the display in Fig. 2 appears, all the LCD indicators will go on. (Refer to Fig. 3.)
5. If any indicator does not appear on the LCD, the corresponding switch is considered abnormal.

Segment	Button	Segment	Button	Segment	Button
①	PRESET EQ	⑪	TIME SET +/▶▶	⑳	STOP
②	EASY CD REC	⑫	ADJUST	㉑	PLAY/DIR
③	●	⑬	TIME CHECK	㉒	BAND
④	REW	⑭	TIMER	㉓	PRESET TUNING
⑤	FF	⑮	VOLUME -	㉔	PLAY/PAUSE
⑥	TIME SET -/◀◀	⑯	VOLUME +	㉕	STOP/CLEAR

Table 1




Fig. 2

CHECK OF ALL INDICATOR ON THE LCD

1. Press the numeric key "8" on the remote controller.
2. All the LCD indicators will go on. (Refer to Fig. 3.)
If any indicator does not appear, the LCD or LCD drive circuit is considered abnormal.






Fig. 3



- To cancel the self check mode, turn off this unit by pressing the power button.
- The unit comes to the self check mode by pressing the numeric keys "4", "5" and "10" on the remote controller, but the self check can not be performed.
- The self check mode will be cancelled by pressing the numeric keys "6" and "9" on the remote controller.

■ Preparations for Check and Adjustment of P.C.B.

- Fabricate the measuring instrument as shown below to measure the audio output from the headphones jack for check and adjustment of the P.C.B.



- When you measure the audio output from the speaker without using the measuring instrument for the headphones output, make connections shown below.




1. Remove the screw (1).
2. Remove the speaker wires and the speaker connector from the front cabinet.

3. Connect the speaker connector to the speaker output connector (CS601).


- The following extension cable kit is necessary to check and adjust the unit's P.C.B.

- RFKZ0048 (A set of 4 extention cables)





●Check and Adjustment of the Tuner P.C.B.

1. Remove the upper cabinet as explained on the page 10 in the Disassembly Instructions. (Ref. No. 5 Removal of the Upper Cabinet)



2. Remove 2 screws (1, 2).




3. Pull out the P.C.B. unit in the direction of the arrow.

4. Put the P.C.B. unit as shown in the left figure.

●Check and adjust the tuner P.C.B. in this condition.

●Check and Adjustment of the Mechanism Control P.C.B.


1. Remove the mechanism as explained on page 10 in the Disassembly Instructions. (Ref. No. 3 Removal of the Mechanism)



2. Connect 2 extension cables.

●Check and adjustment the mechanism control P.C.B. in this condition.


<When adjusting only tape speed>



●Insert the screwdriver through the hole for tape speed adjustment on the bottom of this unit. Then adjust VR301 on the mechanism control P.C.B.

●Check and Adjustment of the CD P.C.B.

1. Remove the upper cabinet as explained on page 10 in the Disassembly Instructions. (Ref. No. 5 Removal of the Upper Cabinet)



- 4. Insert the boss on the CD unit into the hole and fix to make the CD unit stand.
- 5. Remove the disc holder as explained on page 15 in the Disassembly Instructions. (Ref. No. 23 Removal of the Disc Holder)
- 6. Fix a test disc with the disc holder.
- 7. Set switch (S601 and S1001) to ON.

●Check and adjustment the CD P.C.B. in this condition.

■ Measurements and Adjustments

<TUNER SECTION>

●ALIGNMENT INSTRUCTIONS

READ CAREFULLY BEFORE ATTEMPTING ALIGNMENT	
<ul style="list-style-type: none"> ●Set power source voltage to 12 V DC. ●Set function to TUNER/MW or LW. 	<ul style="list-style-type: none"> ●Set volume level to – 12 dB. ●Output of signal generator should be no higher than necessary to obtain an output reading.

●MW-RF ALIGNMENT (The parts other than the ones listed below are aligned at the factory before they are supplied. Therefore, alignment of those parts is unnecessary when used for replacement.)

SIGNAL GENERATOR or SWEEP GENERATOR		RADIO DIAL SETTING	INDICATOR (ELECTRONIC VOLTMETER or OSCILLOSCOPE)	ADJUSTMENT (Refer to Fig. 1.)	REMARKS
CONNECTIONS	FREQUENCY				
Fashion a loop of several turns of wire and radiate a signal into the loop ant. of receiver.	594 kHz	Tune to signal	Headphones Jack (32Ω) (Fabricate the plug as shown in Page 40 and then connect the lead wires of the plug to the measuring instrument.)	(*1) L2-1 (MW ANT Coil)	Adjust for maximum output. Adjust L2-1 by moving coil along the ferrite core.
"	1503 kHz	"	"	CT1 (MW ANT Trimmer)	Adjust for maximum output.

(*1) Fix antenna coil with wax after completing alignment.

●**LW-RF ALIGNMENT** (The parts other than the ones listed below are aligned at the factory before they are supplied. Therefore, alignment of those parts is unnecessary when used for replacement.)

SIGNAL GENERATOR or SWEEP GENERATOR		RADIO DIAL SETTING	INDICATOR (ELECTRONIC VOLTMETER or OSCILLOSCOPE)	ADJUSTMENT (Refer to Fig. 1.)	REMARKS
CONNECTIONS	FREQUENCY				
Fashion a loop of several turns of wire and radiate a signal into the loop ant. of receiver.	153 kHz	Tune to signal	Headphones Jack (32Ω) (Fabricate the plug as shown in Page 40 and then connect the lead wires of the plug to the measuring instrument.)	(*2) L2-2 (LW ANT Coil)	Adjust for maximum output. Adjust L2-2 by moving coil along the ferrite core.
"	270 kHz	"	"	CT2 (LW ANT Trimmer)	Adjust for maximum output.

(*2) Fix antenna coil with wax after completing alignment.

●**ALIGNMENT POINT**




Fig. 1

<**CASSETTE DECK SECTION**>

●**ALIGNMENT INSTRUCTION**

READ CAREFULLY BEFORE ATTEMPTING ALIGNMENT

- Set power source voltage to 12 V DC.
- Set function to TAPE.
- Set volume control to -12 dB.
- Output of signal generator should be no higher than necessary to obtain an output reading.

●**HEAD AZIMUTH ALIGNMENT**

TEST TAPE	INDICATOR (ELECTRONIC VOLTMMETER or OSCILLOSCOPE)	ADJUSTMENT	SPECIFICATION	REMARKS
QZZCFM (8 kHz, -20 dB)	Headphones Jack (32Ω) (Fabricate the plug shown in Page 40 and then connect the lead wires of the plug to the measuring instrument.)	Azimuth Screw (Refer to Fig. 2.)	Maximum output	<ol style="list-style-type: none"> 1. Insert the test tape (QZZCFM) and start playback in the forward direction. 2. Adjust the azimuth screw for maximum waveform on the oscilloscope and the similar output on L and R channels. 3. When adjusting the azimuth in the reverse direction, repeat the adjustment a several times because of a little slip on the forward direction side.

●TAPE SPEED ALIGNMENT

TEST TAPE	INDICATOR (FREQUENCY COUNTER)	ADJUSTMENT	REMARKS
QZZCWAT (3 kHz, -10 dB)	Headphones jack (32Ω) (Fabricate the plug shown in page 34 and then connect the lead wires of the plug to the measuring instrument.)	VR301 (Refer to Fig. 4.)	(Specification: 3000 ± 40 Hz) 1. Insert a test tape (QZZCWAT) in DECK1 and start playback in forward direction. 2. Adjust VR301 until the frequency is set to 3000 ± 20 Hz on the frequency counter. 3. Check that the frequency is set to within ± 40 Hz for playback in forward direction after playback in reverse direction.

●RECORD BIAS VOLTAGE CHECK

TEST TAPE	INDICATOR ELECTRONIC VOLTMETER or OSCILLOSCOPE	ADJUSTMENT	SPECIFICATION	REMARKS
Use Normal tape.	TP6 ...(+) TP4 ...(-) (Refer to Fig. 4 and 5.)	—	15~18 mV	Insert the tape with erase-prevention tabs in deck and start recording.

●ALIGNMENT POINT




Fig. 2





Fig. 4



Keep these cords short. (Line capacitance: 3 pF or less)

●In order not to influence the bias oscillation, divide the voltage with 1 MΩ and 1 kΩ resistors, and measure the voltage across the 1 kΩ resistor.

Fig. 5




Fig. 3

Caution:

- Please replace both azimuth adjustment screws (RHE5152ZB) and springs (RMB0331) used for the forward and reverse sides to new ones simultaneously when readjusting the head azimuth. (Shown in Fig. 2.) Even if you wish to readjust the head azimuth without replacing the screws and springs, a fine adjustment can not be done because of the screw-locking bond adhered to the azimuth screw and spring.
- Please remove the screw-locking bond left on the head base when replacing the azimuth screw.
- If you wish to readjust the head azimuth, be sure to adjust with adhering the cassette tape closely to the mechanism by pushing the center of cassette tape with your finger. (Shown in Fig. 3.)

<CD SECTION>

Caution:

It is very dangerous to look at or touch the laser beam. (Laser radiation is invisible.)
With the unit turned "on", laser radiation is emitted from the pickup lens.
Avoid exposure to the laser beam, especially when performing adjustments.

●Preparation for Adjustment

1. Set up the unit following the procedure described in "Check and Adjustment for the CD P.C.B.". (See page 42.)
2. After completing the setup procedure, switch the unit off then switch it on again (to adjust the unit with the CD unit placed in an upright position).

Measuring Instruments and Special Tools

•Test disc

1. Playability test disc (SZZP1054C)
2. Uneven test disc (SZZP1056C)

•Hexagonal wrench (M2.0) (SZZP1101C)

•Oscilloscope

(1) MECHANICAL ADJUSTMENT


- When the traverse deck is replaced, making adjustments is not necessary. (The traverse deck ass'y is already adjusted.)
- Make adjustments to improve playability when the traverse deck has not been replaced. Make the electrical adjustments first.

1. Connect the oscilloscope's CH. 1 probe across **TJ701** (+) and **TJ702** (VREF) on the Servo P.C.B.

Oscilloscope setting:

VOLT 200 mV
 SWEEP 0.5 μ sec
 Input coupling AC

2. Switch the player power ON, and play track 19 on the test disc (SZZP1056C).
3. Leave the player in Play mode and place it as shown in the figure on the right.
4. Alternately adjust the two mechanical adjusting screws with the 2.0 mm allen wrench (SZZP1101C) until the RF signal amplitude on the oscilloscope is maximize. (Shown in Fig. 7)
5. After completing the adjustment, lock the **mechanical adjustments** with lock paint (RZZ0L01).



Ⓐ Maximize the amplitude.

•NEW DIGITAL SERVO CIRCUIT

A digital servo circuit employed in this unit is a new type circuit. All adjustment VRs, which are equipped with conventional digital servo circuits, are removed from the electric section. Therefore, only mechanical adjustments are necessary.

(2) CHECK OF PLAY OPERATION AFTER ADJUSTMENT

•Checking Skip Search

1. Play an ordinary musical program disc.
2. Press the skip button to check for normal skip search operation (in both the forward and reverse directions).

•Checking Manual Search

1. Play an ordinary musical program disc.
2. Press the manual search button to check for smooth manual search operations at either low or high speed (in both the forward and reverse directions).

•Checking playability

1. Play the 0.7 mm black dot and the 0.7 mm wedge on the test disc (SZZP1054C) and verify that no sound skip or noise occurs.
2. Play the middle tracks of the uneven test disc and verify that no sound skip or noise occurs.

•Locations of Adjustments




Fig. 6




Fig. 7

■ Function of IC Terminals

●IC701 (AN8802SCE1V)

Pin No.	Terminal Name	I/O	Function
1	PDAD	I	PD A channel signal input with delay
2	PDA	I	PD A channel signal input without delay
3	LPD	I	Laser PD connection
4	LD	O	Power supply for LD driving
5	AMPI	I	RF amplifier input
6	Vcc	I	Power supply connection
7	AMPO	O	RF amplifier output (no use, open)
8	CAGC	I	AGC loop filter connection
9	ARF	O	RF AGC output
10	CENV	I	Capacitor connection for RF detection
11	CEA	I	Capacitor connection for HPF amplifier
12	GND	—	Ground connection
13	LDON	I	ON/OFF input of LD APC ("H": ON, "L": OFF)
14	TES	I	Tracking error shunt signal input ("H": shunt)
15	PLAY	I	Play signal input ("H": PLAY)
16	WVEL	I	WVEL control
17	BDO	O	BDO output
18	/RFDET	O	NRFDET output
19	CROSS	O	CROSS output
20	OFTR	O	OFTR output
21	VDET	O	VDET output
22	ENV	O	ENV output
23	TEBPF	I	Vibration detection input
24	TE	O	Tracking error output
25	FE	O	Focus error output
26	PTO	O	Potential amplifier output (no use, open)
27	PTI	I	Potential amplifier inversion input (no use, open)
28	TBAL	I	Tracking balance input
29	FBAL	I	Focus balance input
30	VREF	O	VREF output
31	PDB	I	PD B channel signal input without delay
32	PDBD	I	PD B channel signal input with delay

●IC702 (MN66271RA)

Pin No.	Terminal Name	I/O	Function
1	BCLK	O	Bit clock output for serial data (no used, open)
2	LRCK	O	L/R identification signal output (no use, open)
3	SRDATA	O	Serial data output (no used, open)
4	DV _{DD} 1	I	Power supply input (for digital circuit)
5	DV _{SS} 1	—	GND (for digital circuit)
6	TX	O	Digital audio interface signal output
7	MCLK	I	Microprocessor command clock signal input (Latches data at first transition)
8	MDATA	I	Microprocessor command data signal input
9	MLD	I	Microprocessor command load signal input
10	SENSE	O	Sence signal output (OFT, FESL, MAGEND, NAJEND, POSAD, SFG)
11	/FLOCK	O	Focus servo feeding signal output ("L": Feed)
12	/TLOCK	O	Tracking servo feeding signal output ("L": Feed)
13	BLKCK	O	Sub-code block clock signal output (fBLKCK=75 Hz during normal playback)
14	SQCK	I	External clock signal input for sub-code Q register
15	SUBQ	O	Sub-code Q code output
16	DMUTE	I	Muting input ("H": Mute)
17	STAT	O	Status signal output (CRC, CUE, CLVS, TTSTVP, FCLV, SQCK)
18	/RST	I	Reset input
19	SMCK	O	1/2-divided clock signal of crystal oscillating at MSEL="H" (fSMCK=8.4672 MHz) 1/4-divided clock signal of crystal oscillating at MSEL="L" (fSMCK=4.2336 MHz)
20	PMCK	O	1/192-divided clock signal of crystal oscillating (fPMCK=88.2 KHz) (no use, open)
21	TRV	O	Traverse forced feed output
22	TVD	O	Traverse drive output
23	PC	O	Spindle motor ON signal output ("L": ON)
24	ECM	O	Spindle motor drive signal output (forced mode output)
25	ECS	O	Spindle motor drive signal output (servo error signal output)
26	KICK	O	Kick pulse output
27	TRD	O	Tracking drive output
28	FOD	O	Focus drive output

Pin No.	Terminal Name	I/O	Function
29	VREF	I	D/A (drive) output (TVD, ECS, TRD, FOD, FBAL, TBAL) Reference voltage input
30	FBAL	I	Focus balance adjustment output
31	TBAL	O	Tracking balance adjustment output
32	FE	I	Focus error signal input (analog input)
33	TE	I	Tracking error signal input (analog input)
34	RFENV	I	RF envelope signal input
35	VDET	I	Vibration detection signal input ("H": detection)
36	OFT	I	Off-track signal input ("H": off track)
37	TRCRS	I	Track cross signal input
38	/RFDET	I	RF detection signal input ("L": detection)
39	BDO	I	Dropout signal input ("H": Dropout)
40	LDON	O	Laser on signal output ("H": ON)
41	TES	O	Tracking error shunt signal output ("H": shunt)
42	PLAY	O	Play signal out ("H": PLAY)
43	WVEL	O	Double speed status signal output ("H": Double speed)
44	ARF	I	RF signal input
45	IREF	I	Reference current input
46	DRF	—	DSL bias (no use, open)
47	DSLIF	I/O	DSL loop filter
48	PLLIF	I/O	PLL loop filter
49	VCOF	—	VCO loop filter (no use, open)
50	AVDD2	I	Power supply input (for analog circuit)
51	AVSS2	—	GND (for analog circuit)
52	EFM	—	EFM signal output (not use, open)
53	PCK	—	PLL extraction clock output (fPCK=4.321 MHz during normal playback) (no use, open)
54	PDO	—	Phase comparison signal of EFM and PCK signals (no use, open)
55	SUBC	—	Sub-code serial data output (no use, open)
56	SBCK	I	Clock input for sub-code serial data (no use, GND)
57	Vss	—	GND
58	X1	I	Crystal oscillating circuit input (f=16.9344 MHz)
59	X2	O	Crystal oscillation circuit output (f=16.9344 MHz)
60	VDD	I	Power supply input (for oscillating circuit)
61	BYTCK	—	Byte clock output (no use, open)

Pin No.	Terminal Name	I/O	Function
62	/CLDCK	—	Sub-code frame clock signal output (fCLDCK=7.35 kHz during normal playback) (no use, open)
63	FCLK	—	Crystal frame clock signal output (fFCLK=7.35 kHz, double=14.7 kHz)
64	PFLAG	—	Interpolation flag output ("H": Interpolation) (no use, open)
65	FLAG	—	Flage output (no use, open)
66	CLVS	—	Spindle servo phase synchronizing signal output ("H": CLV, "L": rough servo) (no use, open)
67	CRC	—	Sub-code CRC checked output ("H": OK, "L": NG) (no use, open)
68	DEMPH	—	De-emphasis ON signal output ("H": ON) (no use, open)
69	RESY	—	Frame resynchronizing signal output (no use, open)
70	/RST2	I	Reset input through MASH circuit ("L": Reset)
71	/TEST	I	Test input
72	AVDD1	I	Power supply input (for analog circuit)
73	OUTL	O	Left channel audio signal output
74	AVSS1	—	GND
75	OUTR	O	Right channel audio signal output
76	RSEL	I	RF signal polarity assignment input (at "H" level, RSEL="H"; at "L" level, RSEL=L)
77	CSEL	I	Crystal oscillating frequency designation input ("L": 16.9344 MHz, "H": 33/8688 MHz)
78	PSEL	—	Test input (normally, "L") (no use, GND)
79	MSEL	—	Output frequency switching for SMCK terminal "H": SMCK=8.4672 MHz "L": SMCK=4.2336 MHz (no use, GND)
80	SSEL	I	Output mode switching of SUBQ terminal ("H": Q code buffer mode)

●IC703 (AN8389SE1)

Pin No.	Terminal Name	I/O	Function
1	Vcc	I	Power supply
2	VREF	I	VREF input
3	IN4	I	Motor driver (4) input
4	IN3	I	Motor driver (3) input
5	GND	—	Ground connection
6	NC	—	No connection
7	NRESET	I	Reset input
8	GND	—	Ground connection
9	IN2	I	Motor driver (2) input
10	PC2	I	PC2 (power cut) input
11	IN1	I	Motor driver (1) input
12	PC1	I	PC1 (power cut) input (no use, GND)
13	PVCC1	I	Power supply (1) for driver
14	PGND1	—	Ground connection (1) for driver
15	D1–	O	Motor driver (1) reverse-action output
16	D1+	O	Motor driver (1) forward-action output
17	D2–	O	Motor driver (2) reverse-action output
18	D2+	O	Motor driver (2) forward-action output
19	D3–	O	Motor driver (3) reverse-action output
20	D3+	O	Motor driver (3) forward-action output
21	D4–	O	Motor driver (4) reverse-action output
22	D4+	O	Motor driver (4) forward-action output
23	PGND2	—	Ground connection (2) for driver
24	PVCC2	I	Power supply (2) for driver

●IC2 (XLU2616F-E1)

Pin No.	Terminal Name	I/O	Function
1	X OUT	O	Connect to ceramic oscillator
2	X IN	I	
3	CE	I	PLL tuner strobe signal input
4	DA	I	PLL tuner data input
5	CL	I	PLL tuner clock signal input
6	TUN	O	Tuner sending mode output
7	SD	I	Broadcast receiving signal input
8	IF IN	I	IF signal input
9	P3	O	Tuner mono/stereo switching signal output
10	P0	O	Power control signal output (for AM circuit)
11	P1	O	Power control signal output (for FM circuit)
12	P2	—	—
13	AM IN	I	AM OSC signal input
14	FM IN	I	FM OSC signal input
15	V _{DD}	I	Power supply input (+9 V)
16	PD1	O	Variable capacitor-diode control signal output
17	PD2	—	—
18	GND	—	GND

●IC601 (MND2410REAH2)

Pin No.	Terminal Name	I/O	Function
1	V _{DD}	I	Power supply input (+5 V)
2	OSC1	O	Clock output (3.9 MHz)
3	OSC2	I	Clock input (3.9 MHz)
4	V _{SS}	—	GND
5	XI	I	Clock input (32 kHz)
6	XO	O	Clock output (32 kHz)
7	VREF—	—	AD converter reference voltage (GND)
8	AD IN7	I	Leaf switch signal input (DECK)
9	AD IN6	I	Leaf switch signal input (DECK)
10	PL	O	Solenoid control signal output (H: ON)
11	MBP1	O	Beat proof control signal output
12	MBP2	O	Beat proof control signal output
13	PWR DET	I	Power detection signal input (L: ON)
14	AD IN1	I	AD converter signal input (operation switches)
15	AD IN0	I	AD converter signal input (operation switches)
16	VREF+	—	AD converter reference voltage (GND)
17	BP3	O	Beat proof control signal output (H: ON)
18	MOTOR	O	Deck motor control signal output
19	BEEP	O	Beep signal output
20	VOL PWM	O	PWM output (Volume control)
21	REC H	O	Deck record mode control signal output (H: REC)
22	DMT	O	Deck muting control signal output (L: MUTE)
23	ST LED	I	Tuner stereo signal input
24	DMUTE	O	CD muting control signal output (H: MUTE)
25	PLL CLK	O	PLL tuner clock signal output
26	PWR CONT	O	Power supply circuit control (H: POWER ON)
27	MUTE A	O	Muting control signal output (L: MUTE)
28	PLL CE	O	PLL tuner strobe signal output
29	FUNC	O	Function control signal output (TUNER: I, CD: H, TAPE: L)
30	PLL DI	O	PLL tuner control data signal output
31	REMOCON IN	I	Remote control signal input
32	BLKCK	I	Sub code block clock input
33	STATUS	I	CD status signal input
34	CD RST	I	CD reset signal input (L: RESET)
35	RST	I	System reset signal input (L: RESET)
36	MLD	O	CD signal process strobe signal output
37	MDATA	O	CD signal process data output
38	MCLK	O	CD signal process clock signal output


Pin No.	Terminal Name	I/O	Function
39	CLDCK	O	CD sub-code reading clock output
40	SUBQ	I	CD sub-code data input
41	—	—	—
42	—	—	—
43	CM	I	1-chip microprocessor mode setting input (L: 1-chip)
44	TLOCK	I	CD tracking clock signal input (L: Tracking OK)
45	FLOCK	I	CD focus lock signal input (L: Focus OK)
46	REST	I	CD traverse position detection switch signal input (H: most inside position)
47	TUNED	I	PLL tuner receiving signal input (L: Tuned)
48	CD CLOSE SW	I	CD tray close detection switch signal input (L: Close)
49	SENSE	I	CD sense signal input (H: Detect)
50	REM STBY	I	Remote control sensor power control (H: ON, 4 MHz)
51	NC	—	—
52	NC	—	—
53	BP2	O	Beat proof control signal output (L: ON)
54	SOFT	O	Preset EQ. control signal output (SOFT: L)
55	CLEAR	O	Preset EQ. control signal output (CLEAR: L)
56	LOUD2	O	Loudness control signal output (Less than -10 dB: H)
57	LOUD1	O	Loudness control signal output (Less than -6 dB: H)
58	FLAT	O	Preset EQ. control signal output (FLAT: L)
59	VOCAL	O	Preset EQ. control signal output (VOCAL: L)
60	V _{CC} DET	I	Power detection signal input (L: ON)
61	DES0	I	Connected to +5 V
62	DES1	I	Connected to GND
63	DES2	I	Connected to GND
64	NC	—	—
65	NC	—	—
66	NC	—	—
67 } 93	SEG26 } SEG0	O	LCD segment signal output
94 } 97	COM3 } COM1	O	LCD common signal output
98 } 100	VLC3 } VLC1	I	LCD bias reference voltage input




MN66271RA

IC702


SERVO PROCESSOR/DIGITAL SIGNAL PROCESSOR/
DIGITAL FILTER/D/A CONVERTER





PROCESSOR /



■ Block Diagram • Main circuit







■ Replacement Parts List

Notes: *Important safety notices:

 Components identified by Δ mark have special characteristics important for safety.

Furthermore, special parts which have purposes of fire-retardant (resistors), high-quality sound (capacitors), low-noise (resistors), etc. are used.

When replacing any of components, be sure to use only manufacturer's specified parts shown in the parts list.

*The parenthesized indications in the Remarks columns specify the areas. (Refer to the cover page for area.)

Parts without these indications can be used for all areas.

*Warning: This product uses a diode. Refer to caution statements on page 2.

*The "(SF)" mark denotes the standard part.

Ref. No.	Part No.	Part Name & Description	Remarks	Ref. No.	Part No.	Part Name & Description	Remarks
		INTEGRATED CIRCUIT(S)		Q601	2SC3312RTA	TRANSISTOR	
IC1	TA7358FMATEL	IC, FM FRONT END		Q602, 603	2SC3311R	TRANSISTOR	
IC2	XLU2616F-E1	IC, PLL FREQ. SYNTHESIZER		Q604	UN411FTA	TRANSISTOR	
IC3	LA1831MSATEL	IC, FM/AM IF AMP		Q605	2SC3311AIRTA	TRANSISTOR	
IC301	BA7755	IC, R/P SELECT		Q606	UN4111	TRANSISTOR	
IC302	TA8142AP	IC, P. B. EQ/REC/AMP/ALC		Q607	UN411FTA	TRANSISTOR	
IC601	MND2410REAH2	IC, SYSTEM CONT. /LCD DRIVE		Q608	UN4213	TRANSISTOR	
IC602	S-806H-T	IC, RESET		Q609	2SC3311AIRTA	TRANSISTOR	
IC603	AN7135	IC, POWER AMP		Q610	2SB1398QTA	TRANSISTOR	
IC604	TA8184FMATEL	IC, ELECTRIC VOLUME		Q611	2SC3311AIRTA	TRANSISTOR	
IC605 Δ	BA3936	IC, POWER SUPPLY CONT		Q612	2SB1398QTA	TRANSISTOR	
IC606 Δ	S81350HG	IC, REGULATOR		Q613	UN4111	TRANSISTOR	
IC701	AN8802SCE1V	IC, SERVO AMP		Q614	UN4116	TRANSISTOR	
IC702	MN66271RA	IC, SERVO PROCESSOR		Q615	UN421LTA	TRANSISTOR	
IC703	AN8389SE1	IC, COIL/MOTOR DRIVE		Q616	UN4213	TRANSISTOR	
IC971	DN6851ALB	IC, HALL		Q617	UN411FTA	TRANSISTOR	
		TRANSISTOR(S)		Q701	2SB709S	TRANSISTOR	
Q1, 2	2SC3311R	TRANSISTOR		Q1001	UN4211	TRANSISTOR	
Q3	2SC2786LTA	TRANSISTOR		Q1003 Δ	2SC3311AIRTA	TRANSISTOR	
Q4	2SC3313B	TRANSISTOR		Q1004 Δ	2SB1393AU	TRANSISTOR	
Q5	UN411FTA	TRANSISTOR				DIODE (S)	
Q8	2SC3311R	TRANSISTOR		D1	KV1360NT	DIODE	
Q10	UN411FTA	TRANSISTOR		D2 Δ	RVDMT28R2BTA	DIODE	
Q11	2SD1450RTA	TRANSISTOR		D3	KV1583BMTL	DIODE	
Q12	2SC3313B	TRANSISTOR		D4	KV1360NT	DIODE	
Q14	2SC3311R	TRANSISTOR		D8	MA165	DIODE	
Q15, 16	UN411FTA	TRANSISTOR		D10	MA165	DIODE	
Q101, 102	2SJ164QTA	TRANSISTOR		D11	RVD1SS135TA	DIODE	
Q104	2SC3311AIRTA	TRANSISTOR		D301	MA165	DIODE	
Q105	2SJ164QTA	TRANSISTOR		D302	RVDMT24R7BTA	DIODE	
Q201, 202	2SJ164QTA	TRANSISTOR		D303	MA165	DIODE	
Q204	2SC3311AIRTA	TRANSISTOR		D304	RVDMT26R8BTA	DIODE	
Q205	2SJ164QTA	TRANSISTOR		D601	MA165	DIODE	
Q301, 302	2SC3311AR	TRANSISTOR		D602	MA4051-L	DIODE	
Q303	2SD1450RTA	TRANSISTOR		D603-605	MA165	DIODE	
Q304	UN421LTA	TRANSISTOR		D607 Δ	RVDMT28R2BTA	DIODE	
Q305, 306	2SC3311AR	TRANSISTOR		D608-614	MA165	DIODE	
Q307	2SC3311AIRTA	TRANSISTOR		D617-619	MA165	DIODE	
Q309, 310	UN4211	TRANSISTOR		D625	MA4051-L	DIODE	
Q311	UN421FTA	TRANSISTOR		D626	MA4056MTA	DIODE	
Q312	2SC3311AR	TRANSISTOR		D627	MA165	DIODE	
Q317	UN411FTA	TRANSISTOR		D901-904 Δ	RL203M11	DIODE	
Q401	2SC3312RTA	TRANSISTOR		D971	RVD1SS133TA	DIODE	
Q402, 403	2SC3311AIRTA	TRANSISTOR		D1001	LN170WAL3CF	LED	
Q501	2SC3312RTA	TRANSISTOR		D1002 Δ	MA4130M	DIODE	
Q502, 503	2SC3311AIRTA	TRANSISTOR		D1003, 1004	MA165	DIODE	

Ref. No.	Part No.	Part Name & Description	Remarks	Ref. No.	Part No.	Part Name & Description	Remarks
		VARIABLE RESISTOR(S)		S815	EVQ21405R	SW, REW	
VR301	RRN6B05B73TA	V. R. TAPE SPEED ADJ.		S816	EVQ21405R	SW, FF	
		COMPONENT COMBINATION(S)		S817	EVQ21405R	SW, -/CD SKIP	
Z1	RXABPWB6A	COMPONENT COMBINATION		S818	EVQ21405R	SW, ADJUST/MEMORY	
Z601	RAT0010	BUZZER		S819	EVQ21405R	SW, STOP/CLEAR	
Z602	RSL5097-L	LCD DISPLAY		S901 △	RJJ1SE01-H	SW, AC/DC	
Z603	RCDGP1U58YD	REMOTE SENSOR		S971	RSH1A89ZD-U	SW, MODE DETECT	
		COIL(S)		S972	RSH1A90YD-U	SW, HALF	
L2	RLV6C012-0	COIL		S973	RSH1A90YD-U	SW, R. REC INH	
L3	RL02B011-T	COIL		S974	RSH1A90YD-U	SW, F. REC INH	
L5	RLQZP8R2JT-Y	COIL		S975	RSH1A90YD-U	SW, ATS/Cr02	
L8	ELEXT101KA9	COIL		S1001	RSH1A012-U	SW, LASER ON/OFF	
L9	ELEXT150KA9	COIL				CONNECTOR(S)	
L11	RL01B004-T	COIL		CN701	RJU035T016-1	CONNECTOR(16P)	
L301	RL08C002M-T	COIL		CN702	RJS1A6723-1Q	CONNECTOR(23P)	
L302, 303	RLQZB470KT-D	COIL		CP301	RJP5G18ZA	CONNECTOR(5P)	
L601-603	ELEXT2R2KA9	COIL		CP302	RJT028W010-2	CONNECTOR(10P)	
L853	RLQB221JTA-Y	COIL		CP303	RJT028W009-2	CONNECTOR(9P)	
L860	ELEXT2R2KA9	COIL		CP901	RJT029W003-1	CONNECTOR(3P)	
L901, 902△	RL1500050T-Y	COIL		CP902	RJT029W004	CONNECTOR(4P)	
L1002-1008	RL1500050T-Y	COIL		CS1	RJS1A5211	CONNECTOR(11P)	
		TRANSFORMER(S)		CS601	RJT060B04	CONNECTOR(4P)	
T1	RL12Z014-T	TRANSFORMER		CS801	RJS1A5203	CONNECTOR(3P)	
T901 △	RTP1U1B002AX	TRANSFORMER		CS3021	RJU028W010	SOCKET(10P)	
		FILTER(S)		CS3022	RJT066H10B	CONNECTOR(10P)	
CF1, 2	RLFFETMLA02D	CERAMIC FILTER		CS3023	RJU066H10M	CONNECTOR(10P)	
CF3	RLFDFTD05M	CERAMIC FILTER		CS3031	RJU028W009-1	CONNECTOR(9P)	
		OSCILLATOR(S)		CS3032	RJT066H08B	CONNECTOR(8P)	
X1	RSXZ456KM01	OSCILLATOR(456KHz)		CS3033	RJU066H08M	CONNECTOR(8P)	
X2	RSXC7M20S04T	OSCILLATOR(7. 2MHz)		CS7021	RJS1A6823	CONNECTOR(23P)	
X601	RSXD32K7S03	OSCILLATOR(32. 7KHz)				TRIMMER	
X602	RVBCSA3R9MGT	OSCILLATOR(3. 9MHz)		CT1	RCV10AF1T-S	TRIMMER CAPACITOR	
X701	RSXZ16M9M02T	OSCILLATOR(16. 9344MHz)		CT2	ECRLA020E53R	VARIABLE CAPACITOR	
		FUSE(S)				FUSE HOLDER	
F901 △	XBA2C20TB0	FUSE T2A		FH901, 902	EYF52BC	FUSE HOLDER	
		SWITCH(ES)				I. C PROTECTOR	
S601	RSH1A012-U	SW, CD OPEN/CLOSE		IP603 △	SRUN15	I. C. P	
S701	RSM0006-P	SW, REST				JACK(S)	
S801	EVQ21405R	SW, POWER STANDBY		JK601	RJJ1D25ZA-C	JACK, MIX MIC	
S802	EVQ21405R	SW, STOP		JK602	RJJD7S2YA-C	JACK, HEADPHONES	
S803	EVQ21405R	SW, BAND		JK901 △	RJJ1SE01-H	JACK, AC IN (S901)	
S804	EVQ21405R	SW, PRESET TUNING					
S805	EVQ21405R	SW, +/CD SKIP					
S806	EVQ21405R	SW, PLAY/PAUSE					
S807	EVQ21405R	SW, TIME CHECK					
S808	EVQ21405R	SW, TIMER					
S809	EVQ21405R	SW, VOLUME -					
S810	EVQ21405R	SW, VOLUME +					
S811	EVQ21405R	SW, PRESET EQ					
S812	EVQ21405R	SW, EASY REC					
S813	EVQ21405R	SW, PLAY DIR					
S814	EVQ21405R	SW, REC PAUSE					

Notes : • Capacity values are in microfarads (uF) unless specified otherwise, P=Pico-farads (pF) F=Farads (F)
 • Resistance values are in ohms, unless specified otherwise, 1K=1,000 (OHM) , 1M=1,000k (OHM)

Ref. No.	Part No.	Values & Remarks	Ref. No.	Part No.	Values & Remarks	Ref. No.	Part No.	Values & Remarks
		RESISTORS	R101	ERDS2TJ474	1/4W 470K	R333	ERDS2TJ472	1/4W 4.7K
			R102	ERDS2TJ153	1/4W 15K	R401	ERDS2TJ273	1/4W 27K
			R103	ERDS2TJ750	1/4W 75	R402	ERDS2TJ333	1/4W 33K
R1	ERDS2TJ104	1/4W 100K	R104	ERDS2TJ681	1/4W 680	R403	ERDS2TJ123	1/4W 12K
R2	ERDS2TJ332	1/4W 3.3K	R105	ERDS2TJ822	1/4W 8.2K	R404	ERDS2TJ824	1/4W 820K
R3	ERDS2TJ104	1/4W 100K	R106	ERDS2TJ272T	1/4W 2.7K	R405	ERDS2TJ682T	1/4W 6.8K
R5	ERDS2TJ103	1/4W 10K	R107	ERDS2TJ334	1/4W 330K	R406	ERDS2TJ221	1/4W 220
R6	ERDS2TJ152	1/4W 1.5K	R108	ERDS2TJ822	1/4W 8.2K	R408	ERDS2TJ823T	1/4W 82K
R7	ERDS2TJ330	1/4W 33	R109	ERDS2TJ223	1/4W 22K	R409	ERDS2TJ562	1/4W 5.6K
R8	ERDS2TJ104	1/4W 100K	R110	ERDS2TJ102	1/4W 1K	R411	ERDS2TJ181T	1/4W 180
R9	ERDS2TJ471	1/4W 470	R111	ERDS2TJ272T	1/4W 2.7K	R412	ERDS2TJ1R0	1/4W 1.0
R10	ERDS2TJ102	1/4W 1K	R112	ERDS2TJ470	1/4W 47	R413	ERDS2TJ272T	1/4W 2.7K
R11	ERDS2TJ103	1/4W 10K	R113, 114	ERDS2TJ472	1/4W 4.7K	R414	ERDS2TJ1R2	1/4W 1.2
R12	ERDS2TJ223	1/4W 22K	R201	ERDS2TJ474	1/4W 470K	R415	ERDS2TJ823T	1/4W 82K
R13	ERDS2TJ153	1/4W 15K	R202	ERDS2TJ153	1/4W 15K	R501	ERDS2TJ273	1/4W 27K
R14	ERDS2TJ103	1/4W 10K	R203	ERDS2TJ820	1/4W 82	R502	ERDS2TJ333	1/4W 33K
R15	ERDS2TJ223	1/4W 22K	R204	ERDS2TJ681	1/4W 680	R503	ERDS2TJ123	1/4W 12K
R17	ERDS2TJ103	1/4W 10K	R205	ERDS2TJ822	1/4W 8.2K	R504	ERDS2TJ824	1/4W 820K
R18	ERDS2TJ223	1/4W 22K	R206	ERDS2TJ272T	1/4W 2.7K	R505	ERDS2TJ682T	1/4W 6.8K
R19	ERDS2TJ101	1/4W 100	R207	ERDS2TJ334	1/4W 330K	R506	ERDS2TJ221	1/4W 220
R20	ERDS2TJ151	1/4W 150	R208	ERDS2TJ822	1/4W 8.2K	R508	ERDS2TJ823T	1/4W 82K
R22	ERDS2TJ331	1/4W 330	R209	ERDS2TJ223	1/4W 22K	R509	ERDS2TJ562	1/4W 5.6K
R24	ERDS2TJ471	1/4W 470	R210	ERDS2TJ102	1/4W 1K	R511	ERDS2TJ181T	1/4W 180
R25	ERDS2TJ104	1/4W 100K	R211	ERDS2TJ272T	1/4W 2.7K	R512	ERDS2TJ1R0	1/4W 1.0
R26, 27	ERDS2TJ102	1/4W 1K	R212	ERDS2TJ470	1/4W 47	R513	ERDS2TJ272T	1/4W 2.7K
R28	ERDS2TJ334	1/4W 330K	R213, 214	ERDS2TJ472	1/4W 4.7K	R514	ERDS2TJ1R2	1/4W 1.2
R29	ERDS2TJ331	1/4W 330	R301	ERDS2TJ474	1/4W 470K	R515	ERDS2TJ823T	1/4W 82K
R30	ERDS2TJ332	1/4W 3.3K	R302	ERDS2TJ104	1/4W 100K	R601	ERDS2TJ334	1/4W 330K
R31	ERDS2TJ472	1/4W 4.7K	R303	ERDS2TJ103	1/4W 10K	R602	ERDS2TJ180T	1/4W 18
R36, 37	ERDS2TJ223	1/4W 22K	R304-306	ERDS2TJ182	1/4W 1.8K	R603	ERDS2TJ102	1/4W 1K
R40	ERDS2TJ105T	1/4W 1M	R309	ERDS2TJ123	1/4W 12K	R604	ERDS2TJ101	1/4W 100
R41	ERDS2TJ471	1/4W 470	R310	ERDS2TJ472	1/4W 4.7K	R605, 606	ERDS2TJ332	1/4W 3.3K
R42	ERDS2TJ103	1/4W 10K	R311	ERDS2TJ477T	1/4W 4.7	R607	ERDS2TJ333	1/4W 33K
R43, 44	ERDS2TJ222	1/4W 2.2K	R312	ERDS2TJ123	1/4W 12K	R608, 609	ERDS2TJ823T	1/4W 82K
R45	ERDS2TJ223	1/4W 22K	R313	ERDS2TJ472	1/4W 4.7K	R610	ERDS2TJ104	1/4W 100K
R47	ERDS2TJ332	1/4W 3.3K	R314	ERDS2TJ682T	1/4W 6.8K	R611	ERDS2TJ102	1/4W 1K
R49	ERDS2TJ183T	1/4W 18K	R315	ERDS2TJ472	1/4W 4.7K	R612	ERDS2TJ105T	1/4W 1M
R52	ERDS2TJ223	1/4W 22K	R316	ERDS2TJ222	1/4W 2.2K	R613	ERDS2TJ106T	1/4W 10M
R54	ERDS2TJ222	1/4W 2.2K	R317	ERDS2TJ272T	1/4W 2.7K	R614	ERDS2TJ224T	1/4W 220K
R55, 56	ERDS2TJ682T	1/4W 6.8K	R318	ERDS2TJ153	1/4W 15K	R615, 616	ERDS2TJ471	1/4W 470
R57	ERDS2TJ103	1/4W 10K	R319	ERDS2TJ473	1/4W 47K	R617	ERDS2TJ103	1/4W 10K
R59	ERDS2TJ471	1/4W 470	R320, 321	ERDS2TJ103	1/4W 10K	R618, 619	ERDS2TJ153	1/4W 15K
R61	ERDS2TJ103	1/4W 10K	R322	ERDS2TJ222	1/4W 2.2K	R620, 621	ERDS2TJ472	1/4W 4.7K
R62	ERDS2TJ471	1/4W 470	R324	ERDS2TJ102	1/4W 1K	R622	ERDS2TJ124T	1/4W 120K
R63	ERDS2TJ105T	1/4W 1M	R325	ERDS2TJ103	1/4W 10K	R623	ERDS2TJ472	1/4W 4.7K
R64	ERDS2TJ332	1/4W 3.3K	R327	ERDS2TJ102	1/4W 1K	R624	ERDS2TJ222	1/4W 2.2K
R65	ERDS2TJ470	1/4W 47	R328	ERDS2TJ101	1/4W 100	R625	ERDS2TJ104	1/4W 100K
R66	ERDS2TJ222	1/4W 2.2K	R329	ERDS2TJ335T	1/4W 3.3M	R626	ERDS2TJ333	1/4W 33K
R67	ERDS2TJ102	1/4W 1K	R332	ERDS2TJ333	1/4W 33K	R627	ERDS2TJ560T	1/4W 56

Ref. No.	Part No.	Values & Remarks	Ref. No.	Part No.	Values & Remarks	Ref. No.	Part No.	Values & Remarks
R628	ERDS2TJ103	1/4W 10K	R704	ERJ6GEYJ102A	1/10W 1K	R1009	ERDS2TJ181T	1/4W 180
R629	ERDS2TJ394	1/4W 390K	R705	ERJ6GEYJ103V	1/10W 10K	R1010	ERDS2TJ103	1/4W 10K
R630	ERDS2TJ823T	1/4W 82K	R706	ERJ6GEYJ102A	1/10W 1K	R1011	ERDS2TJ102	1/4W 1K
R631	ERDS2TJ473	1/4W 47K	R707	ERJ6GEYJ473V	1/10W 47K	R1012	ERDS2TJ181T	1/4W 180
R632, 633	ERDS2TJ474	1/4W 470K	R708	ERJ6GEYJ104V	1/10W 100K	R1013	ERDS2TJ122	1/4W 1.2K
R634	ERDS2TJ683	1/4W 68K	R709	ERJ6GEYJ683V	1/10W 68K	R1015	ERDS2TJ152	1/4W 1.5K
R635	ERDS2TJ104	1/4W 100K	R711	ERJ6GEYJ154V	1/10W 150K	R1016, 1017	ERDS2TJ562	1/4W 5.6K
R636	ERDS2TJ153	1/4W 15K	R712	ERJ6GEYJ221V	1/10W 220	R1018, 1019	ERDS2TJ470	1/4W 47
R637	ERDS2TJ184T	1/4W 180K	R714	ERJ6GEY0R00A	1/10W 0.00			
R638	ERDS2TJ154	1/4W 150K	R717-720	ERJ6GEYJ102A	1/10W 1K			CHIP JUMPERS
R641	ERDS2TJ273	1/4W 27K	R721	ERJ6GEYJ101V	1/10W 100			
R642	ERDS2TJ153	1/4W 15K	R722	ERJ6GEYJ563V	1/10W 56K	J701-704	ERJ8GEY0R00A	1/8W 0.00
R643	ERDS2TJ473	1/4W 47K	R723	ERJ6GEYJ182V	1/10W 1.8K	J707-709	ERJ8GEY0R00A	1/8W 0.00
R644, 645	ERDS2TJ273	1/4W 27K	R724	ERJ6GEYJ333V	1/10W 33K	J714-717	ERJ8GEY0R00A	1/8W 0.00
R646	ERDS2TJ473	1/4W 47K	R725	ERJ6GEYJ472V	1/10W 4.7K	J721	ERJ6GEY0R00A	1/10W 0.00
R647	ERDS2TJ222	1/4W 2.2K	R726	ERJ6GEYJ473V	1/10W 47K	J724-726	ERJ6GEY0R00A	1/10W 0.00
R648-651	ERDS2TJ103	1/4W 10K	R727	ERJ6GEYJ103V	1/10W 10K			
R653	ERDS2TJ331	1/4W 330	R728	ERJ6GEYJ392V	1/10W 3.9K			TEST JUMPER
R654	ERDS2TJ183T	1/4W 18K	R730	ERJ6GEYJ331V	1/10W 330			
R655, 656	ERDS2TJ222	1/4W 2.2K	R731	ERJ6GEYJ392V	1/10W 3.9K	TJ701, 702	EYF8CU	TEST JUMPER
R657-659	ERDS2TJ102	1/4W 1K	R734-736	ERJ6GEYJ101V	1/10W 100			
R660, 661	ERDS2TJ472	1/4W 4.7K	R738	ERJ6GEYJ223V	1/10W 22K			CAPACITORS
R662	ERDS2TJ333	1/4W 33K	R739	ERJ6GEYJ681V	1/10W 680			
R663	ERDS2TJ472	1/4W 4.7K	R741-743	ERJ6GEYJ562V	1/10W 5.6K	C4	RCBS1H102KBY	50V 1000P
R664	ERDS2TJ332	1/4W 3.3K	R744	ERJ6GEYJ103V	1/10W 10K	C5	ECBT1H2R2KC5	50V 2.2P
R665	ERDS2TJ102	1/4W 1K	R745	ERJ6GEYJ155V	1/10W 1.5M	C6	RCBS1H102KBY	50V 1000P
R666	ERDS2TJ273	1/4W 27K	R748	ERJ6GEYJ182V	1/10W 1.8K	C8	ECBT1H4R7KC5	50V 4.7P
R667	ERDS2TJ221	1/4W 220	R749	ERJ8GEYJ103V	1/8W 10K	C9	ECEA1HKNO10B	50V 1U
R668	ERDS2TJ470	1/4W 47	R801	ERDS2TJ152	1/4W 1.5K	C10	ECBT1C332MR5	16V 3300P
R669	ERDS2TJ390	1/4W 39	R802	ERDS2TJ222	1/4W 2.2K	C11	ECEA1AKA101B	10V 100U
R670	ERDS2TJ473	1/4W 47K	R803	ERDS2TJ272T	1/4W 2.7K	C12	ECFR1C473MR	16V 0.047U
R671	ERDS2TJ104	1/4W 100K	R804	ERDS2TJ392T	1/4W 3.9K	C13	ECFR1C103MR	16V 0.01U
R674, 675	ERDS2TJ104	1/4W 100K	R805	ERDS2TJ562	1/4W 5.6K	C14	ECBT1C103MS5	16V 0.01U
R676	ERDS2TJ154	1/4W 150K	R806	ERDS2TJ822	1/4W 8.2K	C15	ECBT1H6R8KC5	50V 6.8P
R677	ERDS2TJ184T	1/4W 180K	R807	ERDS2TJ153	1/4W 15K	C16, 17	RCBS1H102KBY	50V 1000P
R678	ERDS2TJ123	1/4W 12K	R808	ERDS2TJ333	1/4W 33K	C18	ECBT1H200JC5	50V 20P
R679	ERDS2TJ122	1/4W 1.2K	R809	ERDS2TJ823T	1/4W 82K	C19	ECBT1H220JC5	50V 22P
R680	ERDS2TJ681	1/4W 680	R810	ERDS2TJ152	1/4W 1.5K	C20	RCBS1H102KBY	50V 1000P
R681	ERDS2TJ682T	1/4W 6.8K	R811	ERDS2TJ222	1/4W 2.2K	C21	ECEA1AKA101B	10V 100U
R682	ERDS2TJ103	1/4W 10K	R812	ERDS2TJ272T	1/4W 2.7K	C22-24	RCBS1H102KBY	50V 1000P
R683	ERDS2TJ331	1/4W 330	R813	ERDS2TJ392T	1/4W 3.9K	C25	ECBT1H150JC5	50V 15P
R684	ERDS2TJ273	1/4W 27K	R814	ERDS2TJ562	1/4W 5.6K	C26	ECBT1H6R8KC5	50V 6.8P
R685, 686	ERDS2TJ103	1/4W 10K	R815	ERDS2TJ822	1/4W 8.2K	C27	ECBT1H4R7KC5	50V 4.7P
R687	ERDS2TJ102	1/4W 1K	R816	ERDS2TJ153	1/4W 15K	C28, 29	RCBS1H102KBY	50V 1000P
R688	ERDS2TJ273	1/4W 27K	R817	ERDS2TJ333	1/4W 33K	C31	RCBS1H102KBY	50V 1000P
R689	ERDS2TJ183T	1/4W 18K	R821	ERDS2TJ104	1/4W 100K	C32, 33	ECBT1H101KB5	50V 100P
R690	ERDS2TJ682T	1/4W 6.8K	R822	ERDS2TJ823T	1/4W 82K	C34	ECBT1H680J5	50V 68P
R691	ERDS2TJ122	1/4W 1.2K	R858	ERDS2TJ104	1/4W 100K	C35	ECBT1H1R5M5	50V 1.5P
R698, 699	ERDS2TJ472	1/4W 4.7K	R950	ERX12SJWR22E	1/2W 0.22	C36, 37	RCBS1H102KBY	50V 1000P
R701	ERJ6GEYJ100	1/10W 10	R951	ERDS2TJ273	1/4W 27K	C38	ECBT1H331KB5	50V 330P
R702	ERJ6GEYJ471V	1/10W 470	R954	ERDS2TJ472	1/4W 4.7K	C39, 40	ECBT1C103MS5	16V 0.01U
R703	ERJ6GEYJ823	1/10W 82K	R1001	ERDS2TJ471	1/4W 470	C44	ECEA1AU101	10V 100U

Ref. No.	Part No.	Values & Remarks	Ref. No.	Part No.	Values & Remarks	Ref. No.	Part No.	Values & Remarks
C47	ECFR1C223MR	16V 0.022U	C211	ECEA1EKA4R7B	25V 4.7U	C610	RCBS1H102KBY	50V 1000P
C48	ECEA0JU101B	6.3V 100U	C212	ECBT1H821KB5	50V 820P	C611	ECBT1H820KB5	50V 82P
C51	ECEA1HKA010B	50V 1U	C213, 214	ECBT1H102KB5	50V 1000P	C612	ECBT1H101KB5	50V 100P
C52	ECFR1C473MR	16V 0.047U	C215	ECBT1H101KB5	50V 100P	C613	ECBT1H470J5	50V 47P
C58	ECBT1H560J5	50V 56P	C301	ECEA1HN010	50V 1U	C614	ECBT1H101KB5	50V 100P
C60	ECEA1CKA100B	16V 10U	C302, 303	ECBT1C103MS5	16V 0.01U	C615	ECBT1C103MS5	16V 0.01U
C61	ECBT1C332MR5	16V 3300P	C304	ECQP2A821JZT	100V 820P	C616, 617	ECBT1H220JC5	50V 22P
C62	RCBS1H102KBY	50V 1000P	C305	ECQP2A681JZT	100V 680P	C618	ECBT1C103MS5	16V 0.01U
C63	ECBA1H681KB5	50V 680P	C306	ECQP2A562JZT	100V 5600P	C619-622	ECBT1H561KB5	50V 560P
C64	ECFR1C473MR	16V 0.047U	C307	ECEA1HKA010B	50V 1U	C624	ECEA1HKA010B	50V 1U
C65	ECBT1H470J5	50V 47P	C308	ECEA1AU101	10V 100U	C625	ECBT1C103MS5	16V 0.01U
C66	ECBT1H47K5	50V 4.7P	C309	ECQB1H223JF3	50V 0.022U	C626	ECEA0JKA470B	6.3V 47U
C67	ECFR1C223MR	16V 0.022U	C310, 311	ECBT1H102KB5	50V 1000P	C628	ECEA1AKA101B	10V 100U
C68	ECEA1HKA010B	50V 1U	C312, 313	ECBT1C222MR5	16V 2200P	C629	RCBS1H102KBY	50V 1000P
C69, 70	ECFR1C183MR	16V 0.018U	C314	ECBT1C332MR5	16V 3300P	C630	ECEA0JU470B	6.3V 47U
C71	ECEA1HKA2R2B	50V 2.2U	C315	ECEA1EU101	25V 100U	C631	ECEA1EKA4R7B	25V 4.7U
C72	ECEA1HKA010B	50V 1U	C319	ECEA1AU221	10V 220U	C632, 633	ECEA1HKA010B	50V 1U
C74	ECBT1H471KB5	50V 470P	C320	ECEA1HKA3R3B	50V 3.3U	C635	ECA1EM331B	25V 330U
C75-77	ECEA1HKA010B	50V 1U	C321	ECEA0JKA220B	6.3V 22U	C636	ECEA1AU101	10V 100U
C80, 81	ECBT1H331KB5	50V 330P	C322	ECEA0JU101B	6.3V 100U	C637	ECEA1HU470	50V 47U
C82	ECBT1H150JC5	50V 15P	C401	ECEA1HKA010B	50V 1U	C638	ECEA1EU470	25V 47U
C83	ECBT1H331KB5	50V 330P	C402	ECBT1H101KB5	50V 100P	C639	ECEA0JU221	6.3V 220U
C84	ECBT1C103MS5	16V 0.01U	C403	ECEA1HKA010B	50V 1U	C640	ECEA1EU101	25V 100U
C86	ECBT1H331KB5	50V 330P	C404	ECBT1C332MR5	16V 3300P	C641	ECEA1CU100	16V 10U
C87	ECBT1C103MS5	16V 0.01U	C405	ECEA1HKA3R3B	50V 0.33U	C642	ECEA0JKA220B	6.3V 22U
C88	RCBS1H102KBY	50V 1000P	C406	ECEA1CKA100B	16V 10U	C643	ECEA1AU221	10V 220U
C89	ECBT1H101KB5	50V 100P	C407	ECEA1HKA2R2B	50V 0.22U	C644	ECBT1H471KB5	50V 470P
C90	ECBT0J223MS5	6.3V 0.022U	C409, 410	ECEA1AU101	10V 100U	C645	ECEA1EU332E	25V 3300U
C91	ECBT1C103MS5	16V 0.01U	C411	ECQV1H224JM3	50V 0.22U	C647	ECEA1HKA2R2B	50V 2.2U
C92, 93	ECBT0J223MS5	6.3V 0.022U	C412	ECEA1AU102B	10V 1000U	C648	ECEA1EKA4R7B	25V 4.7U
C101	ECBT1H101KB5	50V 100P	C413	ECEA1HKA010B	50V 1U	C649	ECEA0JKA470B	6.3V 47U
C102	ECBT1C152KR5	16V 1500P	C414	RCBS1H102KBY	50V 1000P	C650	ECEA1AU101	10V 100U
C103	ECEA0JU330	6.3V 33U	C415	ECBT1C182MR5	16V 1800P	C651, 652	ECBT1H561KB5	50V 560P
C104	ECBT1H331KB5	50V 330P	C501	ECEA1HKA010B	50V 1U	C653	RCBS1H102KBY	50V 1000P
C105	ECFR1C153KR	16V 0.015U	C502	ECBT1H101KB5	50V 100P	C701	ECEA0JKA220	6.3V 22U
C106	ECEA1EKA4R7B	25V 4.7U	C503	ECEA1HKA010B	50V 1U	C702	ECEA1HKA0101	50V 1U
C107	ECEA1HKA010B	50V 1U	C504	ECBT1C332MR5	16V 3300P	C703	ECEA0JKA1011	6.3V 100U
C108	ECEA0JU470B	6.3V 47U	C505	ECEA1HKA3R3B	50V	C704	ECUZ1E104MBN	25V 0.1U
C109, 110	ECBT1H221KB5	50V 220P	C506	ECEA1CKA100B	16V 10U	C705	ECEA1HKA0101	50V 1U
C111	ECEA1EKA4R7B	25V 4.7U	C507	ECEA1HKA2R2B	50V	C706	ECUE1H101JCN	50V 100P
C112	ECBT1H821KB5	50V 820P	C509, 510	ECEA1AU101	10V 100U	C707	ECUV1E273KBN	25V 0.027U
C113, 114	ECBT1H102KB5	50V 1000P	C511	ECQV1H224JM3	50V 0.22U	C708	ECUE1H472KBN	50V 4700P
C115	ECBT1H101KB5	50V 100P	C512	ECEA1AU102B	10V 1000U	C709	ECUE1C473KBN	16V 0.047U
C201	ECBT1H101KB5	50V 100P	C513	ECEA1HKA010B	50V 1U	C710	ECUE1H152KBN	50V 1500P
C202	ECBT1C152KR5	16V 1500P	C514	RCBS1H102KBY	50V 1000P	C711, 712	ECUZ1E104MBN	25V 0.1U
C203	ECEA0JU330	6.3V 33U	C515	ECBT1C182MR5	16V 1800P	C713	ECUV1C104MBN	16V 0.1U
C204	ECBT1H331KB5	50V 330P	C601	ECEA1HKA010B	50V 1U	C714	ECEA0JKA1011	6.3V 100U
C205	ECFR1C153KR	16V 0.015U	C602	ECBT1H101KB5	50V 100P	C715	ECEA0JKA4701	6.3V 47U
C206	ECEA1EKA4R7B	25V 4.7U	C603	ECEA1AU101	10V 100U	C716	ECUE1H561KBN	50V 560P
C207	ECEA1HKA010B	50V 1U	C604	ECEA1HKA010B	50V 1U	C717	ECUZ1E104MBN	25V 0.1U
C208	ECEA0JU470B	6.3V 47U	C605-607	RCBS1H102KBY	50V 1000P	C718	ECUV1C224KBN	16V 0.22U
C209, 210	ECBT1H221KB5	50V 220P	C609	ECEA1AU101	10V 100U	C721, 722	ECUE1H270JCN	50V 27P


[illegible]

Ref. No.	Part No.	Part Name & Description	Remarks
		PACKING MATERIALS	
P1	RPG1885	GIFT BOX	(EB)
P1	RPG1884	GIFT BOX	(EG)
P2	RPN0739	PAD ASS'Y	
		ACCESSORY PARTS	
A1 Δ	VJA0733	AC POWER CORD	(EB)(SF)[VRD]
A1 Δ	RJA0019-2K	AC POWER CORD	(EG)(SF)
A2	RQT2281-B	INSTRUCTIONS MANUAL	(EB)
A2	RQT2283-E	INSTRUCTIONS MANUAL	(EG)
A3	RAK-RX119WH	REMOTE CONTROLLER	
A3-1	RKK0057-K	BATTERY COVER(REMOTE CONT.)	

Note:

[VRD] : indicates parts that are supplied by Video Recorder Division.


■ Packaging




Ref. No.
201
201-1
201-2
202
203
203-1
204
204-1
205
206
207
208
209
210
211
211-1
212
212-1
214
215
216
217
218
220
221
222
223
224
225
226
227
227-1
228
228-1
229
230
231
231-1
232
233
234
235
236
237
237-1
238
239
240
241


Ref. No.	Part No.	Part Name & Description	Remarks	Ref. No.	Part No.	Part Name & Description	Remarks
				242	RUW147ZA	SPRING	
		MECHANISM PARTS		243	RUB515ZA	LEVER	
				244	RUB509ZA	LEVER	
201	RXQ0291	HEAD ASS' Y		245	RDV108ZA	BELT	
201-1	RHE5152ZB	SCREW		249	RMG0102-1	RUBBER	
201-2	RMB0331	SPRING		250	RNL180ZB	LEVER	
202	RJA793ZF	CHASSIS		261	XTW2+6L	SCREW	
203	RZLAR300	LEVER ASS' Y		263	XTN26+7J	SCREW	
203-1	RUW143ZA	SPRING		264	RHE5203ZA	SCREW	
204	1UB0089ZA	LEVER ASS' Y		265	XTW2+8S	SCREW	
204-1	RUW148ZA	SPRING		266	XYC2+JF16	SCREW	
205	1DM0018ZB	REEL TABLE ASS' Y		267	RHD26002	SCREW	
206	1DM0017ZB	REEL TABLE ASS' Y		268	RJS10T7ZA	CONNECTOR (J971)	
207	RML0069-1	LEVER		269	RUB507ZD	LEVER	
208	RDG5772ZC	GEAR		270	RUW144ZA	SPRING	
209	RUB508ZB	LEVER					
210	RUB506ZB	LEVER					
211	1UB0088ZB	PINCH ROLLER ASS' Y					
211-1	RMB0310	SPRING					
212	1UB0087ZB	PINCH ROLLER ASS' Y					
212-1	RUW140ZC	SPRING					
214	RNL12D	ARM					
215	RUB503ZD	LEVER					
216	RFKRAA0320	CHASSIS ASS' Y					
217	RUW142ZA	SPRING					
218	RJD105ZA	SPRING					
220	RUW139ZA	SPRING					
221	RFKPAA0309	MOTOR ASS' Y					
222	1UE0015ZA	PLUNGER ASS' Y					
223	RUB428ZE	SHAFT					
224	RUL1034ZA	PLATE					
225	RMD5014ZC	SPACER					
226	RDG5927ZG	GEAR					
227	RFKRXDS35-K	FLYWHEEL ASS' Y					
227-1	RNW139ZA	WASHER					
228	1DW0038ZB	FLYWHEEL ASS' Y					
228-1	RNW138ZA	WASHER					
229	1DG0006ZB	GEAR ASS' Y					
230	RUB513ZD	LEVER					
231	1UB0091ZA	LEVER ASS' Y					
231-1	RUW146ZA	SPRING					
232	1DR0011ZB	PULLEY ASS' Y					
233	RDV90ZB	BELT					
234	RDG5769ZA	GEAR					
235	RUQ111ZB	SPRING					
236	RUW145ZA	SPRING					
237	1UB0090ZA	ROD ASS' Y					
237-1	RUB512ZB	ROD					
238	RDG5773ZB	GEAR					
239	RUQ112ZA	SPRING					
240	RUS609ZC	SPRING					
241	RUB514ZB	LEVER					

■ Mechanism Parts Location





Cabinet Parts Location





Ref. No.	Part No.	Part Name & Description	Remarks	Ref. No.	Part No.	Part Name & Description	Remarks
		CABINET PARTS		51	XTV3+12GFZ	SCREW	
				52	XTV3+12G	SCREW	
				53	XTV3+10F	SCREW	
1	RFKXDS35-KA	FRONT CABINET ASS'Y		54	RHD30044	SCREW	
2	RFKXDS35EKB	TOP PANEL ASS'Y		55	RHD30006	SCREW	
2-1	RMCO226	SPRING		56	XTV3+10G	SCREW	
3	RKS0159C-K	REAR CABINET	(EB)	57	XTN26+6B	SCREW	
3	RKS0159D-K	REAR CABINET	(EG)	58	XTV26+8G	SCREW	
4	RFKLXDS35KA	CASSETTE HOLDER ASS'Y		59	XYN3+F12FY	SCREW	
4-1	RUS757ZA	SPRING		60	RAE0113Z	TRAVERSE DECK ASS'Y	
5	RFKNXDS35-K	HANDLE ASS'Y		60-1	SHGD112	RUBBER(A)	
6	RFKLXDS35KB	CD COVER ASS'Y		60-2	SHGD113-1	RUBBER(B)	
6-1	RYF0201-K	DISC CLAMPER ASS'Y		60-3	SNSD38	SCREW	
6-2	RMQ0152	HOLDER		61	RME0109	SPRING(A)	
6-3	RHM245ZA	MAGNET		62	RME0142	SPRING(B)	
6-4	RFKNXDS55N-K	DISC PAD ASS'Y		63	RMS0123-1	PIN(A)	
7	RMK0160	CHASSIS		64	RMS0350	PIN(B)	
8	RKK0062-K	BATTERY COVER		65	RMRO698-K	CHASSIS	
9	REE0528	FPC		66	XTV2+6G	SCREW	
10	RJC931ZC	BATTERY TERMINAL (+/-)					
11	RJC511ZB	BATTERY TERMINAL (-)					
12	RJC751ZA	BATTERY TERMINAL, BACK-UP					
13	RMN0234	LED HOLDER					
14	RMN0235	LCD HOLDER					
16	RSC0326	SHIELD PLATE					
17	RGU0967A-K	OPERATION BUTTON					
18	RJR0115	TERMINAL					
19	RMK0221	CHASSIS					
20	RMRO710-X	CONNECTOR HOLDER					
21	XEARR175ED-Y	ROD ANTENNA					
22	EAS10P497C	SPEAKER					
23	REX0546	WIRE ASS'Y(SPEAKER)					
24	RGPO352B-K	LCD PANEL					
25	RML0204-1	EJECT LEVER(CASSETTE)					
26	RDG0183	GEAR					
27	RGU0970-K	EJECT BUTTON(CASSETTE)					
28	RUW170ZB	SPRING					
30	RGQ0107-K	PIECE					
31	RGU0968-K	EJECT BUTTON(CD)					
32	RKF0341-K	COVER(OPERATION BUTTON)					
33	RMB0243	SPRING					
34	RME0155	SPRING					
35	RML0114	EJECT LEVER(CD)					
36	RWJ1103085KX	FLAT CABLE(W801)					
37	RWJ1111080XX	FLAT CABLE(PW1)					
38	REX0548	WIRE ASS'Y(CW901)					
39	REX0547	WIRE ASS'Y(CW902)					
40	RWJ4704125KR	FLAT CABLE(W305)					
41	RWJ1110075QQ	FLAT CABLE(PW301)					
42	RFKBXDS35AK	BATTERY P. C. B. (MAIN)					
43	RFKBXDS35BK	BATTERY P. C. B. (BACK-UP)					
50	XTV3+40GFZ	SCREW					