

Service Manual

Portable Stereo Component CD System

Radio Cassette

Free service manuals
Gratis schema's
Digitized by

RX-DT680

COMPACT
disc
DIGITAL AUDIO

MASH*
multi-stage noise shaping



Color

(K) Black Type

Areas

Country Code	Area	Color
(E)	Continental Europe	(K)
(EB)	Great Britain	
(EG)	F.R. Germany & Italy	

TAPE DECK: RX-FD55 MECHANISM SERIES (AR300)
TRAVERSE DECK: RX-DT55 MECHANISM SERIES (S0DD110)

■ SPECIFICATIONS

General:

Power Requirement: AC; 230~240 V, 50 Hz
Battery; 15 V (10 UM-1, R20/LR20 batteries)
Memory Back-up for Computer/Clock;
6 V (4 UM-3, R6/LR6 batteries)

Power Consumption: 57 W (AC only)
Power Output: Woofer; 60 W (30 W×2)...PMPO
Tweeter; 20 W (10 W×2)...PMPO
Speaker: Woofer; 12 cm×2 PM Dynamic speaker (2.7Ω)
Tweeter; 8 cm×2 PM Dynamic speaker (8Ω)

Input: MIX MIC; 5 mV/200~600Ω, Ø3.5
DC IN; 13.2 V (12~15 V)
Outputs: HEADPHONES; 32Ω, Ø3.5
SPEAKER; LOW; 2.7~8Ω
HIGH; 8~16Ω

Dimensions: CD OUT
641 (W)×267 (H)×232 (D) mm
Main unit; 313 (W)×267 (H)×232 (D) mm
Speaker box; 174 (W)×254 (H)×188 (D) mm

Weight: 8.7 kg without batteries

Disc Player Section:

Sampling Frequency: 44.1 kHz
D-A Conversion: 16-bit linear
Beam Source: Semiconductor laser (wavelength 780 nm)

No. of Channels: 2 channels, stereo
Frequency Range: 20~20,000 Hz (+1/-2 dB)
Dynamic Range: 86 dB
S/N Ratio: 95 dB
Wow and Flutter: Unmeasurable

Radio Section:

Frequency Range: FM; 87.5~108 MHz
LW; 144~288 kHz
MW; 522~1611 kHz
FM; 10.7 MHz
AM; 459 kHz
Sensitivity: FM; 2.0 µV/50 mW output (-3 dB Limit Sens.)
LW; 160 µV/m/50 mW output
MW; 140 µV/m/50 mW output

Tape Deck Section:

Frequency Range: 20~16,000 Hz (with normal tape)
20~17,000 Hz (with CrO₂ tape)
Recording System: AC bias, AC erase
Tape Speed: 4.8 cm/s
Monitor System: Variable sound monitor
Track System: 4-track 2-channel stereo recording and playback

*MASH

- MASH (Multi-Stage Noise Shaping) is an effective oversampling D/A conversion technique which realizes a high S/N ratio and needs no highly complex manufacturing processes such as a laser trimming.
- MASH is a trademark of NTT (Nippon Telegraph and Telephone Corporation).

Notes:

1. Weights and dimensions shown are approximate.
2. Design and specifications are subject to change without notice.

Panasonic

■ CONTENTS

	Page		Page
• PRECAUTION OF LASER DIODE	2	• HOW TO CHECK THE P.C.B.	42~44
• LOCATION OF CONTROLS	3~6	• MEASUREMENTS AND ADJUSTMENTS	45~49
• HANDLING PRECAUTIONS FOR TRAVERSE DECK	7	• FUNCTION OF IC TERMINALS	50~53
• DISASSEMBLY INSTRUCTIONS	7~16	• TROUBLESHOOTING GUIDE	54, 55
• SCHEMATIC DIAGRAM	17~30	• BLOCK DIAGRAM	56~62
• CIRCUIT BOARD DIAGRAM	31~36	• REPLACEMENT PARTS LIST	63 ~70, 74 ~76
• WIRING CONNECTION DIAGRAM	37, 38	• MECHANISM PARTS LOCATION	71~73
• DIGITAL SERVO SYSTEM	39, 40	• CABINET PARTS LOCATION	77, 78
• CHECKING THE OPERATION PROBLEMS ON THE TRAVERSE DECK (OPTICAL PICKUP)	41, 42		

CAUTION:

THIS PRODUCT UTILIZES A LASER.

USE OF CONTROLS OR ADJUSTMENTS OR PERFORMANCE OF PROCEDURES OTHER THAN THOSE SPECIFIED HEREIN MAY RESULT IN HAZARDOUS RADIATION EXPOSURE.

PRECAUTION OF LASER DIODE

CAUTION: This product utilizes a laser diode with the unit turned "on", invisible laser radiation is emitted from the pick up lens.

Wave length: 780 nm

Maximum output radiation power from pick up: 100 μ W/VDE

Laser radiation from the pick up lens is safety level, but be sure the followings:

1. Do not disassemble the optical pick up unit, since radiation from exposed laser diode is dangerous.
2. Do not adjust the variable resistor on the pickup unit. It was already adjusted.
3. Do not look at the focus lens using optical instruments.
4. Recommend not to look at pick up lens for a long time.


ACHTUNG: Dieses produkt enthält eine laserdioden. Im eingeschalteten zustand wird unsichtbare laserstrahlung von der lasereinheit abgestrahlt.

Wellenlänge: 780 nm

Maximale strehlungsleistung der lasereinheit: 100 μ W/VDE

Die strahlung an der lasereinheit ist ungefährlich, wenn folgende punkte beachtet werden:

1. Die lasereinheit nicht zerlegen, da die strahlung an der freigelegten laserdioden gefährlich ist.
2. Den werksseitig justierten einstellregler der lasereinheit nicht verstellen.
3. Nicht mit optischen instrumenten in die fokussierlinse blicken.
4. Nicht über längere zeit in die fokussierlinse blicken.



DANGER-Invisible laser radiation when open and interlock defeated. AVOID DIRECT EXPOSURE TO BEAM.

(Inside of product)

VORSICHT-Unsichtbare Laserstrahlung, wenn Abdeckung geöffnet und Sicherheitsverriegelung überbrückt. Nicht dem Strahl aussetzen.

(Im Inneren des Gerätes)

**CLASS 1
LASER PRODUCT**

**LUOKAN 1 LASERLAITE
KLASS 1 LASER APPARAT**

ADVARSEL: USYNLIG LASERSTRÅLING VED ÅBNING, NÅR SIKKERHEDSAFBRYDERE ER UDE AF FUNKTION. UNDGÅ UDSÆTTELSE FOR STRÅLING.


(Indersiden af apparatet)

VARO! Avattaessa ja suojalukitus ohitettaessa olet alttiina näkymättömälle lasersäteilylle. Älä katso säteeseen.

WARNING! Osynlig laserstrålning när denna del är öppnad och spårren är urkopplad. Betrakta ej strålen.


LOCATION OF CONTROLS

CD/GENERAL CONTROLS




- 1 Speakers (Tweeter) (8 cm, 8Ω)
- 2 Speakers (Woofer) (12 cm, 2.7Ω)
- 3 Bass reflex ports
- 4 Remote control sensor
- 5 Graphic equalizer controls (GRAPHIC EQUALIZER)
- 6 Disc holder
- 7 CD eject button (≡ CD EJECT)
- 8 Edit recording mode select button (EDIT MODE)
- 9 Tape length select button (TAPE LENGTH)
- 10 Set button (SET)
- 11 Automatic tape level setting button (ATLS)
- 12 Stop button (STOP)
- 13 Pause button (PAUSE)
- 14 Play button (PLAY)
- 15 Skip/search buttons (SKIP/SEARCH)
- 16 Headphones jack (PHONES) (Ø3.5, 32Ω)
- 17 Mixing microphone jack (MIXING MIC) (Ø3.5, 200~600Ω)
- 18 Operation switch and operation/battery check AC connection indicator (OPERATION)
- 19 CD mode indicator (CD)
- 20 Track display
- 21 Playing time display
- 22 Over mark indicator (▷)
- 23 Repeat indicator (◁▷)
- 24 Program indicator (PROGRAM)
- 25 Random indicator (RANDOM)
- 26 Music matrix
- 27 Mode select buttons (TAPE•TUNER/BAND•CD)
- 28 Super extra bass system control (S-XBS LEVEL)
- 29 Balance control (BALANCE)
- 30 Volume control and indicators (VOLUME)

TUNER CONTROLS




- 31 Tuning buttons (– TIME SET/TUNING +)
- 32 Preset tuning buttons (▼ PRESET TUNING ▲)
- 33 Tuning memory button (TUNING MEMORY)
- 34 FM mode/beat proof button (FM MODE/B.P)
- 35 Band indicator (FM/MW/LW)
- 36 Frequency display
- 37 Preset channel indicators
- 38 Program indicator (PROGRAM)
- 39 Tuning indicator (TUNED)
- 40 Stereo indicator (STEREO)
- 41 Monaural indicator (MONO)

DECK CONTROLS




- 42 Tape mode indicator (TAPE)
- 43 Tape counter
- 44 Running indicator
- 45 Deck 1/2 indicators (DECK 1 DECK 2)
- 46 Reverse mode indicator (◁↔▷)
- 47 Edit indicator (EDIT)
- 48 Automatic tape level setting indicator (ATLS)
- 49 Recording indicator (REC)
- 50 Tape direction indicator
- 51 Deck 1 cassette compartment cover
- 52 Reverse mode select button (REVERSE MODE)
- 53 Edit recording buttons (ONE TOUCH EDIT)
- 54 Counter reset button (COUNTER RESET)
- 55 Deck selector (DECK SELECTOR)
- 56 Deck 1 cassette eject button (≡ EJECT)
- 57 Fast/tape program sensor button (◁◁ TPS ▷▷)
- 58 Reverse side playback button (REV)
- 59 Stop button (STOP)
- 60 Forward side playback button (FWD)
- 61 Rec-pause button (● || REC PAUSE)
- 62 Deck 2 cassette eject button (≡ EJECT)
- 63 Deck 2 cassette compartment cover

•TIMER CONTROLS




- 64 Timer ON indicator (ON)
- 65 Timer play indicator (TIMER)
- 66 Timer recording indicator (TIMER-REC)
- 67 Timer OFF indicator (OFF)
- 68 Sleep timer indicator (SLEEP)
- 69 Timer ON time/Play mode indicator
- 70 Timer OFF time/Time display
- 71 Timer check button (TIMER CHECK)
- 72 Timer play button (PLAY-TIMER)
- 73 Timer recording button (TIMER-REC)
- 74 Sleep timer button (SLEEP)
- 75 Time adjust button (TIME ADJUST)
- 76 Time set buttons (- TIME SET/TUNING +)

•REAR PANEL SECTION



- 77 Speaker cable compartments
- 78 Speaker release levers (RELEASE)
- 79 Handle
- 80 CD output jacks (CD OUT)
- 81 Speaker terminals (SPEAKERS) (LOW: 2.7~8Ω, HIGH: 8~16Ω)
- 82 Telescopic antenna
- 83 Memory back-up battery compartment cover
- 84 FM antenna terminal (FM ANT)
- 85 DC input jack (DC IN 13.2 V)
- 86 AC socket (AC IN~)
- 87 Battery compartment cover
- 88 Speaker cables

•REMOTE CONTROL OPERATION




- 1 Display button (DISPLAY)
- 2 Random button (RANDOM)
- 3 Repeat button (REPEAT)
- 4 Numeric buttons (1-10/0, +10)
- 5 Cancel button (CANCEL)
- 6 Program button (PROGRAM)

Note:

Please refer to "Front Panel Controls and Functions" for the controls not described above.

Detaching the speakers

1. Unlock the speaker release levers by pulling them in the direction shown below, and slide up each speaker.




2. Connect the speaker cables to the speaker terminals.

Speaker system connection



This unit can be used as a one-piece portable stereo radio cassette recorder, or a three-piece component system, by attaching or detaching the speaker system. Before attaching or detaching the speakers, be sure to disconnect the speaker cables from the speaker terminals. Be sure to press the power switch to turn off the unit before connecting/disconnecting the speaker cables.

Attaching the speakers

1. Align the speaker with the main unit as shown in the figure, interlock the grooves and press down.




2. Connect the speaker cord end, marked by a colored, to the same colored terminal and then in turn to the appropriate speaker.



3. When using the unit with the speakers attached, wind the speaker cables as shown.

Since a strong magnet is used for the speaker, keep magnetized commuter passes, tickets or personal credit cards, recorded tapes, watches, etc. away from the set. The speaker magnet in the set may damage them.



When the tape is caught in the pinch roller, etc. Release the tape by turning the pulley on the motor with the screwdriver in the direction of the arrow.

HANDLING PRECAUTIONS FOR TRAVERSE DECK

The laser diode in the traverse deck (optical pickup) may break down due to potential difference caused by static electricity of clothes or human body.

So, be careful of electrostatic breakdown during repair of the traverse deck (optical pickup).

● Handling of traverse deck (optical pickup)



1. Do not subject the traverse deck (optical pickup) to static electricity as it is extremely sensitive to electrical shock.
2. To prevent the breakdown of the laser diode, an anti-static shorting pin is inserted into the flexible board (FPC board). When removing or connecting the short pin, finish the job in as short time as possible.
3. Take care not to apply excessive stress to the flexible board (FPC board).
4. Do not turn the variable resistor (laser power adjustment). It has already been adjusted.

● Grounding for electrostatic breakdown prevention

1. Human body grounding
Use the anti-static wrist strap to discharge the static electricity from your body.
2. Work table grounding
Put a conductive material (sheet) or steel sheet on the area where the traverse deck (optical pickup) is placed, and ground the sheet.


Caution:

The static electricity of your clothes will not be grounded through the wrist strap. So, take care not to let your clothes touch the traverse deck (optical pickup).




DISASSEMBLY INSTRUCTIONS

Ref. No. 1	Removal of the Front Cabinet
Procedure 1	[Removal of Screws] ● Use a screwdriver similar to the one in the figure.





● If you attach a bushing (part number: RHR109A) to the tip of the screwdriver as shown in the figure, the screwdriver tip will easily fit in the screw heads and you will be able to remove the screws with ease.





1. Remove the battery cover.
2. Remove the 8 screws (1~8).

3. Pull out the S-XBS knob and volume knob.
4. Remove the 1 screw (9).
5. Press the 2 cassette eject buttons and then open the cassette covers.
6. Press the CD eject button and then open the CD cover.
7. Release the claw in the direction of the arrow (1).
8. Remove the front cabinet in the direction of the arrow (2).




Ref. No.
2**Removal of the Mechanism
Operation P.C.B.**Procedure
1→2



1. Release the connector (CN353).
2. Remove the 3 screws (1~3).

Removal of the ConnectorRef. No.
3**Removal of the Mechanism Unit**Procedure
1→2→3


1. Remove the 6 screws (1~6).




2. Pull out the mechanism unit.
3. Release the 2 connectors (CP607, CP609).
4. Release the 4 connectors (CP601, CP602, J951, J971).
5. Remove the 2 solder points.
6. Remove the 1 screw (7).
7. Release the 3 bosses.
8. Release the 4 hooks.
9. Remove the mechanism control P.C.B.












10. Remove the 2 screws (8, 9).





Ref. No.
4**Removal of the Power Supply
P.C.B.**Procedure
1→2→3→4





1. Release the connector (CS901).
2. Remove the 2 screws (1, 2).
3. Remove the 2 plates.
4. Remove the 5 screws (3~7).
5. Release the claw in the direction of the arrow.
6. Pull out the power supply P.C.B.





Removal of the Connector





Ref. No. 5	Removal of the Battery P.C.B.
Procedure 1→2→3→5	 1. Release the claw in the direction of the arrow ①. 2. Remove the battery P.C.B. in the direction of the arrow ②. ●Pull out the battery P.C.B.
Ref. No. 6	Removal of the Battery Spring
Procedure 1→2→3→6	 1. Remove the screw (①). 2. Remove the P.C.B. 3. Release the claw and then remove the battery spring in the direction of the arrow.
Ref. No. 7	Removal of the Back-up Battery P.C.B.
Procedure 1→2→3→7	 ●Release the claw in the direction of arrow ① and then remove the back-up battery P.C.B. in the direction of arrow ②.
Ref. No. 8	Removal of the Upper Cabinet
Procedure 1→8	 1. Remove the 2 screws (①, ②). 2. Remove the 2 screws (③, ④). 3. Remove the upper cabinet.





Ref. No. 9	Removal of the G. Equalizer P.C.B.
Procedure 1→8→9	 1. Remove the connector (CN353). 2. Remove the 4 screws (①~④). 3. Remove the G. equalizer P.C.B. 4. Remove the connectors (CN351, CN352).
Ref. No. 10	Removal of the Traverse Unit
Procedure 1→8→10	 1. Remove the 4 screws (①~④). 2. Release the connector (CN803).
Ref. No. 11	Removal of the System Control P.C.B.
Procedure 1→2→3→8→9→11	 1. Remove the connector (CN803).
Ref. No. 12	Removal of the Tuner P.C.B.
Procedure 1→2→3→8→10→12	 1. Remove the 2 screws (①, ②). 2. Release the 2 connectors (CN1, CN2). 3. Remove the Tuner P.C.B. in the direction of arrow.
Ref. No. 13	Removal of the AF P.C.B.
Procedure 1→2→3→8→10→13	 1. Release the 3 connectors (CN2, CN301, CS901). 2. Remove the AF P.C.B. in the direction of the arrow.









Ref. No. 14	Removal of the Handle
Procedure 1→2→3→8→ 10→11→14	 1. Release 4 ribs in the direction of the arrow ①. 2. Remove the handle in the direction of the arrow ②.
Ref. No. 15	Removal of the Back-up Battery P.C.B.
Procedure 1→2→3→8→ 10→11→12→15	 1. Release the claw in the direction of the arrow ①. 2. Remove the back-up battery P.C.B. in the direction of the arrow ②.
Ref. No. 16	Removal of the Volume P.C.B.
Procedure 1→8→9→16	 1. Release the claw in the direction of arrow ①. 2. Remove the volume P.C.B. in the direction of the arrow ②.
Ref. No. 17	Removal of the Volume Chassis
Procedure 1→8→9→ 16→17	 1. Remove the spring. 2. Remove the 2 screws ①, ②. 3. Release the 3 claws in the direction of arrows ①. 4. Lift up the chassis. 5. Release the claw in the direction of arrow ②. 6. Remove the gear (A). 7. Remove the gear (B) in the direction of the arrow ③.

Ref. No. 18	Removal of the CD cover
Procedure 1→8→18	 •Release 2 ribs in the direction of the arrow.
Ref. No. 19	Removal of the CD Eject Button
Procedure 1→8→19	 1. Remove the screw ①. 2. Release 3 claws in the direction of arrow. 3. Remove the CD eject button.
Ref. No. 20	Removal of the Disc Clamper
Procedure 20	 1. Press the CD eject button and then open the CD cover. 2. Slide the disc clamper in the direction of the arrow ① and then remove the disc clamper in the direction of the arrow ②.
Ref. No. 21	Removal of the Cassette Holder
Procedure 1→21	 •Release 2 ribs in the direction of the arrow.


Ref. No. 22	Removal of the Cassette Panel and Eject Button (DECK 1)
Procedure 1→21→22	 - Release 2 claws in the direction of arrow ①. - Remove the panel in the direction of arrow ②.
Ref. No. 23	Removal of the Cassette Ornament (DECK 1)
Procedure 1→21→22→23	 - Release 6 claws in the direction of arrow ①. - Remove the ornament in the direction of arrow ②.
Ref. No. 24	Removal of the Cassette Panel and Eject Button (DECK 2)
Procedure 1→21→24	 - Release 2 claws in the direction of arrow ①. - Remove the panel in the direction of arrow ②.
Ref. No. 25	Removal of the Cassette Ornament (DECK 2)
Procedure 1→21→25	 - Release 6 claws in the direction of arrow ①. - Remove the ornament in the direction of arrow ②.

Ref. No. 26	Removal of the Deck Operation Button
Procedure 1→21→26	 - Cut the tip of boss. - Remove the button.
Ref. No. 27	Removal of the Operation Button
Procedure 1→27	 Pull out the operation button.
Ref. No. 28	Removal of the Time Set Button
Procedure 1→28	 - Release the claw in the direction of arrow. - Remove the time set button.
Ref. No. 29	Removal of the Volume LED Lens
Procedure 1→29	 - Release the claw in the direction of arrow. - Remove the volume LED lens.

Ref. No. 30	Removal of the Sensor Cover
Procedure 1→30	 1. Release the claw in the direction of arrow ①. 2. Remove the sensor cover in the direction of arrow ②.
Ref. No. 31	Removal of the Function Select Button
Procedure 1→31	 •Release the claw in the direction of arrow.
Ref. No. 32	Removal of the Graphic Equalizer Ornament
Procedure 1→32	 •Release 6 claws in the direction of arrow.
Ref. No. 33	Removal of the Eject Lever
Procedure 1→21→33	 •Release 2 claws in the direction of arrow.

●CD eject lever assembly		●CD cover assembly		●Cassette holder assembly			
							
●SPEAKER SECTION							
Ref. No. 34		Removal of the Front Cabinet					
Procedure 34							
1. Remove 6 screws (①~⑥).							
2. Remove the front cabinet in the direction of arrow.							
Ref. No. 35		Removal of the Tweeter Speaker		Ref. No. 36		Removal of the Woofer Speaker	
Procedure 34→35				Procedure 34→36			
●Remove 4 screws (①~④).				●Remove 4 screws (①~④).			
Ref. No. 37		Removal of the Bush					
Procedure 34→37							
		●Pull out the bush.					

■ SCHEMATIC DIAGRAM •VOLUME, GRAPHIC EQUALIZER, DECK OPERATION AND SYSTEM CONTROL CIRCUIT (Parts list on pages 63~70.)



SCHEMATIC DIAGRAM

TUNER AND CD CIRCUIT (Parts list on pages 63~70.)

CD Signal Line

FM Signal Line


FM OSC Signal Line

LW/MW OSC Signal Line

FM/LW/MW Vcap Control Signal Line

+B Line

A TUNER CIRCUIT



Notes:

(for Tuner circuit)

•VR1: FM VCO adjustment VR.

(for CD circuit)

•S701: Rest switch.

•S702: Laser ON/OFF switch.


•DC Voltage measurements are taken with electronics voltmeter.

The negative terminal of the battery provides negative meter connection point.


()...MW/LW < >...FM (())...CD

•This schematic diagram may be modified at any time with the development of new technology.


IC3 (LM7001)




B CD CIRCUIT


Free service manuals
Gratis schema's
Digitized by
www.freeservicemanuals.info

■ SCHEMATIC DIAGRAM




SCHEMATIC DIAGRAM • MAIN AND POWER SUPPLY CIRCUIT (Parts list on pages 63~70.)

A horizontal timeline with 14 numbered segments. Segment 10 is highlighted in light blue.



CIRCUIT BOARD DIAGRAM




TCA0372DM2R 	MN6475 	M51167AFP 	AN8800SCE2 	MN6650 	MN6626
MN1872410RRY 	BU4066B 	MN74HC00 	M50253P 	LM7001 	AN8377N
AN7273A 	LA4108R 	BA7755 	BA6418N 	RV1B1332L 	BA3822LS
BA3920 	AN7134N-R 	S8053HNB-T S81250HGT 	DN6851ALB 	BN1L3NTA 2SC2784FTA 2SC2785FTA 2SC2786M 2SD1450RTA	
2SA720STA 2SC3311AR 2SA1127-S 2SC829CTA 	2SA952K 2SB621R 2SC829D 2SC1684RTA 2SC1684HRTA 2SC1845FTA 2SC2001K1TA 2SD965Q 	2SC1740SQ 2SC1740STA RVTDT113ZST RVTDT114ES RVTDT114TST RVTDT124TST RVTDT143TST 	RVTDTA143XST RVTDT143XST RVTDTA144TST RVTDT144TST 	2SK301QTA 	
2SK544F-AC 	2SJ40CDTA 	2SB1185E 	2SB709S 	RVD1SS133TA 	RVDMTZ4R7BTA RVDMTZ5R6BTA RVDMTZ11BTA RVDMTZ6R8BTA RVDMTZ8R2BTA
1N5402BM21 	1SV147T4MATU 	RVDSVC321 	SLR33VC160 	MA110TW 	

WIRING CONNECTION DIAGRAM

NOTES:

BLKBlack
 BLUBlue
 BRNBrown
 GRYGray
 GRNGreen
 L.BLULight Blue
 ORGOrange
 PNKPink
 REDRed
 SLDShield Wire
 VLTViolet
 WHTWhite
 YELYellow




DIGITAL SERVO SYSTEM

The newly-developed digital servo system is adopted in the servo circuit of the unit's CD player instead of the ordinary analog servo system.


- The diagrams shown below represent differences between the analog servo and digital servo systems. The HEAD AMP. output signals (i.e., focus error and tracking error output signals) are analog. These analog signals are converted to the 8-bit digital signals through the MN6650. The MN6650 performs the following adjustments automatically; focus offset, tracking offset, focus gain, tracking gain, and tracking balance adjustments. The outputs from the MN6650 such as the focus coil driving signal, tracking coil driving signal, and traverse motor driving signal are converted to analog signals again and sent to the coils and motor to perform proper servo control for a disc.

ANALOG SERVO SYSTEM



DIGITAL SERVO SYSTEM


Only 1 VR requires adjustment (best eye adjustment)



- The servo processor IC MN6650 of the newly-developed digital servo circuit automatically performs the following adjustments which were originally adjusted in the conventional analog servo circuit:
(1) Focus offset, (2) Tracking offset, (3) Focus gain, (4) Tracking gain, and (5) Tracking balance. Therefore, you do not have to perform not the above-mentioned electrical adjustments manually. Only the best eye (PD balance) needs to be adjusted adjustment. You can obtain an optimum servo control for a disc to be played.
[You must perform the best eye (PD balance) adjustment manually.]

The following flow chart shows the sequence of automatic adjustments.

Flow chart on automatic adjustment sequence



■ CHECKING THE OPERATION PROBLEMS ON THE TRAVERSE DECK (OPTICAL PICKUP)

Make sure to follow the procedures below to check the operation problems of the traverse deck (optical pickup) before replacing it. Replace the traverse deck only after the problem is identified.

(Procedure No.)	(Checking Points)	(Cause)	(Testing Procedure)
	Starting the reading operation (TOC).		
1.	Does the laser light up?	NO Faulty laser (Worn out)	Check if the output is minimum 0.5 Vp-p at the test point.
	YES		
2.	Is focus search executed? (Check if lens moves up and down.)	/NO Broken or shorted focus coil	Check if conductance on both ends of coil with the tester at about 30 ohms. (The lens will slightly move up and down during the checking.)
	YES		
	The turntable rotates.		
3.	Tracking ON.	NO Broken or shorted tracking coil	Check if conductance on both ends of coil with the tester at about 30 ohms. (The lens will slightly move to the right or left during the checking.)
	YES		
4.	RF signal output	NO Faulty PD (PHOTO DETECTOR)	Check if the output is minimum 0.5 Vp-p at the test point.
	RF signal output		
	Traverse deck (optical pickup) is normal.		
	Traverse deck (optical pickup) is faulty.		

- Check electrical circuit.
 - CD is not adjusted properly. Adjust CD again.
 - (1) Mechanical adjustment.
 - (2) Focus balance adjustment (PD balance)
- } Refer to pages 45~47
- Check for flaws on disc or if it is warped or not centered.

※Checking Operations of Replaced Traverse Deck (New Traverse Deck)

- a) Check the operations described below on the traverse deck after replacing it.

* Checking Skip Search

1. Play an ordinary musical program disc.
2. Press the skip button to check for normal skip search operation (in both the forward and reverse directions).

* Checking Manual Search

1. Play an ordinary musical program disc.
2. Press the manual search button to check for smooth manual search operations at either low or high speed (in both the forward and reverse directions).

* Checking Using Defect Disc.

1. Play the 0.7 mm black dot and the 0.7 mm wedge on the defect test disc (SZZP1054C) and verify that no sound skip or noise occurs.
2. Play the middle tracks of the uneven test disc (SZZP1056C) and verify that no sound skip or noise occurs.

- b) If the operations are normal, CD adjustment are not required when the traverse deck is replaced.

Note: CD adjustments are required in the cases below. (Mechanical adjustments are not necessary.)
(See pages 45~47.)

- If audio is not played back continuously or noises occur after step (a) is executed.
- If the adjustment VR (VR701) were rotated before the traverse deck was replaced.


Caution:

- It is very dangerous to look at or touch the laser beam. (Laser radiation is invisible.)
With the unit turned "on", laser radiation is emitted from the pickup lens.
Avoid exposure to the laser beam, especially when performing adjustments.


■ HOW TO CHECK THE P.C.B.

- How to check the Tape Deck P.C.B.


1. Remove the front cabinet by following the disassembly instructions in Ref. No. 1 in the Removal of the Front Cabinet. (See page 7.)




2. Remove 3 screws (1~3).
3. Remove the deck operation P.C.B. with the wire connected.
4. Remove 6 screws (4~9).




5. Remove the tape deck unit by pulling it to the front with the wires connected.



6. Remove one screw ⑩.
7. Remove 3 bosses.
8. Remove 4 claws by moving the P.C.B.




9. Turn the tape deck unit upside down.




10. Detach the mechanism and tape deck P.C.B. as shown in the figure.

●How to check the CD P.C.B.

1. Remove the upper cabinet by following the disassembly instructions in Ref. No. 8 in the Removal of the Upper Cabinet. (See page 9.)



2. Remove 4 screws (1~4).
3. Remove the CD unit.





4. Remove the disc clamber by following the disassembly instructions in Ref. No. 20 in the Removal of the Disc Clamber. (See page 12.)
5. Fix the test disc with the disc clamber.

●The optional extension cable kit composed of two 10-pin flat cable and a 8-pin flat cable should be used to perform check of the volume P.C.B., system control P.C.B., tuner P.C.B. and AF P.C.B.

Part number of the Extension Cable Kit: RFKZ0014


10-pin flat cable ×2

8-pin flat cable ×1




●How to check the Volume P.C.B.

1. Remove the upper cabinet by following the disassembly instructions in Ref. No. 8 in the Removal of the Upper Cabinet. (See page 9.)




2. Remove 4 screws (1~4).
3. Remove the graphic equalizer P.C.B.
4. Release 2 connectors (CN351, CN352).




5. Connect two 10-pin flat cable of the extension cable.

●How to check the System Control P.C.B.


1. Remove the graphic equalizer P.C.B. by following the disassembly instructions in Ref. No. 9 in the Removal of the G. Equalizer P.C.B. (See page 10.)




2. Release the connector (CN803).



3. Release 2 connectors (CN2, CN802).
4. Remove the system control P.C.B. in the direction of arrow.




5. Remove 4 solder points.
6. Remove the shield plate.




7. Connect two 10-pin flat cables of the extension cable.

●How to check the Tuner P.C.B.

1. Remove the tuner P.C.B. by following the disassembly instructions in Ref. No. 12 in the Removal of the Tuner P.C.B. (See page 12.)




2. Connect 2 connectors (CN1, CN2).
3. Connect two 10-pin flat cables of the extension cable.



4. Attach the tuner P.C.B. as shown in the figure.


●How to check the AF P.C.B.

1. Remove the upper cabinet by following the disassembly instructions in Ref. No. 8 in the Removal of the Upper Cabinet. (See page 9.)





10. Pull out the AF P.C.B.


2. Remove 3 screws (1~3).
3. Remove the deck operation P.C.B. with the wires connect.
4. Remove 6 screws (4~9).
5. Remove the mechanism unit by pulling it to the front with the wires connect.
6. Remove 4 screws (10~13).
7. Remove the graphic equalizer P.C.B.
8. Release 2 connectors (CN351, CN352).



9. Release 3 connectors (CN2, CN301, CS901).



11. Connect 3 connectors (CN2, CN301, CS901).



12. Connect two 10-pin flat cables of the extension cable.


MEASUREMENTS AND ADJUSTMENTS

<CD SECTION>

■ The optional extension cable kit composed of a 23-pin flat cable and a 2-pin connector should be used to perform measurement and adjustment of the unit's CD P.C.B.

Part number of the Extension Cable Kit: RFKZ0009

2-pin connector ×1




23-pin flat cable ×1



Not use

●HOW TO ADJUST THE CD P.C.B.

1. Attach the CD unit and load the test disc by following the steps in the section "How to check the CD P.C.B." (See page 43).




Notes:
BLU...BLUE
ORG...ORANGE

2. Connect the 2-pin connector of the extension cable kit (RFKZ0009) to CP701 as shown in the figure.

3. Connect the 2-pin connector's orange and blue wires respectively to an oscilloscope as shown in the figure.

●HOW TO ADJUST THE CD P.C.B. IF THE EXTENSION CABLE KIT IS NOT AVAILABLE



1. Solder the lead wire to the connector (CP701) as shown in the figure.

2. Attach the CD unit and load the test disc by following the steps in the section "How to check the CD P.C.B.".

●ALIGNMENT INSTRUCTION

READ CAREFULLY BEFORE ATTEMPTING ALIGNMENT

- Set power source voltage to 15 V DC.
- Set power switch to ON.
- Set function switch to CD.
- Set graphic equalizer control to center.
- Set S-XBS control to minimum.
- Output of signal generator should be no higher than necessary to obtain an output reading.

Caution:

- It is very dangerous to look at or touch the laser beam. (Laser radiation is invisible.) With the unit turned "on", laser radiation is emitted from the pickup lens. Avoid exposure to the laser beam, especially when performing adjustments.

Measuring Instruments and Special Tools

●Test disc

1. Playability test disc (SZZP1054C)
2. Uneven test disc (SZZP1056C)

- Allen wrench (M2.0) (SZZP1101C)
- Oscilloscope
- Lock paint (RZZOL01)

(1) MECHANICAL ADJUSTMENT


- When the traverse deck is replaced, making adjustments is not necessary. (The traverse deck ass'y is already adjusted.)
- Make adjustments to improve playability when the traverse deck has not been replaced. Make the electrical adjustments first.

1. Connect the oscilloscope's CH. 1 probe across **TP702** (+) and **TP703** (V-REF) on the Servo P.C.B.

Oscilloscope setting:
VOLT 200 mV
SWEEP 0.5 μ sec
Input coupling AC

2. Switch the player power **ON**, and play track **19** on the test disc (SZZP1056C).
3. Leave the player in Play mode and place it as shown in the figure on the right.

4. Alternately adjust the two mechanical adjusting screws with the 2.0 mm allen wrench (SZZP1101C) until the RF signal amplitude variation on the oscilloscope is minimized. (Shown in Fig. 2)
5. After completing the adjustment, lock the **mechanical adjustments** with lock paint (RZZOL01).




(A) Minimize the variation of amplitude.

(2) BEST EYE (PD BALANCE) ADJUSTMENT

1. Connect the oscilloscope's CH. 1 probe across **TP702** (+) and **TP703** (V-REF) on the Servo P.C.B.

Oscilloscope setting:
VOLT 200 mV
SWEEP 0.5 μ sec
Input coupling AC

2. Switch the player power **ON**, and play the 1 kHz (track 1) on test disc (SZZP1054C).
3. Adjust **VR701** until the RF signal eye pattern amplitude is maximized.



(B) Maximize the amplitude

(3) CHECK OF PLAY OPERATION AFTER ADJUSTMENT

*Checking Skip Search

1. Play an ordinary musical program disc.
2. Press the skip button to check for normal skip search operation (in both the forward and reverse directions).

*Checking Manual Search

1. Play an ordinary musical program disc.
2. Press the manual search button to check for smooth manual search operations at either low or high speed (in both the forward and reverse directions).

*Checking Playability

1. Play the 0.7 mm black dot and the 0.7 mm wedge on the test disc (SZZP1054C) and verify that no sound skip or noise occurs.
2. Play the middle tracks of the uneven test disc and verify that no sound skip or noise occurs.

■ ALIGNMENT POINT

- Please refer to Circuit Board Diagram for test point location




Fig. 1

Mechanical adjustment screw




Fig. 2

<TUNER SECTION>

●ALIGNMENT INSTRUCTION

Attach the tuner P.C.B. by following the steps in the section "How to check the Tuner P.C.B.".

READ CAREFULLY BEFORE ATTEMPTING ALIGNMENT

- Set power source voltage to 15 V DC.
- Set power switch to ON.
- Set function switch to TUNER-AM or FM.
- Set volume control to center.
- Set balance control to center.
- Set graphic equalizer control to center.
- Set S-XBS control to minimum.
- Output of signal generator should be no higher than necessary to obtain an output reading.

●AM-IF ALIGNMENT

SIGNAL GENERATOR or SWEEP GENERATOR		RADIO DIAL SETTING	INDICATOR (ELECTRONIC VOLTMETER or OSCILLOSCOPE)	ADJUSTMENT (Shown in Fig. 3)	REMARKS
CONNECTIONS	FREQUENCY				
Fashion a loop of several turns of wire and radiate a signal into the loop ant. of receiver.	459 kHz 30% Mod. at 400 Hz	Point of non-interference. (on/about 600 kHz)	Headphones Jack (32 Ω) (Fabricate the plug as shown in Fig. 4 and then connect the lead wires of the plug to the measuring instrument.)	T2 (AM IFT)	Adjust for maximum output.

●LW-RF ALIGNMENT

Fashion a loop of several turns of wire and radiate a signal into the loop ant. of receiver.	144 kHz	Tuning capacitor fully closed.	"	L10 (LW OSC Coil)	Adjust for maximum output.
"	162 kHz	Tune to signal	"	(*1) L7-1 (LW ANT Coil)	Adjust for maximum output. Adjust L7-1 by moving coil along the ferrite core.
"	270 kHz	"	"	CT4 (LW ANT Trimmer)	Adjust for maximum output.

(*1) Fix antenna coil with wax after completing alignment.

●MW-RF ALIGNMENT

"	522 kHz	Tuning capacitor fully closed.	"	L9 (MW OSC Coil)	Adjust for maximum output.
"	603 kHz	Tune to signal.	"	(*2) L7-2 (MW ANT Coil)	Adjust for maximum output. Adjust L7-2 by moving the ferrite core.
"	1404 kHz	"	"	CT3 (MW ANT Trimmer)	Adjust for maximum output.

(*2) Cement antenna ferrite core with wax after completing alignment.

●FM-IF ALIGNMENT

SIGNAL GENERATOR or SWEEP GENERATOR		RADIO DIAL SETTING	INDICATOR (ELECTRONIC VOLTMETER or OSCILLOSCOPE)	ADJUSTMENT (Shown in Fig. 3.)	REMARKS
CONNECTIONS	FREQUENCY				
Connect to test point TP2 through ceramic capacitor (0.001 μ F). Negative side to test point TP2 .	10.7 MHz (SWEEP)	Point of interference (on/ about 90 MHz)	Connect vert. amp. scope to test point TP3 . Negative side to test point TP4 .	T1 (FM 1st)	Adjust for maximum amplitude.
"	"	"	"	T3 (FM 2nd)	Adjust for maximum amplitude.

●FM DC BALANCE ALIGNMENT

FM SIGNAL GENERATOR SOURCE CONNECTION	EQUIPMENT CONNECTION ELECTRONIC COUNTER	ADJUSTMENT (Shown in Fig. 3)	SPECIFICATION	REMARKS
98 MHz, 60 dB (CW) Connect to test point TP1 through FM dummy antenna. Negative side to TP2 .	TP9 ...(+) TP10 ...(-)	T3	0 $\pm$ 30 mV	Adjust T3, for 0 $\pm$ 30 mV reading on DC voltmeter.

●FM SEPARATION ALIGNMENT

FM SIGNAL GENERATOR SOURCE CONNECTION	EQUIPMENT CONNECTION ELECTRONIC COUNTER	ADJUSTMENT	SPECIFICATION	REMARKS
98 MHz, 60 dB (CW) Connect to test point TP1 through FM dummy antenna. Negative side to TP2 .	TP5 ...(+) TP6 ...(-)	VR1	19 kHz	Adjust VR1, for 19 kHz $\pm$ 50 Hz reading on frequency counter.

The parts other than the ones listed below are aligned at the factory before they are supplied. Therefore, alignment of those parts is unnecessary when used for replacement.

<CASSETTE DECK SECTION>

●ALIGNMENT INSTRUCTION

Attach the tape deck unit by following the step in the section "How to check the Tape Deck" in the step 5.

READ CAREFULLY BEFORE ATTEMPTING ALIGNMENT

- Set power source voltage to 15 V DC.
- Set power switch to ON.
- Set function switch to TAPE.
- Set volume control to center.
- Set tone graphic equalizer to center.
- Set S-XBS control to minimum.
- Output of signal generator should be no higher than necessary to obtain an output reading.

●HEAD AZIMUTH ALIGNMENT

TEST TAPE	INDICATOR ELECTRONIC VOLTMETER or OSCILLOSCOPE	ADJUSTMENT	SPECIFICATION	REMARKS
QZZCFM (8 kHz, -20 dB)	Headphones Jack (32 Ω) (Fabricate the plug shown in Fig. 4 and then connect the lead wires of the plug to the measuring instrument.)	Azimuth Screw (Shown in Fig. 5.)	maximum output.	1. Playback mode. 2. Adjust for maximum output.

●TAPE SPEED ALIGNMENT

TEST TAPE	INDICATOR ELECTRONIC VOLTMETER or OSCILLOSCOPE	ADJUSTMENT	REMARKS
QZZCWAT (3 kHz, -10 dB)	Headphones Jack (32 Ω) (Fabricate the plug shown in Fig. 4 and then connect the lead wires of the plug to the measuring instrument.)	DECK 2 HIGH SPEED VR301 DECK 1 NORMAL SPEED VR303 DECK 2 NORMAL SPEED VR302 (Shown in Fig. 7.)	1. Short the test point TP1 and TP2 , TP2 and TP3 to set the high speed mode. 2. Insert test tape (QZZCWAT) in DECK 1 and start playback in forward direction. ●This frequency is defined as F. 3. Insert test tape (QZZCWAT) in DECK 2 and start playback in forward direction. 4. Adjust VR301 until the frequency is set to F$\pm$40 Hz . 5. Open the test point TP1 and TP2 , TP2 and TP3 to set the normal speed mode. 6. Insert test tape (QZZCWAT) in DECK 1 and start playback in forward direction. 7. Adjust VR303 until the frequency is set to 3000$\pm$40 Hz . 8. Insert test tape (QZZCWAT) in DECK 2 and start playback in forward direction. 9. Adjust VR302 until the frequency is set to 3000$\pm$40 Hz .

●RECORD BIAS CHECK

TEST TAPE	INDICATOR ELECTRONIC VOLTMETER or OSCILLOSCOPE	ADJUSTMENT	SPECIFICATION	REMARKS
Use CrO ₂ tape and Normal tape	TP6 ...(+) TP4 ...(-) (Shown in Fig. 6.)	—	CrO ₂ ...18.5 $\pm$ 1 mV Normal...13 $\pm$ 1 mV	●Record mode

●ALIGNMENT POINT

●Please refer to Circuit Board and Wiring Connection Diagram for test point locations.




Fig. 3




Fig. 5

Keep these cords short. (Line capacitance: 3 pF of less)

- In order not to influence the bias oscillation, divide the voltage with 1 M Ω and 1 k Ω resistors, and measure the voltage across the 1 k Ω resistor.

Fig. 6




Fig. 4




Fig. 7

■FUNCTION OF IC TERMINALS

●IC701 (AN8800SC-E2)

Pin No.	Mark	I/O Division	Function
1	LDG	I	+5 V input
2	LDP	—	—
3	LD	O	Laser power control output
4	LPD	I	Laser power monitor input
5	GND	—	Ground terminal
6	LDON	I	Laser power control input
7	AMPI	I	RF signal input
8	AMPO	O	RF signal output
9	RFIN	I	RF signal input
10	RFEQ	—	Ground
11	C.AGC	I	AGC detecting capacitor input
12	ARF	O	RF signal output
13	C.SBDO	I	Dropout detecting capacitor input
14	RFDET	O	RF detections signal output
15	BDO	O	Black dropout detection output
16	VCC	I	Power supply (+5 V input)
17	SDO	O	System dropout detection output
18	VAD+	O	A/D converter reference voltage output
19	VREF	O	Reference voltage output
20	VAD-	O	A/D converter reference voltage output
21	OFTR	O	Off track detection output

●IC702 (TCA0372DM2R)

Pin No.	Mark	I/O Division	Function
1	GND	—	Ground
2	NC	—	—
3	VOU1	O	Spindle motor control output
4	VCC	I	Power supply (+7.5 V input)
5	VOU2	O	Spindle motor control output
6	NC	—	—
7	NC	—	—
8	GND	—	Ground

Pin No.	Mark	I/O Division	Function
22	PLAY	I	Play signal input
23	WVEL	I	High speed signal input
24	TES	I	Tracking error signal input
25	PTO	—	—
26	PTI	I	Traverse speed detection signal input
27	PBO	—	—
28	POT	I	Position detecting buffer input
29	CROSS	O	Tracking error cross detection output
30	TE	O	Tracking error output
31	TEBAL	I	Tracking error gain detecting filter input
32	TBAL	I	Tracking balance adjustment
33	VDET	O	Vibration detection signal output
34	FE	O	Focus error output
35	EBL2	I	Focus balance adjustment
36	FBL1		
37	VCC	I	Power supply (+5 V input)
38	GND	—	Ground
39	PDBD	I	Photo detector current input
40	PDA	I	
41	PDAD	I	
42	PDB	I	

Pin No.	Mark	I/O Division	Function
9	GND	—	Ground
10	NC	—	—
11	-VIN2	I	Spindle motor control input
12	+VIN2		
13	+VIN1		
14	-VIN1	—	—
15	NC		
16	GND	—	Ground

●IC703 (AN8377N): Motor Drive

Pin No.	Mark	I/O Division	Function
1	PVCC	I	Driver power supply (+8.9 input)
2	VCC	I	Power supply (+8.9 V input)
3	TB	O	External transistor base driving output
4	VMON	O	Voltage output
5	TVDI	I	Traverse error signal input
6	FDI	I	Focus error signal input
7	TDI	I	Tracking error signal input
8	VREF	I	Reference voltage input

●IC706 (MN6626)

Pin No.	Mark	I/O Division	Function
1	AVSS	—	Ground
2	IREF	I	Reference current input
3	ARF	I	RF signal input
4	DRF	I	DSL bias input
5	DSL F	O	DSL loop filter
6	PLL F	I	PLL loop filter
7	AVDD	I	Power supply (+5 V input)
8	RSEL	I	+5 V input
9 16	TBUS7 TBUSO	—	Test terminal (Ground)
17	FLAG	—	—
18	IPFLAG		
19	FCLK		
20	BTYCK		
21	WDCK		
22	/RST	I	Reset signal input
23	TX	O	Digital audio interface signal output
24	LDG	—	—
25	RDG		
26	SRDATA	O	Serial data output
27	SCK	O	Serial bit clock output
28	LRCK	O	Clock output
29	XCK	O	Clock output (f=16.9344 MHz)
30	PMCK	—	—
31	CSEL	I	+5 V input
32	PSEL	—	Ground
33	×1	I	Clock input (f=16.9344 MHz)
34	×2	—	—
35	VSS	—	Ground

Pin No.	Mark	I/O Division	Function
9	TD—	O	Inverting output of tracking driver
10	TD+	O	Non-inverting output of tracking driver
11	FD—	O	Inverting output of focus driver
12	FD+	O	Non-inverting output of focus driver
13	TVD—	O	Inverting output of traverse driver
14	TVD+	O	Non-inverting output of traverse driver
15	RESET	O	Reset signal output
16	PC	I	PC input (connect to GND)

Pin No.	Mark	I/O Division	Function
36	SUBQ	O	Sub-code (Q data) output
37	SQCK	I	Sub-code (Q data) clock input f=7.3 kHz
38	/CLDCK	—	—
39	BLKCK	O	Sub-code block (Q data) clock f=75 Hz
40	DEMPH	O	De-emphasis ON signal output
41	MEMPH	I	Emphasis signal input
42	MLD	I	Command load signal input
43	MCLK	I	Command clock signal input
44	MDATA	I	Command data input
45	DMUTE	I	Muting control signal input
46	SMCK	O	Clock output (f=4.2336 MHz)
47	STAT	O	Status signal output
48	CRC	—	—
49	SUBC	—	—
50	SBCK	I	Clock for sub-code serial output
51	/TRON	I	Tracking servo ON signal input
52	CLVS	O	Spindle servo signal output
53	PC	—	—
54	ECM	O	Spindle motor control signal output
55	ECS	O	Spindle motor control signal output
56	VDD	I	Power supply (+5 V input)
57	/TEST	I	+5 V input
58	SSEL	I	+5 V input
59	MSEL	—	—
60	RESY	—	—
61	DO	I	Drop out signal input
62	EFM	—	—
63	PCK		
64	PDO		

●IC704 (MN6650)

Pin No.	Mark	I/O Division	Function
1	TES	O	Tracking error signal output
2	PLAY	O	Play signal output
3	RFDET	I	RF detection signal input
4	DO	I	Dropout signal input
5	OFT	I	Off track signal input
6	ARF	I	RF signal input
7	WVEL	O	High speed status signal output
8	PBO	I	Potension buffer signal input
9	TE	I	Tracking error signal input
10	FE	I	Focus error signal input
11	VR2	I	A/D reference voltage input
12	VR1	I	A/D reference voltage input
13	LDON	O	Laser power control signal output
14	VSS	—	Ground
15	AVSS	—	Ground
16	AVDD	I	Power supply (+5 V input)
17	VDD	I	Power supply (+5 V input)
18	TRV	O	Traverse servo control output
19	VTD	O	Traverse drive output
20	FOD	O	Focus drive output
21	TRD	O	Tracking drive output
22	KICK	O	Track kick signal output

Pin No.	Mark	I/O Division	Function
23	/TEST	I	+5 V input
24	VSS	—	Ground
25	CLVS	I	Spindle servo signal input
26	/TRON	O	Tracking servo signal output
27	MDATA	I	Command data input
28	MCLK	I	Command clock signal input
29	MLD	I	Command load signal input
30	SENSE	O	Sense signal output
31	/FLOCK	O	Focus servo signal output
32	/TLOCK	I	Tracking servo signal output
33	/RST	I	Reset signal input (L: Reset)
34	XI	I	Clock input (fXI=16.9344 MHz)
35	TO	—	Open
36	T1		
37	T2		
38	T3	—	Ground
39	T4		
40	T5		
41	T6	I	Vibration detecting signal input
42	VDET		
43	TBAL		
44	TRCRS	I	Track cross signal input

●IC705 (MN6475)

Pin No.	Mark	I/O Division	Function
1	LRCK	I	Clock input
2	BCLK	I	Serial data bit clock input
3	SRDATA	I	Serial data input
4	COT1	—	Ground
5	COT2		
6	TEST		
7	VDD	I	Power supply (+5 V input)
8	X2	—	Clock (f=33.8688 MHz)
9	X1		
10	VSS	—	Ground
11	AVDDL	I	Power supply (+5 V input)
12	OUT.L	O	AF signal output (Lch)


Pin No.	Mark	I/O Division	Function
13	AVSS.L	—	Ground
14	AVSS.R	—	Ground
15	OUT.R	O	AF signal output (Rch)
16	AVDD.R	I	Power supply input
17	/RST	I	Reset signal input
18	PWM	—	—
19	TP	—	Ground
20	WVEL	I	High speed status signal input
21	DEMPH	I	De-emphasis signal input
22	CSEL	I	+5 V input
23	192FS	—	—
24	768FS	O	Clock output (f=16.9344 MHz)

●IC601 (MN1872410RRM)


Pin No.	Mark	Function
1	VDD	Power supply (+5 V input)
2	OSC1	Clock output (4 MHz)
3	OSC2	Clock input (4 MHz)
4	VSS	GND
5	XI	Clock input (32 kHz)
6	XO	Clock output (32 kHz)
7	VREF-	A/D converter reference voltage (GND)
8	ADIN7	DECK 2 front side record prevention tab detection. "HIGH"...Recording is not possible "LOW"...Recording is possible
9	ADIN6	DECK 2 cassette tape insertion detection. "HIGH"...Playback is not possible "LOW"...Playback is possible
10	ADIN5	DECK1 cassette tape insertion detection. "HIGH"...Playback is not possible "LOW"...Playback is possible
11	ADIN4	Power supply circuit operation detection.
12	ADIN3	—
13	ADIN2	Operation signal input
14	ADIN1	
15	ADIN0	
16	VREF+	A/D converter reference voltage (+5 V)
17	BP3	—
18	MKCLK	Deck control data output
19	BEEP	Beep signal output
20	MKDAT	Deck control data output
21	PLL CE	PLL tuner strove signal output
22	PLL DI	PLL tuner data signal output
23	PLL CL	PLL tuner clock signal output
24	M/ST	Tuner stereo/mono select signal output
25	STEREO	Tuner stereo signal input
26	TUNED	Tuning signal input
27	ATT6	ATLS control signal output
28	CD SLOSE	CD cover open/close detection signal input
29	MUTE A	AF muting signal output
30	POWER CONT	Power AMP control signal output
31	REMOCON IN	Remote control signal input
32	BLKCK	CD sub code block clock signal input
33	MCD OUT	CD line out control
34	RESET	CD reset signal input

Pin No.	Mark	Function
35	RST	System control reset signal input
36	VOL UP	Motor (for Volume) control signal output
37	VOL DOWN	Motor (for Volume) control signal output
38	MCLK	CD signal process IC control signal output
39	SQCD	CD sub-code clock input
40	SUBQ	CD sub-code data input
41	SBOO	—
42	SYNC	—
43	CM	—
44	P77	—
45	9K/10K	AM tuning step select terminal
46	RESET SW	Reset switch (S701) signal input
47	P74	—
48	STAT	CD status signal input
49	TLOCK	CD tracking signal input
50	FLOCK	CD focus lock signal input
51	SENSE	CD sense signal input
52	MDATA	CD signal process IC data output
53	MLD	CD signal process strove signal input
54	DMUTE	CD muting signal output
56	ATT3	ATLS control signal output
57	TAPE H	Input selector control signal output (TAPE)
58	CD H	Input selector control signal output (CD)
59	TUNER H	Input selector control signal output (TUNER)
60	DES 1	—
61	DES 2	—
62	—	—
63	REMOCON STBY	Remote control sensor power control
64	—	—
65	—	—
66	SEG 27	LCD segment signal output
94	SEG 0	
95	COM 2	LCD common signal output
97	COM 0	
98	VLC3	LCD bias reference voltage input V3
99	VLC2	LCD bias reference voltage input V2
100	VLC1	LCD bias reference voltage input V1


■ TROUBLESHOOTING GUIDE



■ BLOCK DIAGRAM • CD CIRCUIT



BLOCK DIAGRAM



Free service manuals
Circuit diagrams
Digitized by
www.freeservicemanuals.info

■ REPLACEMENT PARTS LIST

Notes :

- Important safety notice:
Components identified by  mark have special characteristics important for safety. When replacing any of these components use only manufacturer's specified parts.
- The parenthesized indications in the Remarks column specify the areas. (Refer to the cover page for area.)
Parts without these indications can be used for all areas.
-  Indicates in Remarks column parts that are supplied by MESA.

Ref. No.	Part No.	Part Name & Description	Remarks	Ref. No.	Part No.	Part Name & Description	Remarks
		INTEGRATED CIRCUIT(S)		Q18, 19	2SC2784FTA	TRANSISTOR	
				Q101	2SC1684RTA	TRANSISTOR	
				Q102	RVTDT C114ES	TRANSISTOR	
IC1	AN7273A	I. C, FM/AM IF		Q103	2SC1684HRTA	TRANSISTOR	
IC2	RV1BA1332L	I. C, FM MPX		Q104, 105	2SC2001K1TA	TRANSISTOR	
IC3	LM7001	I. C, PLL FREQ		Q151, 152	2SC1684HRTA	TRANSISTOR	
IC301, 302	BU4066B	I. C, INPUT SELECTOR		Q201	2SC1684RTA	TRANSISTOR	
IC303	AN7134N-R	I. C, POWER AMP	(WOOFER DRIVE)	Q202	RVTDT C114ES	TRANSISTOR	
IC304	LA4108R	I. C, POWER AMP	(TWEETER DRIVE)	Q203	2SC1684HRTA	TRANSISTOR	
IC305	BA3920	I. C, POWER SUPPLY CONT.		Q204, 205	2SC2001K1TA	TRANSISTOR	
IC306	S81250HGT	I. C, REGULATOR		Q251, 252	2SC1684HRTA	TRANSISTOR	
IC351	BA3822LS	I. C, G. EQ AMP		Q301	2SC1684HRTA	TRANSISTOR	
IC352	MN74HC00	I. C, LED DRIVE		Q302	RVTDTA144TST	TRANSISTOR	
IC353	BA6418N	I. C, MOTOR DRIVE		Q303, 304	2SC1684RTA	TRANSISTOR	
IC601	M51167AFP	I. C, HEAD SELECT		Q305	2SB1185E	TRANSISTOR	
IC602	BA7755	I. C, R/P SELECT		Q306, 307	2SC1684RTA	TRANSISTOR	
IC605	M50253P	I. C, SYSTEM CONTROL		Q351	RVTDT C114ES	TRANSISTOR	
IC701	AN8800SCE2	I. C, SERVO AMP		Q401, 402	2SJ40CDA	TRANSISTOR	
IC702	TCA0372DM2R	I. C, SPINDLE MOTOR DRIVE		Q403, 404	RVTDT C144TST	TRANSISTOR	
IC703	AN8377N	I. C, TRAVERSE MOTOR DRIVE		Q408	2SJ40CDA	TRANSISTOR	
IC704	MN6650	I. C, DIGITAL SERVO PROCESSOR		Q411	RVTDT C144TST	TRANSISTOR	
IC705	MN6475	I. C, DIGITAL FILTER		Q501, 502	2SJ40CDA	TRANSISTOR	
IC706	MN6626	I. C, D. SIGNAL PROCESSOR		Q503, 504	RVTDT C144TST	TRANSISTOR	
IC801	MN1872410RRY	I. C, SYSTEM CONT.		Q508	2SJ40CDA	TRANSISTOR	
IC802	S8053HNB-T	I. C, RESET SIGNAL		Q511	RVTDT C144TST	TRANSISTOR	
IC951, 971	DN6851ALB	I. C, HALL		Q601, 602	2SC3311AR	TRANSISTOR	
		IC PROTECTOR		Q603	2SD1450RTA	TRANSISTOR	
				Q605	RVTDT C124TST	TRANSISTOR	
ICP1	RAHICPN15TA	IC PROTECTOR		Q606	2SC1740STA	TRANSISTOR	
ICP2	RAHICPN10TA	IC PROTECTOR		Q607, 608	2SD1450RTA	TRANSISTOR	
ICP3, 4	RAHICPN5TA	IC PROTECTOR		Q609	2SD965Q	TRANSISTOR	
				Q610	2SK301QTA	TRANSISTOR	(M)
		TRANSISTOR(S)		Q611	2SD965Q	TRANSISTOR	
				Q612	RVTDT C144TST	TRANSISTOR	
Q1	2SK544F-AC	TRANSISTOR		Q613, 614	2SB621R	TRANSISTOR	
Q2, 3	2SC2786M	TRANSISTOR		Q615, 616	RVTDT C143TST	TRANSISTOR	
Q4	2SC1675L1L2	TRANSISTOR		Q617	RVTDT C144TST	TRANSISTOR	
Q5	2SC829D	TRANSISTOR		Q618	2SK301QTA	TRANSISTOR	(M)
Q6, 7	2SA720STA	TRANSISTOR		Q619-621	RVTDTA143XST	TRANSISTOR	
Q9	2SA720STA	TRANSISTOR		Q622	RVTDT C144TST	TRANSISTOR	
Q10	2SA720STA	TRANSISTOR		Q624-628	2SC1740STA	TRANSISTOR	
Q12	2SA1127-S	TRANSISTOR		Q629	RVTDT C114TST	TRANSISTOR	
Q13, 14	BN113NTA	TRANSISTOR	(M)	Q630, 631	2SC1740STA	TRANSISTOR	
Q15	2SC829CTA	TRANSISTOR		Q701	2SB709S	TRANSISTOR	
Q16	2SA1127-S	TRANSISTOR		Q802	2SC1740SQ	TRANSISTOR	
Q17	2SC2785F	TRANSISTOR		Q804	RVTDT C1132ST	TRANSISTOR	

Ref. No.	Part No.	Part Name & Description	Remarks	Ref. No.	Part No.	Part Name & Description	Remarks
Q805	RVDTA143XST	TRANSISTOR				COMPONENT COMBINATION (S)	
Q806	RVDTCT143XST	TRANSISTOR					
Q808	2SC2001K1TA	TRANSISTOR		Z601-603	EXBF6L306SVV	COMPONENT COMBINATION	
				Z801	RC0002	COMPONENT COMBINATION	
		DIODE (S)		Z802	RSL5041-L	LCD	(M)
						COIL (S)	
D1	1SV147T4MATU	DIODE		L1	RLQY30S4W-0	COIL	
D2	1SV147T4MATU	DIODE		L2	RLA4Y001-0	COIL	(M)
D3	1SV147T4MATU	DIODE		L3	RLA4Y002-0	COIL	(M)
D4, 5	RVD SVC321	DIODE		L4	RLQZP1R2KT-Y	COIL	
D7, 8	RVD SVC321	DIODE		L7	RLV6C004-0	COIL	(M)
D10, 11	RVD1SS133TA	DIODE		L9	RL02B126-M	COIL	(M)
D12	RVDMTZ7R6BTA	DIODE		L10	RL01B15-M	COIL	(M)
D15-18	RVD1SS133TA	DIODE		L15	RLQZP101KT-Y	COIL	
D301	RVDMTZ11BTA	DIODE		L16	RLQZP1R2KT-Y	COIL	
D302	RVD1SS133TA	DIODE		L17	RLQZP100KT-Y	COIL	
D303	RVDMTZ6R8BTA	DIODE		L20	RLQY30S1W-0	COIL	(E)
D304, 305	RVD1SS133TA	DIODE		L301	RLQZP220KT-Y	COIL	
D306	RVDMTZ11BTA	DIODE		L302	RL09B007-M	COIL	
D307	RVD1SS133TA	DIODE		L303, 304	RLQZP221KT-Y	COIL	
D310	RVDMTZ6R8BTA	DIODE		L305	RLQZB4R7KT-D	COIL	(M)
D352	LN11CP23	DIODE		L351	RLQZB101KT-D	COIL	
D353, 354	RVD1SS133TA	DIODE		L352, 353	RLQV472K-Z	COIL	
D355, 356	SLR33VC160	LED	(M)	L354	RLQZP101KT-Y	COIL	
D357	RVD1SS133TA	DIODE		L355	RLQZP221KT-Y	COIL	
D358	RVDMTZ8R2BTA	DIODE		L356	RLQZB102K-D	COIL	
D601	RVD1SS133TA	DIODE		L601	RL08C002-T	COIL	
D602	RVDMTZ4R7BTA	DIODE		L602	RLQZB470KT-D	COIL	
D603, 604	RVD1SS133TA	DIODE		L603	RLQZB4R7KT-D	COIL	(M)
D701	MA110TW	DIODE		L681, 682	RLQZP101KT-Y	COIL	
D802	RVD1SS133TA	DIODE		L801, 802	RLQZP2R2KT-Y	COIL	
D804, 805	RVD1SS133TA	DIODE		L803	RLQZB1R8KT-D	COIL	
D811	LN083493P	DIODE	(M)	L804-807	RLQZP2R2KT-Y	COIL	
D901-904	1N5402RM21	DIODE	(M)	L811-815	RLQZP2R2KT-Y	COIL	
D905	RVD1SS133TA	DIODE		L817, 818	RLQZP2R2KT-Y	COIL	
D951, 971	RVD1SS133TA	DIODE		L820	RLQZP2R2KT-Y	COIL	
		VARIABLE RESISTOR (S)		L821	RLQZP220KT-Y	COIL	
				L901, 902△	RLQZB220KT-D	COIL	
VR1	EVNDXA00B14	V. R. FM VCO ADJ.				TRANSFORMER (S)	
VR351	EWZ2UAF2054D	V. R. S-XBS LEVEL	(M)	T1	RL14B153-MB	TRANSFORMER	
VR352	EWAJQAW05G54	V. R. G. EQ (100Hz)	(M)	T2	RL12B153-M	TRANSFORMER	
VR353	EWAJQAW05G54	V. R. G. EQ (330Hz)	(M)	T3	SL14B524-Z	TRANSFORMER	
VR354	EWAJQAW05G54	V. R. G. EQ (1KHz)	(M)	T901 △	RTPI1M1B001-X	POWER TRANSFORMER	(M)
VR355	EWAJQAW05G54	V. R. G. EQ (3.3KHz)	(M)			FILTER (S)	
VR356	EWAJQAW05G54	V. R. G. EQ (10KHz)	(M)				
VR357	EWAJUAW09G15	V. R. BALANCE CONT.	(M)	CF1	RLFFETWNA01L	CERAMIC FILTER	
VR358	EWCO7A027B54	V. R. VOLUME CONT.		CF2	RVFSF2459HL3	CERAMIC FILTER	(M)
VR601	RVNCC14B1T-A	V. R. TAPE SPEED ADJ.	(HIGH)				
VR602	RVNCC24B1T-A	V. R. TAPE SPEED ADJ.	(NORMAL)				
VR603	RVNCC73B1T-A	V. R. TAPE SPEED ADJ.					
VR701	EVNDXA00B14	V. R. BEST EYE ADJ.					

Ref. No.	Part No.	Part Name & Description	Remarks	Ref. No.	Part No.	Part Name & Description	Remarks
		OSCILLATOR(S)		S901 Δ	RJ1J5E01-H	SW, AC/DC SELECT.	
				S951	RS1A89ZB-U	SW, MODE DETECT (1)	
				S952	RS1A90YB-U	SW, TAPE DETECT (1)	
X1	SVQ49U722T-D	OSCILLATOR	(M)	S953	RS1A90YB-U	SW, Cr-02 DETECT (1)	
X701	RSX233M8M01T	OSCILLATOR		S971	RS1A89ZB-U	SW, MODE DETECT (2)	
X801	RSXD32K7S02	OSCILLATOR	(M)	S972	RS1A90YB-U	SW, TAPE DETECT (2)	
X802	RVBCSA4R0MGT	OSCILLATOR		S973	RS1A90YB-U	SW, TAB DETECT (2)	(REV)
				S974	RS1A90YB-U	SW, TAB DETECT (2)	(FWD)
		FUSE (S)		S975	RS1A90YB-U	SW, Cr-02 DETECT (2)	
						CONNECTOR	
F901 Δ	XBA2C40TB0	FUSE		CN1	SJT3711	CONNECTOR	
				CN2	SJT3909	CONNECTOR	
		SWITCH(ES)		CN3	RJP2G182A	CONNECTOR	
S351	EVQ21405R	SW, OPERATION		CN301	RJS1A6821	CONNECTOR	(M)
S352	EVQ21405R	SW, TAPE		CN351, 352	RJT003K010M1	CONNECTOR (10P)	
S353	EVQ21405R	SW, TUNER		CN353	RJS3T5ZA	SOCKET	
S354	EVQ21405R	SW, CD		CN354-356	SJS50581B8	SOCKET (5P)	
S356	EVQ21405R	SW, TIME SET/TUN		CN801	RJU003K010M1	SOCKET (10P)	
S357	EVQ21405R	SW, TIMER-REC		CN802	RJS1A6821	CONNECTOR	(M)
S358	EVQ21405R	SW, SLEEP		CN803	RJS1A6823	CONNECTOR	(M)
S359	EVQ21405R	SW, PLAY-TIMER		CP1	RJP2G172A	PLUG	(E)
S360	EVQ21405R	SW, TIME SET/TUNING-		CP301	RJU003K010M1	SOCKET (10P)	
S361	EVQ21405R	SW, TIMER CHECK		CP351-353	SJT305498B1	CONNECTOR	
S362	EVQ21405R	SW, TIME ADJUST		CP601	RJP5G182A	CONNECTOR	
S363	EVQ21405R	SW, STOP		CP602	SJT4D13	CONNECTOR	
S364	EVQ21405R	SW, PAUSE		CP607	SJTD1013	CONNECTOR	
S365	EVQ21405R	SW, FM MODE/B. P.		CP609	RJP9G182A	CONNECTOR	
S366	EVQ21405R	SW, EDIT MODE		CP701, 702	RJP2G172A	PLUG	
S367	EVQ21405R	SW, SKIP/SEARCH		CP703	RJP4G172A	PLUG	
S368	EVQ21405R	SW, PRESET TUNING		CS701	RJU0357016-1	CONNECTOR	
S369	EVQ21405R	SW, TUNING MEMORY		CS702	RJS1A6723	CONNECTOR	
S370	EVQ21405R	SW, SKIP/SEARCH		CS901	SJT30444-H	CONNECTOR	
S371	EVQ21405R	SW, TAPE LENGTH				TRIMMER	
S372	EVQ21405R	SW, PRESET TUNING					
S373	EVQ21405R	SW, ATLS		CT3	RCV10AF1T-S	TRIMMER CAPACITOR	
S374	EVQ21405R	SW, SET		CT4	ECLRA030E53R	TRIMMER CAPACITOR	
S375	EVQ21405R	SW, PLAY				JACK(S)	
S681	EVQ21405R	SW, DECK STOP					
S682	EVQ21405R	SW, PLAY BACK (FWD)		JK1	RJJ92M02-H	EXT ANT	(E) (M)
S683	EVQ21405R	SW, FAST/TPS		JK301	RJJ1D252A-C	MIC	
S684	EVQ21405R	SW, DECK1/2		JK302	RJF10992A	CD OUT	
S685	EVQ21405R	SW, COUNTER RESET		JK303	RJF1098YA-H	SP	
S686	EVQ21405R	SW, PLAY BACK (FWD)		JK304	RJF1098YA-H	SP	
S687	EVQ21405R	SW, FAST/TPS		JK305	RJJ38T01-1H	HEADPHONES	
S688	EVQ21405R	SW, REVERSE MODE		JK901 Δ	RJJ1SE01-H	AC IN	
S689	EVQ21405R	SW, REC PAUSE		JK902 Δ	RJB3ZD-C	DC IN	
S690	EVQ21405R	SW, NORMAL					
S691	EVQ21405R	SW, HIGH					
S701	SSHDS-E	SW, REST					
S801	RS1A012-U	SW, OPEN/CLOSE					
S802	RS1A012-U	SW, LASER ON/OFF					

Notes : * Capacity value are in microfarads (μF) unless specified otherwise, P=Pico-farads (pF) F=Farads (F)
* Resistance values are in ohms, unless specified otherwise, 1K=1,000 (OHM), 1M=1,000k (OHM)

Ref. No.	Part No.	Values & Remarks	Ref. No.	Part No.	Values & Remarks	Ref. No.	Part No.	Values & Remarks
		RESISTORS	R61	ERDS2TJ222	1/4W 2.2K	R203	ERDS2TJ473	1/4W 47K
			R62	ERDS2TJ103	1/4W 10K	R204	ERDS2TJ223	1/4W 22K
			R63	ERDS2TJ102	1/4W 1K	R205	ERDS2TJ563	1/4W 56K
R1	ERDS2TJ470	1/4W 47	R68	ERDS2TJ391	1/4W 390	R206	ERDS2TJ393	1/4W 39K
R2	ERDS2TJ102	1/4W 1K	R69-71	ERDS2TJ103	1/4W 10K	R207	ERDS2TJ223	1/4W 22K
R3	ERDS2TJ104	1/4W 100K	R72	ERDS2TJ104	1/4W 100K	R208	ERDS2TJ183T	1/4W 18K
R4	ERDS2TJ104	1/4W 100K	R73	ERDS2TJ103	1/4W 10K	R209	ERDS2TJ123	1/4W 12K
R5	ERDS2TJ470	1/4W 47	R74-76	ERDS2TJ224T	1/4W 220K	R210	ERDS2TJ223	1/4W 22K
R7	ERDS2TJ222	1/4W 2.2K	R77	ERDS2TJ472	1/4W 4.7K	R211	ERDS2TJ472	1/4W 4.7K
R8	ERDS2TJ104	1/4W 100K	R78	ERDS2TJ103	1/4W 1K	R212	ERDS2TJ561	1/4W 560
R9	ERDS2TJ103	1/4W 10K	R81	ERDS2TJ102	1/4W 1K	R213	ERDS2TJ152	1/4W 1.5K
R10	ERDS2TJ563	1/4W 56K	R91	ERDS2TJ151	1/4W 150 (E)	R214	ERDS2TJ102	1/4W 1K
R11	ERDS2TJ471	1/4W 470	R92	ERDS2TJ101	1/4W 100 (E)	R215	ERDS2TJ223	1/4W 22K
R12	ERDS2TJ224T	1/4W 220K	R101	ERDS2TJ823T	1/4W 82K	R216	ERDS2TJ101	1/4W 100K
R13	ERDS2TJ471	1/4W 470	R102	ERDS2TJ153	1/4W 15K	R217	ERDS2TJ152	1/4W 1.5K
R14	ERDS2TJ473	1/4W 47K	R103	ERDS2TJ473	1/4W 47K	R218	ERDS2TJ2R7T	1/4W 2.7
R15	ERDS2TJ102	1/4W 1K	R104	ERDS2TJ223	1/4W 22K	R219	ERDS2TJ2R2T	1/4W 2.2
R16	ERDS2TJ101	1/4W 100	R105	ERDS2TJ563	1/4W 56K	R220	ERDS2TJ221	1/4W 220
R17	ERDS2TJ332	1/4W 3.3K	R106	ERDS2TJ393	1/4W 39K	R221	ERDS2TJ224T	1/4W 220K
R18	ERDS2TJ334	1/4W 330K	R107	ERDS2TJ223	1/4W 22K	R222	ERDS2TJ151	1/4W 150
R19-21	ERDS2TJ331	1/4W 330	R108	ERDS2TJ183T	1/4W 18K	R223	ERDS2TJ472	1/4W 4.7K
R22	ERDS2TJ103	1/4W 10K	R109	ERDS2TJ123	1/4W 12K	R251	ERDS2TJ105T	1/4W 1M
R23	ERDS2TJ151	1/4W 150	R110	ERDS2TJ223	1/4W 22K	R252, 253	ERDS2TJ472	1/4W 4.7K
R24	ERDS2TJ562	1/4W 5.6K	R111	ERDS2TJ472	1/4W 4.7K	R254	ERDS2TJ561	1/4W 560
R25	ERDS2TJ332	1/4W 3.3K	R112	ERDS2TJ561	1/4W 560	R256	ERDS2TJ682T	1/4W 6.8K
R26	ERDS2TJ102	1/4W 1K	R113	ERDS2TJ152	1/4W 1.5K	R257	ERDS2TJ471	1/4W 470
R27	ERDS2TJ104	1/4W 100K	R114	ERDS2TJ102	1/4W 1K	R258	ERDS2TJ222	1/4W 2.2K
R28	ERDS2TJ562	1/4W 5.6K	R115	ERDS2TJ223	1/4W 22K	R281	ERDS2TJ183T	1/4W 18K
R29	ERDS2TJ681	1/4W 680	R116	ERDS2TJ101	1/4W 100	R282	ERDS2TJ101	1/4W 100K
R30	ERDS2TJ683	1/4W 68K	R117	ERDS2TJ152	1/4W 1.5K	R283	ERDS2TJ474	1/4W 470K
R31	ERDS2TJ102	1/4W 1K	R118	ERDS2TJ2R7T	1/4W 2.7	R284	ERDS2TJ271	1/4W 270
R32	ERDS2TJ682T	1/4W 6.8K	R119	ERDS2TJ2R2T	1/4W 2.2	R285	ERDS2TJ681	1/4W 680
R33, 34	ERDS2TJ104	1/4W 100K	R120	ERDS2TJ221	1/4W 220	R301	ERDS2TJ334	1/4W 330K
R36, 37	ERDS2TJ103	1/4W 10K	R121	ERDS2TJ224T	1/4W 220K	R302	ERDS2TJ102	1/4W 1K
R39, 40	ERDS2TJ104	1/4W 100K	R122	ERDS2TJ151	1/4W 150	R303	ERDS2TJ180T	1/4W 180
R44	ERDS2TJ103	1/4W 10K	R123	ERDS2TJ472	1/4W 4.7K	R304	ERDS2TJ101	1/4W 100
R47	ERDS2TJ103	1/4W 10K	R151	ERDS2TJ105T	1/4W 1M	R305	ERDS2TJ332	1/4W 3.3K
R49	ERDS2EJ121	1/4W 120	R152, 153	ERDS2TJ472	1/4W 4.7K	R307	ERDS2TJ471	1/4W 470
R50	ERDS2TJ102	1/4W 1K	R154	ERDS2TJ561	1/4W 560	R308	ERDS2TJ472	1/4W 4.7K
R51	ERDS2TJ222	1/4W 2.2K	R156	ERDS2TJ682T	1/4W 6.8K	R309	ERDS2TJ104	1/4W 100K
R52	ERDS2TJ471	1/4W 470	R157	ERDS2TJ471	1/4W 470	R311	ERDS2TJ471	1/4W 470
R53	ERDS2TJ683	1/4W 68K	R158	ERDS2TJ222	1/4W 2.2K	R312	ERDS2TJ222	1/4W 2.2K
R54	ERDS2TJ153	1/4W 15K	R181	ERDS2TJ183T	1/4W 18K	R313	ERDS2TJ223	1/4W 22K
R55	ERDS2TJ561	1/4W 560	R182	ERDS2TJ101	1/4W 100	R314	ERDS2TJ102	1/4W 1K
R56	ERDS2TJ222	1/4W 2.2K	R183	ERDS2TJ474	1/4W 470K	R315	ERDS2TJ223	1/4W 22K
R57	ERDS2TJ472	1/4W 4.7K	R184	ERDS2TJ271	1/4W 270	R316	ERDS2TJ332	1/4W 3.3K
R58	ERDS2TJ103	1/4W 10K	R185	ERDS2TJ681	1/4W 680	R317	ERDS2TJ1R5T	1/4W 1.5
R59	ERDS2TJ222	1/4W 2.2K	R201	ERDS2TJ823T	1/4W 82K	R318	ERDS2TJ473	1/4W 47K
R60	ERDS2TJ151	1/4W 150	R202	ERDS2TJ153	1/4W 15K	R319	ERDS2TJ472	1/4W 4.7K


Ref. No.	Part No.	Values & Remarks	Ref. No.	Part No.	Values & Remarks	Ref. No.	Part No.	Values & Remarks
R320	ERDS2TJ333	1/4W 33K	R402	ERDS2TJ123	1/4W 12K	R625	ERDS2TJ123	1/4W 12K
R321	ERDS2TJ222	1/4W 2. 2K	R403	ERDS2TJ122	1/4W 1. 2K	R626	ERDS2TJ272T	1/4W 2. 7K
R322, 323	ERDS2TJ473	1/4W 47K	R405	ERDS2TJ300T	1/4W 30	R627	ERDS2TJ334	1/4W 330K
R324	ERDS2TJ682T	1/4W 6. 8K	R406	ERDS2TJ392T	1/4W 3. 9K	R628	ERDS2TJ123	1/4W 12K
R325	ERDS2TJ153	1/4W 15K	R407	ERDS2TJ682T	1/4W 6. 8K	R629 Δ	ERDS1VJ680T	1/2W 68
R326	ERDS2TJ104	1/4W 100K	R408	ERDS2TJ222	1/4W 2. 2K	R630	ERDS2TJ104	1/4W 100K
R327	ERDS2TJ472	1/4W 4. 7K	R409	ERDS2TJ104	1/4W 100K	R631	ERDS2TJ332	1/4W 3. 3K
R328	ERDS2TJ1R5T	1/4W 1. 5	R410	ERDS2TJ223	1/4W 22K	R632	ERDS2TJ474	1/4W 470K
R329	ERDS2TJ2R7T	1/4W 2. 7	R411	ERDS2TJ822	1/4W 8. 2K	R633	ERDS2TJ472	1/4W 4. 7K
R330	ERDS2TJ101	1/4W 100	R412	ERDS2TJ101	1/4W 100	R634	ERDS2TJ102	1/4W 1K
R331	ERDS2TJ330	1/4W 33	R415	ERDS2TJ474	1/4W 470K	R636	ERDS2TJ223	1/4W 22K
R332	ERDS2TJ102	1/4W 1K	R416	ERDS2TJ154	1/4W 150K	R637	ERDS2TJ2R7T	1/4W 2. 7
R333	ERDS2TJ333	1/4W 33K	R420	ERDS2TJ822	1/4W 8. 2K	R638	ERDS2TJ103	1/4W 10K
R334	ERDS2TJ683	1/4W 68K	R424	ERDS2TJ104	1/4W 100K	R639	ERDS2TJ2R7T	1/4W 2. 7
R335	ERDS2TJ1R5T	1/4W 1. 5	R428	ERDS2TJ152	1/4W 1. 5K	R640	ERDS2TJ334	1/4W 330K
R337	ERDS2TJ102	1/4W 1K	R430	ERDS2TJ822	1/4W 8. 2K	R646-649	ERDS2TJ472	1/4W 4. 7K
R339	ERDS2TJ104	1/4W 100K	R502	ERDS2TJ123	1/4W 12K	R650	ERDS2TJ473	1/4W 47K
R340	ERDS2TJ331	1/4W 330	R503	ERDS2TJ122	1/4W 1. 2K	R651	ERDS2TJ472	1/4W 4. 7K
R351	ERDS2TJ331	1/4W 330	R505	ERDS2TJ330	1/4W 33	R652, 653	ERDS2TJ473	1/4W 47K
R352	ERDS2TJ221	1/4W 220	R506	ERDS2TJ392T	1/4W 3. 9K	R655	ERDS2TJ473	1/4W 47K
R356, 357	ERDS2TG102T	1/4W 1K	R507	ERDS2TJ682T	1/4W 6. 8K	R656	ERDS2TJ335T	1/4W 3. 3M
R358	ERDS2TG122T	1/4W 1. 2K	R508	ERDS2TJ222	1/4W 2. 2K	R657	ERDS2TJ222	1/4W 2. 2K
R359	ERDS2TG152T	1/4W 1. 5K	R509	ERDS2TJ104	1/4W 100K	R658, 659	ERDS2TJ472	1/4W 4. 7K
R360	ERDS2TG222T	1/4W 2. 2K	R510	ERDS2TJ223	1/4W 22K	R660	ERDS2TJ102	1/4W 1K
R361	ERDS2TG272T	1/4W 2. 7K	R511	ERDS2TJ822	1/4W 8. 2K	R661, 662	ERDS2TJ104	1/4W 100K
R362	ERDS2TG392T	1/4W 3. 9K	R512	ERDS2TJ101	1/4W 100	R664	ERDS2TJ104	1/4W 100K
R363	ERDS2TG562T	1/4W 5. 6K	R515	ERDS2TJ474	1/4W 470K	R665	ERDS2TJ222	1/4W 2. 2K
R364	ERDS2TG103T	1/4W 10K	R516	ERDS2TJ154	1/4W 150K	R666	ERDS2TJ103	1/4W 10K
R365	ERDS2TG183T	1/4W 18K	R520	ERDS2TJ822	1/4W 8. 2K	R681, 682	ERDS2TG102T	1/4W 1K
R366	ERDS2TG563T	1/4W 56K	R524	ERDS2TJ104	1/4W 100K	R683	ERDS2TG122T	1/4W 1. 2K
R367, 368	ERDS2TG102T	1/4W 1K	R528	ERDS2TJ152	1/4W 1. 5K	R684	ERDS2TG152T	1/4W 1. 5K
R369	ERDS2TG122T	1/4W 1. 2K	R530	ERDS2TJ822	1/4W 8. 2K	R685	ERDS2TG222T	1/4W 2. 2K
R370	ERDS2TG152T	1/4W 1. 5K	R601	ERDS2TJ334	1/4W 330K	R686	ERDS2TG272T	1/4W 2. 7K
R371	ERDS2TG222T	1/4W 2. 2K	R602	ERDS2TJ102	1/4W 1K	R687	ERDS2TG392T	1/4W 3. 9K
R372	ERDS2TG272T	1/4W 2. 7K	R603	ERDS2TJ103	1/4W 10K	R688	ERDS2TG562T	1/4W 5. 6K
R373	ERDS2TG392T	1/4W 3. 9K	R604, 605	ERDS2TJ102	1/4W 1K	R689	ERDS2TG103T	1/4W 10K
R374	ERDS2TG562T	1/4W 5. 6K	R606	ERDS2TJ472	1/4W 4. 7K	R690	ERDS2TG183T	1/4W 18K
R375	ERDS2TG103T	1/4W 10K	R608	ERDS2TJ822	1/4W 8. 2K	R701	ERJ6GEYJ100	1/10W 10
R376	ERDS2TG183T	1/4W 18K	R609	ERDS2TJ1R2	1/4W 1. 2	R702	ERJ6GEYJ471V	1/10W 470
R377	ERDS2TG563T	1/4W 56K	R610	ERDS2TJ103	1/4W 10K	R703	ERJ6GEYJ102V	1/10W 1K
R378	ERDS2TJ472	1/4W 4. 7K	R611, 612	ERDS2TJ472	1/4W 4. 7K	R704	ERJ6GEYJ103V	1/10W 10K
R379	ERDS2TJ153	1/4W 15K	R613	ERDS2TJ332	1/4W 3. 3K	R706	ERJ6GEYJ473V	1/10W 47K
R380	ERDS2TJ474	1/4W 470K	R614	ERDS2TJ102	1/4W 1K	R707	ERJ6GEYJ222V	1/10W 2. 2K
R381, 382	ERDS2TJ391	1/4W 390	R615	ERDS2TJ221	1/4W 220	R708	ERJ6GEYJ683V	1/10W 68K
R383	ERDS2TJ563	1/4W 56K	R616	ERDS2TJ1R2	1/4W 1. 2	R709	ERJ6GEYJ122V	1/10W 1. 2K
R384	ERDS2TJ103	1/4W 10K	R617	ERDS2TJ562	1/4W 5. 6K	R710	ERJ6GEYJ182V	1/10W 1. 8K
R385	ERDS2TJ472	1/4W 4. 7K	R618	ERDS2TJ153	1/4W 15K	R711	ERJ6GEYJ473V	1/10W 47K
R385	ERDS2TJ682T	1/4W 6. 8K	R619	ERDS2TJ183T	1/4W 18K	R712	ERJ6GEYJ471V	1/10W 470
R386	ERDS2TJ682T	1/4W 6. 8K	R620	ERDS2TJ334	1/4W 330K	R714	ERJ6GEYJ473V	1/10W 47K
R387, 388	ERDS2TJ334	1/4W 330K	R621	ERDS2TJ221	1/4W 220	R715	ERJ6GEYJ223V	1/10W 22K
R389	ERDS2TJ222	1/4W 2. 2K	R622	ERDS2TJ1R2	1/4W 1. 2	R716	ERJ6GEYJ104V	1/10W 100K
R389	ERDS2TJ331	1/4W 330	R623	ERDS2TJ123	1/4W 12K	R717	ERJ6GEYJ682V	1/10W 6. 8K

Ref. No.	Part No.	Values & Remarks	Ref. No.	Part No.	Values & Remarks	Ref. No.	Part No.	Values & Remarks
R718	ERJ6GEYJ223V	1/10W 22K	R874	ERDS2TJ153	1/4W 15K	C60	ECQP2A181G2T	100V 180P
R719	ERJ6GEYJ123V	1/10W 12K	R875	ERDS2TJ104	1/4W 100K	C62	ECBT1H101KB5	50V 100P
R720	ERJ6GEYJ273V	1/10W 27K	R876	ERDS2TJ101	1/4W 100	C64	ECFR1C223MR	16V 0. 022U
R721	ERJ6GEYJ823	1/10W 82K	R877, 878	ERDS2TJ103	1/4W 10K	C65	ECBT1H121KB5	50V 120P
R722	ERJ6GEYJ102V	1/10W 1K	R901	ERDS2TJ471	1/4W 470	C66, 67	ECBT1C103MS5	16V 0. 01U
R723, 724	ERJ6GEYJ104V	1/10W 100K			CHIP JUMPERS	C68	ECEA1HJ010	50V 1U
R725	ERJ6GEYJ471V	1/10W 470				C69	ECEA1HJ47B	50V 0. 47U
R726	ERJ6GEYJ102V	1/10W 1K				C70	ECEA0JU101B	6. 3V 100U
R729, 730	ERJ6GEYJ102V	1/10W 1K	RJ701	ERJ6GEYOR00V	1/10W 0	C71	ECKR1H103MD5	50V 0. 01U
R731	ERJ8GEYJ470V	1/8W 47	RJ703-710	ERJ6GEYOR00V	1/10W 0	C72	ECBT1H101KB5	50V 100P
R732	ERJ6GEYJ562V	1/10W 5. 6K			CAPACITORS	C73	ECKR1H103MD5	50V 0. 01U
R733	ERJ6GEYJ332V	1/10W 3. 3K				C74	ECBT0J153MS5	6. 3V 0. 015U
R734	ERJ6GEYJ562V	1/10W 5. 6K				C75	ECEA1HJ2R2	50V 2. 2U
R735	ERJ6GEYJ222V	1/10W 2. 2K	C2	ECBT1H102KB5	50V 1000P	C76	ECFW1C223MDY	16V 0. 022U
R736	ERJ6GEYJ682V	1/10W 6. 8K	C3	ECCRIH120KC5	50V 12P	C77	ECBT1H102KB5	50V 1000P
R737-739	ERJ6GEYJ562V	1/10W 5. 6K	C4	ECBT1H101KB5	50V 100P	C78	ECEA1HNR47SB	50V 0. 47U
R741-743	ERJ6GEYJ102V	1/10W 1K	C5, 6	ECBT1H102KB5	50V 1000P	C79	ECBT1C103MS5	16V 0. 01U
R744	ERJ6GEYJ393V	1/10W 39K	C7	ECBT1H100JC5	50V 10P	C83	ECEA1CU330	16V 33U
R745, 746	ERJ6GEYJ102V	1/10W 1K	C8	ECBT1H3R9KY	50V 3. 9P	C86, 87	ECBT1H150JC5	50V 15P
R747	ERJ6GEYJ473V	1/10W 47K	C9	ECBT1H150JC5	50V 15P	C88-90	ECBT1H331KB5	50V 330P
R748	ERJ8GEYJ180V	1/8W 18	C10	ECBT1H102KB5	50V 1000P	C91	ECEA1CU100	16V 10U
R802	ERDS2TJ103	1/4W 10K	C11	ECBT1H3R3KC5	50V 3. 3P	C92	ECBT1H102KB5	50V 1000P
R803	ERDS2TJ472	1/4W 4. 7K	C12	ECBT1H2R2KC5	50V 2. 2P	C93	ECEA1CU330	16V 33U
R804-806	ERDS2TJ102	1/4W 1K	C13	ECBT1H181KB5	50V 180P	C94	ECBT1H102KB5	50V 1000P (E)
R807	ERDS2TJ472	1/4W 4. 7K	C14	ECBT1H6R8J	50V 6. 8P	C96	ECEA1CU330	16V 33U
R808-810	ERDS2TJ104	1/4W 100K	C15	ECBT1H102KB5	50V 1000P	C97	ECBT1H102KB5	50V 1000P
R811	ERDS2TJ471	1/4W 470	C17, 18	ECBT1C103MS5	16V 0. 01U	C98	ECBT1H101KB5	50V 100P
R813-815	ERDS2TG103T	1/4W 10K	C19, 20	ECBT1H102KB5	50V 1000P	C99	ECBT1H331KB5	50V 330P
R816	ERDS2TJ471	1/4W 470	C21, 22	ECBT1H181KB5	50V 180P	C101	ECBT1H102KB5	50V 1000P
R817	ERDS2TJ105T	1/4W 1M	C23	ECBT1C103MS5	16V 0. 01U	C102, 103	ECEA1CU100	16V 10U
R818	ERDS2TJ334	1/4W 330K	C24	ECBT1H102KB5	50V 1000P	C104, 105	ECBT1C332MR5	16V 3300P
R820	ERDS2TJ103	1/4W 10K	C25	ECEA1CU100	16V 10U	C106	ECBT1H101KB5	50V 100P
R821	ERDS2TJ183T	1/4W 18K	C26	ECBT1H331KB5	50V 330P	C107	ECFR1C473MR	16V 0. 047U
R822	ERDS2TJ563	1/4W 56K	C29	ECEA0JU101B	6. 3V 100U	C108	ECEA1AU101	10V 100U
R823	ERDS2TJ104	1/4W 100K	C30	ECEA1EU4R7	25V 4. 7U	C109	ECEA1AU222E	10V 2200U
R824	ERDS2TJ823T	1/4W 82K	C31, 32	ECFR1C223MR	16V 0. 022U	C110	ECEA0JU101B	6. 3V 100U
R825	ERDS2TJ103	1/4W 10K	C33	ECEA1AU101	10V 100U	C111	ECEA1EU4R7	25V 4. 7U
R827-830	ERDS2TJ103	1/4W 10K	C34	ECFR1C153MR	16V 0. 015U	C112	ECBT1C332MR5	16V 3300P
R833	ERDS2TJ104	1/4W 100K	C35	ECBT1C103MS5	16V 0. 01U	C113	ECEA1HJ010	50V 1U
R835	ERDS2TJ103	1/4W 10K	C36	ECEA1HJ2R2	50V 2. 2U	C114	ECBT1H471KB5	50V 470P
R840	ERDS2TJ103	1/4W 10K	C37	ECBT1H102KB5	50V 1000P	C115	ECEA0JU101B	6. 3V 100U
R841	ERDS2TJ472	1/4W 4. 7K	C38	ECFR1C153MR	16V 0. 015U	C116	ECBT1H220JC5	50V 22P
R842	ERDS2TJ223	1/4W 22K	C39	ECEA1HJ010	50V 1U	C117	ECBT1C103MS5	16V 0. 01U
R850, 851	ERDS2TJ563	1/4W 56K	C40, 41	ECEA1HJ47B	50V 0. 47U	C118	ECEA1AU470	10V 47U
R854	ERDS2TJ223	1/4W 22K	C42	ECQP2A102J2T	100V 1000P	C119	ECFR1C473MR	16V 0. 047U
R860	ERDS2TJ561	1/4W 560	C44	ECBT1C103MS5	16V 0. 01U	C120	ECEA1AU470	10V 47U
R861	ERDS2TJ391	1/4W 390	C47	ECBT1C103MS5	16V 0. 01U	C121, 122	ECQM1H224J2	50V 0. 22U
R862	ERDS2TJ470	1/4W 47	C48	ECBT1H470J5	50V 47P	C151	ECEA1HJ010	50V 1U
R864	ERDS2TJ474	1/4W 470K	C52	ECFR1C223MR	16V 0. 022U	C152	ECBT1H471KB5	50V 470P
R865-867	ERDS2TJ104	1/4W 100K	C54	ECBT1H6R8KC5	50V 6. 8P	C153	ECEA1CU100	16V 10U
R869-871	ERDS2TJ102	1/4W 1K	C56	ECQP2A391J2T	100V 390P	C154	ECBT1C222MR5	16V 2200P
R872, 873	ERDS2TJ472	1/4W 4. 7K	C58	ECQP2A121G2T	100V 120P	C155, 156	ECFR1C333MR	16V 0. 033U

Ref. No.	Part No.	Values & Remarks	Ref. No.	Part No.	Values & Remarks	Ref. No.	Part No.	Values & Remarks
C157	ECEA1HKR68	50V 0.68U	C303	ECEA1HU010	50V 1U	C418	ECBT1H102KB5	50V 1000P
C158	ECBT1C103MS5	16V 0.01U	C304	ECEA1AU101	10V 100U	C419	ECBT0J223NS5	6.3V 0.022U
C159	ECEA1HUR33	50V 0.33U	C306	ECBT1H102KB5	50V 1000P	C424	ECEA0JU221	6.3V 220U
C160	ECBT1C332MR5	16V 3300P	C308	ECBT1C103MS5	16V 0.01U	C501	ECBT1H102KB5	50V 1000P
C161	ECEA1HUOR1	50V 0.1U	C309, 310	ECEA1HU010	50V 1U	C504	ECQM1H333JZ	50V 0.033U
C162	ECFR1C823MR	16V 0.082U	C311	ECBT1C103MS5	16V 0.01U	C505, 506	ECBT1H471KB5	50V 470P
C163	ECEA1HU2R2	50V 2.2U	C312	ECBT1H220JC5	50V 22P	C507	ECFR1C183KR	16V 0.018U
C165	ECFR1C153MR	16V 0.015U	C313	ECEA1CU100	16V 10U	C508	ECEA1HK010B	50V 1U
C166	ECEA1HU010	50V 1U	C314, 315	ECBT1C103MS5	16V 0.01U	C509	ECEA1EK4R7	25V 4.7U
C181	ECBT1H561KB5	50V 560P	C316	ECEA0JU101B	6.3V 100U	C510	ECEA1HK010B	50V 1U
C182	ECFR1C473MR	16V 0.047U	C317	ECEA1AU101	10V 100U	C511	ECBT1H102KB5	50V 1000P
C183	ECEA1HKR33	50V 0.33U	C318	ECEA0JU221	6.3V 220U	C512	ECFR1C473MR	16V 0.047U
C184	ECBT1H102KB5	50V 1000P	C319-322	ECEA1EU4R7	25V 4.7U	C513	ECEA1CK100B	16V 10U
C201	ECBT1H102KB5	50V 1000P	C323	ECEA1EU101	25V 100U	C514	ECBT1C272MR5	16V 2700P
C202, 203	ECEA1CU100	16V 10U	C324	ECEA1AU471	10V 470U	C515, 516	ECBT1H102KB5	50V 1000P
C204, 205	ECBT1C332MR5	16V 3300P	C325	ECEA1CU101	16V 100U	C517	ECEA1EK4R7	25V 4.7U
C206	ECBT1H101KB5	50V 100P	C326	ECEA1CU221	16V 220U	C518	ECBT1H102KB5	50V 1000P
C207	ECFR1C473MR	16V 0.047U	C327	ECEA1CU100	16V 10U	C519	ECBT0J223NS5	6.3V 0.022U
C208	ECEA1AU101	10V 100U	C328, 329	ECBT1H471KB5	50V 470P	C524	ECEA0JU221	6.3V 220U
C209	ECEA1AU222E	10V 2200U	C330	ECEA1CU101	16V 100U	C601	ECBT1C103MS5	16V 0.01U
C210	ECEA0JU101B	6.3V 100U	C331	ECEA1EU472	25V 4700U	C602	ECQV1H474JZ3	50V 0.47U
C211	ECEA1EU4R7	25V 4.7U	C332	ECEA1CU100	16V 10U	C603	ECQS2B272KZW	125V 2700P
C212	ECBT1C332MR5	16V 3300P	C333	ECBT1C103MS5	16V 0.01U	C604	ECQP2A152JZT	100V0.0015U
C213	ECEA1HU010	50V 1U	C334	ECEA1CU471B	16V 470U	C605	ECBT1C103MS5	16V 0.01U
C214	ECBT1H471KB5	50V 470P	C335	ECEA0JU471	6.3V 470U	C606	ECQP2A392JZT	100V 3900P
C215	ECEA0JU101B	6.3V 100U	C336	ECEA1HU2R2	50V 2.2U	C607	ECEA1HU010	50V 1U
C216	ECBT1H220JC5	50V 22P	C338	ECEA1CU220	16V 22U	C608	ECQV1H473JZ3	50V 0.047U
C217	ECBT1C103MS5	16V 0.01U	C339	ECBT1C103MS5	16V 0.01U	C609	ECEA1AU101	10V 100U
C218	ECEA1AU470	10V 47U	C340	ECEA1EU4R7	25V 4.7U	C610, 611	ECBT1H102KB5	50V 1000P
C219	ECFR1C473MR	16V 0.047U	C341	ECEA1HUOR1	50V 0.1U	C612, 613	ECFR1C103KR	16V 0.01U
C220	ECEA1AU470	10V 47U	C342	ECEA1AU471	10V 470U	C614	ECEA1EU101	25V 100U
C221, 222	ECQM1H224JZ	50V 0.22U	C351	ECEA1AU471	10V 470U	C615	ECEA1AU330	10V 33U
C251	ECEA1HU010	50V 1U	C352	ECBT1C223NYV	16V 0.022U	C616	ECEA1AU101	10V 100U
C252	ECBT1H471KB5	50V 470P	C354	ECEA1CN100SB	16V 10U	C618	ECEA1CK100B	16V 10U
C253	ECEA1CU100	16V 10U	C355	ECEA1HU010	50V 1U	C619	ECEA1HKOR1	50V 0.1U
C254	ECBT1C222MR5	16V 2200P	C356, 357	ECBT1C103MS5	16V 0.01U	C620	ECFR1C223MR	16V 0.022U
C255, 256	ECFR1C333MR	16V 0.033U	C358	ECBT1H102KB5	50V 1000P	C621	ECEA1HK010B	50V 1U
C257	ECEA1HKR68	50V 0.68U	C383	ECEA1AU221	10V 220U	C622	ECEA1CU101	16V 100U
C258	ECBT1C103MS5	16V 0.01U	C384	ECEA1AU101	10V 100U	C623	ECBT1C103MS5	16V 0.01U
C259	ECEA1HUR33	50V 0.33U	C401	ECBT1H102KB5	50V 1000P	C628	ECKF1H153MD	50V 0.015U
C260	ECBT1C332MR5	16V 3300P	C404	ECQM1H333JZ	50V 0.033U	C629	ECEA0JU221	6.3V 220U
C261	ECEA1HUOR1	50V 0.1U	C405, 406	ECBT1H471KB5	50V 470P	C631	ECFR1C104MR	16V 0.1U
C262	ECFR1C823MR	16V 0.082U	C407	ECFR1C183KR	16V 0.018U	C632	ECEA1AU330	10V 33U
C263	ECEA1HU2R2	50V 2.2U	C408	ECEA1HK010B	50V 1U	C633	ECEA1HKOR1	50V 0.1U
C265	ECFR1C153MR	16V 0.015U	C409	ECEA1EK4R7	25V 4.7U	C635	ECEA0JU470B	6.3V 47U
C266	ECEA1HU010	50V 1U	C410	ECEA1HK010B	50V 1U	C636, 637	ECBA1H681KB5	50V 680P
C281	ECBT1H561KB5	50V 560P	C411	ECBT1H102KB5	50V 1000P	C639, 640	ECBT1C103MS5	16V 0.01U
C282	ECFR1C473MR	16V 0.047U	C412	ECFR1C473MR	16V 0.047U	C681, 682	ECBT1H104ZF5	50V 0.1U
C283	ECEA1HKR33	50V 0.33U	C413	ECEA1CK100B	16V 10U	C701	ECEA0JKA220	6.3V 22U
C284	ECBT1H102KB5	50V 1000P	C414	ECBT1C272MR5	16V 2700P	C702	ECEA0JKA470	6.3V 47U
C301	ECEA1HU010	50V 1U	C415, 416	ECBT1H102KB5	50V 1000P	C703	ECEA0JKA101I	6.3V 100U
C302	ECBT1H102KB5	50V 1000P	C417	ECEA1EK4R7	25V 4.7U	C709	ECUV1C224KBM	16V 0.22U

Ref. No.	Part No.	Values & Remarks	Ref. No.	Part No.	Values & Remarks			
C710	ECUV1C104MBM	16V 0.1U	C815, 816	ECBT1H101KB5	50V 100P			
C711	ECUV1E103MBN	25V 0.01U	C817	ECBT1H180JC5	50V 18P			
C713	ECEA1CSN4R7I	16V 4.7U	C818	ECBT1H220JC5	50V 22P			
C714	ECEA1HKS010	50V 1U	C819	ECBT1H102KB5	50V 1000P			
C715	ECUV1H472KBN	50V 4700P	C820-823	ECBA1H681KB5	50V 680P			
C716	ECUV1C473KBN	16V 0.047U	C824-826	ECBT1C103MS5	16V 0.01U			
C717	ECUV1H681KBN	50V 680P	C827	ECEA1AU221	10V 220U			
C718	ECEA1AKS101I	10V 100U	C828	ECQV1H104JZ3	50V 0.1U			
C719	ECUV1E103MBN	25V 0.01U	C829	ECBT1C103MS5	16V 0.01U			
C720	ECUV1E153MBN	25V 0.015U	C830	ECEA0JU470B	6.3V 47U			
C721	ECUV1E103MBN	25V 0.01U	C831-833	ECBT1H102KB5	50V 1000P			
C722	ECEA0JKA470	6.3V 47U	C834-836	ECBA1H681KB5	50V 680P			
C723	ECUV1C104MBM	16V 0.1U	C838-840	ECBT1H331KB5	50V 330P			
C724	ECUV1E333MBN	25V 0.033U	C841-843	ECBT1C103MS5	16V 0.01U			
C725	ECUV1E103MBN	25V 0.01U	C844	ECBT1H331KB5	50V 330P			
C726	ECUV1H471KBN	50V 470P	C845, 846	ECBT1H102KB5	50V 1000P			
C727	ECEA0JKA470	6.3V 47U	C847	ECBT1H330J5	50V 33P			
C728, 729	ECUV1C104MBM	16V 0.1U	C848	ECBT1H102KB5	50V 1000P			
C730	ECUV1C224KBM	16V 0.22U	C850	ECBT1C103MS5	16V 0.01U			
C731	ECEA0JKA331I	6.3V 330U	C851	ECBT1H331KB5	50V 330P			
C732	ECUV1H102MBN	50V 1000P	C852	ECBT1H330J5	50V 33P			
C733	ECEA0JKA101I	6.3V 100U	C853, 854	ECBT1H331KB5	50V 330P			
C734	ECUV1E223MBN	25V 0.022U	C855	ECBT1H330J5	50V 33P			
C735	ECUV1C224KBM	16V 0.22U	C856	ECBT1H680J5	50V 68P			
C737	ECUV1C224KBM	16V 0.22U	C857	ECBT1H331KB5	50V 330P			
C738	ECEA0JKA101I	6.3V 100U	C858	ECBT1H330J5	50V 33P			
C739	ECUV1E103MBN	25V 0.01U	C859-861	ECBT1H331KB5	50V 330P			
C740	ECUV1H472MBN	50V 4700P	C862	ECBT1H101KB5	50V 100P			
C741	ECUV1C224KBM	16V 0.22U	C863	ECBT1H331KB5	50V 330P			
C742	ECUV1C104MBM	16V 0.1U	C864	ECBT1H330J5	50V 33P			
C743	ECEA0JKA331I	6.3V 330U	C865, 866	ECBT1H470J5	50V 47P			
C744, 745	ECUV1H102KBN	50V 1000P	C880	ECBT1H330J5	50V 33P			
C746	ECEA0JKA101I	6.3V 100U	C901-904	ECQV1H474JZ3	50V 0.47U			
C747	ECUV1C104MBM	16V 0.1U	C951	ECBT1H101KB5	50V 100P			
C748	ECEA1HKS010	50V 1U	C971	ECBT1H101KB5	50V 100P			
C749	ECUV1E103MBN	25V 0.01U						
C750	ECUV1H050DCN	50V 5P						
C751	ECUV1C224KBM	16V 0.22U						
C752	ECUV1C104MBM	16V 0.1U						
C753, 754	ECEA1HKS010	50V 1U						
C755	ECUV1C104MBM	16V 0.1U						
C756, 757	ECUV1H050DCN	50V 5P						
C758	ECUV1C224KBM	16V 0.22U						
C763	ECUV1E103MBN	25V 0.01U						
C764	ECUV1H331KBN	50V 330P						
C801-803	ECBA1H681KB5	50V 680P						
C806, 807	ECBA1H681KB5	50V 680P						
C808-810	ECBT1H102KB5	50V 1000P						
C811	ECBT1C103MS5	16V 0.01U						
C812	ECBT1H102KB5	50V 1000P						
C813	ECEA1AU221	10V 220U						
C814	ECBT1H102KB5	50V 1000P						

MECHANISM PARTS LOCATION



Ref. No.	Part No.	Part Name & Description	Remarks	Ref. No.	Part No.	Part Name & Description	Remarks
		MECHANISM PARTS		143	RUB5152A	LEVER	
		DECK1 (P. B)		144	RUB5092A	LEVER	
101	RXQ0051	HEAD ASS'Y		145	RDV1082A	BELT	
102	RUA7932F	CHASSIS		146	RUB5072D	LEVER	
103	RZLAR300A	LEVER ASS'Y		148	RUW1442A	SPRING	
103A	RUW1432A	SPRING		149	RHG30322A	RUBBER	
104	1UB0089Z	ARM		150	RNL1802B	LEVER	
104A	RUW1482A	SPRING		151	REX0074	CABLE ASS'Y	
105	1DM00182B	REEL TABLE ASS'Y		161	XTW2+6L	SCREW	
106	1DM00172B	REEL TABLE ASS'Y		162	XTW2+8L	SCREW	
107	RML0069-1	LEVER		163	XTN26+7J	SCREW	
108	RDG57722C	GEAR		164	RHE52032A	SCREW	
109	RUB5082B	LEVER		165	XTW2+8S	SCREW	
110	RUB5062B	LEVER		166	XYC2+JF16	SCREW	
111	1UB00882B	PINCH ROLLER		167	RHD26002	SCREW	
111A	RUW1412A	SPRING		168	RJS7772A	CONNECTOR (J951)	
112	1UB00872B	PINCH ROLLER				DECK2 (R/P)	
112A	RUW1402B	SPRING		201	RXQ0007	HEAD ASS'Y	
114	RNL12D	ARM		202	RUA7932F	CHASSIS	
115	RUB5032D	LEVER		203	RZLAR300A	LEVER ASS'Y	
116	RZUAR300A	CHASSIS ASS'Y		203A	RUW1432A	SPRING	
117	RUW1422A	SPRING		204	1UB0089Z	ARM	
118	RUD1052A	SPRING		204A	RUW1482A	SPRING	
120	RUW1392A	SPRING		205	1DM00182B	REEL TABLE ASS'Y	
121	RFM1332A	MOTOR ASS'Y		206	1DM00172B	REEL TABLE ASS'Y	
122	1UED0152B	PLUNGER		207	RML0069-1	LEVER	
123	RUB4282E	SHAFT		208	RDG57722C	GEAR	
124	RUL1030YA	PLATE		209	RUB5082B	LEVER	
125	RMD50142C	SPACER		210	RUB5062B	LEVER	
126	RDG59272G	GEAR		211	1UB00882B	PINCH ROLLER	
127	1DM00372B	FLYWHEEL ASS'Y		211A	RUW1412A	SPRING	
127A	RNW1392A	WASHER		212	1UB00872B	PINCH ROLLER	
128	1DM00382B	FLYWHEEL ASS'Y		212A	RUW1402B	SPRING	
128A	RNW1382A	WASHER		213	RUB5072D	LEVER	
129	1DG00062B	GEAR ASS'Y		214	RNL12D	ARM	
130	RUB5132D	LEVER		215	RUB5032D	LEVER	
131	1UB0091Z	LEVER		216	RZUAR300A	CHASSIS ASS'Y	
131A	RUW1462A	SPRING		217	RUW1422A	SPRING	
132	1DR00112B	PULLEY ASS'Y		218	RUD1052A	SPRING	
133	RDV902B	BELT		219	RUW1442A	SPRING	
134	RDG57692A	GEAR		220	RUW1392A	SPRING	
135	RJQ1112B	SPRING		221	RFM1332A	MOTOR ASS'Y	
136	RUW1452A	SPRING		222	1UED0152B	PLUNGER	
137	1UB00902A	ROD		223	RUB4282E	SHAFT	
137A	RUB5122B	ROD		224	RUL1030YA	PLATE	
138	RDG57732B	GEAR		225	RMD50142C	SPACER	
139	RJQ1122A	SPRING		226	RDG59272G	GEAR	
140	RUB5092C	SPRING		227	1DM00372B	FLYWHEEL ASS'Y	
141	RUB5142C	LEVER		227A	RNW1392A	WASHER	
142	RUW1472A	SPRING		228	1DM00382B	FLYWHEEL ASS'Y	

[illegible]

Ref. No.	Part No.	Part Name & Description	Remarks
43	RDG59532C	WORM GEAR	
44	RDG59542A	VOLUME GAER	
45	RM00017-2	SPRING	(M)
46	RMN0118	LCD HOLDER	(M)
47	RMN0119	CHASSIS	(M)
48	RJA8672B	VOLUME CHASSIS	
49	RJD129XA	SPRING	
50	XQN17+C3	SCREW	
51	RFM1562A	MOTOR ASS' Y	
52	XTW3+10F	SCREW	
53	REE0270	FLEXIBLE WIRE	(M)
54	REE0271	FLEXIBLE WIRE	(M)
55	XTWS3+10Q	SCREW	
56	REX0301	WIRE ASS' Y (W802)	(M)
57	REX0304Y	WIRE ASS' Y (W801)	(M)
58	RMJ0103230KQ	FLAT CABLE (W681)	(M)
59	REX0302	WIRE ASS' Y (W302)	(M)
60	REX0303Y	WIRE ASS' Y (W301)	(M)
61	RMJ0104350KQ	FLAT CABLE (W303)	(M)
62	RFKXKDT680E	REAR CABINET ASS' Y	(M) (E)
62	RFKXKDT680EB	REAR CABINET ASS' Y	(M) (EB)
62	RFKXKDT680EG	REAR CABINET ASS' Y	(M) (EG)
62-1	RJC91003	TERMINAL, BATT.	(M)
62-2	RJR0074	TERMINAL, ANT.	(M)
63	RJC5112B	TERMINAL	
64	RJC70031YB	TERMINAL	(M)
65 Δ	RJF282A	FUSE HOLDER	
66	RJB0566G	P. C. B.	(M)
69	RMJ5607080QQ	FLAT CABLE (W603)	(M)
70	RMJ5610080QQ	FLAT CABLE (W604)	(M)
71	RMJ4704210KD	FLAT CABLE (W605)	(M)
72	RMJ4704110KD	FLAT CABLE (W606)	(M)
73	REX0305	WIRE ASS' Y	(M)
74	REX0306	WIRE ASS' Y	(M)
75	XTN26+6B	SCREW	
76	RFKLXDT680PE	EQ. VOLUME ORNAMENT ASS' Y	(M)
77	EAS12P463A-G	SPEAKER (WOOFER)	(M)
78	EAS8PH63D-G	SPEAKER (TWEETER)	(M)
79	RJLAW001W22	SP CORD	(M)
80	RMG0166	CORD BUSHING	(M)
81	RFKXKDT680PA	SP BOX (R)	(M)
81-1	RMRO407	LOCK LEVER (R)	(M)
82	RFKXKDT680PB	SP BOX (L)	(M)
82-1	RMRO408	LOCK LEVER (L)	(M)
83	XTV3+10G	SCREW	(M)
84	XTV3+20JFZ	SCREW	(M)
85	RMS0123-1	PIN	
86	SODD1102	TRAVERSE DECK ASS' Y	
86-1	RDV0014	BELT	
86-2	SHGD112	RUBBER	
86-3	SHGD113-1	RUBBER	
87	XTV26+6G	SCREW	

■ CABINET PARTS LOCATION

