


Service Manual

Dolby NR-Equipped
Stereo Double Cassette Deck

Cassette Deck
RS-CH7



Color

(K) Black Type



Area

Country Code	Area	Color
(PP)	U.S.A./Canada.	(K)

System: SC-CH7

RS-TR165 MECHANISM SERIES (AR300)

Because of unique interconnecting cables,
when a component requires service, send or
bring in the entire system.

■ SPECIFICATIONS

Track system	Compact cassette stereo
Tape speed	4.8 cm/sec. (1 7/8 ips)
Bias frequency	80 kHz
Heads	
(DECK 2) REC/PLAY	Permalloy head
Erasing	Double-gap ferrite head
(DECK 1) PLAY	Permalloy head
Motors	
(DECK 2)	DC servo motor
(DECK 1)	DC servo motor
Wow and flutter	0.1% (WRMS)
Fast Forward and Rewind Time	Approx. 110 seconds with C-60 cassette tape
Frequency response	
METAL	30 Hz~17 kHz
CrO ₂	30 Hz~16 kHz
NORMAL	30 Hz~16 kHz

S/N

(signal level=max recording level,
CrO₂ type tape)
66 dB (CCIR)
74 dB (CCIR)
56 dB (A WTD)

DOLBY B NR on
DOLBY C NR on
DOLBY off

■ GENERAL

Power consumption
Dimensions (W×H×D)

16 W
215×110×297 mm
(8 15/32"×4 11/32"×11 11/16")
2.6 kg (5.7 lb.)

Weight

Notes:

- Specifications are subject to change without notice.
- Weight and dimensions shown are approximate.

System	Tuner	Amplifier	CD Player	Cassette Deck	Speakers
SC-CH7	ST-CH7	SU-CH7	SL-CH7	RS-CH7	SB-CH7

Panasonic®

■ CONTENTS

	Page
SAFETY PRECAUTION	2
LOCATION OF CONTROLS	3
DISASSEMBLY INSTRUCTIONS	4~7
DESCRIPTION OF FL PANEL	8
MEASUREMENTS AND ADJUSTMENTS	9~11
BLOCK DIAGRAM	12, 13
SCHEMATIC DIAGRAM	14~19

	Page
PRINTED CIRCUIT BOARDS AND WIRING CONNECTION DIAGRAM	20~22
FUNCTION OF IC TERMINALS	23, 24
REPLACEMENT PARTS LIST	25~37
MECHANISM PARTS LOCATION (DECK 1)	29, 30
(DECK 2)	33, 34
CABINET PARTS LOCATION	35, 36


■ SAFETY PRECAUTION

1. Before servicing, unplug the power cord to prevent an electric shock.
2. When replacing parts, use only manufacturer's recommended components for safety.
3. Check the condition of the power cord. Replace if wear or damage is evident.
4. After servicing, be sure to restore the lead dress, insulation barriers, insulation papers, shields, etc.
5. Before returning the serviced equipment to the customer, be sure to make the following insulation resistance test to prevent the customer from being exposed to a shock hazard.


•INSULATION RESISTANCE TEST

1. Unplug the power cord and short the two prongs of the plug with a jumper wire.
2. Turn on the power switch.
3. Measure the resistance value with ohmmeter between the jumpered AC plug and each exposed metal cabinet part, such as screwheads antenna, control shafts, handle brackets, etc. Equipment with antenna terminals should read between 3 M Ω and 5.2 M Ω to all exposed parts. (Fig. A) Equipment without antenna terminals should read approximately infinity to all exposed parts. (Fig. B)

Note: Some exposed parts may be isolated from the chassis by design. These will read infinity.



(Flg. A)

Resistance = $3\text{ M}\Omega - 5.2\text{ M}\Omega$ 

(Fig. B)


Resistance = Approx. ∞

4. If the measurement is outside the specified limits, there is a possibility of a shock hazard. The equipment should be repaired and rechecked before it is returned to the customer.

NOTES:


Refer to the service manual for Model No. SU-CH7, Order No. AD9101027C1 for information on ACCESSORIES, INSTALLATION OF THE SYSTEM, CONNECTIONS and PACKAGING.

LOCATION OF CONTROLS



Cassette deck section

- 1 Deck 1/deck 2 selector (DECK 1/2)**
This button is used to select the deck to be operated.
- 2 Dolby noise reduction button (DOLBY NR)**
This button is used to reduce the hissing noise heard from the tape. This unit is provided with both the Dolby B-type and Dolby C-type noise reduction systems.
- 3 Reverse mode button (REVERSE MODE)**
This button is used to select the reverse mode (for playback or recording).
- 4 Tape counter reset button (COUNTER RESET)**
This button is used to reset the tape counter indicator to "000".
- 5 Edit speed button (SPEED)**
This button is used to select the recording speed when edit-recording tapes.
- 6 Synchro-start button (SYNCHRO START)**
This button is used to start a tape-to-tape recording, simultaneously starting deck 1 (the playback deck) and the deck 2 (the recording deck).
- 7 Record/record standby button (● REC PAUSE)**
This button is used to put deck 2 into the record standby mode.
- 8 Fast-forward/rewind/music select button (◀◀ (MS), (MS) ▶▶)**
These buttons are used to advance or rewind the tape, or to quickly search for the beginning of a tune while the tape is being played.
- 9 Playback button (◀, ▶)**
These buttons are used to start the playback or recording (deck 2 only).
- 10 Eject button (▲ EJECT)**
This button is used to open the cassette holder.
- 11 Stop button (□)**
This button is used to stop the tape movement.



Display section

- 12 Playback indicator (PLAY)**
Illuminates to show that deck 1 or 2 is in the playback mode or recording mode (deck 2).
- 13 Tape travel direction indicators (◀, ▶)**
One of these indicators illuminates to show the direction of tape travel.
- 14 Dolby noise reduction indicators (B, C)**
Each indicator illuminates to show the type of Dolby noise reduction system selected by pressing the Dolby noise reduction button.
- 15 Tape counter**
Indicates the amount of tape movement separately for deck 1 or deck 2.
- 16 Edit indicator (EDIT)**
Illuminates when edit-recording tapes or CD.
- 17 Recording indicator (REC)**
Illuminates to indicate that deck 2 is in the recording standby or recording mode.
- 18 Tape indicator**
Illuminates to show that there is a tape in the cassette holder of deck 1 or deck 2.
- 19 Deck 1 operating indicator (DECK 1)**
Illuminates to show that deck 1 can be operated.
- 20 Reverse mode indicators (↔, ↔, ↔)**
Each indicator illuminates to show which of the reverse modes was selected by the reverse mode button.
- 21 Edit speed indicators (×1, ×2)**
One of these indicators will illuminate to show which of the tape-to-tape recording speeds was selected by pressing the edit speed button.
- 22 CD indicator (CD)**
Illuminates when edit-recording a CD.
- 23 Deck 2 operating indicator (DECK 2)**
Illuminates to show that deck 2 can be operated.

■ DISASSEMBLY INSTRUCTIONS

“ATTENTION SERVICER”


Some chassis components may have sharp edges. Be careful when disassembling and servicing.

Ref. No.
1

Removal of the Cabinet

Procedure
1


- Remove 6 screws (①~⑥).



Ref. No.
2

Removal of the Mechanism Control P.C.B.

Procedure
1→2





1. Remove the screw (①).
2. Remove 2 claw in the direction of arrow ① and then remove the holder.
3. Remove the mechanism control P.C.B. in the direction of arrow ②.

Removal of the Flat Cable

(J951, J971)

(CN4, CN6)

(CN9)




4. Remove 5 flat cable (CN4, CN6, CN9, J951, J971).
5. Remove the connector (CN7).


Ref. No.
3

Removal of the Main P.C.B.

Procedure
1→2→3







1. Remove 2 connector (CP1, CP2).





2. Remove 5 screws (①~⑤).

Ref. No. 4	Removal of the Mechanism Unit/Front Panel Ass'y		
Procedure 1→2→4	(Bottom side) 1. Remove 4 screws (①~④).		Main P.C.B. CP 2 CP 1 Mechanism unit and Front panel ass'y 3 4 2. Remove 2 connectors (CP1, CP2). 3. Remove the mechanism unit and front panel in the direction of the arrow.
Ref. No. 5	Removal of the Mechanism Unit	Ref. No. 6	Removal of the Front Panel
Procedure 1→2→4→5	Front panel Claw Claw Claw Mechanism unit Claw ●Remove 5 claws.		Procedure 1→2→4→6 Front panel Eject button 1. Pull out the eject buttons. (DECK 1, DECK 2).
Front panel 2 Claw 3 3. Push the claw in the direction of arrow ②, and then remove the front panel in the direction of arrow ③.		Front panel Lock lever 1 2. Push the lever in the direction of the arrow ①, and then open the front panel.	

Ref. No. 7	Removal of the Operation P.C.B.		
Procedure 1→2→4→6→ 7	 Rear panel Claw Claw	 Operation P.C.B.	
1. Remove 6 screws (①~⑥). 2. Remove 2 claws. 3. Remove the rear panel in the direction of arrow.		4. Remove the operation P.C.B. in the direction of arrow.	

Ref. No. 8	Removal of the Eject rod (DECK 1 and DECK 2)	Ref. No. 9	Removal of the Eject Angle (A) and Eject Angle (B)
Procedure 1→2→4→5→ 6→8	 Eject rod (DECK 2) Eject rod (DECK 1) Claw Claw Spring (DECK 2) Spring (DECK 1)	Procedure 1→2→4→5→ 6→8→9	 Eject angle A ① ② Eject angle B
1. Push the eject rod in the direction of arrow and then open the cassette holder. 2. Remove the spring (DECK 1, DECK 2). 3. Press 4 claws and then remove the eject rod.		■ Removal of the Eject Angle (A) 1. Remove the screw (①). 2. Pull out the eject angle (A). ■ Removal of the Eject Angle (B) 1. Remove the screw (②). 2. Pull out the eject angle (B).	

Ref. No. 10	Removal of the Cassette Holder (DECK 1 and DECK 2)		
Procedure 1→2→4→5→ 6→8→9→10	 Cassette holder (DECK 1) Cassette holder (DECK 2) Shaft	 Rib Rib	
1. Pull out the shaft.		2. Push the rib in the direction of arrow and then remove the cassette holder.	

Ref. No. 11	Check of the Main P.C.B.
Procedure 1→11	

1. Remove 6 screws (①~⑥).

2. Remove 3 screws (⑦~⑨).

3. Remove the rear panel in the direction of arrow.


4. Remove 2 screws (⑩~⑪).

5. Remove the chassis in the direction of arrow.

6. Check the main P.C.B. in the direction of arrow.

■ DESCRIPTION OF FL PANEL [FL 1 (RSL0088-F)]

- Grid assignment



- **Pin connection**

Pin No.	3 5	3 4	3 3	3 2	3 1	3 0	2 9	2 8	2 7	2 6	2 5	2 4	2 3	2 2	2 1	2 0	1 9	1 8	1 7	1 6	1 5	1 4	1 3	1 2	1 1	1 0	9	8	7	6	5	4	3	2	1
Connection	F +	F +	N P	P 1	P 2	P 3	P 4	P 5	P 6	P 7	P 8	P 9	N P	N P	N P	N P	N P	N P	N P	N P	N P	N P	N C	N C	7 G	6 G	5 G	4 G	3 G	2 G	1 G	N P	F —	F —	

- **Anode connection**

	7G	6G	5G	4G	3G	2G	1G
P1			a	a	a	EDIT	
P2	PLAY	—	b	b	b		PLAY
P3	S1		c	c	c	X1	S1
P4	S3	—	d	d	d	CD	S3
P5	S2		e	e	e	X2	S2
P6			f	f	f	—	
P7	DECK1		g	g	g	—	DECK2
P8	S4	—	—	—	—	—	S4
P9	S5	—	—	—	—	—	S5

MEASUREMENTS AND ADJUSTMENTS

This tape deck (RS-CH7) is powered by the amplifier (SU-CH7).


To adjust or check operations on the tape deck as a separate unit, follow the steps below.

1. Apply a power supply voltage of AC 20 V to **TP601** and **TP603**.
2. Short-circuit **TP504** and **TP602** (GND) (power supply switch: ON).


HOW TO CONNECT

Note:

Apply a power supply voltage of AC 20 V to **TP601** and **TP603** by using a Voltage Controller. If it is not available, use a Power Supply Fixture (SZZA1058C) instead.



Adjustment points



Measurement Condition

- Rec. level control; Maximum
- Reverse-mode selector switch; $\Rightarrow$
- Edit-recording tape-speed selector; NORMAL
- Timer-recording switch; off

Measuring instrument

- EVM (Electronic Voltmeter)
- Oscilloscope
- Digital frequency counter
- AF oscillator

Test tape

- Head azimuth adjustment (8 kHz, -20 dB); QZZCFM
- Tape speed adjustment (3 kHz, -10 dB); QZZCWAT
- Playback frequency response (315 Hz, 12.5 kHz, 10 kHz, 8 kHz, 4 kHz, 1 kHz, 250 Hz, 125 Hz, 63 Hz, -20 dB); QZZCFM

- Dolby NR switch; Off
- Make sure heads are clean
- Make sure capstan and pressure roller are clean
- Judgeable room temperature $20 \pm 5^\circ\text{C}$ ($68 \pm 9^\circ\text{F}$)

- ATT (Attenuator)
- DC voltmeter
- Resistor (600 Ω)

- Playback gain adjustment (315 Hz, 0 dB); QZZCFM
- Overall frequency response, Overall gain adjustment Normal reference blank tape; QZZCRA
- CrO₂ reference blank tape; QZZCRX
- Metal reference blank tape; QZZCRZ

HEAD AZIMUTH ADJUSTMENT (DECK 1/2)

1. Playback the azimuth adjustment portion (8 kHz, -20 dB) of the test tape (QZZCFM). Vary the azimuth adjusting screw until the outputs of the L-CH and R-CH are maximized and the lissajous waveform, as illustrated, approaches 0 degrees.

Note: If L-CH and R-CH are not maximized at the same point, adjust to the point where the levels of each channel are maximized and equal.

2. Perform the same adjustment in the play mode.
3. After the adjustment, apply screwlock to the azimuth adjusting screw.




Fig. 1




Fig. 2

TAPE SPEED ADJUSTMENT (DECK 1/2)

Normal speed

1. Shift the edit-recording tape-speed selector to "NORMAL".
2. Playback the middle portion of the test tape (QZZCWAT).
3. Adjust Deck 1=VR721 and Deck 2=VR723 so that the output is within the standard value.

Standard value: 3000 ± 15 Hz (NORMAL speed)

High speed [Set the unit to forward (FWD) mode.]

4. Push the edit speed button (SPEED). This will set the high speed mode.
5. Playback the middle portion on the test tape (QZZCWAT).
6. At that time, check if the output from DECK 1 is within the standard value.

Standard value: 6000 ± 600 Hz (HIGH speed)

7. Adjust VR722 so that the output frequency of DECK 2 is within ± 30 Hz of the value of the output frequency of DECK 1.




Fig. 3

PLAYBACK GAIN ADJUSTMENT (DECK 1/2)

1. Playback the gain adjusted portion (315 Hz, 0 dB) of the test tape (QZZCFM).
2. Adjust Deck 2=VR5 (L-CH) [[VR6 (R-CH)]] and Deck 1=VR3 (L-CH) [[VR4 (R-CH)]] so that the output is within the standard value.

Standard value: $400 \text{ mV} \pm 0.5 \text{ dB}$




Fig. 4

PLAYBACK FREQUENCY RESPONSE (DECK 1/2)

1. Playback the frequency response portion (315 Hz, 12.5 kHz ~ 63 Hz, -20 dB) of the test tape (QZZCFM).
2. Assure that the frequency response is within the range shown in Fig. 6 for both L-CH and R-CH.




Fig. 5





Fig. 6


ERASE CURRENT ADJUSTMENT (DECK 2)

1. Insert the Metal blank test tape (QZZCRZ) and set the unit to the Record Pause mode.
2. Adjust VR301 so that the output between TP301 and TP302 (GND) (the output on both edges of R302) is within the standard value.



Standard value: $190\text{ mA} \pm 5\text{ mA}$ (Metal)

**OVERALL FREQUENCY RESPONSE (DECK 2)**

1. Insert the Normal blank test tape (QZZCRA) and set the unit to the Record Pause mode.
2. Apply a reference input signal (1 kHz, -24 dB) through an attenuator.
3. Attenuate the signal by 20 dB and adjust the frequency from 50 Hz ~ 10 kHz.
4. Record the frequency sweep.
5. Playback the recorded signal and assure that it is within the range shown in Fig. 8 in comparison to the reference frequency (1 kHz).
6. If it is not within the standard range, adjust VR302 (L-CH) and VR303 (R-CH) so that the frequency level is within the standard range.
 - Level up in high frequency range Increase the bias current.
 - Level down in high frequency range Decrease the bias current.
7. Repeat steps 2~6 above using the CrO₂ tape (QZZCRX) and the Metal tape (QZZCRZ) increasing the frequency range to 12.5 kHz (50 Hz ~ 12.5 kHz).
8. Assure that the level is within the range shown in Fig. 9.





LINE IN (Lch): TP1 LINE OUT (Lch): TP5
(Rch): TP2 (Rch): TP6

Normal Overall frequency response chart (NR OUT)**CrO₂ Metal Overall frequency response chart (NR OUT)****OVERALL GAIN ADJUSTMENT (DECK 2)**

1. Insert the Normal blank test tape (QZZCRA) and set the unit to the Record pause mode.
2. Apply a reference input signal (1 kHz, -19 dB). Attenuate the output so that its level becomes 0.4 V.
3. Record this input signal.
4. Playback the signal recorded in step 3 above, and assure that the output is within the standard value.
5. If it is not within the standard value, adjust VR7 (L-CH) and VR8 (R-CH).
6. Repeat the step 2~5 above until the output is within the standard value.

Standard value: $0.4\text{ V} \pm 0.5\text{ dB}$

**BLOCK DIAGRAM**

BLOCK DIAGRAM






chart (NR OUT)





nse chart (NR OUT)





TP5

TP6



SCHEMATIC DIAGRAM (Parts list on pages 25~28)





■ SCHEMATIC DIAGRAM (Parts list on pages 25~28)

- Notes:**
- S810 : Counter reset switch in "OFF" position. (COUNTER RESET)
 - S811 : Stop switch in "OFF" position. (STOP)
 - S812, 813 : FF/REW/MS switch. (S812: ►►, S813: ◄◄)
 - S814, 815 : Playback switch. (S814: ►, S815: ◄)
 - S816 : Rec pause switch. (REC PAUSE)
 - S817 : DECK 1/DECK 2 selector switch.
 - S818 : Synchro start switch. (SYNCHRO START)
 - S819 : Edit speed switch. (SPEED)
 - S820 : Dolby NR switch in "OFF" position.
 - S821 : Reverse mode switch. (REVERSE MODE)
 - S971A~976A : DECK 2 mechanism leaf switch.

- S971A: Mode detect.
- S972A: Half detect.
- S973A: Reverse side record prevention tab detect.
- S974A: Forward side record prevention tab detect.
- S975A: ATS (CrO₂).
- S976A: ATS (Metal).

- S971~973 : Deck 1 mechanism leaf switch.

- S971: Mode detect.
- S972: Half detect.
- S973: ATS (CrO₂).

●Indicated voltage values are the standard values for the unit measured by the DC electronic circuit tester (high-impedance) with the chassis taken as standard.

Therefore, there may exist some errors in the voltage values, depending on the internal impedance of the DC circuit tester.

No mark...Playback ()...Recording

●Important safety notice:

Components identified by ⚡ mark have special characteristics important for safety.

When replacing any of these components, use only manufacturer's specified parts.

●This schematic diagram may be modified at any time with the development of new technology.

— : Positive voltage line

--- : Negative voltage line

→ : Playback signal

→ : Recording signal line

Caution!

IC and LSI are sensitive to static electricity.

Secondary trouble can be prevented by taking care during repair.

●Cover the parts boxes made of plastics with aluminum foil.


●Ground the soldering iron.

●Put a conductive mat on the word table.


●Do not touch the legs of IC or LSI with the fingers directly.

●The supply part number is described alone in the replacement parts list.


















Ref. No.	Production Part No.	Supply Part No.
IC3, 5, 7	BA4558FT1	SVIBA4558F




■ SCHEMATIC DIAGRAM (Parts list on pages 25~28)



(Parts list on pages 25~28)

BA4558FT1 	CXA1331M-T6 	AN7351SCE2 
AN7384N 	M50963-238SP 	LC6512A-4604 
DN6851ALB 	2SB621ARSTA 2SD592QRSTA 2SD1302STTA 	MSA1048ABCTA MSC2458ABCTA 
	DTA114ESTP DTC114ESTP DTC124ESTP DTC144ESTP	2SB1030RSTTA 2SC3312STTA 2SD1450STTA 2SB1036RSTTA 
2SJ164PQRTA 	2SB1357EFTA 2SD2037EFTA 	2SB1240QRTV6 2SD1862QRTV6 2SB1236PQRT6 
	MA167TA MA700TA 1SS254TA 1SR35200TB RVD1SS133TA	MA4130MTA MA4100MTA 
	MA4030LTA MA4036MTA MA4039MTA MA4047MTA MA4062LTA MA4091LTA MA4056MTA	

BLK	Black	ORG	Orange
BLU	Blue	PNK	Pink
BRN	Brown	RED	Red
GRY	Gray	SLD	Shield Wire
GRN	Green	VLT	Violet
L.BLU	Light Blue	WHT	White
		YEL	Yellow



■ FUNCTION OF IC TERMINALS

●IC801 (LC6512A–4604)

Pin No.	Mark	I/O Division	Function
1	PB3	I	Serial data input
2	PC0	I/O	Deck 2 Rotation pulse signal of reel table
3	PC1	I/O	Deck 1 Rotation pulse signal of reel table
4 ⋮ 10	—	—	Connected to GND
11 ⋮ 14	PE0 ⋮ PE3	O	FL port signal output
15	RES	I	Reset terminal
16	TEST	—	Connected to GND
17	VSS		
18 ⋮ 19	NC	—	Not connected
20	OSC1	I/O	Connected to ceramic oscillator (X800)
21	OSC2		

●IC901 (M50963-236SP)

Pin No.	Mark	I/O Division	Function
1	VCC	I	Power supply (+5 V)
2	AVSS	—	Connected to GND
3	VREF	I	Reference voltage input (+5 V)
4	NC	—	Not connected
5	PWN	O	Control voltage terminal of electric volume
6 ⋮ 7	NC	—	Not connected
8	RMT2	O	Rec, amp, mute signal of deck 2 “L” level in mute is off mode “H” level in mute is on mode
9	LMT	O	Line out mute signal
10	VR IN	I	Not used and connected to resistance
11	RLV	I	Recording level detection (at ATLS position)

Pin No.	Mark	I/O Division	Function
22 ⋮ 25	PF0 ⋮ PF3	O	FL port signal output
26 ⋮ 29	PG0 ⋮ PG3	O	FL grid signal output
30	NC	—	Not connected
31 ⋮ 34	PH0 ⋮ PH3	O	FL grid signal output
35 ⋮ 36	P10 ⋮ P11	—	Not connected
37	HOLD		
38	INT	—	Connected to GND
39	VDD	I	Power supply (+5.6 V)
40 ⋮ 47	—	—	Connected to GND
48	PB2	I	Counter reset terminal

Pin No.	Mark	I/O Division	Function
12	KEY2	I	Key switch input Pin 13 is not used and connected to resistance
13	KEY1		
14	QUICK2	O	Pin 15 is not used and connected to resistance
15	QUICK1		
16	ARM2	I	Mute key input Not used ad connected to resistance
17	NC	—	Not connected
18	REC2	I	Recording bias control voltage terminal “L” level when is on “H” level when is off
19 ⋮ 20	NC	—	Not connected
21	POWER IN	I	Power ON/OFF detection terminal
22	CLK IN	I	Clock input for serial data
23	CLK OUT	O	Clock output for serial data

Pin No.	Mark	I/O Division	Function
24	DATA IN	I	Serial data input
25	DATA OUT	O	Serial data output
26	NC	—	Connected to Vss
27	CNVSS	—	Conencted to Vss
28	RESET	I	Reset terminal “L” level when reset is off mode “L”→“H” level when reset is on mode
29	X IN	I	Clock OSC terminal Connected to crystal oscillator
30	X OUT	O	
31	NC	—	Not used
32	Vss	—	Connected to GND
33	TEST	—	Test terminal (“L” level)
34	PW IN	I	Not used
35	REEL2	I	Deck 2 Rotation pulse signal of reel table
36	REEL1	I	Deck 1 Rotation pulse signal of reel table
37	RINH2	I	Deck 2 Reverse Rec. Inh. switch select terminal
38	FINH2	I	Deck 2 Forward Rec. Inh. switch select terminal
39	MODE2	I	Deck 2 mechanism mode switch select terminal
40	HALF2	I	Deck 2 cassette half detection switch “L” level in half detection switch is on mode. “H” level in half detection switch is off mode.
41	MPX	—	Not used
42	T2	O	Deck 2 play select signal “L” level with PLAY mode.
43	X2	O	X2 Speed LED display “L” level when LED is on mode
44	X1	O	Not used
45	VIA	—	

Pin No.	Mark	I/O Division	Function
46	C	O	Dolby C LED display “L” level when LED is on mode “H” level when other mode
47	B	O	
48	ENC	O	Encode/Decode select signal “L” level in encode mode “H” level in decode mode
49	KEY T/S	—	Not use and connected to GND
50	PW OFF	—	Not used
51	SERIAL	O	Control for FL micro computer Serial data output
52	PLAY	O	Not used
53	DIR	O	
54	MSP	O	
55	↔	O	Not used
56	↺↻	O	
57	↻↺	O	
58	SOL2	O	Deck 2 Solenoid control signal “H” level when solenoid is on mode “L” level when solenoid is off mode
59	MOTOR2	O	Deck 2 Motor control signal “H” level when motor is on mode “L” level when motor is off mode
60	MODE1	I	Deck 1 mechanism mode switch select terminal
61	HALF1	I	Deck 1 cassette half detection switch “L” level in half detection switch is on mode “H” level in half detection switch is off mode
62	SOL1	O	Deck 1 Solenoid control signal “H” level when solenoid is on mode “L” level when solenoid is off mode
63	HISP	O	Motor speed control signal “L” level when normal speed “H” level when high speed
64	MOTOR1	O	Deck 1 Motor control signal “H” level when motor is on mode “L” level when motor is off mode

■ REPLACEMENT PARTS LIST

Notes : * Important safety notice:
Components identified by △ mark have special characteristics important for safety. When replacing any of these components use only manufacturer's specified parts.
* The parenthesized indications in the Remarks columns specify the areas. (Refer to the cover page for area.)
Parts without these indications can be used for all areas.

Ref. No.	Part No.	Part Name & Description	Remarks	Ref. No.	Part No.	Part Name & Description	Remarks
		INTEGRATED CIRCUIT(S)		Q932	MSC2458ABCTA	TRANSISTOR	
				Q933	DTA114ESTP	TRANSISTOR	
				Q934	DTC144EKT96	TRANSISTOR	
IC1	AN7384N	I. C, ELECTRIC VOLUME				DIODE (S)	
IC2	AN7351SCE2	I. C, PLAYBACK/REC. AMP.					
IC3	SVIBA4558F	I. C, REC. LEVEL DET.					
IC5	SVIBA4558F	I. C, MUSIC SEL. AMP.		D1, 2	MA167	DIODE	
IC7	SVIBA4558F	I. C, REC. LEVEL CONT.		D3-8	1SS254TA	DIODE	
IC411	CXA1331M-T6	I. C, DOLBY NR (B/C)		D9	MA700TA	DIODE	
IC801	LC6512A-4604	I. C, FL DRIVE		D111	1SS254TA	DIODE	
IC901	M50963-238SP	I. C, MICROCOMPUTER		D601-604	1SR35200TB	DIODE	△
IC971	DN6851ALB	I. C, HALL		D605	1SS254TA	DIODE	
IC971A	DN6851ALB	I. C, HALL		D607	MA4091LTA	DIODE	
		TRANSISTOR(S)		D608	MA4091-M	DIODE	
				D610	MA4062	DIODE	
				D611, 612	MA167	DIODE	
Q3, 4	2SJ164PQRTA	TRANSISTOR		D701-703	1SS254TA	DIODE	
Q5-8	MSA1048ABCTA	TRANSISTOR		D705, 706	1SR35200TB	DIODE	△
Q9	MSC2458ABCTA	TRANSISTOR		D708	1SR35200TB	DIODE	△
Q10-14	MSC2458ABCTA	TRANSISTOR		D800	MA4030LTA	DIODE	
Q15, 16	2SD1450STTA	TRANSISTOR		D802	1SS254TA	DIODE	
Q19	MSC2458ABCTA	TRANSISTOR		D803-805	MA4047MTA	DIODE	
Q20-22	2SC3312STTA	TRANSISTOR		D806	MA4036MTA	DIODE	
Q23	DTC124EST	TRANSISTOR		D807	MA4039MTA	DIODE	
Q301, 302	MSC2458ABCTA	TRANSISTOR		D830	MA4100MTA	DIODE	
Q303	2SB621A-R	TRANSISTOR		D831, 832	1SR35200TB	DIODE	△
Q304	2SD592NCR	TRANSISTOR		D833	SVD1SR35200A	DIODE	
Q601	2SB1036RSTA	TRANSISTOR		D834	1SR35200TB	DIODE	△
Q603	MSC2458ABCTA	TRANSISTOR		D835	MA4100MTA	DIODE	
Q604	2SD2037EFTA	TRANSISTOR		D840	MA167	DIODE	
Q605	2SB1357EFTA	TRANSISTOR		D841	MA4100MTA	DIODE	
Q606	2SD1862QRTV6	TRANSISTOR		D842	MA4056MTA	DIODE	
Q717, 718	2SB1030QTA	TRANSISTOR		D902-907	1SS254TA	DIODE	
Q719, 720	DTC114ESTP	TRANSISTOR		D908	1SR35200TB	DIODE	△
Q721, 722	2SD1302STTA	TRANSISTOR		D909	1SS254TA	DIODE	
Q723, 724	MSA1048ABCTA	TRANSISTOR		D915	1SS254TA	DIODE	
Q726	DTC114ESTP	TRANSISTOR		D919	1SS254TA	DIODE	
Q830	2SB1236PQRT6	TRANSISTOR		D971A	RVD1SS133TA	DIODE	
Q831	2SD1512R	TRANSISTOR		D971	RVD1SS133TA	DIODE	
Q903	DTA114ESTP	TRANSISTOR				VARIABLE RESISTOR(S)	
Q904	2SB1030QTA	TRANSISTOR					
Q905	MSC2458ABCTA	TRANSISTOR					
Q907-909	DTA114ESTP	TRANSISTOR		VR3-6	EVNDXAA00B24	V. R, PLAYBACK GAIN ADJ.	
Q928	DTA114ESTP	TRANSISTOR		VR7, 8	EVNDXAA00B14	V. R, REC. /PLAY LEVEL ADJ.	
Q929	MSC2458ABCTA	TRANSISTOR		VR301	EVNDXAA00B53	V. R, ERASE CURRENT ADJ.	
Q930	DTA114ESTP	TRANSISTOR		VR302, 303	EVNDXAA00B15	V. R, OVERALL GAIN ADJ.	
Q931	DTC144EKT96	TRANSISTOR		VR721-723	EVNDCAA03B53	V. R, TAPE SPEED ADJ.	


Ref. No.	Part No.	Part Name & Description	Remarks	Ref. No.	Part No.	Part Name & Description	Remarks
		COMPONENT COMBINATION (S)		J5	SJSD1005	CONNECTOR (10P)	
				CN4	RJS1A1704	SOCKET (4P)	
				CN6	RJS1A1704	SOCKET (4P)	
Z800	EXBF10E104J	COMPONENT COMBINATION		CN7	SJTD313	CONNECTOR (3P)	
Z801	EXBF8E104J	COMPONENT COMBINATION		CN9	RJS10Q8ZA	SOCKET (10P)	
		COIL (S)		CN10	RJT055B013	CONNECTOR (13P)	
				CN11, 12	RJT057W012-1	CONNECTOR (12P)	
L1, 2	SLQX303-1KT	COIL		CP1	SJTD413	CONNECTOR (4P)	
L3, 4	SLQX272-1YT	COIL		CP2	RJP5G18ZA	CONNECTOR (5P)	
L102	RLM2B005-1M	COIL		CP9	RJS10Q9ZA	SOCKET (10P)	
L202	RLM2B005-1M	COIL		CP11, 12	RJU057W012	SOCKET (12P)	
L301	SL09B4-K	COIL					
L401, 402	SLQX272-1YT	COIL					
L901	ELEXT101KA9	COIL					
		OSCILLATOR (S)					
X800	EF0GC3004T4	OSCILLATOR					
X901	EF0GC4004A4	OSCILLATOR					
		DISPLAY					
FL1	RSL0088-F	DISPLAY					
		SWITCH (ES)					
S810	EVQ21405R	SW, COUNTER RESET					
S811	EVQ21405R	SW, STOP					
S812	EVQ21405R	SW, MS					
S813	EVQ21405R	SW, MS					
S814	EVQ21405R	SW, PLAY					
S815	EVQ21405R	SW, PLAY					
S816	EVQ21405R	SW, REC PAUSE					
S817	EVQ21405R	SW, DECK 1/2					
S818	EVQ21405R	SW, SYNCHRO START					
S819	EVQ21405R	SW, SEED					
S820	EVQ21405R	SW, DOLBY NR					
S821	EVQ21405R	SW, REVERSE MODE					
S971	RSH1A89Z	SW, MODE (DECK1)					
S971A	RSH1A89Z	SW, MODE (DECK2)					
S972	RSH1A90YB-U	SW, HALF (DECK1)					
S972A	RSH1A90YB-U	SW, HALF (DECK2)					
S973	RSH1A90YB-U	SW, ATS/C-r02 (DECK1)					
S973A	RSH1A90YB-U	SW, R. REC INH (DECK2)					
S974A	RSH1A90YB-U	SW, F. REC INH (DECK2)					
S975A	RSH1A90YB-U	SW, ATS/C-r02 (DECK2)					
S976A	RSH1A90YB-U	SW, ATS/METAL (DECK2)					
		CONNECTOR (S)					
J3	RJS7T4ZA	SOCKET (7P)					

Notes : * Capacity valuse are in microfarads (uF) unless specified otherwise,P=Pico-farads (pF) F=Farads (F)
* Resistance values are in ohms,unless specified otherwise,1K=1,000 (OHM) , 1M=1,000k(OHM)

Ref. No.	Part No.	Values & Remarks	Ref. No.	Part No.	Values & Remarks	Ref. No.	Part No.	Values & Remarks
		RESISTORS	R145	ERDS2TJ153	1/4W 15K	R815	ERDS2TJ122	1/4W 1. 2K
			R146	ERDS2TJ822	1/4W 8. 2K	R816	ERDS2TJ152	1/4W 1. 5K
			R147	ERDS2TJ823T	1/4W 82K	R817	ERDS2TJ182	1/4W 1. 8K
R1, 2	ERDS2TJ393	1/4W 39K	R148	ERDS2TJ331	1/4W 330	R818	ERDS2TJ222	1/4W 2. 2K
R3, 4	ERDS2TJ183T	1/4W 18K	R149	ERDS2TJ332	1/4W 3. 3K	R819	ERDS2TJ332	1/4W 3. 3K
R5, 6	ERDS2TJ562	1/4W 5. 6K	R181	ERDS2TJ102	1/4W 1K	R820	ERDS2TJ472	1/4W 4. 7K
R7, 8	ERDS2TJ223	1/4W 22K	R182	ERDS2TJ222	1/4W 2. 2K	R821	ERDS2TJ682T	1/4W 6. 8K
R9	ERDS2TJ332	1/4W 3. 3K	R183	ERDS2TJ243T	1/4W 24K	R822	ERDS2TJ123	1/4W 12K
R10	ERDS2TJ332	1/4W 3. 3K	R184	ERDS2TJ561	1/4W 560	R823	ERDS2TJ223	1/4W 22K
R11, 12	ERDS2TJ1R0	1/4W 1. 0	R188	ERDS2TJ151	1/4W 150	R824-829	ERDS2TJ221	1/4W 220
R13, 14	ERDS2TJ152	1/4W 1. 5K	R189	ERDS2TJ273	1/4W 27K	R830	ERD2FCVG270T	1/4W 27 △
R15, 16	ERDS2TJ273	1/4W 27K	R281	ERDS2TJ102	1/4W 1K	R831	ERDS1FVJ471T	1/2W 470 △
R17	ERDS2TJ472	1/4W 4. 7K	R282	ERDS2TJ222	1/4W 2. 2K	R832	ERDS2TJ103	1/4W 10K
R19, 20	ERDS2TJ101	1/4W 100	R283	ERDS2TJ243T	1/4W 24K	R833	ERDS2TJ223	1/4W 22K
R21, 22	ERDS2TJ104	1/4W 100K	R284	ERDS2TJ561	1/4W 560	R834-840	ERDS2TJ221	1/4W 220
R23, 24	ERDS2TJ101	1/4W 100	R301	ERDS2TJ1R0	1/4W 1. 0	R901-903	ERDS2TJ103	1/4W 10K
R25, 26	ERDS2TJ225	1/4W 2. 2M	R302, 303	ERDS2TJ183T	1/4W 18K	R904	ERDS2TJ152	1/4W 1. 5K
R27, 28	ERDS2EJ820	1/4W 82	R304, 305	ERDS2TJ100	1/4W 10	R905	ERDS2TJ222	1/4W 2. 2K
R29, 30	ERDS2TJ103	1/4W 10K	R306	ERDS2TJ561	1/4W 560	R906	ERDS2TJ103	1/4W 10K
R31, 32	ERDS2TJ273	1/4W 27K	R308	ERDS2TJ561	1/4W 560	R907	ERDS2TJ563	1/4W 56K
R33, 34	ERDS2TJ183T	1/4W 18K	R403, 404	ERDS2TJ472	1/4W 4. 7K	R908-910	ERDS2TJ103	1/4W 10K
R35, 36	ERDS2TJ474	1/4W 470K	R405, 406	ERDS2TJ682T	1/4W 6. 8K	R911	ERDS2TJ392T	1/4W 3. 9K
R37, 38	ERDS2TJ272T	1/4W 2. 7K	R601, 602	ERDS2TJ472	1/4W 4. 7K	R912	ERDS2TJ272T	1/4W 2. 7K
R39, 40	ERDS2TJ332	1/4W 3. 3K	R603	ERDS2TJ103	1/4W 10K	R913	ERDS2TJ123	1/4W 12K
R41, 42	ERDS2TJ223	1/4W 22K	R604	ERDS2TJ472	1/4W 4. 7K	R914	ERDS2TJ103	1/4W 10K
R43, 44	ERDS2TJ103	1/4W 10K	R605, 606	ERD2FCVJ4R7T	1/4W 4. 7 △	R915	ERDS2TJ683	1/4W 68K
R45, 46	ERDS2TJ223	1/4W 22K	R607	ERDS1FVJ331T	1/2W 330 △	R916	ERDS2TJ472	1/4W 4. 7K
R47, 48	ERDS2TJ472	1/4W 4. 7K	R608	ERDS1FVJ271T	1/2W 270 △	R917, 918	ERDS2TJ103	1/4W 10K
R49, 50	ERDS2TJ821	1/4W 820	R609, 610	ERDS2TJ472	1/4W 4. 7K	R919	ERDS2TJ471	1/4W 470
R51, 52	ERDS2TJ470	1/4W 47	R612	ERD2FCVG150T	1/4W 15 △	R920	ERDS2TJ103	1/4W 10K
R53-56	ERDS2TJ222	1/4W 2. 2K	R614	ERDS2TJ102	1/4W 1K	R923	ERDS2TJ470	1/4W 47
R57, 58	ERDS2TJ103	1/4W 10K	R615, 616	ERDS2TJ101	1/4W 100	R925	ERDS2TJ223	1/4W 22K
R59, 60	ERDS2TJ332	1/4W 3. 3K	R717, 718	ERDS2TJ223	1/4W 22K	R926	ERDS2TJ470	1/4W 47
R61, 62	ERDS2TJ473	1/4W 47K	R719-722	ERDS2TJ821	1/4W 820	R927	ERDS2TJ223	1/4W 22K
R65	ERDS2TJ392T	1/4W 3. 9K	R723, 724	ERDS2TJ184T	1/4W 180K	R928	ERDS2TJ103	1/4W 10K
R66	ERDS2TJ682T	1/4W 6. 8K	R726	ERDS2TJ103	1/4W 10K	R932	ERDS2TJ183T	1/4W 18K
R67	ERDS2TJ223	1/4W 22K	R727	ERDS2TJ153	1/4W 15K	R933	ERDS2TJ223	1/4W 22K
R81, 82	ERDS2TJ683	1/4W 68K	R728	ERDS2TJ392T	1/4W 3. 9K	R934	ERDS2TJ105T	1/4W 1M
R83, 84	ERDS2TJ103	1/4W 10K	R729, 730	ERDS2TJ103	1/4W 10K	R935	ERDS2TJ182	1/4W 1. 8K
R85	ERDS2TJ101	1/4W 100	R731	ERDS2TJ332	1/4W 3. 3K	R936-939	ERDS2TJ103	1/4W 10K
R86	ERDS2TJ473	1/4W 47K	R732	ERDS2TJ392T	1/4W 3. 9K	R940, 941	ERDS2TJ472	1/4W 4. 7K
R87	ERDS2TJ103	1/4W 10K	R733	ERDS2TJ103	1/4W 10K	R943	ERDS2TJ103	1/4W 10K
R93	ERDS2TJ273	1/4W 27K	R734	ERDS2TJ221	1/4W 220	R945	ERDS2TJ822	1/4W 8. 2K
R94	ERDS2TJ123	1/4W 12K	R802	ERDS2TJ102	1/4W 1K	R968, 969	ERDS2TJ472	1/4W 4. 7K
R95, 96	ERDS2TJ153	1/4W 15K	R803	ERDS2TJ103	1/4W 10K	R970	ERDS2TJ681	1/4W 680
R141	ERDS2TJ393	1/4W 39K	R807	ERDS2TJ105T	1/4W 1M	R971	ERDS2TJ391	1/4W 390
R142	ERDS2TJ222	1/4W 2. 2K	R808-811	ERDS2TJ221	1/4W 220	R975	ERDS2TJ331	1/4W 330
R143	ERDS2TJ102	1/4W 1K	R813	ERDS2TJ821	1/4W 820	R977	ERDS2TJ103	1/4W 10K
R144	ERDS2TJ473	1/4W 47K	R814	ERDS2TJ102	1/4W 1K	R979	ERDS2TJ153	1/4W 15K

Ref. No.	Part No.	Values & Remarks	Ref. No.	Part No.	Values & Remarks			
R980, 981	ERDS2TJ393	1/4W 39K	C302	ECEA1CU221	16V 220U			
R984, 985	ERDS2TJ393	1/4W 39K	C303	ECKR1H392KB5	50V 3900P			
R990	ERDS2TJ100	1/4W 10	C304, 305	ECFR1E222KV	25V 2200P			
R994	ERDS2TJ102	1/4W 1K	C306	ECKR1H103ZF5	50V 0. 01U			
R995, 996	ERDS2TJ470	1/4W 47	C307, 308	ECBT1H221KB5	50V 220P			
R998, 999	ERDS2TJ2R7T	1/4W 2. 7	C309	ECKR1H103ZF5	50V 0. 01U			
			C310	ECFR1E682KV	25V 6800P			
		CAPACITORS	C401, 402	ECBT1C152JR5	16V 1500P			
			C403, 404	ECEA1EKA4R7B	25V 4. 7U			
C1-3	ECEA1HKA010B	50V 1U	C410, 411	ECEA1AU471	10V 470U			
C5, 6	ECEA1CU220	16V 22U	C602	ECEA1EU222B	25V 2200U			
C7-9	ECBT1H561KB5	50V 560P	C603	ECEA1EU102B	25V 1000U			
C10	ECBT1H561KB5	50V 560P	C604, 605	ECBT1C103MS5	16V 0. 01U			
C11, 12	ECBT1H102KB5	50V 1000P	C606, 607	ECEA1AU101	10V 100U			
C13, 14	ECEA0JKA101B	6. 3V 100U	C608	ECBT1C103MS5	16V 0. 01U			
C15, 16	ECQB1H682JZ3	50V 6800P	C609	ECEA1AU470	10V 47U			
C17-20	ECEA1EKA4R7B	25V 4. 7U	C610	ECKR1H103ZF5	50V 0. 01U			
C21	ECEA0JKA101B	6. 3V 100U	C611	ECEA1AU470	10V 47U			
C25, 26	ECEA1HKA010B	50V 1U	C701	ECEA1EU101	25V 100U			
C27, 28	ECBT1H561KB5	50V 560P	C721, 722	ECFR1H104ZF	50V 0. 1U			
C29, 30	ECKR2H121KB5	500V 120P	C801-804	ECBT1C103MS5	16V 0. 01U			
C31, 32	ECCR1H181K5	50V 180P	C805	ECEA0JKS101B	6. 3V 100U			
C33, 34	ECEA1HKA47B	50V 0. 47U	C806	ECBT1C103MS5	16V 0. 01U			
C35, 36	ECFR1C272JR	16V 2700P	C830	ECA2AM101B	100V 100U			
C37, 38	ECFR1C183JR	16V 0. 018U	C831	ECEA1VKS470Q	35V 47U			
C39, 40	ECFR1C103JR	16V 0. 01U	C832	ECFR1H104ZF	50V 0. 1U			
C41, 42	ECFR1C333JR	16V 0. 033U	C833	ECA1HM471B	50V 470U			
C45, 46	ECKR1H103ZF5	50V 0. 01U	C834	ECEA1EU221	25V 220U			
C49, 50	ECEA1CKA100B	16V 10U	C835	ECA1JM101B	63V 100U			
C53, 54	ECFR1C222JR	16V 2200P	C836	ECEA1VKA330B	35V 33U			
C55	ECBT1H102KB5	50V 1000P	C901	ECEA0JU102	6. 3V 1000U			
C63	ECEA1CKA100B	16V 10U	C903	ECEA1HKA010B	50V 1U			
C64	ECEA1HN010	50V 1U	C904	ECEA1EKA4R7B	25V 4. 7U			
C65	ECFR1C103JR	16V 0. 01U	C905	ECEA1HSN2R2B	50V 2. 2U			
C70	ECEA1EKA4R7B	25V 4. 7U	C906	ECEA0JU471	6. 3V 470U			
C71, 72	ECBT1C332KR5	16V 3300P	C912	ECKT1H122KB	50V 1200P			
C131	ECEA1HK2R2B	50V 2. 2U						
C132	ECEA1HKA3R3B	50V 3. 3U						
C133	ECCR1H470K5	50V 47P						
C182	ECBT1C682KR5	16V 6800P						
C183	ECBA1H681KB5	50V 680P						
C184, 185	ECBT1C222JR5	16V 2200P						
C186	ECEA1HUR56B	50V 0. 56U						
C187	ECEA1HKR33	50V 0. 33U						
C188	ECEA1EKA4R7B	25V 4. 7U						
C282	ECBT1C682KR5	16V 6800P						
C283	ECBA1H681KB5	50V 680P						
C284, 285	ECBT1C222JR5	16V 2200P						
C286	ECEA1HUR56B	50V 0. 56U						
C287	ECEA1HKR33	50V 0. 33U						
C288	ECEA1EKA4R7B	25V 4. 7U						
C301	ECQP1153JZ	100V 0. 015U						

MECHANISM PARTS LOCATION •DECK 1




Note:
When changing mechanism parts, apply the specified grease to areas marked "XX" as shown in the drawing.

Ref. No.	Part Name	Part No.
Ⓐ	FLOIL AK-152	SZZOL 18
Ⓑ	FLOIL 947P	RZZOL 02


Ref. No.	Part No.	Part Name & Description	Remarks	Ref. No.	Part No.	Part Name & Description	Remarks
		MECHANISM PARTS LIST		144	RUB509ZA	LEVER	
(DECK1)				145	RDV108ZA	CAPSTAN BELT	
101	RXQ0051-1	HEAD BLOCK(PLAY)		148	RUW144ZA	SPRING	
102	RUA793ZF	HEAD BASE		149	RHG3032ZA	RUBBER CUSHION	
103	RZLAR300A	ROD		150	RNL180ZB	DAMPER ARM	
103-1	RUW143ZA	SPRING		151	REX0132	LEAD WIRE (4P)	
104	1UB0089ZA	ARM		161	XTW2+6L	SCREW	
104-1	RUW148ZA	SPRING		162	XTW2+8L	SCREW	
105	1DM0018ZB	REEL TABLE (R)		163	XTN26+7J	SCREW	
106	1DM0017ZB	REEL TABLE (F)		164	RHE5203ZA	SCREW	
107	RML0069-1	LEVER		165	XTW2+8S	SCREW	
108	RDG5772ZC	GEAR		166	XYC2+JF16	SCREW	
109	RUB508ZB	BRACKET ROD		167	RHD26002	SCREW	
110	RUB506ZB	LEVER		168	RJS7T7ZA	CONNECTOR(7P) J971	
111	1UB0088ZB	ARM (R)					
111-1	RUW141ZA	SPRING					
112	1UB0087ZB	ARM (F)					
112-1	RUW140ZC	SPRING					
114	RNL1ZD	DAMPER ARM					
115	RUB503ZD	MAIN LEVER					
116	RFKRRSCH9N	CHASSIS ASS'Y					
117	RUW142ZA	SPRING					
118	RUD105ZA	SPRING					
120	RUW139ZA	SPRING					
121	RFKPRSCH9N	DC MOTOR ASS'Y					
122	1UE0015ZB	PLUNGER					
123	RUB428ZE	MOVING IRON CORE					
124	RMA0101	ANGLE					
125	RMD5014ZC	ANGLE					
126	RDG5927ZG	MAIN GEAR					
127	1DW0037ZB	FLYWHEEL (F)					
127-1	RNW139ZA	WASHER					
128	1DW0038ZB	FLYWHEEL (R)					
128-1	RNW138ZA	WASHER					
129	1DG0006ZB	REEL TABLE GEAR					
130	RUB513ZD	ARM					
131	1UB0091ZA	LEVER					
131-1	RUW146ZA	SPRING					
132	1DR0011ZB	MAIN PULLEY					
133	RDV90ZB	BELT					
134	RDG5769ZA	REEL TABLE GEAR					
135	RUQ111ZB	SPRING					
136	RUW145ZA	SPRING					
137	1UB0090ZA	ROD					
137-1	RUB512ZB	ROD					
138	RDG5773ZB	GEAR					
139	RUQ112ZA	SPRING					
140	RUS609ZC	TAPE PRESSURE SPRING					
141	RUB514ZC	LEVER					
142	RUW147ZA	SPRING					
143	RUB515ZA	LEVER					

Ref. No.	Part No.	Part Name & Description	Remarks	Ref. No.	Part No.	Part Name & Description	Remarks
		MECHANISM PARTS LIST		243	RUB515ZA	LEVER	
(DECK2)				244	RUB509ZA	LEVER	
201	RXQ0161	HEAD BLOCK (REC/PLAYBACK)		245	RDV108ZA	CAPSTAN BELT	
202	RUA793ZF	HEAD BASE		249	RHG3032ZA	RUBBER CUSHION	
203	RZLAR300A	ROD		250	RNL180ZB	DAMPER ARM	
203-1	RUW143ZA	SPRING		251	REX017Z	LEAD WIRE (5P)	
204	1UB0089ZA	ARM		261	XTW2+6L	SCREW	
204-1	RUW148ZA	SPRING		262	XTW2+8L	SCREW	
205	1DM0018ZB	REEL TABLE (R)		263	XTN26+7J	SCREW	
206	1DM0017ZB	REEL TABLE (F)		264	RHE5203ZA	SCREW	
207	RML0069-1	LEVER		265	XTW2+8S	SCREW	
208	RDG5772ZC	GEAR		266	XYC2+JF16	SCREW	
209	RUB508ZB	BRAKET ROD		267	RHD26002	SCREW	
210	RUB506ZB	LEVER		268	RJS1077ZA	CONNECTOR(10P) J971A	
211	1UB0088ZB	ARM(R)		269	REX0145	LEAD WIRE ASS'Y	
211-1	RUW141ZA	SPRING					
212	1UB0087ZB	ARM(F)					
212-1	RUW140ZC	SPRING					
214	RNL1ZD	DAMPER ARM					
215	RUB503ZD	MAIN LEVER					
216	RFKRRSCH9N	CHASSIS ASS'Y					
217	RUW142ZA	SPRING					
218	RUD105ZA	SPRING					
219	RUW144ZA	SPRING					
220	RUW139ZA	SPRING					
221	RFM133ZA	DC MOTOR					
222	1UE0015ZB	PLUNGER					
223	RUB428ZE	MOVING IRON CORE					
224	RMA0101	ANGLE					
225	RMD5014ZC	ANGLE					
226	RDG5927ZG	MAIN GEAR					
227	1DW0037ZB	FLYWHEEL (F)					
227-1	RNW139ZA	WASHER					
228	1DW0038ZB	FLYWHEEL (R)					
228-1	RNW138ZA	WASHER					
229	1DG0006ZB	REEL TABLE GEAR					
230	RUB513ZD	ARM					
231	1UB0091ZA	LEVER					
231-1	RUW146ZA	SPRING					
232	1DR0011ZB	MAIN PULLEY					
233	RDV90ZB	BELT					
234	RDG5769ZA	REEL TABLE GEAR					
235	RUQ111ZB	SPRING					
236	RUW145ZA	SPRING					
237	1UB0090ZA	ROD					
237-1	RUB512ZB	ROD					
238	RDG5773ZB	GEAR					
239	RUQ112ZA	SPRING					
240	RUS609ZC	TAPE PRESSURE SPRING					
241	RUB514ZC	LEVER					
242	RUW147ZA	SPRING					

MECHANISM PARTS LOCATION •DECK 2



■ CABINET PARTS LOCATION



[illegible]

Service Manual

Compact Disc Player




Compact Disc Player

SL-CH7

Color

(K) Black Type



Areas

Country Code	Area	Color
(E)	Continental Europe.	(K)
(GC)	Third Region	

System: SC-CH7

NEW MECHANISM SERIES (S0DD110Z)

Because of unique interconnecting cables,
when a component requires service, send or
bring in the entire system.

SPECIFICATIONS

(DIN 45 500)

AUDIO

Frequency response 2 Hz~20 kHz
(±1 dB)

Wow and flutter Below measurable limit

PICKUP

Wavelength 780 nm

GENERAL

Power consumption 17 W

Dimensions (W×H×D) 215×55×295 mm
(8¹⁵/₃₂"×2⁵/₃₂"×11⁵/₁₆")

Weight 2.0 kg (4.4 lb.)

Notes:

1. Total harmonic distortion is measured by the digital spectrum analyzer.
2. Specifications are subject to change without notice.
3. Weight and dimensions shown are approximate.

System	Tuner	Amplifier	CD player	Cassette Deck	Speakers
SC-CH7	ST-CH7L	SU-CH7	SL-CH7	RS-CH7	SB-CH7

Technics / Panasonic
(E) (GC)

■ CONTENTS

	Page
PRECAUTION OF LASER DIODE	2
LOCATION OF CONTROLS	2, 3
HANDLING PRECAUTIONS FOR TRAVERSE DECK	4
DISASSEMBLY INSTRUCTIONS	4~9
SCHEMATIC DIAGRAM	10~15
PRINTED CIRCUIT BOARDS	16, 17
WIRING CONNECTION DIAGRAM	18
BLOCK DIAGRAM	19~21
DIGITAL SERVO SYSTEM	22, 23

	Page
CHECKING THE OPERATION PROBLEMS ON THE TRAVERSE DECK (OPTICAL PICKUP)	24, 25
MEASUREMENTS AND ADJUSTMENTS	25, 26
TROUBLESHOOTING GUIDE	27, 28
DESCRIPTION OF FL PANEL	29
FUNCTIONS OF IC TERMINALS	30~34
REPLACEMENT PARTS LIST	35~38, 41
CABINET PARTS LOCATION	39, 40
CABINET PARTS LOCATION (Loading unit parts)	41

■ PRECAUTION OF LASER DIODE

CAUTION: This product utilizes a laser diode with the unit turned "on", invisible laser radiation is emitted from the pick up lens.
Wave length: 780 nm
Maximum output radiation power from pick up: 100 μ W/VDE

Laser radiation from the pick up lens is safety level, but be sure the followings:

1. Do not disassemble the optical pick up unit, since radiation from exposed laser diode is dangerous.
2. Do not adjust the variable resistor on the pickup unit. It was already adjusted.
3. Do not look at the focus lens using optical instruments.
4. Recommend not to look at pick up lens for a long time.

ACHTUNG: Dieses produkt enthält eine laserdiode. Im eingeschalteten zustand wird unsichtbare laserstrahlung von der lasereinheit abgestrahlt.

Wellenlänge: 780 nm
Maximale strahlungsleistung der lasereinheit: 100 μ W/VDE

Die strahlung an der lasereinheit ist ungefährlich, wenn folgende punkte beachtet werden:

1. Die lasereinheit nicht zerlegen, da die strahlung an der freigelegten laserdiode gefährlich ist.
2. Den werksseitig justierten einstellregler der lasereinheit nicht verstellen.
3. Nicht mit optischen instrumenten in die fokussierlinse blicken.
4. Nicht über längere zeit in die fokussierlinse blicken.

ADVARSEL: I dette a apparat anvendes laser.


ADVARSEL: USYNLIG LASERSTRÅLING VED ÅBNING, NÅR SIKKERHEDSAF-BRYDERE ER UDE AF FUNKTION. UNDGÅ UDSÆTTELSE FOR STRÅLING.

VORSICHT-Usichtbare Laserstrahlung, wenn Abdeckung geöffnet. Nicht dem Strahl aussetzen. RQLS0021

DANGER-Invisible laser radiation when open. AVOID DIRECT EXPOSURE TO BEAM.

VARO! Avattaessa ja suojalukitus ohitettaessa olet alttiina näkymättömälle lasersäteilylle. Älä katso säteeseen.


WARNING! Osynlig laserstråling når denna del är öppnad och spårren är urkopplad. Betrakta ej strålen. RQLS0051



Note:


Refer to the service manual for Model No. SU-CH7, Order No. AD9104082C8 for information on ACCESSORIES. INSTALLATION OF THE SYSTEM, CONNECTIONS and PACKAGING.

■ DISASSEMBLY INSTRUCTIONS



Compact disc player: control section

- ① **Skip buttons (◀◀ SKIP ▶▶)**
Press one of these buttons briefly to move the pickup (backward and forward) to the beginning of a specific track.
- ② **Pause button (|| PAUSE)**
- ③ **Disc tray open/close button (▲ OPEN, ▲ OPEN/CLOSE)**
Used for opening and closing the disc tray.
- ④ **AI edit-recording button (AI)**
This button is used to make an AI edit-recording.
- ⑤ **Edit mode button (NORMAL/TAPE LENGTH)**
This button can be used to choose one of the edit modes or to specify the tape length to be used.
- ⑥ **Search buttons (◀◀ SEARCH ▶▶)**
Use these buttons to move the pickup forward and backward.
- ⑦ **Stop button (□)**
- ⑧ **Play button (▶)**



Compact disc player: display section

- a **Link indicator (LINK)**
Illuminates when the unit is in a condition the disc link is possible.
- b **Edit indicator (EDIT)**
Illuminates when edit-recording a CD.
- c **Disc indicator (DISC)**
Illuminates when a disc has been loaded.
- d **Multi-display**
This display shows the track number and elapsed play time of the current track, or the remaining time of the tape while the unit is in the CD-edit mode. ("SIDE A" or "SIDE B" illuminates.)
- e **Fade end indicator (FADE END)**
Illuminates when the unit is normal edit mode, and illuminates to show fading at the end of the tape.
- f **Repeat indicator (↺)**
Illuminates when the repeat mode is activated.
- g **Auto space indicator (AUTO SPACE)**
Illuminates during edit-recording of compact discs, and shows that the auto space function is activated.
- h **Pause indicator (||)**
Illuminates when the pause mode is activated.
- i **Play indicator (▶)**
Illuminates when the play mode is activated.
- j **Program cancel indicator (CANCEL)**
Illuminates when the programmed track can be cancelled.
- k **Program play indicator (PROGRAM)**
Illuminates during program play.
- l **AI edit-recording indicator (AI)**
Illuminates when AI edit-recording mode is activated.
- m **Tape side indicator (▶ A, ▶ B)**
Shows the tape side (A or B) to be recorded on when performing the edit-recording of compact disc.
- n **Track number indicator (1-20)**
Shows the number of tracks.
- o **"Over" mark (▶)**
This indicator illuminates if the total number of tracks on the disc is 21 or more.
- p **Peak search indicator (PEAK SEARCH)**
Illuminates while the CD player automatically scans for the peak level on the CD.
When peak search ends, "PEAK" flashes to indicate the peak level.

■ HANDLING PRECAUTIONS FOR TRAVERSE DECK

The laser diode in the traverse deck (optical pickup) may break down due to potential difference caused by static electricity of clothes or human body.

So, be careful of electrostatic breakdown during repair of the traverse deck (optical pickup).

● Handling of traverse deck (optical pickup)


1. Do not subject the traverse deck (optical pickup) to static electricity as it is extremely sensitive to electrical shock.
2. To prevent the breakdown of the laser diode, an anti-static shorting pin is inserted into the flexible board (FPC board). When removing or connecting the short pin, finish the job in as short time as possible.
3. Take care not to apply excessive stress to the flexible board (FPC board).
4. Do not turn the variable resistor (laser power adjustment). It has already been adjusted.

● Grounding for electrostatic breakdown prevention

1. Human body grounding
Use the anti-static wrist strap to discharge the static electricity from your body.
2. Work table grounding
Put a conductive material (sheet) or steel sheet on the area where the traverse deck (optical pickup) is placed, and ground the sheet.

Caution:

The static electricity of your clothes will not be grounded through the wrist strap. So, take care not to let your clothes touch the traverse deck (optical pickup).



■ LOCATION OF CONTROLS

Warning: This product uses a laser diodes. Refer to caution statements on page 2.

ACHTUNG: ●Die lasereinheit nicht zerlegen.

●Die lasereinheit darf nur gegen eine vom hersteller spezifizierte einheit ausgetauscht werden.





“ATTENTION SERVICER”




Some chassis components may have sharp edges. Be careful when disassembling and servicing.

Ref. No. 1	Removal of the Cabinet	Ref. No. 2	Removal of the Power Transformer
Procedure 1	●Remove 5 screws (①~⑤).	Procedure 1→2	1. Remove 2 screws (①, ②). 2. Remove the connector (CN11) in the direction of arrow.

Ref. No. 3	Removal of the Front Panel Unit		
Procedure 1→3			
1. Push the rack gear slowly in the direction of the arrow until the disc tray comes up. 2. Remove the 2 claws and then the ornament plate in the direction of arrow C. 5. Remove the connector (CN601). 6. Remove the screws (1, 2). 7. Remove the front panel unit in the direction of arrow E. 4. Push the disc tray in the direction of the arrow D to insert it in the unit.			
Ref. No. 4	Removal of the Loading Unit		
Procedure 1→3→4			
1. Remove 2 connectors (CN301, CN302). 2. Remove 4 screws (1-4).			
Ref. No. 5	Removal of the Front Panel		
Procedure 1→3→5			
1. Remove the spring. 2. Push the claw in the direction of arrow A and then remove the front panel in the direction of arrow B.			

Ref. No. 6	Removal of the Operation P.C.B.		
Procedure 1→3→5→6	Rear panel Operation P.C.B.		
1. Remove 4 screws (❶~❹). 2. Remove the rear panel in the direction of arrow A. 3. Remove the operation P.C.B. in the direction of arrow B.			
Ref. No. 7	Removal of the Main P.C.B.	Ref. No. 8	Removal of the Disk Clamper
Procedure 1→2→3→7	Main P.C.B. CN301 CN302	Procedure 1→3→8	Disk clamper
1. Remove 3 screws (❶~❸). 2. Remove 2 connectors (CN301, CN302).		● Remove 3 screws (❶~❸).	
Ref. No. 9	Removal of the Magnet and Holder	Ref. No. 10	Removal of the Guide Shaft and Guide Shaft Holder
Procedure 1→3→8→9	Yoke Magnet Claws Disk holder	Procedure 1→3→4→8→10	Guide shaft Guide holder
● Remove 3 claws.		1. Remove 3 screws (❶~❸). 2. Remove the guide shaft and guide shaft holder in the direction of arrow.	

Ref. No. 11	Removal of the Disk Tray
Procedure 1→3→4→8→ 10→11	
 1. Move the lever in the direction of arrow ① until the traverse unit goes down and the disc tray slightly slides in the direction of arrow ②. 2. Slide the disc tray in the direction of arrow ②. 3. Remove the disc tray in the direction of arrow ③.	
Ref. No. 12	Removal of the Lever (A)
Procedure 1→3→4→8→ 10→11→12	
 1. Remove the spring. 2. Push the claw in the direction of arrow.	
Ref. No. 13	Removal of the Servo P.C.B.
Procedure 1→3→4→13	
 1. Remove 2 screws. (①, ②). 2. Remove 2 claws. 3. Remove the servo P.C.B. in the direction of arrow. 4. Remove 2 connectors (CP702, CP703). 5. Remove the F.P.C. board (S701).	
 • Removal of the FPC board Push the top of the connector in the direction of the arrow ①, and then pullout the flat cable. Note: Insert a short pin into the traverse deck's F.P.C. board.	


Ref. No. 14	Removal of the Loading P.C.B. and Loading Motor.
Procedure 1→3→4→8→ 10→11→12→14	
 1. Remove the belt. 2. Remove 2 screws (①, ②). 3. Remove the screw (③). 4. Unsolder the 2 terminal of loading motor.	
Ref. No. 15	Removal of the Traverse Unit
Procedure 1→3→4→8→ 10→11→13→15	
 1. Release the cables from the code claspers. 2. Remove 2 pin in the direction of arrow. 3. Remove the claw and remove the traverse unit in the direction of arrow.	
Ref. No. 16	Removal of the Traverse Chassis and Lever B
Procedure 1→3→4→8→ 10→11→12→13→ 15→16	
 ■ Remove the traverse chassis. 1. Push the claw (A) in the direction of arrow ①, and then move the slider (A) in the direction of arrow ②. 2. Push 2 claws (B) in the direction of arrow ③, and then remove the traverse chassis. ■ Remove the lever (B) 1. Push the claw (A) in the direction of arrow ①, and then move the lever (A) in the direction of arrow ②. 2. Remove the spring. 3. Remove the lever (B) in the direction of arrow ④.	


Ref. No. 14	Removal of the Loading P.C.B. and Loading Motor.
Procedure 1→3→4→8→ 10→11→12→14	1. Remove the belt. 2. Remove 2 screws (①, ②). 3. Remove the screw (③). 4. Unsolder the 2 terminal of loading motor.
Ref. No. 15	Removal of the Traverse Unit
Procedure 1→3→4→8→ 10→11→13→15	1. Release the cables from the code clamps. 2. Remove 2 pin in the direction of arrow. 3. Remove the claw and remove the traverse unit in the direction of arrow.
Ref. No. 16	Removal of the Traverse Chassis and Lever B
Procedure 1→3→4→8→ 10→11→12→13→ 15→16	■ Remove the traverse chassis. 1. Push the claw (A) in the direction of arrow ①, and then move the slider (A) in the direction of arrow ②. 2. Push 2 claws (B) in the direction of arrow ③, and then remove the traverse chassis. ■ Remove the lever (B) 1. Push the claw (A) in the direction of arrow ①, and then move the lever (A) in the direction of arrow ②. 2. Remove the spring. 3. Remove the lever (B) in the direction of arrow ④.

Ref. No. 17	Removal of the Slider (A) and Slider (B)
Procedure 1→3→4→8→ 10→11→12→ 13→15→16→17	■ Removal of the slider (A) ● Move the slider (A) in the direction of arrow ①, and remove the load (A) in the direction of arrow ②. ■ Removal of the slider (B) ● Push the claw in the direction of arrow ③, and remove the slider (B) in the direction of arrow ④.
Ref. No. 18	Check of the Main P.C.B.
Procedure 1→3→18	1. Remove 5 screws (①~⑤). 2. Connect the flat cable to CN601 as shown in figure. 3. Connect the G.N.D. terminal to the chassis by the lead wire. 4. Check the main P.C.B. as shown in the figure.
Ref. No. 19	Check of the Operation P.C.B. and Servo P.C.B
Procedure 1→3→5→6→ 19	To play disk 1. push S601 so that the disc tray comes up. 2. Place the test disk on the tray. Then, push S604 to set the test disc. 3. Push S604 to start the test disk play. 1. Connect the flat cable to CN601 as shown in Fig. 1. 2. Remove 2 screws (①~④). 3. Place the loading unit sideways as shown in Fig. 2. Note: Make sure not to damage the flat cable. 4. Detach the operation P.C.B. and the servo P.C.B. as shown in Figure.

SCHEMATIC DIAGRAM (Parts list on pages 35~38)

A SERVO CIRCUIT





- Notes:
- S601 : Disk tray open/close switch.
 - S602 : Pause switch.
 - S603 : Stop switch.
 - S604 : Play switch.
 - S605, 606 : Skip switch.
(S605: ◀◀, S606: ▶▶)
 - S607, 608 : Search switch.
(S607: ◀◀, S608: ▶▶)
 - S612 : Edit mode switch (NORMAL/TAPE LENGTH).
 - S613 : AI edit recording switch.
 - S701 : Reset switch.
 - S790, 791 : Desk tray open/close detection switch.

•Indicated voltage values are the standard values for the unit measured by the DC electronic circuit tester (high-impedance) with the chassis taken as standard. Therefore, there may exist some errors in the voltage values, depending on the internal impedance of the DC circuit tester.

•The parenthesized are the values of voltage generated during playing (Test disc 1 kHz, L+R 0 dB), others are voltage values in stop mode.

- Positive voltage line
- Negative voltage line
- CD signal line

•Important safety notice:
Components identified by Δ mark have special characteristics important for safety. When replacing any of these components, use only manufacturer's specified parts.

•This schematic diagram may be modified at any time with the development of new technology.


•Caution!
IC and LSI are sensitive to static electricity.
Secondary trouble can be prevented by taking care during repair.

- Cover the parts boxes made of plastics with aluminum foil.
- Ground the soldering iron.
- Put a conductive mat on the work table.
- Do not touch the legs of IC or LSI with the fingers directly.

•The supply part number is described alone in the replacement parts list.

Ref No.	Production Parts No.	Supply Parts No.
IC1	LM2940T5M	LM2940T5
IC801	BA4558F	SVIBA4558FT1

■ SCHEMATIC DIAGRAM (Parts list on pages 35~38)



5

6

7

8

9




10

11

12



13

14


C MOTOR/SWITCH CIRCUIT**D** MAIN CIRCUIT**E** POWER TRANSFORMER CIRCUIT

■ WIRING C



TP702



BA4558FT1 	TCA0372DM2R 	MN6475 	AN8800SCE2 		MN6626 MN1554PKL1 MN187204PKW	MN6650 	AN8377N 		
LM2940T5M 	DTA114ESTP DTC114ESTP DTA124ESTP DTC124ESTP DTC144ESTP 2SA933SQRSTA			2SC1740SQSTA 2SD2144STA		2SB1238QSTV6 2SD1862QRTV6 	2SD2037EFTA 	1SS254TA 1SR35200TB 	MA4270MTA
1. Vin 2. GND 3. Vout								Ca カソード A アノード	Ca カソード A アノード




SPINDLE MOTOR





TRAVERSE MOTOR

■ WIRING CONNECTION DIAGRAM



BLOCK DIAGRAM






DIGITAL SERVO SYSTEM

The newly-developed digital servo system is adopted in the servo circuit of the unit's CD player instead of the ordinary analog servo system.


1. The diagrams shown below represent differences between the analog servo and digital servo systems. The HEAD AMP. output signals (i.e., focus error and tracking error output signals) are analog. These analog signals are converted to the 8-bit digital signals through the MN6650. The MN6650 performs the following adjustments automatically; focus offset, tracking offset, focus gain, tracking gain, and tracking balance adjustments. The outputs from the MN6650 such as the focus coil driving signal, tracking coil driving signal, and traverse motor driving signal are converted to analog signals again and sent to the coils and motor to perform proper servo control for a disc.



2. The servo processor IC MN6650 of the newly-developed digital servo circuit automatically performs the following adjustments which were originally adjusted in the conventional analog servo circuit:
(1) Focus offset, (2) Tracking offset, (3) Focus gain, (4) Tracking gain, and (5) Tracking balance. Therefore, you do not have to perform not the above-mentioned electrical adjustments manually. Only the best eye (PD balance) needs to be adjusted adjustment. You can obtain an optimum servo control for a disc to be played.
[You must perform the best eye (PD balance) adjustment manually.]

The following flow chart shows the sequence of automatic adjustments.


Flow chart on automatic adjustment sequence



2. The servo processor IC MN6650 of the newly-developed digital servo circuit automatically performs the following adjustments which were originally adjusted in the conventional analog servo circuit:
(1) Focus offset, (2) Tracking offset, (3) Focus gain, (4) Tracking gain, and (5) Tracking balance. Therefore, you do not have to perform not the above-mentioned electrical adjustments manually. Only the best eye (PD balance) needs to be adjusted adjustment. You can obtain an optimum servo control for a disc to be played.
[You must perform the best eye (PD balance) adjustment manually.]

The following flow chart shows the sequence of automatic adjustments.

- **Flow chart on automatic adjustment sequence**



<CD SECTION>

■ CHECKING THE OPERATION PROBLEMS ON THE TRAVERSE DECK (OPTICAL PICKUP)

Make sure to follow the procedures below to check the operation problems of the traverse deck (optical pickup) before replacing it. Replace the traverse deck only after the problem is identified.

(Procedure No.)	(Checking Points)	(Cause)	(Testing Procedure)
	Starting the reading operation (TOC).		
1.	Does the laser light up?	Faulty laser (Worn out)	Check if the output is minimum 0.5 Vp-p at the test point.
2.	Is focus search executed? (Check if lens moves up and down.)	Broken or shorted focus coil	Check if conductance on both ends of coil with the tester at about 30 ohms. (The lens will slightly move up and down during the checking.)
	The turntable rotates.		
3.	Tracking ON.	Broken or shorted tracking coil	Check if conductance on both ends of coil with the tester at about 30 ohms. (The lens will slightly move to the right or left during the checking.)
4.	RF signal output	Faulty PD (PHOTO DETECTOR)	Check if the output is minimum 0.5 Vp-p at the test point.
	Traverse deck (optical pickup) is normal.		
	Traverse deck (optical pickup) is faulty.		

※Replace traverse deck.

- Check electrical circuit.
- CD is not adjusted properly. Adjust CD again.
 - (1) Mechanical adjustment.
 - (2) Focus balance adjustment (PD balance) } Refer to page 26
- Check for flaws on disc or if it is warped or not centered.

※ Checking Operations of Replaced Traverse Deck (New Traverse Deck)

a) Check the operations described below on the traverse deck after replacing it.

* Checking Skip Search

1. Play an ordinary musical program disc.
2. Press the skip button to check for normal skip search operation (in both the forward and reverse directions).

* Checking Manual Search

1. Play an ordinary musical program disc.
2. Press the manual search button to check for smooth manual search operations at either low or high speed (in both the forward and reverse directions).

* Checking Using Defect Disc.

1. Play the 0.7 mm black dot and the 0.7 mm wedge on the defect test disc (SZZP1054C) and verify that no sound skip or noise occurs.
2. Play the middle tracks of the uneven test disc (SZZP1056C) and verify that no sound skip or noise occurs.

b) If the operations are normal, CD adjustment are not required when the traverse deck is replaced.

Note: CD adjustments are required in the cases below. (Mechanical adjustments are not necessary.)

(See item 1–3 on page 26.)

- If audio is not played back continuously or noises occur after step (a) is executed.
- If the adjustment VRs (VR701) were rotated before the traverse deck was replaced.
- If the ICs in the servo circuit or adjustment VRs were replaced.

■ MEASUREMENTS AND ADJUSTMENTS

Caution:

- It is very dangerous to look at or touch the laser beam. (Laser radiation is invisible.) With the unit turned "on", laser radiation is emitted from the pickup lens. Avoid exposure to the laser beam, especially when performing adjustments.



This CD player is powered by the amplifier (SU-CH7). To adjust it or check operations as a separate unit, follow the steps below.

1. Apply a power supply voltage of AC 23 V to **TP1** and **TP2**.
2. Short-circuit **TP1** and Chassis (GND). (POWER supply switch: ON.)

HOW TO CONNECT

Note:

Apply a power supply voltage of AC 20 V to **TP1** and **TP2** by using a Voltage Controller. If it is not available, use a Power Supply Fixture (Continental Europe: SZZA1062C, Great Britain: SZZA1063C) instead.



ADJUSTMENT POINT

- Please refer to Circuit Board Diagram for test point location




Fig. 1




Fig. 2

Caution:

- It is very dangerous to look at or touch the laser beam. (Laser radiation is invisible.) With the unit turned "on", laser radiation is emitted from the pickup lens. Avoid exposure to the laser beam, especially when performing adjustments.

Measuring Instruments and Special Tools

• Test disc

1. Playability test disc (SZZP1054C)
2. Uneven test disc (SZZP1056C)

• Allen wrench (M2.0) (SZZP1101C)

• Oscilloscope

(1) MECHANICAL ADJUSTMENT


- When the traverse deck is replaced, making adjustments is not necessary. (The traverse deck ass'y is already adjusted.)
- Make adjustments to improve playability when the traverse deck has not been replaced. Make the electrical adjustments first.

1. Connect the oscilloscope's CH. 1 probe across **TP702** (+) and **TP703** (V-REF) on the Servo P.C.B.

Oscilloscope setting:

VOLT 200 mV
SWEEP 0.5 μ sec
Input coupling AC

2. Switch the player power ON, and play track 19 on the test disc (SZZP1056C).
3. Leave the player in Play mode and place it as shown in the figure on the right.
4. Alternately adjust the two mechanical adjusting screws with the 2.0 mm allen wrench (SZZP1101C) until the RF signal amplitude variation on the oscilloscope is minimized. (Shown in Fig. 2)
5. After completing the adjustment, lock the mechanical adjustments with lock paint (RZZOL01).



Ⓐ Minimize the variation of amplitude.


(2) BEST EYE (PD BALANCE) ADJUSTMENT

1. Connect the oscilloscope's CH. 1 probe across **TP702** (+) and **TP703** (V-REF) on the Servo P.C.B.

Oscilloscope setting:

VOLT 200 mV
SWEEP 0.5 μ sec
Input coupling AC

2. Switch the player power ON, and play the 1 kHz (track 1) on test disc (SZZP1054C).
3. Adjust VR701 until the RF signal eye pattern amplitude is maximized.



Ⓑ Maximize the amplitude

(3) CHECK OF PLAY OPERATION AFTER ADJUSTMENT

*Checking Skip Search

1. Play an ordinary musical program disc.
2. Press the skip button to check for normal skip search operation (in both the forward and reverse directions).


*Checking Manual Search

1. Play an ordinary musical program disc.
2. Press the manual search button to check for smooth manual search operations at either low or high speed (in both the forward and reverse directions).

*Checking Playability


1. Play the 0.7 mm black dot and the 0.7 mm wedge on the test disc (SZZP1054C) and verify that no sound skip or noise occurs.
2. Play the middle tracks of the uneven test disc and verify that no sound skip or noise occurs.

TROUBLESHOOTING GUIDE



DESCRIPTION OF FL PANEL

•Grid assianment



•Pin connection

Pin No.	5	5	5	5	5	4	4	4	4	4	4	4	4	4	3	3	3	3	3	3	3	3	2	2	2	2	2	2	2	2	1	1	1
Connection	F	F	N	N	N	1	2	3	4	5	6	7	8	9	1	P	P	P	P	P	P	P	N	N	N	N	N	N	N	N	N	N	N
	2	2	P	P	P	G	G	G	G	G	G	G	G	G	G	6	5	4	3	2	1	0	P	P	P	P	P	P	P	P	P	P	P

Pin No.	1	1	1	1	1	1	1	0	9	8	7	6	5	4	3	2	1
Connection	P	P	P	P	P	P	P	N	N	N	N	N	N	N	N	F	F
	5	6	7	4	3	2	1	P	P	P	P	P	P	P	P	1	1

•Anode connection

	10G	9G	8G	7G	6G	5G	4G	3G	2G	1G
P1	▷ (A)	a	a	a	a	a	a	a	a	▷
P2	▷ (B)	b	b	b	b	b	b	b	b	□ □
P3	LINK	c	c	c	c	c	c	c	c	↻
P4	DISC	d	d	d	d	d	d	d	d	↘
P5	AI	e	e	e	e	e	e	e	e	▷
P6	EDIT	f	f	f	f	f	f	f	f	/
P7	—	g	g	g	g	g	g	g	g	CANCEL
P8	—	TRACK	MIN	NO.	SEC	SEARCH	MIN		SEC	—
P9	—	—	—	—	—	PEAK	—	—	FADE END	—
P10	SIDE A	—	:	—	SIDE B	—	:	—	AUTO SPACE	PROGRAM
P11	(1)	(3)	(5)	(7)	(9)	(11)	(13)	(15)	(17)	(19)
P12	1	3	5	7	9	11	13	15	17	19
P13	(1)	(3)	(5)	(7)	(9)	(11)	(13)	(15)	(17)	(19)
P14	(2)	(4)	(6)	(8)	(10)	(12)	(14)	(16)	(18)	(20)
P15	2	4	6	8	10	12	14	16	18	20
P16	(2)	(4)	(6)	(8)	(10)	(12)	(14)	(16)	(18)	(20)

FUNCTIONS OF IC TERMINALS

•IC401 (MN1554PKL1)

Pin No.	Mark	I/O Division	Function
1	MUTE RELAY	—	(Not used, open)
2	PLUNGER	—	(Not used, open)
3	SYNĊ	—	(Not used, open)
4	SIRQ	I	(Not used, connected to power supply)
5	BLKCK	I	Sub-code block clock signal (f BLKCK=75 Hz)
6	SQCK	O	External clock for sub-code Q resistor
7	SBO	—	(Not used, open)
8	SUB Q	I	Sub-code Q code input
9	RESET	I	Reset input
10	CLOSE SW	I	Disc holder "close" detection
11	OPEN SW	I	Disc holder "open" detection
12	REST SW	I	Reset switch signal input
13	NC	—	Not connected
14	CLOSE	O	Loading motor "close" command
15	OPEN	O	Loading motor "open" command
16 └ 24	NC	—	Not connected (Pin 17 is connected to GND)
25	V _{DD}	I	Power supply
26 └ 30	NC	—	Not connected (Pin 29, 30 is connected to GND)
31	FUTA SW	—	(Not used, connected to resistance)
32	MODE	—	(Not used, connected to GND)
33	STAT	I	Status signal (CRC, CVE, CLVS, TTSTOP, FCLV, SQOK)

Pin No.	Mark	I/O Division	Function
34	TLOCK	I	Tracking servo pull-in signal (L: pull-in)
35	FLOCK	I	Focas servo pull-in signal (L: pull-in)
36	SENSE	I	Sense signal
37	RECV	I	External data receipt command signal
38	SEND	I	External data transmission command signal
39	ACK	I	Data discrimination signal
40	CLK	I	Data lock signal
41 └ 44	DATA 0 └ DATA 3	O	Key scan signal
45 └ 52	NC	—	Not connected
53	OSC 2	I	Clock terminal (4.2336 MHz)
54	OSC 1		
55	X1	—	(Not used, open)
56	X0	—	(Not used, open)
57	GND	—	GND
58	DMUTE	O	Muting output (Hi mute)
59	MDATA	O	Micro computer command data output
60	MCLK	O	Micro computer command clock signal output
61	MLD	O	Micro computer command load signal output
62	D. OUT	—	(Not used, open)
63	EMPH	—	(Not used, open)
64	SERVO RST	—	Not connected

•IC601 (MN187204PKW)

Pin No.	Mark	I/O Division	Function
1 └ 7	SEG 6 └ SEG 0	O	FL segment signal output
8	VPP	I	FL motor power supply
9	VDD	I	Power supply
10	OSC 2	I	Clock terminal (4.2336 MHz)
11	OSC 1		
12	GND	—	GND
13 • 14	NC	—	Not connected
15 └ 18	DATA 3 └ DATA 0	O	Key scan data output
19	CLK	O	Data lock signal
20	ACK	O	Data discrimination signal
21	/SEND	O	External data transmission command signal
22	/RECV	O	External data receipt command signal
23 • 24	NC	—	Not connected

Pin No.	Mark	I/O Division	Function
25	BSDT O	O	System data control
26	BSDT I	I	
27	BSCK O	O	System clock control
28	BSCK I	I	
29	RESET	I	Reset input
30 └ 35	KEY 5 └ KEY 0	I	Key scan data input
36	NC	—	Not connected
37	CM	—	GND
38	PCON	O	Servo circuit power switch
39 └ 45	NC	—	Not connected
46 └ 55	DGT 0 └ DGT 9	O	FL digit signal output
56 └ 64	SEG 15 └ SEG 7	O	FL segment signal output

●IC701 (AN8800SC-E2)

Pin No.	Mark	I/O Division	Function
1	LDG	I	Loop gain switch for auto pwer control VCC: NORMAL OPEN: +20 dB This machine for “NORMAL”
2	LDP	I	Monitor PD polequality switch for auto power control OPEN: P sub PD GND: N sub PD This machine for “P sub PD”
3	LD	O	Laser diode control output
4	LPD	I	Laser diode power monitor PD signal input
5	GND	—	Analog GND
6	LDON	I	Laser diode auto power control H: ON L: OFF
7	AMPI	I	Reverse amplifier input
8	AMPO	O	Reverse amplifier input
9	RFIN	I	RF AGC input (H: light level)
10	RFEQ	—	GND
11	C.AGC	—	Condenser connection for RF AGC loop filter
12	ARF	O	RF output after AGC (H: light level)
13	C.SBDO	—	Low level detected wave condenser connection for dark level drop-out detection
14	/RFDET	O	RF detection output
15	BDO	O	Black dropout detection output
16	VCC	—	Power supply (+5 V)
17	SDO	O	System dropout dection output
18	VAD+	O	Plus power supply for A/D converter
19	VREF	O	Reference voltage of servo error signal
20	VAD—	O	Power supply for A/D converter

●IC702 (TCA0372DM2R)

Pin No.	Mark	I/O Division	Function
1	GND	—	Connected to P.GND
2	NC	—	—
3	VOUT1	O	Spindle motor drive signal output
4	VCC	I	Power supply (+7.5 V)
5	VOUT2	O	Spindle motor drive signal output
6	NC	—	Connected to P.GND
7	NC	—	Connected to P.GND
8	GND	—	Connected to P.GND

Pin No.	Mark	I/O Division	Function
21	OFTR	O	Off track detction output
22	PLAY	I	“Play” signal input (H: ON, L: OFF)
23	WVEL	I	High speed input (H: high speed L: normal)
24	TES	I	Tracking error shunt signal input (H: shunt L: output)
25	PTO	O	Traverse speed detection signal output
26	PTI	I	Traverse speed detection signal input
27	PBO	O	Potention buffer output
28	PBI	I	Potention buffer input
29	CROSS	O	Tracking error cross detection output
30	TE	O	Tracking error output
31	TEBPF	I	Tremble detection output
32	TBAL	I	Tracking balance adjustment
33	VDET	O	Vibration detection output
34	FE	O	Focus error output
35	FBL2	—	Focus balance adjustment 2
36	FBL1	—	Focus balance adjustment 1
37	VCC	—	Power supply (+5 V)
38	GND	—	GND
39	PDBD	I	Photo detector current input
40	PDA	I	Photo detector current input
41	PDAD	I	Photo detector current input
42	PDB	I	Photo detector current input

Pin No.	Mark	I/O Division	Function
9	GND	—	Connected to P.GND
10	NC	—	Connected to P.GND
11	—VIN2	I	Spindle motor drive signal input
12	+VIN2	I	Spindle motor drive signal input
13	+VIN1	I	Spindle motor drive signal input
14	—VIN1	I	Spindle motor drive signal input
15	NC	—	Connected to P.GND
16	GND	—	Connected to P.GND

●IC703 (AN8377N)

Pin No.	Mark	I/O Division	Function
1	PVCC	I	Driver power supply (+5 V)
2	VCC	I	Power supply (+5 V)
3	TB	O	External transistor base driving output
4	VMON	O	Voltage (+5 V) output
5	TVDI	I	Traverse error signal input
6	FDI	I	Focus error signal input
7	TDI	I	Tracking error signal input
8	VREF	I	Reference voltage input


●IC704 (MN6650)

Pin No.	Mark	I/O Division	Function
1	TES	O	Tracking error shunt signal (H: Shunt)
2	PLAY	O	“Play” signal (H: play)
3	/RFDET	I	RF detection signal (L: detection)
4	DO	I	Dropout signal (H: dropout)
5	OFT	I	Off track signal (H: off track)
6	ARF	I	RF signal input
7	WVEL	O	High speed status signal (H: high speed)
8	PBO	I	Potension buffer signal input (Analog input)
9	TE	I	Tracking error signal input (Analog input)
10	FE	I	Focus error signal input (Analog input)
11	VR2	I	Reference voltage for A/D (Low reverse)
12	VR1	I	Reference voltage for A/D (High reverse)
13	LDON	O	Laser “ON” signal (H: ON)
14	VSS	I	Power supply (Digital system OV)
15	AVSS	I	Power supply (Analog system OV)
16	AVDD	I	Power supply (Analog system +5 V)
17	VDD	I	Power supply (Digital system +5 V)
18	TRV	O	Traverse force transmission output
19	TVD	O	Traverse drive output
20	FOD	O	Focus drive output
21	TRD	O	Tracking drive output
22	KICK	O	Kick pulse output

Pin No.	Mark	I/O Division	Function
9	TD—	O	Inverting output of tracking driver
10	TD+	O	Non-inverting output of tracking driver
11	FD—	O	Inverting output of focus driver
12	FD+	O	Non-inverting output of focus driver
13	TVD—	O	Inverting output of traverse driver
14	TVD+	O	Non-inverting output of traverse driver
15	RESET	O	Reset signal output
16	PC	I	PC input

Pin No.	Mark	I/O Division	Function
23	/TEST	I	Test terminal (“L”, normal)
24	VSS	I	Power supply (Digital system OV)
25	CLVS	I	Spindle servo condition signal (H: CLV L: Rough servo)
26	/TRON	O	Tracking servo “ON” signal (L: ON)
27	MDATA	I	Micro computer command data input
28	MCLK	I	Micro computer command clock signal input
29	MLD	I	Micro computer command load signal input (L: load)
30	SENSE	O	Sense signal input
31	/FLOCK	O	Focus servo pull-in signal (L: take-in condition)
32	/TLOCK	O	Tracking servo pull-in signal (L: take-in condition)
33	/RST	I	Reset input (L: reset)
34	XI	I	Clock input (fXI=16.9344 MHz)
35	T0	O	Test terminal (“Open”, normal)
36	T1	O	Test terminal (“Open”, normal)
37	T2	O	Test terminal (“Open”, normal)
38	T3	O	Test terminal (“Open”, normal)
39	T4	I	Test terminal (“L”, normal)
40	T5	I	Test terminal (“L”, normal)
41	T6	I	Test terminal (“L”, normal)
42	VDET	I	Vibration detection signal input (H: detection)
43	TBAL	O	Tracking balance adjustment output
44	TRCRS	I	Track cross signal input

●IC705 (MN6475)



Pin No.	Mark	I/O Division	Function
1	LRCK	I	L/R detection signal
2	BCLK	I	Bit clock for SRDATA
3	SRDATA	I	Serial data input
4	COT1	—	Connected to D.GND
5	COT2	—	Connected to D.GND
6	TEST	—	Connected to D.GND
7	VDD	I	Digital system power supply (+5 V)
8	×2	—	Crystal oscillator connection
9	×1	—	Crystal oscillator connection
10	VSS	—	Connected to GND
11	AVDDL	I	Power supply (+5 V)
12	OUT.L	O	Lch output
13	AVSSL	—	Connected to A.GND
14	AVSSR	—	Connected to A.GND
15	OUT.R	O	Rch output
16	AVDDR	I	Power supply (+5 V)
17	/RST	I	Reset signal input (L: reset)
18	PWM	—	NC
19	CP	—	Connected to D.GND
20	WVEL	I	High speed status signal input (H: high speed)
21	DEMPH	I	De-emphasis ON signal (H: ON)
22	CSEL	I	Test terminal
23	192FS/384FS	—	NC
24	768FS	O	Clock output

Pin No.	Mark	I/O Division	Function
1	LRCK	I	L/R clock input
2	BCLK	I	Serial input bit clock input
3	SRDATA	I	Serial input date input
4	COT1	—	Test mode input terminal 1 (normal: L)
5	COT2	—	Test mode input terminal 2 (normal: L)
6	TEST	—	Test mode input terminal 3 (normal: L)
7	DVDD	I	Digital system power supply (+5 V)
8	×2	—	Crystal oscillator connection
9	×1	—	Crystal oscillator connection
10	DVSS	—	Digital system ground terminal
11	AVDDL	I	Analog system power supply 1 (+5 V)
12	OUTL	O	Analog output (Lch)
13	AVSSL	—	Analog system ground terminal 1
14	AVSSR	—	Analog system ground terminal 2
15	OUTR	O	Analog output (Rch)
16	AVDDR	I	Analog system power supply 2 (+5 V)
17	RSTB	I	Reset terminal (L: reset)
18	PWM	O	PWM output
19	TP	—	Test terminal (normal: L)
20	WVEL	I	Motion speed switch (H: high speed)
21	DEMPH	I	Digital de-emphasis ON/OFF terminal (H: ON)
22	CSEL	I	Output clock frequency selection terminal of CK192
23	CK192	O	Clock devided frequency output
24	CK768	O	Clock output

SL-CH7

SL-CH7

●IC706 (MN6626)

Pin No.	Mark	I/O Division	Function
1	AVSS	I	GND for DSL, PLL circuit (OV)
2	IRFF	I	Reference electric current input
3	ARF	I	RF signal input
4	DRF	I	DSL bias
5	DSLFB	O	DSL loop filter
6	PLLFB	—	PLL loop filter
7	AVDD	I	Power supply for DSL, PLL
8	RSEL	I	RF signal quality decision terminal
9	TBUS7	O	Test terminal (normal: Open)
16	TBUS0	O	
17	FLAG	O	Error/frag output
18	IPFLAG	O	Interpolation flag
19	FCLK	O	Crystal frame clock
20	BTCLK	O	Byte clock
21	WDCK	O	Ward clock
22	/RST	I	Reset input
23	TX	O	Digital audio interface output
24	LDG	O	Lch deglitch signal
25	RDG	O	Rch deglitch signal
26	SRDATA	O	Serial data signal
27	SCK	O	Bit clock for SRDATA
28	LRCK	O	L, R discrimination signal
29	XCK	O	Crystal oscillator clock output
30	PMCK	O	$\frac{1}{192}$ devided frequency clock signal of crystal oscillator
31	CSEL	I	Test terminal (normal: L)
32	PSEL	I	Test terminal (normal: L)
33	X1	—	Crystal oscillator circuit input
34	X2	—	Crystal oscillator circuit output
35	VSS	I	Power supply (OV)
36	SUBQ	O	Sub-code Q-code output
37	SQCK	I	External clock for sub-code Q resister
38	/CLDCK	O	Sub-code frame clock signal
39	BLKCK	O	Sub-code block clock signal
40	DEMPH	O	De-emphasis ON signal
41	MEMP	I	Emphasis signal input (For digital audio interface)
42	MLD	I	Micro computer command load signal input (L: load)

Pin No.	Mark	I/O Division	Function
43	MCLK	I	Micro computer command clock signal input
44	MDATA	I	Micro computer command data input
45	DMUTE	I	Muting input
46	SMCK	O	MSEL = $\frac{1}{2}$ devided frequency clock signal of crystal oscillator when "H" level MSEL = $\frac{1}{4}$ devided frequency clock signal of crystal oscillator when "L" level
47	STAT	O	Status signal
48	CRC	O	Sub-code CRC check result (H: OK, L: NG)
49	SUBC	O	Sub-code serial output data
50	SBCK	I	Clock input for sub-code serial output
51	/TRON	I	Tracking servo ON signal
52	CLVS	O	Spindle servo phase synchronization condition signal (H: CLV L: rough servo)
53	PC	O	Sprindle motor ON signal (L: ON)
54	ECM	O	Spindle motor drive signal (Force mode output)
55	ECS	O	Spindle motor drive signal (Servo error signal output)
56	VDD	I	Power supply (+5 V)
57	/TEST	I	Test terminal (normal: H)
58	SSEL	I	SUBQ terminal Output mode switch terminal (H: Q code buffer mode)
59	MSEL	I	SMCK terminal output frequency switch terminal
60	RESY	O	Resynchronization signal of frame synchronization (H: synchronization, L: not)
61	DO	I	Drop-out signal (H: drop-out)
62	EFM	O	EFM signal output
63	PCK	O	PLL extract clock output
64	PDO	—	Phase comparison signal of EFM signal and PCK signal

■ REPLACEMENT PARTS LIST

Notes : * Important safety notice:
Components identified by $\triangle$ mark have special characteristics important for safety. When replacing any of these components use only manufacturer's specified parts.
* The parenthesized indications in the Remarks columns specify the areas. (Refer to the cover page for area.)
Parts without these indications can be used for all areas.
• Warning: This product uses a laser diode. Refer to caution statements on page 2.

Ref. No.	Part No.	Part Name & Description	Remarks	Ref. No.	Part No.	Part Name & Description	Remarks
		INTEGRATED CIRCUIT(S)		D9	1SR35200TB	DIODE	
IC1	LM2940T5	I. C, REGULATOR		D10	MA4082LTA	DIODE	
IC401	MN1554PKL1	I. C, SYSTEM CONTROL		D11	MA4270	DIODE	
IC601	MN187204PKW	I. C, SYSTEM CONT. & FL DRIVE		D12	MA4056MTA	DIODE	
IC701	AN8800SCE2	I. C, SERVO AMP.		D13, 14	MA4068M	DIODE	
IC702	TCA0372DM2R	I. C, SPINDLE MOTOR DRIVE		D401	MA4039HTA	DIODE	
IC703	AN8377N	I. C, TRAVERSE MOTOR DRIVE		D402	1SS254TA	DIODE	
IC704	MN6650	I. C, DIGITAL SERVO PROCESSOR		D603, 604	MA4043M	DIODE	
IC705	MN6475	I. C, DIGITAL FILTER		D611, 612	1SS254TA	DIODE	
IC706	MN6626	I. C, DIGITAL SIGNAL PRO.		D701	MA110TW	DIODE	
IC790	TA7291S	I. C, MOTOR DRIVE		D801, 802	1SS254TA	DIODE	
IC801	SVIBA4558F	I. C, L. P. FILTER AMP.		D852	1SS254TA	DIODE	
				D854, 855	1SS254TA	DIODE	
						VARIABLE RESISTOR(S)	
		IC PROTECTOR(S)		VR701	EVNDXAA00B14	V. R, BEST EYE	
ICP12	SRUN20T	IC PROTECTOR				COIL(S)	
		TRANSISTOR(S)		L431, 432	RLQZP3R3KT-Y	COIL	
						OSCILLATOR(S)	
Q1	DTA114ESTP	TRANSISTOR		X601	EF0GC4234T4	OSCILLATOR	
Q2	2SD1862QRTV6	TRANSISTOR		X701	RSXZ33M8M01T	OSCILLATOR	
Q3	2SA933SQR	TRANSISTOR				DISPLAY	
Q4-6	2SD2037EFTA	TRANSISTOR					
Q7	DTC124EST	TRANSISTOR		FL601	RSL0080-F	DISPLAY	
Q8	2SB1238QSTV6	TRANSISTOR				SWITCH(ES)	
Q9	2SC1740SQ	TRANSISTOR		S601	EVQ21405R	SW, OPEN/CLOSE	
Q10	2SA933SQR	TRANSISTOR		S602	EVQ21405R	SW, PAUSE	
Q11	2SD2037EFTA	TRANSISTOR		S603	EVQ21405R	SW, STOP	
Q421, 422	2SC1740SQ	TRANSISTOR		S604	EVQ21405R	SW, PLAY	
Q431	2SC1740SQ	TRANSISTOR		S605	EVQ21405R	SW, SKIP (REV)	
Q432	DTC144EKT96	TRANSISTOR		S606	EVQ21405R	SW, SKIP (FWD)	
Q433	2SC1740SQ	TRANSISTOR		S607	EVQ21405R	SW, SEARCH (REV)	
Q434	DTC144EKT96	TRANSISTOR		S608	EVQ21405R	SW, SEARCH (FWD)	
Q701	2SB709S	TRANSISTOR		S612	EVQ21405R	SW, NORMAL/TAPE LENGTH	
Q803, 804	2SD2144S	TRANSISTOR		S613	EVQ21405R	SW, AI	
Q852	DTA124ESTP	TRANSISTOR		S701	SSH05-E	SW, REST	
Q853	DTC114ESTP	TRANSISTOR		S790	RSHLA005	SW, LOADING CLOSE DETECT	
Q854	DTA114ESTP	TRANSISTOR		S791	RSHLA005	SW, LOADING OPEN DETECT	
		DIODE(S)					
D1-3	1SR35200TB	DIODE	$\triangle$				
D5	1SR35200TB	DIODE	$\triangle$				
D7	1SS254TA	DIODE					
D8	MA4056MTA	DIODE					

Ref. No.	Part No.	Part Name & Description	Remarks				
		CONNECTOR(S)					
CN11	RJU057W009	SOCKET (9P)					
CN301	RJS1A6823	SOCKET (23P)					
CN302	EMCS0660MT6	CONNECTOR (6P)					
CN601	RJS20Q11ZA	SOCKET (20P)					
CP11	RJT057W009-1	CONNECTOR (9P)					
CP601	RJS20Q11ZA	SOCKET (20P)					
CP701, 702	RJP2G17ZA	CONNECTOR (2P)					
CP703	RJP4G17ZA	CONNECTOR (4P)					
CS701	RJU035T016-1	SOCKET (16P)					
CS702	RJS1A6723-1Q	SOCKET (23P)					
CP790	RJP6G17ZA	PLUG (6P)					
JK801	RJT055K011	CONTROL TERMINAL					
		TRANSFORMER(S)					
T11	RTP1K4J021	POWER TRANSFORMER	$\triangle$				


Notes : * Capacity value are in microfarads (uF) unless specified otherwise, P=Pico-farads (pF) F=Farads (F)
* Resistance values are in ohms, unless specified otherwise, 1K=1,000 (OHM) , 1M=1,000k (OHM)

Ref. No.	Part No.	Values & Remarks	Ref. No.	Part No.	Values & Remarks	Ref. No.	Part No.	Values & Remarks
			R432	ERDS2TJ470	1/4W 47	R717	ERJ6GEYJ682V	1/10W 6.8K
		RESISTORS	R433, 434	ERDS2TJ393	1/4W 39K	R718	ERJ6GEYJ223V	1/10W 22K
			R435	ERDS2TJ223	1/4W 22K	R719	ERJ6GEYJ123V	1/10W 12K
R1	ERD2FCVJ6R8T	1/4W 6.8 $\triangle$	R436	ERDS2TJ470	1/4W 47	R720	ERJ6GEYJ273V	1/10W 27K
R2	ERDS2TJ473	1/4W 47K	R438	ERDS2TJ470	1/4W 47	R721	ERJ6GEYJ823	1/10W 82K
R3	ERDS2TJ223	1/4W 22K	R439, 440	ERDS2TJ393	1/4W 39K	R722	ERJ6GEYJ102V	1/10W 1K
R4	ERDS2TJ102	1/4W 1K	R441	ERDS2TJ223	1/4W 22K	R723, 724	ERJ6GEYJ104V	1/10W 100K
R5	ERDS2TJ473	1/4W 47K	R442	ERDS2TJ470	1/4W 47	R725	ERJ6GEYJ471V	1/10W 470
R6	ERDS2TJ472	1/4W 4.7K	R443	ERDS2TJ100	1/4W 10	R726	ERJ6GEYJ102V	1/10W 1K
R7	ERDS1FVJ271T	1/2W 270 $\triangle$	R451	ERDS2TJ103	1/4W 10K	R729, 730	ERJ6GEYJ102V	1/10W 1K
R8, 9	ERDS2TJ1R0	1/4W 1.0	R452, 453	ERDS2TJ102	1/4W 1K	R731	ERJ8GEYJ470V	1/8W 47
R10	ERDS2TJ3R9T	1/4W 3.9	R600-605	ERDS2TJ472	1/4W 4.7K	R732	ERJ6GEYJ562V	1/10W 5.6K
R11, 12	ERD2FCVG221T	1/4W 220 $\triangle$	R606	ERDS2TJ105T	1/4W 1M	R733	ERJ6GEYJ332V	1/10W 3.3K
R13	ERDS2TJ222	1/4W 2.2K	R607-614	ERDS2TJ221	1/4W 220	R734	ERJ6GEYJ562V	1/10W 5.6K
R14, 15	ERDS2TJ332	1/4W 3.3K	R701	ERJ6GEYJ100	1/10W 10	R735	ERJ6GEYJ222V	1/10W 2.2K
R16	ERDS2TJ102	1/4W 1K	R702	ERJ6GEYJ471V	1/10W 470	R736	ERJ6GEYJ682V	1/10W 6.8K
R17	ERD2FCVJ6R8T	1/4W 6.8	R703	ERJ6GEYJ102V	1/10W 1K	R737-739	ERJ6GEYJ562V	1/10W 5.6K
R18, 19	ERDS2TJ1R0	1/4W 1.0	R704	ERJ6GEYJ103V	1/10W 10K	R741-743	ERJ6GEYJ102V	1/10W 1K
R20	ERD2FCVG220T	1/4W 22	R706	ERJ6GEYJ473V	1/10W 47K	R744	ERJ6GEYJ393V	1/10W 39K
R303	ERDS2TJ560T	1/4W 56	R707	ERJ6GEYJ222V	1/10W 2.2K	R745, 746	ERJ6GEYJ102V	1/10W 1K
R304	ERDS2TJ102	1/4W 1K	R708	ERJ6GEYJ683V	1/10W 68K	R747	ERJ6GEYJ473V	1/10W 47K
R401-408	ERDS2TJ472	1/4W 4.7K	R709	ERJ6GEYJ122V	1/10W 1.2K	R748	ERJ8GEYJ180V	1/8W 18
R419	ERDS2TJ472	1/4W 4.7K	R710	ERJ6GEYJ182V	1/10W 1.8K	R817, 818	ERDS2TJ243T	1/4W 24K
R420	ERDS2TJ105T	1/4W 1M	R711	ERJ6GEYJ473V	1/10W 47K	R819, 820	ERDS2TJ473	1/4W 47K
R421	ERDS2TJ221	1/4W 220	R712	ERJ6GEYJ471V	1/10W 470	R821, 822	ERDS2TJ273	1/4W 27K
R422-425	ERDS2TJ472	1/4W 4.7K	R714	ERJ6GEYJ473V	1/10W 47K	R823, 824	ERDS2TJ473	1/4W 47K
R426	ERDS2TJ102	1/4W 1K	R715	ERJ6GEYJ223V	1/10W 22K	R825, 826	ERDS2TJ122	1/4W 1.2K
R427	ERDS2TJ472	1/4W 4.7K	R716	ERJ6GEYJ104V	1/10W 100K	R827, 828	ERDS2TJ473	1/4W 47K

Ref. No.	Part No.	Values & Remarks	Ref. No.	Part No.	Values & Remarks
R829, 830	ERDS2TJ471	1/4W 470	C728, 729	ECUV1C104MBM	16V 0.1U
R833, 834	ERDS2TJ102	1/4W 1K	C730	ECUV1C224KBM	16V 0.22U
R841, 842	ERDS2TJ104	1/4W 100K	C731	ECEA0JKS3311	6.3V 330U
R852	ERDS2TJ221	1/4W 220	C732	ECUE1H102MBN	50V 1000P
R853	ERDS2TJ102	1/4W 1K	C733	ECEA0JKS1011	6.3V 100U
R854, 855	ERDS2TJ472	1/4W 4.7K	C734	ECUE1E223MBN	25V 0.022U
			C735	ECUV1C224KBM	16V 0.22U
		CAPACITORS	C737	ECUV1C224KBM	16V 0.22U
			C738	ECEA0JKS1011	6.3V 100U
C1, 2	ECBT1E103ZF	25V 0.01U	C739	ECUE1E103MBN	25V 0.01U
C3	ECEA1EU222B	25V 2200U	C740	ECUE1H472MBN	50V 4700P
C4	ECEA1EU101	25V 100U	C741	ECUV1C224KBM	16V 0.22U
C5	ECBT1H102KB5	50V 1000P	C742	ECUV1C104MBM	16V 0.1U
C6	ECEA0JKA470B	6.3V 47U	C743	ECEA0JKS3311	6.3V 330U
C7, 8	ECBT1H102KB5	50V 1000P	C744, 745	ECUE1H102KBN	50V 1000P
C9	ECEA1AGE101B	10V 100U	C746	ECEA0JKS1011	6.3V 100U
C10	ECEA1AU221	10V 220U	C747	ECUV1C104MBM	16V 0.1U
C11	ECEA1CGE470B	16V 47U	C748	ECEA1HKS010	50V 1U
C12	ECEA0JU221	6.3V 220U	C749	ECUE1E103MBN	25V 0.01U
C13, 14	ECBT1H102KB5	50V 1000P	C750	ECUE1H050DCN	50V 5P
C15, 16	ECEA1AU470	10V 47U	C751	ECUV1C224KBM	16V 0.22U
C17	ECEA1HU101	50V 100U	C752	ECUV1C104MBM	16V 0.1U
C18	ECBT1H102KB5	50V 1000P	C753, 754	ECEA1HKS010	50V 1U
C19	ECEA0JKA470B	6.3V 47U	C755	ECUV1C104MBM	16V 0.1U
C303-305	ECBT1H102KB5	50V 1000P	C756, 757	ECUE1H050DCN	50V 5P
C402	ECBT1H104ZF5	50V 0.1U	C758	ECUV1C224KBM	16V 0.22U
C421	ECEA1HKA010B	50V 1U	C763	ECUE1E103MBN	25V 0.01U
C434	ECBT1H104ZF5	50V 0.1U	C764	ECUE1H331KBN	50V 330P
C601	ECBT1H104ZF5	50V 0.1U	C790	ECA1AKF820E	10V 82U
C602	ECBT1E103ZF	25V 0.01U	C811, 812	ECBT1H102KB5	50V 1000P
C603-606	ECBT1H104ZF5	50V 0.1U	C813, 814	ECBT1H101KB5	50V 100P
C701	ECEA0JKA220	6.3V 22U	C815, 816	ECEA1HU220	50V 22U
C702	ECEA0JKS470	6.3V 47U	C819, 820	ECBT1H101KB5	50V 100P
C703	ECEA0JKS1011	6.3V 100U	C827, 828	ECEA1AU101	10V 100U
C709	ECUV1C224KBM	16V 0.22U			
C710	ECUV1C104MBM	16V 0.1U			CHIP JUMPER(S)
C711	ECUE1E103MBN	25V 0.01U			
C713	ECEA1CSN4R71	16V 4.7U	J701	ERJ6GEY0R00V	1/10W 0
C714	ECEA1HKS010	50V 1U	J703-710	ERJ6GEY0R00V	1/10W 0
C715	ECUE1H472KBN	50V 4700P			
C716	ECUE1C473KBN	16V 0.047U			
C717	ECUE1H681KBN	50V 680P			
C718	ECEA1AKS1011	10V 100U			
C719	ECUE1E103MBN	25V 0.01U			
C720	ECUE1E153MBN	25V 0.015U			
C721	ECUE1E103MBN	25V 0.01U			
C722	ECEA0JKS470	6.3V 47U			
C723	ECUV1C104MBM	16V 0.1U			
C724	ECUV1E333MBN	H 25V 0.033U			
C725	ECUE1E103MBN	25V 0.01U			
C726	ECUE1H471KBN	50V 470P			
C727	ECEA0JKS470	6.3V 47U			


[illegible]

CABINET PARTS LOCATION



Ref. No.	Part No.	Part Name & Description	Remarks
		LOADING UNIT PARTS	
301	REM0019	MOTOR ASS'Y	
302	RMKD105	CHASSIS	
303	RME0063	SPRING	
304	RMG0158	BELT	
305	RML0177	LEVER	
306	RML0178	LEVER	
307	RMM0058	SLIDE PLATE 1	
308	XTN26+6G	SCREW	
309	XYN2+F6FZ	SCREW	
310	RHD20010	SCREW	
311	RMU0046	GUIDE SHAFT	
312	RHD20009-1	SCREW	
313	RMA0328	HOLDER	
314	RMKD103	DISK TRAY	
315	XTN2+8G	SCREW	
316	XTB3+25GFZ	SCREW	
317	XTN26+6G	SCREW	
318	XTN3+8JFZ	SCREW	
319	RXQ0122	TRAY HOLDER	
319-1	RHM245ZA	MAGNET	
319-2	RMR0334	HOLDER	
319-3	RXQ0123	DISK HOLDER	
320	RFKNXDT77B-H	GEAR ASS'Y	
321	RFKJXDT77-H	CHASSIS ASS'Y	
321-1	RDG0142	GEAR	
321-2	RDG0143	DRIVE GEAR 1	
321-3	RDP0041	PULLEY	
321-4	SDR014	ROLLER B	
322	RFKNXDT77C-H	HOLDER	
322-1	RMG0159	RUBBER	
323	SDD110Z	TRAVERSE UNIT	
323-1	SHGD112	RUBBER A	
323-2	SHGD113-1	RUBBER B	
323-3	RDV0014	BELT	
324	RMS0123-1	PIN	
325	RMM0059	SLIDE PLATE 2	
326	XTV26+6G	SCREW	
327	RME0087	SPRING	

■ CABINET PARTS LOCATION (Loading unit parts)



Service Manual

LW/MW/FM Stereo Tuner

Tuner

ST-CH7L



Because of unique interconnecting cables,
when a component requires service, send or
bring in the entire system.

SPECIFICATIONS

(DIN 45 500)

FM TUNER SECTION

Frequency range	87.50~108.00 MHz (0.05 MHz step)
Sensitivity	1.5 μ V (IHF, usable)
S/N 30 dB	1.5 μ V (75 Ω)
S/N 26 dB	1.3 μ V (75 Ω)
S/N 20 dB	1.2 μ V (75 Ω)
IHF 46 dB stereo quieting sensitivity	28 μ V (75 Ω)
Total harmonic distortion	
MONO	0.2%
STEREO	0.3%
S/N	
MONO	60 dB (74 dB, IHF)
STEREO	58 dB (70 dB, IHF)
Frequency response	20 Hz~15 kHz, +0.5 dB~-1.5 dB
Alternate channel selectivity $\pm$ 400 kHz	50 dB
Stereo separation 1 kHz	40 dB
10 kHz	30 dB
Channel balance (250 Hz~6,300 Hz)	$\pm$ 1.5 dB
Limiting point	1.2 μ V
Bandwidth	
IF amplifier	180 kHz
FM demodulator	1000 kHz
Antenna terminal	75 Ω (unbalanced)

LW/MW TUNER SECTION

Frequency range	
MW	522~1611 kHz (9 kHz-step)
	530~1620 kHz (10 kHz-step)
LW	144~288 kHz (9 kHz-step)
	146~290 kHz (+2 kHz-shift)

Color

(K) Black Type

Areas

Country Code	Area	Color
(E)	Continental Europe.	(K)
(GC)	Asia, Latin America, Middle Near East and Africa.	
(GN)	Oceania.	

System: SC-CH7

Sensitivity (S/N 20 dB)

MW	20 μ V, 300 μ V/m
LW	50 μ V

Selectivity ($\pm$ 9 kHz)

MW	(at 999 kHz) 50 dB
LW	(at 216 kHz) 50 dB

TIMER SECTION

Clock	Quartz-lock type
Functions	24-hour indication
	24-hour programmable;
	weekly (1 time)
	once only (1 time)
	sleep (1~120 min., 1-min. intervals)
Setting intervals	1 minute~23 hours, 59 minutes
	(at 1 min. intervals)

GENERAL

Power consumption	8 W
Dimensions (W×H×D)	215×55×295 mm
	(8 ¹⁵ / ₃₂ "×2 ⁵ / ₃₂ "×11 ⁵ / ₈ "
Weight	1.4 kg (3.0 lb.)

Notes:

1. Total harmonic distortion is measured by the digital spectrum analyzer.
2. Specifications are subject to change without notice.
3. Weight and dimensions shown are approximate.

System	Tuner	Amplifier	CD Player	Cassette Deck	Speakers
SC-CH7	ST-CH7L	SU-CH7	SL-CH7	RS-CH7	SB-CH7

Technics / Panasonic

(E)

(GC) (GN)

CONTENTS


	Page
LOCATION OF CONTROLS	2,3
DISASSEMBLY INSTRUCTIONS	4
MEASUREMENTS AND ADJUSTMENTS	5,6
DESCRIPTION OF FL PANEL	7
FUNCTION OF IC TERMINALS	8
SCHEMATIC DIAGRAM	9~12

	Page
PRINTED CIRCUIT BOARDS AND WIRING CONNECTION DIAGRAM	13, 14
BLOCK DIAGRAM	15, 16
REPLACEMENT PARTS LIST	17~21
CABINET PARTS LOCATIONS	21

Note:


Refer to the service manual for Model No. SU-CH7, Order No. AD9104082C8 for information on ACCESSORIES, INSTALLATION OF THE SYSTEM, CONNECTIONS and PACKAGING.

LOCATION OF CONTROLS



Tuner: control section

- ① **Timer set button (TIMER SET)**
This button is used when making the timer setting.
- ② **Timer select buttons (▼ SELECT ▲)**
These buttons are used when setting the time. And when making the timer setting, to select the type of timer operation, the day, the time, etc.
- ③ **Remote signal sensor (SENSOR)**
- ④ **Band select button (BAND)**
This button is used to select either the MW, LW or FM band.
- ⑤ **Preset-tuning buttons (▼ PRESET ▲)**
These buttons are used to select channel numbers for a broadcasting station which has been stored in the tuner's memory.
- ⑥ **Timer cancel button (CANCEL)**
This button is used to cancel the timer setting.
- ⑦ **Power "STANDBY ⏻/ON" switch (POWER STANDBY ⏻/ON)**
This switch switches ON and OFF the secondary circuit power only. The unit is in the "standby" condition when this switch is set to the STANDBY ⏻ position. Regardless of the switch setting, the primary circuit is always "live" as long as the power cord is connected to an electrical outlet.
- ⑧ **Timer setting confirmation button (RECALL)**
This button is used to confirm the timer setting.
- ⑨ **Clock set button (CLOCK SET)**
This button is used to set the present time.
- ⑩ **Memory button (MEMORY)**
This button is used when presetting broadcast station frequencies into memory.
- ⑪ **Tuning buttons (▼ TUNING ▲)**
These buttons are used for tuning the desired broadcast station.








Tuner: display section

- (a) Timer play/recording indicator (PLAY, REC)**
This indicator shows that timer play mode or timer recording mode is activated.
- (b) Timer mode-indicator (ONCE, WEEKLY)**
This indicator shows the timer operation mode (ONCE or WEEKLY).
- (c) Day display (SUN-SAT)**
This display shows the present day, or the day the timer has been set for, if used.
- (d) Sleep indicator (SLEEP)**
Illuminates when the sleep timer is activated.
- (e) Timer ON/OFF indicator (ON, OFF)**
This indicator shows whether the times for timer switch-ON and switch-OFF have been set.
- (f) Time display**
This display shows the present time, or the time the timer has been set for.
- (g) FM stereo indicator (STEREO)**
This indicator automatically illuminates when an FM stereo broadcast is being received. It will not illuminate if the FM mode button is used to select monaural mode.
- (h) Band indicator (FM, MW, LW)**
Illuminates to show which band is selected.
- (i) Digital frequency display**
Displays the broadcast frequencies.
- (j) Quartz lock indicator (QUARTZ LOCK)**
This indicator illuminates when the unit is precisely tuned to a broadcast station.
- (k) Memory indicator (MEMO)**
This indicator illuminates when the memory button is pressed.
- (l) Preset channel display**
This display shows the channel number selected by the preset-tuning buttons.
- (m) FM mode indicator (AUTO, MONO)**
When FM broadcasts are being received, usually the "AUTO" indication is illuminated. When the FM mode is set to monaural, "MONO" illuminates.

DISASSEMBLY INSTRUCTIONS

“ATTENTION SERVICER”

Some chassis components may have sharp edges. Be careful when disassembling and servicing.

Ref. No. 1	Removal of the Cabinet		
Procedure 1			
•Remove the 5 screws (①~⑤).			
Ref. No. 2	Removal of the Front Panel	Ref. No. 3	Removal of the Operation P.C.B.
Procedure 1→2		Procedure 1→2→3	
			
1. Remove the 2 screws (①, ②). 2. Remove the front panel in the direction of arrow.		1. Pull up the position ① of the front panel in the direction of the arrow ①, and then remove the reinforce plate in the direction of the arrow ②.	
Ref. No. 4	Removal of the Main P.C.B.		
Procedure 1→2→4			
			
•Remove the 8 screws (①~⑧).		2. Remove the 6 screws (①~⑥).	

MEASUREMENTS AND ADJUSTMENTS


This TUNER (ST-CH7L) is powered by the amplifier (SU-CH7). To adjust it or check operations as a separate unit, follow the steps below.

1. Apply a power supply voltage of AC 23 V to **TP701** and **TP702**.
2. Power supply switch: ON


HOW TO CONNECT

Note:

Apply a power supply voltage of AC 23 V to **TP701** and **TP702** by using a Voltage Controller. If it is not available, use a Power Supply Fixture (SZZA1058C) instead.



ADJUSTMENT POINT



FM ADJUSTMENT

Control positions and equipment used

- FM signal generator (FM-SG)
- Stereo modulator
- Distortion analyser
- DC electronic voltmeter (EVM)
- Frequency counter
- Choke coil (100 μ H)
- Resistor (100 k Ω)

Note: For Z201 (AM ANT and OSC coil), Z202 (AM-IFT), they are supplied as adjusted parts. So, do not turn the cores of the parts. If it is not necessary to adjust the AM circuit.


FM OFFSET VOLTAGE AND MONO DISTORTION ADJUSTMENT

1. Test equipment connection is shown in figure.
2. Set the unit to "FM" mode.
3. Set the radio frequency display and signal generator to 100.10 MHz.
4. Adjust the core of **T201** so that the voltage measured in signal mode is 0 mV (0 ± 20 mV) in 300 mV range.
5. Adjust **T202** so that the distortion factor of L-CH and R-CH is minimized.
6. Repeat steps 4 and 5.

Note: The adjusting screwdriver used should be made of resin.

FM SIGNAL GENERATOR CONDITION

Modulation 100%
Modulation frequency 1 kHz
Output level 66 dB



FM MPX VCO ADJUSTMENT



1. Test equipment connection is shown in figure.
2. Set the unit to "stereo" position.
3. Set the radio frequency display and signal generator to 100.10 MHz.
4. Adjust **VR501** for 19 kHz $\pm$ 30 Hz on frequency counter reading.

USING ALTERNATE SYSTEM

1. Receive the stereo broadcast.
2. Adjust **VR301** until stereo indicator lights up. Fix the arm of **VR301** as shown in figure.

FM SIGNAL GENERATOR CONDITION

Modulation 100%
Modulation frequency 0 kHz
Output level 66 dB




- (A)-(B),
(D)-(E) "Stereo" OFF position
(B)-(D) "Stereo" ON position
(Indicator lighting)
(C) Adjust point of pilot circuit

PLL CLOCK FREQUENCY ADJUSTMENT


1. Test equipment connection is shown in figure.
2. Adjust **CT101** for 2070 $\pm$ 0.010 kHz (2050 $\pm$ 0.010 kHz...GC only) on frequency counter reading.

Use a high impedance probe.



■ DESCRIPTION OF FL PANEL [FL901 (RSL0096-F)]

● GRID ASSIGNMENT



● PIN CONNECTION

PIN NO.	3	3	2	2	2	2	2	2	2	2	2	1	1	1	1	1	1	1	1	1	9	8	7	6	5	4	3	2	1	
CONNECTION	F	F	N	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	N	1	2	3	4	5	6	7	N	F	F	
	2	2	P	7	5	4	3	2	1	0	9	8	0	1	2	3	4	5	6	6	C	G	G	G	G	G	G	P	1	1

Note: 1) F1, F2 Filament
2) NP No pin
3) 1G~8G Grid

● ANODE CONNECTION

	7G	6G	5G	4G	3G	2G	1G
P0	SLEEP	AM	2d	L W	2d	2d	CH.
P1	—	PM	2e	FM	2e	2e	MHz
P2	WEEKLY	2c	2c	AM	2c	2c	kHz
P3	—	—	2g	MW	2g	2g	2a, 2d, 2e, 2g
P4	ONCE	—	2f	—	2f	2f	MEMO
P5	—	2b	2b	—	2b	2b	AUTO
P6		2a, 2d, 2e, 2g	2a	STEREO	2a	2a	QUARTZ LOCK
P7	PLAY	ON	col	S1	2h	2h	2b
P8	WED	1d	1d	—	1d	1d	1d
P9	SAT	1e	1e	—	1e	1e	1e
P10	TUE	1c	1c	—	1c	1c	1c
P11	FRI	1g	1g	—	1g	1g	1g
P12	MON	1f	1f	—	1f	1f	1f
P13	THU	1b	1b	—	1b	1b	1b
P14	SUN	1a	1a	—	1a	1a	1a
P15	REC	OFF	DP, 2	—	DP, 1	1h	2c
P16	—	—	—	—	—	—	MONO

■ FUNCTIONS OF IC TERMINALS

● IC901 (MN187125STT1)

Pin No.	Mark	I/O Division	Function	Pin No.	Mark	I/O Division	Function
1	VDD	I	Power supply (+B)	22	SBT1	O	Clock terminal for serial data.
2	OSC2	I	Connected to crystal oscillator (X901) (4.19 MHz)	23	CE	O	Serial transmission operation Chip enable terminal
3	OSC1	O		24	SBO1	O	Serial data signal output
4	VSS	I	Connected to ground terminal	25	CLOCK OUT	O	External control clock signal input-output
5	X1	I	Connected to ground terminal	26	CLOCK IN	I	
6	X0	O	Not connected	27	DATA OUT	O	External control data signal output
7	KEY2	I	Key scan signal input	28	NC	—	Not connected
8	KEY1 BIN	I	Connect to ground terminal	29	CM	I	Connectd to ground terminal
9	CR	I	Not connected	30	DATA IN	I	External control data signal input
10	STEREO	I	Stereo input Inputs when stereo signal receipt "L", monaural signal receipt "H".	31	SD	I	Input for stop signal during auto tuning. Stops auto tuning at high level. Receipt: H, No signal: L
11	DIR	I	When broadcasting receipt "L", stereo/normal broadcasting receipt "H". Not connected	32	MUT	O	Output for erasing shock noise when lock-off at PLL. <Muting out> 1. Power switch "off". 2. Frequency change (up/down, FM↔AM↔TV) Put out "H" when those of above two.
12	MONO	O	Auto/mono change over terminal.	33	A IN		
13 14	MFRO	O	Remote control signal terminal. Not connected	34	B IN		
15	INT	I	Remote control input	35 37	KS1 KS3	O	Key scan signal output
16	POWER DOWN	I	Power supply level detection	38 45	DGT0 DGT7	O	Digit signal output to FL display
17 18	SDC BM	O	DTS selective output terminal. Not connected	46	P71	I	Serial data signal input
19	POWER			47 48 63	P70 SEG15 SEG0	O	Segment signal output to FL display
20	TB	I	Band data input	64	VPP	I	FL motor power supply
21	RESET	I	Reset signal input Input of reset for micro computer stand				

SCHEMATIC DIAGRAM (Parts list on pages 17~20.)

Notes:

•S901, 902 : Preset channel switch.
(S901: Up, S902: Down)

•S903 : Band select switch.

•S904 : Memory switch.

•S905, 906 : Tuning switch.

(S905: Up, S906: Down)

•S907, 908 : Timer select Switch.

(S907: Up, S908: Down)

•S909 : Timer set switch.

•S910 : Clock set switch.

•S911 : Timer setting confirmatin switch.

•S912 : Timer cancel switch.

•S913 : Power switch.


•Indicated voltage values are the standard values for the unit measured by the DC electronic circuit tester (high-impedance) with the chassis taken as standard. Therefore, there may exist some errors in the voltage values, depending on the internal impedance of the DC circuit tester.

() : MW voltage, [] : LW voltage, □ : MUTING voltage

•Important safety notice

Components identified by Δ mark have special characteristics important for safety. When replacing any of these components, use only manufacturer's specified parts.

•This schematic diagram may be modified at any time with the development of new technology.



Caution!

IC and LSI are sensitive to static electricity.


Secondary trouble can be prevented by taking care during repair.


•Cover the parts boxes made of plastics with aluminum coil.

•Ground the soldering iron.

•Put a conductive mat on the work table.

•Do not touch the legs of IC or LSI with the fingers directly.





MAIN P.C.B.


OPERATION P.C.B.

Terminal guide of IC's transistors and diodes

LM7001 	AN7273W
MN187125STT1 	RVIBA1332L
2SC1685RSTTA 	2SC2785FETA 2SC2787LTA
2SC1740SQSTA KSA1175YGTA KSC2785YGTA DTC144ESTP 	
2SD1862QRTV6 	1SS254TA 1SR35200TB
1SS291TA 	MA4047MTA MA4068MTA
MA4240HTA MA4150MTA 	

LM7001	AN7273W
MN187125STT1	RVIBA1332L
2SC1685RSTTA	2SC2785FETA 2SC2787LTA
	2SC1740SQSTA KSA1175YGTA KSC2785YGTA DTC144ESTP
2SD1862QRTV6	1SS254TA 1SR35200TB
1SS291TA	MA4047MTA MA4068MTA
MA4240HTA MA4150MTA	

■ BLOCK DIAGRAM



Notes : * Capacity value are in microfarads (uF) unless specified otherwise, P=Pico-farads (pF) F=Farads (F)
* Resistance values are in ohms, unless specified otherwise, 1K=1,000(OHM) , 1M=1,000k(OHM)

Ref. No.	Part No.	Part Name & Description	Remarks	Ref. No.	Part No.	Part Name & Description	Remarks
		CABINET PARTS		9	RFKJ7CH7LE-K	CASSIS ASS'Y	
				9-1	SHG1654	FOOT	
1	RHD30007	SCREW		10	RGU0553-K	BUTTON, PRESET	
2	RKM0158-K	CABINET		11	RGU0554-K	BUTTON, TUNING	
3	RGR0116A-C	REAR PANEL	(E)	12	RGU0555-A	BUTTON, TIMER	
3	RGR0116A-D1	REAR PANEL	(GC, GN)	13	RGU0556-K	BUTTON, POWER	
4	RMRO427	HOLDER		14	RGU0557-K	BUTTON, BAND SELECT	
5	SHE170-2	SPACER		15	RFKJ7CH7LE-K	FRONT PANEL ASS'Y	(E)
6	XTBS26+8J	SCREW		15	RFKJ7CH7LGCK	FRONT PANEL ASS'Y	(GC, GN)
7	XTBS3+8JFZ1	SCREW		16	RMN0123	FL HOLDER	
8	XTB3+12JFZ	SCREW		17	XTB3+8JFZ	SCREW	

■ CABINET PARTS LOCATION

