


Service Manual



VSX-2016AV-S

ORDER NO.
RRV3397

AUDIO/VIDEO MULTI-CHANNEL RECEIVER

VSX-2016AV-S VSX-81TXV VSX-81TXV-S VSX-9110TXV-K

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).

Model	Type	Power Requirement	Remarks
VSX-2016AV-S	HYXJ5	AC 220 V to 230 V	
VSX-81TXV	KUXJCA	AC 120 V	
VSX-81TXV-S	KUXJCA	AC 120 V	
VSX-9110TXV-K	KUXJ	AC 120 V	



For details, refer to "Important Check Points for good servicing".

PIONEER CORPORATION 4-1, Meguro 1-chome, Meguro-ku, Tokyo 153-8654, Japan

PIONEER ELECTRONICS (USA) INC. P.O. Box 1760, Long Beach, CA 90801-1760, U.S.A.

PIONEER EUROPE NV Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium

PIONEER ELECTRONICS ASIACENTRE PTE. LTD. 253 Alexandra Road, #04-01, Singapore 159936

©PIONEER CORPORATION 2006

SAFETY INFORMATION

A



This service manual is intended for qualified service technicians ; it is not meant for the casual do-it-yourselfer. Qualified technicians have the necessary test equipment and tools, and have been trained to properly and safely repair complex products such as those covered by this manual.

■ Improperly performed repairs can adversely affect the safety and reliability of the product and may void the warranty. If you are not qualified to perform the repair of this product properly and safely, you should not risk trying to do so and refer the repair to a qualified service technician.

WARNING

B This product contains lead in solder and certain electrical parts contain chemicals which are known to the state of California to cause cancer, birth defects or other reproductive harm.

Health & Safety Code Section 25249.6 - Proposition 65

NOTICE

(FOR CANADIAN MODEL ONLY)

■ Fuse symbols (fast operating fuse) and/or (slow operating fuse) on PCB indicate that replacement parts must be of identical designation.

REMARQUE

(POUR MODÈLE CANADIEN SEULEMENT)

■ Les symboles de fusible (fusible de type rapide) et/ou (fusible de type lent) sur CCI indiquent que les pièces de remplacement doivent avoir la même désignation.

C


(FOR USA MODEL ONLY)

1. SAFETY PRECAUTIONS

The following check should be performed for the continued protection of the customer and service technician.

LEAKAGE CURRENT CHECK

Measure leakage current to a known earth ground (water pipe, conduit, etc.) by connecting a leakage current tester such as Simpson Model 229-2 or equivalent between the earth ground and all exposed metal parts of the appliance (input/output terminals, screwheads, metal overlays, control shaft, etc.). Plug the AC line cord of the appliance directly into a 120V AC 60 Hz outlet and turn the AC power switch on. Any current measured must not exceed 0.5 mA.



AC Leakage Test

ANY MEASUREMENTS NOT WITHIN THE LIMITS OUTLINED ABOVE ARE INDICATIVE OF A POTENTIAL SHOCK HAZARD AND MUST BE CORRECTED BEFORE RETURNING THE APPLIANCE TO THE CUSTOMER.

2. PRODUCT SAFETY NOTICE

Many electrical and mechanical parts in the appliance have special safety related characteristics. These are often not evident from visual inspection nor the protection afforded by them necessarily can be obtained by using replacement components rated for voltage, wattage, etc. Replacement parts which have these special safety characteristics are identified in this Service Manual.

Electrical components having such features are identified by marking with a on the schematics and on the parts list in this Service Manual.

The use of a substitute replacement component which does not have the same safety characteristics as the PIONEER recommended replacement one, shown in the parts list in this Service Manual, may create shock, fire, or other hazards.

Product Safety is continuously under review and new instructions are issued from time to time. For the latest information, always consult the current PIONEER Service Manual. A subscription to, or additional copies of, PIONEER Service Manual may be obtained at a nominal charge from PIONEER.

F

[Important Check Points for Good Servicing]

In this manual, procedures that must be performed during repairs are marked with the below symbol.
Please be sure to confirm and follow these procedures.

1. Product safety



Please conform to product regulations (such as safety and radiation regulations), and maintain a safe servicing environment by following the safety instructions described in this manual.

- ① Use specified parts for repair.
 - Use genuine parts. Be sure to use important parts for safety.
 - ② Do not perform modifications without proper instructions.
- Please follow the specified safety methods when modification(addition/change of parts) is required due to interferences such as radio/TV interference and foreign noise.
- ③ Make sure the soldering of repaired locations is properly performed.

When you solder while repairing, please be sure that there are no cold solder and other debris.
Soldering should be finished with the proper quantity. (Refer to the example)

- ④ Make sure the screws are tightly fastened.
- Please be sure that all screws are fastened, and that there are no loose screws.

- ⑤ Make sure each connectors are correctly inserted.
- Please be sure that all connectors are inserted, and that there are no imperfect insertion.
- ⑥ Make sure the wiring cables are set to their original state.

Please replace the wiring and cables to the original state after repairs.
In addition, be sure that there are no pinched wires, etc.

- ⑦ Make sure screws and soldering scraps do not remain inside the product.
- Please check that neither solder debris nor screws remain inside the product.
- ⑧ There should be no semi-broken wires, scratches, melting, etc. on the coating of the power cord.

Damaged power cords may lead to fire accidents, so please be sure that there are no damages.
If you find a damaged power cord, please exchange it with a suitable one.

- ⑨ There should be no spark traces or similar marks on the power plug.
 - When spark traces or similar marks are found on the power supply plug, please check the connection and advise on secure connections and suitable usage. Please exchange the power cord if necessary.
 - ⑩ Safe environment should be secured during servicing.
- When you perform repairs, please pay attention to static electricity, furniture, household articles, etc. in order to prevent injuries.
Please pay attention to your surroundings and repair safely.

2. Adjustments



To keep the original performance of the products, optimum adjustments and confirmation of characteristics within specification.
Adjustments should be performed in accordance with the procedures/instructions described in this manual.

3. Lubricants, Glues, and Replacement parts



Use grease and adhesives that are equal to the specified substance.
Make sure the proper amount is applied.

4. Cleaning



For parts that require cleaning, such as optical pickups, tape deck heads, lenses and mirrors used in projection monitors, proper cleaning should be performed to restore their performances.

5. Shipping mode and Shipping screws



To protect products from damages or failures during transit, the shipping mode should be set or the shipping screws should be installed before shipment. Please be sure to follow this method especially if it is specified in this manual.

CONTENTS

1.	SPECIFICATIONS	6
2.	EXPLODED VIEWS AND PARTS LIST	10
A	2.1 PACKING SECTION	10
	2.2 EXTERIOR SECTION.....	12
	2.3 CHASSIS SECTION	14
	2.4 REAR SECTION	16
	2.5 POWER AMP SECTION.....	20
	2.6 FRONT PANEL SECTION	22
B	3. BLOCK DIAGRAM AND SCHEMATIC DIAGRAM.....	24
	3.1 BLOCK DIAGRAM for AUDIO BLOCK.....	24
	3.2 BLOCK DIAGRAM for VIDEO BLOCK.....	26
	3.3 OVERALL WIRING DIAGRAM.....	28
	3.4 AUDIO IN ASSY (1/2)	30
	3.5 AUDIO IN (2/2) and 12V-REG ASSYS.....	32
	3.6 MAIN CONTROL ASSY (1/3).....	34
	3.7 MAIN CONTROL (2/3), GUARD-C and GUARD-F ASSYS	36
	3.8 MAIN CONTROL ASSY (3/3).....	38
	3.9 DSP ASSY (1/4).....	40
	3.10 DSP ASSY (2/4).....	42
	3.11 DSP ASSY (3/4).....	44
	3.12 DSP ASSY (4/4).....	46
	3.13 COMPOSITE ASSY	48
	3.14 S-VIDEO and BRIDGE 2 ASSYS	50
	3.15 COMPONENT ASSY	52
	3.16 DISPLAY, VOLUME and MULTI JOG ASSYS	54
C	3.17 HEADPHONE, FRONT-IN, PRIMARY and TRANS 1 ASSYS	56
	3.18 TRANS 2-1, DIODE 1, VH TR, BRIDGE 1 and PS/SP ASSYS.....	58
	3.19 TRANS 2-2, TRANS SIDE, LOCAL P-SUPPLY, DC/DC, IR I/O and VIDEO CONNECT ASSYS	60
	3.20 POWER AMP-L, POSI 1-L and POSI 2-L ASSYS	62
	3.21 POWER AMP-R and POSI 1-R ASSYS.....	64
	3.22 POWER AMP IN and POWER PROTECT ASSYS.....	66
	3.23 HDMI & DVC ASSY (1/2)	68
	3.24 HDMI & DVC ASSY (2/2)	70
	3.25 USB ASSY (VSX-2016AV-S ONLY)	72
D	4. PCB CONNECTION DIAGRAM	74
	4.1 AUDIO IN ASSY.....	76
	4.2 12V-REG ASSY	80
	4.3 BRIDGE 2 ASSY	81
	4.4 MAIN CONTROL ASSY	82
	4.5 DSP ASSY	86
	4.6 COMPOSITE ASSY	90
	4.7 S-VIDEO ASSY.....	94
	4.8 COMPONENT ASSY	98
	4.9 DISPLAY ASSY.....	102
	4.10 VOLUME ASSY.....	106
	4.11 HEADPHONE ASSY.....	107
	4.12 MULTIJOG ASSY.....	108
	4.13 FRONT IN ASSY.....	112
E	4.14 PRIMARY ASSY	116
	4.15 TRANS 1 ASSYS	120
	4.16 TRANS 2-1 ASSY	121
	4.17 DIODE 1 and VH TR ASSYS	122
	4.18 BRIDGE 1 ASSY.....	123
	4.19 PS/SP ASSY	124
	4.20 TRANS 2-2 ASSY	128
	4.21 POSI 1-L, POSI 2-L and POSI 1-R ASSYS	129
	4.22 TRANS SIDE ASSY	130
F	4.23 IR I/O ASSY	132
	4.24 LOCAL P-SUPPLY ASSY	134
	4.25 DC/DC ASSY	136
	4.26 VIDEO CONNECT ASSY.....	138
	4.27 POWER AMP-L ASSY	140
	4.28 POWER AMP-R ASSY	144
	4.29 POWER AMP IN ASSY.....	148
	4.30 POWER PROTECT ASSY	150

5	6	7	8
4.31 HDMI & DVC ASSY		152	
4.32 USB ASSY (VSX-2016AV-S ONLY).....		156	
5. PCB PARTS LIST		158	
6. ADJUSTMENT		194	
7. GENERAL INFORMATION		195	A
7.1 DIAGNOSIS.....		195	
7.1.1 TEST MODE.....		195	
7.1.2 PROTECTION CIRCUIT SPECIFICATION		198	
7.1.3 DSP TROUBLESHOOTING		200	
7.1.4 HDMI TROUBLESHOOTING		216	
7.1.5 USB MODULE.....		228	
7.1.6 HOW TO UPDATE FIRMWARE.....		233	
7.1.7 HOW TO UPDATE THE FLASH ROMS FOR VARIOUS MICROCOMPUTERS		234	
7.1.8 HOW TO UPDATE THE DSP FLASH ROM BY PLAYING BACK CD.....		236	
7.1.9 DISASSEMBLY		238	
7.2 PARTS		246	
7.2.1 IC		246	B
8. PANEL FACILITIES		261	

C

D

E

F

1. SPECIFICATIONS

A

■ For VSX-2016AV-S

Amplifier section

Continuous Power Output (Stereo)

Front 150 W + 150 W (DIN 1 kHz, THD 1 %, 6 Ω)
120 W + 120 W (DIN 1 kHz, THD 1 %, 8 Ω)

Continuous Power Output (Multichannel)

Front 150 W + 150 W (DIN 1 kHz, THD 1 %, 6 Ω)
120 W + 120 W (DIN 1 kHz, THD 1 %, 8 Ω)

Center 150 W (DIN 1 kHz, THD 1 %, 6 Ω)
120 W (DIN 1 kHz, THD 1 %, 8 Ω)

B Surround 150 W + 150 W (DIN 1 kHz, THD 1 %, 6 Ω)
120 W + 120 W (DIN 1 kHz, THD 1 %, 8 Ω)

Surround back 150 W + 150 W (DIN 1 kHz, THD 1 %, 6 Ω)
120 W + 120 W (DIN 1 kHz, THD 1 %, 8 Ω)

Rated Power Output 130 W+130 W
(20 Hz to 20 kHz, 0.09 %, 6 Ω)

Rated Power Output 110 W+110 W
(20 Hz to 20 kHz, 0.09 %, 8 Ω)

- The above specifications are applicable when the power supply is 230 V.

C Audio Section

Input (Sensitivity/Impedance)

LINE 335 mV/47 kΩ
Frequency Response (LINE) .. 5 Hz to 100 000 Hz ± 3 dB

Output (Level/Impedance)

REC 335 mV/2.2 kΩ

Tone Control

BASS ± 6 dB (100 Hz)
TREBLE ± 6 dB (10 kHz)
LOUDNESS +4 dB / +2 dB (100Hz/10 kHz)
(at volume position -40 dB)

D Signal-to-Noise Ratio (IHF, short circuited, A network)

LINE 103 dB

Signal-to-Noise Ratio

[DIN (continuous rated power output/50mW)]

LINE 92 dB / 65 dB

E Composite Video / S-Video Section

Input (Sensitivity/Impedance) 1 Vp-p/75 Ω

Output (Level/Impedance) 1 Vp-p/75 Ω

Signal-to-Noise Ratio 65 dB

Frequency Response 5 Hz to 10 MHz

F Component Video Section

Input (Sensitivity/Impedance) 1 Vp-p/75 Ω

Output (Level/Impedance) 1 Vp-p/75 Ω

Signal-to-Noise Ratio 65 dB

Frequency Response 5 Hz to 100 MHz

FM Tuner Section

Frequency Range 87.5 MHz to 108 MHz

Usable Sensitivity Mono: 15.2 dBf, IHF (1.6 μV/75 Ω)

50 dB Quieting Sensitivity Mono: 20.2 dBf

Stereo: 41.2 dBf

Sensitivity (DIN) Mono: 1.1 μV (S/N 26 dB)

Stereo: 50 μV (S/N 46 dB)

Signal-to-Noise Ratio Mono: 76 dB (at 85 dBf)

Stereo: 72 dB (at 85 dBf)

Signal-to-Noise Ratio (DIN) Mono: 62 dB

Stereo: 58 dB

Distortion Stereo: 0.6 % (1 kHz)

Alternate Channel Selectivity 70 dB (400 kHz)

Stereo Separation 40 dB (1 kHz)

Frequency Response 30 Hz to 15 kHz ± 1 dB

Antenna Input 75 Ω unbalanced

AM Tuner Section

Frequency Range 531 kHz to 1602 kHz (9 kHz step)

Sensitivity (IHF, Loop antenna) 350 μV/m

Selectivity 30 dB

Signal-to-Noise Ratio 50 dB

Antenna Loop antenna

Miscellaneous

Power Requirements ... AC 220 V to 230 V, 50 Hz / 60 Hz

Power Consumption 450 W

In standby 0.7 W

Dimensions 420 (W) mm x 173 (H) mm x 466 (D) mm

Weight (without package) 15.3 kg

Furnished Parts

Setup microphone (for Auto MCACC setup) 1

AA/LR6 dry cell batteries 2

Remote control unit 1

AM loop antenna 1

FM wire antenna 1

iPod audio control cable 1

Warranty card 1

These operating instructions



Note

- Specifications and the design are subject to possible modifications without notice, due to improvements.

■ For VSX-81TXV, VSX-81TXV-S and VSX-9110TXV-K

Amplifier section (VSX-81TX and VSX-81TXV-S)

Continuous average power output of 110 watts* per channel, min., at 8 ohms, from 20 Hz to 20 000 Hz with no more than 0.09 %** total harmonic distortion (front).

Continuous Power Output (20 Hz to 20 kHz, 8 Ω, 0.09 %)
 Front 110 W + 110 W
 Center 110 W
 Surround 110 W + 110 W
 Surround back 110 W + 110 W

Continuous Power Output (1 kHz, 6 Ω, 1.0 %)
 Front 150 W + 150 W
 Center 150 W
 Surround 150 W + 150 W
 Surround back 150 W + 150 W

Total harmonic distortion 0.09 %
 (20 Hz to 20 kHz, 110 W, 8 Ω)

* Measured pursuant to the Federal Trade Commission's Trade Regulation rule on Power Output Claims for Amplifiers

** Measured by Audio Spectrum Analyzer

Amplifier section (VSX-9110TXV-K)

Continuous average power output of 120 watts* per channel, min., at 8 ohms, from 20 Hz to 20 000 Hz with no more than 0.2 %** total harmonic distortion (front).

Continuous Power Output (20 Hz to 20 kHz, 8 Ω, 0.2 %)
 Front 120 W + 120 W
 Center 120 W
 Surround 120 W + 120 W
 Surround back 120 W + 120 W

Continuous Power Output (1 kHz, 6 Ω, 1.0 %)
 Front 150 W + 150 W
 Center 150 W
 Surround 150 W + 150 W
 Surround back 150 W + 150 W

Total harmonic distortion 0.2 %
 (20 Hz to 20 kHz, 120 W, 8 Ω)

* Measured pursuant to the Federal Trade Commission's Trade Regulation rule on Power Output Claims for Amplifiers

** Measured by Audio Spectrum Analyzer

Audio Section

Input (Sensitivity/Impedance)

LINE 335 mV/47 kΩ
 Frequency Response (LINE) 5 Hz to 100 000 Hz -3 dB

Output (Level/Impedance)
 REC 335 mV/2.2 kΩ

Tone Control
 BASS ± 6 dB (100 Hz)
 TREBLE ± 6 dB (10 kHz)
 LOUDNESS +4 dB / +2 dB (100Hz/10 kHz)
 (at volume position -40 dB)

Signal-to-Noise Ratio (IHF, short circuited, A network)

LINE 103 dB

Signal-to-Noise Ratio [EIA, at 1W (1 kHz)]

LINE 83 dB

Composite Video / S-Video Section

Input (Sensitivity/Impedance)	1 Vp-p/75 Ω
Output (Level/Impedance)	1 Vp-p/75 Ω
Signal-to-Noise Ratio	65 dB
Frequency Response	5 Hz to 10 MHz

Component Video Section

Input (Sensitivity/Impedance)	1 Vp-p/75 Ω
Output (Level/Impedance)	1 Vp-p/75 Ω
Signal-to-Noise Ratio	65 dB
Frequency Response	5 Hz to 100 MHz

FM Tuner Section

Frequency Range	87.5 MHz to 108 MHz	
Usable Sensitivity	Mono: 13.2 dBf, IHF (1.3 μV/75 Ω) 50 dB Quieting Sensitivity	Mono: 20.2 dBf Stereo: 38.6 dBf
Signal-to-Noise Ratio	Mono: 73 dB (at 85 dBf) Stereo: 70 dB (at 85 dBf)	
Distortion	Stereo: 0.5 % (1 kHz)	
Alternate Channel Selectivity	60 dB (400 kHz)	
Stereo Separation	40 dB (1 kHz)	
Frequency Response	30 Hz to 15 kHz ± 1 dB	
Antenna Input	75 Ω unbalanced	

AM Tuner Section

Frequency Range	530 kHz to 1700 kHz
Sensitivity (IHF, Loop antenna)	350 μV/m
Selectivity	25 dB
Signal-to-Noise Ratio	50 dB
Antenna	Loop antenna

Miscellaneous

Power Requirements	AC 120 V, 60 Hz
Power Consumption	490 W, 650 VA
In standby	0.65 W
AC Outlet	(switched) 100 W MAX.
Dimensions	420 (W) mm x 173 (H) mm x 466 (D) mm (16 9/16 (W) in. x 6 13/16 (H) in. x 18 3/8 (D) in.)
Weight (without package)	15.3 kg (33 lbs 12 oz)

Furnished Parts

Setup microphone (for Auto MCACC setup)	1
AA/IEC R6P dry cell batteries	2
Remote control unit	1
AM loop antenna	1
FM wire antenna	1
iPod audio control cable	1
Warranty card	1
These operating instructions	



Note

- Specifications and the design are subject to possible modifications without notice, due to improvements.

A

B

C

D

E


F

A


● Accessories




AM Loop Antenna
(ATB7013)




FM Wire Antenna
(ADH7030)




AA/LR6 Dry Cell Batteries
(VEM1021: VSX-2016AV-S)
AA/IED R6P Dry Cell Batteries
(VEM1031: Other models)



Audio Control Cable for iPod
(ADE7119)



Remote Control Unit
(AXD7432: VSX-2016AV-S)
(AXD7431: Other models)



Setup Microphone
(for Auto MCACC setup)
(APM7008)

Windows Media® and the Windows logo are trademarks or registered trademarks of Microsoft Corporation in the United States and/or other countries.

D The THX logo is a trademark of THX Ltd. which may be registered in some jurisdictions. All rights reserved.

Manufactured under license from Dolby Laboratories.
"Dolby", "Pro Logic", "Surround EX", and the double-D symbol are trademarks of Dolby Laboratories.

"DTS", "DTS-ES", "Neo:6" and "DTS 96/24" are trademarks of Digital Theater Systems, Inc.

E

F

■ 5 ■

6 ■

7 ■

8 ■

A ■

B ■

C ■

D ■

E ■

F ■

■ 5 ■

6 ■

VSX-2016AV-S

7 ■

9 ■


8 ■

2. EXPLODED VIEWS AND PARTS LIST

NOTES:

- Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.
- The \triangle mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- Screws adjacent to ∇ mark on product are used for disassembly.
- For the applying amount of lubricants or glue, follow the instructions in this manual.
(In the case of no amount instructions, apply as you think it appropriate.)

2.1 PACKING SECTION



(1) PACKING SECTION PARTS LIST

Mark No.	Description	Part No.	Mark No.	Description	Part No.
1	iPod Audio Control Cable	ADE7119	15	Battery Cover	XZN3140
2	Setup Microphone (for Auto MCACC setup)	APM7008	NSP 16	Dry Cell Battery	See Contrast table (2)
3	FM Wire Antenna	ADH7030	NSP 17	Polyethylene Bag	See Contrast table (2)
4	AM Loop Antenna	ATB7013	18	Front Pad	AHA7456
			19	Rear Pad	AHA7457
NSP 5	Warranty Card	See Contrast table (2)	20	Packing Sheet	RHC1023
6	Caution Sheet(Spanish/English)	ARM7083	21	Packing Case	See Contrast table (2)
7	Disclaimer	See Contrast table (2)	22	LABEL (WEEE)	See Contrast table (2)
8	Operating Instructions (English)	See Contrast table (2)			
9	Operating Instructions (French)	See Contrast table (2)			
10	Operating Instructions (German)	See Contrast table (2)			
11	Operating Instructions (Italian)	See Contrast table (2)			
12	Operating Instructions (Spanish)	See Contrast table (2)			
13	Operating Instructions (Dutch)	See Contrast table (2)			
14	Remote Control Unit	See Contrast table (2)			


(2) CONTRAST TABLE

VSX-2016AV-S/HYXJ5, VSX-81TXV/KUXJCA, VSX-81TXV-S/KUXJCA and VSX-9110TXV-K/KUXJ are constructed the same except for the following:

Mark	No.	Symbol and Description	VSX-2016AV-S /HYXJ5	VSX-81TXV /KUXJCA	VSX-81TXV-S /KUXJCA	VSX-9110TXV-K /KUXJ
NSP	5	Warranty Card	ARY7065	ARY7007	ARY7007	ARY7045
	7	Disclaimer (English/French/German/Italian /Spanish/Dutch)	ARX7081	Not used	Not used	Not used
	7	Disclaimer (English/French)	Not used	ARX7080	ARX7080	ARX7080
	8	Operating Instructions (English)	ARB7355	ARB7356	ARB7356	ARB7357
	9	Operating Instructions (French)	ARC7693	Not used	Not used	Not used
	10	Operating Instructions (German)	ARC7694	Not used	Not used	Not used
	11	Operating Instructions (Italian)	ARC7695	Not used	Not used	Not used
	12	Operating Instructions (Spanish)	ARC7696	Not used	Not used	Not used
	13	Operating Instructions (Dutch)	ARC7697	Not used	Not used	Not used
	14	Remote Control Unit	AXD7432	AXD7431	AXD7431	AXD7431
NSP	16	Dry Cell Battery AA/LR6	VEM1021	Not used	Not used	Not used
NSP	16	Dry Cell Battery AA/IEC R6P	Not used	VEM1031	VEM1031	VEM1031
NSP	17	Polyethylene Bag	AHG7132	AHG7117	AHG7117	AHG7117
	21	Packing Case 2016SHY	AHD8437	Not used	Not used	Not used
	21	Packing Case 81KKU	Not used	AHD8428	Not used	Not used
	21	Packing Case 81SKU	Not used	Not used	AHD8432	Not used
	21	Packing Case 9110KKU	Not used	Not used	Not used	AHD8433
	22	LABEL (WEEE)	ARW7322	Not used	Not used	Not used

2.2 EXTERIOR SECTION


A




B




C




D



E



Refer to
"2.3 CHASSIS SECTION".



F

Refer to
"2.6 FRONT PANEL SECTION".

(1) EXTERIOR SECTION PARTS LIST

<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>	
1	Bonnet	See Contrast table (2)	
3	Insulator	See Contrast table (2)	A
6	Screw	BBZ30P080FCC	
7	Screw	See Contrast table (2)	
8	Screw	IBP30P090FCC	
11	4P Shielded Cable	See Contrast table (2)	
12	Earth Spring	ABH7245	

(2) CONTRAST TABLE

VSX-2016AV-S/HYXJ5, VSX-81TXV/KUXJCA, VSX-81TXV-S/KUXJCA and VSX-9110TXV-K/KUXJ are constructed the same except for the following:

Mark	No.	Symbol and Description	VSX-2016AV-S /HYXJ5	VSX-81TXV /KUXJCA	VSX-81TXV-S /KUXJCA	VSX-9110TXV-K /KUXJ
	1	Bonnet 2016S	AZN8020	Not used	AZN8020	Not used
	1	Bonnet 81B	Not used	AZN8021	Not used	AZN8021
	3	Insulator	PNW2766	AMR7198	AMR7198	PNW2766
	7	Screw	BCZ40P060FNI	BCZ40P060FTB	BCZ40P060FNI	BCZ40P060FTB
	11	4P Shielded Cable	XDX3028	Not used	Not used	Not used

A

B

C


D

E

F

2.3 CHASSIS SECTION

A



14

VSX-2016AV-S

1

2

3

4

(1) CHASSIS SECTION PARTS LIST

<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>	<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>
1	PRIMARY Assy	See Contrast table (2)	26	SP Sheet 2016	AEC7560
2	TRANS 1 Assy	AWX9038	27	Nylon Rivet	AEC7408
3	TRANS 2-1 Assy	See Contrast table (2)	28	Nylon Rivet	AEC7406
4	TRANS 2-2 Assy	AWX9062	29	Locking Card Spacer	PNW2917
5	DIODE 1 Assy	AWX9060	30	PCB Mold	AMR2534
6	PS/SP Assy	See Contrast table (2)	31	Inter Holder A	AMR7500
7	DC/DC Assy	AWX9015	32	Inter Holder B	AMR7501
8	LOCAL P-SUPPLY Assy	See Contrast table (2)	33	Card Spacer	DNK2769
9	GUARD-C Assy	AWX9051	NSP 34	Under Base 2016	ANA7189
10	GUARD-F Assy	AWX9070	NSP 35	Panel Stay 2016	AND7082
11	BRIDGE 1 Assy	AWX9078	36	Side Clamp	DEC2007
12	12V-REG Assy	AWX9014	37	Under Beam V1	ANG7478
13	VH TR Assy	AWX9061	NSP 38	Trans Frame 74	ANG7539
14	TRANS SIDE Assy	AWX9056	NSP 39	Binder	ZCA-BK1
△ 15	Fuse (FU1)	See Contrast table (2)	40	Screw 3x15	ABA7100
△ 16	Fuse (FU7,FU8)	See Contrast table (2)	41	Screw	ABA7109
△ 17	Fuse (FU4)	See Contrast table (2)	42	Screw	BBT30P100FCC
△ 18	Fuse (FU5,FU6)	See Contrast table (2)	44	Screw	BBZ30P080FCC
△ 19	Power Transformer (T1501)	See Contrast table (2)	49	Bridge Spacer	AEB7201
△ 20	AC Power Cord	See Contrast table (2)	50	Primary Barrier	See Contrast table (2)
21	Cord Stopper	See Contrast table (2)	51	Shield Case	See Contrast table (2)
22	Primary Angle 56	ANG7526	NSP 52	Fuse Card	See Contrast table (2)
NSP 23	Wire Saddle	DEC1450	NSP 53	Fuse Card	See Contrast table (2)
24	DSP Shield 2016	ANG7546	NSP 54	Fuse Card	See Contrast table (2)
25	Cushion Circle 14B	AED7081	NSP 55	Fuse Card	See Contrast table (2)

(2) CONTRAST TABLE

VSX-2016AV-S/HYXJ5, VSX-81TXV/KUXJCA, VSX-81TXV-S/KUXJCA and VSX-9110TXV-K/KUXJ are constructed the same except for the following:



<u>Mark</u>	<u>No.</u>	<u>Symbol and Description</u>	<u>VSX-2016AV-S /HYXJ5</u>	<u>VSX-81TXV /KUXJCA</u>	<u>VSX-81TXV-S /KUXJCA</u>	<u>VSX-9110TXV-K /KUXJ</u>
△	1	PRIMARY Assy	AWX9035	AWX9034	AWX9034	AWX9034
	3	TRANS 2-1 Assy	AWX9059	AWX9058	AWX9058	AWX9058
	6	PS/SP Assy	AWX9107	AWX9052	AWX9052	AWX9052
	8	LOCAL P-SUPPLY Assy	AWX9064	AWX9063	AWX9063	AWX9063
△	15	Fuse (FU1: T5 A L 250 V)	REK1029	Not used	Not used	Not used
△	15	Fuse (FU1: 10 A/125 V)	Not used	REK1154	REK1154	REK1154
△	16	Fuse (FU7,FU8: T2.5 A L 250 V)	REK1026	Not used	Not used	Not used
△	16	Fuse (FU7,FU8: 2.5 A/125 V)	Not used	REK1146	REK1146	REK1146
△	17	Fuse (FU4: T4 A L 250 V)	REK1028	Not used	Not used	Not used
△	17	Fuse (FU4: 5 A/125 V)	Not used	REK1067	REK1067	REK1067
△	18	Fuse (FU5,FU6: T800 mA L 250 V)	REK1021	Not used	Not used	Not used
△	18	Fuse (FU5,FU6: 1.25 A/125 V)	Not used	REK1143	REK1143	REK1143
△	19	Power Transformer (T1501)	ATS7408	ATS7407	ATS7407	ATS7407
△	20	AC Power Cord	VDG1080	VDG1075	VDG1075	VDG1075
	21	Cord Stopper	CM-22B	CM-22C	CM-22C	CM-22C
NSP	50	Primary Barrier	AEC7569	Not used	Not used	Not used
NSP	51	Shield Case	AMR7526	Not used	Not used	Not used
NSP	52	Fuse Card	AAX7098	Not used	Not used	Not used
NSP	53	Fuse Card	AAX7277	Not used	Not used	Not used
NSP	54	Fuse Card	AAX7099	Not used	Not used	Not used
NSP	55	Fuse Card	AAX2367	Not used	Not used	Not used

1 2 3 4
2.4 REAR SECTION

A

- VSX-2016AV-S

B



(1) REAR SECTION PARTS LIST

<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>
1	BRIDGE 2 Assy	AWX9050
2	VIDEO CONNECT Assy	AWX9069
3	COMPONENT Assy	AWX9031
4	S-VIDEO Assy	AWX9030
5	COMPOSITE Assy	AWX9028
6	IR I/O Assy	AWX9067
7	MAIN CONTROL Assy	AWX9009
8	HDMI & DVC Assy	AWQ7037
9	AUDIO IN Assy	AWX9013
10	USB Assy	AWX8704
11	DSP Assy	AWX8698
12	FM/AM Tuner Unit	AXX7170
13	Rear Panel 2016SHY	ANC8377
14	19P FFC/60V (J58)	ADD7535
15	11P FFC/60V (J59)	ADD7536
16	17P FFC/60V (J54)	ADD7540
17	29P FFC/60V (J55)	ADD7532
18	19P FFC/60V (J56)	ADD7533
20	10P FFC/60V (J51)	ADD7528
21	Card Spacer	AEC7214
23	Screw	BBZ26P080FCC
24	Screw	BBZ30P080FCC
27	Screw	PMZ30P060FCC

A

B


C

D

E

F

- VSX-81TXV, -S, VSX-9110TXV-K



(1) REAR SECTION PARTS LIST

<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>	<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>
1	BRIDGE 2 Assy	AWX9050	16	17P FFC/60V (J54)	ADD7540
2	VIDEO CONNECT Assy	AWX9069	17	29P FFC/60V (J55)	ADD7532
3	COMPONENT Assy	See Contrast table (2)	18	19P FFC/60V (J56)	ADD7533
4	S-VIDEO Assy	See Contrast table (2)	19	12P FFC/60V (J52)	See Contrast table (2)
5	COMPOSITE Assy	See Contrast table (2)	20	10P FFC/60V (J51)	ADD7528
6	IR I/O Assy	See Contrast table (2)			
7	MAIN CONTROL Assy	See Contrast table (2)	21	Card Spacer	AEC7214
8	HDMI & DVC Assy	AWQ7037	23	Screw	BBZ26P080FCC
9	AUDIO IN Assy	See Contrast table (2)	24	Screw	BBZ30P080FCC
11	DSP Assy	See Contrast table (2)	27	Screw	PMZ30P060FCC
12	FM/AM Tuner Unit	See Contrast table (2)	29	Screw 2.85 x 7	ABA7078
13	Rear Panel	See Contrast table (2)			
14	19P FFC/60V (J58)	ADD7535			
15	11P FFC/60V (J59)	ADD7536			

(2) CONTRAST TABLE

VSX-81TXV/KUXJCA, VSX-81TXV-S/KUXJCA and VSX-9110TXV-K/KUXJ are constructed the same except for the following:

<u>Mark</u>	<u>No.</u>	<u>Symbol and Description</u>	<u>VSX-81TXV /KUXJCA</u>	<u>VSX-81TXV-S /KUXJCA</u>	<u>VSX-9110TXV-K /KUXJ</u>
	3	COMPONENT Assy	AWX9032	AWX9032	AWX9032
	4	S-VIDEO Assy	AWX9029	AWX9029	AWX9029
	5	COMPOSITE Assy	AWX9026	AWX9026	AWX9026
	6	IR I/O Assy	AWX9066	AWX9066	AWX9066
	7	MAIN CONTROL Assy	AWX9008	AWX9008	AWX9008
	9	AUDIO IN Assy	AWX9012	AWX9012	AWX9012
	11	DSP Assy	AWX8697	AWX8697	AWX8697
	12	FM/AM Tuner Unit	AXX7172	AXX7172	AXX7172
	13	Rear Panel 81KKU	ANC8378	Not used	Not used
	13	Rear Panel 81SKU	Not used	ANC8379	Not used
	13	Rear Panel 9110KKU	Not used	Not used	ANC8380
	19	12P FFC/60V (J52)	ADD7529	ADD7529	ADD7529

C


D

E

F

2.5 POWER AMP SECTION

A



E

F

(1) POWER AMP SECTION PARTS LIST

<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>	<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>
1	POSI 2-L Assy	See Contrast table (2)	11	H.S. Angle 2016	ANG7547
2	POWER AMP-L Assy	See Contrast table (2)	12	Nyron Rivet	AEC7408
3	POWER AMP-R Assy	See Contrast table (2)	13	17P FFC/60V (J57)	ADD7534
4	POSI 1-L Assy	See Contrast table (2)	⚠ 14	DC Fan Motor	See Contrast table (2)
5	POSI 1-R Assy	See Contrast table (2)	NSP 15	Binder	ZCA-BK1
6	POWER AMP IN Assy	AWX9075	16	Screw 3X19	ABA7085
7	POWER PROTECT Assy	See Contrast table (2)	17	Screw	See Contrast table (2)
NSP 8	Heat Sink 45	ANH7152	18	Screw	BBT30P100FCC
9	PCB Angle 45	ANG7406	20	Screw	BBZ30P080FCC
10	Mica Sheet 45	AEE7047			

A

B

(2) CONTRAST TABLE

VSX-2016AV-S/HYXJ5, VSX-81TXV/KUXJCA, VSX-81TXV-S/KUXJCA and VSX-9110TXV-K/KUXJ are constructed the same except for the following:

<u>Mark</u>	<u>No.</u>	<u>Symbol and Description</u>	<u>VSX-2016AV-S /HYXJ5</u>	<u>VSX-81TXV /KUXJCA</u>	<u>VSX-81TXV-S /KUXJCA</u>	<u>VSX-9110TXV-K /KUXJ</u>
	1	POSI 2-L Assy	AWX9082	Not used	Not used	Not used
	2	POWER AMP-L Assy	AWX9072	AWX9071	AWX9071	AWX9071
	3	POWER AMP-R Assy	AWX9073	AWX9106	AWX9106	AWX9106
	4	POSI 1-L Assy	AWX9081	AWX9080	AWX9080	AWX9080
	5	POSI 1-R Assy	AWX9084	AWX9083	AWX9083	AWX9083
⚠	7	POWER PROTECT Assy	AWX9077	AWX9076	AWX9076	AWX9076
	14	DC Fan Motor	AXM7029	Not used	Not used	Not used
	17	Screw	BBZ30P300FTC	Not used	Not used	Not used

C


D

E


F

2.6 FRONT PANEL SECTION

A




B




C

D



E



F

(1) FRONT PANEL SECTION PARTS LIST

<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>	<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>
1	HEADPHONE Assy	AWX9049	NSP 16	Func BTN Assy	See Contrast table (2)
2	MULTI JOG Assy	See Contrast table (2)	17	STDBY BTN Assy	See Contrast table (2)
3	DISPLAY Assy	See Contrast table (2)	21	Screw	BBZ30P080FCC
4	VOLUME Assy	See Contrast table (2)	25	Screw	PPZ30P080FNI
5	FRONT-IN Assy	See Contrast table (2)	26	Earth Plate	See Contrast table (2)
7	F Panel	See Contrast table (2)	NSP 27	Energy Star Label	See Contrast table (2)
8	Pioneer Name Plate	See Contrast table (2)			
9	Window	See Contrast table (2)			
10	Rotary Knob	See Contrast table (2)			
11	Input Cover	See Contrast table (2)			
12	Ring	ABH7213			
13	P Base Assy	See Contrast table (2)			
NSP 14	P Base	See Contrast table (2)			
NSP 15	Side Button	See Contrast table (2)			


(2) CONTRAST TABLE


VSX-2016AV-S/HYXJ5, VSX-81TXV/KUXJCA, VSX-81TXV-S/KUXJCA and VSX-9110TXV-K/KUXJ are constructed the same except for the following:

<u>Mark</u>	<u>No.</u>	<u>Symbol and Description</u>	<u>VSX-2016AV-S /HYXJ5</u>	<u>VSX-81TXV /KUXJCA</u>	<u>VSX-81TXV-S /KUXJCA</u>	<u>VSX-9110TXV-K /KUXJ</u>
	2	MULTI JOG Assy	AWX9112	AWX9045	AWX9112	AWX9045
	3	DISPLAY Assy	AWX9103	AWX9040	AWX9040	AWX9040
	4	VOLUME Assy	AWX9111	AWX9044	AWX9111	AWX9044
	5	FRONT-IN Assy	AWX9048	AWX9047	AWX9047	AWX9047
	7	F Panel 2016SHY	ANB7400	Not used	Not used	Not used
	7	F Panel 81KKU		ANB7397	Not used	Not used
	7	F Panel 81SKU		Not used	ANB7398	Not used
	7	F Panel 9110KKU		Not used	Not used	ANB7399
	8	Pioneer Name Plate	VAM1129	VAM1109	VAM1129	Not used
	8	Pioneer Badge B		Not used	Not used	XAM3006
	9	Window 2016HY	AAK8330	Not used	AAK8330	AAK8330
	9	Window 81K	Not used	AAK8331	Not used	Not used
	10	Rotary Knob P	AAA7033	Not used	AAA7033	Not used
	10	Rotary Knob B	Not used	AAA7024	Not used	AAA7024
	11	Input Cover V3S	XAK3533	Not used	XAK3533	Not used
	11	Input Cover 81K		AAK8355	Not used	Not used
	13	P Base 2016SHY Assy	AXG7287	Not used	Not used	Not used
	13	P Base 81KKU Assy	Not used	AXG7290	Not used	Not used
	13	P Base 81SKU Assy	Not used	Not used	AXG7308	Not used
	13	P Base 9110KKU Assy	Not used	Not used	Not used	AXG7309
NSP	14	P Base 2016SHY	AMB7920	Not used	Not used	Not used
NSP	14	P Base 81KKU	Not used	AMB7919	Not used	Not used
NSP	14	P Base 81SKU	Not used	Not used	AMB7925	Not used
NSP	14	P Base 9110KKU	Not used	Not used	Not used	AMB7921
NSP	15	Side Button S	AAD7760	Not used	AAD7760	Not used
NSP	15	Side Button K		AAD7761	Not used	AAD7761
NSP	16	Func BTN S Assy	AAD7757	Not used	AAD7757	Not used
NSP	16	Func BTN K Assy	Not used	AAD7758	Not used	AAD7758
NSP	17	STDBY BTN 915P Assy	XAD3217	Not used	XAD3217	Not used
NSP	17	STDBY BTN 915K Assy	Not used	XAD3216	Not used	XAD3216
NSP	26	Earth Plate	ABK7062	Not Used	ABK7062	Not used
NSP	27	Energy Ster Label	Not used	AAX8022	AAX8022	AAX8022


3. BLOCK DIAGRAM AND SCHEMATIC DIAGRAM

3.1 BLOCK DIAGRAM for AUDIO BLOCK






3.2 BLOCK DIAGRAM for VIDEO BLOCK



A



B


C


D

E

F


3.3 OVERALL WIRING DIAGRAM







- When ordering service parts, be sure to refer to "EXPLODED VIEWS and PARTS LIST" or "PCB PARTS LIST".
- The mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- : The power supply is shown with the marked box.

POSI 1-L ASSY
(VSX-2016AV : AWX9081)
(VSX-81TXV, VSX-9110TXV : AWX9080)




FM/AM TUNER UNIT
(VSX-2016AV : AXX7170)
(VSX-81TXV, VSX-9110TXV : AXX7172)




POWER CORD

VSX-2016AV : VDG1080
VSX-81TXV, VSX-9110TXV : VDG1075




3.4 AUDIO IN ASSY (1/2)



A 1/2

A 1/2 AUDIO IN ASSY

(VSX-2016AV : AWX9013)
(VSX-81TXV, VSX-9110TXV : AWX9012)




3.5 AUDIO IN (2/2) and 12V-REG ASSYS


2

4

A



C




32

VSX-2016AV-S

4

A 2/2 AUDIO IN ASSY (VSX-2016AV : AWX9013) (VSX-81TXV, VSX-9110TXV : AWX9012)



| NOTE

- NOTE**

1. RESISTORS
Unit: k Ω , M Ω or Ω unless otherwise noted.
Rated power: 1/16W unless otherwise noted.
Tolerance: (\pm) 5% unless otherwise noted.

2. CAPACITORS
Unit: pF or μ F unless otherwise noted.
Ratings: Capacity(μ F)/Voltage(V) unless otherwise noted.
Rated Voltage: 50V except for electrolytic

(L) : Audio Signal Route (L ch)

(M) → : Audio Signal Route (Mic-in)

: Audio Signal Route (Mic ch)

: Audio Signal Route (Front L ch)
(SI)

 : Audio Signal Route (Surround L)

(C) →: Audio Signal Route (Center ch)

(SBL) → : Audio Signal Route (Surround Back L)


(SW) → : Audio Signal Route (SubWoofer ch)

A

3.6 MAIN CONTROL ASSY (1/3)

C 1/3 MAIN CONTROL ASSY (VSX-2016AV : AWX9009) (VSX-81TXV, VSX-9110TXV : AWX9008)

A



1

2

3

4


34

C 1/3

L CN2301


Z 3502


VSX-2016AV-S



3.7 MAIN CONTROL (2/3), GUARD-C and GUARD-F ASSYS

C 2/3 MAIN CONTROL ASSY (VSX-2016AV : AWX9009) (VSX-81TXV, VSX-9110TXV : AWX9008)






C 2/3 D E


3.8 MAIN CONTROL ASSY (3/3)

A


AB CN3702




B




C



D




E



F

C 3/3

CN5812
V

2

3

4


AB CN3702

C 1/3 (TUNER)






C 2/3 (USB)

C 1/3 (MR)


C 2/3 (XM)




IC105 CD4094BPW PORT EXPANDER

A 2/2 CN509
K CN1401A 2/2 CN509
K CN1401


H CN1001




CN110 XKP3065



CN113 CKS382





(L) : Audio Signal Route (L ch)

(M) : Audio Signal Route (Mic ch)

(D) : Audio Data Route

(V) : Video Signal Route

(SY) : S-Video Signal Route (Y ch)


(SC) : S-Video Signal Route (C ch)

3.9 DSP ASSY (1/4)


G 1/4 DSP ASSY
(VSY 2016)

(VSX-2016AV : AWX8698)

(VSX-81TXV, VSX-9110TXV : AWX8697)



G 1/4




A 2/2 CN507

3.10 DSP ASSY (2/4)

G 2/4 DSP ASSY


(VSX-2016AV : AWX8698)

(VSX-81TXV, VSX-9110TXV : AWX8697)



G 2/4

(D) → : Audio Data Route




3.11 DSP ASSY (3/4)


G 3/4 DSP ASSY

(VSX-2016AV : AWX8698)

(VSX-81TXV, VSX-9110TXV : AWX8697)



** AROUND R247
The corrective is not "CDTI" but "SDTI".
But now the connection of PCB is like this.
If this route is used, it should correct the PCB.
(NOW NO USE THIS ROUTE)



(D) → : Audio Data Route

A

D

E

E

G 3/4


3.12 DSP ASSY (4/4)

G 4/4 DSP ASSY
(VSY 2016)

(VSX-2016AV : AWX8698)

(VSX-81TXV, VSX-9110TXV : AWX8697)

AK 2/2 CN1001



C 2/3 CN305

VSX-81TXV, VSX-9110TXV
ONLY


A 2/2 CN512

8

G 4/4


(D) : Audio Data Route


A



3.13 COMPOSITE ASSY


H COMPOSITE ASSY
(VSX-2016AV : AWX9028)
(VSX-81TXV, VSX-9110TXV : AWX9026)






3.14 S-VIDEO and BRIDGE 2 ASSYS

I S-VIDEO ASSY (VSX-2016AV : AWX9030) (VSX-81TXV, VSX-9110TXV : AWX9029)






S-VIDEO


GCS (CHASSIS)

VSX-81TXV,
VSX-911TXV
ONLY

JA1351

RKN1004
12V TRIGGER
(DC OUT 12V /100mA MAX)

J BRIDGE 2 ASSY (AWX9050)

**AC CN3803****A 2/2**
CN2901 XXP3068

V-12A	FRO	(FO)
GND	GND	(SL)
GND	GND	(C)
FLO	GND	(SBL)
GND	GND	(SW)
SRO	GND	(SY)
GND	GND	(SC)
SLO	GND	
SWO	GND	
GND	GND	
CO	GND	
GND	GND	
SBRO	GND	
GND	GND	
SBLO	GND	


CN2902 XXP3068

V-12A	FRO	(FO)
GND	GND	(SL)
GND	GND	(C)
FLO	GND	(SBL)
GND	GND	(SW)
SRO	GND	(SY)
GND	GND	(SC)
SLO	GND	
SWO	GND	
GND	GND	
CO	GND	
GND	GND	
SBRO	GND	
GND	GND	
SBLO	GND	


K CN1405**I J**

3.15 COMPONENT ASSY

K COMPONENT ASSY (VSX-2016AV : AWX9031) (VSX-81TXV, VSX-9110TXV : AWX9032)



- (FL) : Audio Signal Route (Front L ch)
- (SL) : Audio Signal Route (Surround L ch)
- (C) : Audio Signal Route (Center ch)
- (SBL) : Audio Signal Route (Surround Back L ch)
- (SW) : Audio Signal Route (SubWoofer ch)
- (Y) : Video Signal Route (Component Y ch)
- (Cb) : Video Signal Route (Component Cb ch)
- (Cr) : Video Signal Route (Component Cr ch)


**NOTES**

- RESISTORS: Unit k- Ω , M- Ω or Ω unless otherwise noted.
- CAPACITORS: No marked Capacitors are C_{EAT} or C_{SRV} . Unit μ F or μ F unless otherwise noted. Tolerance: $\pm 5\%$ unless otherwise noted.
- DIODES: No marked Diodes are 1SS355.
- Parts or parts block marked by "STBY" are standby.

- CAPACITORS: No marked Capacitors are C_{EAT} or C_{SRV} . Unit μ F or μ F unless otherwise noted. Tolerance: $\pm 5\%$ unless otherwise noted.
- DIODES: No marked Diodes are 1SS355.
- Parts or parts block marked by "STBY" are standby.

3.16 DISPLAY, VOLUME and MULTI JOG ASSYS

A **L** DISPLAY ASSY
 (VSX-2016AV : AWX9103)
 (VSX-81TXV, VSX-9110TXV : AWX9040)




VOLUME ASSY


VOLUME ASSIST
S2451 : SIGNAL SELECT
S2452 : SBCH PROCESSING
S2453 : MULTI CH IN
S2454 : MASTER VOLUME

MULTI JOG ASSY

S2551 : MULTI JOG
S2551 : DVR/VCR2
S2552 : VIDEO/GAME
S2553 : CD
S2554 : CD-R/TAPE/MD
S2555 : FM/AM
S2556 : USB (XM)
S2557 : iPod
S2558 : HDMI
S2561 : ENTER
S2562 : SYSTEM SETUP
S2563 : RETURN
S2564 : TONE
S2565 : TUNING/STATION
S2566 : TUNER EDIT
S2567 : SPEAKERS
S2571 : Ⓜ STANDBY/ON
S2572 : EON MODE (MULTI ROOM ON/OFF)
S2573 : PTY SEARCH (MULTI ROOM CONTROL)
S2574 : LISTENING MODE
S2575 : DVD/LD
S2576 : TV/SAT
S2577 : DVR/VCR1




IC2301
PE5503A
(NEC)
DISPLAY U-COM




3.17 HEADPHONE, FRONT-IN, PRIMARY and TRANS 1 ASSYS


O HEADPHONE ASSY (AWX9049)



P FRONT-IN ASSY (VSX-2016AV : AWX9048)
(VSX-81TXV, VSX-9110TXV : AWX9047)



**Q PRIMARY ASSY (VSX-2016AV : AWX9035)
(VSX-81TXV, VSX-9110TXV : AWX9034)**




1 2 3 4
3.18 TRANS 2-1, DIODE 1, VH TR, BRIDGE 1 and PS/SP ASSYS

A


S TRANS 2-1 ASSY
(VSX-2116AV : AWX9059)
(VSX-81TXV, VSX-9110TXV : AWX9058)

CAUTION : FOR CONTINUED PROTECTION AGAINST RISK OF FIRE. REPLACE ONLY WITH SAME TYPE NO. 491007 MFD, BY LITTELFUSE INC. FOR IC3251 and IC3252.

T DIODE 1 ASSY
(AWX9060)



B




C

V BRIDGE 1 ASSY
(AWX9078)

CN5812 XXP3071

CN5811 XXP3071



AK 2/2
CN1002

J3251 D20PDY0610E C -B -VH +VH C -B +VH C -B -56V

3251
51048-0600


CN3351
52147-0610

U

VH TR ASSY
(AWX9061)

CAUTION : FOR CONTINUED PROTECTION AGAINST RISK OF FIRE. REPLACE ONLY WITH SAME TYPE NO. ICP-N15, MFD BY ROHM CO., LTD. FOR IC3351 and IC3352.

S T U V



3.19 TRANS 2-2, TRANS SIDE, LOCAL P-SUPPLY, DC/DC, IR I/O and VIDEO CONNECT ASSYS

Z LOCAL P-SUPPLY ASSY (VSX-2016AV : AWX9064) (VSX-81TXV, VSX-9110TXV : AWX9063)

• NOTE FOR FUSE REPLACEMENT
CAUTION -FOR CONTINUED PROTECTION AGAINST RISK OF FIRE.
REPLACE WITH SAME TYPE AND RATINGS ONLY.

FU4
VSX-2016 : REK1028 (T4AL/250V)
VSX-81TXV, VSX-9110TXV : REK1067 (5A/125V)

FU5, FU6
VSX-2016 : REK1021 (T800mAL/250V)
VSX-81TXV, VSX-9110TXV : REK1143 (1.25A/125V)

FU7, FU8
VSX-2016 : REK1026 (T2.5AL/250V)
VSX-81TXV, VSX-9110TXV : REK1146 (2.5A/125V)

J3401 PF 2PG-R40

FL C3401 STBY

VREG C3401 STBY

FU8 H3402 H3401 AKR7001

FU7 H3403 H3403 AKR7001


FU4 H3406 H3405 AKR7001

FU5 H3408 H3407 AKR7001


FU6 H3410 H3409 AKR7001

DREG C3401 STBY

(L) : Audio Signal Route (L ch)
(D) : Audio Data Route





AB IR I/O ASSY (VSX-2016AV : AWX9067) (VSX-81TXV, VSX-9110TXV : AWX9066)



3.20 POWER AMP-L, POSI 1-L and POSI 2-L ASSYS


AD POWER AMP-L ASSY (VSX-2016AV : AWX9072)
(VSX-81TXV, VSX-9110TXV : AWX9071)






3.21 POWER AMP-R and POSI 1-R ASSYS

AG POWER AMP-R ASSY (VSX-2016AV : AWX9073)
(VSX-81TXV, VSX-9110TXV : AWX9106)



(C) → : Audio Signal Route (Center ch)



3.22 POWER AMP IN and POWER PROTECT ASSYS

2

4

A

A

B

6



1

AJ

1

6


1



10

AI | AJ

VSX-2016AV-S




(FL) : Audio Signal Route (Front L ch)
 (SL) : Audio Signal Route (Surround L ch)
 (C) : Audio Signal Route (Center ch)
 (SBL) : Audio Signal Route (Surround Back L ch)

W CN3003

NOTE
1.RESISTORS
 Unit: k Ω , M Ω or Ω unless otherwise noted.
 Rated power: 1/16W unless otherwise noted.
 Tolerance: (\pm) $\pm 5\%$ unless otherwise noted.
2.CAPACITORS
 Unit: pF or μ F unless otherwise noted.
 Ratings: Capacitance(μ F)/Voltage(V) unless otherwise noted.
 Rated Voltage: 50V except for electrolytic capacitors.


AD CN5003




AI AJ

3.23 HDMI & DVC ASSY (1/2)


AK 1/2 HDMI & DVC ASSY (AWQ7037)




AK 1/2




3.24 HDMI & DVC ASSY (2/2)



AK 2/2 HDMI & DVC ASSY (AWQ7037)



C 4/4
CN801




V
CN5811


Chip Size	RESISTOR
	: 2 1 2 5 Size RS1/10S~
	: 1 6 0 8 Size RS1/16S~
CAPACITOR	: 2 1 2 5 Size CKS0**~
	: 1 6 0 8 Size CCS0**~ CKS0**~

AK 2/2



3.25 USB ASSY (VSX-2016AV-S ONLY)

A AL USB ASSY (AWX8704)





A 2/2
CN516



Chip Size	
RESISTOR	: 2125 Size RS1/10S~
CAPACITOR	: 1608 Size RS1/16S~
ELECTRIC CAPS	: 2125Size CKS0**~
	: 1608 Size CCSR**~ CKSR**~

ELECTRIC CAPS	
+	JQ : CEJQ***M**

AL

4. PCB CONNECTION DIAGRAM

A

NOTE FOR PCB DIAGRAMS :


1. Part numbers in PCB diagrams match those in the schematic diagrams.
2. A comparison between the main parts of PCB and schematic diagrams is shown below.

Symbol In PCB Diagrams	Symbol In Schematic Diagrams	Part Name
		Transistor
		Transistor with resistor
		Field effect transistor
		Resistor array
		3-terminal regulator

3. The parts mounted on this PCB include all necessary parts for several destinations.

For further information for respective destinations, be sure to check with the schematic diagram.

4. View point of PCB diagrams.



B

C

D

E

F

■ 5 ■

6 ■

7 ■

8 ■

A ■

B ■

C ■

D ■

E ■

F ■

■ 5 ■

6 ■

7 ■

8 ■

VSX-2016AV-S

75 ■

4.1 AUDIO IN ASSY

SIDE A

A

B

C

5

E

76

A vertical scale starting at 0 and ending at 220, with major tick marks labeled every 10 units: 0, 10, 20, 30, 40, 50, 60, 70, 80, 90, 100, 110, 120, 130, 140, 150, 160, 170, 180, 190, 200, 210, 220.

2

AUDIO IN ASSY

AA CN651

C CN302

C CN301

3 | P 13504

AI CN703

P 1663


2 2

AUDIO IN ASSY
PRODUCTION CODE

AWX9012 AWX90
 AWX9013 AWX
 AWX9087

VSX-2016AV-S

SIDE A



A

SIDE B

A

B

C

D

E


(ANP7559-C)

CN507

CN509

CN512

A AUDIO IN ASSY



A horizontal number line starting at 0 and ending at 12. There are 12 tick marks in total, including the start and end points. The labels 1 through 12 are placed below the line, corresponding to each tick mark.

VSX-2016AV-S

SIDE B

A

220

210

200

190

180

170

160

150

140

130

120

110

100

90

80

70

60

50

40

30

20

10


0

C

D

E

F

A

4.2 12V-REG ASSY

SIDE A

SIDE A

A

B

C

D

E

F

G


1

2

3

4

B 12V-REG ASSY




SIDE B

SIDE B

D

E

F



B 12V-REG ASSY

B

B

80

1

2

3


4

■ 5 ■ 6 ■ 7 ■ 8

4.3 BRIDGE 2 ASSY


SIDE A

SIDE A



SIDE B

SIDE B



J

J

4.4 MAIN CONTROL ASSY


SIDE A

A

C MAIN CONTROL ASSY

AB CN3702

V CN5812



82

SIDE B

A

B


C

D

E

F


C MAIN CONTROL ASSY



VSX-2016AV-S

SIDE B

A



VSX-2016AV-S

C
85

83

SIDE A

A

B

6

D


8

5

G DSP ASSY

C CN305



AK C



G

SIDE A

A



B

C

D

E

F

G

87

SIDE B

A

B

C



D

E

F

G DSP ASSY

CN801

**G**

88

VSX-2016AV-S

SIDE B

A


B

C

D

E


F



G


89

H COMPOSITE ASSY



SIDE A

A



H

91

SIDE B

A

B



C

D

E

F

H COMPOSITE ASSY

**H**

92

SIDE B

A

8


H

93

4.7 S-VIDEO ASSY



SIDE A

I S-VIDEO ASSY



SIDE A

A




SIDE B

A

S-VIDEO ASSY

B



C

D

E

F

SIDE B

A


8

C

D

6


F




4.8 COMPONENT ASSY

SIDE A

K COMPONENT ASSY



K



90 100 110 120 130 140 150 160 170 180

SIDE B

A

B



C

D

E

F

K COMPONENT ASSY

**K**



100

SIDE B

A

2

COMPONENT ASS'Y



(ANP7561-B)

A horizontal number line with tick marks at intervals of 10, ranging from 90 on the left to 0 on the right. An arrow points to the left from the tick mark at 10, with the label X positioned below it.

6


K

101

4.9 DISPLAY ASSY

SIDE A

L DISPLAY ASSY




L

102

VSX-2016AV-S

SIDE A

A



B

C

D

E

F

L

103

SIDE B

A

B


C

1

F

1


L DISPLAY ASSY



A horizontal number line with tick marks at intervals of 10, ranging from 270 on the left to 140 on the right. The labels are: 270, 260, 250, 240, 230, 220, 210, 200, 190, 180, 170, 160, 150, 140.

SIDE B

A



(ANP7562-B)



6

F

L

105

4.10 VOLUME ASSY



M

106

1

2

3

4


M

■ 5 ■ 6 ■ 7 ■ 8

4.11 HEADPHONE ASSY


SIDE A

SIDE A



SIDE B

SIDE B



O

O

SIDE A

A

N MULTI JOG ASSY


B

1

1

1

□



SIDE A

A


B

C

D

E

F



150 160 170 180 190 200 210 220 230 240 250 260 270 280 290 300 310 320 330

SIDE B

A

B


N MULTI JOG ASSY

C

D

F

F




110

110

SIDE B

A




N

111

SIDE A



P FRONT-IN ASSY



P

SIDE A

A



B

C

D

E

F

SIDE B

P FRONT-IN ASSY



B

C

D

F

E



VSX-2016AV-S


114

SIDE B

A


115

115



4.14 PRIMARY ASSY


SIDE A



Q

116

VSX-2016AV-S



1

2


3

4

SIDE B

A

Q PRIMARY ASSY



330 320 310 300 290 280 270 260 250 240

1

2

3

4



Q

118

VSX-2016AV-S

SIDE B

A



250 240 230 220 210 200 190

← X

VSX-2016AV-S

Q

119

B

C

D

E

F

7

8

■ 1 ■ 2 ■ 3 ■ 4
4.15 TRANS 1 ASSYS

SIDE A

A

B

C

SIDE B


D

E


F

SIDE A

R TRANS 1 ASSY



R TRANS 1 ASSY



R

R

120

1 2 3 4

VSX-2016AV-S

A

B


C

D


F

F

T DIODE 1 ASSY



T DIODE 1 ASSY



122

1

2

5


4

■ 4.18 BRIDGE 1 ASSY

SIDE A

SIDE A


V BRIDGE 1 ASSY AK CN1002



SIDE B

SIDE B

V BRIDGE 1 ASSY



V

V

1 2 3 4
4.19 PS/SP ASSY

SIDE A

A

W PS/SP ASSY

B

C

D

E

F

W

124

X →

VSX-2016AV-S

160
150
140
130
120
110
100
90
80
70
60
50
40
30
20
10
Y
0

2


3

4

1

2

3




3

4

2


3

4




SIDE B**W PS/SP ASSY**

Y12A Y8B Y11A



CN3102 CN3101


**W**

126


1 2 3 4

VSX-2016AV-S

Y8B Y11A



02 CN3101



240 230 220 210 200 190 180 170 160 150 140

SIDE A

SIDE A

A

B


C

B

□

6

X TRANS 2-2 ASSY




SIDE B

SIDE B

B

□

6



X TRANS 2-2 ASSY

VSX-2016AV-S

X

X

128

1

2


4

■ 5 ■ 6 ■ 7 ■ 8

4.21 POSI 1-L, POSI 2-L and POSI 1-R ASSYS


SIDE A

SIDE A



SIDE B

SIDE B




AE AF AH

AE AF AH

4.22 TRANS SIDE ASSY


SIDE A



Y TRANS SIDE ASSY



SIDE B

Y TRANS SIDE ASSY



SIDE A**SIDE B****Y**


131

4.23 IR I/O ASSY

SIDE A


SIDE A

AB IR I/O ASSY



SIDE B

SIDE B



AB

AB

VSX-2016AV-S

■ 5 ■

6 ■

7 ■

8 ■

A ■

B ■

C ■

D ■


E ■

F ■

SIDE A

SIDE A

Z LOCAL P-SUPPLY ASSY



5

6


7

8

SIDE B

SIDE B

Z LOCAL P-SUPPLY ASSY



Z


Z

4.25 DC/DC ASSY

SIDE A

SIDE A


AA DC/DC ASSY



SIDE B**SIDE B**

A

AA DC/DC ASSY

**AA****AA**

137


F

4.26 VIDEO CONNECT ASSY

SIDE A

SIDE A

AC VIDEO CONNECT ASSY



AC

138

AC


VSX-2016AV-S

4

SIDE B**SIDE B**

A

AC VIDEO CONNECT ASSY


**AC****AC**

139

1 2 3 4
4.27 POWER AMP-L ASSY

SIDE A

B AD POWER AMP-L ASSY



AD

140

VSX-2016AV-S

1

2

3

4

SIDE B

A



AD POWER AMP-L ASSY

B

Y3

Y5

CN5005



F

AD

142

VSX-2016AV-S

SIDE B

A


B

6

D

F

6




SIDE A

A

AG POWER AMP-R ASSY

B



AG

SIDE A

A

8

C

D

三

This diagram shows the PCB layout for the ANP7564-B module. It features several integrated circuits (ICs) and various passive components like resistors (R), capacitors (C), and inductors (L). Key labels include:

- W CN3102**: Located at the bottom left, connected to the circuit via a Production code 5002.
- W CN3006**: Located at the bottom center, connected to the circuit via a Production code 5002.
- AI CN5602**: Located on the right side, connected to the circuit via a Production code 5002.
- AI CN5303**: Located on the far right, connected to the circuit via a Production code 5002.

The PCB includes several ground planes labeled **GND** and **AMUTE**. Component values and part numbers are indicated throughout the layout, such as R5323, C5323, IC5301, and IC5302.

SIDE B

A



B

C

D


1

AG POWER AMP-R ASSY



46

146




4.29 POWER AMP IN ASSY

SIDE A

SIDE A


AI POWER AMP IN ASSY



SIDE B**SIDE B**

A

AI POWER AMP IN ASSY




4.30 POWER PROTECT ASSY

SIDE A

SIDE A

AJ POWER PROTECT ASSY



AJ

AJ

150

1 2 3 4


VSX-2016AV-S

4

SIDE B

SIDE B

AJ POWER PROTECT ASSY



AJ

AJ

4.31 HDMI & DVC ASSY

SIDE A

A


B

C

1

F


AK HDMI & DVC ASSY



AK

SIDE A

A



B

C

D

E

F

SIDE B

A



B

C



D

F

AK HDMI & DVC ASSY




AK




4.32 USB ASSY (VSX-2016AV-S ONLY)

SIDE A



SIDE A



AL

■ 5 ■

6 ■

7 ■

8 ■

A ■

B ■

C ■

D ■

E ■

F ■

■ 5 ■

6 ■

7 ■

8 ■

VSX-2016AV-S

157 ■

5. PCB PARTS LIST

- A**
- NOTES:
- Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.
 - The Δ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
 - When ordering resistors, first convert resistance values into code form as shown in the following examples.
- Ex.1 When there are 2 effective digits (any digit apart from 0), such as 560 ohm and 47k ohm (tolerance is shown by J=5%, and K=10%).

560 Ω	$\rightarrow 56 \times 10^1 \rightarrow 561$	RD1/4PU[5 6 1]J
47k Ω	$\rightarrow 47 \times 10^3 \rightarrow 473$	RD1/4PU[4 7 3]J
0.5 Ω	$\rightarrow R50$	RN2H[R 5 0]K
1 Ω	$\rightarrow R10$	RS1P[1 R 0]K

Ex.2 When there are 3 effective digits (such as in high precision metal film resistors).

5.62k Ω	$\rightarrow 562 \times 10^1 \rightarrow 5621$	RN1/4PC[5 6 2 1]F
----------------	--	-------------------

- Meaning of the figures and others in the parentheses in the parts list.

Example) IC 301 is on the point (face A, 91 of x-axis, and 111 of y-axis) of the corresponding PC board.
IC 301 (A, 91, 111) IC NJM2068V

■ LIST OF WHOLE PCB ASSEMBLIES

Mark	Symbol and Description	VSX-2016AV-S /HYXJ5	VSX-81TXV /KUXJCA	VSX-81TXV-S /KUXJCA	VSX-9110TXV-K /KUXJ
C	1..MAIN ASSY	AWK7889	AWK7888	AWK7888	AWK7888
	2..MAIN CONTROL ASSY	AWX9009	AWX9008	AWX9008	AWX9008
	2..AUDIO IN ASSY	AWX9013	AWX9012	AWX9012	AWX9012
	2..12V-REG ASSY	AWX9014	AWX9014	AWX9014	AWX9014
	2..GUARD-C ASSY	AWX9051	AWX9051	AWX9051	AWX9051
	2..GUARD-F ASSY	AWX9070	AWX9070	AWX9070	AWX9070
D	1..DSP ASSY	AWX8698	AWX8697	AWX8697	AWX8697
E	1..VIDEO ASSY	AWK7898	AWK7897	AWK7897	AWK7897
	2..COMPOSITE ASSY	AWX9028	AWX9026	AWX9026	AWX9026
	2..S-VIDEO ASSY	AWX9030	AWX9029	AWX9029	AWX9029
	2..COMPONENT ASSY	AWX9031	AWX9032	AWX9032	AWX9032
	2..BRIDGE 2 ASSY	AWX9050	AWX9050	AWX9050	AWX9050
F	1..COMPLEX ASSY	AWK7902	AWK7901	AWK7943	AWK7901
	2..PRIMARY ASSY	AWX9035	AWX9034	AWX9034	AWX9034
	2..TRANS 1 ASSY	AWX9038	AWX9038	AWX9038	AWX9038
	2..DISPLAY ASSY	AWX9103	AWX9040	AWX9040	AWX9040
	2..VOLUME ASSY	AWX9111	AWX9044	AWX9111	AWX9044
	2..MULTI JOG ASSY	AWX9112	AWX9045	AWX9112	AWX9045
	2..FRONT-IN ASSY	AWX9048	AWX9047	AWX9047	AWX9047
	2..HEADPHONE ASSY	AWX9049	AWX9049	AWX9049	AWX9049
G	1..SECONDARY ASSY	AWK7911	AWK7910	AWK7910	AWK7910
	2..PS/SP ASSY	AWX9107	AWX9052	AWX9052	AWX9052
	2..TRANS SIDE ASSY	AWX9056	AWX9056	AWX9056	AWX9056
	2..TRANS 2-1 ASSY	AWX9059	AWX9058	AWX9058	AWX9058
	2..DIODE 1 ASSY	AWX9060	AWX9060	AWX9060	AWX9060
	2..VH TR ASSY	AWX9061	AWX9061	AWX9061	AWX9061
	2..TRANS 2-2 ASSY	AWX9062	AWX9062	AWX9062	AWX9062
	2..LOCAL P-SUPPLY ASSY	AWX9064	AWX9063	AWX9063	AWX9063
	2..IR I/O ASSY	AWX9067	AWX9066	AWX9066	AWX9066
	2..VIDEO CONNECT ASSY	AWX9069	AWX9069	AWX9069	AWX9069
H	2..DC/DC ASSY	AWX9015	AWX9015	AWX9015	AWX9015
	2..BRIDGE 1 ASSY	AWX9078	AWX9078	AWX9078	AWX9078
	1..POWER AMP ASSY	AWK7920	AWK7919	AWK7919	AWK7919
	2..POWER AMP-L ASSY	AWX9072	AWX9071	AWX9071	AWX9071
	2..POWER AMP-R ASSY	AWX9073	AWX9106	AWX9106	AWX9106
	2..POWER AMP IN ASSY	AWX9075	AWX9075	AWX9075	AWX9075
	2..POWER PROTECT ASSY	AWX9077	AWX9076	AWX9076	AWX9076
	2..POSI 1-L ASSY	AWX9081	AWX9080	AWX9080	AWX9080
	2..POSI 2-L ASSY	AWX9082	Not used	Not used	Not used
	2..POSI 1-R ASSY	AWX9084	AWX9083	AWX9083	AWX9083
I	1..HDMI & DVC ASSY	AWQ7037	AWQ7037	AWQ7037	AWQ7037
	1..USB ASSY	AWX8704	Not used	Not used	Not used

■ CONTRAST OF PCB ASSEMBLIES

A AUDIO IN ASSY

AWX9013 and AWX9012 are constructed the same except for the following :

Mark	Symbol and Description	AWX9013	AWX9012
	IC663	Not used	NJM78M12FA
	D671	Not used	RB501V-40
	C501, C502, C505-C510, C513-C518	CCSRCH101J50	Not used
	C521-C526, C541-C544, C549-C552	CCSRCH101J50	Not used
	C503, C504, C511, C512, C519, C520	CCSRCH221J50	Not used
	C527, C528, C531-C536, C539, C540	CCSRCH151J50	Not used
	C547, C548	CCSRCH151J50	Not used
	C678	Not used	CKSRYB103K50
	C679	Not used	CEAT100M50
	CN516 15P PLUG	XKP3067	Not used

A

C MAIN CONTROL ASSY

AWX9009 and AWX9008 are constructed the same except for the following :

Mark	Symbol and Description	AWX9009	AWX9008
	IC251	LC72725M	Not used
	Q102	Not used	RT1P241M
	C251	CEAT100M50	Not used
	C253	CCSRCH561J50	Not used
	C254	CEAT101M10	Not used
	C255	CKSRYB102K50	Not used
	C256, C257	CCSRCH270J50	Not used
	C260	CKSRYB472K50	Not used
	R116, R131	Not used	RS1/16S104J
	R124, R126, R127, R171	RS1/16S101J	Not used
	R128-R130, R132, R199, R333	Not used	RS1/16S101J
	R152	RS1/16S473J	Not used
	R153	Not used	RS1/16S473J
	R156	Not used	RS1/16S103J
	R187, R188	RS1/16S0R0J	Not used
	R189	RS1/16S104J	Not used
	R251	RS1/16S473J	RS1/16S474J
	R252-R254	RS1/16S102J	Not used
	R383, R384	Not used	RS1/16S0R0J
	CN305 12P CONNECTOR	Not used	VKN1243
	X251 CRYSTAL RESONATOR (4.332 MHz)	ASS7004	Not used

C

G DSP ASSY

AWX8698 and AWX8697 are constructed the same except for the following :

Mark	Symbol and Description	AWX8698	AWX8797
	IC501	Not used	F2602E-01
	IC502	Not used	AAT4618IGV-0.5-1
	IC601	Not used	TC74VHC157FTS1
	D501, D502	Not used	UDZS5R6(B)
	L501, L601 CHIP SOLID INDUCTOR	Not used	QTL1013
	L502 CHIP SOLID INDUCTOR	Not used	ATL7002
	C501	Not used	CEVW470M6R3
	C502, C504-C506, C508, C602	Not used	CKSRYB104K16
	C503, C601	Not used	CCSRCH471J50
	C507	Not used	CEVW101M16

E

Mark	Symbol and Description	AWX8698	AWX8797
	C509, C510	Not used	CCSRCH100D50
	C513	Not used	CKSQYB105K16
	R503, R613-R616	RS1/16S0R0J	Not used

F

Mark	Symbol and Description	AWX8698	AWX8797
	R504, R506, R516, R523-R526, R528 R601-R603, R605, R608, R610-R612	Not used Not used	RS1/16S101J RS1/16S101J
A	R505, R507 R510 R511 R514, R515, R517, R519-R521 R518	Not used Not used Not used Not used Not used	RS1/16S102J RS1/16S471J RS1/16S105J RS1/16S104J RAB4C101J
	R527, R529, R604, R606, R607, R609 R531 R964 X501 CRYSTAL RESONATOR (45.1584 MHz) CN501 4P SOCKET	Not used Not used Not used Not used Not used	RS1/16S470J RS1/16S103J RAB4C104J ASS7065 AKP7201
B	CN952 12P CONNECTOR JA351	Not used AKB7131 (JACK)	VKN1416 AKB7173 (PIN JACK 2P)

H COMPOSITE ASSY

AWX9028 and AWX9026 are constructed the same except for the following :

Mark	Symbol and Description	AWX9028	AWX9026
C	IC1002 IC1151 Q1151 D1006 D1007	Not used Not used Not used Not used Not used	CD74HC4051PW M61545FP IMX25 DAN202U 1SS355
	D1112 C1003, C1004, C1164 C1015 C1023 C1101-C1104	Not used Not used Not used Not used CCSRCH101J50	DAN217U CKSRYB103K50 CEAT101M10 CCSRCH181J50 Not used
D	C1151-C1154 C1155, C1156, C1161, C1162 C1157, C1158 C1159, C1163 C1160	Not used Not used Not used Not used Not used	CEAT2R2M50 CCSRCH101J50 CCSRCH331J50 CKSRYB104K50 CEAT100M50
E	R1005 R1053 R1151, R1152 R1153, R1154 R1155, R1156	Not used Not used Not used Not used Not used	RS1/16S750J RS1/16S0R0J RS1/16S104J RS1/16S202J RS1/16S103J
	R1157, R1158 R1159, R1160, R1164 R1163 1004 PIN JACK (2P) 1005 PIN JACK (2P) JA1006 PIN JACK (1P)	Not used Not used Not used Not used Not used AKB7175	RS1/16S101J RS1/16S471J RS1/16S473J AKB7176 AKB7181 Not used

I S-VIDEO ASSY

AWX9030 and AWX9029 are constructed the same except for the following :

Mark	Symbol and Description	AWX9030	AWX9029
F	IC1301 Q1301 Q1351, Q1353 Q1352 D1302	Not used Not used Not used Not used Not used	MAX3232CPW 2SC4081(QRS) 2SA1576A(RS) RT1N241M 1SS355
	D1351 L1351 CHIP SOLID INDUCTOR C1304, C1305 C1306 C1308	Not used Not used Not used Not used Not used	UDZS5R1(B) ATL7002 CKSRYB105K10 CKSRYB473K50 CKSRYB224K16

Mark	Symbol and Description	AWX9030	AWX9029
	C1309, C1311, C1353	Not used	CKSRYB103K50
	C1310	Not used	CCSRCH331J50
	C1352	Not used	CKSRYB104K16
	C1354	Not used	CKSRYB102K50
	C1355	Not used	CKSRYB472K50
	R1301-R1304	Not used	RS1/16S101J
	R1305, R1308	Not used	RS1/16S224J
	R1306	Not used	RS1/16S474J
	R1307, R1353, R1354	Not used	RS1/16S103J
	R1309	Not used	RS1/16S0R0J
	R1310	RS1/16S103J	Not used
	R1351, R1352	Not used	RS1/16S180J
	R1355, R1356	Not used	RS1/16S472J
	CN1301 9P D-SUB SOCKET	Not used	AKP1213
	CN1302 07P CONNECTOR	RKN1048	Not used
	JA1351 JACK	Not used	RKN1004
	KN1351 SCREW PLATE	Not used	VNE1948

K COMPONENT ASSY

AWX9031 and AWX9032 are constructed the same except for the following :

Mark	Symbol and Description	AWX9031	AWX9032
	C1501, C1502, C1521, C1522, C1541, C1542	CCSRCH101J50	Not used
	C1561, C1562	CCSRCH101J50	Not used
	C1507, C1508, C1527, C1528, C1569-C1572	CCSRCH271J50	Not used

L DISPLAY ASSY

AWX9103 and AWX9040 are constructed the same except for the following :

Mark	Symbol and Description	AWX9103	AWX9040
	IC2401	Not used	CD4053BNS
	Q2402	Not used	UMB1N
	Q2403	Not used	DTC124EUA
	D2401	Not used	1SS355
	D2402	Not used	DAN217U
	D2415	Not used	DAN202U
	C2402	Not used	CKSRYB153K50
	C2412	Not used	CKSRYB103K50
	R2407	Not used	RS1/16S223J
	R2408, R2410	Not used	RS1/16S103J
	R2409	Not used	RS1/16S392J
	R2414	RS1/16S0R0J	Not used

M VOLUME ASSY

AWX9111 and AWX9044 are different in part number, but construction is the same.

E

N MULTI JOG ASSY

AWX9112 and AWX9045 are different in part number, but construction is the same.

P FRONT-IN ASSY

AWX9048 and AWX9047 are constructed the same except for the following :

Mark	Symbol and Description	AWX9048	AWX9047
	L2752, L2753 CHIP FERRITE BEAD	VTL1169	Not used
	C2673	CKSRYB104K16	CKSRYB104K25
	C2753, C2756	CKSRYB104K16	Not used
	C2755	CEAT101M16	Not used
	C2757	CCSRCH471J50	Not used

Mark	Symbol and Description	AWX9048	AWX9047
	R2751, R2752 CN2652 CONNECTOR JA2751 USB CONNECTOR	RS1/16S0R0J B4B-PH-K-S XKP3086	Not used Not used Not used

A

Q PRIMARY ASSY

AWX9035 and AWX9034 are constructed the same except for the following :

Mark	Symbol and Description	AWX9035	AWX9034
▲	RY2001	ASR7013	ASR7022
▲	T2001 STANDBY TRANSFORMER	ATT7040	ATT7043
▲	R2001 (2.2 M, 1/2 W)	Not used	RCN1080
	R2002	RD1/4MUF101J	RD1/4MUF220J
▲	2001 AC SOCKET 1P	Not used	AKP1033

B

S TRANS 2-1 ASSY

AWX9059 and AWX9058 are constructed the same except for the following :

Mark	Symbol and Description	AWX9059	AWX9058
	D3253	UDZS8R2(B)	UDZS10(B)
	D3254	UDZS7R5(B)	UDZS9R1(B)
	D3255	UDZS9R1(B)	UDZS10(B)
	D3256	UDZS8R2(B)	UDZS9R1(B)
	D3263	UDZS13(B)	UDZS10(B)
	D3264	UDZS15(B)	UDZS12(B)

C

W PS/SP ASSY

AWX9107 and AWX9052 are constructed the same except for the following :

Mark	Symbol and Description	AWX9107	AWX9052
	C3101, C3102	ACH7255	ACH7258
	CN3001 SPEAKER TERMINAL 8P	AKE7119	AKE7118
	CN3002 SPEAKER TERMINAL 6P	AKE7108	AKE7107

Z LOCAL P-SUPPLY ASSY

AWX9064 and AWX9063 are constructed the same except for the following :

Mark	Symbol and Description	AWX9064	AWX9063
▲	IC3502 (1.6A)	AEK7012	Not used
▲	Q3501	UMD2N	Not used
▲	Q3502	2SD1763A(DE)	Not used
▲	Q3503	DTC124EUA	Not used
▲	D3509, D3510	1SR154-400	Not used
	D3511	UDZS27(B)	Not used
	C3510	CEANP102M16	Not used
	C3511	CEAT102M35	Not used
	C3512, C3514	CEAT100M50	Not used
	C3513	CKSRYB102K50	Not used

E

Mark	Symbol and Description	AWX9064	AWX9063
	C3515	CEANP470M25	Not used
	R3504	RS1/16S472J	Not used
	R3505	RS1/16S101J	Not used
	R3506	RS1/16S222J	Not used

F

AB IR I/O ASSY

AWX9067 and AWX9066 are constructed the same except for the following :

Mark	Symbol and Description	AWX9067	AWX9066
	D3702	Not used	ISS355
	L3701, L3703 INDUCTOR	Not used	CTF1473
	L3702 CHIP SOLID INDUCTOR	Not used	QTL1013
	L3704 INDUCTOR	Not used	CTF1385
	C3758	Not used	CKSRYB103K50

Mark	Symbol and Description	AWX9067	AWX9066
	R3701	Not used	RS1/16S0R0J
	R3702	Not used	RS1/16S102J
	R3703, R3755	RS1/16S0R0J	Not used
	JA3701 CONNECTOR	Not used	CKS4124
	JA3702 JACK	Not used	RKN1004

AD POWER AMP-L ASSY

AWX9072 and AWX9071 are constructed the same except for the following :

Mark	Symbol and Description	AWX9072	AWX9071
	CN5005 CONNECTOR	B2B-PH-K-R	Not used

AE POSI 1-L ASSY

AWX9081 and AWX9080 are constructed the same except for the following :

Mark	Symbol and Description	AWX9081	AWX9080
	TH4501 POSISTOR	PTFM04BH222Q2N34B0	PTFM04BC222Q2N34B0

AG POWER AMP-R ASSY

AWX9073 and AWX9106 are constructed the same except for the following :

Mark	Symbol and Description	AWX9073	AWX9106
	5002 PCB BINDER	VEF1040	Not used

AH POSI 1-R ASSY

AWX9084 and AWX9083 are constructed the same except for the following :

Mark	Symbol and Description	AWX9084	AWX9083
	TH4503 POSISTOR	PTFM04BH222Q2N34B0	PTFM04BC222Q2N34B0

AJ POWER PROTECT ASSY

AWX9077 and AWX9076 are constructed the same except for the following :

Mark	Symbol and Description	AWX9077	AWX9076
	Q5703	RT1N241M	Not used
	Q5706	RT1P241M	Not used
	D5702	1SS355	Not used
	C5706	CKSRYB103K50	Not used
	R5704, R5709	Not used	RS1/16S0R0J
	R5705, R5708, R5746	RS1/16S0R0J	Not used
	R5706	RS1/16S822J	Not used
	R5718	RS1/16S104J	Not used
	CN5706 3 PIN CONNECTOR	S3B-EH	Not used

■ PCB PARTS LIST FOR VSX-2016AV-S/HYXJ5 UNLESS OTHER WISE NOTED

Mark No.	Description	Part No.	Mark No.	Description	Part No.
A	MAIN ASSY (AWK7889)		R 511 (B,302,128)		RS1/16S222J
	MISCELLANEOUS		R 512 (B,302,118)		RS1/16S222J
A	J 663 JUMPER WIRE	D20PDD0605E	R 513 (B,302,142)		RS1/16S331J
			R 514 (B,302,135)		RS1/16S331J
			R 515 (B,302,209)		RS1/16S331J
			R 516 (B,302,202)		RS1/16S331J
			R 517 (B,302,222)		RS1/16S331J
			R 518 (B,302,216)		RS1/16S331J
			R 519 (B,302,155)		RS1/16S222J
			R 520 (B,302,148)		RS1/16S222J
B	IC 501 (A,262,69) 8CH E-VOL	R2S15205FP	R 521 (B,302,168)		RS1/16S331J
	IC 701 (A,205,68) OP-AMP IC	BA4560RF	R 522 (B,302,161)		RS1/16S331J
	IC 702 (A,220,73) OP-AMP IC	BA4560RF	R 523 (B,302,182)		RS1/16S331J
	IC 703 (A,220,56) IC	TC4066BFT	R 524 (B,302,176)		RS1/16S331J
	IC 741 (A,177,68) OP-AMP IC	BA4560RF	R 525 (B,302,195)		RS1/16S331J
			R 526 (B,302,189)		RS1/16S331J
			R 527 (B,309,56)		RS1/16S474J
			R 528 (B,309,51)		RS1/16S474J
			R 529 (B,309,69)		RS1/16S474J
			R 530 (B,309,64)		RS1/16S474J
			R 531 (B,309,84)		RS1/16S474J
C	△D 661 (B,39,52) DIODE	1SR154-400	R 532 (B,309,79)		RS1/16S474J
	△D 662 (B,34,52) DIODE	1SR154-400	R 533 (B,309,97)		RS1/16S474J
	△D 663 (B,25,52) DIODE	1SR154-400	R 534 (B,309,92)		RS1/16S474J
	△D 664 (B,30,52) DIODE	1SR154-400	R 535 (B,309,110)		RS1/16S474J
	D 669 (B,127,75) DIODE	UDZS7R5(B)	R 536 (B,309,107)		RS1/16S474J
	D 670 (B,127,87) DIODE	UDZS7R5(B)	R 537 (B,309,128)		RS1/16S474J
	J 662 (A,85,59) 3P HOUSING WIRE ASSY	ADX7509	R 538 (B,309,118)		RS1/16S474J
	CN501 (A,258,24) 19P PLUG	XKP3069	R 539 (B,309,140)		RS1/16S474J
	CN507 (A,266,24) B TO B CONNECTOR	BTEM20S-1S	R 540 (B,309,134)		RS1/16S474J
	CN509 (A,234,48) 23P PLUG	XKP3071	R 541 (B,309,210)		RS1/16S474J
D	CN511 (A,131,47) B TO B CONNECTOR	BTEM20S-1S	R 542 (B,309,205)		RS1/16S474J
	CN512 (A,220,24) 23P PLUG	XKP3071	R 543 (B,309,223)		RS1/16S474J
	CN513 (A,98,48) 23P PLUG	XKP3071	R 544 (B,309,218)		RS1/16S474J
	CN516 (A,39,24) 15P PLUG	XKP3067	R 545 (B,309,154)		RS1/16S474J
	CN520 (A,282,208) 17P SOCKET	XKP3079	R 546 (B,309,149)		RS1/16S474J
	CN521 (A,317,60) PIN JACK (4P)	AKB7172	R 547 (B,309,167)		RS1/16S474J
	CN522 (A,317,88) PIN JACK (4P)	AKB7172	R 548 (B,309,162)		RS1/16S474J
	CN524 (A,317,158) PIN JACK (4P)	AKB7172	R 549 (B,309,182)		RS1/16S474J
	CN525 (A,317,186) PIN JACK (4P)	AKB7172	R 550 (B,309,177)		RS1/16S474J
	CN526 (A,317,214) PIN JACK (4P)	AKB7172	R 551 (B,309,195)		RS1/16S474J
	CN661 (A,26,62) CONNECTOR POST	S10B-PH	R 552 (B,309,190)		RS1/16S474J
	523 (A,317,123) PIN JACK (6P)	AKB7182	R 561 (A,246,87)		RS1/16S472J
E	Y 661 AWG14 BOARD IN	ADX7511	R 562 (A,244,75)		RS1/16S472J
	501 (A,150,71) PCB BINDER	VEF1040	R 563 (A,244,58)		RS1/16S102J
	664 (A,46,67) 6P CABLE HOLDER	51048-0600	R 564 (A,244,57)		RS1/16S102J
			R 565 (B,268,42)		RS1/16S0R0J
			R 566 (B,275,42)		RS1/16S0R0J
			R 571 (B,256,33)		RS1/16S0R0J
			R 572 (B,234,53)		RS1/16S0R0J
			R 601 (B,222,22)		RS1/16S0R0J
F	R 501 (B,303,54)	RS1/16S331J	R 663 (B,133,76)		RS1/16S472J
	R 502 (B,302,43)	RS1/16S331J	R 664 (B,133,88)		RS1/16S472J
	R 503 (B,302,71)	RS1/16S222J	R 665 (B,133,72)		RS1/16S101J
	R 504 (B,302,64)	RS1/16S222J	R 666 (B,133,84)		RS1/16S101J
	R 505 (B,302,84)	RS1/16S331J			
	R 506 (B,302,77)	RS1/16S331J			
	R 507 (B,302,97)	RS1/16S331J			
	R 508 (B,302,90)	RS1/16S331J			
	R 509 (B,302,110)	RS1/16S331J			
	R 510 (B,302,103)	RS1/16S331J			

Mark No.**Description****Part No.**

R 701 (A,203,61)	RS1/16S473J	R 778 (B,197,79)	RS1/16S101J
R 702 (A,208,61)	RS1/16S473J	R 781 (A,161,61)	RS1/16S473J
R 703 (B,204,60)	RS1/16S332J	R 782 (A,166,61)	RS1/16S473J
R 704 (B,207,60)	RS1/16S332J	R 783 (B,162,60)	RS1/16S272J
R 705 (B,202,60)	RS1/16S332J	R 784 (B,165,60)	RS1/16S272J
R 706 (B,209,60)	RS1/16S332J	R 785 (B,160,60)	RS1/16S272J
R 707 (B,202,64)	RS1/16S392J	R 786 (B,167,60)	RS1/16S272J
R 708 (B,209,64)	RS1/16S392J	R 787 (B,160,64)	RS1/16S272J
R 709 (B,204,64)	RS1/16S472J	R 788 (B,167,64)	RS1/16S272J
R 710 (B,207,64)	RS1/16S472J	R 789 (B,162,64)	RS1/16S392J
R 711 (B,204,68)	RS1/16S272J	R 790 (B,165,64)	RS1/16S392J
R 712 (B,207,68)	RS1/16S272J	R 791 (B,162,68)	RS1/16S122J
R 713 (B,202,72)	RS1/16S331J	R 792 (B,165,68)	RS1/16S122J
R 714 (B,209,72)	RS1/16S331J	R 793 (B,160,72)	RS1/16S221J
R 715 (B,204,72)	RS1/16S474J	R 794 (B,167,72)	RS1/16S221J
R 716 (B,207,72)	RS1/16S474J	R 797 (B,158,79)	RS1/16S101J
R 719 (B,223,80)	RS1/16S0R0J	R 798 (B,169,79)	RS1/16S101J
R 720 (B,216,80)	RS1/16S0R0J	R 801 (B,262,165)	RS1/16S223J
R 721 (B,223,77)	RS1/16S472J	R 802 (B,262,176)	RS1/16S223J
R 722 (B,216,77)	RS1/16S472J	R 805 (A,266,165)	RS1/16S682J
R 723 (A,226,70)	RS1/16S472J	R 806 (A,266,175)	RS1/16S682J
R 724 (A,213,70)	RS1/16S472J	R 807 (A,269,168)	RS1/16S331J
R 725 (A,226,74)	RS1/16S122J	R 808 (A,269,173)	RS1/16S331J
R 726 (A,213,74)	RS1/16S122J	R 811 (A,263,165)	RS1/16S153J
R 727 (B,223,73)	RS1/16S392J	R 812 (A,263,175)	RS1/16S153J
R 728 (B,216,73)	RS1/16S392J	R 815 (B,262,194)	RS1/16S104J
R 731 (B,225,66)	RS1/16S101J	R 816 (B,262,186)	RS1/16S104J
R 732 (B,214,66)	RS1/16S101J	R 821 (B,262,134)	RS1/16S223J
R 733 (A,226,48)	RS1/16S473J	R 822 (B,262,144)	RS1/16S223J
R 741 (A,175,61)	RS1/16S473J	R 825 (A,266,134)	RS1/16S682J
R 742 (A,180,61)	RS1/16S473J	R 826 (A,266,144)	RS1/16S682J
R 743 (B,176,60)	RS1/16S272J	R 827 (A,269,137)	RS1/16S331J
R 744 (B,179,60)	RS1/16S332J	R 828 (A,269,142)	RS1/16S331J
R 745 (B,174,60)	RS1/16S272J	R 831 (A,263,134)	RS1/16S153J
R 746 (B,181,60)	RS1/16S562J	R 832 (A,263,144)	RS1/16S153J
R 747 (B,174,64)	RS1/16S272J	R 835 (B,275,194)	RS1/16S104J
R 748 (B,181,64)	RS1/16S393J	R 836 (B,275,186)	RS1/16S104J
R 749 (B,176,64)	RS1/16S392J	R 841 (B,262,149)	RS1/16S223J
R 750 (B,179,64)	RS1/16S182J	R 842 (B,262,160)	RS1/16S223J
R 751 (B,176,68)	RS1/16S122J	R 845 (A,266,150)	RS1/16S682J
R 752 (B,179,68)	RS1/16S362J	R 846 (A,266,160)	RS1/16S682J
R 753 (B,174,72)	RS1/16S221J	R 847 (A,269,152)	RS1/16S331J
R 754 (B,181,72)	RS1/16S121J	R 848 (A,269,157)	RS1/16S331J
R 757 (B,172,79)	RS1/16S101J	R 851 (A,263,150)	RS1/16S153J
R 758 (B,183,79)	RS1/16S101J	R 852 (A,263,160)	RS1/16S153J
R 761 (A,189,61)	RS1/16S473J	R 855 (B,269,194)	RS1/16S104J
R 762 (A,194,61)	RS1/16S473J	R 856 (B,269,186)	RS1/16S104J
R 763 (B,190,60)	RS1/16S272J	R 861 (B,262,118)	RS1/16S223J
R 764 (B,193,60)	RS1/16S272J	R 862 (B,262,129)	RS1/16S223J
R 765 (B,188,60)	RS1/16S272J	R 865 (A,266,118)	RS1/16S682J
R 766 (B,195,60)	RS1/16S272J	R 866 (A,266,128)	RS1/16S682J
R 767 (B,188,64)	RS1/16S272J	R 867 (A,269,121)	RS1/16S331J
R 768 (B,195,64)	RS1/16S272J	R 868 (A,269,126)	RS1/16S331J
R 769 (B,190,64)	RS1/16S392J	R 871 (A,263,118)	RS1/16S153J
R 770 (B,193,64)	RS1/16S392J	R 872 (A,263,128)	RS1/16S153J
R 771 (B,190,68)	RS1/16S122J	R 875 (B,282,194)	RS1/16S104J
R 772 (B,193,68)	RS1/16S122J	R 876 (B,282,186)	RS1/16S104J
R 773 (B,188,72)	RS1/16S221J	R 883 (A,253,116)	RS1/16S0R0J
R 774 (B,195,72)	RS1/16S221J		
R 777 (B,186,79)	RS1/16S101J		

Mark No.	Description	Part No.	Mark No.	Description	Part No.
CAPACITORS					
A	C 501 (B,307,56)	CCSRCH101J50	C 562 (A,300,103)	ELECT. CAPACITOR	CEAT470M25
	C 502 (B,307,51)	CCSRCH101J50	C 563 (A,300,131)		CEAT100M50
	C 503 (B,307,69)	CCSRCH221J50	C 564 (A,300,120)		CEAT100M50
	C 504 (B,307,64)	CCSRCH221J50	C 565 (A,300,144)	ELECT. CAPACITOR	CEAT470M25
	C 505 (B,307,84)	CCSRCH101J50	C 566 (A,300,135)	ELECT. CAPACITOR	CEAT470M25
	C 506 (B,307,79)	CCSRCH101J50	C 567 (A,300,210)	ELECT. CAPACITOR	CEAT470M25
	C 507 (B,307,97)	CCSRCH101J50	C 568 (A,300,201)	ELECT. CAPACITOR	CEAT470M25
	C 508 (B,307,92)	CCSRCH101J50	C 569 (A,293,210)	ELECT. CAPACITOR	CEAT470M25
	C 509 (B,307,110)	CCSRCH101J50	C 570 (A,293,201)	ELECT. CAPACITOR	CEAT470M25
	C 510 (B,307,107)	CCSRCH101J50	C 571 (A,300,157)		CEAT100M50
B	C 511 (B,307,128)	CCSRCH221J50	C 572 (A,300,148)		CEAT100M50
	C 512 (B,307,118)	CCSRCH221J50	C 573 (A,300,170)	ELECT. CAPACITOR	CEAT470M25
	C 513 (B,307,140)	CCSRCH101J50	C 574 (A,300,161)	ELECT. CAPACITOR	CEAT470M25
	C 514 (B,307,134)	CCSRCH101J50	C 575 (A,300,184)	ELECT. CAPACITOR	CEAT470M25
	C 515 (B,307,210)	CCSRCH101J50	C 576 (A,300,175)	ELECT. CAPACITOR	CEAT470M25
	C 516 (B,307,205)	CCSRCH101J50	C 577 (A,300,197)	ELECT. CAPACITOR	CEAT470M25
	C 517 (B,307,223)	CCSRCH101J50	C 578 (A,300,188)	ELECT. CAPACITOR	CEAT470M25
	C 518 (B,307,218)	CCSRCH101J50	C 579 (A,270,87)		CEAT101M16
	C 519 (B,307,154)	CCSRCH221J50	C 580 (A,268,95)		CEAT101M16
	C 520 (B,307,149)	CCSRCH221J50	C 581 (A,264,87)		CEAT101M16
	C 521 (B,307,167)	CCSRCH101J50	C 582 (A,262,95)		CEAT101M16
	C 522 (B,307,162)	CCSRCH101J50	C 583 (A,258,87)		CEAT101M16
	C 523 (B,307,182)	CCSRCH101J50	C 584 (A,256,95)		CEAT101M16
C	C 524 (B,307,177)	CCSRCH101J50	C 585 (A,252,87)		CEAT101M16
	C 525 (B,307,195)	CCSRCH101J50	C 586 (A,250,95)		CEAT101M16
	C 526 (B,307,190)	CCSRCH101J50	C 587 (A,247,84)		CKSRYB473K50
	C 527 (B,297,49)	CCSRCH151J50	C 588 (A,246,84)		CKSRYB154K10
	C 528 (B,298,44)	CCSRCH151J50	C 589 (A,244,84)		CKSRYB223K50
	C 531 (B,297,83)	CCSRCH151J50	C 590 (A,247,76)		CKSRYB473K50
	C 532 (B,298,79)	CCSRCH151J50	C 591 (A,247,74)		CKSRYB154K10
	C 533 (B,297,96)	CCSRCH151J50	C 592 (A,244,73)		CKSRYB223K50
	C 534 (B,298,92)	CCSRCH151J50	C 593 (A,248,59)		CCSRCH101J50
	C 535 (B,297,109)	CCSRCH151J50	C 594 (A,247,59)		CCSRCH101J50
	C 536 (B,298,105)	CCSRCH151J50	C 595 (A,247,79)		CKSRYB103K50
D	C 539 (B,297,141)	CCSRCH151J50	C 596 (A,247,78)		CKSRYB103K50
	C 540 (B,298,137)	CCSRCH151J50	C 599 (A,269,35)		CEQJ100M25
	C 541 (B,297,209)	CCSRCH101J50	C 600 (A,274,35)		CEQJ100M25
	C 542 (B,298,203)	CCSRCH101J50	C 641 (B,309,114)		CKSRYB103K50
	C 543 (B,300,222)	CCSRCH101J50	C 642 (B,309,88)		CKSRYB103K50
	C 544 (B,300,216)	CCSRCH101J50	C 643 (B,309,214)		CKSRYB103K50
	C 547 (B,297,167)	CCSRCH151J50	C 644 (B,309,158)		CKSRYB103K50
	C 548 (B,298,163)	CCSRCH151J50	C 645 (B,309,186)		CKSRYB103K50
	C 549 (B,297,182)	CCSRCH101J50	C 661 (A,50,48)	ELECT. CAPACITOR	CEAT222M25
	C 550 (B,298,177)	CCSRCH101J50	C 662 (A,64,48)	ELECT. CAPACITOR	CEAT222M25
	C 551 (B,297,194)	CCSRCH101J50	C 673 (A,130,76)		CEAT2R2M50
E	C 552 (B,297,190)	CCSRCH101J50	C 674 (A,130,86)		CEAT2R2M50
	C 553 (A,300,51) ELECT. CAPACITOR	CEAT470M25	C 675 (A,143,76)		CEAT100M50
	C 554 (A,300,42) ELECT. CAPACITOR	CEAT470M25	C 676 (A,143,86)		CEAT100M50
	C 555 (A,300,73)	CEAT100M50	C 701 (A,202,53)		CEAT2R2M50
	C 556 (A,300,64)	CEAT100M50	C 702 (A,208,53)		CEAT2R2M50
	C 557 (A,300,86) ELECT. CAPACITOR	CEAT470M25	C 703 (A,203,62)		CCSRCH471J50
	C 558 (A,300,77) ELECT. CAPACITOR	CEAT470M25	C 704 (A,208,62)		CCSRCH471J50
	C 559 (A,300,99) ELECT. CAPACITOR	CEAT470M25	C 705 (A,203,64)		CCSRCH331J50
	C 560 (A,300,90) ELECT. CAPACITOR	CEAT470M25	C 706 (A,208,64)		CCSRCH331J50
	C 561 (A,300,112) ELECT. CAPACITOR	CEAT470M25	C 707 (B,202,68)		CCSRCH391J50
F			C 708 (B,209,68)		CCSRCH391J50
			C 709 (A,202,76)		CEAT100M50
			C 710 (A,209,76)		CEAT100M50
			C 713 (A,223,69)		CEAT100M50
			C 714 (A,216,69)		CEAT100M50

Mark No.**Description**

C 717 (A,208,72)
 C 718 (A,203,72)
 C 719 (A,217,77)
 C 720 (A,222,77)
 C 721 (A,224,53)

C 722 (A,215,56)
 C 741 (A,174,53)
 C 742 (A,180,53)
 C 743 (A,175,62)
 C 744 (A,180,62)

C 745 (A,175,64)
 C 746 (A,180,64)
 C 747 (B,174,68)
 C 748 (B,181,68)
 C 749 (A,174,76)

C 750 (A,181,76)
 C 751 (B,176,79)
 C 752 (B,179,79)
 C 753 (A,180,72)
 C 754 (A,175,72)

C 761 (A,188,53)
 C 762 (A,194,53)
 C 763 (A,189,62)
 C 764 (A,194,62)
 C 765 (A,189,64)

C 766 (A,194,64)
 C 767 (B,188,68)
 C 768 (B,195,68)
 C 769 (A,188,76)
 C 770 (A,195,76)

C 771 (B,190,79)
 C 772 (B,193,79)
 C 773 (A,194,72)
 C 774 (A,189,72)
 C 781 (A,160,53)

C 782 (A,166,53)
 C 783 (A,161,62)
 C 784 (A,166,62)
 C 785 (A,161,64)
 C 786 (A,166,64)

C 787 (B,160,68)
 C 788 (B,167,68)
 C 789 (A,160,76)
 C 790 (A,167,76)
 C 791 (B,162,79)

C 792 (B,165,79)
 C 793 (A,166,72)
 C 794 (A,161,72)
 C 801 (A,253,108)
 C 802 (A,253,101)

C 805 (A,263,164)
 C 806 (A,263,176)
 C 807 (A,260,192) ELECT. CAPACITOR
 C 808 (A,260,185) ELECT. CAPACITOR
 C 809 (A,260,168)

C 810 (A,260,173)
 C 821 (A,265,108)
 C 822 (A,265,101)
 C 825 (A,263,133)
 C 826 (A,263,145)

Part No.

CKSRYB103K50
 CKSRYB103K50
 CKSRYB104K50
 CKSRYB104K50
 CKSRYB103K50

CKSRYB103K50
 CEAT2R2M50
 CEAT2R2M50
 CCSRCH331J50
 CKSRYB223K50

CCSRCH331J50
 CKSRYB103K50
 CCSRCH471J50
 CKSRYB682K50
 CEAT100M50

CEAT100M50
 CKSRYB472K50
 CKSRYB472K50
 CKSRYB103K50
 CKSRYB103K50

CEAT2R2M50
 CEAT2R2M50
 CCSRCH331J50
 CCSRCH331J50
 CCSRCH331J50

CCSRCH331J50
 CCSRCH471J50
 CCSRCH471J50
 CEAT100M50
 CEAT100M50

CKSRYB472K50
 CKSRYB472K50
 CKSRYB103K50
 CKSRYB103K50
 CEAT2R2M50

CEAT2R2M50
 CCSRCH331J50
 CCSRCH331J50
 CCSRCH331J50
 CCSRCH331J50

CCSRCH471J50
 CCSRCH471J50
 CEAT100M50
 CEAT100M50
 CKSRYB472K50

CKSRYB472K50
 CKSRYB103K50
 CKSRYB103K50
 CEAT4R7M50
 CEAT4R7M50

CCSRCH101J50
 CCSRCH101J50
 CEAT470M25
 CEAT470M25
 CKSRYB103K50

CKSRYB103K50
 CEAT4R7M50
 CEAT4R7M50
 CCSRCH101J50
 CCSRCH101J50

Mark No.**Description**

C 827 (A,273,192) ELECT. CAPACITOR
 C 828 (A,273,185) ELECT. CAPACITOR
 C 829 (A,260,137)
 C 830 (A,260,142)
 C 841 (A,259,108)

C 842 (A,259,101)
 C 845 (A,263,148)
 C 846 (A,263,161)
 C 847 (A,266,192) ELECT. CAPACITOR
 C 848 (A,266,185) ELECT. CAPACITOR

C 849 (A,260,152)
 C 850 (A,260,157)
 C 861 (A,271,108)
 C 862 (A,271,101)
 C 865 (A,263,117)

C 866 (A,263,129)
 C 867 (A,279,192) ELECT. CAPACITOR
 C 868 (A,279,185) ELECT. CAPACITOR
 C 869 (A,260,121)
 C 870 (A,260,126)

B 12V-REG ASSY

MISCELLANEOUS

IC 661 (A,12,90) REGULATOR IC
 IC 662 (A,39,90) REGULATOR IC
 D 665 (B,28,90) CHIP DIODE
 D 666 (B,56,88) CHIP DIODE
 663 (A,46,77) 6P CABLE HOLDER

NJM78M12FA
 NJM79M12FA
 RB501V-40
 RB501V-40
 51048-0600

CAPACITORS

C 667 (B,11,86)
 C 668 (B,39,86)
 C 669 (A,25,92)
 C 670 (A,52,92)

CKSRYB103K50
 CKSRYB103K50
 CEAT221M25
 CEAT221M25

C MAIN CONTROL ASSY)

MISCELLANEOUS

IC 101 (A,150,186) CPU
 IC 102 (A,175,187) FLASH ROM
 IC 103 (A,114,172) LOGIC IC
 IC 104 (A,127,188) RESET IC
 IC 105 (A,209,126) LOGIC IC

PEG116A
 AYW7121
 CD4094BPW
 BU4842F
 CD4094BPW

IC 106 (A,126,200) LOGIC IC
 IC 107 (A,101,131) IC
 IC 108 (A,99,165) LOGIC IC
 IC 109 (A,123,174) LOGIC IC
 IC 251 (A,110,192) RDS DECORDER IC

SN74AHCT08PW
 TC74VHCT125AFTS1
 SN74LV244ATPW
 SN74AHCT32PW
 LC72725M

IC 301 (A,157,130) CPU
 IC 302 (A,184,132) FLASH ROM
 IC 303 (A,127,123) LOGIC IC
 IC 304 (A,95,113) IC
 IC 305 (A,130,139) LOGIC IC

PEG117A
 AYW7125
 CD4094BPW
 TC74VHCT125AFTS1
 SN74AHC02PW

IC 306 (A,94,131) LOGIC IC
 IC 307 (A,160,210) LOGIC IC
 IC 308 (A,114,132) LOGIC IC
 IC 310 (A,197,141) IC
 Q 101 (B,106,182) TRANSISTOR

SN74LV125APW
 SN74AHC08PW
 SN74LV244APW
 NJM2391DL-33
 DTC143TK

C

D

E

F

Mark No.**Description****Part No.****Mark No.****Description****Part No.**

A	Q 103 (B,137,183) CHIP TR (DUAL)	RN2901	102 (A,218,163) PCB BINDER	VEF1040
	Q 104 (A,120,194) CHIP TR (PNP X 2)	UMB1N		
	Q 105 (B,189,204) CHIP TR (PNP X 2)	UMB1N		
	Q 106 (B,190,196) CHIP TR (PNP X 2)	UMB1N		
	Q 107 (B,93,148) TRANSISTOR	RT1N241M		
	Q 108 (B,94,142) CHIP TR (PNP X 2)	UMB1N	R 101 (A,137,198)	RAB4C101J
	Q 109 (A,98,179) DIGITAL TR (SC-70)	RT1P241M	R 102 (A,135,192)	RS1/16S101J
	Q 110 (A,104,179) DIGITAL TR (SC-70)	RT1P241M	R 103 (A,132,168)	RAB4C101J
	Q 301 (B,215,147) TRANSISTOR	2SA1036K	R 104 (A,137,172)	RAB4C101J
	Q 302 (B,212,137) TRANSISTOR	RT1N241M	R 105 (A,142,169)	RAB4C101J

D 101 (B,135,174) DIODE	DAN202U	R 106 (A,147,168)	RAB4C101J	
D 102 (A,203,194) DIODE	DAN202U	R 107 (A,158,169)	RAB4C101J	
D 103 (A,189,188) DIODE	1SS355	R 108 (A,163,171)	RAB4C101J	
D 104 (B,186,185) DIODE	DAP202U	R 109 (A,152,206)	RAB4C101J	
B	D 105 (B,186,189) DIODE	DAN202U	R 110 (A,135,190)	RS1/16S101J

D 106 (B,189,212) DIODE	UDZS5R1(B)	R 111 (A,131,199)	RS1/16S104J
D 107 (A,118,189) DIODE	DAN202U	R 112 (A,134,196)	RS1/16S101J
D 108 (A,200,193) DIODE	RB520S-30	R 113 (B,131,205)	RS1/16S101J
D 109 (A,177,168) CHIP DIODE	RB501V-40	R 114 (A,134,194)	RS1/16S101J
D 114 (B,101,144) DIODE	1SS355	R 115 (B,147,200)	RS1/16S101J

D 116 (A,174,169) CHIP DIODE	RB501V-40	R 117 (A,131,193)	RS1/16S103J	
D 291 (A,30,137) DIODE	1SS355	R 118 (B,151,184)	RS1/16S512J	
D 301 (B,214,141) DIODE	DAN202U	R 120 (A,131,188)	RS1/16S101J	
D 302 (A,190,119) CHIP DIODE	RB501V-40	R 121 (A,129,188)	RS1/16S104J	
C	L 101 (B,194,178) CHIP SOLID	ATL7002	R 123 (B,147,186)	RS1/16S473J

L 102 (B,200,205) CHIP SOLID	ATL7002	R 124 (A,129,183)	RS1/16S101J
L 281 (B,31,202) CHIP SOLID	QTL1013	R 125 (A,130,182)	RS1/16S101J
L 291 (A,26,138) INDUCTOR	CTF1473	R 126 (A,130,180)	RS1/16S101J
L 292 (A,26,137) INDUCTOR	CTF1473	R 127 (A,131,179)	RS1/16S101J
L 293 (A,26,135) INDUCTOR	CTF1473	R 133 (A,132,183)	RS1/16S104J

L 294 (A,26,134) INDUCTOR	CTF1473	R 134 (B,147,182)	RS1/16S104J
L 295 (A,29,144) INDUCTOR	CTF1473	R 136 (B,143,174)	RS1/16S222J
L 301 (A,181,152) CHIP SOLID	QTL1013	R 137 (B,142,160)	RS1/16S474J
L 381 (B,74,189) CHIP SOLID	QTL1013	R 138 (B,152,171)	RS1/16S104J
JA281 (A,17,170) OPT. LINK IN	AKS7001	R 139 (A,151,168)	RS1/16S473J

D	JA282 (A,17,183) OPT. LINK IN	AKS7001	R 140 (A,153,169)	RS1/16S473J
	JA283 (A,17,197) OPT. LINK IN	AKS7001	R 141 (B,138,164)	RS1/16S101J
	JA284 (A,17,210) OPT. LINK OUT	AKS7002	R 142 (A,156,169)	RS1/16S104J
	JA291 (A,9,131) MINI JACK (4P) /W SW	XKN3015	R 144 (A,167,168)	RS1/16S473J
	JA292 (A,11,143) JACK	RKN1004	R 145 (A,166,174)	RS1/16S101J

KN281 (A,13,153) SCREW PLATE	VNE1948	R 147 (B,172,198)	RS1/16S473J
X 101 (A,133,187) CERAMIC	XSS3004	R 151 (A,142,203)	RS1/16S473J
X 251 (A,107,201) CRYSTAL (4.332M)	ASS7004	R 152 (A,143,203)	RS1/16S473J
X 301 (A,144,131) CERAMIC	XSS3004	R 154 (A,139,203)	RS1/16S222J
CN101 (A,208,215) CONNECTOR	CKS3394	R 155 (A,148,208)	RS1/16S473J

E	CN102 (A,223,129) 9P JUMPER CONNECTOR	52147-0910	R 157 (B,176,198)	RS1/16S104J
	CN103 (A,197,187) CONNECTOR	CKS3384	R 160 (A,138,203)	RS1/16S101J
	CN104 (A,60,177) 11P PLUG	XKP3065	R 161 (B,200,201)	RS1/16S0R0J
	CN106 (A,111,212) 23P SOCKET	XKP3082	R 162 (B,195,213)	RS1/16S223J
	CN107 (A,31,177) 13P PLUG	XKP3066	R 164 (B,184,180)	RS1/16S105J

CN108 (A,29,153) 13P PLUG	XKP3066	R 166 (B,188,185)	RS1/16S105J
CN109 (A,55,153) 11P PLUG	XKP3065	R 169 (A,125,180)	RS1/16S473J
CN110 (A,56,130) 11P PLUG	XKP3065	R 170 (A,115,167)	RS1/16S473J
CN111 (A,28,130) 13P PLUG	XKP3066	R 178 (B,105,186)	RS1/16S470J
CN112 (A,64,102) 23P SOCKET	XKP3082	R 179 (B,96,144)	RS1/16S104J

F	CN113 (A,94,180) CONNECTOR	CKS3382	R 180 (A,209,132)	RAB4C473J
	CN281 (A,33,209) 23P PLUG	XKP3071	R 181 (A,105,132)	RS1/16S101J
	CN301 (A,170,98) B TO B CONNECTOR	BTEM20P-1R	R 182 (A,102,137)	RS1/16S182J
	CN302 (A,199,102) 23P SOCKET	XKP3082	R 183 (A,101,137)	RS1/16S104J
	101 (A,218,170) PCB BINDER	VEF1040	R 184 (A,99,137)	RS1/16S104J

Mark No.**Description**

R 185 (A,101,122)
 R 186 (A,96,125)
 R 187 (A,103,125)
 R 188 (A,122,180)
 R 189 (A,96,171)

R 190 (A,98,171)
 R 191 (A,101,171)
 R 192 (A,100,171)
 R 193 (A,91,125)
 R 194 (A,117,179)

R 251 (A,117,198)
 R 252 (A,104,195)
 R 253 (A,106,184)
 R 254 (A,106,186)
 R 281 (B,24,170)

R 282 (B,23,183)
 R 283 (B,24,197)
 R 301 (A,145,137)
 R 302 (A,135,134)
 R 303 (A,135,125)

R 304 (A,139,127)
 R 305 (A,142,120)
 R 306 (B,160,129)
 R 307 (A,156,142)
 R 308 (A,146,142)

R 309 (A,154,119)
 R 310 (A,139,129)
 R 311 (B,153,139)
 R 312 (A,140,140)
 R 313 (A,135,144)

R 314 (A,138,138)
 R 315 (A,125,135)
 R 316 (A,137,140)
 R 317 (B,147,134)
 R 318 (B,147,113)

R 319 (B,145,113)
 R 322 (B,155,129)
 R 323 (B,157,129)
 R 324 (B,168,114)
 R 325 (B,164,114)

R 326 (B,161,119)
 R 327 (B,166,118)
 R 328 (A,164,117)
 R 329 (A,166,117)
 R 330 (A,165,120)

R 334 (B,158,140)
 R 335 (B,163,129)
 R 336 (B,151,137)
 R 337 (B,147,136)
 R 340 (B,180,142)

R 344 (B,122,157)
 R 345 (A,125,167)
 R 346 (A,100,116)
 R 347 (B,211,147)
 R 348 (B,212,143)

R 349 (B,110,132)
 R 350 (B,104,136)
 R 351 (B,112,132)
 R 352 (B,108,146)
 R 353 (A,111,125)

Part No.

RS1/16S101J
 RS1/16S104J
 RS1/16S0R0J
 RS1/16S0R0J
 RS1/16S104J

RS1/16S104J
 RS1/16S104J
 RS1/16S104J
 RS1/16S104J
 RS1/16S101J

RS1/16S473J
 RS1/16S102J
 RS1/16S102J
 RS1/16S102J
 RS1/16S101J

RS1/16S101J
 RS1/16S101J
 RAB4C101J
 RAB4C101J
 RAB4C101J

RS1/16S473J
 RAB4C101J
 RS1/16S101J
 RAB4C101J
 RAB4C101J

RS1/16S101J
 RS1/16S473J
 RS1/16S472J
 RS1/16S473J
 RS1/16S101J

RS1/16S101J
 RS1/16S101J
 RS1/16S473J
 RS1/16S473J
 RS1/16S473J

RS1/16S473J
 RS1/16S101J
 RS1/16S101J
 RS1/16S101J
 RS1/16S473J

RS1/16S473J
 RS1/16S101J
 RS1/16S101J
 RS1/16S101J
 RS1/16S101J

RS1/16S473J
 RS1/16S101J
 RS1/16S101J
 RS1/16S473J
 RS1/16S473J

RS1/16S104J
 RS1/16S104J
 RS1/16S101J
 RS1/16S473J
 RS1/16S222J

RS1/16S104J
 RS1/16S104J
 RS1/16S104J
 RS1/16S104J
 RS1/16S104J

Mark No.**Description**

R 354 (A,110,125)
 R 355 (B,115,129)
 R 357 (B,90,139)
 R 361 (B,163,111)
 R 362 (B,151,113)

R 363 (B,138,110)
 R 364 (B,171,114)
 R 385 (B,92,107)

CAPACITORS

C 101 (B,195,174)
 C 102 (A,197,176)
 C 103 (B,192,177)
 C 104 (A,142,198)
 C 106 (A,125,190)

C 108 (A,137,186)
 C 110 (B,143,184)
 C 112 (A,142,176)
 C 113 (B,162,188)
 C 115 (A,174,200)

C 118 (A,110,176)
 C 119 (A,185,210)
 C 120 (B,184,183)
 C 121 (B,191,185)
 C 125 (A,100,189)

C 126 (A,205,127)
 C 127 (A,122,202)
 C 128 (A,97,131)
 C 129 (A,94,166)
 C 130 (A,120,174)

C 251 (A,111,182)
 C 253 (A,114,187)
 C 254 (A,118,205)
 C 255 (A,112,197)
 C 256 (B,112,204)

C 257 (B,109,204)
 C 260 (A,108,185)
 C 281 (B,23,175)
 C 282 (B,23,187)
 C 283 (B,22,203)

C 284 (B,22,211)
 C 285 (A,31,198)
 C 293 (B,24,159)
 C 301 (A,208,143)
 C 302 (B,204,144)

C 304 (A,197,131)
 C 305 (A,143,127)
 C 307 (A,172,130)
 C 309 (A,152,142)
 C 311 (A,184,145)

C 314 (A,123,124)
 C 315 (A,91,113)
 C 316 (A,126,140)
 C 317 (A,90,132)
 C 318 (A,164,209)

C 319 (A,110,135)

Part No.

RS1/16S104J
 RS1/16S104J
 RS1/16S104J
 RS1/16S331J
 RS1/16S331J

RS1/16S331J
 RS1/16S331J
 RS1/16S0R0J

CKSRYB103K50
 CEAT102M10
 CKSRYB103K50
 CKSRYB104K16
 CKSRYB105K10

CKSRYB104K16
 CKSRYB472K50
 CKSRYB104K16
 CKSRYB104K16
 CKSRYB104K16

CKSRYB104K16
 CEAT100M50
 CKSRYB473K25
 CKSRYB473K25
 CEAT471M6R3

CKSRYB104K16
 CKSRYB104K16
 CKSRYB104K16
 CKSRYB104K16
 CKSRYB104K16

CEAT100M50
 CCSRCH561J50
 CEAT101M10
 CKSRYB102K50
 CCSRCH270J50

CCSRCH270J50
 CKSRYB472K50
 CKSRYB104K16
 CKSRYB104K16
 CKSRYB104K16

CKSRYB104K16
 CEAT101M10
 CKSRYB104K16
 CEAT102M10
 CKSRYB104K16

CEAT331M10
 CKSRYB104K16
 CKSRYB104K16
 CKSRYB104K16
 CKSRYB104K16

CKSRYB104K16
 CKSRYB104K16
 CKSRYB104K16
 CKSRYB104K16
 CKSRYB104K16

CKSRYB104K16

A

C

D

E

F

Mark No.	Description	Part No.	Mark No.	Description	Part No.
-----------------	--------------------	-----------------	-----------------	--------------------	-----------------

D GUARD-C ASSY

GUARD-C Assy has no service part.

Mark No.	Description	Part No.
-----------------	--------------------	-----------------

X 551 (A,91,28) CRYSTAL RESONATOR
 CN301 (A,185,49) 10P CONNECTOR
 CN402 (A,165,14) 19P SOCKET
 CN801 (A,124,60) 26P PLUG
 CN901 (A,173,11) B TO B CONNCTOR

VSS1171
 VKN1414
 XKP3080
 AKP7208
 BTEM20P-1R

E GUARD-F ASSY
MISCELLANEOUS

921 (A,245,238) PCB BINDER

VEF1040

CN951 (A,128,14) 23P SOCKET

XKP3083

G DSP ASSY
MISCELLANEOUS

IC 101 (A,65,37) DSP IC
 IC 103 (B,43,38) LOGIC IC (LATCHES)
 IC 104 (B,41,21) LOGIC IC (LATCHES)
 IC 105 (A,16,16) 2 TO 4 LINE DECODER
 IC 106 (A,15,37) FLASH ROM

 IC 107 (A,33,49) SRAM (4M)
 IC 109 (A,8,19) 1 CHIP OR GATE
 IC 201 (A,113,37) DSP IC
 IC 291 (A,143,55) IC
 IC 301 (A,191,36) DA I/F TRANCEIVER

ADSP-21266SKSTZ-2D
 TC74VHC573FS1
 TC74VHC573FS1
 TC7W139FU
 AYW7128

 CY7C1049C3312VXC
 TCTSH32FUS1
 DSPEC56371AF180
 TC74VHC08FTS1
 AK4114VQ

RESISTORS

R 101 (A,44,45)
 R 103 (A,46,39)
 R 104 (A,46,38)
 R 105 (A,46,35)
 R 106 (A,50,24)

RAB4C472J
 RS1/16S101J
 RS1/16S472J
 RAB4C470J
 RAB4C470J

IC 107 (A,72,19)
 IC 108 (A,52,17)
 IC 109 (A,54,18)
 IC 110 (A,57,18)
 IC 111 (A,62,18)

R 107 (A,49,21)
 R 108 (A,52,17)
 R 109 (A,54,18)
 R 110 (A,57,18)
 R 111 (A,62,18)

RS1/16S470J
 RS1/16S470J
 RS1/16S470J
 RAB4C470J
 RAB4C470J

IC 401 (A,154,28) AUDIO 8CH DAC
 IC 481 (A,170,28) AD CONVERTER IC
 IC 551 (A,98,25) LOGIC IC
 IC 651 (A,141,47) IC
 △ IC 901 (B,83,45) REGULATOR IC

AK4359VF
 AK5358ET
 TC7WHU04FU
 TC74VHC157FTS1
 MM1663DT

 BD7820FP
 BD7802FP
 BD00KA5WFP

 MA152WA
 MA152WK

R 112 (A,72,19)
 R 113 (A,84,31)
 R 114 (B,75,34)
 R 115 (B,79,34)
 R 116 (B,75,38)

RAB4C220J
 RAB4C101J
 RS1/16S220J
 RS1/16S220J
 RS1/16S101J

△ IC 902 (A,82,16) REGULATOR IC
 △ IC 903 (B,203,16) REGULATOR IC
 △ IC 904 (A,176,25) LDO REGULATOR
 D 401 (B,164,18) DIODE
 D 402 (A,166,19) DIODE

BD7820FP
 BD7802FP
 BD00KA5WFP

 MA152WA
 MA152WK

R 117 (B,77,37)
 R 118 (A,80,40)

RS1/16S101J
 RS1/16S101J

R 119 (B,75,44)
 R 120 (B,77,44)

RS1/16S472J
 RS1/16S472J

R 122 (B,63,53)

RS1/16S101J

D 906 (B,73,23) DIODE
 L 101 (A,73,57) CHIP SOLID INDUCTOR

RB160L-40
 QTL1013

R 125 (B,69,49)
 R 127 (B,66,48)

RS1/16S101J
 RS1/16S101J

L 102 (A,67,18) CHIP SOLID INDUCTOR
 L 104 (B,35,34) CHIP SOLID INDUCTOR

ATL7002
 QTL1013

R 129 (B,64,48)
 R 131 (B,62,48)

RS1/16S101J
 RS1/16S101J

L 105 (B,32,17) CHIP SOLID INDUCTOR

QTL1013

R 132 (B,62,43)

RS1/16S100J

L 106 (A,13,20) CHIP SOLID INDUCTOR
 L 107 (A,19,23) CHIP SOLID INDUCTOR
 L 108 (B,32,54) CHIP SOLID INDUCTOR

QTL1013
 QTL1013
 QTL1013

R 135 (B,52,52)
 R 136 (B,57,49)
 R 137 (B,81,34)

RS1/16S472J
 RS1/16S101J
 RS1/16S101J

L 201 (B,105,32) CHIP SOLID INDUCTOR
 L 202 (A,127,34) CHIP SOLID INDUCTOR

QTL1013
 ATL7002

R 148 (A,41,16)
 R 149 (A,14,20)

RAB4C470J
 RS1/16S470J

L 203 (A,98,18) CHIP SOLID INDUCTOR
 L 291 (A,149,55) CHIP SOLID INDUCTOR

ATL7002
 QTL1013

R 150 (A,16,20)
 R 153 (A,8,21)

RS1/16S470J
 RS1/16S470J

L 301 (B,188,48) CHIP SOLID INDUCTOR
 L 302 (A,182,36) CHIP SOLID INDUCTOR

QTL1013
 QTL1013

R 154 (A,9,14)
 R 155 (B,54,52)

RS1/16S472J
 RS1/16S472J

L 305 (A,202,29) CHIP SOLID INDUCTOR

QTL1013

R 156 (B,50,52)

RS1/16S472J

L 401 (B,146,32) CHIP SOLID INDUCTOR
 L 481 (B,163,30) CHIP SOLID INDUCTOR
 L 482 (A,175,35) CHIP SOLID INDUCTOR

QTL1013
 QTL1013
 QTL1013

R 201 (A,116,48)
 R 202 (B,120,40)
 R 203 (B,118,40)

RAB4C101J
 RS1/16S103J
 RS1/16S103J

L 551 (A,101,23) CHIP SOLID INDUCTOR

QTL1013

R 204 (B,116,40)

RS1/16S103J

L 651 (A,147,50) CHIP SOLID INDUCTOR

QTL1013

R 205 (B,114,40)

RS1/16S103J

L 901 (B,191,19) CHIP SOLID INDUCTOR

ATL7002

R 207 (B,112,40)

RS1/16S473J

L 902 (B,187,19) CHIP SOLID INDUCTOR

ATL7002

R 209 (B,112,35)

RS1/16S472J

L 903 (B,179,19) CHIP SOLID INDUCTOR

ATL7002

R 212 (A,101,36)

RS1/16S473J

JA351 (A,225,22) JACK

AKB7131

R 214 (B,100,34)

RS1/16S101J

X 301 (A,190,25) CRYSTAL RESONATOR

XSS3003

R 215 (B,104,40)

RS1/16S101J

F

R 216 (A,98,33)

RS1/16S101J

R 217 (A,100,33)

RS1/16S101J

Mark No.**Description****Part No.**

R 218 (A,97,33)	RS1/16S101J	R 553 (A,99,28)	RS1/16S0R0J
R 219 (A,97,36)	RS1/16S472J	R 554 (A,99,21)	RS1/16S220J
R 220 (A,110,27)	RS1/16S101J	R 555 (A,95,22)	RS1/16S220J
R 222 (B,106,24)	RS1/16S101J	R 613 (B,162,41)	RS1/16S0R0J
R 226 (B,116,34)	RS1/16S473J	R 614 (B,160,41)	RS1/16S0R0J
R 228 (B,106,28)	RS1/16S472J	R 615 (A,175,40)	RS1/16S0R0J
R 233 (B,126,35)	RS1/16S470J	R 616 (B,178,41)	RS1/16S0R0J
R 237 (A,124,39)	RS1/16S470J	R 651 (A,134,49)	RAB4C101J
R 238 (A,124,43)	RS1/16S470J	R 654 (A,134,45)	RAB4C470J
R 239 (A,124,44)	RS1/16S470J	R 657 (A,147,44)	RS1/16S470J
R 240 (A,124,46)	RS1/16S470J	R 658 (B,144,47)	RS1/16S470J
R 241 (A,124,47)	RS1/16S470J	R 659 (A,147,46)	RS1/16S470J
R 244 (B,120,46)	RS1/16S470J	R 660 (A,147,47)	RS1/16S101J
R 246 (B,129,48)	RS1/16S470J	R 661 (B,141,49)	RS1/16S101J
R 248 (B,116,26)	RS1/16S470J	R 662 (A,147,49)	RS1/16S101J
R 250 (B,118,26)	RS1/16S470J	R 668 (B,138,45)	RS1/16S104J
R 261 (B,125,30)	RS1/16S222J	R 805 (A,135,58) RESISTOR ARRAY	RAB4C104J
R 291 (B,145,54)	RS1/16S220J	R 806 (A,94,47) RESISTOR ARRAY	RAB4C104J
R 292 (B,143,54)	RS1/16S220J	R 810 (A,135,61)	RS1/16S104J
R 293 (A,136,54)	RS1/16S220J	R 901 (B,208,16)	RS1/16S104J
R 294 (A,136,52)	RS1/16S220J	R 902 (B,84,57)	RS1/16S0R0J
R 302 (B,195,49)	RS1/16S104J	R 903 (B,77,57)	RS1/16S0R0J
R 303 (B,193,49)	RS1/16S104J	R 906 (A,74,14)	RS1/16S1802F
R 304 (B,191,49)	RS1/16S104J	R 907 (A,73,12)	RS1/16S3002F
R 306 (A,185,45)	RS1/16S0R0J	R 908 (B,177,33)	RS1/16S2002F
R 309 (B,184,48)	RS1/16S0R0J	R 909 (B,174,34)	RS1/16S3002F
R 311 (A,182,44)	RS1/16S101J	R 919 (B,178,23)	RS1/16S0R0J
R 312 (A,184,33)	RS1/16S470J	R 929 (B,181,19)	RS1/16S104J
R 313 (A,184,32)	RS1/16S101J	R 930 (B,183,19)	RS1/16S104J
R 314 (A,184,30)	RS1/16S101J	R 951 (A,133,14) RESISTOR ARRAY	RAB4C104J
R 315 (A,184,29)	RS1/16S101J	R 955 (A,116,18)	RS1/16S472J
R 317 (A,184,28)	RS1/16S470J	R 962 (B,94,15)	RS1/16S104J
R 321 (A,198,30)	RAB4C101J		
R 324 (A,197,26)	RS1/16S103J		
R 325 (A,200,38)	RS1/16S1802F		
R 326 (A,199,41)	RS1/16S0R0J	C 101 (A,78,58)	CEVW101M16
R 351 (B,214,16)	RS1/16S750J	C 102 (A,67,14)	CEVW101M4
R 352 (B,217,30)	RS1/16S750J	C 103 (A,50,51)	CCSRCH471J50
R 361 (B,208,28)	RS1/16S100J	C 104 (A,49,51)	CKSRYB104K16
R 362 (B,212,30)	RS1/16S100J	C 105 (A,50,48)	CCSRCH471J50
R 401 (B,160,36)	RS1/16S470J	C 106 (A,49,48)	CKSRYB104K16
R 402 (B,158,36)	RS1/16S470J	C 107 (A,50,45)	CCSRCH471J50
R 404 (B,156,30)	RS1/16S101J	C 108 (A,49,45)	CKSRYB104K16
R 405 (B,154,30)	RS1/16S101J	C 109 (A,50,43)	CCSRCH471J50
R 406 (B,152,30)	RS1/16S101J	C 110 (A,49,43)	CKSRYB104K16
R 407 (B,150,33)	RS1/16S4R7J	C 111 (A,50,39)	CCSRCH471J50
R 408 (A,143,19)	RS1/16S101J	C 112 (A,49,39)	CKSRYB104K16
R 409 (A,145,18)	RS1/16S101J	C 113 (A,50,36)	CCSRCH471J50
R 410 (A,148,18)	RS1/16S101J	C 114 (A,49,36)	CKSRYB104K16
R 411 (A,150,18)	RS1/16S101J	C 115 (A,50,33)	CCSRCH471J50
R 412 (A,153,18)	RS1/16S101J	C 116 (A,49,33)	CKSRYB104K16
R 413 (A,155,18)	RS1/16S101J	C 117 (A,50,30)	CCSRCH471J50
R 414 (A,158,18)	RS1/16S101J	C 118 (A,49,30)	CKSRYB104K16
R 415 (A,160,18)	RS1/16S101J	C 119 (A,50,27)	CCSRCH471J50
R 481 (B,170,30)	RS1/16S101J	C 120 (A,49,27)	CKSRYB104K16
R 482 (B,172,35)	RS1/16S470J	C 121 (A,54,23)	CCSRCH471J50
R 483 (B,169,35)	RS1/16S470J	C 122 (A,54,21)	CKSRYB104K16
R 503 (A,153,52)	RS1/16S0R0J	C 123 (A,57,23)	CCSRCH471J50
R 551 (A,96,26)	RS1/16S105J	C 124 (A,57,21)	CKSRYB104K16
R 552 (A,96,30)	RS1/16S152J	C 125 (A,60,23)	CCSRCH471J50

Mark No.**Description****Part No.****Part No.****Part No.**

R 553 (A,99,28)

RS1/16S0R0J

R 554 (A,99,21)

RS1/16S220J

R 555 (A,95,22)

RS1/16S220J

R 613 (B,162,41)

RS1/16S0R0J

R 614 (B,160,41)

RS1/16S0R0J

R 615 (A,175,40)

RS1/16S0R0J

R 616 (B,178,41)

RS1/16S0R0J

R 651 (A,134,49)

RAB4C101J

R 654 (A,134,45)

RAB4C470J

R 657 (A,147,44)

RS1/16S470J

R 658 (B,144,47)

RS1/16S470J

R 659 (A,147,46)

RS1/16S470J

R 660 (A,147,47)

RS1/16S101J

R 661 (B,141,49)

RS1/16S101J

R 662 (A,147,49)

RS1/16S101J

R 668 (B,138,45)

RS1/16S104J

R 805 (A,135,58) RESISTOR ARRAY

RAB4C104J

R 806 (A,94,47) RESISTOR ARRAY

RAB4C104J

R 810 (A,135,61)

RS1/16S104J

R 901 (B,208,16)

RS1/16S104J

R 902 (B,84,57)

RS1/16S0R0J

R 903 (B,77,57)

RS1/16S0R0J

R 906 (A,74,14)

RS1/16S1802F

R 907 (A,73,12)

RS1/16S3002F

R 908 (B,177,33)

RS1/16S2002F

CAPACITORS

C 101 (A,78,58)

CEVW101M16

C 102 (A,67,14)

CEVW101M4

C 103 (A,50,51)

CCSRCH471J50

C 104 (A,49,51)

CKSRYB104K16

C 105 (A,50,48)

CCSRCH471J50

C 106 (A,49,48)

CKSRYB104K16

C 107 (A,50,45)

CCSRCH471J50

C 108 (A,49,45)

CKSRYB104K16

C 109 (A,50,43)

CCSRCH471J50

C 110 (A,49,43)

CKSRYB104K16

C 111 (A,50,39)

CCSRCH471J50

C 112 (A,49,39)

CKSRYB104K16

C 113 (A,50,36)

CCSRCH471J50

C 114 (A,49,36)

CKSRYB104K16

C 115 (A,50,33)

CCSRCH471J50

C 116 (A,49,33)

CKSRYB104K16

C 117 (A,50,30)

CCSRCH471J50

C 118 (A,49,30)

CKSRYB104K16

C 119 (A,50,27)

CCSRCH471J50

C 120 (A,49,27)

CKSRYB104K16

C 121 (A,54,23)

CCSRCH471J50

C 122 (A,54,21)

CKSRYB104K16

C 123 (A,57,23)

CCSRCH471J50

C 124 (A,57,21)

CKSRYB104K16

C 125 (A,60,23)

CCSRCH471J50

A

E

F

Mark No.	Description	Part No.	Mark No.	Description	Part No.
A	C 126 (A,60,21)	CKSRYB104K16	C 188 (A,9,16)	CKSRYB104K16	CKSRYB104K16
	C 127 (A,64,23)	CCSRCH471J50	C 201 (A,119,47)	CCSRCH471J50	CCSRCH471J50
	C 128 (A,64,21)	CKSRYB104K16	C 202 (A,119,48)	CKSRYB104K16	CKSRYB104K16
	C 129 (A,67,23)	CCSRCH471J50	C 203 (A,112,47)	CCSRCH471J50	CCSRCH471J50
	C 130 (A,67,21)	CKSRYB104K16	C 204 (A,112,48)	CKSRYB104K16	CKSRYB104K16
	C 131 (A,69,23)	CCSRCH471J50	C 205 (A,107,47)	CCSRCH471J50	CCSRCH471J50
	C 132 (A,69,21)	CKSRYB104K16	C 206 (A,107,48)	CKSRYB104K16	CKSRYB104K16
	C 133 (A,73,23)	CCSRCH471J50	C 207 (A,103,42)	CCSRCH471J50	CCSRCH471J50
	C 134 (A,73,21)	CKSRYB104K16	C 208 (A,101,42)	CKSRYB104K16	CKSRYB104K16
	C 135 (A,76,24)	CCSRCH471J50	C 209 (A,103,39)	CCSRCH471J50	CCSRCH471J50
B	C 136 (A,76,23)	CKSRYB104K16	C 210 (A,101,39)	CKSRYB104K16	CKSRYB104K16
	C 137 (A,79,26)	CCSRCH471J50	C 211 (A,103,31)	CCSRCH471J50	CCSRCH471J50
	C 138 (A,81,26)	CKSRYB104K16	C 212 (A,101,31)	CKSRYB104K16	CKSRYB104K16
	C 139 (A,79,28)	CCSRCH471J50	C 216 (A,105,28)	CCSRCH471J50	CCSRCH471J50
	C 140 (A,81,28)	CKSRYB104K16	C 217 (A,105,26)	CKSRYB104K16	CKSRYB104K16
	C 141 (A,79,32)	CCSRCH471J50	C 218 (A,108,28)	CCSRCH471J50	CCSRCH471J50
	C 142 (A,81,32)	CKSRYB104K16	C 219 (A,108,26)	CKSRYB104K16	CKSRYB104K16
	C 143 (A,79,35)	CCSRCH471J50	C 220 (B,110,35)	CCSRCH471J50	CCSRCH471J50
	C 144 (A,81,35)	CKSRYB104K16	C 221 (A,114,28)	CCSRCH471J50	CCSRCH471J50
	C 145 (A,79,43)	CCSRCH471J50	C 222 (A,114,27)	CKSRYB104K16	CKSRYB104K16
C	C 146 (A,81,43)	CKSRYB104K16	C 223 (A,123,33)	CCSRCH471J50	CCSRCH471J50
	C 147 (A,79,38)	CCSRCH471J50	C 224 (A,125,33)	CKSRYB104K16	CKSRYB104K16
	C 148 (A,81,38)	CKSRYB104K16	C 225 (A,123,36)	CCSRCH471J50	CCSRCH471J50
	C 149 (A,79,45)	CCSRCH471J50	C 226 (A,125,36)	CKSRYB104K16	CKSRYB104K16
	C 150 (A,81,45)	CKSRYB104K16	C 227 (A,123,41)	CCSRCH471J50	CCSRCH471J50
	C 151 (A,79,48)	CCSRCH471J50	C 228 (A,125,41)	CKSRYB104K16	CKSRYB104K16
	C 152 (A,81,48)	CKSRYB104K16	C 229 (A,131,35)	CHIP ELECT. CAPACITOR	CEVV101M4
	C 153 (A,77,52)	CCSRCH471J50	C 230 (A,93,17)	CEVV101M16	CEVV101M16
	C 154 (A,77,53)	CKSRYB104K16	C 291 (A,142,59)	CCSRCH471J50	CCSRCH471J50
	C 155 (A,74,52)	CCSRCH471J50	C 292 (A,142,60)	CKSRYB104K16	CKSRYB104K16
D	C 156 (A,74,53)	CKSRYB104K16	C 303 (A,183,41)	CCSRCH471J50	CCSRCH471J50
	C 157 (A,71,52)	CCSRCH471J50	C 304 (A,185,41)	CKSRYB104K16	CKSRYB104K16
	C 158 (A,71,53)	CKSRYB104K16	C 305 (A,179,42)	CEVV470M6R3	CEVV470M6R3
	C 159 (A,68,52)	CCSRCH471J50	C 306 (A,184,36)	CCSRCH471J50	CCSRCH471J50
	C 160 (A,68,53)	CKSRYB104K16	C 307 (A,185,36)	CKSRYB104K16	CKSRYB104K16
	C 161 (B,65,53)	CKSRYB103K50	C 310 (A,188,28)	CCSRCH120J50	CCSRCH120J50
	C 162 (A,66,52)	CCSRCH471J50	C 311 (A,192,28)	CCSRCH120J50	CCSRCH120J50
	C 163 (A,66,53)	CKSRYB104K16	C 312 (B,196,28)	CKSRYB104K16	CKSRYB104K16
	C 164 (A,63,52)	CCSRCH471J50	C 315 (B,198,28)	CKSRYB102K50	CKSRYB102K50
	C 165 (A,63,53)	CKSRYB104K16	C 316 (A,205,31)	CEVV470M6R3	CEVV470M6R3
E	C 166 (A,60,52)	CCSRCH471J50	C 317 (A,200,35)	CKSRYB104K16	CKSRYB104K16
	C 167 (A,60,53)	CKSRYB104K16	C 318 (A,199,35)	CCSRCH471J50	CCSRCH471J50
	C 168 (A,57,52)	CCSRCH471J50	C 319 (A,199,38)	CKSRYB474K10	CKSRYB474K10
	C 169 (A,57,53)	CKSRYB104K16	C 353 (B,210,16)	CKSRYB103K50	CKSRYB103K50
	C 170 (A,54,52)	CCSRCH471J50	C 354 (B,215,30)	CKSRYB103K50	CKSRYB103K50
	C 171 (A,54,53)	CKSRYB104K16	C 401 (A,147,30)	CCSRCH471J50	CCSRCH471J50
	C 174 (A,22,17)	CEVV101M16	C 402 (A,148,30)	CKSRYB104K16	CKSRYB104K16
	C 175 (B,36,38)	CCSRCH471J50	C 403 (A,145,36)	CEVV101M16	CEVV101M16
	C 176 (B,34,38)	CKSRYB104K16	C 404 (B,160,30)	CKSRYB104K16	CKSRYB104K16
	C 177 (B,33,21)	CCSRCH471J50	C 407 (B,143,19)	CCSRCH471J50	CCSRCH471J50
F	C 178 (B,31,21)	CKSRYB104K16	C 408 (B,145,19)	CCSRCH471J50	CCSRCH471J50
	C 179 (A,14,16)	CCSRCH471J50	C 409 (B,148,19)	CCSRCH471J50	CCSRCH471J50
	C 180 (A,12,16)	CKSRYB104K16	C 410 (B,150,19)	CCSRCH471J50	CCSRCH471J50
	C 181 (A,15,25)	CCSRCH471J50	C 411 (B,153,19)	CCSRCH471J50	CCSRCH471J50
	C 182 (A,15,23)	CKSRYB104K16	C 412 (B,155,19)	CCSRCH471J50	CCSRCH471J50
	C 183 (A,40,49)	CCSRCH471J50	C 413 (B,158,19)	CCSRCH471J50	CCSRCH471J50
	C 184 (A,42,49)	CKSRYB104K16	C 414 (B,160,19)	CCSRCH471J50	CCSRCH471J50
	C 185 (A,26,51)	CCSRCH471J50	C 415 (A,158,22)	CCSRCH471J50	CCSRCH471J50
	C 186 (A,24,51)	CKSRYB104K16	C 416 (A,158,21)	CKSRYB104K16	CKSRYB104K16
	C 187 (A,9,17)	CCSRCH471J50	C 417 (A,154,36)	CEVV101M16	CEVV101M16

Mark No. **Description**

C 418 (A,145,25)	CEVV470M6R3
C 420 (A,148,27)	CKSRYB104K16
C 481 (B,167,35)	CKSRYB104K16
C 482 (A,165,29)	CKSRYB104K16
C 483 (A,162,29)	CKSQYB225K10
C 485 (A,169,23)	CCSRCH471J50
C 486 (A,169,21)	CKSRYB104K16
C 487 (A,163,34)	CEVV101M16
C 488 (A,172,23)	CCSRCH471J50
C 489 (A,172,21)	CKSRYB104K16
C 490 (A,171,35)	CEVV100M16
C 552 (A,102,26)	CKSRYB104K16
C 553 (A,101,26)	CCSRCH471J50
C 554 (A,94,26)	CCSRCH100D50
C 555 (A,94,30)	CCSRCH100D50
C 651 (A,141,50)	CCSRCH471J50
C 652 (A,141,52)	CKSRYB104K16
C 801 (B,126,51)	CKSRYB104K16
C 901 (B,77,50)	CKSQYB105K16
C 903 (B,88,49)	CKSRYB105K6R3
C 904 (A,83,21)	CKSRYB105K6R3
C 905 (A,73,15) CHIP CERAMIC C.	DCG1028
C 906 (B,197,20)	CKSRYB104K16
C 907 (B,203,24)	CKSRYB105K6R3
C 908 (B,181,34)	CKSRYB105K6R3
C 909 (B,179,34)	CKSRYB105K6R3
C 918 (B,177,19)	CKSRYB103K50
C 921 (B,128,30)	CCSRCH471J50
C 922 (B,130,30)	CKSRYB103K50
C 923 (B,173,29)	CKSRYB104K16
C 924 (B,175,29)	CCSRCH471J50

Part No.

CD74HC4051PW
CD74HC4053PW
LA7109
BU4094BCF
PDC132A
UPC4570G2
2SC4081
2SC4081
2SC4081
RT1N431M
DAN202U
DAN202U
1SS355
1SS355
DAP202U
UDZS6R2(B)
UDZS6R2(B)
UDZS6R2(B)
UDZS6R2(B)
1SS355
UDZS5R1(B)
UDZS5R1(B)
UDZS5R1(B)
LCTAW120J2520
LAU330J

Mark No.

JA 1006(A,57,233)	PIN JACK (1P)
X 1001(A,44,196)	CRYSTAL (14.31818M)
CN1001(A,184,173)	11P SOCKET
CN1002(A,77,178)	21P SOCKET
CN1003(A,184,198)	13P SOCKET

CN1004(A,161,233)	20P SOCKET
1003(A,78,233)	PIN JACK (2P)
1001(A,134,233)	PIN JACK (2P)
1002(A,106,233)	PIN JACK (2P)

RESISTORS

R 1001(B,142,224)	RS1/16S750J
R 1002(B,125,221)	RS1/16S750J
R 1003(B,97,220)	RS1/16S750J
R 1004(B,69,220)	RS1/16S750J
R 1007(B,81,220)	RS1/16S750J

R 1009(B,108,220)	RS1/16S750J
R 1011(B,54,219)	RS1/16S750J
R 1014(B,99,198)	RS1/16S102J
R 1017(B,105,201)	RS1/16S103J
R 1018(B,114,201)	RS1/16S103J

R 1019(B,122,201)	RS1/16S103J
R 1020(B,131,201)	RS1/16S103J
R 1021(A,108,203)	RS1/16S103J
R 1022(A,117,203)	RS1/16S103J
R 1023(B,133,204)	RS1/16S473J

R 1024(B,135,205)	RS1/16S473J
R 1025(B,66,204)	RS1/16S473J
R 1026(B,63,204)	RS1/16S473J
R 1030(B,85,196)	RS1/16S473J
R 1031(B,71,193)	RS1/16S473J
R 1032(B,69,193)	RS1/16S473J
R 1033(B,54,189)	RS1/16S473J
R 1034(A,42,177)	RS1/16S102J
R 1035(B,28,187)	RS1/16S512J
R 1036(B,30,187)	RS1/16S392J

R 1037(B,41,189)	RS1/16S102J
R 1039(A,25,193)	RS1/16S331J
R 1040(A,25,196)	RS1/16S331J
R 1041(A,27,196)	RS1/16S331J
R 1043(B,175,192)	RS1/16S561J

R 1046(B,179,190)	RS1/16S102J
R 1049(B,94,203)	RS1/16S103J
R 1051(B,88,200)	RS1/16S0R0J
R 1054(B,90,209)	RS1/16S473J
R 1101(A,162,205)	RS1/16S104J

R 1102(A,158,206)	RS1/16S104J
R 1103(A,164,205)	RS1/16S331J
R 1104(A,155,205)	RS1/16S331J
R 1105(B,163,199)	RS1/16S104J
R 1106(B,156,199)	RS1/16S104J

R 1107(B,163,193)	RS1/16S472J
R 1108(B,157,193)	RS1/16S472J
R 1109(B,168,195)	RS1/16S472J
R 1110(B,150,195)	RS1/16S472J
R 1111(B,163,190)	RS1/16S103J

L 1002(B,180,192)	CHIP COIL
L 1003(A,33,200)	AXIAL INDUCTOR

A

C

E

F

Mark No. **Description**
Part No.
Mark No. **Description**
Part No.

A	R 1112(B,155,189)	RS1/16S103J	C 1105(A,163,201)	CEAT100M50
	R 1113(A,165,188)	RS1/16S103J	C 1106(A,155,201)	CEAT100M50
	R 1114(A,154,189)	RS1/16S103J	C 1107(A,168,197)	CEAT100M50
	R 1115(B,162,183)	RS1/16S101J	C 1108(A,150,197)	CEAT100M50
	R 1116(B,156,183)	RS1/16S101J	C 1113(A,157,193)	CKSRYB103K50
	R 1117(B,169,185)	RS1/16S104J	C 1114(A,162,193)	CKSRYB103K50
B	R 1118(B,167,182)	RS1/16S104J	C 1115(A,162,180)	CEAT100M50
	R 1122(A,170,205)	RS1/16S514J	C 1116(A,156,180)	CEAT100M50
	R 1124(A,170,208)	RS1/16S393J	C 1117(A,174,198)	CKSRYB103K50
			C 1118(B,167,224)	CKSRYB103K50
			C 1127(A,171,220)	CKSRYB104K50
C	<u>CAPACITORS</u>		I S-VIDEO ASSY	
	C 1001(A,75,202)	CKSRYB103K50	MISCELLANEOUS	
	C 1002(A,73,204)	CKSRYB103K50	IC 1201(A,115,134) IC	CD74HC4051PW
	C 1005(A,91,212)	CKSRYB104K50	IC 1202(A,103,134) IC	CD74HC4051PW
	C 1006(A,94,212)	CKSRYB104K50	IC 1203(A,111,119) IC	CD74HC4053PW
	C 1008(B,65,202)	CKSRYB104K50	IC 1204(A,130,136) IC	LA7213
D	C 1011(B,96,205)	CKSRYB103K50	IC 1205(A,66,138) VIDEO AMP IC	LA7109
	C 1012(B,101,198)	CKSRYB103K50		
	C 1014(A,88,197)	CEAT101M10	Q 1201(B,147,133) TRANSISTOR	RT1N241M
	C 1016(A,116,200)	CEAT101M10	Q 1203(B,135,115) TRANSISTOR	2SC4081
	C 1017(A,125,200)	CEAT101M10	Q 1204(B,135,106) TRANSISTOR	2SC4081
	C 1018(A,134,200)	CEAT101M10	Q 1205(A,148,117) TRANSISTOR	2SC4081
E	C 1019(B,116,211)	CKSRYB104K50	Q 1206(B,155,104) TRANSISTOR	2SC4081
	C 1020(A,120,208)	CKSRYB104K50	D 1201(B,141,129) DIODE	1SS355
	C 1021(A,123,214)	CEAT101M10	D 1202(B,144,134) DIODE	1SS355
	C 1022(A,129,214)	CEAT101M10	D 1203(B,79,133) DIODE	DAN202K
	C 1024(B,84,225)	CCSRCH181J50	D 1204(A,83,129) DIODE	DAN202K
	C 1025(B,113,224)	CCSRCH181J50	D 1251(B,93,114) DIODE	1SS355
F	C 1026(B,56,224)	CCSRCH181J50	D 1252(B,77,115) DIODE	1SS355
	C 1027(A,45,180)	CEAT101M10	D 1301(B,170,143) DIODE	1SS355
	C 1028(A,45,187)	CEAT101M10	L 1201(A,155,109) CHIP COIL	LCTAW120J2520
	C 1029(A,45,177)	CKSRYB473K25	L 1202(B,162,108) CHIP COIL	LCTAW120J2520
	C 1030(A,27,185)	CKSRYB473K25	L 1301(B,161,128) CHIP SOLID INDUCTOR	QTL1013
	C 1031(A,39,177)	CCSRCH101J50		
G	C 1032(A,35,177)	CKSRYB122K50	CN1201(A,175,128) 13P SOCKET	XKP3077
	C 1033(A,31,177)	CKSRYB122K50	CN1202(A,175,104) 11P SOCKET	XKP3076
	C 1035(B,34,187)	CKSRYB103K50	CN1203(A,68,108) 15P SOCKET	XKP3078
	C 1036(B,47,191)	CCSRCH150J50	CN1204 SOCKET	XKB3052
	C 1037(B,45,191)	CCSRCH180J50	CN1205(A,97,163) SOCKET	XKB3051
	C 1038(B,36,190)	CCSRCH240J50		
H	C 1039(B,33,194)	CCSRCH240J50	CN1206(A,125,163) SOCKET	XKB3051
	C 1040(A,31,193)	CCSRCH101J50	CN1302(A,175,152) 07P CONNECTOR	RKN1048
	C 1041(A,28,193)	CCSRCH101J50		
	C 1042(A,27,193)	CCSRCH101J50		
	C 1045(B,184,192)	CCSRCH330J50		
	C 1046(B,178,193)	CCSRCH120J50		
I	C 1047(B,180,194)	CCSRCJ3R0C50	R 1201(B,131,152)	RS1/16S750J
	C 1093(B,111,224)	CKSRYB103K50	R 1202(B,133,152)	RS1/16S750J
	C 1095(B,82,225)	CKSRYB103K50	R 1203(B,117,152)	RS1/16S750J
	C 1096(B,79,225)	CKSRYB103K50	R 1204(B,119,152)	RS1/16S750J
	C 1097(B,54,224)	CKSRYB103K50	R 1205(B,89,152)	RS1/16S750J
	C 1098(B,43,224)	CKSRYB103K50	R 1206(B,91,152)	RS1/16S750J
J	C 1101(A,162,206)	CCSRCH101J50	R 1207(B,61,151)	RS1/16S750J
	C 1102(A,158,205)	CCSRCH101J50	R 1208(B,63,151)	RS1/16S750J
	C 1103(A,160,200)	CCSRCH101J50	R 1209(B,47,148)	RS1/16S750J
	C 1104(A,158,200)	CCSRCH101J50	R 1210(B,49,148)	RS1/16S750J
K			R 1211(B,103,149)	RS1/16S750J
			R 1212(B,105,149)	RS1/16S750J
			R 1213(B,75,149)	RS1/16S750J
			R 1214(B,77,149)	RS1/16S750J
			R 1215(B,123,134)	RS1/16S331J

Mark No.**Description**

R 1216(B,125,134)
 R 1217(B,141,134)
 R 1218(B,144,129)
 R 1223(B,137,115)
 R 1224(B,138,106)

R 1225(A,59,132)
 R 1226(A,63,132)
 R 1227(A,65,132)
 R 1228(A,87,131)
 R 1229(A,68,132)

R 1230(A,87,133)
 R 1231(B,80,137)
 R 1232(A,72,130)
 R 1235(A,155,111)
 R 1236(B,167,108)

R 1237(B,130,115)
 R 1238(B,130,106)
 R 1243(A,145,119)
 R 1244(B,157,102)
 R 1310(A,175,147)

CAPACITORS

C 1201(B,133,148)
 C 1202(B,119,148)
 C 1203(B,91,148)
 C 1204(B,63,148)
 C 1205(B,49,151)

C 1206(B,47,151)
 C 1207(B,105,152)
 C 1208(B,103,152)
 C 1209(B,77,152)
 C 1210(B,75,152)

C 1211(A,111,134)
 C 1212(A,119,132)
 C 1213(A,99,134)
 C 1214(A,107,131)
 C 1215(A,115,115)

C 1216(A,108,121)
 C 1217(A,132,141) ELECT. CAPACITOR
 C 1218(A,138,135)
 C 1219(A,138,128)
 C 1221(A,125,115)

C 1222(A,125,106)
 C 1223(A,145,115)
 C 1224(A,145,106)
 C 1225(B,132,110)
 C 1226(B,140,110)

C 1227(A,47,118)
 C 1228(B,57,129)
 C 1229(A,55,118)
 C 1230(A,87,130)
 C 1231(A,62,118)

C 1232(A,87,135)
 C 1233(B,59,142)
 C 1234(B,59,134)
 C 1235(A,53,143)
 C 1236(A,53,136)

Part No.

RS1/16S224J
 RS1/16S472J
 RS1/16S223J
 RS1/16S102J
 RS1/16S102J

RS1/16S103J
 RS1/16S103J
 RS1/16S103J
 RS1/16S103J
 RS1/16S103J

RS1/16S103J
 RS1/16S473J
 RS1/16S473J
 RS1/16S561J
 RS1/16S561J

RS1/16S103J
 RS1/16S103J
 RS1/16S102J
 RS1/16S102J
 RS1/16S103J

CKSRYB104K16
 CKSRYB104K16
 CKSRYB104K16
 CKSRYB104K16
 CCSRCH181J50

CCSRCH181J50
 CCSRCH181J50
 CCSRCH181J50
 CCSRCH181J50
 CCSRCH181J50

CKSRYB104K16
 CKSRYB104K16
 CKSRYB104K16
 CKSRYB104K16
 CKSRYB104K16

CKSRYB104K16
 CEAT3R3M50
 CEAT101M10
 CEAT101M10
 CEAT101M10

CEAT101M10
 CEAT101M10
 CEAT101M10
 CKSRYB103K50
 CKSRYB103K50

CEAT101M10
 CKSRYB104K16
 CEAT101M10
 CKSRYB104K16
 CEAT101M10

CKSRYB104K16
 CKSRYB104K16
 CKSRYB104K16
 CEAT101M16
 CEAT101M16

Mark No.**Description**

C 1243(A,155,113)
 C 1244(B,167,109)
 C 1245(A,152,112)
 C 1246(B,158,108)
 C 1249(A,155,107)

C 1250(B,162,111)
 C 1292(B,73,158)
 C 1293(B,93,158)
 C 1294(B,129,158)
 C 1301(A,158,138)

C 1302(A,153,141)

J BRIDGE 2 ASSY**MISCELLANEOUS**

CN2901(A,21,29) 17P PLUG
 CN2902(A,100,29) 17P PLUG

CCSRCRCH120J50
 CCSRCH120J50
 CCSRCH330J50
 CCSRCH330J50
 CCSRCJ3R0C50

A

K COMPONENT ASSY
MISCELLANEOUS

IC 1401(A,113,70) MULTIPLEXER (4CHx2)
 IC 1402(A,124,72) MULTIPLEXER (4CHx2)
 IC 1403(A,139,69) MULTIPLEXER (2CHx3)
 IC 1404(B,93,70) VIDEO IC
 IC 1405(A,129,50) LOGIC IC

TC74LVX4052FT
 TC74LVX4052FT
 TC74LVX4053FT
 NJM2581M
 CD4094BPW

C

Q 1401(B,87,57) TRANSISTOR
 Q 1402(B,71,57) TRANSISTOR
 Q 1403(B,163,64) TRANSISTOR
 Q 1405(B,163,69) TRANSISTOR
 Q 1407(B,163,74) TRANSISTOR

2SC4081
 2SA1576A
 2SA1576A
 2SA1576A
 2SA1576A

D

Q 1415(B,156,59) TRANSISTOR
 Q 1416(B,162,50) TRANSISTOR
 Q 1417(B,167,42) TRANSISTOR
 Q 1501(A,62,65) TRANSISTOR
 Q 1502(A,68,65) TRANSISTOR

2SC4081
 2SC4081
 2SC4081
 IMX25
 IMX25

Q 1521(A,49,65) TRANSISTOR
 Q 1522(A,55,65) TRANSISTOR
 Q 1541(A,36,65) TRANSISTOR
 Q 1542(A,42,65) TRANSISTOR
 Q 1561(A,22,65) TRANSISTOR

IMX25
 IMX25
 IMX25
 IMX25
 IMX25

E

Q 1562(A,29,65) TRANSISTOR
 D 1401(B,85,43) DIODE
 D 1402(B,83,43) DIODE
 L 1401(B,166,58) CHIP COIL
 L 1402(B,169,53) CHIP COIL

IMX25
 1SS355
 1SS355
 LCTAW120J2520
 LCTAW120J2520

L 1403(B,175,49) CHIP COIL
 JA1401(A,141,94) 6P RCA PIN JACK
 JA1402(A,99,94) 6P RCA PIN JACK
 CN1401(A,175,56) 13P SOCKET
 CN1402(A,175,30) 11P SOCKET

LCTAW120J2520
 XKB3053
 XKB3053
 XKP3077
 XKP3076

CN1403(A,68,39) 13P SOCKET
 CN1405(A,19,59) 17P SOCKET
 CN1406(A,53,41) CONNECTOR
 CN1501(A,58,94) PIN JACK (4P)
 CN1502(A,30,94) PIN JACK (4P)

XKP3077
 XKP3079
 CKS3384
 AKB7172
 AKB7172

1401(A,166,28) PCB BINDER

VEF1040

F

Mark No. **Description**
Part No.
Mark No. **Description**
Part No.
RESISTORS

R 1401(B,149,85)
R 1402(B,138,85)
A R 1403(B,124,85)
R 1404(B,157,85)
R 1405(B,145,85)

R 1406(B,131,85)
R 1407(B,115,85)
R 1408(B,103,85)
R 1409(B,89,85)
R 1410(B,107,78)

R 1411(B,93,78)
R 1412(B,83,79)
B R 1416(B,91,61)
R 1417(B,85,57)
R 1418(B,75,56)

R 1419(B,82,58)
R 1420(B,78,58)
R 1421(B,159,64)
R 1422(B,159,69)
R 1423(B,159,74)

R 1424(B,169,59)
R 1425(B,171,54)
R 1426(B,173,53)
C R 1430(B,133,54)
R 1431(B,131,54)

R 1432(B,131,50)
R 1433(B,134,46)
R 1434(A,134,46)
R 1439(B,126,49)
R 1440(B,124,49)

R 1441(B,128,48)
R 1442(B,128,45)
R 1443(B,157,64)
R 1444(B,160,64)
D R 1446(B,157,69)

R 1447(B,161,69)
R 1449(B,157,74)
R 1450(B,161,74)
R 1461(B,162,60)
R 1462(B,163,55)

R 1463(B,166,48)
R 1464(B,157,55)
R 1465(B,166,52)
R 1466(B,173,47)
E R 1501(B,62,59)

R 1502(B,68,59)
R 1503(B,62,65)
R 1504(B,68,65)
R 1505(B,62,70)
R 1506(B,68,70)

R 1507(B,63,86)
R 1508(B,67,87)
R 1509(A,62,60)
R 1510(A,68,60)
F R 1511(A,60,69)

R 1512(A,67,69)
R 1521(B,49,59)
R 1522(B,55,59)
R 1523(B,49,65)
R 1524(B,55,65)

R 1525(B,49,70)
R 1526(B,55,70)
R 1527(B,49,86)
R 1528(B,53,87)
R 1529(A,49,60)

R 1530(A,55,60)
R 1531(A,47,69)
R 1532(A,54,69)
R 1541(B,36,59)
R 1542(B,42,59)

R 1543(B,36,65)
R 1544(B,42,65)
R 1545(B,36,70)
R 1546(B,42,70)
R 1547(B,35,86)

R 1548(B,39,87)
R 1549(A,36,60)
R 1550(A,42,60)
R 1551(A,34,69)
R 1552(A,41,69)

R 1561(B,23,61)
R 1562(B,29,61)
R 1563(B,22,65)
R 1564(B,29,65)
R 1565(B,22,70)

R 1566(B,29,70)
R 1567(B,21,86)
R 1568(B,25,87)
R 1569(A,23,60)
R 1570(A,29,60)

R 1571(A,21,69)
R 1572(A,27,69)
R 1573(A,65,46)
R 1574(A,62,46)
R 1575(A,63,44)

R 1576(A,61,43)

CAPACITORS

C 1413(A,118,70)
C 1414(A,107,72)
C 1415(A,131,70)
C 1416(A,117,73)
C 1417(A,143,67)

C 1418(A,135,72)
C 1419(A,101,61)
C 1420(A,95,61)
C 1421(A,97,53)
C 1425(A,83,67)

C 1426(A,83,73)
C 1427(B,86,67)
C 1428(B,86,72)
C 1431(B,82,60)
C 1432(B,78,60)

RS1/16S103J
RS1/16S271J
RS1/16S271J
RS1/16S121J
RS1/16S121J

RS1/16S101J
RS1/16S101J
RS1/16S474J
RS1/16S474J
RS1/16S103J

RS1/16S103J
RS1/16S103J
RS1/16S103J
RS1/16S103J
RS1/16S103J

RS1/16S121J
RS1/16S121J
RS1/16S101J
RS1/16S101J
RS1/16S474J

RS1/16S271J
RS1/16S271J
RS1/16S121J
RS1/16S121J
RS1/16S101J

RS1/16S101J
RS1/16S474J
RS1/16S474J
RS1/16S103J
RS1/16S103J

RS1/16S103J
RS1/16S473J
RS1/16S473J
RS1/16S473J
RS1/16S473J

RS1/16S471J
CKSRYB103K50
CKSRYB103K50
CKSRYB103K50
CKSRYB103K50
CKSRYB103K50

CKSRYB103K50
CEAT101M10
CEAT101M10
CEAT101M10
CEAT101M10

CEAT101M10
CKSRYB104K25
CKSRYB104K25
CKSRYB224K10
CKSRYB224K10

Mark No. **Description**

C 1433(B,153,64)
 C 1434(B,168,64)
 C 1435(B,153,70)
 C 1436(B,168,69)
 C 1437(B,152,76)

C 1438(B,168,73)
 C 1439(A,151,63)
 C 1440(A,151,68)
 C 1441(A,150,74)
 C 1445(A,170,59)

C 1446(A,170,55)
 C 1447(A,172,50)
 C 1448(A,169,59)
 C 1449(A,169,55)
 C 1450(A,170,50)

C 1454(A,170,57)
 C 1455(A,170,52)
 C 1456(A,172,48)
 C 1469(A,130,54)
 C 1471(A,163,58)

C 1472(A,163,53)
 C 1473(A,166,46)
 C 1490(B,147,85)
 C 1491(B,133,85)
 C 1492(B,105,85)

C 1493(B,91,85)
 C 1501(B,63,84)
 C 1502(B,67,85)
 C 1507(B,60,70)
 C 1508(B,66,70)

C 1521(B,49,84)
 C 1522(B,53,85)
 C 1527(B,47,70)
 C 1528(B,53,70)
 C 1531(A,60,78) ELECT. CAPACITOR

C 1532(A,67,78) ELECT. CAPACITOR
 C 1533(A,47,78) ELECT. CAPACITOR
 C 1541(B,35,84)
 C 1542(B,39,85)
 C 1547(A,54,78) ELECT. CAPACITOR

C 1548(A,34,78) ELECT. CAPACITOR
 C 1549(A,41,78) ELECT. CAPACITOR
 C 1550(A,21,78) ELECT. CAPACITOR
 C 1551(A,27,78) ELECT. CAPACITOR
 C 1561(B,21,84)

C 1562(B,25,85)
 C 1567(A,60,46)
 C 1568(A,58,44)
 C 1569(B,34,70)
 C 1570(B,40,70)

C 1571(B,20,70)
 C 1572(B,27,70)
 C 1591(B,58,86)
 C 1593(B,30,86)

COMPLEX ASSY
MISCELLANEOUS

△ Y 14 AWG18 BOARD IN
 △ Y 15 AWG18 BOARD IN

Part No.

CKSRYB103K50
 CKSRYB103K50
 CKSRYB103K50
 CKSRYB103K50
 CKSRYB103K50

CKSRYB103K50
 CEAT100M50
 CEAT100M50
 CEAT100M50
 CCSRCH120J50

CCSRCH120J50
 CCSRCH120J50
 CCSRCH330J50
 CCSRCH330J50
 CCSRCH330J50

CCSRCJ3R0C50
 CCSRCJ3R0C50
 CCSRCJ3R0C50
 CKSRYB104K50
 CEAT100M50

CEAT100M50
 CEAT100M50
 CKSRYB103K50
 CKSRYB103K50
 CKSRYB103K50

CKSRYB103K50
 CCSRCH101J50
 CCSRCH101J50
 CCSRCH271J50
 CCSRCH271J50

CCSRCH101J50
 CCSRCH101J50
 CCSRCH271J50
 CCSRCH271J50
 CEAT470M25

CEAT470M25
 CEAT470M25
 CCSRCH101J50
 CCSRCH101J50
 CEAT470M25

CEAT470M25
 CEAT470M25
 CEAT470M25
 CEAT470M25
 CCSRCH101J50

CCSRCH101J50
 CKSRYB472K50
 CKSRYB472K50
 CCSRCH271J50
 CCSRCH271J50

CCSRCH271J50
 CCSRCH271J50
 CKSRYB103K50
 CKSRYB103K50

ADX7500
 ADX7501

Mark No.
L DISPLAY ASSY
MISCELLANEOUS

IC 2301(B,164,214) DISPLAY U-COM
 IC 2402(A,237,230) REMOTE RECEIVER UNIT
 Q 2401(B,205,185) TRANSISTOR
 Q 2404(B,251,192) TRANSISTOR
 Q 2405(B,231,192) TRANSISTOR

Q 2406(B,225,220) DIGITAL TR (SC-70)
 Q 2407(B,70,220) DIGITAL TR (SC-70)
 Q 2408(B,65,214) DIGITAL TR (SC-70)
 D 2404(B,238,190) DIODE
 D 2405(B,254,195) DIODE

D 2406(B,252,209) DIODE
 D 2408(A,237,220) LED (ORANGE)
 D 2410(A,76,218) LED (RED)
 D 2412(A,58,214) LED (RED)
 D 2416(B,53,227) DIODE

D 2401(A,248,205) RADIAL INDUCTOR
 V 2301(A,218,237) FL TUBE
 X 2301(A,179,197) CERAMIC (5M)
 CN2301(A,269,204) CONNECTOR
 2302(A,48,221) 17P CABLE HOLDER
 2301(A,157,201) FL HOLDER (FE)
 2303(A,267,196) CABLE HOLDER (4P)

RESISTORS

R 2301(B,104,240)
 R 2302(B,106,240)
 R 2303(B,108,240)
 R 2304(B,110,240)
 R 2305(B,112,240)

R 2306(B,114,240)
 R 2307(B,116,240)
 R 2308(B,118,240)
 R 2309(B,120,240)
 R 2310(B,122,240)

R 2311(B,124,240)
 R 2312(B,126,240)
 R 2313(B,128,240)
 R 2314(B,130,240)
 R 2315(B,132,240)

R 2316(B,134,240)
 R 2317(B,136,240)
 R 2318(B,138,240)
 R 2319(B,140,240)
 R 2320(B,142,240)

R 2321(B,144,240)
 R 2322(B,146,240)
 R 2323(B,148,240)
 R 2324(B,150,240)
 R 2325(B,152,240)

R 2326(B,154,240)
 R 2327(B,156,240)
 R 2328(B,158,240)
 R 2329(B,160,240)
 R 2330(B,162,240)

Part No.

PE5503A

RPM7540-H9

RT1N241M

2SA1576A

RT1N241M

1SS355

1SS355

DAN202U

SLI-343DCW(STU)

SLI-343URW(RST)

SLI-343URW(RST)

1SS355

LFCA2R2J

AAV7105

VSS1142

CKS3394

51048-1700

VNF1096

51063-0405

A

B

C

D

E

F

Mark No. **Description**
Part No.
Mark No. **Description**
Part No.

A	R 2331(B,164,240)	RS1/16S104J	R 2422(B,64,219)	RS1/16S331J
	R 2332(B,166,240)	RS1/16S104J	R 2424(B,135,193)	RS1/16S472J
	R 2333(B,168,240)	RS1/16S104J		
	R 2334(B,170,240)	RS1/16S104J		
	R 2335(B,172,240)	RS1/16S104J		
	R 2336(B,174,240)	RS1/16S104J	C 2303(B,221,238)	CCSRCH471J50
	R 2337(B,176,240)	RS1/16S104J	C 2304(A,230,236) ELECT. CAPACITOR	CEAT101M35
	R 2338(B,180,240)	RS1/16S473J	C 2305(B,178,231)	CCSRCH471J50
	R 2339(B,182,240)	RS1/16S473J	C 2306(B,180,231)	CCSRCH471J50
	R 2340(B,184,240)	RS1/16S473J	C 2307(B,182,231)	CCSRCH471J50
B	R 2341(B,186,240)	RS1/16S473J	C 2308(B,183,231)	CCSRCH471J50
	R 2342(B,188,240)	RS1/16S473J	C 2309(B,187,231)	CCSRCH471J50
	R 2343(B,190,240)	RS1/16S473J	C 2310(B,189,231)	CCSRCH471J50
	R 2344(B,192,240)	RS1/16S473J	C 2311(B,190,231)	CCSRCH471J50
	R 2345(B,194,240)	RS1/16S473J	C 2312(B,192,231)	CCSRCH471J50
	R 2346(B,196,240)	RS1/16S473J	C 2313(B,196,231)	CCSRCH471J50
	R 2347(B,198,240)	RS1/16S473J	C 2314(B,197,231)	CCSRCH471J50
	R 2348(B,200,240)	RS1/16S473J	C 2315(B,199,231)	CCSRCH471J50
	R 2349(B,202,240)	RS1/16S473J	C 2316(B,201,231)	CCSRCH471J50
	R 2350(B,204,240)	RS1/16S473J	C 2317(B,204,231)	CCSRCH471J50
C	R 2351(B,206,240)	RS1/16S473J	C 2318(B,206,231)	CCSRCH471J50
	R 2352(B,208,240)	RS1/16S473J	C 2319(B,208,231)	CCSRCH471J50
	R 2353(B,210,240)	RS1/16S473J	C 2320(B,209,231)	CCSRCH471J50
	R 2354(B,198,200)	RS1/16S473J	C 2351(B,180,215)	CKSRYB103K50
	R 2355(B,206,191)	RS1/16S473J	C 2353(B,185,207)	CKSRYB104K25
	R 2356(B,190,207)	RS1/16S473J	C 2354(B,175,202)	CKSRYB104K25
	R 2357(B,193,202)	RS1/16S473J	C 2359(B,142,204)	CKSRYB103K50
	R 2358(B,181,201)	RS1/16S105J	C 2360(A,87,231) ELECT. CAPACITOR	CEQ470M50
	R 2359(B,176,202)	RS1/16S104J	C 2361(B,161,230)	CKSRYB103K50
	R 2361(B,172,197)	RS1/16S221J	C 2362(B,160,230)	CKSRYB103K50
D	R 2362(B,170,194)	RS1/16S221J	C 2403(B,247,195)	CKSRYB103K50
	R 2363(B,169,194)	RS1/16S221J	C 2404(B,237,236)	CKSRYB103K50
	R 2364(B,167,194)	RS1/16S221J	C 2405(A,247,235)	CEQ101M6R3
	R 2366(B,162,198)	RS1/16S104J	C 2406(B,245,209)	CKSRYB103K50
	R 2368(B,126,199)	RS1/16S473J	C 2407(A,229,210)	CEQ221M6R3
	R 2369(B,131,208)	RS1/16S474J		
	R 2370(B,114,207)	RS1/16S221J		
	R 2371(B,136,208)	RS1/16S104J		
	R 2372(B,135,208)	RS1/16S221J		
	R 2373(B,133,208)	RS1/16S101J		
E	R 2374(B,134,212)	RS1/16S221J	S 2451(A,289,207) SWITCH	VSG1024
	R 2375(B,129,208)	RS1/16S104J	S 2452(A,304,207) SWITCH	VSG1024
	R 2377(B,135,204)	RS1/16S474J	S 2453(A,314,207) SWITCH	VSG1024
	R 2378(B,133,204)	RS1/16S104J	S 2454(A,302,174) ROTARY ENCODER	ASX7048
	R 2401(B,262,227)	RS1/16S221J	2451(A,278,202) CABLE HOLDER (4P)	51063-0405
	R 2402(B,260,227)	RS1/16S0R0J		
	R 2403(B,258,225)	RS1/16S0R0J		
	R 2404(B,256,224)	RS1/16S0R0J		
	R 2405(B,254,223)	RS1/16S0R0J		
	R 2406(B,201,185)	RS1/16S473J		
F	R 2411(B,247,191)	RS1/16S0R0J	M VOLUME ASSY	
	R 2412(B,249,192)	RS1/16S104J	MISCELLANEOUS	
	R 2413(B,240,191)	RS1/16S472J		
	R 2414(B,237,196)	RS1/16S0R0J	J 2451 JUMPER WIRE	D15A04-100-2651
	R 2415(B,257,192)	RS1/16S104J	S 2451(A,289,207) SWITCH	VSG1024
	R 2416(B,251,195)	RS1/16S103J	S 2452(A,304,207) SWITCH	VSG1024
	R 2417(B,239,196)	RS1/16S102J	S 2453(A,314,207) SWITCH	VSG1024
	R 2419(B,232,240)	RS1/16S101J	S 2454(A,302,174) ROTARY ENCODER	ASX7048
	R 2420(B,233,220)	RS1/16S331J	2451(A,278,202) CABLE HOLDER (4P)	51063-0405
	R 2421(B,72,225)	RS1/16S331J		
RESISTORS				
R 2451(B,296,206)				
R 2452(B,311,206)				
CAPACITORS				
C 2451(B,281,208)				
C 2452(B,304,186)				
C 2453(B,299,186)				

Mark No. **Description****Part No.****Mark No.** **Description****Part No.****N MULTI JOG ASSY****MISCELLANEOUS**

IC 2501(B,157,111)	LOGIC IC	CD4094BNS
Q 2501(B,162,146)	DIGITAL TR (SC-70)	RT1N431M
Q 2502(B,174,146)	DIGITAL TR (SC-70)	RT1N431M
Q 2503(B,195,146)	DIGITAL TR (SC-70)	RT1N431M
Q 2504(B,217,146)	DIGITAL TR (SC-70)	RT1N431M
Q 2505(B,237,147)	DIGITAL TR (SC-70)	RT1N431M
Q 2506(B,259,146)	DIGITAL TR (SC-70)	RT1N431M
Q 2507(B,280,146)	DIGITAL TR (SC-70)	RT1N431M
Q 2508(B,314,140)	DIGITAL TR (SC-70)	RT1N431M
Q 2509(B,131,147)	DIGITAL TR (SC-70)	RT1N431M
Q 2510(B,22,184)	DIGITAL TR (SC-70)	RT1N431M
Q 2511(B,121,147)	DIGITAL TR (SC-70)	RT1N431M
Q 2512(B,87,146)	DIGITAL TR (SC-70)	RT1N431M
D 2502(A,155,147)	LED (ORANGE)	SLI-343DCW(STU)
D 2504(A,177,147)	LED (ORANGE)	SLI-343DCW(STU)
D 2506(A,198,147)	LED (ORANGE)	SLI-343DCW(STU)
D 2508(A,220,147)	LED (ORANGE)	SLI-343DCW(STU)
D 2510(A,241,147)	LED (ORANGE)	SLI-343DCW(STU)
D 2512(A,263,147)	LED (ORANGE)	SLI-343DCW(STU)
D 2514(A,284,147)	LED (ORANGE)	SLI-343DCW(STU)
D 2516(A,306,147)	LED (ORANGE)	SLI-343DCW(STU)
D 2518(A,134,147)	LED (ORANGE)	SLI-343DCW(STU)
D 2520(A,16,186)	LED (BLUE)	SLR-343BBT(HJKL)
D 2522(A,112,147)	LED (ORANGE)	SLI-343DCW(STU)
D 2524(A,91,147)	LED (ORANGE)	SLI-343DCW(STU)
J 2501	JUMPER WIRE	D20PDD1715E
S 2501(A,36,119)	ROTARY ENCODER	ASX7031
S 2551(A,154,141)	SWITCH	VSG1024
S 2552(A,181,141)	SWITCH	VSG1024
S 2553(A,202,141)	SWITCH	VSG1024
S 2554(A,224,141)	SWITCH	VSG1024
S 2555(A,245,141)	SWITCH	VSG1024
S 2556(A,267,141)	SWITCH	VSG1024
S 2557(A,288,141)	SWITCH	VSG1024
S 2558(A,310,141)	SWITCH	VSG1024
S 2561(A,74,117)	SWITCH	VSG1024
S 2562(A,106,91)	SWITCH	VSG1024
S 2563(A,120,91)	SWITCH	VSG1024
S 2564(A,135,91)	SWITCH	VSG1024
S 2565(A,150,91)	SWITCH	VSG1024
S 2566(A,165,91)	SWITCH	VSG1024
S 2567(A,179,91)	SWITCH	VSG1024
S 2571(A,15,179)	SWITCH	VSG1024
S 2572(A,18,142)	SWITCH	VSG1024
S 2573(A,33,142)	SWITCH	VSG1024
S 2574(A,48,142)	SWITCH	VSG1024
S 2575(A,90,141)	SWITCH	VSG1024
S 2576(A,116,141)	SWITCH	VSG1024
S 2577(A,138,141)	SWITCH	VSG1024
2501(A,41,205)	17P CABLE HOLDER	51048-1700

RESISTORS

R 2501(B,151,152)		RS1/16S331J
R 2502(B,184,152)		RS1/16S331J
R 2503(B,194,152)		RS1/16S331J
R 2504(B,216,152)		RS1/16S331J
R 2505(B,237,152)		RS1/16S331J

Part No.**Mark No.** **Description****Part No.**

R 2506(B,259,152)
R 2507(B,280,152)
R 2508(B,302,152)
R 2509(B,142,152)
R 2510(B,9,186)

R 2511(B,119,152)
R 2512(B,87,151)
R 2513(B,160,103)
R 2514(B,149,141)
R 2515(B,173,141)

R 2516(B,194,141)
R 2517(B,216,141)
R 2518(B,237,141)
R 2519(B,258,141)
R 2520(B,280,141)

R 2521(B,301,142)
R 2522(B,77,113)
R 2523(B,106,98)
R 2524(B,117,90)
R 2525(B,132,90)

R 2526(B,145,90)
R 2527(B,160,90)
R 2528(B,175,90)
R 2529(B,12,181)
R 2530(B,18,146)

R 2531(B,30,142)
R 2532(B,45,142)
R 2533(B,87,141)
R 2534(B,106,143)
R 2535(B,130,141)

R 2536(B,18,181)

CKSRYB103K50
CKSRYB103K50
CKSRYB103K50
CKSRYB102K50
CKSRYB102K50
CKSRYB102K50

CAPACITORS

C 2501(B,148,108)
C 2502(B,36,129)
C 2503(B,33,129)
C 2511(B,151,141)
C 2561(B,79,113)

C 2571(B,18,181)

CKSRYB102K50

O HEADPHONE ASSY
MISCELLANEOUS

KN2851(A,13,54) WRAPPING TERMINAL VNF1084
CN2851(A,19,70) 4P JUMPER CONNECTOR 52147-0410
2851(A,15,14) PHONE JACK AKN7029

RESISTORS

R 2851(B,20,26)
R 2852(B,16,27)

RS1/16S102J
RS1/16S0R0J

CAPACITORS

C 2851(B,19,42)
C 2852(B,11,29)
C 2853(B,10,40)
C 2854(B,13,43)
C 2855(B,13,45)

CKSRYB392K50
CKSRYB392K50
CCSRCH471J50
CKSRYB103K50
CKSRYB104K16

Mark No. **Description**
Part No.
Mark No. **Description**
Part No.
P FRONT-IN ASSY
MISCELLANEOUS

A	IC 2701(B,36,55) OP-AMP IC Q 2651(B,116,47) CHIP TRANSISTOR D 2701(B,29,62) DIODE D 2702(B,33,32) DIODE D 2703(B,31,29) DIODE	BA4560RF HN1C01FU DAN217 UDZS5R1(B) UDZS5R1(B)
	D 2704(B,28,46) DIODE L 2653(B,117,59) INDUCTOR L 2671(B,143,58) INDUCTOR L 2681(B,92,65) CHIP SOLID INDUCTOR L 2752(B,68,60) CHIP FERRITE BEADS	UDZS5R1(B) CTF1385 CTF1385 QTL1013 VTL1169
B	L 2753(B,72,55) CHIP FERRITE BEADS JA 2651(A,109,69) PIN JACK (4P) JA 2652(A,88,77) OPTICAL IN MODULE JA 2701(A,45,73) JACK JA 2751(A,65,76) USB CONNECTOR	VTL1169 XKX3003 GP1FM513RZ RKN1004 XKP3086
	KN2651(A,156,42) WRAPPING TERMINAL KN3351(A,44,37) WRAPPING TERMINAL CN2651(A,40,28) CONNECTOR CN2652(A,67,42) CONNECTOR	VNF1084 VNF1084 CKS3382 B4B-PH

RESISTORS

C	R 2651(B,121,58) R 2652(B,107,57) R 2653(B,128,58) R 2654(B,111,56) R 2655(B,128,54)	RS1/16S0R0J RS1/16S0R0J RS1/16S104J RS1/16S104J RS1/16S221J	C 2701(B,42,69) C 2702(A,36,66) C 2703(B,32,62) C 2704(B,36,62) C 2705(B,32,48)	CCSRCH471J50 CEAT100M50 CCSRCH101J50 CCSRCH330J50 CCSRCH330J50
D	R 2656(B,107,52) R 2657(B,124,54) R 2658(B,113,56) R 2659(B,122,46) R 2660(B,113,51)	RS1/16S221J RS1/16S104J RS1/16S104J RS1/16S221J RS1/16S221J	C 2706(A,34,36) C 2707(B,48,43) C 2709(B,52,43) C 2712(A,35,44) C 2713(B,40,57)	CEAT100M50 CKSRYB103K50 CKSRYB223K50 CEAT100M50 CKSRYB103K50
E	R 2661(B,118,46) R 2662(B,113,43) R 2663(B,120,46) R 2664(B,112,48) R 2665(B,100,46)	RS1/16S153J RS1/16S153J RS1/16S101J RS1/16S101J RS1/16S470J	C 2714(B,40,53) C 2715(A,49,59) C 2716(A,49,53) C 2718(B,40,38) C 2719(B,40,36)	CKSRYB103K50 CEAT100M50 CEAT100M50 CKSRYB102K50 CCSRCH221J50
F	R 2666(B,100,39) R 2668(B,131,57) R 2671(B,141,62) R 2672(B,145,62) R 2673(B,152,59)	RS1/16S470J RS1/16S0R0J RS1/16S750J RS1/16S0R0J RS1/16S750J	C 2753(B,68,56) C 2755(A,68,51) C 2756(B,73,51) C 2757(B,73,46)	CKSRYB104K16 CEAT101M16 CKSRYB104K16 CCSRCH471J50
	R 2674(B,150,64) R 2675(B,152,55) R 2676(B,148,58) R 2681(B,85,65) R 2701(B,41,65)	RS1/16S750J RS1/16S0R0J RS1/16S0R0J RS1/16S101J RS1/16S102J		
	R 2702(B,38,68) R 2703(B,40,69) R 2704(B,30,66) R 2705(B,34,62) R 2706(B,30,57)	RS1/16S682J RS1/16S104J RS1/16S101J RS1/16S104J RS1/16S472J	△ IC 2001(A,305,99) REGULATOR IC Q 2001(B,281,60) DIGITAL TR (SC-70) D 2001(B,276,60) DIODE D 2002(B,276,65) DIODE △ D 2003(B,296,87) BRIDGE DIODE	NJM78M56FA RT1N431M 1SS355 1SS355 S1WB(A)60SD
	R 2707(B,38,62) R 2708(B,41,61) R 2709(B,30,48) R 2710(B,34,48) R 2711(B,36,48)	RS1/16S333J RS1/16S101J RS1/16S472J RS1/16S333J RS1/16S101J	D 2004(B,304,75) DIODE D 2006(B,308,70) DIODE △ L 2001(A,244,24) LINE FILTER H 2001(A,243,46) FUSE CLIP H 2002(A,223,46) FUSE CLIP	1SS355 UDZS5R1(B) XTF3004 AKR7001 AKR7001

Q PRIMARY ASSY
MISCELLANEOUS

△ IC 2001(A,305,99) REGULATOR IC Q 2001(B,281,60) DIGITAL TR (SC-70) D 2001(B,276,60) DIODE D 2002(B,276,65) DIODE △ D 2003(B,296,87) BRIDGE DIODE	NJM78M56FA RT1N431M 1SS355 1SS355 S1WB(A)60SD
D 2004(B,304,75) DIODE D 2006(B,308,70) DIODE △ L 2001(A,244,24) LINE FILTER H 2001(A,243,46) FUSE CLIP H 2002(A,223,46) FUSE CLIP	1SS355 UDZS5R1(B) XTF3004 AKR7001 AKR7001

Mark No.**Description****Part No.**

KN2001(A,194,19)	SCREW PLATE	VNE1948
▲RY2001(A,251,58)	JOE LOW POWER RELAY	ASR7013
▲T 2001(A,273,84)	STANDBY TRANSFORMER	ATT7040
CN2001(A,301,115)	9P SOCKET	KP200TA9L
CN2002(A,246,115)	5P SOCKET	KP200TA5L

▲CN2003(A,225,25) AC CORD SOCKET

RKP1751

RESISTORS

R 2002(A,279,68)	CARBON FILM
R 2003(B,305,70)	
R 2004(B,302,70)	

CAPACITORS

▲C 2002(A,266,26)	FILM (0.01, 275 V)	ACE7013
▲C 2003(A,251,52)	10000P, 250 V	XCG3009
C 2004(A,290,106)	FILM CAPACITOR	CQMBA103J50
C 2009(A,303,88)	ELECT. CAPACITOR	CEAT332M25
C 2010(A,309,106)		CEAT221M25
C 2011(B,310,85)		CKSRYB103K50

R TRANS 1 ASSY

TRANS 1 Assy has no service part.

SECONDARY ASSY**MISCELLANEOUS**

Y 9	AWG18 BOARD IN	ADX7502
Y 10	AWG18 BOARD IN	ADX7503
Y 11	AWG18 BOARD IN	ADX7504
Y 12	AWG18 BOARD IN	ADX7505

S TRANS 2-1 ASSY**MISCELLANEOUS**

▲IC 3251(A,228,215)	PROTECTOR (7A)
▲IC 3252(A,239,164)	PROTECTOR (7A)
Q 3251(B,244,224)	CHIP TRANSISTOR
Q 3252(B,253,224)	TRANSISTOR
Q 3253(B,261,224)	TRANSISTOR
▲D 3251(B,234,181)	BRIDGE DIODE
D 3253(B,236,216)	DIODE
D 3254(B,263,217)	DIODE
D 3255(B,233,216)	DIODE
D 3256(B,263,219)	DIODE
D 3257(B,233,223)	DIODE
D 3258(B,258,218)	DIODE
D 3259(B,238,223)	DIODE
D 3260(B,258,220)	DIODE
D 3261(B,240,220)	DIODE
D 3262(B,253,220)	DIODE
D 3263(B,238,218)	DIODE
D 3264(B,253,218)	DIODE
D 3265(B,257,226)	DIODE
D 3266(B,267,227)	DIODE
J 3251	JUMPER WIRE

3251(A,261,193) 6P CABLE HOLDER

Part No.**Mark No.****Description****Part No.****RESISTORS**

▲R 3253(A,243,192)	METAL OXIDE	RS1LMF472J
▲R 3254(A,263,212)	METAL OXIDE	RS1LMF472J
▲R 3255(A,245,195)	CARBON FILM	RD1/2LMF332J
▲R 3256(A,259,215)	CARBON FILM	RD1/2LMF332J

A

CAPACITORS

C 3253(A,243,186)	ELECT. CAPACITOR	CEAT471M2A
C 3254(A,253,172)	ELECT. CAPACITOR	CEAT471M2A
C 3255(A,240,202)	ELECT. CAPACITOR	CEAT101M63
C 3256(A,240,213)	ELECT. CAPACITOR	CEAT101M63
C 3257(A,269,190)	ELECT. CAPACITOR	CEAT221M2A
C 3258(A,262,201)	ELECT. CAPACITOR	CEAT221M2A

B

T DIODE 1 ASSY**MISCELLANEOUS**

▲D 3301(A,175,164)	DIODE	D5SBA20(B)
▲D 3302(A,175,199)	DIODE	D5SBA20(B)

RESISTORS

▲R 3301(A,194,172)	CARBON FILM	RD1/4MUF100J
--------------------	-------------	--------------

C

CAPACITORS

C 3301(A,191,182)	FILM CAPACITOR	CFTLA104J2A
C 3302(A,196,177)	FILM CAPACITOR	CFTLA104J2A

U VH TR ASSY**MISCELLANEOUS**

▲IC 3351(A,177,136)	IC PROTECTOR	ICP-N15
▲IC 3352(A,177,152)	IC PROTECTOR	ICP-N15
Q 3351(B,172,130)	CHIP TRANSISTOR	2SA1514K
▲Q 3352(A,162,135)	TRANSISTOR	2SB1186A
▲Q 3353(A,162,150)	TRANSISTOR	2SD1763A
Q 3354(B,172,145)	CHIP TRANSISTOR	2SC3906K
▲D 3351(B,173,141)	DIODE	1SR154-400
▲D 3352(B,176,157)	DIODE	1SR154-400
CN3351(A,184,138)	6P JUMPER CONNECTOR	52147-0610

D

RESISTORS

R 3351(B,179,129)		RS1/16S471J
R 3352(B,168,128)		RS1/16S100J
R 3353(B,168,143)		RS1/16S100J
R 3354(B,177,144)		RS1/16S471J

E

V BRIDGE 1 ASSY**MISCELLANEOUS**

CN5811(A,46,130)	23P PLUG	XKP3071
CN5812(A,46,105)	23P PLUG	XKP3071
5811(A,8,101)	PCB BINDER	VEF1040

F

Mark No. **Description****Part No.****Mark No.** **Description****Part No.**** PS/SP ASSY****MISCELLANEOUS**

A	Q 3001(B,161,85) CHIP TRANSISTOR	DTC114TUA	C 3001(A,164,89)	CEAT101M50
	Q 3002(B,229,97) CHIP TRANSISTOR	DTC114TUA	C 3011(A,190,60)	CFTLA104J50
	Q 3003(B,247,90) CHIP TRANSISTOR	DTC114TUA	C 3012(A,203,53)	CFTLA104J50
	Q 3004(B,290,84) CHIP TRANSISTOR	DTC114TUA	C 3013(A,190,42) FILM CAPACITOR	CQMBA103J50
	Q 3005(B,212,99) CHIP TRANSISTOR	DTC114TUA	C 3021(A,157,48)	CFTLA104J50
B	D 3001(B,168,80) DIODE	1SS355	C 3022(A,157,39)	CFTLA104J50
	D 3002(B,165,80) DIODE	1SS355	C 3023(A,169,42) FILM CAPACITOR	CQMBA103J50
	D 3003(B,216,88) DIODE	1SS355	C 3031(A,205,66)	CFTLA104J50
	D 3004(B,213,88) DIODE	1SS355	C 3032(A,200,60)	CFTLA104J50
	D 3005(B,247,82) DIODE	1SS355	C 3033(A,211,42) FILM CAPACITOR	CQMBA103J50
C	D 3006(B,244,82) DIODE	1SS355	C 3041(A,257,63)	CFTLA104J50
	D 3007(B,291,79) DIODE	1SS355	C 3042(A,253,57)	CFTLA104J50
	D 3008(B,289,79) DIODE	1SS355	C 3043(A,253,42) FILM CAPACITOR	CQMBA103J50
	D 3009(B,217,99) DIODE	1SS355	C 3051(A,224,70)	CFTLA104J50
	D 3010(B,215,99) DIODE	1SS355	C 3052(A,230,70)	CFTLA104J50
C	L 3011(A,188,78) COIL	ATH1053	C 3053(A,232,42) FILM CAPACITOR	CQMBA103J50
	L 3021(A,146,69) COIL	ATH1053	C 3061(A,308,58)	CFTLA104J50
	L 3031(A,199,83) COIL	ATH1053	C 3062(A,302,53)	CFTLA104J50
	L 3041(A,258,82) COIL	ATH1053	C 3063(A,295,42) FILM CAPACITOR	CQMBA103J50
	L 3051(A,236,90) COIL	ATH1053	C 3071(A,274,70)	CFTLA104J50
C	L 3061(A,299,74) COIL	ATH1053	C 3072(A,279,65)	CFTLA104J50
	L 3071(A,280,84) COIL	ATH1053	C 3073(A,274,42) FILM CAPACITOR	CQMBA103J50
	J 3009(A,174,89) CONNECTOR ASSY	PF13PG-R07	C 3091(B,181,50)	CKSRYB222K50
	KN3001(A,318,64) WRAPPING TERMINAL	VNF1084	C 3092(B,179,50)	CKSRYB222K50
	RY3001(A,163,81) RELAY	ASR7001	C 3093(B,265,50)	CKSRYB222K50
C	RY3002(A,211,89) RELAY	ASR7001	C 3094(B,263,50)	CKSRYB222K50
	RY3003(A,242,83) RELAY	ASR7001	C 3096(B,318,55)	CKSRYB222K50
	RY3004(A,286,82) RELAY	ASR7001	C 3101(A,212,137)	ACH7255
	RY3005(A,219,103) RELAY	ASR7001	C 3102(A,258,137)	ACH7255
	CN3001(A,190,33) SPEAKER TERMINAL 8-P	AKE7119		
D	CN3002(A,274,33) SPEAKER TERMINAL 6-P	AKE7108		
	CN3007(A,313,90) 5P PLUG	KM200TA5	H 3401(A,120,100) FUSE CLIP	AKR7001
	CN3008(A,313,145) 9P PLUG	KM200TA9	H 3402(A,98,100) FUSE CLIP	AKR7001
	Y 13 AWG14 BOARD IN	ADX7512	H 3403(A,120,87) FUSE CLIP	AKR7001
	Y 8 AWG14 BOARD IN	ADX7512	H 3404(A,98,87) FUSE CLIP	AKR7001
			H 3405(A,120,74) FUSE CLIP	AKR7001
E				
	RESISTORS			
	△ R 3011(A,187,68) METAL OXIDE	RS1/2LMF4R7J	H 3406(A,98,74) FUSE CLIP	AKR7001
	△ R 3012(A,175,64) METAL OXIDE	RS1LMF100J	H 3407(A,119,57) FUSE CLIP	AKR7001
	△ R 3013(A,193,94) METAL OXIDE	RS2LMF331J	H 3408(A,97,57) FUSE CLIP	AKR7001
	△ R 3021(A,148,79) METAL OXIDE	RS1/2LMF4R7J	H 3409(A,120,45) FUSE CLIP	AKR7001
E	△ R 3022(A,152,51) METAL OXIDE	RS1LMF100J	H 3410(A,98,45) FUSE CLIP	AKR7001
	△ R 3023(A,188,97) METAL OXIDE	RS2LMF331J	J 3401(A,132,97) CONNECTOR ASSY	PF12PG-R40
	△ R 3031(A,196,87) METAL OXIDE	RS1/2LMF4R7J		
	△ R 3032(A,194,67) METAL OXIDE	RS1LMF100J		
	△ R 3041(A,254,82) METAL OXIDE	RS1/2LMF4R7J		
E	△ R 3042(A,267,67) METAL OXIDE	RS1LMF100J		
	△ R 3051(A,240,93) METAL OXIDE	RS1/2LMF4R7J		
	△ R 3052(A,237,79) METAL OXIDE	RS1LMF100J		
	△ R 3061(A,309,63) METAL OXIDE	RS1/2LMF4R7J		
	△ R 3062(A,313,73) METAL OXIDE	RS1LMF100J		
F	△ R 3071(A,280,88) METAL OXIDE	RS1/2LMF4R7J		
	△ R 3072(A,268,94) METAL OXIDE	RS1LMF100J		
	R 3101(A,222,115) CARBON FILM	RD1/4MUF473J		
	R 3102(A,252,115) CARBON FILM	RD1/4MUF473J		

Mark No. **Description****CAPACITORS**

C 3001(A,164,89)	CEAT101M50
C 3011(A,190,60)	CFTLA104J50
C 3012(A,203,53)	CFTLA104J50
C 3013(A,190,42) FILM CAPACITOR	CQMBA103J50
C 3021(A,157,48)	CFTLA104J50

C 3022(A,157,39)	CFTLA104J50
C 3023(A,169,42) FILM CAPACITOR	CQMBA103J50
C 3031(A,205,66)	CFTLA104J50
C 3032(A,200,60)	CFTLA104J50
C 3033(A,211,42) FILM CAPACITOR	CQMBA103J50

C 3041(A,257,63)	CFTLA104J50
C 3042(A,253,57)	CFTLA104J50
C 3043(A,253,42) FILM CAPACITOR	CQMBA103J50
C 3051(A,224,70)	CFTLA104J50
C 3052(A,230,70)	CFTLA104J50

C 3053(A,232,42) FILM CAPACITOR	CQMBA103J50
C 3061(A,308,58)	CFTLA104J50
C 3062(A,302,53)	CFTLA104J50
C 3063(A,295,42) FILM CAPACITOR	CQMBA103J50
C 3071(A,274,70)	CFTLA104J50

C 3072(A,279,65)	CFTLA104J50
C 3073(A,274,42) FILM CAPACITOR	CQMBA103J50
C 3091(B,181,50)	CKSRYB222K50
C 3092(B,179,50)	CKSRYB222K50
C 3093(B,265,50)	CKSRYB222K50

C 3094(B,263,50)	CKSRYB222K50
C 3096(B,318,55)	CKSRYB222K50
C 3101(A,212,137)	ACH7255
C 3102(A,258,137)	ACH7255

 TRANS 2-2 ASSY
MISCELLANEOUS

H 3401(A,120,100) FUSE CLIP	AKR7001
H 3402(A,98,100) FUSE CLIP	AKR7001
H 3403(A,120,87) FUSE CLIP	AKR7001
H 3404(A,98,87) FUSE CLIP	AKR7001
H 3405(A,120,74) FUSE CLIP	AKR7001

J 3401(A,132,97) CONNECTOR ASSY	PF12PG-R40
 TRANS SIDE ASSY	
MISCELLANEOUS	

J 3201 JUMPER WIRE	D20PDY0410E
CN3202(A,60,8) CONNECTOR	CKS3382
CN3203(A,319,21) CONNECTOR	B13B-PH
3201(A,84,28) 4P CABLE HOLDER	51048-0400

<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>
-----------------	--------------------	-----------------

Z LOCAL P-SUPPLY ASSY

MISCELLANEOUS

△ IC 3502(A,120,181) PROTECTOR (1.6A)	AEK7012
△ IC 3504(A,80,176) IC	NJM78M05FA
△ IC 3505(A,80,226) REGULATOR IC	NJM78M56FA
△ IC 3506(A,80,201) IC	NJM79M05FA
△ IC 3510(A,111,238) PROTECTOR (1.6A)	AEK7012

Q 3501(B,110,149) TRANSISTOR	UDM2N
△ Q 3502(A,80,151) TRANSISTOR	2SD1763A
Q 3503(B,144,140) DIGITAL TRANSISTOR	DTC124EUA
Q 3504(B,109,230) CHIP TRANSISTOR	RSR015P03
Q 3505(B,115,232) DIGITAL TRANSISTOR	DTC124EUA

△ D 3501(B,120,163) DIODE	1SR154-400
△ D 3502(B,124,163) DIODE	1SR154-400
△ D 3503(B,128,163) DIODE	1SR154-400
D 3504(B,136,146) DIODE	UDZS6R2(B)
D 3505(B,138,146) DIODE	UDZS6R2(B)

D 3506(B,141,146) DIODE	UDZS6R2(B)
D 3507(B,143,146) DIODE	UDZS6R2(B)
D 3508(B,142,180) DIODE	UDZS6R2(B)
△ D 3509(B,108,160) DIODE	1SR154-400
△ D 3510(B,113,160) DIODE	1SR154-400

D 3511(B,112,132) DIODE	UDZS27(B)
D 3512(A,117,196) DIODE	D3SBA20(B)
△ D 3513(B,86,180) CHIP DIODE	RB501V-40
△ D 3514(A,95,181) DIODE	MTZJ6R2(B)
D 3515(B,87,236) CHIP DIODE	RB501V-40

D 3516(B,87,204) CHIP DIODE	RB501V-40
D 3529(B,80,196) DIODE	1SS355
J 3502 9P JUMPER WIRE	D20PDY0915E
J 3503(A,152,132) CONNECTOR ASSY	PF05PG-Q15
J 3504(A,160,239) CONNECTOR ASSY	PF10PG-R07
J 3505(A,138,232) CONNECTOR ASSY	PF09PG-R37
J 3506 JUMPER WIRE	D20PDY0410E
CN3501(A,141,151) CONNECTOR	B12B-PH
3502(A,149,215) 9P CABLE HOLDER	51048-0900
3506(A,150,167) 4P CABLE HOLDER	51048-0400

RESISTORS

R 3501(B,120,152)	RS1/16S473J
△ R 3503(A,127,156) CARBON FILM	RD1/4MUF391J
R 3504(B,111,142)	RS1/16S472J
R 3505(B,108,142)	RS1/16S101J
R 3506(B,140,139)	RS1/16S222J
△ R 3508(A,134,181) CARBON FILM	RD1/4MUF4R7J
R 3511(B,106,235)	RS1/16S103J
R 3512(B,113,235)	RS1/16S101J

CAPACITORS

C 3501(A,150,148) FILM CAPACITOR	COMBA104J50
C 3502(A,122,168) ELECT. CAPACITOR	CEANP101M35
C 3503(A,118,157) ELECT. CAPACITOR	CEAT101M35
C 3504(A,123,147)	CEAT221M35
C 3505(A,139,179)	CEAT101M16
C 3506(A,133,145)	CEAT470M50
C 3508(B,122,152)	CKSRYB103K50
C 3510(A,110,171) ELECT. CAPACITOR	CEANP102M16
C 3511(A,107,154) ELECT. CAPACITOR	CEAT102M35
C 3512(A,109,135)	CEAT100M50

<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>
-----------------	--------------------	-----------------

C 3513(B,83,149)	CKSRYB102K50
C 3514(A,145,136)	CEAT100M50
C 3515(A,137,140)	CEANP470M25
C 3516(A,122,187)	CQMBA104J50
C 3517(B,83,175)	CKSRYB103K50
C 3518(A,85,189)	CEAT221M16
C 3519(A,117,208)	CEAT682M16
C 3520(A,134,208)	CEAT222M16
C 3521(B,83,224)	CKSRYB103K50
C 3522(B,87,201)	CKSRYB103K50
C 3523(A,88,227)	CEAT101M16
C 3524(A,85,214)	CEAT101M16

AA DC/DC ASSY

MISCELLANEOUS

△ IC 651 (A,43,196) REGULATOR IC	PQ1CG3032FZ
Q 651 (A,65,206) TRANSISTOR	2SD1858X
△ D 651 (B,45,207) DIODE	RB051L-40
△ D 652 (B,66,211) DIODE	UDZS7R5(B)
△ D 653 (A,38,152) DIODE	D3SBA20(B)
△ D 654 (A,68,231) DIODE	MTZJ6R2(B)
L 651 (A,50,212) INDUCTOR	ATH7020
KN651 (A,40,181) SCREW PLATE	VNE1948
CN651 (A,70,221) 3P TOP POST	B3B-EH
CN652 (A,70,166) 4P JUMPER CONNECTOR	52147-0410
651 (A,52,146) PCB BINDER	VEF1040

RESISTORS

△ R 651 (A,64,164) CARBON FILM	RD1/4MUF4R7J
R 652 (B,39,194) CHIP METAL FILM R	RN1/16SE1800D
R 653 (B,38,195)	RN1/16SE3001D
R 654 (B,41,192)	RN1/16SE1001D
R 655 (B,64,210)	RS1/16S302J
R 656 (B,62,210)	RS1/16S101J
C 659 (A,69,206)	CEAT101M16

CAPACITORS

C 651 (A,68,150) FILM CAPACITOR	CQMBA104J50
C 654 (A,59,176) ELECT. CAPACITOR	CEAT103M16
C 655 (A,67,189) ELECT. CAPACITOR	CEHAZL102M16
C 657 (A,55,226) ELECT. CAPACITOR	CEHAZL102M6R3
C 658 (A,67,214)	CEAT101M16

AB IR I/O ASSY

MISCELLANEOUS

Q 3751(B,34,66) TRANSISTOR	2SD1664
D 3752(B,41,60) DIODE	UDZS10(B)
KN3751(A,40,91) SCREW PLATE	VNE1948
CN3701(A,58,46) 10P CONNECTOR	VKN1241
CN3702(A,74,44) 23P SOCKET	XKP3082
CN3703(A,28,43) CONNECTOR	CKS3376

RESISTORS

R 3703(B,25,84)	RS1/16S0R0J
R 3752(A,38,66) CARBON FILM RESISTOR	RD1/4MUF391J
R 3755(B,48,62)	RS1/16S0R0J

Mark No.	Description	Part No.	Mark No.	Description	Part No.
-----------------	--------------------	-----------------	-----------------	--------------------	-----------------

CAPACITORS

A	C 3701(B,49,81)	CKSRYB104K50	D 5001(B,190,188)	CHIP ZENER DIODE	UDZS3R6(B)
	C 3702(B,27,84)	CCSRCH471J50	D 5002(B,188,188)	DIODE	1SS355
	C 3752(A,38,61)	CEAT101M16	D 5003(B,180,184)	DIODE	1SS355
	C 3753(B,26,71)	CKSRYB103K50	D 5004(B,172,184)	DIODE	1SS355
	C 3754(B,24,71)	CKSRYB104K50	D 5005(B,177,184)	DIODE	UDZS4R7(B)
	C 3755(B,28,71)	CKSRYB105K10	D 5006(B,175,184)	DIODE	UDZS4R7(B)
	C 3756(B,67,56)	CKSRYB103K50	D 5041(B,149,174)	DIODE	1SS355
	C 3757(B,71,58)	CCSRCH471J50	D 5042(B,151,174)	DIODE	1SS355
			D 5043(B,151,203)	DIODE	1SS355
			D 5044(B,154,171)	DIODE	1SS355

AC VIDEO CONNECT ASSY**MISCELLANEOUS**

B	CN3801(A,288,240) CONNECTOR POST	S9B-PH	D 5101(B,137,188)	CHIP ZENER DIODE	UDZS3R6(B)
	CN3802(A,298,175) 21P PLUG	XKP3070	D 5102(B,135,188)	DIODE	1SS355
	CN3803(A,305,198) 15P PLUG	XKP3067	D 5103(B,126,184)	DIODE	1SS355
	CN3804(A,308,222) 13P PLUG	XKP3066	D 5104(B,119,184)	DIODE	1SS355

POWER AMP ASSY**MISCELLANEOUS**

C	J 3 JUMPER WIRE	D20PDY0525E	D 5201(B,279,187)	CHIP ZENER DIODE	UDZS3R6(B)
	Y 5 LEAD WITH HOUSING	ADX7404	D 5202(B,276,187)	DIODE	1SS355
	Y 4 LEAD WITH HOUSING	ADX7460	D 5203(B,268,183)	DIODE	1SS355
	Y 3 LEAD WITH HOUSING	ADX7458	D 5204(B,261,183)	DIODE	1SS355
	Y 2 LEAD WITH HOUSING	ADX7457	D 5205(B,266,183)	DIODE	UDZS4R7(B)
	Y 1 LEAD WITH HOUSING	ADX7459	D 5206(B,263,183)	DIODE	UDZS4R7(B)
	Y 6 LEAD WITH HOUSING	ADX7498	D 5241(B,238,173)	DIODE	1SS355

AD POWER AMP-L ASSY**MISCELLANEOUS**

D	△ IC 5001(A,174,135) DARLINGTON POWER IC	SAP17N(OY)	CN5001(A,319,200) 13P SOCKET	XKP3077
	△ IC 5002(A,208,135) DARLINGTON POWER IC	SAP17P(OY)	CN5002(A,85,214) 11P SOCKET	XKP3076
	△ IC 5101(A,106,135) DARLINGTON POWER IC	SAP17N(OY)	CN5003(A,312,191) PLUG 6-P	KM250NA6L
	△ IC 5102(A,140,135) DARLINGTON POWER IC	SAP17P(OY)	CN5004(A,176,224) CONNECTOR POST	B2B-PH
	△ IC 5201(A,242,135) DARLINGTON POWER IC	SAP17N(OY)	5001(A,160,225) PCB BINDER	VEF1040

RESISTORS

E	△ IC 5202(A,276,135) DARLINGTON POWER IC	SAP17P(OY)	R 5001(B,192,202)	RS1/16S102J
	△ IC 5601(A,310,135) DARLINGTON POWER IC	SAP17N(OY)	R 5002(B,180,202)	RS1/16S221J
	Q 5001(B,186,207) CHIP TRANSISTOR	2SD2704K	R 5003(B,177,203)	RS1/16S333J
	Q 5002(B,174,194) TRANSISTOR	IMT4	R 5004(B,192,205)	RS1/16S103J
	Q 5003(B,188,198) CHIP TRANSISTOR	2SA1514K	R 5005(B,170,191)	RS1/16S152J
	Q 5004(A,185,184) TRANSISTOR	2SA1145	R 5006(B,168,198)	RS1/16S821J
	Q 5005(A,161,191) TRANSISTOR	2SC2705	R 5007(B,191,197)	RS1/16S2001F
	Q 5041(B,149,195) CHIP TR	2SA1255	R 5008(B,179,194)	RS1/16S682J
	Q 5101(B,132,207) CHIP TRANSISTOR	2SD2704K	R 5009(A,183,193) CARBON FILM	RD1/2VM473J
	Q 5102(B,120,194) TRANSISTOR	IMT4	R 5010(B,190,183)	RS1/16S151J
F	Q 5103(B,134,198) CHIP TRANSISTOR	2SA1514K	R 5011(B,188,184)	RN1/16SE1201D
	Q 5104(A,131,184) TRANSISTOR	2SA1145	R 5012(B,162,195)	RS1/16S221J
	Q 5105(A,108,191) TRANSISTOR	2SC2705	R 5013(B,183,150) CHIP RESISTOR	RS1/16S62R0F
	Q 5141(B,91,201) CHIP TR	2SA1255	R 5021(B,176,153)	RS1/16S101J
	Q 5201(B,274,206) CHIP TRANSISTOR	2SD2704K	R 5022(B,190,153)	RS1/16S101J
	Q 5202(B,262,193) TRANSISTOR	IMT4	△ R 5023(A,196,166) CARBON FILM	RD1/4MUF4R7J
	Q 5203(B,276,197) CHIP TRANSISTOR	2SA1514K	△ R 5024(A,162,176) CARBON FILM	RD1/4MUF4R7J
	Q 5204(A,273,183) TRANSISTOR	2SA1145	△ R 5025(B,163,156) CHIP (0.047, 0.5 W)	ACN7132
	Q 5205(A,250,191) TRANSISTOR	2SC2705	△ R 5026(B,200,156) CHIP (0.047, 0.5 W)	ACN7132
	Q 5241(B,238,197) CHIP TR	2SA1255	△ R 5027(A,190,166) RESISTOR (0.18, 5 W)	ACN7121

Mark No.	Description	Part No.	Mark No.	Description	Part No.
R 5029(B,167,203)		RN1/10SE3302D	R 5213(B,257,149)	CHIP RESISTOR	RS1/16S62R0F
R 5030(B,173,203)		RN1/16SE1001D	R 5221(B,251,153)		RS1/16S101J
R 5031(B,173,205)		RN1/16SE1500D	R 5222(B,265,153)		RS1/16S101J
R 5032(B,160,195)		RS1/16S151J	▲ R 5223(A,280,164)	CARBON FILM	RD1/4MUF4R7J
R 5041(B,147,169)		RS1/16S473J	▲ R 5224(A,249,175)	CARBON FILM	RD1/4MUF4R7J
R 5042(B,149,169)		RS1/16S223J	▲ R 5225(B,238,156)	CHIP (0.047, 0.5 W)	A ACN7132
R 5043(B,145,169)		RS1/16S471J	▲ R 5226(B,276,156)	CHIP (0.047, 0.5 W)	ACN7132
R 5044(B,151,169)		RS1/16S471J	▲ R 5227(A,274,165)	RESISTOR (0.18, 5 W)	ACN7121
R 5045(B,151,179)		RS1/16S472J	R 5229(B,255,202)		RN1/10SE3302D
R 5046(B,154,179)		RS1/16S472J	R 5230(B,261,202)		RN1/16SE1001D
R 5047(B,150,187)		RS1/16S122J	R 5231(B,261,204)		RN1/16SE1500D
R 5048(B,151,183)		RS1/16S154J	R 5232(B,248,195)		RS1/16S151J
R 5049(B,154,183)		RS1/16S103J	R 5241(B,237,169)		RS1/16S473J
R 5050(B,152,187)		RS1/16S103J	R 5242(B,239,169)		RS1/16S223J
R 5101(B,139,202)		RS1/16S102J	R 5243(B,235,169)		RS1/16S471J
R 5102(B,126,202)		RS1/16S221J	R 5244(B,241,169)		B RS1/16S471J
R 5103(B,123,203)		RS1/16S333J	R 5245(B,240,180)		RS1/16S472J
R 5104(B,139,205)		RS1/16S103J	R 5246(B,242,180)		RS1/16S472J
R 5105(B,116,191)		RS1/16S152J	R 5247(B,240,189)		RS1/16S122J
R 5106(B,115,198)		RS1/16S821J	R 5248(B,237,180)		RS1/16S154J
R 5107(B,138,197)		RS1/16S2001F	R 5249(B,242,184)		RS1/16S103J
R 5108(B,126,194)		RS1/16S682J	R 5250(B,240,184)		RS1/16S103J
R 5109(A,130,193)	CARBON FILM	RD1/2VM473J	▲ R 5292(B,300,156)	CHIP (0.047, 0.5 W)	ACN7132
R 5110(B,137,183)		RS1/16S151J	R 5613(B,317,154)	CHIP RESISTOR	RS1/16S62R0F
R 5111(B,135,184)		RN1/16SE1201D	R 5621(B,312,154)		RS1/16S101J
R 5112(B,109,195)		RS1/16S221J	CAPACITORS		
R 5113(B,115,150)	CHIP RESISTOR	RS1/16S62R0F	C 5001(A,183,203)	CEAT4R7M50	
R 5121(B,108,153)		RS1/16S101J	C 5002(B,177,200)	CCSRCH221J50	
R 5122(B,129,150)		RS1/16S101J	C 5004(B,167,194)	CKSRYB102K50	
▲ R 5123(A,138,166)	CARBON FILM	RD1/4MUF4R7J	C 5007(A,195,193)	CEAT101M10	
▲ R 5124(A,108,176)	CARBON FILM	RD1/4MUF4R7J	C 5008(B,164,195)	ACG7057	
▲ R 5125(B,99,156)	CHIP (0.047, 0.5 W)	ACN7132	C 5009(A,179,189)	CEAT100M2A	
▲ R 5126(B,136,156)	CHIP (0.047, 0.5 W)	ACN7132	C 5011(B,169,142)	ACG7056	
▲ R 5127(A,132,166)	RESISTOR (0.18, 5 W)	ACN7121	C 5012(B,197,142)	ACG7056	
R 5129(B,113,203)		RN1/10SE3302D	C 5015(B,168,205)	CCSRCH220J50	
R 5130(B,119,203)		RN1/16SE1001D	C 5016(B,168,207)	CCSRCH220J50	
R 5131(B,119,205)		RN1/16SE1500D	D		
R 5132(B,106,195)		RS1/16S151J	C 5017(A,172,207)	CEAT331M10	
R 5141(B,93,184)		RS1/16S473J	C 5023(A,190,180)	CEAT100M63	
R 5142(B,95,184)		RS1/16S223J	C 5024(A,166,184)	CEAT100M63	
R 5143(B,91,184)		RS1/16S471J	C 5032(B,162,199)	CKSRYB224K16	
R 5144(B,97,184)		RS1/16S471J	C 5041(A,147,190)	CEANP2R2M50	
R 5145(B,93,193)		RS1/16S472J	E		
R 5146(B,96,193)		RS1/16S472J	C 5051(A,217,183)	CEAT100M2A	
R 5147(B,89,196)		RS1/16S122J	C 5052(A,222,177)	CEAT100M2A	
R 5148(B,95,197)		RS1/16S154J	C 5101(A,129,203)	CEAT4R7M50	
R 5149(B,97,197)		RS1/16S103J	C 5102(B,123,200)	CCSRCH221J50	
R 5150(B,97,202)		RS1/16S103J	C 5104(B,113,194)	CKSRYB102K50	
R 5201(B,281,201)		RS1/16S102J	F		
R 5202(B,268,201)		RS1/16S221J	C 5107(A,141,193)	CEAT101M10	
R 5203(B,265,202)		RS1/16S333J	C 5108(B,111,195)	ACG7057	
R 5204(B,281,204)		RS1/16S103J	C 5109(A,125,189)	CEAT100M2A	
R 5205(B,258,191)		RS1/16S152J	C 5111(B,101,142)	ACG7056	
R 5206(B,257,198)		RS1/16S821J	C 5112(B,130,142)	CEAT100M200V	
R 5207(B,279,196)		RS1/16S2001F	F		
R 5208(B,268,193)		RS1/16S682J	C 5115(B,115,205)	CCSRCH220J50	
R 5209(A,271,192)	CARBON FILM RESISTOR	RD1/2VM473J	C 5116(B,115,207)	CCSRCH220J50	
R 5210(B,278,183)		RS1/16S151J	C 5117(A,119,207)	CEAT331M10	
R 5211(B,276,183)		RN1/16SE1201D	C 5123(A,137,180)	CEAT100M63	
R 5212(B,251,195)		RS1/16S221J	C 5124(A,112,184)	CEAT100M63	

Mark No.	Description	Part No.	Mark No.	Description	Part No.
A	C 5132(B,108,199)	CKSRYB224K16	Q 5571(B,223,38)	TRANSISTOR	2SC4081
	C 5141(A,88,191)	CEANP2R2M50	Q 5572(B,220,38)	TRANSISTOR	2SC4081
	C 5201(A,271,202)	CEAT4R7M50	D 5301(B,191,58)	CHIP ZENER DIODE	UDZS3R6(B)
	C 5202(B,265,199)	CCSRCH221J50	D 5302(B,188,58)	DIODE	1SS355
	C 5204(B,255,194)	CKSRYB102K50	D 5303(B,180,62)	DIODE	1SS355
	C 5207(A,283,192)	CEAT101M10	D 5304(B,173,62)	DIODE	1SS355
B	C 5208(B,253,195) CERAMIC (4P, 200 V)	ACG7057	D 5305(B,177,62)	DIODE	UDZS4R7(B)
	C 5209(A,267,187) ELECT. CAPACITOR	CEAT100M2A	D 5306(B,175,62)	DIODE	UDZS4R7(B)
	C 5211(B,243,142) CERAMIC (100P, 200 V)	ACG7056	D 5341(B,151,71)	DIODE	1SS355
	C 5212(B,271,142) CERAMIC (100P, 200 V)	ACG7056	D 5342(B,149,71)	DIODE	1SS355
	C 5215(B,257,204)	CCSRCH220J50	D 5343(B,150,50)	DIODE	1SS355
	C 5216(B,257,206)	CCSRCH220J50	D 5344(B,153,71)	DIODE	1SS355
C	C 5217(A,261,206)	CEAT331M10	D 5401(B,137,58)	CHIP ZENER DIODE	UDZS3R6(B)
	C 5223(A,287,181)	CEAT100M63	D 5402(B,135,58)	DIODE	1SS355
	C 5224(A,255,184)	CEAT100M63	D 5403(B,126,62)	DIODE	1SS355
	C 5232(B,250,199)	CKSRYB224K16	D 5404(B,119,62)	DIODE	1SS355
	C 5241(A,237,192)	CEANP2R2M50	D 5405(B,124,62)	DIODE	UDZS4R7(B)
	C 5611(B,307,142) CERAMIC (100P, 200 V)	ACG7056	D 5406(B,122,62)	DIODE	UDZS4R7(B)

AE POSI 1-L ASSY**MISCELLANEOUS**

- ⚠ TH4501(A,54,223) POSISTOR
J 4501(A,66,220) CONNECTOR ASSY

PTFM04BH220Q2N34B0
PG02KS-E07

AF POSI 2-L ASSY**MISCELLANEOUS**

- ⚠ TH4502(A,79,235) POSISTOR
J 4502(A,76,223) CONNECTOR ASSY

PTFM04BC220Q2N34B0
PG02KS2E07

AG POWER AMP-R ASSY**MISCELLANEOUS**

- ⚠ IC 5301(A,196,111) DARLINGTON POWER IC
⚠ IC 5302(A,162,111) DARLINGTON POWER IC
⚠ IC 5401(A,128,111) DARLINGTON POWER IC
⚠ IC 5402(A,94,111) DARLINGTON POWER IC
⚠ IC 5501(A,264,111) DARLINGTON POWER IC

SAP17N(OY)
SAP17P(OY)
SAP17N(OY)
SAP17P(OY)
SAP17N(OY)

- ⚠ IC 5502(A,230,111) DARLINGTON POWER IC
⚠ IC 5602(A,298,111) DARLINGTON POWER IC
Q 5301(B,186,38) CHIP TRANSISTOR
Q 5302(B,176,52) TRANSISTOR
Q 5303(B,187,48) CHIP TRANSISTOR

SAP17P(OY)
SAP17P(OY)
2SD2704K
IMT4
2SA1514K

- Q 5304(A,185,62) TRANSISTOR
Q 5305(A,161,55) TRANSISTOR
Q 5341(B,146,56) CHIP TR
Q 5401(B,132,38) CHIP TRANSISTOR
Q 5402(B,122,52) TRANSISTOR

2SA1145
2SC2705
2SA1255
2SD2704K
IMT4

- Q 5403(B,133,48) CHIP TRANSISTOR
Q 5404(A,131,62) TRANSISTOR
Q 5405(A,108,55) TRANSISTOR
Q 5441(B,91,45) CHIP TR
Q 5501(B,275,38) CHIP TRANSISTOR

2SA1514K
2SA1145
2SC2705
2SA1255
2SD2704K

- Q 5502(B,266,52) TRANSISTOR
Q 5503(B,277,48) CHIP TRANSISTOR
Q 5504(A,274,63) TRANSISTOR
Q 5505(A,252,55) TRANSISTOR
Q 5541(B,239,49) CHIP TR

IMT4
2SA1514K
2SA1145
2SC2705
2SA1255

RESISTORS

- R 5301(B,192,43)
R 5302(B,180,42)
R 5303(B,177,41)
R 5304(B,192,40)
R 5305(B,170,55)
- CN5301(A,319,31) 13P SOCKET
CN5302(A,85,45) 11P SOCKET
CN5303(A,312,68) PLUG 6-P

- CN5304(A,143,23) CONNECTOR POST
5002(A,236,21) PCB BINDER
- R 5306(B,168,47)
R 5307(B,190,48)
R 5308(B,179,54)
R 5309(A,183,48) CARBON FILM
R 5310(B,191,62)

- R 5311(B,188,62)
R 5312(B,162,51)
R 5313(B,183,97) CHIP RESISTOR
R 5321(B,190,93)
R 5322(B,176,93)
- ⚠ R 5323(A,196,79) CARBON FILM
⚠ R 5324(A,161,70) CARBON FILM
⚠ R 5325(B,203,91) CHIP (0.047, 0.5 W)
⚠ R 5326(B,166,91) CHIP (0.047, 0.5 W)
⚠ R 5327(A,172,80) RESISTOR (0.18, 5 W)

RS1/16S102J

RS1/16S221J

RS1/16S333J

RS1/16S103J

RS1/16S152J

RS1/16S821J

RS1/16S2001F

RS1/16S682J

RD1/2VM473J

RS1/16S151J

RN1/16SE1201D

RS1/16S221J

RS1/16S62R0F

RS1/16S101J

RS1/16S101J

RD1/4MUF4R7J

RD1/4MUF4R7J

ACN7132

ACN7132

ACN7121

Mark No.	Description	Part No.	Mark No.	Description	Part No.
R 5329(B,168,44)		RN1/10SE3302D	R 5513(B,257,97)	CHIP RESISTOR	RS1/16S62R0F
R 5330(B,173,45)		RN1/16SE1001D	R 5521(B,268,94)		RS1/16S101J
R 5331(B,173,43)		RN1/16SE1500D	R 5522(B,251,93)		RS1/16S101J
R 5332(B,160,51)		RS1/16S151J	▲ R 5523(A,280,82)	CARBON FILM RESISTOR	RD1/4MUF4R7J
R 5341(B,150,75)		RS1/16S473J	▲ R 5524(A,250,70)	CARBON FILM RESISTOR	RD1/4MUF4R7J
R 5342(B,148,75)		RS1/16S223J	▲ R 5525(B,277,91)	CHIP (0.047, 0.5 W)	A ACN7132
R 5343(B,153,75)		RS1/16S471J	▲ R 5526(B,241,91)	CHIP (0.047, 0.5 W)	ACN7132
R 5344(B,146,75)		RS1/16S471J	▲ R 5527(A,256,80)	RESISTOR (0.18, 5 W)	ACN7121
R 5345(B,152,65)		RS1/16S472J	R 5529(B,258,44)		RN1/10SE3302D
R 5346(B,149,65)		RS1/16S472J	R 5530(B,263,45)		RN1/16SE1001D
R 5347(B,145,62)		RS1/16S122J	R 5531(B,263,43)		RN1/16SE1500D
R 5348(B,148,61)		RS1/16S154J	R 5532(B,250,51)		RS1/16S151J
R 5349(B,150,61)		RS1/16S103J	R 5541(B,241,77)		RS1/16S473J
R 5350(B,150,55)		RS1/16S103J	R 5542(B,235,77)		RS1/16S223J
R 5401(B,139,43)		RS1/16S102J	R 5543(B,239,77)		RS1/16S471J
R 5402(B,126,42)		RS1/16S221J	R 5544(B,237,77)		B RS1/16S471J
R 5403(B,123,41)		RS1/16S333J	R 5545(B,240,64)		RS1/16S472J
R 5404(B,139,40)		RS1/16S103J	R 5546(B,238,64)		RS1/16S472J
R 5405(B,116,55)		RS1/16S152J	R 5547(B,238,57)		RS1/16S122J
R 5406(B,114,47)		RS1/16S821J	R 5548(B,235,68)		RS1/16S154J
R 5407(B,137,48)		RS1/16S2001F	R 5549(B,236,64)		RS1/16S103J
R 5408(B,126,54)		RS1/16S682J	R 5550(B,242,46)		RS1/16S103J
R 5409(A,129,48) CARBON FILM		RD1/2VM473J	R 5571(B,226,38)		RS1/16S472J
R 5410(B,137,62)		RS1/16S151J	▲ R 5592(B,301,91)	CHIP (0.047, 0.5 W)	ACN7132
R 5411(B,135,62)		RN1/16SE1201D	R 5622(B,311,93)		RS1/16S101J
R 5412(B,109,51)		RS1/16S221J			C
R 5413(B,115,97) CHIP RESISTOR		RS1/16S62R0F	C 5301(A,183,43)		CEAT4R7M50
R 5421(B,128,93)		RS1/16S101J	C 5302(B,177,43)		CCSRCH221J50
R 5422(B,108,93)		RS1/16S101J	C 5304(B,167,51)		CKSRYB102K50
▲ R 5423(A,138,80) CARBON FILM		RD1/4MUF4R7J	C 5307(A,195,53)		CEAT101M10
▲ R 5424(A,107,70) CARBON FILM		RD1/4MUF4R7J	C 5308(B,164,51)	CERAMIC (4P, 200 V)	ACG7057
▲ R 5425(B,135,91) CHIP (0.047, 0.5 W)		ACN7132	C 5309(A,179,58)	ELECT. CAPACITOR	CEAT100M2A
▲ R 5426(B,99,91) CHIP (0.047, 0.5 W)		ACN7132	C 5311(B,197,104)	CERAMIC (100P, 200 V)	ACG7056
▲ R 5427(A,114,80) RESISTOR (0.18, 5 W)		ACN7121	C 5312(B,170,104)	CERAMIC (100P, 200 V)	ACG7056
R 5429(B,114,44)		RN1/10SE3302D	C 5315(B,168,41)		CCSRCH220J50
R 5430(B,119,45)		RN1/16SE1001D	C 5316(B,168,39)		CCSRCH220J50
R 5431(B,119,43)		RN1/16SE1500D			D
R 5432(B,106,51)		RS1/16S151J	C 5317(A,172,39)		CEAT331M10
R 5441(B,95,63)		RS1/16S473J	C 5323(A,190,66)		CEAT100M63
R 5442(B,93,63)		RS1/16S223J	C 5324(A,165,62)		CEAT100M63
R 5443(B,97,63)		RS1/16S471J	C 5332(B,162,47)		CKSRYB224K16
R 5444(B,91,63)		RS1/16S471J	C 5341(A,145,66)		CEANP2R2M50
R 5445(B,96,54)		RS1/16S472J			
R 5446(B,92,54)		RS1/16S472J	C 5351(A,226,68)	ELECT. CAPACITOR	CEAT100M2A
R 5447(B,88,49)		RS1/16S122J	C 5352(A,222,62)	ELECT. CAPACITOR	CEAT100M2A
R 5448(B,94,50)		RS1/16S154J	C 5401(A,129,43)		CEAT4R7M50
R 5449(B,96,50)		RS1/16S103J	C 5402(B,123,43)		CCSRCH221J50
R 5450(B,96,46)		RS1/16S103J	C 5404(B,113,51)		CKSRYB102K50
R 5501(B,283,44)		RS1/16S102J			
R 5502(B,270,42)		RS1/16S221J	C 5407(A,141,53)		CEAT101M10
R 5503(B,267,41)		RS1/16S333J	C 5408(B,111,51)	CERAMIC (4P, 200 V)	ACG7057
R 5504(B,283,40)		RS1/16S103J	C 5409(A,125,58)	ELECT. CAPACITOR	CEAT100M2A
R 5505(B,260,55)		RS1/16S152J	C 5411(B,130,104)	CERAMIC (100P, 200 V)	ACG7056
R 5506(B,258,47)		RS1/16S821J	C 5412(B,101,104)	CERAMIC (100P, 200 V)	ACG7056
R 5507(B,281,48)		RS1/16S2001F			
R 5508(B,270,54)		RS1/16S682J	C 5415(B,114,41)		CCSRCH220J50
R 5509(A,273,48) CARBON FILM		RD1/2VM473J	C 5416(B,114,39)		CCSRCH220J50
R 5510(B,280,63)		RS1/16S151J	C 5417(A,119,39)		CEAT331M10
R 5511(B,277,63)		RS1/16SE1201D	C 5423(A,137,66)		CEAT100M63
R 5512(B,253,51)		RS1/16S221J	C 5424(A,111,62)		CEAT100M63

Mark No.	Description	Part No.	Mark No.	Description	Part No.
A	C 5432(B,108,47)	CKSRYB224K16	R 5606(B,41,38)		RS1/16S821J
	C 5441(A,88,53)	CEANP2R2M50	R 5607(B,42,59)		RS1/16S2001F
	C 5501(A,273,43)	CEAT4R7M50	R 5608(B,42,42)		RS1/16S682J
	C 5502(B,267,43)	CCSRCH221J50	R 5609(A,32,46) CARBON FILM		RD1/2VM473J
	C 5504(B,257,51)	CKSRYB102K50	R 5610(B,30,59)		RS1/16S151J
	C 5507(A,284,54)	CEAT101M10	R 5611(B,33,59)		RN1/16SE1201D
	C 5508(B,255,51) CERAMIC (4P, 200 V)	ACG7057	R 5612(B,33,34)		RS1/16S221J
	C 5509(A,267,58) ELECT. CAPACITOR	CEAT100M2A	△ R 5623(A,65,58) CARBON FILM		RD1/4MUF4R7J
	C 5511(B,271,104) CERAMIC (100P, 200 V)	ACG7056	△ R 5624(A,65,40) CARBON FILM		RD1/4MUF4R7J
	C 5512(B,243,104) CERAMIC (100P, 200 V)	ACG7056	△ R 5627(A,19,56) RESISTOR (0.18, 5 W)		ACN7121
B	C 5515(B,258,41)	CCSRCH220J50	R 5629(B,47,48)		RN1/10SE3302D
	C 5516(B,258,39)	CCSRCH220J50	R 5630(B,49,46)		RN1/16SE1001D
	C 5517(A,263,39)	CEAT331M10	R 5631(B,49,51)		RN1/16SE1500D
	C 5523(A,289,64)	CEAT100M63	R 5632(B,30,36)		RS1/16S151J
	C 5524(A,254,62)	CEAT100M63	R 5641(B,14,43)		RS1/16S473J
	C 5532(B,252,47)	CKSRYB224K16	R 5642(B,17,33)		RS1/16S223J
	C 5541(A,238,54)	CEANP2R2M50	R 5643(B,14,33)		RS1/16S471J
	C 5571(A,229,35)	CEAT331M10	R 5644(B,15,38)		RS1/16S471J
	C 5612(B,307,104) CERAMIC (100P, 200 V)	ACG7056	R 5645(B,18,28)		RS1/16S472J
			R 5646(B,20,28)		RS1/16S472J
C	AH POSI 1-R ASSY		R 5647(B,10,33)		RS1/16S122J
	MISCELLANEOUS		R 5648(B,45,25)		RS1/16S154J
	△ TH4503(A,54,235) POSISTOR	PTFM04BH22202N34B0	R 5649(B,49,26)		RS1/16S103J
	J 4551(A,66,232) CONNECTOR ASSY	PG02KS-E07	R 5650(B,51,26)		RS1/16S103J

CAPACITORS

C 5601(A,53,45)	CEAT4R7M50
C 5602(B,50,41)	CCSRCH221J50
C 5604(B,44,36)	CKSRYB102K50
C 5607(A,38,57)	CEAT101M10
C 5608(B,36,42) CERAMIC (4P, 200 V)	ACG7057
C 5609(A,27,51) ELECT. CAPACITOR	CEAT100M2A
C 5615(B,45,47)	CCSRCH220J50
C 5616(B,42,49)	CCSRCH220J50
C 5617(A,47,52)	CEAT331M10
C 5623(A,69,58)	CEAT100M63
C 5624(A,69,42)	CEAT100M63
C 5632(B,28,39)	CKSRYB224K16
C 5641(A,12,35)	CEANP2R2M50

AJ POWER PROTECT ASSY
MISCELLANEOUS

IC 5701(B,19,110) OP-AMP IC	BA4560RF
Q 5701(B,26,161) TRANSISTOR	RT1N241M
Q 5702(B,16,161) DIGITAL TR (SC-70)	RT1P241M
Q 5703(B,16,151) TRANSISTOR	RT1N241M
Q 5704(B,33,100) TRANSISTOR	2SC4081
Q 5705(B,23,161) TRANSISTOR	RT1N241M
Q 5706(B,12,161) DIGITAL TR (SC-70)	RT1P241M
D 5701(B,23,94) DIODE	1SS355
D 5702(B,30,205) DIODE	1SS355
CN5701(A,28,171) 11P PLUG	XKP3065

RESISTORS

R 5601(B,58,93)	RS1/16S102J	CN5702(A,15,138) 11P PLUG	XKP3065
R 5602(B,54,41)	RS1/16S221J	CN5703(A,8,85) 19P CONNECTOR	52044-1945
R 5603(B,52,41)	RS1/16S333J	CN5704(A,37,83) CONNECTOR	S5B-PH
R 5604(B,57,82)	RS1/16S103J	CN5705(A,30,223) 17P CONNECTOR	52044-1745
R 5605(B,46,36)	RS1/16S152J	CN5706(A,38,222) 3PIN CONNECTOR	S3B-EH

Mark No. **Description**
RESISTORS

R 5701(B,23,151)
R 5702(B,21,151)
R 5703(B,10,181)
R 5705(B,18,187)
R 5706(B,19,151)

R 5707(B,18,181)
R 5708(B,13,187)
R 5710(B,17,118)
R 5711(B,13,112)
R 5712(B,13,108)

R 5713(B,23,106)
R 5714(B,24,131)
R 5715(B,27,101)
R 5716(B,29,101)
R 5717(B,33,95)

R 5718(B,30,210)
R 5720(B,31,95)
R 5721(B,29,95)
R 5746(B,20,181)
R 5747(B,18,161)

R 5750(B,35,95)
R 5751(B,26,131)
R 5752(B,25,101)

CAPACITORS

C 5701(B,13,181)
C 5702(B,15,181)
C 5703(B,23,110)
C 5704(B,23,114)
C 5705(B,31,101)

C 5706(B,37,217)

AK HDMI & DVC ASSY
MISCELLANEOUS

IC 101 (A,56,65) HDMI RECEIVER
IC 151 (A,25,86) EEPROM
IC 152 (A,30,86) LOGIC IC
IC 171 (A,25,66) EEPROM
IC 172 (A,30,66) LOGIC IC

IC 202 (A,77,22) IC
IC 203 (A,77,12) IC
IC 301 (A,52,33) HDMI TRANSMITTER
IC 401 (A,135,64) VIDEO DECODER
IC 402 (A,150,65) IC

IC 452 (A,90,70) IC
IC 453 (A,87,63) IC
IC 454 (A,87,54) IC
IC 501 (B,107,36) CPU
IC 502 (A,107,38) FLASH ROM

IC 504 (A,97,25) IC
IC 701 (A,108,59) VIDEO ENCODER IC
△IC 901 (B,144,27) REGULATOR IC
△IC 902 (B,140,41) IC
△IC 903 (B,156,40) REGULATOR IC

Part No.

RS1/16S562J
RS1/16S562J
RS1/16S473J
RS1/16S0R0J
RS1/16S822J

RS1/16S473J
RS1/16S0R0J
RS1/16S223J
RS1/16S103J
RS1/16S472J

RS1/16S103J
RS1/16S102J
RS1/16S473J
RS1/16S472J
RS1/16S103J

RS1/16S104J
RS1/16S103J
RS1/16S683J
RS1/16S0R0J
RS1/16S0R0J

RS1/16S0R0J
RS1/16S0R0J
RS1/16S0R0J

CKSRYB104K50
CKSRYB104K50
CKSRYB103K50
CKSRYB103K50
CKSRYB223K50

CKSRYB103K50

SII9033CTU
BR24L02FV-W
SN74CBT3257CPW
BR24L02FV-W
SN74CBT3257CPW

TC74LCX541FTS1
TC74LCX541FTS1
SII9030CTU-7
ADV7401BSTZ-80
TC7WU04FU

TC7SZ125FU
TC74LCX541FTS1
TC74LCX541FTS1
PEG118A
AYW7123

TC74VHC125FTS1
ADV7172KSTZ
BD7802FP
NJM2885DL1-18
BD7802FP

Mark No. **Description**

△ IC 904 (B,158,57) REGULATOR IC
△ IC 911 (B,104,11) REGULATOR IC
Q 101 (A,42,91) DUAL MOS FET
Q 151 (A,18,91) CHIP TRANSISTOR
Q 152 (B,24,83) CHIP TRANSISTOR

Q 153 (A,39,84) DUAL MOS FET
Q 161 (A,35,45) DUAL MOS FET
Q 171 (A,18,68) CHIP TRANSISTOR
Q 172 (B,24,63) CHIP TRANSISTOR
Q 173 (A,37,65) DUAL MOS FET

Q 301 (B,42,31) DIGITAL TR (SC-70)
Q 351 (B,28,32) CHIP TR (PNP X 2)
Q 352 (B,31,37) CHIP TRANSISTOR
Q 353 (A,41,42) DUAL MOS FET
Q 731 (A,95,70) TRANSISTOR

Q 741 (A,100,70) TRANSISTOR
Q 751 (A,104,70) TRANSISTOR
Q 761 (A,109,70) TRANSISTOR
Q 771 (A,113,70) TRANSISTOR
Q 781 (A,118,70) TRANSISTOR

D 151 (B,20,79) DIODE
D 171 (B,20,55) DIODE
D 381 (B,28,49) DIODE
D 551 (A,89,38) CHIP DIODE
D 903 (B,148,50) DIODE

L 101 (A,72,46) CHIP BEADS
L 103 (A,80,84) CHIP BEADS
L 104 (A,36,48) CHIP BEADS
L 302 (B,53,30) CHIP BEADS
L 304 (A,74,31) CHIP BEADS

L 305 (A,69,46) CHIP BEADS
△ L 351 (A,29,26) COIL
△ L 352 (A,29,29) COIL
△ L 353 (A,29,32) COIL
△ L 354 (A,29,35) COIL

L 401 (A,149,53) CHIP BEADS
L 402 (B,146,73) CHIP BEADS
L 403 (A,158,61) CHIP BEADS
L 404 (A,148,88) CHIP BEADS
L 501 (A,82,38) CHIP BEADS

L 701 (A,100,51) CHIP BEADS
L 702 (B,125,84) CHIP BEADS
JA101 (A,16,79) HDMI CONNECTOR
JA102 (A,16,57) HDMI CONNECTOR
JA301 (A,16,35) HDMI CONNECTOR

X 101 (A,60,48) CRYSTAL (27M)
X 401 (A,152,72) CRYSTAL (28.63636M)
X 501 (A,112,29) CERAMIC (15.7M)
CN501 (A,18,19) 07P CONNECTOR
CN1001(A,137,13) 26P SOCKET

CN1002(A,86,81) 23P SOCKET
CN1002(A,86,81) 23P SOCKET

RESISTORS

R 101 (A,52,83) RESISTOR ARRAY
R 102 (A,66,79) RESISTOR ARRAY
R 103 (A,50,79)
R 104 (B,52,77)
R 105 (A,47,79)

Part No.

MM1561JF
NJM2872BF05

HN1K02FU
DTC114YUA
DTC114YUA

A

HN1K02FU
DTC114YUA
DTC114YUA
HN1K02FU

RT1P241M
UMB1N
DTC114YUA
HN1K02FU
2SA1576A

B

2SA1576A
2SA1576A
2SA1576A
2SA1576A
2SA1576A
2SA1576A
2SA1576A
2SA1576A
2SA1576A

C

ATL7010
ATL7010
ATL7010
ATL7010
ATL7010
ATL7010
ATH7022
ATH7022
ATH7022
ATH7022

ATL7010
ATL7010
ATL7010
ATL7010
ATL7010

D

ATL7010
ATL7010
AKP7210
AKP7210
AKP7210
XSS3004
RKN1048
AKP7209

E

ASS7066
ASS7067
XSS3004

RK1048
AKP7209
XKP3082
RAB4CQ100J
RAB4CQ470J
RS1/16S100J
RS1/16S100J
RS1/16S103J

F

Mark No.	Description	Part No.	Mark No.	Description	Part No.
A	R 106 (A,49,79)	RS1/16S103J	R 303 (B,57,39)		RS1/16S100J
	R 107 (A,57,83) RESISTOR ARRAY	RAB4CQ470J	R 306 (B,50,42)		RS1/16S101J
	R 108 (A,60,83) RESISTOR ARRAY	RAB4CQ470J	R 312 (B,51,34) CHIP RESISTOR		RS1/16S4750F
	R 109 (B,60,71)	RS1/16S470J	R 313 (A,44,39)		RS1/16S472J
	R 111 (B,50,48)	RS1/16S101J	R 314 (B,49,26)		RS1/16S100J
B	R 112 (B,49,53)	RS1/16S470J	R 315 (B,45,27)		RS1/16S100J
	R 113 (B,52,61)	RS1/16S680J	R 316 (A,45,24)		RS1/16S471J
	R 114 (B,64,53)	RS1/16S472J	R 318 (B,55,26)		RS1/16S472J
	R 115 (A,71,49)	RS1/16S472J	R 319 (B,49,35)		RS1/16S3901F
	R 118 (A,61,51)	RS1/16S105J	R 325 (B,59,30)		RS1/16S150J
B	R 119 (A,67,49)	RS1/16S471J	R 326 (A,48,43)		RS1/16S100J
	R 120 (B,63,60)	RS1/16S221J	R 327 (A,46,43)		RS1/16S100J
	R 121 (A,67,50)	RS1/16S221J	R 331 (A,60,43) RESISTOR ARRAY		RAB4CQ473J
	R 122 (B,54,61)	RS1/16S470J	R 332 (A,75,61)		RS1/16S473J
	R 123 (B,55,53)	RS1/16S100J	R 333 (A,75,72) RESISTOR ARRAY		RAB4CQ473J
C	R 124 (A,58,51)	RS1/16S152J	R 334 (A,75,70) RESISTOR ARRAY		RAB4CQ473J
	R 125 (A,52,47) RESISTOR ARRAY	RAB4CQ680J	R 335 (A,75,67) RESISTOR ARRAY		RAB4CQ473J
	R 126 (A,71,72) RESISTOR ARRAY	RAB4CQ470J	R 336 (A,75,64) RESISTOR ARRAY		RAB4CQ473J
	R 127 (A,71,70) RESISTOR ARRAY	RAB4CQ470J	R 337 (A,75,58) RESISTOR ARRAY		RAB4CQ473J
	R 128 (A,71,67) RESISTOR ARRAY	RAB4CQ220J	R 338 (A,75,55) RESISTOR ARRAY		RAB4CQ473J
C	R 129 (A,71,64) RESISTOR ARRAY	RAB4CQ220J	R 351 (B,27,37)		RS1/16S472J
	R 130 (A,71,58) RESISTOR ARRAY	RAB4CQ220J	R 352 (B,24,37)		RS1/16S472J
	R 131 (A,71,55) RESISTOR ARRAY	RAB4CQ220J	R 353 (B,29,37)		RS1/16S272J
	R 132 (A,71,61)	RS1/16S150J	R 354 (B,24,31)		RS1/16S272J
	R 133 (B,44,89)	RS1/16S103J	R 355 (A,44,43)		RS1/16S472J
C	R 134 (A,40,90)	RS1/16S103J	R 356 (A,38,43)		RS1/16S472J
	R 135 (A,46,89)	RS1/16S103J	R 386 (B,26,44)		RS1/16S473J
	R 136 (B,40,88)	RS1/16S103J	R 389 (B,28,44)		RS1/16S102J
	R 137 (B,46,89)	RS1/16S104J	R 403 (A,132,54) RESISTOR ARRAY		RAB4CQ470J
	R 138 (A,38,90)	RS1/16S104J	R 404 (B,134,56)		RS1/16S330J
D	R 151 (B,31,83)	RS1/16S100J	R 405 (B,131,61)		RS1/16S330J
	R 152 (B,29,83)	RS1/16S100J	R 406 (A,139,52)		RS1/16S330J
	R 153 (B,26,83)	RS1/16S101J	R 407 (A,142,54) RESISTOR ARRAY		RAB4CQ560J
	R 154 (B,31,79)	RS1/16S103J	R 408 (B,144,56)		RS1/16S560J
	R 155 (B,29,79)	RS1/16S103J	R 409 (B,142,57)		RS1/16S560J
D	R 156 (B,26,79)	RS1/16S103J	R 410 (B,144,61)		RS1/16S103J
	R 157 (B,18,91)	RS1/16S473J	R 411 (B,135,64)		RS1/16S100J
	R 158 (A,39,87)	RS1/16S472J	R 412 (B,140,57)		RS1/16S560J
	R 159 (A,39,81)	RS1/16S472J	R 413 (B,138,61)		RS1/16S560J
	R 161 (B,21,83)	RS1/16S102J	R 414 (A,150,69)		RS1/16S105J
E	R 171 (B,31,63)	RS1/16S100J	R 415 (A,153,69)		RS1/16S101J
	R 172 (B,29,63)	RS1/16S100J	R 416 (A,146,64)		RS1/16S101J
	R 173 (B,26,63)	RS1/16S101J	R 417 (A,154,65)		RS1/16S0R0J
	R 174 (B,31,59)	RS1/16S103J	R 418 (B,142,73)		RS1/16S132J
	R 175 (B,29,59)	RS1/16S103J	R 419 (B,142,69)		RS1/16S391J
E	R 176 (B,26,59)	RS1/16S103J	R 421 (A,148,80)		RS1/10S0R0J
	R 177 (B,24,49)	RS1/16S473J	R 422 (A,148,82)		RS1/10S0R0J
	R 178 (A,35,68)	RS1/16S472J	R 423 (A,145,73)		RS1/16S103J
	R 179 (A,37,63)	RS1/16S472J	R 424 (B,133,71)		RS1/16S272J
	R 181 (B,20,61)	RS1/16S102J	R 425 (B,135,71)		RS1/16S272J
F	R 201 (A,83,27)	RS1/16S470J	R 431 (A,123,69)		RS1/16S471J
	R 202 (A,84,25)	RS1/16S470J	R 432 (B,126,65)		RS1/16S103J
	R 203 (A,84,24)	RS1/16S470J	R 434 (B,122,62)		RS1/16S330J
	R 204 (A,83,22) RESISTOR ARRAY	RAB4CQ470J	R 435 (B,124,62)		RS1/16S330J
	R 205 (A,83,19)	RS1/16S470J	R 436 (A,124,60) RESISTOR ARRAY		RAB4CQ470J
F	R 206 (A,83,17) RESISTOR ARRAY	RAB4CQ470J	R 452 (A,89,73)		RS1/16S330J
	R 207 (A,84,15)	RS1/16S470J	R 453 (A,80,62) RESISTOR ARRAY		RAB4CQ680J
	R 208 (A,84,14)	RS1/16S470J	R 454 (A,80,65) RESISTOR ARRAY		RAB4CQ680J
	R 209 (A,84,12)	RS1/16S470J	R 455 (A,80,55) RESISTOR ARRAY		RAB4CQ680J
	R 210 (B,80,11)	RS1/16S470J	R 456 (A,80,58) RESISTOR ARRAY		RAB4CQ680J

Mark No.	Description	Part No.	Mark No.	Description	Part No.
R 461 (A,137,48)	RESISTOR ARRAY	RAB4CQ473J	R 716 (A,100,60)		RS1/16S103J
R 462 (A,142,50)	RESISTOR ARRAY	RAB4CQ473J	R 718 (A,99,58)		RS1/16S103J
R 463 (A,105,51)	RESISTOR ARRAY	RAB4CQ473J	R 719 (A,94,59)		RS1/16S471J
R 464 (A,109,51)	RESISTOR ARRAY	RAB4CQ473J	R 721 (A,99,54)		RS1/16S470J
R 465 (B,133,64)		RS1/16S473J	R 731 (B,96,66)		RS1/16S1500F
R 506 (B,125,32)		RS1/16S221J	R 732 (B,94,66)		RS1/16S0R0J
R 508 (B,119,27)		RS1/16S472J	R 733 (A,94,74)		RS1/16S102J
R 511 (B,129,23)		RS1/16S101J	R 741 (B,101,66)		RS1/16S1500F
R 517 (B,112,22)		RS1/16S101J	R 742 (B,99,66)		RS1/16S0R0J
R 520 (B,127,32)		RS1/16S103J	R 743 (A,99,74)		RS1/16S102J
R 524 (B,107,19)		RS1/16S100J	R 751 (B,105,66)		RS1/16S1500F
R 525 (B,105,19)		RS1/16S100J	R 752 (B,104,66)		RS1/16S0R0J
R 526 (B,99,17)		RS1/16S100J	R 753 (A,103,74)		RS1/16S102J
R 527 (B,95,17)		RS1/16S100J	R 761 (B,110,66)		RS1/16S1500F
R 528 (B,93,22)		RS1/16S470J	R 762 (B,108,66)		RS1/16S3R3J
R 529 (B,90,26)		RS1/16S473J	R 763 (A,108,74)		RS1/16S102J
R 530 (B,109,19)		RS1/16S222J	R 771 (B,114,66)		RS1/16S1500F
R 531 (B,103,19)		RS1/16S222J	R 772 (B,112,66)		RS1/16S3R3J
R 533 (B,97,17)		RS1/16S222J	R 773 (A,112,74)		RS1/16S102J
R 534 (B,92,17)		RS1/16S222J	R 781 (B,119,66)		RS1/16S1500F
R 537 (B,129,40)		RS1/16S101J	R 782 (B,117,66)		RS1/16S3R3J
R 538 (B,127,40)		RS1/16S101J	R 783 (A,117,74)		RS1/16S102J
R 539 (B,125,40)		RS1/16S101J	R 902 (A,147,40)		RS1/10S0R0J
R 540 (A,102,23)		RS1/16S470J	R 1001(A,108,17)		RS1/10S0R0J
R 541 (A,91,25)		RS1/16S103J	R 1002(A,93,18)		RS1/10S100J
R 542 (A,91,23)		RS1/16S470J	R 1101(B,91,73)		RS1/10S0R0J
R 543 (A,91,26)		RS1/16S472J	R 1102(B,89,73)		RS1/10S0R0J
R 544 (A,91,28)		RS1/16S470J	R 1105(A,43,79)		RS1/10S0R0J
R 546 (B,95,22)		RS1/16S101J	R 1107(B,63,53)		RS1/16S0R0J
R 548 (A,89,31)		RS1/16S473J	R 1108(B,61,60)		RS1/16S0R0J
R 549 (B,93,26)		RS1/16S473J	R 1301(B,43,36)		RS1/10S0R0J
R 551 (A,119,42)		RS1/16S473J			
R 561 (B,121,27)		RS1/16S103J			
R 562 (B,127,27)		RS1/16S103J			
R 564 (B,123,23)		RS1/16S103J			
R 565 (B,116,22)		RS1/16S103J			
R 566 (A,105,23)		RS1/16S103J			
R 567 (A,115,25)		RS1/16S103J			
R 568 (B,123,48)		RS1/16S103J			
R 569 (A,89,32)		RS1/16S103J			
R 571 (B,19,22)		RS1/16S103J			
R 580 (B,83,33)		RS1/16S101J			
R 581 (A,96,30)		RS1/16S101J			
R 582 (A,103,30)		RS1/16S101J			
R 583 (A,99,30)		RS1/16S101J			
R 586 (B,131,44)		RS1/16S103J			
R 588 (A,107,22)		RS1/16S103J			
R 594 (A,123,23)		RS1/16S0R0J			
R 702 (A,116,54)		RS1/16S103J			
R 704 (A,116,55)		RS1/16S103J			
R 705 (A,119,57)		RS1/16S103J			
R 706 (A,116,58)		RS1/16S103J			
R 707 (A,119,59)		RS1/16S470J			
R 708 (A,119,60)		RS1/16S470J			
R 709 (A,119,62)		RS1/16S1201F			
R 710 (A,119,63)		RS1/16S1201F			
R 711 (A,100,62)		RS1/16S1201F			
R 712 (A,100,64)		RS1/16S1201F			
R 713 (B,97,59)		RS1/16S470J			
R 714 (B,100,59)		RS1/16S103J			

CAPACITORS

C 101 (A,46,79)	CKSRYB105K10
C 102 (A,52,79)	CKSRYB104K16
C 103 (A,54,79)	CKSRYB104K16
C 104 (A,55,79)	CKSRYB104K16
C 106 (A,59,79)	CKSRYB104K16
C 110 (A,64,79)	CKSRYB104K16
C 112 (A,77,48)	CEVW101M16
C 115 (A,74,77)	CEVW101M16
C 116 (B,46,74)	CKSRYB105K10
C 117 (A,43,77)	CKSRYB105K10
C 118 (B,49,70)	CKSRYB104K16
C 119 (B,46,70)	CKSRYB104K16
C 120 (B,49,66)	CKSRYB104K16
C 121 (B,46,66)	CKSRYB105K10
C 122 (B,49,60)	CKSRYB104K16
C 123 (B,45,60)	CKSRYB104K16
C 124 (B,45,56)	CKSRYB104K16
C 125 (A,41,49)	CEVW101M16
C 126 (A,46,51)	CKSRYB104K16
C 127 (A,47,51)	CKSRYB104K16
C 128 (A,49,51)	CKSRYB104K16
C 129 (A,68,53)	CKSRYB104K16
C 130 (A,52,51)	CKSRYB104K16
C 131 (A,54,51)	CKSRYB104K16
C 132 (A,56,50)	CKSRYB104K16

Mark No.	Description	Part No.	Mark No.	Description	Part No.
A	C 133 (B,61,53)	CKSRYB104K16	C 430 (A,132,75)		CKSRYB104K16
	C 134 (B,59,60)	CKSRYB104K16	C 431 (A,127,82)		CEVV100M16
	C 135 (A,67,47)	CKSRYB103K50	C 432 (A,132,77)		CKSRYB104K16
	C 136 (A,65,51)	CKSRYB103K50	C 433 (A,132,82)		CEVV100M16
	C 137 (A,58,45)	CCSRCH120J50	C 434 (B,131,76)		CKSRYB103K50
	C 138 (A,62,45)	CCSRCH120J50	C 435 (B,129,76)		CKSRYB104K16
	C 139 (B,67,72)	CKSRYB104K16	C 436 (B,127,76)		DCH1201
	C 140 (B,67,68)	CKSRYB104K16	C 437 (B,137,76)		CKSRYB104K16
	C 141 (B,70,66)	CKSRYB104K16	C 438 (A,126,76)		CKSRYB104K16
	C 142 (B,67,64)	CKSRYB104K16	C 439 (A,126,74)		CKSRYB104K16
B	C 143 (B,66,60)	CKSRYB104K16	C 440 (A,123,72)		CKSRYB104K16
	C 144 (A,44,89)	CKSRYB103K50	C 441 (A,123,71)		CKSRYB102K50
	C 145 (B,38,88)	CKSRYB103K50	C 443 (A,124,68)		CKSRYB103K50
	C 151 (A,22,87)	CKSRYB104K16	C 444 (A,156,51)		CEVV101M16
	C 153 (A,34,83)	CKSRYB104K16	C 445 (A,124,63)		CKSRYB104K16
	C 171 (A,21,68)	CKSRYB104K16	C 452 (A,87,69)		CKSRYB104K16
	C 173 (A,34,64)	CKSRYB104K16	C 453 (A,86,58)		CKSRYB104K16
	C 191 (B,26,73)	CKSRYB104K16	C 454 (A,86,49)		CKSRYB104K16
	C 192 (B,29,73)	CKSRYB102K50	C 501 (B,123,32)		CKSRYB103K50
	C 202 (A,77,27)	CKSRYB104K16	C 502 (B,116,27)		CKSRYB104K16
C	C 203 (A,77,17)	CKSRYB104K16	C 503 (A,85,44)		CEVV101M16
	C 301 (A,56,44)	CKSRYB104K16	C 505 (B,123,43)		CKSRYB104K16
	C 302 (A,51,43)	CKSRYB104K16	C 506 (B,97,45)		CKSRYB104K16
	C 303 (A,49,43)	CKSRYB104K16	C 507 (A,97,21)		CKSRYB104K16
	C 304 (B,49,30)	CKSRYB104K16	C 551 (A,119,39)		CKSRYB104K16
	C 305 (B,53,34)	CKSRYB105K10	C 552 (A,94,40)		CKSRYB104K16
	C 308 (B,45,31)	CKSRYB104K16	C 571 (B,21,18)		CKSRYB104K16
	C 311 (B,45,36)	CKSRYB104K16	C 701 (A,95,52)		CEVV101M16
	C 312 (A,58,24)	CKSRYB105K10	C 702 (A,113,51)		CKSRYB104K16
	C 313 (B,51,26)	CKSRYB104K16	C 703 (A,102,51)		CKSRYB104K16
D	C 314 (A,50,24)	CKSRYB104K16	C 704 (A,116,60)		CKSRYB104K16
	C 315 (A,44,22)	CKSRYB103K50	C 705 (A,119,65)		CKSRYB104K16
	C 316 (A,68,30)	CEVV101M16	C 706 (B,109,59)		CKSRYB104K16
	C 317 (A,68,40)	CEVV101M16	C 707 (B,107,59)		CKSRYB104K16
	C 318 (B,56,34)	CKSRYB105K10	C 708 (B,105,59)		CKSRYB104K16
	C 319 (B,59,35)	CKSRYB104K16	C 709 (B,102,60)		CKSRYB104K16
	C 351 (B,21,39)	CKSRYB104K16	C 710 (B,111,59)		CKSRYB105K10
	C 391 (B,26,53)	CKSRYB104K16	C 711 (A,121,81)		CEVV101M16
	C 392 (B,29,53)	CKSRYB102K50	C 712 (A,100,65)		CKSRYB104K16
	C 401 (A,148,47)	CEVV101M16	C 713 (A,96,58)		CKSRYB103K50
E	C 402 (A,130,53)	CKSRYB104K16	C 714 (A,98,57)		CKSRYB104K16
	C 403 (A,135,53)	CKSRYB105K10	C 731 (A,94,72)		CKSRYB104K16
	C 404 (A,138,53)	CKSRYB104K16	C 741 (A,99,72)		CKSRYB104K16
	C 405 (A,144,66)	CKSRYB104K16	C 751 (A,103,72)		CKSRYB104K16
	C 406 (A,150,75)	CCSRCH7R0D50	C 761 (A,108,72)		CKSRYB104K16
	C 407 (A,154,75)	CCSRCH7R0D50	C 771 (A,112,72)		CKSRYB104K16
	C 408 (A,153,65)	CKSRYB104K16	C 781 (A,117,72)		CKSRYB104K16
	C 409 (B,144,73)	CHIP CAPACITOR	C 901 (B,149,23)		CKSRYB105K10
	C 410 (B,144,69)	CKSRYB103K50	C 902 (B,142,18)		CKSQYB225K10
	C 411 (A,144,69)	CKSRYB471K50	C 904 (B,145,38)		CKSRYB105K10
F	C 412 (A,146,70)	CKSQYB225K10	C 905 (B,138,33)	CHIP CERAMIC C.	DCG1028
	C 421 (A,143,77)	CKSRYB104K16	C 907 (B,151,42)		CKSRYB105K10
	C 422 (A,141,77)	CKSRYB104K16	C 908 (B,158,49)		CKSQYB225K10
	C 423 (A,140,77)	CKSRYB104K16	C 910 (B,153,54)		CKSRYB105K10
	C 424 (A,136,75)	CKSRYB103K50	C 911 (B,160,63)		CKSRYB471K50
	C 425 (A,136,77)	CKSRYB104K16	C 912 (B,153,59)		CKSQYB225K10
	C 426 (A,137,78)	DCH1201	C 915 (B,109,11)		CKSRYB104K16
	C 427 (B,135,76)	CKSRYB104K16	C 916 (B,107,11)		CKSRYB103K50
	C 428 (A,137,81)	CKSRYB104K16	C 917 (B,99,11)		CKSQYB225K10
	C 429 (A,142,85)	CEVV101M16	C 1001(A,111,18)		CKSRYB104K16

Mark No. **Description**

C 1002(A,100,17)

Part No.

CEVW101M16

Mark No. **Description**

R 738 (A,39,55)

Part No.

RS1/16S100J

R 741 (B,79,23)

RS1/16S101J

R 744 (A,77,20)

RS1/16S101J

R 745 (A,76,21)

RS1/16S101J

R 746 (A,74,20)

RS1/16S101J

AL

USB ASSY

MISCELLANEOUS

IC 701 (A,37,40) USB MEDIA CONTROL IC	TCC760HC01-AG
▲IC 702 (A,63,35) REGULATOR IC	MM1561JF
▲IC 703 (A,87,25) REGULATOR IC	BD7802FP
IC 761 (A,63,46) SD-RAM(64M)	HY57V641620ETP-6
IC 762 (A,87,46) FLASH ROM	AYW7088
IC 9762 FLASH MEMORY IC	S29AL016D70TFI010
IC 771 (A,58,59) LOAD SWITCHING	AAT4618GV-0.5-1
IC 781 (A,37,16) AUDIO DAC	AK4387ET
IC 951 (A,67,28) IC	TC74VHCT08AFTS1
IC 953 (A,52,25) IC	TC74VHC08FTS1
Q 782 (B,94,44) CHIP TRANSISTOR	DTC114YUA
Q 783 (B,92,38) TRANSISTOR	2SA1576A
Q 784 (B,87,32) TRANSISTOR	IMX9
L 701 (B,27,42) INDUCTOR	LCTC100K1608
L 702 (B,34,33) CHIP SOLID INDUCTOR	QTL1013
L 703 (A,24,30) CHIP SOLID INDUCTOR	QTL1013
L 704 (B,53,56) CHIP SOLID INDUCTOR	QTL1013
L 705 (B,28,38) CHIP FERRITE BEADS	VTL1169
L 731 (A,28,60) CHIP FERRITE BEADS	VTL1169
L 733 (A,36,56) COIL	VTH1043
L 761 (B,78,47) CHIP SOLID INDUCTOR	QTL1013
L 762 (B,85,44) CHIP SOLID INDUCTOR	QTL1013
L 781 (B,46,19) CHIP SOLID INDUCTOR	QTL1013
L 951 (A,59,30) CHIP SOLID INDUCTOR	QTL1013
L 953 (A,72,37) CHIP SOLID INDUCTOR	QTL1013
X 701 (A,23,42) CRYSTAL OSCILLATOR	CSS1614
CN701 (A,33,60) CONNECTOR	B4B-PH-K-S
CN702 (A,87,16) 15P SOCKET	XKP3078

RESISTORS

R 702 (A,43,55)	RS1/16S473J
R 703 (A,38,53)	RS1/16S0R0J
R 704 (A,35,53)	RS1/16S0R0J
R 705 (A,30,54)	RS1/16S470J
R 706 (A,30,52)	RS1/16S470J
R 707 (B,32,48)	RS1/16S470J
R 708 (B,22,51)	RS1/16S470J
R 709 (B,23,41)	RS1/16S0R0J
R 710 (B,35,42)	RS1/16S0R0J
R 711 (B,37,42)	RS1/16S472J
R 712 (A,27,43)	RS1/16S475J
R 717 (A,31,29)	RS1/16S473J
R 718 (A,36,25)	RS1/16S101J
R 719 (A,35,25)	RS1/16S101J
R 720 (A,35,21)	RS1/16S101J
R 724 (A,39,21)	RS1/16S472J
R 725 (A,44,25)	RS1/16S472J
R 726 (A,42,21)	RS1/16S472J
R 727 (A,33,21)	RS1/16S101J
R 729 (B,30,38)	RS1/16S103J
R 730 (B,39,33)	RS1/16S102J
R 734 (A,43,58)	RS1/16S0R0J
R 735 (A,32,55)	RS1/16S153J
R 736 (A,40,55)	RS1/16S153J
R 737 (A,34,55)	RS1/16S100J

CAPACITORS

C 701 (A,49,36)	CKSRYB104K16
C 702 (A,47,36)	CCSRCH471J50
C 703 (A,49,40)	CKSRYB104K16
C 704 (A,47,40)	CCSRCH471J50
C 705 (A,49,44)	CKSRYB104K16
C 706 (A,47,44)	CCSRCH471J50
C 707 (A,45,51)	CKSRYB104K16
C 708 (A,45,50)	CCSRCH471J50
C 709 (A,30,51)	CKSRYB104K16
C 710 (A,30,50)	CCSRCH471J50
C 711 (B,30,45)	CKSRYB104K16
C 712 (B,27,45)	CCSRCH471J50
C 713 (A,26,46)	CCSRCH120J50
C 714 (A,26,39)	CCSRCH120J50
C 715 (B,26,38)	CKSRYB331K50
C 716 (B,32,33)	CKSRYB104K16
C 717 (B,30,33)	CCSRCH471J50
C 719 (A,25,36)	CCSRCH471J50
C 720 (B,23,30)	CKSRYB104K16
C 721 (A,24,24)	CEQJ01M6R3

6. ADJUSTMENT

- There is no information to be shown in this chapter.

<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>
A	C 723 (A,37,27) C 724 (A,37,29) C 726 (A,34,27) C 727 (A,34,29) C 728 (A,41,28)	CCSRCH471J50 CKSRYB104K16 CKSRYB104K16 CCSRCH471J50 CKSRYB104K16
	C 729 (A,41,29) C 730 (B,60,34) C 731 (A,25,55) C 732 (B,29,55) C 733 (B,29,60)	CCSRCH471J50 CCSRCH471J50 CEJQ101M16 CKSRYB104K16 CKSRYB104K16
B	C 734 (B,41,32) C 735 (B,37,33) C 741 (A,92,19) C 742 (B,96,20) C 743 (A,96,32)	CKSRYB103K50 CKSRYB103K50 CEJQ101M16 CKSRYB104K16 CKSRYB105K6R3
	C 745 (B,64,35) C 746 (A,53,32) C 761 (B,71,46) C 762 (B,73,46) C 763 (B,67,46)	CKSRYB105K6R3 CKSQYB225K10 CKSRYB104K16 CCSRCH471J50 CCSRCH471J50
C	C 764 (B,65,46) C 766 (B,52,50) C 767 (B,80,44) C 768 (B,82,44) C 771 (A,62,60)	CCSRCH471J50 CCSRCH471J50 CKSRYB104K16 CCSRCH471J50 CKSQYB105K16
	C 773 (A,55,60) C 781 (A,44,17) C 782 (A,45,19) C 783 (A,49,19) C 784 (A,45,16)	CKSRYB104K16 CCSRCH471J50 CKSRYB104K16 CEJQ470M16 CKSRYB104K16
	C 786 (A,55,16) C 788 (A,42,18) C 789 (A,77,26) C 790 (A,79,25) C 791 (A,75,31)	CEJQ100M16 CKSRYB104K16 CKSRYB102K50 CKSRYB102K50 CEJQ100M16
D	C 792 (A,81,31) C 951 (A,58,27) C 952 (A,59,27) C 956 (A,70,34) C 957 (A,70,33)	CEJQ100M16 CCSRCH471J50 CKSRYB105K10 CKSQYB105K10 CCSRCH471J50
E		
F		

7. GENERAL INFORMATION

7.1 DIAGNOSIS

7.1.1 TEST MODE

A

■ Version indication

[Purpose]

The versions for various microcomputers and DSP firmware are displayed.

[How to enter/exit]

During Standby mode, simultaneously press and hold the STANDBY/ON and MULTI CH IN keys for 5 seconds to enter this mode. This mode is automatically exited when the indications of all versions have finished.

[Basic operations]

FL Display	Description of Version Indications	Duration (sec.)	Devices that can be considered generally normal, with the corresponding indications
POWER OFF ↓ M1. 000 F1. 000 ↓ D1. 000 H1. 000 ↓ f1. 000 s1. 000 ↓ USB 2006. 1. 9 ↓ Normal display	Mx.xxx : Main microcomputer Fx.xxx : Display microcomputer Dx.xxx : DSP microcomputer Hx.xxx : HDMI microcomputer fx.xxx : 1st DSP firmware sx.xxx : 2nd DSP firmware USB xxxx.xx.xx : USB firmware	5	Main microcomputer and display microcomputer DSP microcomputer and HDMI microcomputer 1st DSP firmware : Flash ROM (IC106) near the DSP IC 2nd DSP firmware : Flash ROM within the DSP IC (IC201) USB firmware : Flash ROM (IC762) near the USB IC (IC701)

[Notes]

- If the version indication becomes "##," a failure in communications between the corresponding microcomputers or a failure in the corresponding microcomputers is likely.
- In this submode, the user settings will not be cleared.
- If the USB firmware version indication becomes "##," return the unit to Normal mode, switch Function to USB, then reenter Test mode and check the USB firmware version. If the indication becomes "##" again, communication between the main microcomputer and the USB firmware is in failure.

B

C

D

E

F

A

■ Detected protection history

[Purpose]

The numbers of detections for various protection processes are displayed.

[How to enter/exit]

During Standby mode, simultaneously press and hold the DVR/VCR1 and ENTER keys for 5 seconds to enter this mode. This mode is automatically exited when all the indications have finished.

B

[Basic operations]

FL Display	Description of Indications	Duration (sec.)
POWER OFF ↓ DC : 000 ↓ OVER: 010 ↓ CON : 002 ↓ FAN : 002 ↓ TEMP: 255 ↓ Normal display	Number of DC detections Number of overload detections Number of detections of cord disconnection (DC and OL DET line) (simultaneous detections of DC and OVERLOAD) Number of detections of fan abnormalities Number of detections of abnormal temperature	3 3 3 3 3

C

[Description]

When the keys are pressed, the numbers of DC detections, overload detections, detections of connectors disconnection inside unit (It is detected by both DC and OVERLOAD detections.), detections of fan abnormalities, and detections of abnormal temperature are displayed for 3 seconds each, in that order.

The maximum value of each detections is 255.

E

F

■ Error indications when an abnormality in the amplifier system is detected

[Purpose]

An error message is displayed when an abnormality in the amplifier system is detected.

[Error Messages]

FL Display	Status	Duration (sec.)
AMP ERROR	When AMP DC is detected	Flashes 3 times.
FAN STOP	When stopping of the fan is detected	Flashes 3 times.
OVERHEAT	When a thermal shutdown (abnormal temperature), etc. is detected	Flashes 3 times.
12V TRG ERR KUXJ and KUXJCA types only	When the 12-V trigger circuit is short-circuited	Flashes
XM ANT ERR KUXJ and KUXJCA types only	The power supply of the XM antenna is abnormally	Flashes

[Description]

AMP ERROR : After a failure in the amplifier block or high DC output is detected, the shutdown process starts, then the power will be shut off. Then the MCACC LED will flash. The power cannot be turned on again. If you wish to turn on the unit after a shutdown activated by DC detection, enter Test mode, by proceeding with the steps described in "How to enter release mode" below.

FAN STOP : The fan does not function.

OVERHEAT : The temperature of the amplifier is abnormally high.

After a failure is detected, the shutdown process starts, then the power will be off. The power can be turned on again in Normal mode.

12V TRG ERR : The 12-V trigger output is short-circuited.
(KUXJ and KUXJCA types only)

XM ANT ERR : The power supply of the XM antenna is abnormally.
(KUXJ and KUXJCA types only)

[How to enter release mode]

Press and hold [DVR/VCR2] and [ENTER] keys on the front panel simultaneously for 5 seconds in standby mode.


7.1.2 PROTECTION CIRCUIT SPECIFICATION

A


● Protection Circuit Process List

Item	Purpose	Detection Method	Process	Warning Indication	Remarks
DC detection	To detect amplifier damage (defect status) A process to protect speakers (for protection of connected external devices)	Detects when the DC_PROTECT port becomes "L". (Pin 120 of IC101)	Turns muting on and speaker relay off, then turns off the power after 3 seconds. Then flashes MCACC indicator.	Flashing "AMP ERR" for 3 seconds.	Once detected and turned the power off, input a key never again. If the DC_DET port becomes "H" within 3 seconds, the unit returns to normal condition automatically.
AMP overload	To detect overloading (abnormal status) With low-load driving or a short circuit of the speaker terminals (for protection of the amplifier)	Detects when the OL_DET port becomes "L" (checks by interrupt). (Pin 28 of IC101)	Turns muting on and speaker relay off, and immediately turns off the power. Then flashes PHASE CONTROL indicator.	None	
Overheat detection	Self reset type protection feature by temperature-rise of heat sink	Detects when the TEMP2 port becomes "H". (Pin 44 of IC2301)	Turns muting on and speaker relay off, then turns off the power after 3 seconds.	Flashing "OVERHEAT" for 3 seconds.	If the TEMP2 port becomes "L" within 3 seconds, the unit returns to normal condition automatically.
12V trigger failure detection	To detect the shortcircuit of 12V trigger output (load more than 50mA) (for protection of the amplifier)	Detects when the 12VDET port becomes "H". (Pin 44 of IC2301)	Turns 12V trigger output to off.	Flashing "12V ERR"	Continue showing warning. Release the FL indication by switching the INPUT SEL or the turns the power off.

● DC Detection Circuit



● OL (Over Load) Detection Circuit



7.1.3 DSP TROUBLESHOOTING

A

Simplified diagnosis

Herein is described how to easily diagnose a defective part in the DSP Assy, only with operations of the main unit.


- If the sound is not output when Sound Delay is ON

If the sound is output without a problem when Sound Delay is OFF (0.0 fr) but an abnormality in the sound is detected when Sound Delay is ON (0.1 to 6.0 fr), it is most likely that SRAM (IC107) or DECODER IC (IC105) in the 1st DSP block is in failure.


Troubleshooting

- It is assumed that there is no loose connection or damage in the LCRs.
- : KUXJ and KUXJCA types only


Step 0: Preliminary confirmation



Step 2: Power supply





Step 1: Connections





D


E

F



A






Step 4: Audio Clock (Until Switch)


- When a sound is not out with the digital (COAX, OPT IN) signal input. → Go to Step 4-1
- When a sound is not out with the analog signal input. → Go to Step 4-2
- When a sound is not out with the HDMI. (It is assumption that failure diagnosis of HDMI assy completed)
When the source is DVD-A or PCM96k
→ Go to Step 4-3-1
When the source is compression or less than PCM48k
→ Go to Step 4-3-2
- When a sound is not out with the XM Radio.
→ Go to Step 4-4

Step 4-1: When a sound is not out with the digital (COAX, OPT IN) signal input


Check that changes by pulling out and inserting the digital input lines. (Function is able to change the assignment. Therefore it is not specified.)




Step 3: Operating Master Clock




A





B







Step 4-2: When a sound is not out with the analog signal input




A




B




C




D




E




F




Step 4-3-1: When a sound is not out with the HDMI (When the source is DVD-A or PCM96k)







Step 4-4: When a sound is not out with the XM Radio


Insert the XM Antenna and check it.





A




Step 5: Audio Clock (1st DSP from Switch)







Step 6: Audio Clock (2nd DSP from 1st DSP)




A




B




C




D




E







F




Step 7: Audio Clock (DAC output from 2nd DSP)











Step 8: 1st DSP





Step 9: 2nd DSP






DSP Block Diagram

Signal Block


• **■**: KUXJ and KUXJCA types only

→ : I2S MCLK
 → : I2S DATA (2ch)
 -→ : I2S DATA (compression or 2ch)
 -→ : I2S LRCK, MBCK
 -→ : Control/Memory bus line
 → : Analog audio signal
 → : SPDIF, operating clock



• Power Block and GND Map

• : KUXJ and KUXJCA types only



7.1.4 HDMI TROUBLESHOOTING

A

■ HDMI Simple Diagnosis


Please refer to the one point trouble shooting first before checking the flow chart on the next page.

HDMI

Symptom	Remedy
The HDMI indicator blinks continuously.	Check all the points below.
No picture or sound.	<ul style="list-style-type: none"> This receiver is HDCP-compatible. Check that the components you are connecting are also HDCP-compatible. If they are not, please connect them using the component, S-video or composite video jacks. Depending on the connected source component, it's possible that it will not work with this receiver (even if it is HDCP-compatible). In this case, connect using the component, S-video or composite video jacks between source and receiver. If the problem still persists when connecting your HDMI component directly to your monitor, please consult the component or monitor manual or contact the manufacturer for support.
No picture.	<ul style="list-style-type: none"> To see the on-screen display, you must also connect the receiver and TV with a composite, component, or S-video cable. Depending on the output settings of the source component, it may be outputting a video format that can't be displayed. Change the output settings of the source, or connect using the component, S-video or composite jacks.
No sound, or sound suddenly ceases.	<ul style="list-style-type: none"> Check that the HDMI AV setting is set to AMP/THROUGH. If the component is a DVI device, use a separate connection for the audio. Check the audio output settings of the source component.
Noisy or distorted picture.	<ul style="list-style-type: none"> If the problem still persists when connecting your HDMI component directly to your monitor, please consult the component or monitor manual or contact the manufacturer for support.


B

1. Causes for noncompletion of HDMI authentication between the source equipment and this unit (the HDMI indicator is unlit or flashes)



D

2. Causes for noncompletion of HDMI authentication between the monitor and this unit (no display or sound from the monitor)




E

■ HDMI Troubleshooting




- The parts marked like **V+5** in the following chart are located in "HDMI & DVC Assy Check Points".

Common section



Step 1-1: Connections



Step 1-2: Power supply










Step 1-3: Reset




HDMI section


Step 2-1: Power supply





A




B







A




B




C










D





E



F











**Step 2-6: VIDEO CLK, DATA****Step 2-7: AUDIO CLK, DATA**




A



Video converter section

Step 3-1: Power Supply




B








A




B




C



D



E




F

Diagnose the MAIN CONTROL
Assy or COMPONENT Assy.

■ HDMI & DVC Assy Check Points (Power supply section)


AK HDMI & DVC ASSY

SIDE B



A

■ HDMI & DVC Assy Check Points (Signal section)



B


C

D

E

F

■ Block Diagram of the HDMI & DVC Assy



7.1.5 USB MODULE

A

■ Description of Error Indications

FL Display	Error Content	Possible causes and actions to be taken
USB ERROR1 USB ERR1	Detection of overcurrent to a USB device	Overcurrent (500 mA or more) is consumed at the connected USB device. • Some USB devices, such as a portable HDD, need more current than that this unit supplies. (Use the AC adaptor for the connected USB device.) • The USB power is short-circuited.
USB ERROR2 USB ERR2	Detection of a medium not supported	A USB device that this unit does not support (other than the Mass Storage Class) is connected (such as a mouse, printer, or digital camera). • Connect a mass storage class USB device.
USB ERROR3 USB ERR3	Communication error with the system microcomputer	Communication between TCC760HC01-AG (IC701) and PEG116A (IC101) failed. • Defective connection (connectors) inside this unit • See STEP 3 of Troubleshooting.

B

■ Operations when overcurrent to a USB device is detected

(1) Overcurrent to a USB device is detected at the port for the microcomputer.

C

(2) The power supply to the USB device is stopped.

(3) Control of 5 V power is disabled at the port for the microcomputer.

■ (4) Change of indications on the FL display

Flashes for 2 sec.

V3 Low usage **USB:ERR1** In a case of an 8-digit FL display



Lights up after flashing for 2 sec.

USB:ERR1

In a case of an 8-digit FL display

D

(5) To supply power to the USB module again:

- Turn the power to the unit off then back on.
- Set the function setting to anything other than USB then back to USB.
- Press the USB play key on the remote control unit.

E

(6) After overcurrent is detected, if the USB play key is pressed while the error indication is displayed, power supply to the USB module is restored. If overcurrent is no longer detected, the indications shown below are displayed (normal indication):

USB:ERR1

In a case of an 8-digit FL display

F

In the above case, if overcurrent is detected again, the above procedures 1 through 4 are repeated.

■ In a case where a medium not supported is connected

(1) Change of indications on the FL displays

Flashes for 2 sec.

USB:ERR2

In a case of an 8-digit FL display



Lights up after flashing for 2 sec.

USB:ERR2

In a case of an 8-digit FL display


If overcurrent is detected before detection of a non-supported medium, the error indication "USB ERROR1" remains, as the power supply to the USB module is stopped.

On supported media

The formats of supported media that can be played back on this unit are MP3, WMA, and AAC.

Some media in MPEG4 can also be played back. As AAC derives from MPEG4 codec, playback of media in AAC codec of MPEG4 is possible.

■ Block Diagram of the USB Assy



Main parts

TCC760HC01-AG
16M FLASH ROM
64M SDRAM
LOAD SWITCH
2ch DAC


Purpose

: USB Host control decoder (MP3/WMA/MPEG-4AAC)
: Firmware is stored
: Temporary storage area of decoding music file
: Current limitation to USB device power
: D/A converter for analog output

A


■ USB Troubleshooting

Step 1: Connectors



B

Step 2: Power supply




C

D

E

F





**Step 3: Operation of USB Media control IC****Note:** Please confirm it with the USB memory connected for the content.


Fig. 1

	IC701	IC953 (5 V → 3 V)	CN702
XRST	pin 72	pin 3	pins 1,2
USCS	pin 121	pin 11	pins 12,13
HREQ	pin 122	pin 6	pins 4,5
USDAI	pin 118	pin 8	pins 9,10

Fig. 2


	IC701	IC951 (3 V → 5 V)	CN702
USCLK	pin 116	pins 4,5	pin 6
USDAO	pin 115	pins 9,10	pin 8
TREQ	pin 123	pins 12,13	pin 11

A




B

Fig. D+



X: 1 μsec/div, Y: 2 V/div



Fig. D-



X: 1 μsec/div, Y: 2 V/div

C

Step 4: Audio Out check



7.1.6 HOW TO UPDATE FIRMWARE

A

■ Explanation

With this unit, updating of the firmware of the USB module can be performed, using a USB memory stick. However, if the hardware of the flash memory that stores the firmware or the firmware itself has a problem, updating cannot be performed in a manner described below. In such a case, replacement of the flash memory is required.

B

■ Procedures

1. Turn the unit on then set the function setting to USB function.
2. Insert the USB memory stick that contains the "player.rom" file.*
3. "LOADING" is indicated on the FL display.
4. "UPDATE" is indicated on the FL display.
5. Wait until "FINISH" is indicated on the FL display.
6. Remove the USB memory stick then set the function setting to anything other than USB.
7. Return the function setting to USB function and wait for about 5 seconds in order to obtain the version data of the USB firmware.
8. Turn the unit off (Standby mode).
9. Check the version ("U_xxxxxx" is suffixed to the version indication).
If the version is not updated, the data for the new version may not have been obtained in Step 7. Repeat Step 7 and the subsequent steps.

C

Notes * :

- Never reinsert the USB memory stick that contains the "player.rom" file.
- In a rare case, depending on the type of USB memory stick, the above-mentioned updating procedures are not possible.
In such a case, try with other type of USB memory stick.

D

Importance:

- Never change the function setting or turn the power off during the process of Steps 3 through 5. If you do, loading of the firmware will fail, and updating procedures cannot be continued. In such a case, replacement of the flash memory is required.

E

F

7.1.7 HOW TO UPDATE THE FLASH ROMS FOR VARIOUS MICROCOMPUTERS

■ HDMI, MAIN and DSP microcomputer

A [Purpose]

Refer to this section when updating of a Flash ROM is required by the service information, etc.

B [Tools to be used]

- PC with a serial port
- RS-232C cable (cf. following note)
- Program for updating (ufu.exe)
- RS-232C I/F jig (GGF1348)
- Firmware ("mot" extension)
- 7-pin FFC (VDA1681)

C Note;

Please use a RS-232C cable properly as follows.

For updating HDMI microcomputer

--> straight cable (PC terminal-9pin male) [Connections A]

For updating MAIN microcomputer or DSP microcomputer


--> cross cable (PC terminal-25pin female) [Connections B]

D [Connections A]

(HDMI microcomputer)

E - HY and KU models -

Connect as indicated in the figure below:




F [Connections A]

(MAIN microcomputer)

(DSP microcomputer)

G - HY models -

Connect as indicated in the figure below:




H [Connections B]

(MAIN microcomputer)

(DSP microcomputer)

I - KU models -

Connect as indicated in the figure below:




[Note]


Do NOT disconnect the AC power cords of this unit nor the PC.

[Procedures]

1. Turn off the power to this unit by setting the main volume level to "--dB."
2. Connect the 232C I/F jigs and the PC, as indicated in "Connections."
3. (HDMI microcomputer) :
Simultaneously press and hold the ENTER and FM/AM keys for about 5 seconds.
(MAIN microcomputer) :
Simultaneously press and hold the ENTER and HDMI keys for about 5 seconds.
(DSP microcomputer) :
 - KU models
Simultaneously press and hold the ENTER and XM keys for about 5 seconds.
 - HY models
Simultaneously press and hold the ENTER and USB keys for about 5 seconds.
4. The unit is turned on, and "HDMI DOWNLOAD", "MAIN DOWNLOAD" or "DSPM DOWNLOAD" is displayed.
5. Double-click on "ufu.exe".
6. Check that "Full" is selected in MODE SELECT.
7. Select the firm ware file with "mot" extension.
8. Select the communication speed.
 - Basic speed: 19200
 - Data transfer speed: 57600
9. Click on "START" button.
10. (HDMI microcomputer) :
"Completed" is displayed for about 1 minutes in the "ufu.exe" window.
(MAIN microcomputer), (DSP microcomputer) :
"Completed" is displayed for about 3 minutes in the "ufu.exe" window.
11. Disconnect then reconnect the AC power cord of the unit. If the unit is not reset, retry from Step 2.
12. Reset the receiver.
Note: Note that all the data the receiver retains will be cleared.



Check that "Full" is selected in MODE SELECT.



Select the communication speed.

- Basic speed: 19200
- Data transfer speed: 57600

[Resetting the receiver]

1. Reset the receiver.

Note: Note that all the data the receiver retains will be cleared.

Resetting the receiver

Use this procedure to reset all the receiver's settings to the factory default. Use the front panel controls to do this.

1 Switch the receiver into standby.**2 While holding down the front panel AV PARAMETER button, press and hold STANDBY/ON for about three seconds.**

The display shows **RESET?**.

3 Press the front panel ENTER button.

The display shows **RESET OK?**.

4 Press SETUP to confirm.

OK appears in the display to indicate that the receiver has been reset to the factory default settings.

- Note that all settings will be saved, even if the receiver is unplugged.

7.1.8 HOW TO UPDATE THE DSP FLASH ROM BY PLAYING BACK CD

[Purpose]

By referring to this section, rewrite the DSP Flash ROM when required. Rewriting is instructed through service information, etc. By playing back a CD-R on which a DSP program is recorded, using a normal CD player, rewriting is possible.

[Tools to be used]

Please use DVD plaer based on MTK system (DV-270, 370, 373, 575K, 280, 380, 383, etc.) ,Mitsubishi system (DV-59AVi, 868AVi, S969AVi, 668AVi, etc.) or Fujitsu system (DV-343, 444, 545, etc.) DO NOT use DVD player based on ST system (DV-353, 454, 250, 400, 555K, 260, 363, 464, 466, 563, etc.) The factory confirmed that DVD players based on ST system cannot send the correct data to the VSX unit using the update disc.

You can check the base system of our DVD players on the firmware version list at PSN web (Niis)

- Coaxial cable or Optical cable
- Update disc(CD-R disc)
- Headphone

[Connections]

Connect this unit and a player, as shown in the figure below.



[Preparations]

Burn the provided DSP program to a CD-R, using commercially available software for writing. It is necessary to select the writing format, "For music player", not "for PC data" format .

Note:

Depending on the writing format of the commercially available software to be used, data on a CD-R may not be used for DSP program rewriting. If the HDMI indicator does not flash when the disc is played back in the way indicated in Step 5 below, data burned on the CD-R are not appropriate. **To know whether the writing software is OK or not, play back the WMA9Pro stream stored on the last track of the disc. (Refer to "Troubleshooting" on next section.)**

If audio data are normally played back, the disc and the player can be used for updating. If audio data are not correctly played back (with noise, etc.), that writing software is not appropriate. Burn the DSP program on a CD-R disc, using other writing software.

[Note]

- **Do NOT disconnect the AC cords of this unit nor the CD/DVD player while rewriting is in progress.**
- **The "OK" indication displayed after updating means the checksum on the flash ROM is OK.**
If the "OK" indication is not displayed, updating has not been completed.

Note that confirmation with audio check or version check is insufficient for checking if updating has been completed.

If you set the unit to STANDBY OFF without confirming of "OK" indication on the FL display, be sure to perform the updating procedures again.

[Procedures]

1. Reset the receiver.

Note: Note that all the data the receiver retains will be cleared.

Resetting the system

Use this procedure to reset all the receiver's settings to the factory default. Use the front panel controls to do this.

1 Switch the receiver into standby.

2 While holding down the front panel TONE button, press and hold STANDBY/ON for about three seconds.
The display shows **RESET?**

3 Press the front panel ENTER button.

The display shows **RESET OK?**

4 Press SYSTEM SETUP to confirm.

OK appears in the display to indicate that the receiver has been reset to the factory default settings.

- Note that all settings will be saved, even if the receiver is unplugged.

[Procedures]

2. Check the versions of the DSP and microcomputer.
Check the versions by referring to "Version indication" in "7.1.1 TEST MODE."
3. Connect a CD or DVD player.
 - (1) Connect the CD or DVD player to be used for updating to any digital input connector of this unit.
 - (2) With the INPUT SELECTOR, select the input being used.
4. Check if the digital signal is locked (received).
 - (1) Play back a stream for updating with the player.
 - (2) Set the receiver to normal setting, "Signal Select" to Auto, then check on the Signal Select indicator whether the input is set to Auto and Digital.
5. Start up this unit in writing mode.
 - (1) Relocate the CD playback starting point to the beginning (time: 0:00) of the track No and pause playback.
 - (2) Set the volume of the receiver to -∞ dB and set the receiver to STANDBY OFF.
 - (3) Simultaneously press and hold the ENTER and iPOD keys until "DSPF DOWNLOAD" is displayed on the FL display. The unit enters writing mode.
6. Play back the track on CD disc.
 - (1) Release Pause mode of the player and play back the track where the DSP program stream signal to be burned is stored.
 - (2) After 5-10 seconds, the HDMI indicator starts flashing. Be sure to check that it is flashing.
 - (3) Flashing indicates that a correct stream is being received and that updating is in progress.
- Note:** Do NOT turn off the unit while the HDMI indicator is flashing. If the unit is turned off, be sure to go back to Step 5. (As the Flash ROM goes into unusual status if the power is off during rewriting, the unit may not start properly.) Even in such a case, you can restore the unit by performing Steps 5 to 8.
7. Wait until rewriting is completed.
 - (1) Basically, wait until "OK" is displayed on the FL display. It takes about 2 minutes for updating.
 - (2) After confirming that "OK" is displayed, stop or pause the player then after 5 seconds set the player to STANDBY OFF.
8. Check the version of the program after updating.
 - (1) Check the version by simultaneously pressing and holding the STANDBY/ON and MULTI CH IN keys.
 - (2) For confirmation, check basic operations.

A

B

C

D

E

F

7.1.9 DISASSEMBLY

Note 1: Even if the unit shown in the photos and illustrations in this manual may differ from your product, the procedures described here are common.

Note 2: For performing the diagnosis shown below, the following jigs for service is required:

- 11P board to board extension jig cable (GGD1482)
 - 13P board to board extension jig cable (GGD1483)
 - 15P board to board extension jig cable (GGD1484)
 - 21P board to board extension jig cable (GGD1485)



1. Before the Power Amp Block is removed

Before the Power Amp Block is removed, discharge C3257 and C3258 on the TRANS 2-1 Assy. as indicated below.


If you don't, the IC protectors (IC3351 and IC3352) on the VH TR Assy may be open, and DC voltage may be generated at the power amplifier output, which will result in "AMP FBB".

[Procedure]

- ① Unplug the AC power cord.
 - ② Discharge C3257 and C3258 on the TRANS 2-1 Assy.
Note: For discharging, use a load of 100Ω , 3W or more, to protect the IC protectors. Do NOT discharge instantly by short-circuiting.
 - ③ Check that the voltage between the electrodes of each C3257 and C3258 is 1V or less.
 - ④ Reassembling the Power Amp Block.



2. PCB Location




A

3. Disassembly


1 Bonnet

- ① Remove the eight screws.



● Rear view

- ② Remove the eight screws.
③ Remove the bonnet.







2 Power Amp Block

Caution:

Before removing the Power Amp Block, discharge C3257 and C3258 on the TRANS 2-1 Assy.

Refer to "1. Before the Power Amp Block is removed".


- ① Remove the seven screws.
- ② Disconnect the three flexible cables and the one connector.
- ③ Disconnect the one jumper wire.
- ④ Disconnect the six connectors.
- ⑤ Remove the power amp block.



3 Replacing the Power Transistor


● POWER PROTECT Assy

- ① Remove the one nylon rivet.
- ② Disconnect the one connector. (VSX-2016AV only)
- ③ Remove the POWER PROTECT Assy by removing the two connectors.




● HS Angle 2016

- ① Remove the four screws.
- ② Remove the HS angle 2016.




● POWER AMP IN Assy

- ① Remove the one nyrond rivet.
- ② Remove the POWER AMP IN Assy by removing the four connectors.




● HS Angle 2016

- ① Remove the four screws.
- ② Release the clamer.
- ③ Remove the HS angle 2016.



● Replacing the Power Transistor




Replace




A 4 Replacing the AUDIO IN Assy

• Rear Panel


- ① Disconnect the one connector.
- ② Remove the four cushion circle 14B.
- ③ Remove the four screws.
- ④ Remove the one screw.
(KU model: Remove the three screws.)
- ⑤ Remove the three screws.



• Rear view




- ⑥ Remove the one screw.
- ⑦ Remove the three screws.
- ⑧ Remove the 32 screws.
(KU model: Remove the 34 screws.)
- ⑨ Remove the rear panel.




• FM/AM TUNER Unit

- ① Remove the FM/AM TUNER Unit by removing the one flexible cable.




• PCB Assys

- ① Disconnect cables, connectors, as required.
- ② First remove the BRIDGE 2 Assy, then remove the COMPOSITE, S-VIDEO, COMPONENT and VIDEO CONNECT Assys.




● DSP Shield Section

- ① Remove the one screw.
- ② Remove the two screws.
- ③ Disconnect cables, connectors, as required.
- ④ Remove the DSP shield 2016 with PCB Assemblies..



● AUDIO IN Assy


- ① Remove the two screws.
- ② Remove the five screws.
- ③ Release the locking card spacer.
- ④ Disconnect cables, connectors, as required.
- ⑤ Remove the AUDIO IN Assy.



4. Diagnosis


1 Preparations

- ① Remove the bonnet.
- ② Remove the rear panel.
- ① Remove the BRIDGE 2 Assy.
- ② Remove the VIDEO CONNECT Assy.
- ③ Remove the COMPONENT, S-VIDEO, COMPOSITE Assys.



- ④ Connect the earth points to chassis as follows.

- a Pin jack (GND) on the DSP Assy ↔ chassis
- b Pin jack (L side GND) on the AUDIO IN Assy ↔ chassis
- c Pin jack (Yellow GND) on the COMPOSITE Assy ↔ chassis
- d Speaker terminal (L side black) ↔ chassis



A


2 Diagnosis

● COMPONENT Assy

Jig cable

- 11P board to board extension jig cable (GGD1482)
- 13P board to board extension jig cable (GGD1483) ×2

- ① Connect the three extension jig cables.
- ② Reassembling the S-VIDEO and COMPOSITE Assys.
- ③ Reassembling the VIDEO CONNECT Assy.
- ④ Connect the one flexible cable.
- ⑤ Insert the insulation sheet.
- ⑥ Arrange the unit as shown in the photo below.



↓


Diagnosis

● S-VIDEO Assy

Jig cable

- 11P board to board extension jig cable (GGD1482)
- 13P board to board extension jig cable (GGD1483)
- 15P board to board extension jig cable (GGD1484)

- ① Connect the three extension jig cables.
- ② Reassembling the COMPONENT and COMPOSITE Assys.
- ③ Reassembling the BRIDGE 2 and VIDEO CONNECT Assys.
- ④ Connect the one flexible cable.



↓


Diagnosis

● COMPOSITE Assy

Jig cable

- 11P board to board extension jig cable (GGD1482)
- 13P board to board extension jig cable (GGD1483)
- 21P board to board extension jig cable (GGD1485)

- ① Connect the three extension jig cables.
- ② Reassembling the COMPONENT and S-VIDEO Assys.
- ③ Reassembling the BRIDGE 2 and VIDEO CONNECT Assys.
- ④ Connect the one flexible cable.



Diagnosis

7.2 PARTS

7.2.1 IC

A

- The information shown in the list is basic information and may not correspond exactly to that shown in the schematic diagrams.

- **List of IC**


M61545FP, LA7109, PDC132A, PEG118A, PEG116A, TCC760HC01-AG, AAT4618IGV-0.5-1

■ ■ M61545FP (COMPOSITE ASSY : IC1151)

- 2 ch Electronic Volume IC

- **Block Diagram**

B



C

- **Pin Function**

No.	Pin Name	I/O	Pin Function
1	VIN1	I	1-ch input
2	NC	-	Non connection
3	VOUT1	O	1-ch output
4	NC	-	Non connection
5	GND	-	Ground
6	NC	-	Non connection
7	DATA	I	Control data input Inputs data in synchronization with clock.
8	CLK	I	Clock input pin for transferring serial data
9	NC	-	Non connection
10	VCC	-	Power supply
11	VOUT2	O	2-ch output
12	VIN2	I	2-ch input
13	NC	-	Non connection
14	Cref	I	Vref filter


E

F

■ LA7109 (COMPOSITE ASSY : IC1004), (S-VIDEO ASSY : IC1205)

- Video Amp IC

● Block Diagram



● Pin Function

No.	Pin Name	I/O	Pin Function	No.	Pin Name	I/O	Pin Function
1	VIN1+	I	Input pin	19	-VCC3	-	-VCC power supply
2	NFB1	I	Negative feedback pin of amp	20	MUTE3	I	Changeover pin of mute ability
3	MUTE1	I	Changeover pin of mute ability	21	VOUT6	O	Output pin
4	VIN2+	I	Input pin	22	DR CTL1	I	Changeover pin of drive ability
5	NFB2	I	Negative feedback pin of amp	23	VOUT5	O	Output pin
6	-VCC1	-	-VCC power supply	24	GND	-	Ground
7	VIN3+	I	Input pin	25	VOUT4	O	Output pin
8	NFB3	I	Negative feedback pin of amp	26	+VCC2	-	+VCC power supply
9	N.C.	-	Recommend connecting to -Vcc	27	N.C.	-	Recommend connecting to -Vcc
10	N.C.	-	Recommend connecting to -Vcc	28	N.C.	-	Recommend connecting to -Vcc
11	VIN4+	I	Input pin	29	-VCC4	-	-VCC power supply
12	NFB4	I	Negative feedback pin of amp	30	MUTE4	I	Changeover pin of mute ability
13	MUTE2	I	Changeover pin of mute ability	31	VOUT3	O	Output pin
14	VIN5+	I	Input pin	32	DR CTL2	I	Changeover pin of drive ability
15	NFB5	I	Negative feedback pin of amp	33	VOUT2	O	Output pin
16	-VCC2	-	-VCC power supply	34	GND	-	Ground
17	VIN6+	I	Input pin	35	VOUT1	O	Output pin
18	NFB6	I	Negative feedback pin of amp	36	+VCC1	-	+VCC power supply

A

PDC132A (COMPOSITE ASSY : IC1006)


- Character Generator IC

• Pin Arrangement (Top view)

VSS1	1	24	VDD1
XtalIN	2	23	RST
XtalOUT	3	22	CTRL3
CTRL1	4	21	CTRL2
BLANK	5	20	SEPIN
OSCIN	6	19	SEPOUT
OSCOUT	7	18	SEPC
CHARA	8	17	SYNIN
CS	9	16	VDD1
SCLK	10	15	CVIN
SIN	11	14	NC
VDD2	12	13	CVOUT

B

• Block Diagram



F

● Pin Function

No.	Pin Name	I/O	Pin Function
1	VSS1	–	Digital ground
2	XtalIN	I	Crystal oscillator connection (2fsc or 4fsc)
3	XtalOUT	O	Crystal oscillator connection (2fsc or 4fsc)
4	CTRL1	I	Crystal oscillator input switching L: crystal oscillator mode, H: external clock mode
5	BLANK	O	Blank signal output Outputs a composite sync signal when MODO is high.
6	OSCIN	I	Connections for the coil and capacitor that form the oscillator that generates the character output dot clock.
7	OSCOUT	O	Connections for the coil and capacitor that form the oscillator that generates the character output dot clock.
8	CHARA	I	Character signal output
9	CS	I	Enable input for serial data input Serial data input is enabled when low. A pull-up resistor is built in (hysteresis input).
10	SCLK	I	Clock input for serial data I/O A pull-up resistor is built in (hysteresis input).
11	SIN	I	Serial data input A pull-up resistor is built in (hysteresis input).
12	VDD2	–	Analog power supply
13	CVOUT	O	Composite video signal output
14	NC	–	Must be either connected to ground or left open.
15	CVIN	I	Composite video signal input
16	VDD1	–	+5 V digital power supply
17	SYNIN	I	Video signal input for the built-in sync separator circuit
18	SEPC	O	Built-in sync separator circuit bias voltage monitor pin
19	SEPOUT	O	Built-in sync separator circuit composite sync signal output
20	SEPIN	I	Inputs a vertical synchronization signal created by integrating the SEPOUT pin output signal.
21	CTRL2	I	The setting indicated by this pin takes priority in switching between the NTSC, PAL, PAL-M and PAL-N formats. A low level selects NTSC after a reset. The microprocessor command NTSC, PAL, PAL-M, or PAL-N setting is valid. High = PAL-M format.
22	CTRL3	I	Controls whether or not the VSYNC signal is input to the SEPIN input. Low = VSYNC input, high = VSYNC not input.
23	RST	I	System reset input
24	VDD1	–	+5 V digital power supply


A

■ PEG118A (HDMI & DVC ASSY : IC501)

- HDMI Microcomputer

● Pin Arrangement (Top view)

B



F

● Pin Function

No.	Mark	Pin Name	I/O	Pin Function
1	P96/ANEX1/SOUT4	HD_DO	O	Main controller communication DATA OUT
2	P95/ANEX0/CLK4	HD_SCK	I	Main controller communication CLOCK IN
3	P94/DA1/TB4IN	VCRST	O	ADV7401/ADV7172 RESET, (L: RESET)
4	P93/DA0/TB3IN	/1080P	O	TMDS amplitude switch (L:1080p, H: excepting 1080p)
5	P92/TB2IN/SOUT3	NC	O	OPEN
6	P91/TB1IN/SIN3	NC	O	OPEN
7	P90/TB0IN/CLK3	NC	O	OPEN
8	BYTE	BYTE	-	GND
9	CNVss	CNVSS	-	GND
10	P87/XCIN	NC	O	OPEN
11	P86/XCOUT	NC	O	OPEN
12	RESET	XRESET	I	Main controller communication RESET input (L: RESET)
13	XOUT	XOUT	O	XTAL
14	VSS	VSS	-	GND
15	XIN	XIN	I	XTAL
16	VCC	VCC	-	Power supply 3.3V
17	P85/NMI	NMI	I	Pull up with Vcc
18	P84/INT2	TXINT	I	Sil9030 interrupt
19	P83/INT1	RXINT	I	Sil9033 interrupt
20	P82/INT0	HD_REQI	I	Main controller communication REQ IN
21	P81/TA4IN/U	VSYNC	I	Sil9033 VSYNC input
22	P80/TA4OUT/U	RXRST	O	Sil9033 RESET (L: RESET)
23	P77/TA3IN	RXMUTE	I	Sil9033 MUTE IN
24	P76/TA3OUT	MCK_OFF	O	AUDIO MCK OFF (not used)
25	P75/TA2IN/W	TXRST	O	Sil9030 RESET (L: RESET)
26	P74/TA2OUT/W	HD_REQO	O	Main controller communication REQ OUT
27	P73/CTS2/RTS2/TA1IN/V	VCINT(NC)	O	ADV7401 interrupt (not used)
28	P72/CLK2/TA1OUT/V	MUTE	O	AUDIO MUTE (H: MUTE)
29	P71/RxD2/SCL/TA0IN/TB5IN	VC_SCL	O	I2C SCL(ADV7401/ADV7172)
30	P70/TxD2/SDA/TA0OUT	VC_SDA	O	I2C SDA(ADV7401/ADV7172)
31	P67/TxD1/SDA1	CSDA	O	I2C SDA(Sil9033/Sil9030)
32	P66/RxD1/SCL1	CSCL	O	I2C SCL(Sil9033/Sil9030)
33	P65/CLK1	CLK1(NC)	O	OPEN
34	P64/CTS1/RTS1/CTS0/CLKS1	CTS1(NC)	O	OPEN
35	P63/TxD0/SDA0	TXD0	O	RS232C TXD
36	P62/RxD0/SCL0	RXD0	I	RS232C RXD
37	P61/CLK0	NC	O	OPEN
38	P60/CTS0/RTS0	RTS0	O	RS232C RTS
39	P57/RDY/CLKOUT	RDY	I	Pull up with Vcc
40	P56/ALE	ALE	O	OPEN
41	P55/HOLD	HOLD	I	Pull up with Vcc
42	P54/HLDA	HLDA	O	OPEN
43	P53/BCLK	BCLK	O	Pull up with Vcc
44	P52/RD	RD	O	FLASH ROM I/F RD
45	P51/WRH/BHE	BHE	O	OPEN
46	P50/WRL/WR	WR	O	FLASH ROM I/F WR
47	P47/CS3	PUSEL	O	DDC communication pull-up resistor switch (L: Normal operation)
48	P46/CS2	NC	O	OPEN


A

No.	Mark	Pin Name	I/O	Pin Function
49	P45/CS1	NC	O	OPEN
50	P44/CS0	CS0	O	FLASH ROM I/F CS
51	P43/A19	NC	O	OPEN
52	P42/A18	A18	O	FLASH ROM I/F
53	P41/A17	A17	O	FLASH ROM I/F
54	P40/A16	A16	O	FLASH ROM I/F
55	P37/A15	A15	O	FLASH ROM I/F
56	P36/A14	A14	O	FLASH ROM I/F
57	P35/A13	A13	O	FLASH ROM I/F
58	P34/A12	A12	O	FLASH ROM I/F
59	P33/A11	A11	O	FLASH ROM I/F
60	P32/A10	A10	O	FLASH ROM I/F
61	P31/A9	A9	O	FLASH ROM I/F
62	Vcc	VCC	-	Power supply 3.3V
63	P30/A8(/⑧/D7)	A8	O	FLASH ROM I/F
64	Vss	GND	-	GND
65	P27/A7(/D7/D6)	A7	O	FLASH ROM I/F
66	P26/A6(/D6/D5)	A6	O	FLASH ROM I/F
67	P25/A5(/D5/D4)	A5	O	FLASH ROM I/F
68	P24/A4(/D4/D3)	A4	O	FLASH ROM I/F
69	P23/A3(/D3/D2)	A3	O	FLASH ROM I/F
70	P22/A2(/D2/D1)	A2	O	FLASH ROM I/F
71	P21/A1(/D1/D0)	A1	O	FLASH ROM I/F
72	P20/A0(/D0/⑨)	NC	O	OPEN
73	P17/D15/INT5	D15	I	FLASH ROM I/F
74	P16/D14/INT4	D14	I	FLASH ROM I/F
75	P15/D13/INT3	D13	I	FLASH ROM I/F
76	P14/D12	D12	I	FLASH ROM I/F
77	P13/D11	D11	I	FLASH ROM I/F
78	P12/D10	D10	I	FLASH ROM I/F
79	P11/D9	D9	I	FLASH ROM I/F
80	P10/D8	D8	I	FLASH ROM I/F
81	P07/D7	D7	I	FLASH ROM I/F
82	P06/D6	D6	I	FLASH ROM I/F
83	P05/D5	D5	I	FLASH ROM I/F
84	P04/D4	D4	I	FLASH ROM I/F
85	P03/D3	D3	I	FLASH ROM I/F
86	P02/D2	D2	I	FLASH ROM I/F
87	P01/D1	D1	I	FLASH ROM I/F
88	P00/D0	D0	I	FLASH ROM I/F
89	P107/AN7/KI3	I2S_OFF	O	Audio data control I2S data OFF (H: OFF)
90	P106/AN6/KI2	SCDT	I	Sil9033 SCDT input
91	P105/AN5/KI1	VCOE	O	Video data select (L: HDMI, H: Analog VIDEO)
92	P104/AN4/KI0	HPDET0	O	Hot Plug Detect control (IN1)
93	P103/AN3	HPDET1	O	Hot Plug Detect control (IN2)
94	P102/AN2	WP0	O	EDID1 E2PROM WP control (L: Normal operation, H: Writing)
95	P101/AN1	WP1	O	EDID2 E2PROM WP control (L: Normal operation, H: Writing)
96	AVSS	AVSS	-	GND
97	P100/AN0	DSD_OFF	O	Audio data control DSD data OFF (H: OFF)
98	VREF	VREF	-	Reference voltage 3.3V
99	AVcc	AVCC	-	Power supply 3.3V
100	P97/ADTRG/SIN4	HD_DI	I	Main controller communication (DATA IN)

■ PEG116A (MAIN CONTROL ASSY : IC101)

- Main Microcomputer

● Pin Arrangement (Top view)



A

● Pin Function

No.	Mark	Pin Name	I/O	Pin Function
1	VREF	Vref(5V)	—	Reference voltage (5V)
2	AVcc	Avcc(5V)	—	Power supply (5V)
3	P97/ADTRG/SIN4	HDMI / DSP DO	I	Data input for HDMI/DSP microcomputer
4	P96/ANEX1/SOUT4	HDMI / DSP DI	O/L	Data output for HDMI/DSP microcomputer
5	P95/ANEX0/CLK4	HDMI / DSP CLK	O/L	Clock output for HDMI/DSP microcomputer
B	P94/DA1/TB4IN	HDMI RDY	I	Ready input for HDMI microcomputer
7	P93/DA0/TB3IN	HDMI RST	O/L	Reset output for HDMI microcomputer
8	P92/TB2IN/SOUT3	DISP DI	O/L	Communication data output of the display microcomputer
9	P91/TB1IN/SIN3	DISP DO	I	Communication data input of the display microcomputer
10	P90/TB0IN/CLK3	DISP CLK	O/L	Communication clock output of the display microcomputer
11	P141	SB MUTE	O/L	MUTE for SB ch (L: MUTE)
12	P140	XFLAG (USB)	I	Error signal from the USB module
13	BYTE	L: 16 bit	—	Bus width setting of the external flash L= 16bit, H= 8bit
14	CNVss	Vss(EXP mode)	—	Shift from the single chip mode to the memory expansion mode Set to VCC at internal FLASH rewriting.
C	P87/XCIN	DSP RDY	I	Microcomputer communication Request input to the main microcomputer
16	P86/XCOUT	DSP RST	O/L	DSP controller communication
17	RESET	RESET	I	Reset input from the main microcomputer
18	XOUT	Xout	O	Connect a ceramic resonator (15.7 MHz)
19	Vss	Vss(GND)	—	Ground
20	XIN	Xin	I	Connect a ceramic resonator
21	Vcc1	Vcc1(5V)	—	Power supply Vcc1(5V)
22	P85/NMI	NMI	I	47k pull-up
23	P84/INT2	WAKEUP(AC PULSE)	(I)	AC pulse input
24	P83/INT1	TREQ(USB)	I	Communication request signal from the USB module
25	P82/INT0	1W WAKEUP	I	Display microcomputer communication
D	P81/TA4IN/U	RDS CK/XM LOW SPEED	I	(RDS model) CLOCK IN/(XM) Low speed Data Part
27	P80/TA4OUT/U	RDS DT/LINK ACTIVE(XM)	I	(RDS model) DATA IN/(XM) LINK active indicator
28	P77/TA3IN	OL DET	I	OVERLOAD detection (L: abnormal)
29	P76/TA3OUT	POFFINFO	O/L	Notify power off to DSP controller (an outlet comes off)
30	P75/TA2IN/W	DISP REQ	O/L	Display microcomputer communication
31	P74/TA2OUT/W	DISP RDY	I	Display microcomputer communication
32	P73/CTS2/RTS2/TA1IN/V	DISP RST	O/H	Display microcomputer communication
33	P72/CLK2/TA1OUT/V	USBCLK	I	Communication clock input with the USB module
34	P71/RxD2/SCL2/TA0IN/TB5IN	USBDO/XM Rx	I	Communication data input with the USB module/XM communication data input
35	P70/TxD2/SDA2/TA0OUT	USBDI/XM Tx	O/L	Communication data output with the USB module/XM communication data output
E	P67/TxD1/SDA1	232C TxD	O/L	RS-232C open
37	Vcc1	Vcc1(5V)	—	Power supply (5V)
38	P66/RxD1/SCL1	232C RxD	I	RS-232C open
39	Vss	Vss(GND)	—	Ground
40	P65/CLK1	JIG CLK	—	RS-232C open
41	P64/CTS1/RTS1/CTS0/CLKS1	232C CTS	O/L	RS-232C
42	P63/TxD0/SDA0	Tx(SR+/iPOD)	O/L	SR+/iPod communication data output
43	P62/RxD0/SCL0	Rx(SR+/iPOD)	I	SR+/iPod communication data input
F	P61/CLK0	LOW COMSUMPTION	O/L	AMUTE power ON/OFF (ON: H)
45	P60/CTS0/RTS0	S-DET	I	S-VIDEO detection (H)
46	P137	WAKE_UPB(XM)	I	For XMDT communication
47	P136	USB HREQ	O/L	Communication enabling signal to the USB module
48	P135	EXP ST	O/L	Expansion IC communication

No.	Mark	Pin Name	I/O	Pin Function
49	P134	EXP OE	O/L	Expansion IC communication
50	P57/RDY/CLKOUT	Vcc(5V)	I	Power supply Vcc (5V)
51	P56/ALE	OPEN	O/L	NC (open at memory expansion mode)
52	P55/HOLD	Vcc(5V)	I	Power supply Vcc (5V)
53	P54/HLDA	OPEN	O/L	NC (open at memory expansion mode)
54	P133	OSD RST	O/L	OSD communication
55	P132	OSD CS	O/L	OSD communication
56	P131	OSD DT/EXP DT	O/L	OSD communication and expansion IC communication
57	P130	OSD CLK/EXP CLK	O/L	OSD communication and expansion IC communication
58	P53/BCLK	OPEN	O/L	NC (open at memory expansion mode)
59	P52/RD	RD	O/L	FLASH MEMORY I/F READ
60	P51/WRH/BHE	OPEN	O/L	FLASH MEMORY I/F WRITE
61	P50/WRL/WR	WR	O/L	FLASH MEMORY I/F WRITE
62	P127	PREGAIN	O/L	PREGAIN not used
63	P126	UART SW2	O/L	L: Select SR+ path, H: Select iPod or XM path
64	P125	UART SW1	O/L	L: Select DSP microcomputer path, H: Select HDMI microcomputer path
65	P47/CS3	EVOL DT2	O/L	Electronic VOL & function IC communication
66	P46/CS2	CS2	O/L	Electronic VOL & function IC communication
67	P45/CS1	EVOL CK	O/L	Electronic VOL & function IC communication
68	P44/CS0	CS0	O/L	FLASH MEMORY CE control
69	P43/A19	OPEN	O/L	FLASH MEMORY communication address output
70	P42/A18	A18	O/L	FLASH MEMORY communication address output
71	P41/A17	A17	O/L	FLASH MEMORY communication address output
72	P40/A16	A16	O/L	FLASH MEMORY communication address output
73	P37/A15	A15	O/L	FLASH MEMORY communication address output
74	P36/A14	A14	O/L	FLASH MEMORY communication address output
75	P35/A13	A13	O/L	FLASH MEMORY communication address output
76	P34/A12	A12	O/L	FLASH MEMORY communication address output
77	P33/A11	A11	O/L	FLASH MEMORY communication address output
78	P32/A10	A10	O/L	FLASH MEMORY communication address output
79	P31/A9	A9	O/L	FLASH MEMORY communication address output
80	P124	RY C/R	O/L	Center, surround SP relay (ON: H)
81	P123	RY B	O/L	SP-B relay (ON: H)
82	P122	RY A	O/L	SP-A relay (ON: H)
83	P121	RY HP	O/L	HP relay (ON: H)
84	P120	AC1 RELAY	O/L	AC relay (ON: H)
85	Vcc2	Vcc2(5V)	-	Power supply Vcc1 (5V)
86	P30/A8/(23)/D7)	A8	O/L	FLASH MEMORY communication address output
87	Vss	Vss(GND)	-	Ground Vss(GND)
88	P27/AN27/A7/(D7/D6)	A7	O/L	FLASH MEMORY communication address output
89	P26/AN26/A6/(D6/D5)	A6	O/L	FLASH MEMORY communication address output
90	P25/AN25/A5/(D5/D4)	A5	O/L	FLASH MEMORY communication address output
91	P24/AN24/A4/(D4/D3)	A4	O/L	FLASH MEMORY communication address output
92	P23/AN23/A3/(D3/D2)	A3	O/L	FLASH MEMORY communication address output
93	P22/AN22/A2/(D2/D1)	A2	O/L	FLASH MEMORY communication address output
94	P21/AN21/A1/(D1/D0)	A1	O/L	FLASH MEMORY communication address output
95	P20/AN20/A0/(D0/23)	OPEN	O/L	FLASH MEMORY communication address output
96	P17/D15/INT5	D15	O/L	FLASH MEMORY communication data input/output

A

No.	Mark	Pin Name	I/O	Pin Function
97	P16/D14/INT4	D14	O/L	FLASH MEMORY communication data input/output
98	P15/D13/INT3	D13	O/L	FLASH MEMORY communication data input/output
99	P14/D12	D12	O/L	FLASH MEMORY communication data input/output
100	P13/D11	D11	O/L	FLASH MEMORY communication data input/output
101	P12/D10	D10	O/L	FLASH MEMORY communication data input/output
B	102	P11/D9	D9	O/L FLASH MEMORY communication data input/output
	103	P10/D8	D8	O/L FLASH MEMORY communication data input/output
	104	P07/AN07/D7	D7	O/L FLASH MEMORY communication data input/output
	105	P06/AN06/D6	D6	O/L FLASH MEMORY communication data input/output
	106	P05/AN05/D5	D5	O/L FLASH MEMORY communication data input/output
	107	P04/AN04/D4	D4	O/L FLASH MEMORY communication data input/output
	108	P03/AN03/D3	D3	O/L FLASH MEMORY communication data input/output
	109	P02/AN02/D2	D2	O/L FLASH MEMORY communication data input/output
C	110	P01/AN01/D1	D1	O/L FLASH MEMORY communication data input/output
	111	P00/AN00/D0	D0	O/L FLASH MEMORY communication data input/output
	112	P117	NC	O/L NC
	113	P116	MRVOL DT	O/L EVOL communication data for SUBROOM
	114	P115	TUNER DI	O/L TUNER module communication
	115	P114	TUNER CLK	O/L TUNER module communication
	116	P113	TUNER DO	I TUNER module communication
	117	P112	TUNER CE	O/L TUNER module communication
	118	P111	AMUTE	O/L AMUTE (L: MUTE, H: MUTE OFF)
	119	P110	MRMUTE	O/L MR MUTE (L: MUTE, H: MUTE OFF)
D	120	P107/AN7/KI3	DC PROTECT	I DC abnormality detection (L detection)
	121	P106/AN6/KI2	FAN STOP	I FAN STOP detection (L at FAN rotation: abnormality)
	122	P105/AN5/KI1	TEMP1	I Temperature detection (H: high temperature)
	123	P104/AN4/KI0	XM/ERR	I XM Error
	124	P103/AN3	WATT IN	I (A/D) Voltage detection for limitter control
	125	P102/AN2	SIMUKE2	I (A/D) Destination distinction
	126	P101/AN1	SIMUKE1	I (A/D) Destination distinction
	127	Avss	Avss(GND)	- Ground Vss (GND)
	128	P100/AN0	HDMI/ DSP REQ	O/L REQ output for HDMI/DSP microcomputer


E

F


■ TCC760HC01-AG (USB ASSY : IC701)

- USB Media Control IC

● Pin Arrangement (Top view)



● Block Diagram



A

● Pin Functions

No.	Pin Name	I/O	Pin Function
1	VSSIO	—	Digital ground for I/O
2	XD4	I/O	External bus data bit [4]
3	XD5	I/O	External bus data bit [5]
4	XD6	I/O	External bus data bit [6]
5	XD7	I/O	External bus data bit [7]
6	XD8	I/O	External bus data bit [8]
7	VDDI	—	Digital power supply for internal core (1.8 V)
B	VSSI	—	Digital ground for internal
8	XD9	I/O	External bus data bit [9]
9	XD10	I/O	External bus data bit [10]
10	XD11	I/O	External bus data bit [11]
11	XD12	I/O	External bus data bit [12]
12	XD13	I/O	External bus data bit [13]
13	XD14	I/O	External bus data bit [14]
14	XD15	I/O	External bus data bit [15]
C	VDDIO	—	Digital power supply for I/O (1.8 V to 3.3 V)
16	XA0	I/O	External bus address bit [0]
17	XA1	I/O	External bus address bit [1]
18	XA2	I/O	External bus address bit [2]
19	XA3	I/O	External bus address bit [3]
20	XA4	I/O	External bus address bit [4]
21	XA5	I/O	External bus address bit [5]
D	XA6	I/O	External bus address bit [6]
22	VDDI	—	Digital power supply for internal core (1.8 V)
23	VSSI	—	Digital ground for internal
24	XA7	I/O	External bus address bit [7]
25	XA8	I/O	External bus address bit [8]
E	XA9	I/O	External bus address bit [9]
26	XA10	I/O	External bus address bit [10]
27	XA11	I/O	External bus address bit [11]
28	XA12	I/O	External bus address bit [12]
F	VSSIO	—	Digital ground for I/O
32	VDDIO	—	Digital power supply for I/O (1.8 V to 3.3 V)
33	XA13/BA0	I/O	External bus address bit [13] / SDRAM bank address 0
34	XA14/BA1	I/O	External bus address bit [14] / SDRAM bank address 1
35	XA15/nCAS	I/O	External bus address bit [15] / SDRAM CAS signal
36	XA16/nRAS/ALE	I/O	External bus address bit [16] / SDRAM RAS signal / ALE for NAND flash
37	XA17/CLE	I/O	External bus address bit [17] / CLE for NAND flash
38	XA18	I/O	External bus address bit [18]
39	XA19	I/O	External bus address bit [19]
40	VDDI	—	Digital power supply for internal core (1.8 V)
41	XA20/DQM1	I/O	External bus address bit [20] / Data I/O mask 1
42	XA21/DQM0	I/O	External bus address bit [21] / Data I/O mask 0
43	SD_CLK/GPO	I/O	SDRAM clock / GPO, SD_CLK can be used as a general purpose output.
44	VSSIO	—	Digital ground for I/O
45	SD_nCS/GPIO_B1	I/O	Chip select signal for SDRAM, active low / GPIO_B[1]
46	nCS0/nOE0/GPIO_B2	I/O	External bus chip select [0] / NAND flash output enable [0] / GPIO_B[2]
47	nCS1/nOE1/GPIO_B3	I/O	External bus chip select [1] / NAND flash output enable [1] / GPIO_B[3]
48	nCS2/nOE2/GPIO_B4	I/O	External bus chip select [2] / NAND flash output enable [2] / GPIO_B[4]
49	nCS3/nOE3/GPIO_B5	I/O	External bus chip select [3] / NAND flash output enable [3] / GPIO_B[5]

No.	Pin Name	I/O	Pin Function
51	USB_DP/GPIO_B26	I/O	USB function D+ signal / GPIO_B[26]
52	USB_DN/GPIO_B27	I/O	USB function D- signal / GPIO_B[27]
53	USBH_DP/GPIO_B28	I/O	USB host D+ signal / GPIO_B[28]
54	USBH_DN/GPIO_B29	I/O	USB host D- signal / GPIO_B[29]
55	VSSI	-	Digital ground for internal
56	SD_CKE/GPIO_B0	I/O	SDRAM clock enable signal, active high / GPIO_B[0]
57	ND_nWE/GPIO_B7	I/O	NAND flash WE, active low / GPIO_B[7]
58	nWE	I/O	Static memory write enable signal, active low
59	nOE	I/O	Static memory output enable signal, active low
60	UT_TX/GPIO_B8	I/O	UART or IrDA TX data / GPIO_B[8]
61	UT_RX/IDE_nCS1/GPIO_B9	I/O	UART or IrDA RX data / IDE chip select 1 / GPIO_B[9]
62	BCLK/GPIO_B21	I/O	I2S bit clock / GPIO_B[21]
63	LRCK/GPIO_B22	I/O	I2S word clock / GPIO_B[22]
64	VDD_USB	-	Power supply for USB I/O (3.3 V)
65	VSSIO	-	Digital ground for I/O
66	MCLK/GPIO_B23	I/O	I2S system clock / GPIO_B[23]
67	DAO/GPIO_B24	I/O	I2S digital audio data output / GPIO_B[24]
68	DAI/GPIO_B25	I/O	I2S digital audio data input / GPIO_B[25]
69	XTIN	I	Sub crystal oscillator input (32.768 kHz)
70	XTOUT	O	Sub crystal oscillator output (32.768 kHz)
71	VDD_OSC	-	Digital power supply for oscillators (1.8 V)
72	nRESET	I	System reset, active low
73	READY	I	Ready information from external device
74	XIN	I	Main crystal oscillator input for PLL (12 MHz)
75	XOUT	O	Main crystal oscillator output for PLL (12 MHz)
76	VDDIO	-	Digital power supply for I/O (1.8 V to 3.3 V)
77	VDDA_PLL	-	Analog and digital power supply for PLL (1.8 V)
78	XFILT	AO	PLL filter output
79	VSSA_PLL	-	Analog ground for PLL
80	VBBA_PLL	-	Analog ground for PLL
81	VDDA_ADC	-	Analog power supply for ADC (3.3 V)
82	ADIN0	AI	General purpose multi-channel ADC input 0
83	ADIN2	AI	General purpose multi-channel ADC input 2
84	ADIN4	AI	General purpose multi-channel ADC input 4
85	VSSA_ADC	-	Analog ground for ADC
86	VBBA_ADC	-	Analog ground for ADC
87	VDDI_ADC	-	Digital power supply for ADC (1.8 V)
88	VSSI_ADC	-	Digital ground for ADC
89	PKG1	I	Package ID 1, pull-up for normal operation
90	GPIO_D15	I/O	GPIO_D[15]
91	GPIO_D16	I/O	GPIO_D[16]
92	GPIO_D17	I/O	GPIO_D[17]
93	GPIO_D18	I/O	GPIO_D[18]
94	GPIO_D19	I/O	GPIO_D[19]
95	GPIO_D20	I/O	GPIO_D[20]
96	GPIO_D21	I/O	GPIO_D[21]
97	VSSIO	-	Digital ground for I/O
98	MODE1	I	Mode select input 1, Pull-down for normal operation.
99	TDI	I	JTAG serial data input for ARM940T
100	TMS	I	JTAG test mode select for ARM940T

A


No.	Pin Name	I/O	Pin Function
101	TCK	I	JTAG test clock for ARM940T
102	TDO	I/O	JTAG serial data output for ARM940T
103	nTRST	I	JTAG reset signal for ARM940T, active low
104	SDO0/GPIO_A0	I/O	Serial data output 0 / GPIO_A[0]
105	SCK0/GPIO_A1	I/O	Serial clock input 0 / GPIO_A[1]
106	SFRM0/GPIO_A2	I/O	Serial frame 0 / GPIO_A[2]
107	SDI0/GPIO_A3	I/O	Serial data input 0 / GPIO_A[3]
108	SDO1/GPIO_A4	I/O	Serial data output 1 / GPIO_A[4]
109	VDDI	-	Digital power supply for internal core (1.8 V)
110	VSSI	-	Digital ground for internal
111	SCK1/GPIO_A5	I/O	Serial clock input 1 / GPIO_A[5]
112	VDDIO	-	Digital power supply for I/O (1.8 V to 3.3 V)
113	SFRM1/GPIO_A6	I/O	Serial frame 1 / GPIO_A[6]
114	SDI1/GPIO_A7	I/O	Serial data input 1 / GPIO_A[7]
115	SDO2/GPIO_A8	I/O	Serial data output 2 / GPIO_A[8]
116	SCK2/GPIO_A9	I/O	Serial clock input 2 / GPIO_A[9]
117	SFRM2/GPIO_A10	I/O	Serial frame 2 / GPIO_A[10]
118	SDI2/GPIO_A11	I/O	Serial data input 2 / GPIO_A[11]
119	VDDI	-	Digital power supply for internal core (1.8 V)
120	VSSI	-	Digital ground for internal
121	EXINT0/GPIO_A12	I/O	External interrupt request [0] / GPIO_A[12]
122	EXINT1/GPIO_A13	I/O	External interrupt request [1] / GPIO_A[13]
123	EXINT2/GPIO_A14	I/O	External interrupt request [2] / GPIO_A[14]
124	EXINT3/GPIO_A15	I/O	External interrupt request [3] / GPIO_A[15]
125	XD0	I/O	External bus data bit [0]
126	XD1	I/O	External bus data bit [1]
127	XD2	I/O	External bus data bit [2]
128	XD3	I/O	External bus data bit [3]

D

■ AAT4618IGV-0.5-1 (USB ASSY : IC771)

- Load Switching IC

● Pin Arrangement (Top view)




● Pin Function

No.	Pin Name	I/O	Pin Function
1	OUT	O	P-channel MOS FET drain
2	GND	-	Ground
3	FAULT	O	Open-drain FAULT output
4	ON (ON)	I	Enable input: 4618 active low, 4618- active high
5	IN	I	P-channel MOS FET source

F

8. PANEL FACILITIES

Front panel (VSX-2016AV-S/HYXJ5)



1 MULTI JOG dial

Use the **MULTI JOG** dial to select various settings and menu options.

2 Ⓛ STANDBY/ON

Switches the receiver between on and standby. Power indicator lights when the receiver is on.

3 EON MODE

Use to search for programs that are broadcasting traffic or news information.

PTY SEARCH

Use this button to search for RDS program types.

4 LISTENING MODE

Use with the **MULTI JOG** dial to select the various listening modes.

5 PHASE CONTROL indicator

Lights when Phase Control is switched on.

6 HDMI indicator

Blinks when connecting an HDMI-equipped component; lights when the component is connected.

7 Character display

8 Remote sensor

Receives the signals from the remote control.

9 MCACC indicator

Lights when one of the MCACC presets is selected.

10 SIGNAL SELECT

Use to select an input signal.

SBch PROCESSING - Selects the surround back channel mode or virtual surround back mode.

MULTI CH IN - Press to select the multichannel analog inputs.

11 MASTER VOLUME dial

12 ENTER

13 PHONES jack

Use to connect headphones. When the headphones are connected, there is no sound output from the speakers.

14 Input source buttons

Press to select an input source.

15 VIDEO/GAME INPUT

16 USB interface

Connect a USB audio device for playback.

17 MCACC SETUP MIC jack

Use to connect the supplied microphone.

18 SYSTEM SETUP

Press to access the System Setup menu.

19 RETURN

Press to confirm and exit the current menu screen.

20 TONE

Press this button to access the bass and treble controls, which you can then adjust with the **MULTI JOG** dial.

21 TUNING/STATION

Use to find radio frequencies and to select preset stations.

22 TUNER EDIT

Use with the **MULTI JOG** dial to memorize and name stations for recall.

23 SPEAKERS

Use to change the speaker system.

A

B


C

D

E

F

Front panel (VSX-81TXV, VSX-81TXV-S, VSX-9110TXV-K)



C

1 MULTI JOG dial

Use the **MULTI JOG** dial to select various settings and menu options.

2 STANDBY/ON

Switches the receiver between on and standby. Power indicator lights when the receiver is on.

3 MULTI ROOM controls

If you've made multi-room connections (see Multi-room listening) use these controls to control the sub room from the main room (see Using the multi-room controls).

4 LISTENING MODE

Use with the **MULTI JOG** dial to select the various listening modes.

5 PHASE CONTROL indicator

Lights when Phase Control is switched on.

6 HDMI indicator

Blinks when connecting an HDMI-equipped component; lights when the component is connected.

7 Character display

See Display.

8 Remote sensor

Receives the signals from the remote control (see Operating range of remote control unit).

9 MCACC indicator

Lights when one of the MCACC presets is selected.

10 SIGNAL SELECT

Use to select an input signal.

SBch PROCESSING – Selects the surround back channel mode or virtual surround back mode.

MULTI CH IN – Press to select the multichannel analog inputs.

F 11 MASTER VOLUME dial

12 ENTER

13 PHONES jack

Use to connect headphones. When the headphones are connected, there is no sound output from the speakers.

14 Input source buttons

Press to select an input source.

15 VIDEO/GAME INPUT

See Connecting a component to the front panel inputs.

16 MCACC SETUP MIC jack

Use to connect the supplied microphone.

17 SYSTEM SETUP

Press to access the System Setup menu.

18 RETURN

Press to confirm and exit the current menu screen.

19 TONE

Press this button to access the bass and treble controls, which you can then adjust with the **MULTI JOG** dial.

20 TUNING/STATION

Use to find radio frequencies and to select preset stations.


21 TUNER EDIT

Use with the **MULTI JOG** dial to memorize and name stations for recall.

22 SPEAKERS

Use to change the speaker system.

Rear panel (VSX-2016AV-S/HYXJ5)



Caution

- Before making or changing the connections, switch off the power and disconnect the power cord from the power outlet. Plugging in should be the final step.

1 HDMI connectors (x3)

Two inputs and one output for high-quality audio/video connection to compatible HDMI devices.

→ Connecting using HDMI.

2 Coaxial digital audio inputs (x2)

Use for digital audio sources, including DVD players/recorders, digital satellite receivers, CD players, etc.

3 Optical digital audio output / input(s) (x4)

Use the OUT jack for recording to a CD or MiniDisc recorder.

→ Connecting digital audio sources.

Use the IN jacks for digital audio sources, including DVD players/recorders, digital satellite receivers, CD players, etc.

4 Control input/output

Use to connect other Pioneer components so that you can control all your equipment from a single IR remote sensor.

→ Operating other Pioneer components with this unit's sensor.

5 Stereo analog audio source inputs/(outputs) (x3)

Use for connection to audio sources such as CD players, tape decks, turntables, etc.

→ Connecting analog audio sources.

6 Component video connections (x4)

Use the inputs to connect any video source that has component video output, such as a DVD recorder. Use the output for connection to a monitor or TV.

→ Using the component video jacks.

7 Audio/video source inputs/(outputs) (x6)

Use for connection to audio/visual sources, such as DVD players/recorders, VCRs, etc. Each set of inputs has jacks for composite video, S-video and stereo analog audio.

→ Connecting a DVD/HDD recorder, VCR and other video sources.

8 iPod input terminal

Use to connect your Apple iPod as an audio source.

→ Connecting an iPod.

9 AM and FM antenna terminals

Use to connect indoor or outdoor antennas for radio broadcasts.

→ Connecting antennas.

10 Multichannel pre-amplifier outputs

Use to connect separate amplifiers for front, center, surround, surround back and subwoofer channels.

→ Connecting additional amplifiers.

11 Composite and S-video monitor outputs

Use to connect monitors and TVs.

→ Connecting your TV and DVD recorder.

12 Multichannel analog audio inputs

7.1 channel inputs for connection to a DVD player with multichannel analog outputs.


→ Connecting the multichannel analog inputs.

13 Speaker terminals

Use for connection to the main front, center, surround and surround back speakers.

→ Installing your speaker system.

Rear panel (VSX-81TXV, VSX-81TXV-S, VSX-9110TXV-K)



VSX-81TXV, VSX-81TXV-S, VSX-9110TXV-K

Caution

- Before making or changing the connections, switch off the power and disconnect the power cord from the power outlet.
Plugging in should be the final step.

1 HDMI connectors (x3)

Two inputs and one output for high-quality audio/video connection to compatible HDMI devices.

C → Connecting using HDMI.

2 XM Radio input

→ See Using XM Radio.

3 Coaxial digital audio inputs (x2)

Use for digital audio sources, including DVD players/recorders, digital satellite receivers, CD players, etc.

→ See also The Input Setup menu to assign the inputs.

4 Optical digital audio output / input(s) (x4)

Use the OUT jack for recording to a CD or MiniDisc recorder. → Connecting digital audio sources.

D Use the IN jacks for digital audio sources, including DVD players/recorders, digital satellite receivers, CD players, etc.

→ See also The Input Setup menu to assign the inputs.

5 Control input/output

E Use to connect other Pioneer components so that you can control all your equipment from a single IR remote sensor.

→ Operating other Pioneer components with this unit's sensor.

6 Stereo analog audio source inputs/(outputs) (x3)

Use for connection to audio sources such as CD players, tape decks, turntables, etc.

→ Connecting analog audio sources.

7 Remote input (multi-room and source)

Use for connection to an external remote control sensor for use in a multi-room setup, for example.

→ Connecting an IR receiver.

8 Component video connections (x4)

Use the inputs to connect any video source that has component video output, such as a DVD recorder. Use the output for connection to a monitor or TV.

→ Using the component video jacks.

9 RS-232C connector

Use for connection to a PC for graphical output when using Advanced MCACC.

→ Connecting a PC for Advanced MCACC output.

10 iPod input terminal

Use to connect your Apple iPod as an audio source.

→ Connecting an iPod.

11 Audio/video source inputs(outputs) (x6)

Use for connection to audio/visual sources, such as DVD players/recorders, VCRs, etc. Each set of inputs has jacks for composite video, S-video and stereo analog audio.

→ Connecting a DVD/HDD recorder, VCR and other video sources.

12 AM and FM antenna terminals

Use to connect indoor or outdoor antennas for radio broadcasts.

→ Connecting antennas.

13 Multichannel pre-amplifier outputs

Use to connect separate amplifiers for front, center, surround, surround back and subwoofer channels.

→ Connecting additional amplifiers (see also Installing your speaker system for powered subwoofer connection).

14 Composite and S-video monitor outputs

Use to connect monitors and TVs.

→ Connecting your TV and DVD player.

15 Multichannel analog audio inputs

7.1 channel inputs for connection to a DVD player with multichannel analog outputs.

→ Connecting the multichannel analog inputs.

16 12V trigger jack (total 50 mA max.)

Use to switch components in your system on and off according to the input function of the receiver.

→ Switching components on and off using the 12 volt trigger.

17 Multi-room and source outputs

Use to connect a second amplifier in a separate room.

→ Multi-room listening.

18 Speaker terminals

Use for connection to the main front, center, surround and surround back speakers.


→ Installing your speaker system.

19 Switched AC power outlet (100 W/0.8 A max.)

Use to power another component in the system. Power to the outlet switches on and off with the receiver.

→ AC outlet.

Display (VSX-2016AV-S/HYXJ5)



1 SIGNAL indicators

Light to indicate the currently selected input signal.
AUTO lights when the receiver is set to select the input signal automatically.

2 Program format indicators

These change according to which channels are active in digital sources.

L - Left front channel

C - Center channel

R - Right front channel

SL - Left surround channel

S - Surround channel (mono)

SR - Right surround channel

SBL - Left surround back channel

SB - Surround back channel (mono)

SBR - Right surround back channel

LFE - Low frequency effects channel (the ((())) indicators light when an LFE signal is being input)

3 Digital format indicators

Light when a signal encoded in the corresponding format is detected (**DSD ▶ PCM** lights during DSD (Direct Stream Digital) to PCM conversion with SACDs).

4 OVER / ATT

OVER lights to indicate that the level of an analog source is too high. **ATT** lights when you use the attenuator (**ANALOG ATT**) to reduce it.

5 VIDEO CONV.

Lights when digital video conversion is enabled.

6 V.SB

Lights during Virtual surround back processing.

7 Sound processing indicators

Light according to the active AV parameter(s).

8 TUNER indicators

TUNED - Lights when a broadcast is being received.

STEREO - Lights when a stereo FM broadcast is being received in auto stereo mode.

MONO - Lights when the mono mode is set using the **MPX** button.

9 EON / RDS indicators

EON - Lights when the EON mode is set (flashes during EON reception). The **O** indicator lights when the current station carries the EON service.

RDS - Lights when an RDS broadcast is received.

10 Master volume level

11 HDMI connection indicators

Light to indicate the HDMI input currently selected.

12 STREAM DIRECT

Lights when Direct / Pure Direct is selected.

13 Speaker indicators

Indicate the current speaker system, **A** and/or **B**.

14 Listening mode indicators

THX - Lights when a Home THX mode is selected.

ADV. SURROUND - Lights when an Advanced Surround mode has been selected.

STEREO - Lights when stereo listening is switched on.

STANDARD - Lights when a Standard Surround mode is switched on.

15 SLEEP

Lights when the receiver is in sleep mode.

16 Matrix decoding format indicators

PRO LOGIC IIx - This lights to indicate **Pro Logic II** / **Pro Logic IIx** decoding.

Neo:6 - When one of the Neo:6 modes of the receiver is on, this lights to indicate Neo:6 processing.


17 Character display

Displays various system information.

18 SR+

Lights when the SR+ mode is switched on.

A Display (VSX-81TXV, VSX-81TXV-S, VSX-9110TXV-K)



1 SIGNAL indicators

Light to indicate the currently selected input signal.
AUTO lights when the receiver is set to select the input signal automatically.

2 Program format indicators

These change according to which channels are active in digital sources.

C L – Left front channel

C – Center channel

R – Right front channel

SL – Left surround channel

S – Surround channel (mono)

SR – Right surround channel

SBL – Left surround back channel

SB – Surround back channel (mono)

SBR – Right surround back channel

LFE – Low frequency effects channel (the ((())) indicators light when an LFE signal is being input)

3 Digital format indicators

D Light when a signal encoded in the corresponding format is detected.

4 OVER / ATT

OVER lights to indicate that the level of an analog source is too high. **ATT** lights when you use the attenuator (**ANALOG ATT**) to reduce it.

5 MULTI-ROOM

Lights when the multi-room feature is active.

6 VIDEO CONV.

Lights when digital video conversion is enabled.

E 7 V.SB

Lights during Virtual surround back processing.

8 Sound processing indicators

Light according to the active AV parameter(s).

F 9 TUNER indicators

TUNED – Lights when a broadcast is being received.

STEREO – Lights when a stereo FM broadcast is being received in auto stereo mode.

MONO – Lights when the mono mode is set using the **MPX** button.

10 HDMI connection indicators

Light to indicate the HDMI input currently selected.

11 Master volume level

12 STREAM DIRECT

Lights when Direct / Pure Direct is selected.

13 Speaker indicators

Indicate the current speaker system, **A** and/or **B**.

14 Listening mode indicators

THX – Lights when a Home THX mode is selected.

ADV. SURROUND – Lights when an Advanced Surround mode has been selected.

STEREO – Lights when stereo listening is switched on (see Listening in stereo).

STANDARD – Lights when a Standard Surround mode is switched on (see Listening in surround sound).

15 SLEEP

Lights when the receiver is in sleep mode.

16 Matrix decoding format indicators

DPRO LOGIC IIx – This lights to indicate **DPro Logic II** / **DPro Logic IIx** decoding.

Neo:6 – When one of the Neo:6 modes of the receiver is on, this lights to indicate Neo:6 processing.


17 Character display

Displays various system information.

18 SR+

Lights when the SR+ mode is switched on.

Remote control (VSX-2016AV-S/HYXJ5)



The remote has been conveniently color-coded according to component control using the following system (press the corresponding input source button to access):

- **Green** - Receiver controls (see below)
- **Red** - DVD controls
- **Blue** - Tuner controls
- **White** - Other controls

1 RECEIVER ⏹

This switches between standby and on for this receiver.

2 INPUT SELECT

Use to select the input source (use SHIFT for INPUT SELECT ⌂).

3 Input source buttons

Press to select control of other components.

4 Number buttons and other receiver/component controls

Use the number buttons to directly select a radio frequency or the tracks on a CD, DVD, etc.

DISC (ENTER) can be used to enter commands for TV or DTV, and also to select a disc in a multi-CD player.

Press **RECEIVER** first to access:

SLEEP - Use to put the receiver in sleep mode and select the amount of time before sleep.

VIDEO SEL - Press repeatedly to select the video source.

ANALOG ATT - Attenuates (lowers) the level of an analog input signal to prevent distortion.

SR+ - Switches the SR+ mode on/off.

DIMMER - Dims or brightens the display.

MIDNIGHT/LOUDNESS - Use Midnight when listening to movie soundtracks at low volume. Use Loudness to boost the bass and treble at low volume.

DIALOG E - Use to make dialog stand out when watching TV or a movie.

S. RETRIEVER - Press to restore CD quality sound to compressed audio sources.

Press **TUNER** first to access:

D.ACCESS - After pressing, you can access a radio station directly using the number buttons.

CLASS - Switches between the three banks (classes) of radio station presets.

5 Tuner/component control buttons/SETUP

These button controls can be accessed after you have selected the corresponding input source button (**DVD**, **DVR1**, **TV**, etc.). Press **RECEIVER** first to access the following controls:

AV PARAMETER - Use to access the AV options.

SETUP - Use to access the System Setup menu.

CH LEVEL - Press repeatedly to select a channel, then use **↔/→** to adjust the level.

RETURN - Press to confirm and exit the current menu screen (also use to return to the previous menu with DVDs or to select closed captioning with DTV).

6 ↔/↑ (TUNE/ST) / ENTER

Use the arrow buttons when setting up your surround sound system and the AV options. Also used to control DVD menus/options and for deck 1 of a double cassette deck player. Use the **TUNE ↑/↓** buttons to find radio frequencies and use **ST ↔/→** to find preset stations.

7 TV CONTROL buttons

These buttons are dedicated to control the TV assigned to the **TV CTRL** button. Thus if you only have one TV to hook up to this system assign it to the **TV CTRL** input source button. If you have two TVs, assign the main TV to the **TV CTRL** button.

TV ⏹ - Use to turn on/off the power of the TV.

TV VOL +/− - Use to adjust the volume on your TV.

INPUT SELECT - Use to select the TV input signal.

TV CH +/− - Use to select channels.

A

8 Component control buttons

The main buttons (▶, □, etc.) are used to control a component after you have selected it using the input source buttons.

The controls above these buttons can be accessed after you have selected the corresponding input source button (for example **DVD**, **DVR1** or **TV**). The following controls can be accessed when listening to the built-in tuner:

MPX - Switches between stereo and mono reception of FM broadcasts. If the signal is weak then switching to mono will improve the sound quality.

DISP - Switches between named station presets and radio frequencies. Also used to display RDS information.

EON - Use to search for programs that are broadcasting traffic or news information.

9 STATUS

Press to check selected receiver settings.

10 MULTI OPE

Use this button to perform multi operations.

C 11 SHIFT

Press to access the controls outlined in white boxes (for example, **INPUT SELECT** ), or to display the currently selected input source in the remote control LCD.

12 SOURCE ⌂

Press to turn on/off other components connected to the receiver.

13 Character display (LCD)

This display shows information when transmitting control signals.

D The following commands are shown when you're setting the remote to control other components:

SETUP - Indicates the setup mode, from which you choose the options below.

PRESET - See Selecting preset codes directly.

LEARNING - See Programming signals from other remote controls.

MULTI OP - See Multi Operation and System Off.

SYS OFF - See Multi Operation and System Off.

DIRECT F - See Direct function.

RENAME - See Renaming input source names.

E ERASE - See Erasing one of the remote control button settings.

RESET - See Resetting the remote control presets.

READ ID - See Confirming preset codes.

14 RECEIVER

Switches the remote to control the receiver (used to select the green commands above the number buttons (**ANALOG ATT**, etc)). Also use this button to set up surround sound.

15 VOL +/-

Use to set the listening volume.

F

16 MUTE

Mutes the sound or restores the sound if it has been muted (adjusting the volume also restores the sound).

17 Receiver controls

SIGNAL SEL - Use to select an input signal.

SBch - Use to select the surround/virtual back channel mode.

STEREO - Switches between direct and stereo playback. Direct playback bypasses the tone controls and any other signal processing for the most accurate reproduction of a source.

THX - Press to select a Home THX listening mode.

STANDARD - Press for Standard decoding and to switch between the various **D**Pro Logic IIx and Neo: 6 options.


ADV.SURR - Use to switch between the various surround modes.

18 PHASE - Press to switch on/off Phase Control.

MCACC - Press to switch between MCACC presets.

S.DIRECT - Press to select Auto Surround or Stream Direct listening.

Remote control (VSX-81TXV, VSX-81TXV-S, VSX-9110TXV-K)



The remote has been conveniently color-coded according to component control using the following system (press the corresponding input source button to access):

- **Green** – Receiver controls (see below)
- **Red** – DVD controls
- **Blue** – Tuner/XM Radio controls
- **Yellow** – iPod controls
- **White** – Other controls

1 RECEIVER ⏹

This switches between standby and on for this receiver.

2 INPUT SELECT

Use to select the input source (use **SHIFT** for **INPUT SELECT** ⌂).

3 Input source buttons

Press to select control of other components (see Controlling the rest of your system).

4 Number buttons and other receiver/component controls

Use the number buttons to directly select a radio frequency or the tracks on a CD, DVD, etc.

DISC (ENTER) can be used to enter commands for TV or DTV, and also to select a disc in a multi-CD player.

Press **RECEIVER** first to access:

SLEEP – Use to put the receiver in sleep mode and select the amount of time before sleep.

VIDEO SEL – Press repeatedly to select the video source.

ANALOG ATT – Attenuates (lowers) the level of an analog input signal to prevent distortion.

SR+ – Switches the SR+ mode on/off.

DIMMER – Dims or brightens the display.

MIDNIGHT/LOUDNESS – Use Midnight when listening to movie soundtracks at low volume. Use Loudness to boost the bass and treble at low volume.

DIALOG E – Use to make dialog stand out when watching TV or a movie.

S. RETRIEVER – Press to restore CD quality sound to compressed audio sources.

Press **TUNER** first to access:

D.ACCESS – After pressing, you can access a radio station directly using the number buttons.

CLASS – Switches between the three banks (classes) of radio station presets.

5 Tuner/component control buttons/SETUP

These button controls can be accessed after you have selected the corresponding input source button (**DVD**, **DVR1**, **TV**, etc.). The **BAND** and **T.EDIT** tuner controls are explained from. Press **RECEIVER** first to access the following controls:

AV PARAMETER – Use to access the AV options.

SETUP – Use to access the System Setup menu.

CH LEVEL – Press repeatedly to select a channel, then use **↔/→** to adjust the level.

RETURN – Press to confirm and exit the current menu screen (also use to return to the previous menu with DVDs or to select closed captioning with DTV).

6 ⏪ ⏩ ⏪ ⏩ (TUNE/ST) /ENTER

Use the arrow buttons when setting up your surround sound system and the AV options.

Also used to control DVD menus/options and for deck 1 of a double cassette deck player. Use the **TUNE ⏪/↑** buttons to find radio frequencies and use **ST ⏪/→** to find preset stations.

7 TV CONTROL buttons

These buttons are dedicated to control the TV assigned to the **TV CTRL** button. Thus if you only have one TV to hook up to this system assign it to the **TV CTRL** input source button. If you have two TVs, assign the main TV to the **TV CTRL** button.

TV ⏹ – Use to turn on/off the power of the TV.

TV VOL +/– – Use to adjust the volume on your TV.

INPUT SELECT – Use to select the TV input signal.

TV CH +/– – Use to select channels.

A

8 Component control buttons

The main buttons (▶, ■, etc.) are used to control a component after you have selected it using the input source buttons.

The controls above these buttons can be accessed after you have selected the corresponding input source button (for example **DVD**, **DVR1** or **TV**). The following controls can be accessed when listening to the built-in tuner:

MPX – Switches between stereo and mono reception of FM broadcasts. If the signal is weak then switching to mono will improve the sound quality.

DISP – Switches between named station presets and radio frequencies.

9 STATUS

Press to check selected receiver settings.

10 MULTI OPE

Use this button to perform multi operations.

11 SHIFT

Press to access the controls outlined in white boxes (for example, **INPUT SELECT** ▶), or to display the currently selected input source in the remote control LCD.

12 SOURCE ⏹

Press to turn on/off other components connected to the receiver.

13 Character display (LCD)

This display shows information when transmitting control signals.

The following commands are shown when you're setting the remote to control other components (see Controlling the rest of your system):

SETUP – Indicates the setup mode, from which you choose the options below

PRESET – See Selecting preset codes directly.

LEARNING – See Programming signals from other remote controls.

MULTI OP – See Multi Operation and System Off.

SYS OFF – See Multi Operation and System Off.

DIRECT F – See Direct function.

RENAME – See Renaming input source names.

ERASE – See Erasing one of the remote control button settings.

RESET – See Resetting the remote control presets.

READ ID – See Confirming preset codes.

14 RECEIVER

Switches the remote to control the receiver (used to select the green commands above the number buttons (**ANALOG ATT**, etc))). Also use this button to set up surround sound . With **SHIFT**, this selects the multi-room control.

15 VOL +/–

Use to set the listening volume.

16 MUTE

Mutes the sound or restores the sound if it has been muted (adjusting the volume also restores the sound).

17 Receiver controls

SIGNAL SEL – Use to select an input signal.

SBch – Use to select the surround/virtual back channel mode.

STEREO – Switches between direct and stereo playback. Direct playback bypasses the tone controls and any other signal processing for the most accurate reproduction of a source.

THX – Press to select a Home THX listening mode.

STANDARD – Press for Standard decoding and to switch between the various **D** Pro Logic IIx and Neo:6 options.

ADV.SURR – Use to switch between the various surround modes.

18 PHASE – Press to switch on/off Phase Control.

MCACC – Press to switch between MCACC presets.

S.DIRECT – Press to select Auto Surround or Stream Direct listening.

B

C

D

E

F

■ 5 ■

6 ■

7 ■

8 ■

A ■

B ■

C ■

D ■

E ■

F ■

■ Jigs list

A

Name	Jig No.	Remarks
11P board to board extension jig cable	GGD1482	Diagonosis
13P board to board extension jig cable	GGD1483	Diagonosis
15P board to board extension jig cable	GGD1484	Diagonosis
21P board to board extension jig cable	GGD1485	Diagonosis
RS-232C I/F jig	GGF1348	Update the Flash ROMS
7-pin FFC	VDA1681	Update the Flash ROMS

B

■ CLEANING



Before shipping out the product, be sure to clean the following positions by using the prescribed cleaning tools:

Position to be cleaned	Cleaning tools
Fans	Cleaning paper : GED-008

C

D

E

F