


Service Manual

PIONEER
The Art of Entertainment



ORDER NO.
ARP2650

MULTI CD DOUBLE DECK AMPLIFIER

XD-J115M

CD DOUBLE DECK AMPLIFIER

XD-J110

XD-J115M AND XD-J110 HAVE THE FOLLOWING :

Type	Model		Power Requirement	Remarks
	XD-J115M	XD-J110		
HE	○	○	AC220V-230V, 240V (Switchable)*	
HB	○	○	AC220V-230V, 240V (Switchable)*	
HEWZIW	○	○	AC220V-230V, 240V (Switchable)*	

* Change the connection of the power transformer's primary wiring.

- This manual is applicable to the following : XD-J115M/HE, HB and HEWZIW ; XD-J110/HE, HB and HEWZIW.
- For the following : XD-J115M/HB and HEWZIW ; XD-J110/HB and HEWZIW, refer to page 113.
- These products are systems components.
Each of these products does not function properly when independent ; to avoid malfunctions, be sure to connect it to the prescribed system component (s), otherwise damage may result.

CONTENTS

1. SAFETY INFORMATION	2	5. PCB PARTS LIST	83
2. EXPLODED VIEWS, PACKING AND PARTS LIST	4	6. ADJUSTMENTS	89
3. BLOCK DIAGRAM	29	7. FOR XD-J115M/HB, HEWZIW, XD-J110/HB AND HEWZIW TYPES	113
4. SCHEMATIC AND PCB CONNECTION DIAGRAMS	31	8. PANEL FACILITIES	133
		9. SPECIFICATIONS	144

PIONEER ELECTRONIC CORPORATION 4-1, Meguro 1-Chome, Meguro-ku, Tokyo 153, Japan
PIONEER ELECTRONICS SERVICE INC. P.O. Box 1760, Long Beach, California 90801 U.S.A.
PIONEER ELECTRONICS OF CANADA, INC. 300 Allstate Parkway Markham, Ontario L3R 0P2 Canada
PIONEER ELECTRONIC [EUROPE] N.V. Haven 1087 Keetberglaan 1, 9120 Melsele, Belgium
PIONEER ELECTRONICS AUSTRALIA PTY. LTD. 178-184 Boundary Road, Braeside, Victoria 3195, Australia TEL: [03] 580-9911
 © PIONEER ELECTRONIC CORPORATION 1993

DG JAN. 1993 Printed in Japan

1. SAFETY INFORMATION

(FOR EUROPEAN MODEL ONLY)

VARO!
AVATTAESSA JA SUOJALUKITUS OHITETTAESSA OLET ALTTIINA NAKYMATTOMALLE LASERSATEILYLLE. ALÄ KATSO SÄTEESEEN.



LASER
Kuva 1
Lasersäteilyn
varoitusmerkki

ADVERSEL!
USYNLIG LASERSTRÅLING VED ÅBNING NÅR SIKKERHEDSÅFBRYDERE ER UDE AF FUNKTION UDGÅR UDSÆTTELSE FOR STRÅLING.

VARNING!
OSYNLIG LASERSTRÅLNING NÅR DENNA DEL ÄR ÖPPNAD OCH SPÄRREN ÄR URKOPPLAD. BETRÄKTA EJ STRÅLEN.

WARNING!
DEVICE INCLUDES LASER DIODE WHICH EMITS INVISIBLE INFRARED RADIATION WHICH IS DANGEROUS TO EYES. THERE IS A WARNING SIGN ACCORDING TO PICTURE 1 INSIDE THE DEVICE CLOSE TO THE LASER DIODE.



LASER
Picture 1
Warning sign for
laser radiation

IMPORTANT
THIS PIONEER APPARATUS CONTAINS LASER OF CLASS 1. SERVICING OPERATION OF THE APPARATUS SHOULD BE DONE BY A SPECIALLY INSTRUCTED PERSON.

LASER DIODE CHARACTERISTICS
MAXIMUM OUTPUT POWER: 5 mw
WAVELENGTH: 780-785 nm

Additional Laser Caution

- Laser Interlock Mechanism**
The ON/OFF (ON : low level, OFF : high level) status of the LSP1 (S601) and LSP2 (S602) switches for detecting the loading state is detected by the system microprocessor, and the design prevents laser diode oscillation when both switches LSP1 and LSP2 are not ON (low level) (clamped state).
Thus, interlock will no longer function if switches LSP1 (S601) and LSP2 (S602) are deliberately shorted.
The interlock also does not operate in the test mode*.
Laser diode oscillation will continue, if pin 1 of M51593FP (IC101) on the preamplifier board loaded on pick up assembly are connected to GND, or pin 19 is connected to low level (ON), or else the terminals of Q101 are shorted to each other (fault condition).


- When the cover is opened with the servo mechanism block removed to be turned over, close viewing of the objective lens with the naked eye will cause exposure to a Class 1 laser beam.

* Refer to page 94.

LABEL CHECK (MULTI MAGAZINE type)

HE, HEWZIW and HB types

HB type



CLASS 1 LASER PRODUCT
ARW1021

HE and HEWZIW types

ADVARSEL!
USYNLIG LASERSTRÅLING VED ÅBNING NÅR SIKKERHEDSÅFBRYDERE ER UDE AF FUNKTION UDGÅR UDSÆTTELSE FOR STRÅLING.
VARNING!
OSYNLIG LASERSTRÅLNING NÅR DENNA DEL ÄR ÖPPNAD OCH SPÄRREN ÄR URKOPPLAD. BETRÄKTA EJ STRÅLEN.

HE and HEWZIW types


CAUTION
INVISIBLE LASER RADIATION WHEN OPEN. AVOID EXPOSURE TO BEAM
ARW1023

HB type

LABEL CHECK (SINGLE MAGAZINE type)

HE, HEWZIW and HB types

HB type



CLASS 1 LASER PRODUCT
ARW1021

HE and HEWZIW types

ADVARSEL!
USYNLIG LASERSTRÅLING VED ÅBNING NÅR SIKKERHEDSÅFBRYDERE ER UDE AF FUNKTION UDGÅR UDSÆTTELSE FOR STRÅLING.
VARNING!
OSYNLIG LASERSTRÅLNING NÅR DENNA DEL ÄR ÖPPNAD OCH SPÄRREN ÄR URKOPPLAD. BETRÄKTA EJ STRÅLEN.

HE and HEWZIW types

CAUTION
INVISIBLE LASER RADIATION WHEN OPEN. AVOID EXPOSURE TO BEAM
ARW1023

HB type

Additional Laser Caution

- Laser Interlock Mechanism**
The position of the switch (S601) for detecting loading completion is detected by the system microprocessor, and the design prevents laser diode oscillation when the switch (S601) is not in CLMP terminal side (when CLMP signal is OFF, that is high level).
Thus, the interlock will no longer function if the switch (S601) is deliberately connected to ground (low level). The interlock also does not operate in the test mode*.
Laser diode oscillation will continue, if pins 1 and 2 of M51593FP (IC101) on the preamplifier board loaded on pick up assembly are connected to GND, or pin 19 is connected to low level (ON), or else the terminals of Q101 are shorted to each other (fault condition).

- When the cover is opened, close viewing of the objective lens with the naked eye will cause exposure to a Class 1 or higher laser beam.

* Refer to page 103.

LITHIUM BATTERY NOTICE

WARNING!
Lithium batteries. Danger of explosion. Replacement must be done by qualified personnel and only by following the instructions given in the service manual.

This warning is stated on the product or in the operating instructions. When replacing the lithium batteries, follow the note below.

Dispose of the used battery promptly. Keep away from children. Do not disassemble and do not dispose of in fire. The battery used in this device may present a fire or chemical hazard if mistreated. Do not recharge, disassemble, heat above 100°C or incinerate. Replace only with the same Part Number. Use of another battery may present a risk of fire or explosion.

Note: The lithium battery installation position is shown in the exploded view and the P.C. board pattern.

ADVARSEL!
Lithiumbatteri — Eksplosionsfare ved fejlagtig håndtering. Udskiftning må kun ske med batteri af samme fabrikat og type. Levér det brugte batteri tilbage til leverandøren.

Denne advarsel er angivet på produktet eller i brugsvejledningen. Ved udskiftning af lithium batterierne følges nedenstående anvisning.
Batterierne må kun udskiftes med batterier af samme type og mærke.

VARNING
Explosionsfara vid felaktigt batteribyte. Använd samma batterityp eller en ekvivalent typ som rekommenderas av apparattillverkaren. Kassera använt batteri enligt fabrikantens instruktion.

Denna varning finns på apparaten eller i bruksanvisningen. Följ nedanstående anvisningar vid byte av litiumbatterier. Batterierna får endast bytas ut mot litiumbatterier av samma typ och fabrikat.

2. EXPLODED VIEWS, PACKING AND PARTS LIST

NOTES:

- Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.
- The Δ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- Parts marked by "☉" are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.


2.1 DECK AMP BLOCK (XD-J115M AND XD-J110)

2.1.1 Exterior (1/2)

Parts list

Mark	No.	Description	Parts No.	Mark	No.	Description	Parts No.
Δ	1	POWER TRANSFORMER (T)	ATS1469		26	AF ASSEMBLY	AWZ4645
Δ	2	FUSE (T800mA/250V, FU1102)	AEK-507		27	VOLUME ASSEMBLY	AWZ4653
	3			28	
	4	REAR PANEL (MTL)	ANC2008	NSP	29	TRANS CONNECT ASSEMBLY	AWZ4672
	5	HEAT SINK (AL)	ANH1408		30	SUB TRANS ASSEMBLY	AWZ4678
	6	PLATE L	ANG1536				
	7	PLATE R	ANG1537		31	NYLON RIVET	AEC1160
NSP	8	PLATE	ANG1561	NSP	32	NAME PLATE (For XD-J115M)	AAL2022
NSP	9	HOLDER	ANG1600	NSP	32	NAME PLATE (For XD-J110)	AAL2019
	10					
	11	HEAT SINK HOLDER (MTL)	ANG1777		33	MICA SHEET	AEP-313
	12	PCB HOLDER B (MTL)	ANG1779				
	13	PCB HOLDER (MTL)	ANG1838				
NSP	14	BINDER	AEC-093				
	15					
	16					
	17	SCREW	ABA-222				
	18	SCREW (3 x 18)	ABA1018				
	19	SCREW	BBZ30P080FZK				
	20	SCREW	BBZ30P100FZK				
	21	SCREW	VPZ30P080FZK				
	22	BADGE (ABS)	AAM1047				
	23	VOL KNOB	AAB1337				
	24	AAB1339				
	25	BONNET CASE (MTL)	ANE1390				

● Exterior (1/2)



EXTERIOR (2/2)
(Refer to Pages 7-9.)

CD UNIT
(Refer to Pages 16-27.)

NOTE : Screws adjacent to ▼ mark on the product are used for disassembly.

2.1.2 Exterior (2/2)


● Exterior (2/2)

A

B

C

D



A

B

C

D

XD-J115M, XD-J110

XD-J115M, XD-J110

Parts list

Mark	No.	Description	Parts No.	Mark	No.	Description	Parts No.
△NSP	1	FLAT CABLE (J112)	ADD1112	31	BUTTON (POWER)	AAD2370	
△	2	FLAT CABLE (J105)	ADD1116	32	BUTTON (FUNCTION)	AAD2372	
	3	CASSETTE 1 MECHA UNIT	EXK2026	33	BUTTON (GEQ)	AAD2373	
	4	CASSETTE 2 MECHA UNIT	EXK2056	34		
	5	PCB HOLDER A (MTL)	ANG1778	35	BUTTON (AUDITION)	AAD2375	
	6	HEAT SINK HOLDER (MTL)	ANG1837	36	CURSÓR BUTTON	AAD2377	
	7	SHIELD PLATE (MECHA)	ANK1157	37	BUTTON (DECK)	AAD2379	
	8	DOOR SPRING L	ABH1085	38	EJECT BUTTON L (PLS)	AAD2380	
	9	DOOR SPRING R	ABH1086	39	EJECT BUTTON R (PLS)	AAD2381	
	10	KEEP PLATE	ABK1017	40	SLIDE KNOB (PLS)	AAE1160	
NSP	11	EARTH LEAD	ADB1006	41	DISPLAY ASSEMBLY	AWZ4656	
	12	NYLON RIVET	AEC1160	42	HEADPHONE ASSEMBLY	AWZ4666	
	13		43		
	14	DAMPER ASSEMBLY	AXA1008	44	TAPE ASSEMBLY	AWV1335	
	15	SHEET	AAX1301	NSP 45	SHIELD PLATE	ANK1159	
	16	SCREW (2.6×8)	ABA1095	46	SW ASSEMBLY	AWK1746	
	17	SCREW	BBZ30P080FZK	47	SCREW	PBZ26P250FMC	
	18	SCREW	BPZ26P080FMC	NSP 48	BUSH	AEC1326	
	19	SCREW	VPZ30P080FZK	NSP 49	COLLAR	AEC1327	
	20	CASSETTE DOOR L (PLS)	AAN1365	△ 50	LITHIUM BATTERY	AEX1014	
	21	CASSETTE DOOR R (PLS)	AAN1376				
	22	FRONT PANEL (For XD-J115M)	AMB2094				
	22	FRONT PANEL (For XD-J110)	AMB2093				
	23	FILTER (REMOCON)	AAK2376				
	24	DECORATIVE PLATE (DECK)	AAK2398				
	25	DECORATIVE PLATE (AMP)	AAK2441				
	26	DECORATIVE PLATE (DOOR) L	AAK2400				
	27	DECORATIVE PLATE (DOOR) R	AAK2402				
	28	FL FILTER (PVC)	AAK2430				
	29	POWER LENS (PLS)	AAK2442				
	30	BADGE (ABS)	AAM1047				

2.1.3 Cassette 1 Mecha Unit

Parts list

Mark	No.	Description	Parts No.	Mark	No.	Description	Parts No.
	1	FLYWHEEL UNIT (FWD)	EXA1222	46	SCREW (M2×8)	ATZ20P080FMC	
	2	FLYWHEEL UNIT (RVS)	EXA1223	47	SCREW	BSZ20P050FMC	
	3	ROLLER UNIT (FWD)	EXA1224	48	SCREW	PMS26P025FUC	
	4	ROLLER UNIT (RVS)	EXA1225	49	WASHER	EBF1008	
	5	LIMITER UNIT	EXA1226	50	WASHER	EBF1009	
	6		51	WASHER	EBF1010	
	7	EJECT LEVER L2	AZN2063	52	WASHER	EBF1011	
	8	LEVER	ENV1305	53		
	9	BRAKE	ENV1317	54	ARM UNIT	EXX1006	
	10	GEAR	ENV1318	55	ARM UNIT	EXX1003	
	11	LOCK ARM	ENV1159	56	P HEAD ASSEMBLY	EXX1008	
	12	NR ARM	ENV1163	57	ARM	ENC1288	
	13		58	HEAD BASE UNIT	EXA1230	
	14	REEL	ENV1335	59		
	15	REEL BUSH	ENV1338	NSP 60	BRACKET	ENC1284	
	16	ARM	ENV1330	NSP 61	PLATE	ENC1285	
	17	EJECT LEVER L1	AZN2108	NSP 62	BRACKET	ENC1199	
	18	BUSH	ENV1184	63		
	19	MAGNET	ENV1336	NSP 64	HOLDER	ENV1161	
	20	BELT	ENT1023	NSP 65	HOLDER	ENV1301	
	21	SPRING	EBH1424	NSP 66	GEAR	ENV1177	
	22	SPRING	EBH1401	NSP 67	P HEAD UNIT	EXA1110	
	23	SPRING	EBH1203	NSP 68	SCREW	JGZ14P085FNI	
	24	SPRING	EBH1402	NSP 69	SCREW	JGZ14P040FNI	
	25		NSP 70	CHASSIS UNIT	
	26	SPRING	EBH1406				
	27	SPRING	EBH1407				
	28	SPRING	EBH1408				
	29					
	30	SPRING	EBH1409				
	31	SPRING	EBH1410				
	32	SPRING	EBH1256				
	33	SPRING	EBL1013				
	34	SPRING	EBL1014				
	35	MOTOR UNIT	EXA1241				
	36	SWITCH (Detect)	ESN1009				
	37	SWITCH (Mode)	ESN1010				
	38	SOLENOID	EXP1005				
	39	HALL IC	DN6847SE				
	40	COMPLEX PCB	ENX1020				
	41	CONNECTOR (10P)	EKS1013				
	42	LEAD WIRE (4P)	EDD1003				
	43	CONNECTOR (3P)	EDE1009				
	44	SCREW (AZIMUTH)	EBA1020				
	45					

Note :
When removing the chassis unit to replace the arm unit (EXX1003 ; No. 55 - 1/2, 2/2), the chassis unit can be easily removed by cutting the $\text{\textcircled{A}}$ part of No.55 (1/2) with a nippers, etc. (see following illustration).

A

B

C


D

A

B

C

D



XD-J115M, XD-J110

2.1.4 Cassette 2 Mecha Unit

Note :

When removing the chassis unit to replace the arm unit (EXX1003 ; No. 55-1/2, 2/2), the chassis unit can be easily removed by cutting the ③ part of No.55 (1/2) with a nippers, etc. (see following illustration).

A

B

C


D

A

B

C

D



XD-J115M, XD-J110


Parts list

Mark	No.	Description	Parts No.	Mark	No.	Description	Parts No.
	1	FLYWHEEL UNIT (FWD)	EXA1222		46	SCREW (M2 × 8)	ATZ20P080FMC
	2	FLYWHEEL UNIT (RVS)	EXA1223		47	SCREW	BSZ20P050FMC
	3	ROLLER UNIT (FWD)	EXA1224		48	SCREW	PMS26P025FUC
	4	ROLLER UNIT (RVS)	EXA1225		49	WASHER	EBF1008
	5	LIMITER UNIT	EXA1226		50	WASHER	EBF1009
	6			51	WASHER	EBF1010
	7	EJECT LEVER R2	AZN2064		52	WASHER	EBF1011
	8	NR LEVER	ENV1305		53	
	9	BRAKE	ENV1317		54	ARM UNIT	EXX1006
	10	CAM GEAR	ENV1318		55	ARM UNIT	EXX1003
	11	LOCK ARM	ENV1159		56	R/P HEAD ASSEMBLY	EXX1013
	12	NR ARM	ENV1163		57	ARM	ENC1289
	13			58	HEAD BASE UNIT	EXA1230
	14	REEL	ENV1335		59	
	15	REEL BUSH	ENV1338	NSP	60	BRACKET	ENC1284
	16	ARM	ENV1330	NSP	61	PLATE	ENC1285
	17	EJECT LEVER R1	AZN2109	NSP	62	BRACKET	ENC1289
	18	BUSH	ENV1184		63	
	19	MAGNET	ENV1336	NSP	64	HOLDER	ENV1161
	20	BELT	ENT1023	NSP	65	HOLDER	ENV1301
	21	SPRING	EBH1424	NSP	66	GEAR	ENV1177
	22	SPRING	EBH1401	NSP	67	R/P HEAD UNIT	EXA1234
	23	SPRING	EBH1203	NSP	68	SCREW	JGZ14P085FNI
	24	SPRING	EBH1402	NSP	69	SCREW	JGZ14P040FNI
	25		NSP	70	CHASSIS UNIT
	26	SPRING	EBH1406				
	27	SPRING	EBH1407				
	28	SPRING	EBH1408				
	29					
	30	SPRING	EBH1409				
	31	SPRING	EBH1410				
	32	SPRING	EBH1256				
	33	SPRING	EBL1013				
	34	SPRING	EBL1014				
	35	MOTOR UNIT	EXA1241				
	36	SWITCH (Detect)	ESN1009				
	37	SWITCH (Mode)	ESN1010				
	38	SOLENOID	EXP1005				
	39	HALL IC	DN6847SE				
	40	SUB COMPLEX PCB	ENX1019				
	41	CONNECTOR (15P)	EKS1012				
	42	LEAD WIRE (4P)	EDD1003				
	43	CONNECTOR (5P)	EDE1008				
	44	SCREW (AZIMUTH)	EBA1020				
	45					

XD-J115M


2.2 CD BLOCK

2.2.1 Multi CD Unit (For XD-J115M)



Parts list

Mark	No.	Description	Parts No.	Mark	No.	Description	Parts No.
	1	FUNCTION PANEL ASSEMBLY	PEA1270		21	FOOT ASSEMBLY	PXA1201
	2	NAME PLATE	AAM1047		22	SCREW	BBZ30P080FCC
	3	DISPLAY WINDOW	PAM1595		23	
	4	DOOR	PNW2267		24	
	5	DOOR SPRING	PBH1022		25	
	6			26	
	7	MODE BUTTON	PAC1706	NSP	27	MOTHER BOARD ASSEMBLY	PWM1728
	8		NSP	28	PCB HOLDER	PNW2100
	9	DISPLAY BOARD ASSEMBLY	PWZ2443	NSP	29	FUNCTION PANEL	PNW2327
	10	CONTROL BUTTON	PAC1705	NSP	30	FLAT CABLE	D20PYY0615
	11	22P F • F • C/30V	PDD1114	NSP	31	EARTH LEAD	XDF-503
	12	SCREW	PPZ30P080FMC				
	13	SCREW	BBZ30P060FCC				
	14					
	15	POWER BOARD ASSEMBLY	PWZ2442				
	16	SCREW	IBZ30P080FCC				
	17	SCREW	PDZ30P050FMC				
NSP	18	MULTI MECHA ASSEMBLY	PXA1469				
	19	CORD CLAMPER	RNH-184				
NSP	20	UNDER BASE	PNA1967				




2.2.2 Multi Mecha Assembly

*1: Fix the motor 101 on the loading board assembly 105 so that the label attached on the motor faces the direction illustrated.

*2: Fix the motor 101 on the motor board assembly 110 so that the label attached on the motor faces the direction illustrated.

• How to install the disc table

- 1 Use nippers or other tool to cut the three sections marked (A) and the three sections marked (B) in figure. Then remove the spacer.
- 2 While supporting the spindle motor shaft with the stopper, put spacer on top of yoke M, and stick the disc table on top (takes about 9kg pressure). Detach the spacer.




XD-J115M

Parts list

Mark No.	Description	Part No.	Mark No.	Description	Part No.
1	Motor pulley	PNW1634	49	Guide bar	PLA1094
2	Gear holder	PNW1929	50	Disc table	PNW1067
3	*****		51	Gear 1	PNW2052
4	Cam gear	PNW1923	52	Gear 2	PNW2053
5	Belt	PEB1138	53	Gear 3	PNW2054
6	Top guide	PNW2061	54	Pinion gear	PNW2055
7	Gear pulley	PNW1918	55	PWB holder	PNW2057
8	Gear S	PNW1919	56	Carriage DC motor / 0.3W	PXM1027
9	Gear L	PNW1920	57	D.C. motor assembly (spindle, with oil)	PEA1235
10	Eject spring	PBH1107			
11	Switch lever	PNW1927	58	Pickup assembly	PEA1285
12	Seven bar	PNW1931	59	Disc table assembly	PEA1035
13	Sub rotary lever	PNW1933	60	Screw	BBZ26P060FMC
14	Sub rotary lever spring	PBH1111	61	Screw	BPZ20P060FMC
15	Rotary lever	PNW1932	62	Screw	BPZ26P100FMC
16	Drive plate	PNW1930	63	Screw	JFZ17P025FZK
17	Motor screw	PBA-112	64	Screw	JFZ20P040FMC
18	Holder lever spring	PBH1110	65	Washer	WT12D032D025
19	Disc holder	PNW1924	66	*****	
20	Cushion A	PED1001	67	Stopper spring	PBH1131
21	Holder lever	PNW1925	68	Stopper	PNW2069
22	Float rubber	PEB1014	69	D.C. motor assembly (CARRIAGE)	PEA1246
23	Float rubber	PEB1132	70	Upper chassis	PNB1267
24	Float screw	PBA1073	71	Sub chassis	PNW2073
25	Release lever	PNW1934			
26	Release spring	PBH1106			
27	Clamper cam	PNW1922	NSP 101	Motor	VXM1033
28	Clamper holder	PNW1921	NSP 102	Eject lever	PNB1306
29	Clamper spring	PBH1109	103	*****	
30	Clamper	PNW1857	NSP 104	Servo mechanism assembly M	PXA1417
31	Lock lever	PNW1917			
32	Lock spring	PBH1108	NSP 105	Loading board assembly	PWZ2038
33	Stair L	PNW1915	106	*****	
34	Stair R	PNW1916	NSP 107	Rubber tube	PEB1171
35	Synchronize lever	PNW1926	NSP 108	Main chassis	PNW2074
36	Motor assembly (LOADING, DISC SELECT)	PEA1130	NSP 109	Select board assembly	PWZ2533
37	Screw	PMZ26P040FMC	NSP 110	Motor board assembly	PWZ2040
38	Screw	PPZ30P080FMC	NSP 111	Mechanism board assembly	PWX1192
39	Screw	BBZ30P060FMC	NSP 112	Earth lead unit	PDF1074
40	Washer	WT26D047D025	NSP 113	Clamp magnet	PMF1014
41	Washer	WA31D054D025	NSP 114	Gear stopper	PNB1303
42	E ring	Z39-010			
43	Screw	IPZ30P080FMC	NSP 115	Yoke M	PNB1312
44	Rubber spacer	PEB1238	NSP 116	AV angle	PNB1405
45	Rubber spacer	PEB1179	NSP 117	Carriage base	PNW2058
46	Silent ring	PBK1093			
47	Washer	WA62D130D025			
48	Earth spring	PBH1132			

XD-J110

2.2.3 Single CD Unit (For XD-J110)



Parts list

Mark No.	Description	Parts No.	Mark No.	Description	Parts No.
1	NAME PLATE	AAM1047	11	SCREW	BBZ30P160FMC
2	FUNCTION PANEL ASSEMBLY	PEA1272	12	SCREW	PDZ30P050FMC
3	DISPLAY WINDOW	PAM1594	13	CORD CLAMPER	RNH-184
4	CONTROL BUTTON	PAC1705	NSP 14	SINGLE MECHA ASSEMBLY	PXA1495
5	DISPLAY BOARD ASSEMBLY	PWZ2433	15	POWER BOARD ASSEMBLY	PWZ2437
6	24P F • F • C/30V	PDD1113	16	SCREW	BBZ30P060FMC
7	SCREW	PPZ30P080FMC	NSP 17	PCB HOLDER	PNW2100
8	NAME PLATE	PNW2234	NSP 18	UNDER BASE	PNA1967
9	SCREW	BBZ30P080FCC	19	FOOT ASSEMBLY	PXA1201
10	SCREW	PPZ30P120FMC	△ 20	MOTHER BOARD ASSEMBLY	PWM1729
			NSP 21	FUNCTION PANEL	PNW2325

A

B

C


D

A

B



C

D



2.2.4 Single Mecha Assembly


A
B
C
D



A
B
C
D

Parts list


Mark	No.	Description	Part No.
	1	Lever switch (CLAMP)	DSK1003
	2	Float screw	FBA1048
	3	Rubber belt	PEB1193
	4	Motor pulley	PNW1634
	5	Tray	PNW2290
	6	Float base	PNW2032
	7	Drive gear	PNW2266
	8	Gear pulley	PNW2034
	9	Clamper base	PNW2035
	10	Clamp cam	PNW2036
	11	DC motor/0.75W (LOADING)	PXM1010
	12	Float rubber	PEB1014
	13	Float rubber	PEB1132
	14	Screw	BPZ26P080FMC
	15	Screw	Z39 - 018
	16	Screw	PMZ26P040FMC
	17	Pinion gear	PNW2055
	18	DC motor (CARRIAGE)	PXM1027
	19	DC motor assembly (SPINDLE, with oil)	PEA1235
	20	Carriage base	PNW2058
	21	Disc table	PNW1068
	22	Screw	JFZ20P030FNI
	23	Screw	JFZ17P025FZK
	24	Gear 3	PNW2054
	25	Gear 2	PNW2053
	26	Washer	WT12D032D025
	27	Pickup assembly	PEA1179
	28	Guide bar	PLA1094
	29	Gear 1	PNW2052
NSP	30	Gear stopper	PNB1303
	31	Screw	BPZ20P060FMC
	32	PWB holder	PNW2057
	33	Screw	BPZ26P100FMC
NSP	34	Earth lead unit	PDF1104
	35	Screw	BBZ26P060FMC
NSP	36	Mechanism board assembly	PWX1192
NSP	37	Clamp magnet	PMF1014
NSP	38	Yoke	PNB1216
NSP	39	Shield plate	PNB1317
NSP	40	Clamper S	PNW1609
NSP	41	Loading base	PNW2030
NSP	42	Earth lead unit	XDF - 502
NSP	43	Servo mechanism assembly	PXA1478
NSP	44	DC motor assembly (CARRIAGE)	PEA1246



2.3 PACKING


Parts list

Mark	No.	Description	Part No.	Mark	No.	Description	Part No.
	1	OPERATING INSTRUCTIONS (English, French, German, Italian) (For XD-J115M)	ARE1266		6	FRONT PAD L, R	AHA1559
		OPERATING INSTRUCTIONS (English, French, German, Italian) (For XD-J110)	ARE1264		7	REAR PAD L, R	AHA1560
	2	OPERATING INSTRUCTIONS (Dutch, Swedish, Spanish, Portuguese) (For XD-J115M)	ARE1267		8	PACKING CASE (For XD-J115M)	AHD2507
		OPERATING INSTRUCTIONS (Dutch, Swedish, Spanish, Portuguese) (For XD-J110)	ARE1265			PACKING CASE (For XD-J110)	AHD2506
	3	REMOTE CONTROL UNIT (CU-DC030)	AXD1337	NSP	9	PACKING SHEET	AHG1151
	4	AC POWER CORD	ADG1127		10	BATTERY COVER	AZN2236
NSP	5	BATTERY (R03, AAA)	AEX-021		11	PP CASE (XD-J115M only)	PYY1169
					12	MAGAZINE ASSEMBLY (XD-J115M only)	PXA1507



3. BLOCK DIAGRAM

3.1 DECK AMP BLOCK (For XD-J115M and XD-J110)



A


B

C

D

3.2 CD BLOCK

● Multi CD Unit (For XD-J115M) and Single CD Unit (For XD-J110)



A

B

C


D

4. SCHEMATIC AND PCB CONNECTION DIAGRAMS

4.1 DECK AMP BLOCK

(For XD-J115M/HE, HB and XD-J110/HE, HB)

4.1.1 Overall Schematic Diagram



Note:

- When ordering service parts, be sure to refer to "PARTS LIST of EXPLODED VIEWS" or "PCB PARTS LIST".
- Since these are basic circuits, some parts of them or the values of some components may be changed for improvement.
- RESISTORS:**
Unit: k: kΩ, M: MΩ, Ω unless otherwise noted.
Rated power: 1/4W, 1/8W, 1/10W unless otherwise noted.
Tolerance: (F): ±1%, (G): ±2%, (K): ±10%, (M): ±20% or ±5% unless otherwise noted.
- CAPACITORS:**
Unit: p: pF or μF unless otherwise noted.
Ratings: capacitor (μF)/voltage (V) unless otherwise noted.
Rated voltage: 50V except for electrolytic capacitors.

- COILS:**
Unit: m: mH or μH unless otherwise noted.
- VOLTAGE AND CURRENT:**
V: Signal voltage at rated output.
DC: DC voltage (V) at no input signal unless otherwise noted.
Value in () is DC voltage at rated power.
mA or -mA: DC current at no input signal unless otherwise noted.
- OTHERS:**
Signal route.
Adjusting point.
Measurement point.
The Δ mark found on some component parts indicates the importance of the safety factor of the parts. Therefore, when replacing, be sure to use parts of identical designation.

- SWITCHES** (Underline indicates switch position):
DISPLAY assembly
S1801 AI BGM S1819 ASES
S1802 FUNCTION S1820 2 REC PAUSE
S1804 AI MEMORY S1901 DOLBY ON/OFF
S1805 POWER S3801 GEQ FREQ UP
S1806 1 REV S3802 GEQ LEVEL DOWN
S1807 1 PLAY S3806 SURROUND & WIDE
S1808 1 STOP S3807 GEQ LEVEL UP
S1809 2 REW S3808 GEQ MODE
S1810 2 FF S3809 SOUND SELECTOR
S1811 1 REW S3810 PRESET/PGM
S1812 1 FF S3811 GEQ ON/OFF
S1813 2 STOP S3813 SFC MOVIE/A
S1814 2 REV S3814 SFC DISCO/B
S1815 2 PLAY S3815 SFC HALL/C
S1816 COPY S3816 SFC MEMO
S1818 2 REC MUTE S3817 SFC CLEAR

9. For SCH-□ on the schematic diagram
• SCH-□ indicates the drawing number of the schematic diagram. (SCH stands for schematic diagram.)

SCH-1

Overall Schematic Diagram

Overall Schematic Diagram

SCH-1

This PCB connection diagram is vived from the foil side.


A

- (A) TO CD UNIT CN13
- (B) TO SUB TRANS assembly CN105
- (C) TO SUB TRANS assembly CN103
- (D) TO TUNER assembly
- (E) TO DISPLAY assembly CN115
- (F) TO TAPE assembly CN105
- (G) TO HEAD PHONE assembly CN108
- (H) TO VOLUME assembly J111
- (I) A IN
- (J) B IN
- (K) B OUT
- (L) A OUT
- (M) SP-RY

B

C

D



A

B

C

D

42

e

2

4

3

5

1

e

2


4

3

5

This PCB connection diagram is viewed from the parts mounted side.

4.1.2 AF Assembly



- (A) To CD UNIT CN13
 - (B) To SUB TRANS assembly CN102
 - (C) To SUB TRANS assembly CN103
 - (D) To TUNER assembly
 - (E) To DISPLAY assembly CN112
 - (F) To TAPE assembly CN105
 - (G) To HEAD PHONE assembly CN106
 - (H) To VOLUME assembly J111
 - (I) A IN
 - (J) B IN
 - (K) B OUT
 - (L) A OUT
 - (M) SP-RY
- To SW assembly

NOTE
 1. This P.C.B. connection diagram is viewed from the parts mounted side.
 2. The parts which have been mounted on the board can be replaced with those shown with the corresponding wiring symbols listed in the following Table.

P.C.B. pattern diagram indication	Corresponding part symbol	Part Name
		Transistor
		Radiator type transistor
		Diode
		Resistor
		Capacitor (Polarized)
		Capacitor (Non-polarized)


Others

P.C.B. pattern diagram indication	Part Name
	IC
	Switch
	Relay
	Coil
	Filter
	Variable resistor or Semi-fixed resistor

3. The capacitor terminal marked with ⊕ (double circles) shows negative terminal.
 4. The diode terminal marked with ⊕ (double circles) shows cathode side.
 5. The transistor terminal to which E is affixed shows the emitter.

To HEADPHONE assembly CN106 (⇒ SCH-4)


AF assembly (AWZ4645)



SCH-2

AF assembly

To DISPLAY assembly CN112 (⇒ SCH-5 (1/2))



SCH-2

AF assembly

To SUB TRANS assembly CN102 (SCH-6)


To SUB TRANS assembly CN103 (SCH-6)

- FL AC
- FL AC
- SUB 1
- SUB 3
- SUB CND
- SUB 4
- SUB 2
- MAIN1
- MAIN1
- MAIN CND
- MAIN CND
- MAIN2
- MAIN2
- PROTECT
- NC
- +5.5V
- FL-30V
- POWER RY
- 30V CND
- D.CND
- AC (TUNER)
- AC (TUNER)

XD-J115M, XD-J110

4.1.3 TAPE Assembly, 1 Mecha Unit and 2 Mecha Unit

A
B
C
D
E
F






Pin No.	Voltage [V]
1-4	0
5, 6	5
7	-5
8-11	0
12, 13	-5
14	5

Pin No.	Voltage [V]
1-3	0
4	-5
5-7	0
8	5

Pin No.	Voltage [V]
1-3	0
4	-5
5-7	0
8	5

SCH-3 TAPE assembly
1 Mecha Unit
2 Mecha Unit


- REC C-02
- PB C-02-NDR-2
- BIAS CONT
- REC MUTE
- PB MUTE
- DOLBY PB/REC
- PB 1/2
- 2 PULSE
- 1 PULSE
- 1/2R
- SOL2
- NO10R
- SOL1
- K10(COM 1M)
- K11(COM 2M)
- K00(C-02)
- K01(CHRF)
- K02(MODE)
- K03(ARR)
- K04(LRF)
- DOLBY OFF/B/C
- *** END




IC-302
5V7A.505N

Pin No.	Volts	Pin No.	Volts
1	0	8	0
2	-	9	5
3	0.4	10	7.2
4	0	11	0.4
5	4.5	12	-
6	0	13	0
7	0	14	5

This PCB connection diagram is viewed from the parts mounted side.



TAPE assembly (AWV1335)



VR4451 VR4452 VR4122 VR4121 VR4352 VR4351

Q4460-Q4462 IC4301 IC4302

Q4353-Q4355 Q4351 Q4352 IC4121


Q4321 Q4322

IC4202 Q4208 Q4209 IC4201

Q4203-Q4207


Q4421 IC4421

Q4451-Q4454 IC4151



1 2 3 4 5 6

This PCB connection diagram is viewed from the foil side.



1 Mechs Unit (EXK205) (1/2)

2 Mechs Unit (EXK205) (1/2)

TAPE assembly (WV135)

1 Mechs Unit (EXK205) (2/2)

2 Mechs Unit (EXK205) (2/2)

- IC4121
- IC44S1
- IC45S1
- IC45S2
- IC45S3
- IC45S4
- IC45S5
- IC41S1
- IC43S1
- IC43S2
- IC43S3
- IC43S4
- IC43S5
- IC43S6


4.1.4 HEADPHONE Assembly and VOLUME Assembly

A

To AF assembly J111

A

VOLUME assembly (AWZ4653)




B

To AF assembly CN106

B

HEADPHONE assembly (AWZ4666)





C

C

D

D

This PCB connection diagram is viewed from the parts mounted side.




SCH-4 HEADPHONE assembly
VOLUME assembly

HEADPHONE assembly
VOLUME assembly **SCH-4**

4.1.5 DISPLAY Assembly and SW Assembly





To AF assembly CN112 (SCH-2) or (SCH-9)



DISPLAY assembly (AWZ4656)

To AF assembly CN112

This PCB connection diagram is viewed from the parts mounted side.





SCH-5
- (2/2) SW assembly

This PCB connection diagram is viewed from the foil side.


DISPLAY assembly (AW546E) To AF assembly CN15

IC1701 IC3701 IC1705 IC3705 03801 01701 01705 IC3801


380E



IC1013 IC1014 IC1015 IC1014
IC1012 01123 01123





(AW24681 : HB type)
SUB TRANS assembly (AW24678 : HE type)




TRANS CONNECT assembly

This PCB connection diagram is viewed from the foil side.

4.1.6 SUB TRANS Assembly and TRANS CONNECT Assembly




This PCB connection diagram is viewed from the parts mounted side.



SCH-6 SUB TRANS assembly
TRANS CONNECT assembly


SUB TRANS assembly
TRANS CONNECT assembly **SCH-6**

This PCB connection diagram is viewed from the foil side.



4.2.1 Multi CD Unit (For XD-J115M)

This PCB connection diagram is viewed from the parts mounted side.





Waveforms


Note: The encircled numbers denote measuring points in the schematic diagram.

*1 50T-JUMP: After switching to the pause mode, press the manual search key.


*2 FOCUS-IN: Press the key without loading a disc.







SCH-7 MOTHER BOARD assembly
 POWER BOARD assembly
 DISPLAY BOARD assembly




To DECK AMP SECTION
 AF assembly J13 (⇔ SCH-2) or (⇔ SCH-9)

MOTHER BOARD assembly
 POWER BOARD assembly
 DISPLAY BOARD assembly



SCH-7

4.2.2 Single CD Unit (For XD-J110)




IC351 (PD4446A)


Pin No.	Voltage (V)	Pin No.	Voltage (V)	Pin No.	Voltage (V)	Pin No.	Voltage (V)
1	5.0	17	-1.1	33	5.0	49	0
2	-25.7	18	-25.7	34	1.3 to 1.1	50	NC
3	-25.7	19	-5.0	35	5.0	51	5.0
4	0	20	-19.5	36	0	52	5.0
5	-25.7	21	-19.5	37	5.0	53	5.0
6	-25.7	22	-12.1	38	2.1 to 1.7	54	5.0
7	-25.7	23	-1.1	39	0	55	0
8	-25.7	24	-1.1	40	5.0	56	2.3
9	-25.7	25	-1.1	41	NC	57	2.3
10	-25.7	26	5.0	42	0	58	0
11	-25.7	27	-12.1	43	0.5	59	0
12	0	28	-12.1	44	5.0	60	NC
13	0	29	-12.1	45	4.9	61	5.0
14	NC	30	-12.1	46	0	62	5.0
15	NC	31	0	47	0	63	0
16	-11.0	32	5.0	48	0	64	5.0



DISPLAY BOARD assembly (PWZ2433)



TO DECK AMP SECTION AF assembly J13 (⇨ SCH-2) or (⇨ SCH-9)



IC151 (CXA1372Q)

Pin No	Voltage (V)	Pin No	Voltage (V)
1	0	25	5.0
2	0	26	0
3	0	27	4.9
4	0	28	0
5	0.4	29	0
6	0	30	NC
7	0.3	31	2.5
8	0	32	2.6
9	0	33	4.9
10	5.0	34	-1.7
11	0	35	-1.9
12	0	36	5.0
13	0	37	-0.9
14	1.1	38	-2.1
15	0	39	0
16	-4.0	40	0.9
17	1.2	41	-5.0
18	0	42	0
19	-5.0	43	0
20	5.0	44	0
21	5.0	45	0
22	4.9	46	0
23	5.0	47	0
24	4.9	48	0

IC401 (TC9237BF)

Pin No	Voltage (V)	Pin No	Voltage (V)
1	5.0	15	0
2	0	16	2.5
3	5.0	17	2.8
4	5.0	18	5.0
5	2.8	19	3.0
6	2.5	20	0
7	0	21	0
8	0	22	0
9	2.5	23	0
10	2.8	24	5.0
11	5.0	25	2.5
12	0	26	2.4
13	NC	27	2.5
14	0	28	5.0

IC301 (CXD2500AQ)

Pin No	Voltage (V)	Pin No	Voltage (V)	Pin No	Voltage (V)	Pin No	Voltage (V)
1	5.0	21	0	41	NC	61	NC
2	NC	22	2.8	42	5.0	62	NC
3	5.0	23	5.0	43	NC	63	1 to 1.1
4	2.8	24	2.5	44	NC	64	NC
5	N.C.	25	NC	45	NC	65	0
6	5.0	26	0	46	4.4	66	1.5 to 4.4
7	NC	27	2.5	47	0	67	4.9
8	NC	28	0	48	0	68	0
9	0	29	NC	49	0	69	1.1 to 1.1
10	0	30	0	50	NC	70	5.0
11	NC	31	NC	51	NC	71	5.0
12	0	32	2.5	52	0	72	5.0
13	NC	33	5.0	53	2.5	73	5.0
14	NC	34	2.5	54	NC	74	5.0
15	NC	35	2.3	55	0	75	5.0
16	NC	36	NC	56	NC	76	0
17	0	37	NC	57	NC	77	5.0
18	2.8	38	NC	58	NC	78	5.0
19	2.4	39	NC	59	0	79	5.0
20	2.4	40	NC	60	NC	80	0

IC20 (M5298P)

Pin No	Voltage (V)
1	-10.0
2	NC
3	-5.0
4	0
5	-10.0
6	NC
7	NC
8	NC
9	5.0
10	NC
11	0.5
12	5.0
13	9.8
14	5.0
15	1.2
16	9.8
















MOTHER BOARD assembly
POWER BOARD assembly
DISPLAY BOARD assembly


Waveforms

Note: The encircled numbers denote measuring points in the schematic diagram.


*1 50T-JUMP: After switching to the pause mode, press the manual search key.

*2 FOCUS-IN: Press the key without loading a disc.

<p>② TP1—Pin 1 : PLAY MODE (RF) 500mV/div. 500nsec/div.</p>  <p style="text-align: right;">— GND</p>	<p>⑤ IC202—Pin4 : FOCUS-IN (*2) MODE (FODR) 1V/div. 200msec/div.</p>  <p style="text-align: right;">— GND</p>	<p>⑦ IC201—Pin3 : TRACK SEARCH MODE (SPDR) 2V/div. 50msec/div.</p>  <p style="text-align: right;">— GND</p>
<p>② TP1—Pin 1 : TRACK SEARCH MODE (RF) 500mV/div. 200μsec/div.</p>  <p style="text-align: right;">— GND</p>	<p>⑤ IC202—Pin4 : PLAY MODE (FODR) 1V/div. 1msec/div.</p>  <p style="text-align: right;">— GND</p>	<p>⑧ IC202—Pin9 : PLAY MODE (CADR) 200mV/div. 2sec/div.</p>  <p style="text-align: right;">— GND</p>
<p>③ TP1—Pin 6 : PLAY MODE (FOER) 100mV/div. 10msec/div.</p>  <p style="text-align: right;">— GND</p>	<p>⑥ IC202—Pin3 : PLAY MODE (TRDR) 500mV/div. 1msec/div.</p>  <p style="text-align: right;">— GND</p>	<p>⑧ IC202—Pin9 : TRACK SEARCH MODE (CADR) 2V/div. 500msec/div.</p>  <p style="text-align: right;">— GND</p>
<p>④ TP1—Pin 2 : PLAY MODE (TRER) 1V/div. 10msec/div.</p>  <p style="text-align: right;">— GND</p>	<p>⑥ IC202—Pin3 : 50T-JUMP (*1) MODE (TRDR) 500mV/div. 1msec/div.</p>  <p style="text-align: right;">— GND</p>	<p>⑨ IC151—Pin32 : PLAY MODE (EFM) 2V/div. 500nsec/div.</p>  <p style="text-align: right;">— GND</p>
<p>④ TP1—Pin 2 : 50T-JUMP (*1) MODE (TRER) 1V/div. 1msec/div.</p>  <p style="text-align: right;">— GND</p>	<p>⑦ IC201—Pin3 : PLAY MODE (SPDR) 1V/div. 50msec/div.</p>  <p style="text-align: right;">— GND</p>	<p>⑩ IC401—Pin9 : PLAY MODE (LO) (D/A DATA OUT) 2V/div. 0.1μsec/div.</p>  <p style="text-align: right;">— GND</p>



This PCB connection diagram is viewed from the parts mounted side.




This PCB connection diagram is viewed from the foil side.

A

B

C

D



A

B

C

D

XD-J115M

5. PCB PARTS LIST

NOTES :

- Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.
- The Δ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- Parts marked by "⊙" are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.
- When ordering resistors, first convert resistance values into code form as shown in the following examples.

Ex. 1 When there are 2 effective digits (any digit apart from 0), such as 560 ohm and 47k ohm (tolerance is shown by J = 5%, and K = 10%).

560Ω → 56 × 10¹ → 561 RD1/8PM $\overline{\text{3}} \overline{\text{6}} \overline{\text{1}} \text{J}$
 47kΩ → 47 × 10³ → 473 RD1/4PS $\overline{\text{4}} \overline{\text{7}} \overline{\text{3}} \text{J}$
 0.5Ω → 0R5 RN2H $\overline{\text{5}} \overline{\text{0}} \text{K}$
 1Ω → 010 RS1P $\overline{\text{0}} \overline{\text{1}} \overline{\text{0}} \text{K}$

Ex. 2 When there are 3 effective digits (such as in high precision metal film resistors).

5.62kΩ → 562 × 10¹ → 5621 RM1/4PC $\overline{\text{5}} \overline{\text{6}} \overline{\text{2}} \overline{\text{1}} \text{F}$

5.1 FOR XD-J115M/HE

Mark	No.	Description	Parts No.	Mark	No.	Description	Parts No.
LIST OF ASSEMBLIES					Q1253, Q1261		2SA1048
DECK AMP BLOCK					Q1002		2SA1515
		AF ASSEMBLY	AWZ4645		Q1252, Q1254, Q1262, Q1271, Q1272,		2SC2458
		VOLUME ASSEMBLY	AWZ4653		Q2201, Q2202		
		DISPLAY ASSEMBLY	AWZ4656		Q2102, Q2103, Q2203		XDA143ES
		HEADPHONE ASSEMBLY	AWZ4666		Q1003		XDC124ES
NSP		TRANS CONNECT ASSEMBLY	AWZ4672		Q2101		XDC143ES
		SUB TRANS ASSEMBLY	AWZ4678		D1201		D3SBA20 (A)
		TAPE ASSEMBLY	AWV1335		D1001, D1002, D1256, D1258 - D1261,		HSS104 - 02
		SW ASSEMBLY	AWK1746		D1901 - D1903		
CD BLOCK					D1161, D1162		RD5.1ESB2
		MOTHER BOARD ASSEMBLY	PWM1728		D1904, D1911, D1912		RD5.6ESB
		POWER BOARD ASSEMBLY	PWZ2442		D1003, D1004, D1011, D1012		S5566
		DISPLAY BOARD ASSEMBLY	PWZ2443				
NSP		LOADING BOARD ASSEMBLY	PWZ2038		RELAY		
NSP		SELECT BOARD ASSEMBLY	PWZ2533		RY1251		ASR1035
NSP		MOTOR BOARD ASSEMBLY	PWZ2040		COILS		
					L1201, L1202		ATH - 133
					L1901		LAU221K
DECK AMP BLOCK							
AF ASSEMBLY							
SEMICONDUCTORS							
		IC1010, IC1202	ICP - N10		CAPACITORS		
		IC3101, IC3102	LA3607		C1003, C1201, C1202 (2200/42)		ACH1109
		IC3103	LC7522		C2305, C2306		CCSQCH101J50
		IC1902	M51951BSL		C3307		CCSQCH102J50
		IC2101, IC3301	MC14052BF		C3129, C3130		CCSQCH221J50
					C3125, C3126, C3305, C3306		CCSQCH681J50
		IC2102	MC14066BF		C3140, C3141		CCSQL101J50
		IC1001, IC1002	MC7812CT		C1204		CEANP100M100
		IC1003	NJM78M05FAS		C1252, C1904		CEAS010M50
		IC1006	NJM7912FA		C1261, C2103, C2104		CEAS100M50
		IC1005	NJM79M05FA		C3135, C3136		CEAS101M10
		IC1901	PD5214A		C1903		CEAS101M16
		IC1201	STK4150 - 2G		C1209 - C1212		CEAS101M50
		IC2103, IC2301, IC2501, IC3302,	XRA4558F - P		C1004		CEAS102M35
		IC3303			C1005, C1006, C1011, C1205, C1206,		CEAS220M25
					C3311, C3312		

Mark	No.	Description	Parts No.
	C1271		CEAS221M16
	C1009, C1010		CEAS222M25
	C2309, C2310, C2315, C2316,		CEAS2R2M50
	C3131 - C3134, C3301, C3302		
	C2317, C2318		CEAS330M25
	C3113, C3114, C3119, C3120		CEASR15M50
	C3117, C3118		CEASR47M50
	C1007, C1008		CEHAQ220M16
	C1901, C1902, C1910		CKCYP473Z50
	C3109, C3110, C3115, C3116		CKCYX683M25
	C1207, C1208		CKPUYX182M16
	C1905 - C1909		CKSQYB102K50
	C2311, C2312		CKSQYB152K50
	C3121, C3122, C3127, C3128		CKSQYB182K50
	C3105, C3106, C3111, C3112		CKSQYB273K50
	C3103, C3104, C3123, C3124		CKSQYB472K50
	C2313, C2314		CKSQYB562K50
	C3101, C3102, C3107, C3108		CKSQYF103Z50
	C3137, C3138, C3142		CKSQYF473Z50
	C1215 - C1218		CQMA473J50
RESISTORS			
	R1007 - R1010		RD1/2PMFL100J
	R1254		RD1/4PM153J
	R1256		RD1/4PM243J
	R1015		RD1/4PM331J
	R1213, R1214		RD1/4PM4R7J
	R1211, R1212		RD1/4PM561J
	R1207, R1208		RD1/4PM563J
	R2317, R2318		RD1/4PM820J
	R1215, R1216		RD1/4PMFL100J
	R1209, R1210		RD1/4PMFL101J
	R3651, R3652		RS1/10S000J
	R2313, R2314		RS1/10S101J
	R2303, R2304, R3315 - R3318		RS1/10S102J
	R1927, R2113 - R2117, R2213, R2114,		RS1/10S103J
	R3105, R3106, R3130, R3131		
	R2108, R2315, R2316, R3301, R3302,		RS1/10S104J
	R3503, R3504		
	R3111 - R3126		RS1/10S105J
	R2311, R2312		RS1/10S122J
	R2101, R2102, R3103, R3104		RS1/10S123J
	R2103, R2104		RS1/10S133J
	R3307 - R3312		RS1/10S152J
	R2507, R2508		RS1/10S153J
	R2215, R2216		RS1/10S203J
	R2201, R2202, R2301, R2302		RS1/10S221J
	R1904 - R1908		RS1/10S222J
	R2105, R2106		RS1/10S332J
	R3305, R3306		RS1/10S333J
	R2501, R2502		RS1/10S392J
	R2109, R2110, R3511, R3512		RS1/10S472J
	R2107, R2305 - R2308, R3101, R3102		RS1/10S473J
	R2309, R2310		RS1/10S474J
	R1918, R1919		RS1/10S563J
	R2503, R2504		RS1/10S682J
	R3109, R3110		RS1/10S823J

Mark	No.	Description	Parts No.
	R1261, R1262		RS2LMFR22J
	Other Resistors		RD1/8PM□□□□
OTHERS			
	X1901 (8.00MHz)		ASS1015
	6P PIN JACK		AKB1121
	2P PIN JACK		AKB1146
	4P SPEAKER TERMINAL		AKE1012
	DC JACK		AKN - 203
	14P SOCKET		AKP1048
	CN112 40P SOCKET		AKP1085
	CN105 36P SOCKET		AKP1105
	CN106 7P JUMPER CONNECTOR		KPE7
	SCREW		BBZ30P080FZK
VOLUME ASSEMBLY			
SEMICONDUCTORS			
	IC1502		TA7291S
	IC1501		XRA4558 - P
	Q1501, Q1502		2SC2878
	Q1503		XDA124ES
CAPACITORS			
	C1507, C1508		CEAS101M16
	C1501 - C1504		CEAS220M25
	C1505, C1506		CEAS470M25
	C1511		CKDYX104M25
	C1509, C1510		CKPUYF473Z16
RESISTORS			
	VR1501 (100k - 4B*2)		ACX1053
	R1511, R1512		RD1/4PM820J
	Other Resistors		RD1/8PM□□□□
DISPLAY ASSEMBLY			
SEMICONDUCTORS			
	IC3702		BA3826S
	IC3901		PDC009A
	IC1701, IC1702		SN74LS05N
	Q3701		2SC2458
	Q3901, Q3902		XDC124ES
	Q1701, Q1702		XDC143ES
	D1701 - D1704, D1707, D1716		AEL1064
	D1705, D1706, D1709 - D1713, D1715		AEL1065
	D1708, D1714, D1801 - D1806,		HSS104 - 02
	D3702 - D3705, D3801 - D3806,		
	D3901 - D3907		
SWITCHES			
	S1801, S1802, S1804 - S1816,		ASG1034
	S1818 - S1820, S3801, S3802,		
	S3806 - S3811, S3813 - S3817		
	S1901		ASH1012

Mark	No.	Description	Parts No.
COIL			
	L3901		LAU221K
CAPACITORS			
	C3901		ACH1135
	C1901		COCCL100D50
	C3907		CEAS100M50
	C3904, C3908		CEAS470M10
	C3701, C3702		CEJA2R2M50
	C3906		CKCYB102K50
	C3703, C3905		CKPUYB102K50
	C3902, C3903		CKPUYF223Z25
RESISTORS			
	R3710, R3719		RD1/2PM2R2J
	Other Resistors		RD1/8PM□□□□
OTHERS			
	X3901 (12MHz)		ASS1062
	CN1901 40P SOCKET		AKP1085
	V3901 FL TUBE		AAV1166
	REMOTE CONTROL		AXX1023
	SENSOR UNIT		
HEADPHONE ASSEMBLY			
SEMICONDUCTORS			
	IC1231		M5216P
	Q1231, Q1232		2SC2458
	Q1233		XDA124ES
CAPACITORS			
	C1235, C1236		CEAS220M25
	C1231		CEAS2R2M50
	C1241, C1242		CEAS330M25
	C1233, C1234		CEAS470M25
	C1232		CEJA2R2M50
	C1237, C1238		CKPUYB101K50
	C1239, C1240		CKPUYB151K50
RESISTORS			
	R1243, R1244		RS1LMF820J
	Other Resistors		RD1/8PM□□□□
OTHERS			
	HEADPHONE JACK		AKN1010
TRANS CONNECT ASSEMBLY			
CAPACITORS			
	C1158, C1159		CQMXA104J100

Mark	No.	Description	Parts No.
SUB TRANS ASSEMBLY			
SEMICONDUCTORS			
	IC1015		ICP - N10
	IC1011, IC1012		ICP - N38
	IC1013, IC1014		ICP - N75
	IC1152		NJM78M12FAS
	IC1151		NJM78M56FAS
	Q1151, Q1153		2SB560
	Q1152		2SC2458
	D1154, D1156, D1159		HSS104 - 02
	D1160		RD10ESB
	D1151		RD15ESB
	D1155		RD36ESB2
	D1001 - D1009, D1152, D1153, D1157,		S5566
	D1158		
RELAY			
	RY1151		ASR1027
TRANSFORMER			
	T1151		ATT1219
CAPACITORS			
	C1101 (0.01/400)		ACG1003
	C1152, C1157		CEAS220M50
	C1133		CEAS221M100
	C1156		CEAS222M25
	C1151, C1154		CEAS470M16
	C1155		CEAS470M25
RESISTORS			
	R1152		RD1/4PM273J
	R1155, R1556		RD1/4PM470J
	Other Resistors		RD1/8PM□□□□
OTHERS			
	CN 1P AC INLET		AKP1121
TAPE ASSEMBLY			
SEMICONDUCTORS			
	IC4421		CXA1100P
	IC4202		MC14066BF
	IC4302		SN74LS05N
	IC4121, IC4151		UPC4570G2
	IC4201, IC4251, IC4301		XRA4558F - P
	Q4352, Q4904, Q4906, Q4908, Q4910		2SA1515
	Q4203, Q4204, Q4355, Q4451 - Q4454		2SC2458
	Q4205, Q4206, Q4461, Q4462		2SC2878
	Q4353, Q4354		2SC3377
	Q4321, Q4322		2SK373
	Q4207, Q4421, Q4460		XDA124ES
	Q4208		XDA143ES
	Q4905, Q4907, Q4909, Q4911		XDC124ES
	Q4209, Q4351		XDC143ES

Mark	No.	Description	Parts No.
	D4251, D4252, D4321 - D4326, D4451, D4452, D4903 - D4912		HSS104 - 02
COILS & TRANSFORMERS			
	F4401, F4402, T4351, L4301, L4302, L4303, L4304	ATF1064, ATX - 043, LTA392J, LTA822J	
CAPACITORS			
	C4362 (2000p/630), C4333, C4334, C4354, C4319, C4320, C4123, C4124	ACE1020, CCCSL100D50, CCCSL221J50, CCDSL271K500, CCSQCH331J50	
	C4252, C4151, C4152, C4253, C4303, C4304, C4403, C4404, C4453, C4454, C4254, C4213, C4214, C4358, C4363, C4405, C4406, C4409, C4410	CCSQCH560J50, CCSQCH561J50, CEAS010M50, CEAS0R1M50, CEAS100M50	
	C4133, C4134, C4161, C4162, C4402, C4455, C4456, C4321, C4322, C4309, C4310, C4353	CEAS101M10, CEAS220M16, CEAS2R2M50, CEAS330M16, CEAS3R3M50	
	C4131, C4132, C4159, C4160, C4325, C4326, C4361, C4129, C4130, C4157, C4158, C4407, C4408, C4307, C4308	CEAS470M10, CEAS470M16, CEAS4R7M50, CEASR22M50, CFTXA823J50	
	C4323, C4324, C4356, C4352, C4360, C4211, C4212, C4311, C4312, C4305, C4306	CKCYB681K50, CKCYF103Z50, CKSQYB152K50, CKSQYB223K50, CKSQYB272K50	
	C4251, C4357, C4355, C4209, C4210, C4127, C4128, C4155, C4156	CKSQYB473K50, CQMA123K250, CQMA153J50, CQMA183J50, CQMA223J50	
	C4317, C4318, C4351, C4313, C4314	CQMA333J50, CQMA562K400, CQMA822J50	
RESISTORS			
	VR4901, VR4902, VR4121, VR4122, VR4151, VR4152, VR4451, VR4452, VR4351, VR4352	VRTP6HS103, VRTP6HS202, VRTP6HS204	
	R4449, R4129, R4130, R4157, R4158, R4315, R4316, R4461, R4462, R4201, R4202, R4409, R4416 - R4418, R4420, R4422, R4307, R4308, R4419, R4209, R4210, R4459	RS1/10S000J, RS1/10S101J, RS1/10S102J, RS1/10S103J, RS1/10S104J, RS1/10S105J	

Mark	No.	Description	Parts No.
	R4257, R4421, R4127, R4128, R4155, R4156, R4123, R4124, R4151, R4152, R4219, R4220, R4252, R4253		RS1/10S123J, RS1/10S124J, RS1/10S154J, RS1/10S181J
	R4222, R4321, R4322, R4413, R4414, R4458, R4254, R4259, R4251, R4401, R4402, R4407, R4408, R4411, R4412		RS1/10S222J, RS1/10S223J, RS1/10S224J, RS1/10S242J, RS1/10S273J
	R4319, R4320, R4207, R4208, R4311, R4312, R4403, R4404, R4313, R4314		RS1/10S302J, RS1/10S332J, RS1/10S333J, RS1/10S362J, RS1/10S393J
	R4427, R4455, R4456, R4215, R4216, R4231, R4450, R4218, R4230, R4256, R4258, R4255		RS1/10S433J, RS1/10S471J, RS1/10S472J, RS1/10S473J, RS1/10S514J
	R4125, R4126, R4153, R4154, R4325, R4326, R4405, R4406, R4463, R4464, R4309, R4310, R4317, R4318		RS1/10S622J, RS1/10S681J, RS1/10S682J, RS1/10S683J, RS1/10S820J
	Other Resistors		RD1/8PM□□□□
OTHERS			
	CN 36P SOCKET		AKP1105
SW ASSEMBLY			
SEMICONDUCTORS			
	IC1		TC74HC74AP
	Q1 - Q3, Q6, Q7, Q4, Q5		XDC124ES, XDC143ES
	D1 - D14		HSS104 - 02
CAPACITORS			
	C4, C5, C2, C3, C6, C1		CCCSL101J50, CEANP100M35, CEASR15M50, CEAS101M10, CEAS220M25
RESISTORS			
	R13		RD1/4PM390J
	Other Resistors		RD1/8PM□□□□

Mark	No.	Description	Parts No.
CD BLOCK			
MOTHER BOARD ASSEMBLY			
SEMICONDUCTORS			
	IC151, IC301, IC201, IC202, IC405, IC351, IC401		CXA1372Q, CXD2500AQ, LA6520, NJM4565D - D, PD4439A, TC9237BF, 2SC1740S, 2SD2144S, DTA124ES, DTC124ES
	Q361, Q381, Q382, Q403, Q404, Q406, Q405		D381 - D383
SWITCH			
	S351		PSG1006
CAPACITORS			
	C403, C404, C435 - C438, C429, C430, C433, C434, C31 - C34, C216, C217, C302, C351		CCSQCH180J50, CCSQCH390J50, CCSQCH560J50, CEAS220M25, CEAS330M16, CEAS4R7M50, CEASR47M50, CKSQYB103K50, CKSQYB104K25, CKSQYB152K50
	C160, C162, C309, C157, C164, C167, C169, C202, C203, C205, C206, C212, C308, C354, C375, C158, C159, C161, C163, C301, C304, C306, C441, C442		CEAS4R7M50, CEASR47M50, CKSQYB182K50, CKSQYB332K50, CKSQYB333K25, CKSQYB472K50, CKSQYB473K25
	C155, C170, C156, C168, C171, C172, C307		CKSQYB182K50, CKSQYB332K50, CKSQYB333K25, CKSQYB472K50, CKSQYB473K25
	C41 - C44, C353, C356, C361, C420, C410, C411, C414 - C416, C418, C419, C422, C423, C431, C432, C421, C424, C426		CKSQYF103Z50, CKSQYF104Z25, CKSQYF473Z25
RESISTORS			
	VR151, VR152 (22k)		RCP1046
	Other Resistors		RS1/10S□□□□
OTHERS			
	CN131 12P FFC CONNECTOR, CN201 6P TOP POST, CN351 22P FFC CONNECTOR, X401 (16.9344MHz), X351 (4.19MHz)		12FM - 1.0BT, B6P - SHF, HLEM22S, PSS1008, VSS1014

Mark	No.	Description	Parts No.
POWER BOARD ASSEMBLY			
SEMICONDUCTORS			
	IC20, Q62, D1, D2		M5298P, 2SC1740S, 11ES2
CAPACITORS			
	C60, C28, C27, C11 - C16		CEAS010M50, CEAS101M10, CEAS102M10, CKCYF103Z50
RESISTORS			
	All Resistors		RD1/6PM□□□□
OTHERS			
	CN13 13P JUMPER CONNECTOR		KPE13
DISPLAY BOARD ASSEMBLY			
SEMICONDUCTORS			
	D701 - D706		1SS254
SWITCHES			
	S701 - S718		PSG1006
OTHERS			
	CN701 22P FFC CONNECTOR, V701 FL TUBE		HLEM22R, PEL1076
LOADING BOARD ASSEMBLY			
SWITCHES			
	S601, S602 PUSH SWITCH		DSG1016
SELECT BOARD ASSEMBLY			
SWITCHES			
	S604 - S606 PUSH SWITCH, S603 DETECTOR SWITCH		DSG1016, PSG1010
MOTOR BOARD ASSEMBLY			
<i>MOTOR BOARD assembly has no service part.</i>			

5.2 FOR XD-J110/HE

Mark	No.	Description	Parts No.
------	-----	-------------	-----------

LIST OF ASSEMBLIES

DECK AMP BLOCK

		AF ASSEMBLY	AWZ4645
		VOLUME ASSEMBLY	AWZ4653
		DISPLAY ASSEMBLY	AWZ4656
		HEAD PHONE ASSEMBLY	AWZ4666
NSP		TRANS CONNECT ASSEMBLY	AWZ4672

		SUB TRANS ASSEMBLY	AWZ4678
		TAPE ASSEMBLY	AWV1335
		SW ASSEMBLY	AWK1746

CD BLOCK

△		MOTHER BOARD ASSEMBLY	PWM1729
		DISPLAY BOARD ASSEMBLY	PWZ2433
		POWER BOARD ASSEMBLY	PWZ2437
NSP		MECHANISM BOARD ASSEMBLY	PWX1192

NOTE :

The DECK AMP BLOCK of XD-J110/HE is the same as that of XD-J115M/HE.
Refer to "6.1 FOR XD-J115M/HE".

MOTHER BOARD ASSEMBLY

SEMICONDUCTORS

		IC151	CXA1372Q
		IC301	CXD2500AQ
△		IC201, IC202	LA6520
		IC405	NJM4565D-D
		IC351	PD4466A
		IC401	TC9237BF
		Q381, Q382	2SC1740S
		Q403, Q404	2SD2144S
		Q406	DTA124ES
		Q405	DTC124ES

		D381-D383	1SS133X
--	--	-----------	---------

SWITCH

		S351	PSG1006
--	--	------	---------

CAPACITORS

		C403, C404	CCSQCH180J50
		C435-C438	CCSQCH390J50
		C429, C430	CCSQCH560J50
		C433, R434	CEAS220M25
		C31-C34, C216, C217, C302, C351	CEAS330M16
		C160, C162	CEAS4R7M50
		C309	CEASR47M50
		C157, C164, C167, C169, C212, C308, C354, C375	CKSQYB103K50
		C158, C159, C161, C163, C301, C304, C306, C441, C442	CKSQYB104K25
			CKSQYB152K50

		C155	CKSQYB182K50
		C170	CKSQYB332K50
		C156, C168	CKSQYB333K25

Mark	No.	Description	Parts No.
------	-----	-------------	-----------

		C171, C172	CKSQYB472K50
		C307	CKSQYB473K25

		C41-C44, C202, C203, C205, C206, C353, C356, C361, C420	CKSQYF103Z50
--	--	---	--------------

		C410, C411, C414-C416, C418, C419, C422, C423, C431, C432	CKSQYF104Z25
--	--	---	--------------

		C421, C424, C426	CKSQYF473Z25
--	--	------------------	--------------

RESISTORS

		VR151, VR152 (22k)	RCP1046
--	--	--------------------	---------

		Other Resistors	RS1/10S□□□□
--	--	-----------------	-------------

OTHERS

		CN131 12P FFC CONNECTOR	12FM-1.0BT
		CN201 6P TOP POST	B6P-SHF
		CN351 24P FFC CONNECTOR	HLEM24S
		X401 (16.9344MHZ)	PSS1008
		X351 (4.19MHZ)	VSS1014

DISPLAY BOARD ASSEMBLY

SEMICONDUCTORS

		D703-D705, D707	1SS254
--	--	-----------------	--------

SWITCHES

		S707-S714, S716-S718	PSG1006
--	--	----------------------	---------

OTHERS

		CN701 24P FFC CONNECTOR	HLEM24R
		V701 FL TUBE	PEL1062

POWER BOARD ASSEMBLY

SEMICONDUCTORS

△		IC20	M5298P
---	--	------	--------

		Q62	2SC1740S
--	--	-----	----------

△		D1, D2	11ES2
---	--	--------	-------

CAPACITORS

		C60	CEAS010M50
		C28	CEAS101M10
		C27	CEAS222M6R3
		C11-C16	CKCYF103Z50

RESISTORS

		All Resistors	RD1/6PM□□□□
--	--	---------------	-------------

OTHERS

		CN13 13P JUMPER CONNECTOR	KPE13
--	--	---------------------------	-------

MECHANISM BOARD ASSEMBLY

SWITCH

		S610 PUSH SWITCH	DSG1016
--	--	------------------	---------

6. ADJUSTMENTS

6.1 DECK AMP BLOCK (XD-J115M AND XD-J110)

6.1.1 Adjustment of Mechanical Section

- The adjustment location and the measuring location, refer to Fig. 6-4.
- Set the function switch to "TAPE".
- Test tape : STD-301 (3kHz 30min)

1. Adjustment of tape speed							
No.	Mode	Input signal & Test tape	Adjustment location		Measuring location	Adjustment value	Remarks
1	PLAY	Playback the STD-301 tape to 3kHz.	Deck I	TAPE assembly VR4901	JP-L (Lch)	Press the PLAY button and adjust the frequency to 3010Hz ±10Hz. Make sure that the wow and flutter is 3010Hz ±55Hz.	
2	PLAY (Double speed mode)			—		Press the PLAY button in double speed mode and confirm that the frequency is 6000Hz ±1000Hz. Note down the figure.	Release the double speed mode after adjustment.
3	PLAY (Double speed mode)		Deck II	TAPE assembly VR4903	JP-L (Lch)	Press the PLAY button in double speed mode and adjust the frequency to be within ±30Hz of the figure recorded at step No. 2.	Release the double speed mode after adjustment.
4	PLAY			TAPE assembly VR4902		Press the PLAY button and adjust the frequency to 3010Hz ±10Hz. Make sure that the wow and flutter is 3010Hz ±55Hz.	

Double-speed mode : The double-speed mode can be entered by short circuiting the line between TP4901 and TP4902. The mode is canceled by opening the short circuited line and switching the power to OFF.

6.1.2 Adjustment of Electrical Section

- Check and conduct the following before adjusting the electric section.

- Adjustment of tape speed has been completed.
- Clean and demagnetize the head using a head eraser.
- When measured, the level should be 0dBV = 1Vrms.
- Use side A of the specified tape for adjustment.
 - STD-331E : For adjustment of playback system.
 - STD-631 : NORMAL blank tape
- Prepare the following measuring devices :
 - AC millivoltmeter
 - Low-frequency oscillator
 - Attenuator
 - Oscilloscope
- Adjust both L and R channels, unless specified otherwise.
- Set the DOLBY NR switches to OFF, unless specified otherwise.
- Warm up the unit for several minutes before adjustment. Especially before adjusting the frequency characteristics of recording and playback, warm up for 3 to 5 minutes in REC/PLAY mode.
- Make sure to follow the proper order of the adjustment procedure. Any change in the order may cause an improper result.

Manufactured under license from Dolby Laboratories Licensing Corporation.
DOLBY and the double-D symbol are trademarks of Dolby Laboratories Licensing Corporation.

■ List of Adjustment

Deck I

- Head azimuth adjustment
- Playback level adjustment

Deck II

- Head azimuth adjustment
- Playback level adjustment
- Bias oscillation frequency adjustment
- Recording level adjustment
- Adjustment of frequency characteristics of recording/playback

*As the reference recording level is 250nwb/m for STD-331E, the recording level will be higher by 4 dB for STD-331B (160nwb/m). When adjusting, pay careful attention to the type of tape used.





Fig. 6-1 Test Tape STD-331E



REV azimuth adjustment screw FWD azimuth adjustment screw

NOTE: Before adjusting, remove the deck panel.

Fig. 6-2 Head Azimuth Adjustment




Fig. 6-3 Frequency Characteristics

Head Adjustment of Deck I

- Deck I is provided with an automatic tape selector mechanism.
- Note: Do not switch over FWD and REV while the screw driver is inserted.

1. Head Azimuth Adjustment

Procedure	Tape selector (Auto)	Mode	Input signal/test tape	Adjustment location	Measuring location	Adjustment value	Remarks
1	NORM	PLAY	Playback the test tape STD-331E (10kHz, -20dB).	Head azimuth adjustment screw (Fig. 6-2)	TAPE assembly JP-L (Lch) JP-R (Rch)	Maximum playback signal level.	Lock the screw with screw lock after completing adjustment.

2. Playback Level Adjustment

- Be sure to make a careful adjustment, as the adjustment determines the DOLBY NR level for playback.

Procedure	Tape selector (Auto)	Mode	Input signal/test tape	Adjustment location	Measuring location	Adjustment value	Remarks
1	NORM	PLAY	Playback the test tape STD-331E (315Hz, 0dB).	TAPE assembly VR4151 (Lch) VR4152 (Rch)	TAPE assembly JP-L (Lch) JP-R (Rch)	-6.3dBV	

Head Adjustment of Deck II

- Deck II is provided with an automatic tape selector mechanism.
- Note: Do not switch over FWD and REV while the screw driver is inserted.

1. Head Azimuth Adjustment

Procedure	Tape selector (Auto)	Mode	Input signal/test tape	Adjustment location	Measuring location	Adjustment value	Remarks
1	NORM	PLAY	Playback the test tape STD-331E (10kHz, -20dB).	Head azimuth adjustment screw (Fig. 6-2)	TAPE assembly JP-L (Lch) JP-R (Rch)	Maximum playback signal level.	Lock the screw with screw lock after completing adjustment.

2. Playback Level Adjustment

- Be sure to make a careful adjustment, as the adjustment determines the DOLBY NR level for playback.

Procedure	Tape selector (Auto)	Mode	Input signal/test tape	Adjustment location	Measuring location	Adjustment value	Remarks
1	NORM	PLAY	Playback the test tape STD-331E (315Hz, 0dB).	TAPE assembly VR4121 (Lch) VR4122 (Rch)	TAPE assembly JP-L (Lch) JP-R (Rch)	-6.3dBV	

3. Bias Oscillation Frequency Adjustment

Procedure	Tape selector (Auto)	Mode	Input signal/test tape	Adjustment location	Measuring location	Adjustment value	Remarks
1	NORM	REC	Load the test tape STD-631 and set to record mode.	TAPE assembly T4351	Area between ① and ② (TAPE assembly) shown in Fig. 6-4.	The oscillation frequency is 105kHz ± 5kHz.	

4. Recording Level Adjustment

Procedure	Tape selector (Auto)	Mode	Input signal/test tape	Adjustment location	Measuring location	Adjustment value	Remarks
1	NORM	REC	Apply a signal of 315Hz to the VCR input terminal and set the function to "VCR".	Input signal level	TAPE assembly JP-L (Lch) JP-R (Rch)	-10.3dBV	
2	NORM	REC/PLAY	Record and playback the test tape STD-631 (315Hz).	TAPE assembly VR4451 (Lch) VR4452 (Rch)	TAPE assembly JP-L (Lch) JP-R (Rch)	Repeat the recording/playback, and make adjustment so that the playback level of 315Hz is -10.3dBV.	

5. Adjustment of Frequency Characteristics of Recording/playback

● As this procedure is for adjustment of the recording bias, be careful not to increase the distortion by underadjusting the bias.

Pro-cedure	Tape selector (Auto)	Mode	Input signal/test tape	Adjustment location	Measuring location	Adjustment value	Remarks
1	NORM	REC	Apply a signal of 315Hz to the VCR input terminal and set the function to "VCR".	Input signal level	TAPE assembly JP-L (Lch) JP-R (Rch)	-30.3dBV	
2	NORM	REC/ PLAY	Record and playback the test tape STD-631 (315Hz and 10kHz).	TAPE assembly VR4351 (Lch) VR4352 (Rch)	TAPE assembly JP-L (Lch) JP-R (Rch)	Repeat the recording/playback, and make adjustment so that the playback level of 10kHz remains $0 \pm 0.5\text{dB}$ in relation to 315Hz.	




Fig. 6-4 Adjustment Points

6.2 CD BLOCK

6.2.1 Multi CD Unit (For XD-J115M)

If a disc player is adjusted incorrectly or inadequately, it may malfunction or not work at all even though there is nothing at all wrong with the pickup or the circuitry. Adjust correctly following the adjustment procedure.

● Adjustment Items/Verification Items and Order

If the specified values cannot be obtained or no adjustment is possible by performing the verifications or adjustments described in steps 1 - 4, the pickup block may be defective.

Step	Item	Test Point	Adjustment Location
1	Focus offset verification	TP1, Pin 6(FCS. ERR)	None
2	Tracking error balance verification	TP1, Pin 2(TRK. ERR)	None
3	Pickup radial/tangential direction tilt adjustment	TP1, Pin 1(RF)	Radial tilt adjustment screw, Tangential tilt adjustment screw
4	RF level verification	TP1, Pin 1(RF)	None
5	Focus servo loop gain adjustment	TP1, Pin 5(FCS. IN) TP1, Pin 6(FCS. ERR)	VR152(FCS. GAN)
6	Tracking servo loop gain adjustment	TP1, Pin 3(TRK. IN) TP1, Pin 2(TRK. ERR)	VR151(TRK. GAN)

● Abbreviation table

FCS. ERR	:Focus Error
TRK. ERR	:Tracking Error
FCS GAN	:Focus Gain
TRK GAN	:Tracking Gain
FCS. IN	:Focus In
TRK. IN	:Tracking In

● Measuring Instruments and Tools

1. Dual trace oscilloscope (10:1 probe)
2. Low-frequency oscillator
3. Test disc (YEDS-7)
4. Low pass filter ($39\text{k}\Omega + 0.001\ \mu\text{F}$)
5. Resistor (100 k Ω)
6. Standard tools

● Test Point and Adjustment Variable Resistor Positions




Figure 1. Adjustment Locations

● Notes

1. Use a 10:1 probe for the oscilloscope.
2. All the knob positions (settings) for the oscilloscope in the adjustment procedures are for when a 10:1 probe is used.

● Test Mode

These models have a test mode so that the adjustments and checks required for service can be carried out easily. When these models are in test mode, the keys on the front panel work differently from normal. Adjustments and checks can be carried out by operating these keys with the correct procedure. For these models, all adjustments are carried out in test mode.

[Setting these models to test mode]

How to set this model into test mode.

1. Turn off the power switch of DECK AMP.
2. Press the TEST mode switch (S351). (See Figure 1.)
3. Turn on the power switch of DECK AMP.

When the test mode is set correctly, the display is different from what it usually is when the power is turned on. If the display is still the same as usual, test mode has not been set correctly, so repeat Steps 1 - 3.

[Release from test mode]

Here is the procedure for releasing the test mode:

1. Press the STOP key and stop all operations.
2. Turn off the power switch of DECK AMP.

[Operations of the keys in test mode]

Code	Key Name	Function In Test Mode	Explanation
	PGM (PROGRAM)	Focus servo close	The laser diode is lit up and the focus actuator is lifted up, then lowered slowly and the focus servo is closed at the point where the objective lens is focused on the disc. With the player in this state, if you lightly rotate the stopped disc by hand, you can hear the sound the focus servo. If you can hear this sound, the focus servo is operating correctly. If you press this key with no disc mounted, the laser diode lights up, the focus actuator is pulled up, then the actuator is lowered and raised three times and returned to its original position.
▶ /	PLAY/PAUSE	Spindle servo ON	Starts the spindle motor in the clockwise direction and when the disc rotation reaches the prescribed speed (about 500 rpm at the inner periphery), sets the spindle servo in a closed loop. Be careful. Pressing this key when there is no disc mounted makes the spindle motor run at the maximum speed. If the focus servo does not go correctly into a closed loop or the laser light shines on the mirror section at the outermost periphery of the disc, the same symptom is occurred.
▶ /	PLAY/PAUSE	Tracking servo close/open	Pressing this key when the focus servo and spindle servo are operating correctly in closed loops puts the tracking servo into a closed loop, displays the track number being played back and the elapsed time on the front panel, and outputs the playback signal. If the elapsed time is not displayed or not counted correctly or the audio is not played back correctly, it may be that the laser is shining on the section with no sound recorded at the outer edge of the disc, that something is out of adjustment, or that there is some other problem. This key is a toggle key and open/close the tracking servo alternately. This key has no effect if no disc is mounted.

Code	Key Name	Function In Test Mode	Explanation
◀◀ • ▶▶	MANUAL / TRACK SEARCH REV	Carriage reverse (inwards)	Moves the pickup position toward the inner diameter of the disc. When this key is pressed with the tracking servo in a closed loop, the tracking servo automatically goes into an open loop. Since the motor does not automatically stop at the mechanical end point in test mode, be careful with this operation.
▶▶ • ◀◀	MANUAL / TRACK SEARCH FWD	Carriage forward (outwards)	Moves the pickup position toward the outer diameter of the disc. When this key is pressed with the tracking servo in a closed loop, the tracking servo automatically goes into an open loop. Since the motor does not automatically stop at the mechanical end point in test mode, be careful with this operation.
■	STOP	Stop	Initializes and the disc rotation stops. The pickup and disc remain where they are when this key is pressed.
▲	EJECT	CD magazine eject	Stores Disc 1 in the CD magazine, then ejects the CD magazine. However, even though the CD magazine is ejected, the pickup does not return to the park position. Even if the CD magazine is mounted again, the pickup remains where it is.

Note : When inserting the magazine, disc 1 of the magazine is loaded automatically.

[How to play back a disc in test mode]

In test mode, since the servos operate independently, playing back a disc requires that you operate the keys in the correct order to close the servos.

Here is the key operation sequence for playing back a disc in test mode.

- PGM(PROGRAM) Lights up the laser diode and closes the focus servo.
- ↓
- PLAY/PAUSE ▶/|| Starts the spindle motor and closes the spindle servo.
- ↓
- PLAY/PAUSE ▶/|| Closes the tracking servo.

Wait at least 2-3 seconds between each of these operations.

1. Focus Offset Verification

● Objective	Verify the DC offset for the focus error amp.		
● Symptom when out of adjustment	The model does not focus in and the RF signal is dirty.		
● Measurement instrument connections	Connect the oscilloscope to TP1, Pin 6 (FCS. ERR) [Settings] 5 mV/division 10 ms/division DC mode	● Player state ● Adjustment location ● Disc	Test mode, stopped (just the Power switch on) None None needed
[Procedure] Verify the DC voltage at TP1, Pin 6 (FCS. ERR) is 0 ± 50 mV.			

Note : If the specified values cannot be obtained or no adjustment is possible by performing the verifications or adjustments described in adjustment items 1 - 4, the pickup block may be defective.

2. Tracking Error Balance Verification


● Objective	To verify that there is no variation in the sensitivity of the tracking photo diode.		
● Symptom when out of adjustment	Play does not start or track search is impossible.		
● Measurement instrument connections	Connect the oscilloscope to TP1, Pin 2 (TRK. ERR). This connection may be via a low pass filter. [Settings] 50 mV/division 5 ms/division DC mode	● Player state ● Adjustment location ● Disc	Test mode, focus and spindle servos closed and tracking servo open None YEDS-7

[Procedure]

1. Move the pickup to midway across the disc (R=35 mm) with the MANUAL / TRACK SEARCH FWD ▶▶ · ▶▶ or REV |◀◀ · ◀◀ key.
2. Press the PGM(PROGRAM) key, then the PLAY/PAUSE ▶/|| key in that order to close the focus servo then the spindle servo.
3. Line up the bright line (ground) at the center of the oscilloscope screen and put the oscilloscope into DC mode.
4. Supposing that the positive amplitude of the tracking error signal at TP1, pin 2 (TRK ERR) is (A) and the negative amplitude is (B), the following expression is satisfied.

When $A \geq B$, $\frac{A-B}{C} \times \frac{1}{2} \leq 0.1$

When $A < B$, $\frac{B-A}{C} \times \frac{1}{2} \leq 0.1$





3. Pickup Radial/Tangential Tilt Adjustment

● Objective	To adjust the angle of the pickup relative to the disc so that the laser beams are shone straight down into the disc for the best read out of the RF signals.		
● Symptom when out of adjustment	Sound broken; some discs can be played but not others.		
● Measurement instrument connections	Connect the oscilloscope to TP1, Pin 1 (RF). [Settings] 20 mV/division 200 ns/division AC mode	● Player state ● Adjustment location ● Disc	Test mode, play Pickup radial tilt adjustment screw and tangential tilt adjustment screw YEDS-7

[Procedure]

1. Press the MANUAL / TRACK SEARCH FWD ►► or REV ◄◄ key to move the pickup to halfway across the disc (R=35mm). Press the PGM (PROGRAM) key, the PLAY/PAUSE ►/|| key twice in that order to close the respective servos and put the player into play mode.
2. First, adjust the radial tilt adjustment screw with a Phillips screwdriver so that the eye pattern (the diamond shape at the center of the RF signal) can be seen the most clearly.
3. Next, adjust the tangential tilt adjustment screw with a Phillips screwdriver so that the eye pattern (the diamond shape at the center of the RF signal) can be seen the most clearly (Figure 3).
4. Adjust the radial tilt adjustment screw and the tangential tilt adjustment screw again so that the eye pattern can be seen the most clearly. As necessary, adjust the two screws alternately so that the eye pattern can be seen the most clearly.
5. When the adjustment is completed, lock the radial and tangential adjustment screw.

Note: Radial and tangential mean the directions relative to the disc shown in Figure 2.



4. RF Level Verification

● Objective	To verify the playback RF signal amplitude		
● Symptom when out of adjustment	No play or no search		
● Measurement instrument connections	Connect the oscilloscope to TP1, Pin 1 (RF). [Settings] 50 mV/division 10 ms/division AC mode	● Player state ● Adjustment location ● Disc	Test mode, play None YEDS-7

[Procedure]

1. Move the pickup to midway across the disc (R=35 mm) with the MANUAL / TRACK SEARCH FWD ►► or REV ◄◄ key, then press the PGM (PROGRAM) key, the PLAY/PAUSE ►/|| key twice in that order to close the respective servos and put the player into play mode.
2. Verify the RF signal amplitude is 1.2Vp-p ± 0.2 V.

5. Focus Servo Loop Gain Adjustment

● Objective	To optimize the focus servo loop gain.		
● Symptom when out of adjustment	Playback does not start or focus actuator noisy.		
● Measurement instrument connections	See figure 4.	● Player state	Test mode, play
	[Settings] CH1 CH2 20 mV/division 5 mV/division X-Y mode	● Adjustment location	VR152 (FCS. GAN)
		● Disc	YEDS-7

[Procedure]

1. Set the AF generator output to 1.2 kHz and 1 Vp-p.
2. Press the MANUAL / TRACK SEARCH FWD ►► or REV ◄◄ key to move the pickup to halfway across the disc (R=35 mm), then press the PGM (PROGRAM) key, the PLAY/PAUSE ►/|| key twice in that order to close the corresponding servos and put the player into play mode.
3. Adjust VR152 (FCS. GAN) so that the Lissajous waveform is symmetrical about the X axis and the Y axis.





Figure 4

Focus Gain Adjustment



6. Tracking Servo Loop Gain Adjustment

● Objective	To optimize the tracking servo loop gain.		
● Symptom when out of adjustment	Playback does not start, during searches the actuator is noisy, or tracks are skipped.		
● Measurement instrument connections	See Figure 5.	● Player state	Test mode, play
	[Settings] CH1 CH2 50 mV/division 20 mV/division X-Y mode	● Adjustment location	VR151 (TRK. GAN)
		● Disc	YEDS-7

[Procedure]

1. Set the AF generator output to 1.2 kHz and 2 Vp-p.
2. Press the MANUAL / TRACK SEARCH FWD ►► or REV ◄◄ key to move the pickup to halfway across the disc (R=35 mm), then press the PGM (PROGRAM) key, the PLAY/PAUSE ►/|| key twice in that order to close the corresponding servos and put the player into play mode.
3. Adjust VR151 (TRK. GAN) so that the Lissajous waveform is symmetrical about the X axis and the Y axis.





Figure 5

Tracking Gain Adjustment



6.2.2 Single CD Unit (For XD-J110)

● Adjustment Methods

If a disc player is adjusted incorrectly or inadequately, it may malfunction or not work at all even though there is nothing at all wrong with the pickup or the circuitry. Adjust correctly following the adjustment procedure.

● Adjustment Items/Verification Items and Order

If the specified values cannot be obtained or no adjustment is possible by performing the verifications or adjustments described in steps 1 - 4, the pickup block may be defective.

Step	Item	Test Point	Adjustment Location
1	Focus offset verification	TP1, Pin 6 (FCS. ERR)	None
2	Tracking error balance verification	TP1, Pin 2 (TRK. ERR)	None
3	Pickup radial/tangential direction tilt adjustment	TP1, Pin 1 (RF)	Radial tilt adjustment screw, Tangential tilt adjustment screw
4	RF level verification	TP1, Pin 1 (RF)	None
5	Focus servo loop gain adjustment	TP1, Pin 5 (FCS. IN) TP1, Pin 6 (FCS. ERR)	VR152 (FCS. GAN)
6	Tracking servo loop gain adjustment	TP1, Pin 3 (TRK. IN) TP1, Pin 2 (TRK. ERR)	VR151 (TRK. GAN)

- Abbreviation table**
- FCS. ERR :Focus Error
 - TRK. ERR :Tracking Error
 - FCS GAN :Focus Gain
 - TRK GAN :Tracking Gain
 - FCS. IN :Focus In
 - TRK. IN :Tracking In

● Measuring Instruments and Tools

1. Dual trace oscilloscope (10:1 probe)
2. Low-frequency oscillator
3. Test disc (YEDS-7, 8cm disc)
4. Resistor (100 kΩ)
5. Standard tools

● Test Point and Adjustment Variable Resistor Positions




Figure 1. Adjustment Locations

● Notes

1. Use a 10:1 probe for the oscilloscope.
2. All the knob positions (settings) for the oscilloscope in the adjustment procedures are for when a 10:1 probe is used.

● Test Mode

These models have a test mode so that the adjustments and checks required for service can be carried out easily. When these models are in test mode, the keys on the front panel work differently from normal. Adjustments and checks can be carried out by operating these keys with the correct procedure. For these models, all adjustments are carried out in test mode.

[Setting these models to test mode]

- How to set this model into test mode.
1. Turn off the power switch of DECK AMP.
 2. Press the TEST mode switch (S351). (See Figure 1.)
 3. Turn on the power switch of DECK AMP.

When the test mode is set correctly, the display is different from what it usually is when the power is turned on. If the display is still the same as usual, test mode has not been set correctly, so repeat Steps 1 - 3.

[Release from test mode]

Here is the procedure for releasing the test mode:

1. Press the STOP key and stop all operations.
2. Turn off the power switch of DECK AMP.

[Operations of the keys in test mode]

Code	Key Name	Function in Test Mode	Explanation
	PROGRAM	Focus servo close	The laser diode is lit up and the focus actuator is lifted up, then lowered slowly and the focus servo is closed at the point where the objective lens is focused on the disc. With the player in this state, if you lightly rotate the stopped disc by hand, you can hear the sound the focus servo. If you can hear this sound, the focus servo is operating correctly. If you press this key with no disc mounted, the laser diode lights up, the focus actuator is pulled up, then the actuator is lowered and raised three times and returned to its original position.
▶/	PLAY/PAUSE	Spindle servo ON	Starts the spindle motor in the clockwise direction and when the disc rotation reaches the prescribed speed (about 500 rpm at the inner periphery), sets the spindle servo in a closed loop. Be careful. Pressing this key when there is no disc mounted makes the spindle motor run at the maximum speed. If the focus servo does not go correctly into a closed loop or the laser light shines on the mirror section at the outermost periphery of the disc, the same symptom is occurred.
▶/	PLAY/PAUSE	Tracking servo close/open	Pressing this key when the focus servo and spindle servo are operating correctly in closed loops puts the tracking servo into a closed loop, displays the track number being played back and the elapsed time on the front panel, and outputs the playback signal. If the elapsed time is not displayed or not counted correctly or the audio is not played back correctly, it may be that the laser is shining on the section with no sound recorded at the outer edge of the disc, that something is out of adjustment, or that there is some other problem. This key is a toggle key and open/close the tracking servo alternately. This key has no effect if no disc is mounted.

Code	Key Name	Function in Test Mode	Explanation
◀◀	MANUAL/ TRACK SEARCH REV	Carriage reverse (inwards)	Moves the pickup position toward the inner diameter of the disc. When this key is pressed with the tracking servo in a closed loop, the tracking servo automatically goes into an open loop. Since the motor does not automatically stop at the mechanical end point in test mode, be careful with this operation.
▶▶	MANUAL/ TRACK SEARCH FWD	Carriage forward (outwards)	Moves the pickup position toward the outer diameter of the disc. When this key is pressed with the tracking servo in a closed loop, the tracking servo automatically goes into an open loop. Since the motor does not automatically stop at the mechanical end point in test mode, be careful with this operation.
■	STOP	Stop	Initializes and the disc rotation stops. The pickup and disc remain where they are when this key is pressed.
▲	OPEN/CLOSE	Disc tray open / close	Stores Disc 1 in the CD magazine, then ejects the CD magazine. However, even though the CD magazine is ejected, the pickup does not return to the park position. Even if the CD magazine is mounted again, the pickup remains where it is.

Note : When inserting the magazine, disc 1 of the magazine is loaded automatically.

[How to play back a disc in test mode]

In test mode, since the servos operate independently, playing back a disc requires that you operate the keys in the correct order to close the servos.

Here is the key operation sequence for playing back a disc in test mode.

- PROGRAM Lights up the laser diode and closes the focus servo.
- ↓
- PLAY/PAUSE ▶/|| Starts the spindle motor and closes the spindle servo.
- ↓
- PLAY/PAUSE ▶/|| Closes the tracking servo.

Wait at least 2-3 seconds between each of these operations.

1. Focus Offset Verification

● Objective	Verify the DC offset for the focus error amp.		
● Symptom when out of adjustment	The model does not focus in and the RF signal is dirty.		
● Measurement instrument connections	Connect the oscilloscope to TP1, Pin 6 (FCS. ERR) [Settings] 5 mV/division 10 ms/division DC mode	● Player state ● Adjustment location ● Disc	Test mode, stopped (just the Power switch on) None None needed
[Procedure] Verify the DC voltage at TP1, Pin 6 (FCS. ERR) is 0 ± 50 mV.			

Note : If the specified values cannot be obtained or no adjustment is possible by performing the verifications or adjustments described in adjustment items 1 – 4, the pickup block may be defective.

2. Tracking Error Balance Verification

● Objective	To verify that there is no variation in the sensitivity of the tracking photo diode.		
● Symptom when out of adjustment	Play does not start or track search is impossible.		
● Measurement instrument connections	Connect the oscilloscope to TP1, Pin 2 (TRK. ERR). This connection may be via a low pass filter. [Settings] 50 mV/division 5 ms/division DC mode	● Player state ● Adjustment location ● Disc	Test mode, focus and spindle servos closed and tracking servo open None YEDS-7
[Procedure] 1. Move the pickup to midway across the disc (R=35 mm) with the MANUAL / TRACK SEARCH FWD ▶▶ · ▶▶ or REV ◀◀ · ◀◀ key. 2. Press the PGM (PROGRAM) key, then the PLAY / PAUSE ▶ / key in that order to close the focus servo then the spindle servo. 3. Line up the bright line (ground) at the center of the oscilloscope screen and put the oscilloscope into DC mode. 4. Supposing that the positive amplitude of the tracking error signal at TP1, pin 2 (TRK ERR) is (A) and the negative amplitude is (B), the following expression is satisfied.			
When $A \geq B$, $\frac{A-B}{C} \times \frac{1}{2} \leq 0.1$	<p>When there is a DC component</p>		
When $A < B$, $\frac{B-A}{C} \times \frac{1}{2} \leq 0.1$	<p>When there is no DC component</p>		

2. Tracking Error Balance Verification

● Objective	To verify that there is no variation in the sensitivity of the tracking photo diode.		
● Symptom when out of adjustment	Play does not start or track search is impossible.		
● Measurement instrument connections	Connect the oscilloscope to TP1, Pin 2 (TRK. ERR). This connection may be via a low pass filter.	● Player state	Test mode, focus and spindle servos closed and tracking servo open
	[Settings] 50 mV/division 5 ms/division DC mode	● Adjustment location	None
		● Disc	YEDS-7

[Procedure]

1. Move the pickup to midway across the disc (R=35 mm) with the MANUAL / TRACK SEARCH FWD ►► • ►► or ►► • ►► key.
2. Press the PROGRAM key, then the PLAY/PAUSE ►/|| key in that order to close the focus servo then the spindle servo.
3. Line up the bright line (ground) at the center of the oscilloscope screen and put the oscilloscope into DC mode.
4. Supposing that the positive amplitude of the tracking error signal at TP1, pin 2 (TRK ERR) is (A) and the negative amplitude is (B), the following expression is satisfied.

$$\text{When } A \geq B, \frac{A-B}{C} \times \frac{1}{2} \leq 0.1$$

$$\text{When } A < B, \frac{B-A}{C} \times \frac{1}{2} \leq 0.1$$




Figure 2

3. Pickup Radial/Tangential Tilt Adjustment

● Objective	To adjust the angle of the pickup relative to the disc so that the laser beams are shone straight down into the disc for the best read out of the RF signals.		
● Symptom when out of adjustment	Sound broken; some discs can be played but not others.		
● Measurement instrument connections	Connect the oscilloscope to TP1, Pin 1 (RF).	● Player state	Test mode, play
	[Settings] 20 mV/division 200 ns/division AC mode	● Adjustment location	Pickup radial tilt adjustment screw and tangential tilt adjustment screw
		● Disc	8 cm disc (However, those with approx. 20 min of audio signal (music).)

[Procedure]

1. Press the MANUAL / TRACK SEARCH FWD ►► • ►► or ►► • ►► key to move the pickup to the external circumference of the disc. Press the PROGRAM key, the PLAY/PAUSE ►/|| key, then the PLAY/PAUSE ►/|| key in that order to close the respective servos and put the player into play mode.
2. First, adjust the radial tilt adjustment screw with a hexagonal wrench so that the eye pattern (the diamond shape at the center of the RF signal) can be seen the most clearly.
3. Next, adjust the tangential tilt adjustment screw with a ball-point type hexagonal wrench so that the eye pattern (the diamond shape at the center of the RF signal) can be seen the most clearly (Figure 3).
* The ball-point type hexagonal wrench is used because the disc will get in the way if a normal hexagonal wrench is used.
4. Adjust the radial tilt adjustment screw and the tangential tilt adjustment screw again so that the eye pattern can be seen the most clearly. As necessary, adjust the two screws alternately so that the eye pattern can be seen the most clearly.
5. When the adjustment is completed, lock the radial and tangential adjustment screw.

Note: Radial and tangential mean the directions relative to the disc.





Figure 3



4. RF Level Verification

● Objective	To verify the playback RF signal amplitude		
● Symptom when out of adjustment	No play or no search		
● Measurement instrument connections	Connect the oscilloscope to TP1, Pin 1 (RF). [Settings] 50 mV/division 10 ms/division AC mode	● Player state	Test mode, play
		● Adjustment location	None
		● Disc	YEDS-7
[Procedure]			
<ol style="list-style-type: none"> 1. Move the pickup to midway across the disc (R=35 mm) with the MANUAL/TRACK SEARCH FWD ►► • ►► or ◀◀ • ◀◀ key, then press the PROGRAM key, the PLAY/PAUSE ►/ key, then the PLAY/PAUSE ►/ key in that order to close the respective servos and put the player into play mode. 2. Verify the RF signal amplitude is 1.2 Vp-p ± 0.2 V. 			

5. Focus Servo Loop Gain Adjustment

● Objective	To optimize the focus servo loop gain.		
● Symptom when out of adjustment	Playback does not start or focus actuator noisy.		
● Measurement instrument connections	See figure 4. [Settings] CH1 20 mV/division CH2 5 mV/division X - Y mode	● Player state	Test mode, play
		● Adjustment location	VR152 (FCS. GAN)
		● Disc	YEDS-7
[Procedure]			
<ol style="list-style-type: none"> 1. Set the AF generator output to 1.2 kHz and 1 Vp-p. 2. Press the MANUAL/TRACK SEARCH FWD ►► • ►► or ◀◀ • ◀◀ key to move the pickup to halfway across the disc (R=35 mm), then press the PROGRAM key, the PLAY/PAUSE ►/ key, then the PLAY/PAUSE ►/ key in that order to close the corresponding servos and put the player into play mode. 3. Adjust VR152 (FCS. GAN) so that the Lissajous waveform is symmetrical about the X axis and the Y axis. 			
<p style="text-align: center;">Figure 4</p>			
<p style="text-align: center;">Focus Gain Adjustment</p> <p style="text-align: center;">Higher gain Optimum gain Lower gain</p>			

6. Tracking Servo Loop Gain Adjustment

● Objective	To optimize the tracking servo loop gain.		
● Symptom when out of adjustment	Playback does not start, during searches the actuator is noisy, or tracks are skipped.		
● Measurement instrument connections	See Figure 5.	● Player state	Test mode, play
	[Settings] CH1 CH2 50 mV/division 20 mV/division X-Y mode	● Adjustment location	VR151 (TRK. GAN)
		● Disc	YEDS-7

- [Procedure]**
1. Set the AF generator output to 1.2 kHz and 2 Vp-p.
 2. Press the MANUAL/TRACK SEARCH FWD ►► or ◀◀ key to move the pickup to halfway across the disc (R=35 mm), then press the PROGRAM key, the PLAY/PAUSE ►/|| key, then the PLAY/PAUSE ►/|| key in that order to close the corresponding servos and put the player into play mode.
 3. Adjust VR151 (TRK. GAN) so that the Lissajous waveform is symmetrical about the X axis and the Y axis.





Figure 5

Tracking Gain Adjustment



Higher gain

Optimum gain

Lower gain

7. FOR XD-J115M/HB, HEWZIWI, XD-J110/HB AND HEWZIWI TYPES

- NOTES :**
- Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.
 - The Δ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
 - Parts marked by "⊙" are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.

7.1 FOR XD-J115M/HB AND HEWZIWI

Contrast of Miscellaneous Parts

XD-J115M/HB, HEWZIWI and HE have the same construction except for the following :

Mark	Symbol & Description	Part No.			Remarks
		HE type	HB type	HEWZIWI type	
NSP	AF assembly	AWZ4645	AWZ4645	AWZ4646	
	VOLUME assembly	AWZ4653	AWZ4653	AWZ4654	
	HEADPHONE assembly	AWZ4666	AWZ4666	AWZ4667	
	TRANS CONNECT assembly	AWZ4672	AWZ4672	AWZ4673	
	SUB TRANS assembly	AWZ4678	AWZ4681	AWZ4679	
Δ	AC Power cord	ADG1127	ADG1118	ADG1127	
	Strain relief	AEC-882	
NSP	Rear panel	ANC2008	ANC2009	ANC2008	(Rear panel)
	Screw (GND)	ABA1047	
	Name plate	AAL2022	AAL2021	AAL2023	
	Operating instructions (English, French, German, Italian)	ARE1266	
	Operating instructions (Dutch, Swedish, Spanish, Portuguese)	ARE1267	
	Operating instructions (English)	ARB1409	
	Operating instructions (German, Italian)	ARC1399	

VOLUME Assembly

AWZ4654 and AWZ 4653 have the same construction except for the following :

Mark	Symbol & Description	Part No.		Remarks
		AWZ4653	AWZ4654	
	C1513, C1514	CCPJSL330J50	

AF Assem
AWZ4646

Mark	
	L12
	C13
	C1
	C1
	C1
	C2
	C3
	C2
	C2
	C2
	C2
	C1
	C1
	R1
	R1
	R1

TRANS C
AWZ467

Mark	
	C

SUB TR
AWZ468

Mark	

AF Assembly
AWZ4646 and AWZ 4645 have the same construction except for the following :

Mark	Symbol & Description	Part No.		Remarks
		AWZ4645	AWZ4646	
	L1201, L1202	ATH-133	ATH-059	
	C1219, C1220	CKDYF473Z50	
	C1221, C1222, C1312	CKCYB103K50	
	C1223, C1224	CCPUSL470J50	
	C1311	CKDYB103K50	
	C1317	CKCYF473Z50	
	C2101, C2102, C2307, C2308, C3303, C3304, C3501, C3502	CCSQCH101J50	
	C2201-C2206, C2301, C2302	CCSQCH391J50	
	C2207-2210	CKCYB391K50	
	C2303, C2304	CKSQYB222K50	
	C2305, C2306	CCSQCH101J50	
	C2319, C2320, C2503, C2504	CKSQYB472K50	
	C2321, C2322	CKSQYB102K50	
	R1215, R1216	RD1/4PMFL100J	RD1/4PMFL101J	
	R1217, R1218	RD1/4PM100J	
	R1313	RD1/8PM100J	
	R2301, R2302	RS1/10S221J	RS1/10S102J	
	2P Pin jack	AKB1146	AKB1100	

TRANS CONNECT Assembly
AWZ4673 and AWZ4672 have the same construction except for the following :

Mark	Symbol & Description	Part No.		Remarks
		AWZ4672	AWZ4673	
	C1160, C1161	COMXA104J100	

SUB TRANS Assembly
AWZ4681, AWZ4679 and AWZ4678 have the same construction except for the following :

Mark	Symbol & Description	Part No.			Remarks
		AWZ4678	AWZ4681	AWZ4679	
	L1101	ATF-151	
	C1162	COMXA104J100	
	CN 1P AC inlet	AKP1121	AKP1121	

HEADPHONE Assembly
AWZ4667 and AWZ4666 have the same construction except for the following :

Mark	Symbol & Description	Part No.		Remarks
		AWZ4666	AWZ4667	
	C1243, C1244, C1249, C1250 C1245, C1246, C1248	CKPUYB101K50 CKPUYF473Z16	

7.2 FOR XD-J110/HB AND HEWZI
Contrast of Miscellaneous Parts

XD-J110/HB, HEWZI and HE have the same construction except for the following :

Mark	Symbol & Description	Part No.			Remarks
		HE type	HB type	HEWZI type	
NSP	AF assembly	AWZ4645	AWZ4645	AWZ4646	
	VOLUME assembly	AWZ4653	AWZ4653	AWZ4654	
	HEADPHONE assembly	AWZ4666	AWZ4666	AWZ4667	
	TRANS CONNECT assembly	AWZ4672	AWZ4672	AWZ4673	
	SUB TRANS assembly	AWZ4678	AWZ4681	AWZ4679	
Δ	AC Power cord	ADG1127	ADG1118	ADG1127	
Δ	Strain relief	AEC-882	
	Rear panel	ANC2008	ANC2009	ANC2008	(Rear panel)
	Screw (GND)	ABA1047	
NSP	Name plate	AAL2019	AAL2018	AAL2020	
	Operating instructions (English, French, German, Italian)	ARE1264	
	Operating instructions (Dutch, Swedish, Spanish, Portuguese)	ARE1265	
	Operating instructions (English)	ARB1408	
	Operating instructions (German, Italian)	ARC1398	


Note : All assemblies of XD-J110/HB and HEWZI are the same as those of XD-J115M/HB and HEWZI.
Refer to "7.1 XD-J115M/HB AND HEWZI".

7.3 SCHEMATIC DIAGRAMS AND PCB PATTERNS
(For XD-J115M/HEWZIW and XD-J110/HEWZIW)

7.3.1 AF Assembly

To HEADPHONE assembly CN106 (⇒ SCH-10)

A
B
C
D
E
F



AF assembly
SCH-9

Q6 (→ SCH-10)

To VOLUME assembly J111 (→ SCH-10)

P.V. con -- VOLUME Assy -->

ROTECT / for SP RT Cont.

IB

TOP INP/PLG

FRONT
-14dB
REC. MIC MIX

for AMP u-con.,
for AMP u-con.

for DISP. Assy (SPA SIC)

FRONT DISP. ASSY

R1513 C1517
10 1/4W 0.047

SPEAKERS (REAR)

R1217 C1526
10 1/4W 1000µ
R1218 1000µ
10 1/4W

SPEAKERS (FRONT)

+5V

- FL AC
- FL AC
- SUB 1
- SUB 3
- SUB CND
- SUB 4
- SUB 2
- MAIN1
- MAIN1
- MAIN CND
- MAIN CND
- MAIN2
- MAIN2
- PROTECT
- NC
- +5.6V
- FL-30V
- POWER RT
- 30V CND
- D.CND
- AC (TUNER)
- AC (TUNER)

To SUB TRANS assembly
CN102 (→ SCH-11)

To SUB TRANS assembly
CN103 (→ SCH-11)


SCH-9

AF assembly

This PCB connection diagram is viewed from the parts mounted side.

IC2301	IC2103 IC2101	Q2201-Q2203	Q1262Q1261Q1272Q1271Q1254IC1010	Q1252 Q1253	IC1005	IC1201
IC1902	IC3103 IC1901	IC2102 IC3102 Q2101-Q2103	IC2501 IC3302	Q1002 Q1003	IC1003	IC1006 IC1002
		IC3104	IC3301 IC3303	IC1202		IC1001

AF assembly (AWZ4646)



A
B
C
D

A
B
C
D

7.3.2 HEADPHONE Assembly and VOLUME Assembly

A

—

B


—

C

—

D

HEADPHONE assembly (AWZ4667)



A

—

B


—

C



—

D

VOLUME assembly (AWZ4654)



This PCB connection diagram is viewed from the parts mounted side.




SCH-10 HEADPHONE assembly
VOLUME assembly

To AF assembly J111 (⇨ SCH-9)

HEADPHONE assembly
VOLUME assembly **SCH-10**

7.3.3 SUB TRANS Assembly and TRANS CONNECT Assembly



A
B
C
D

A
B
C
D

SCH-11

SCH-11

Line Voltage Selection
Line voltage can be changed with the following steps.
1. Disconnect the AC Power cord.
2. Remove the top cover.
3. Change the connection with the power transformer (T1) primary taps.
4. Stick the line voltage label on the rear panel.


Part No.	Description
AAX-193	220V label
AAX-192	240V label

SUB TRANS assembly
TRANS CONNECT assembly


This PCB connection diagram is viewed from the parts mounted side.

A

A



SUB TRANS assembly (AWZ4679)



TRANS CONNECT assembly

B

B

C

C

D


D

XD-J115M, XD-J110

8. PANEL FACILITIES

REAR PANEL FACILITIES

XD-J115M/XD-J110



Multi-CD cassette deck amplifier: XD-J115M
CD cassette deck amplifier: XD-J110

① SURROUND SPEAKERS jacks

Connect the surround speaker systems.

NOTE:

Connect a speaker system having a nominal impedance of 16 Ω or more.

② SPEAKERS terminals

L: Connect the left speaker system as seen from the listening position.
R: Connect the right speaker system as seen from the listening position.

NOTE:

Connect a speaker system having a nominal impedance ranging from 8 Ω to 16 Ω .

③ TUNER jacks

Connect the tuner flat cable here.

④ AC INLET jack

Connect the power cord here.

⑤ VCR IN/OUT jacks

IN : Connect to audio output jacks of VCR.
OUT : Connect to audio input jacks of VCR.

⑥ PHONO Input jacks

Connect the audio cord of the turntable to these jacks.






⑦ Ground terminal (GND)

Connect this to the ground terminal on the turntable (except for PL-J210)

⑧ TURNTABLE (DC 12V OUTPUT) jack

This jack supplies power to the turntable PL-J210.
Connect the power supply cord of the turntable to this jack.

[XD-J115M]



FRONT PANEL FACILITIES

Multi-CD cassette deck amplifier: XD-J115M

- This unit has an automatic tape type selector.
- Tapes can be played back on deck I; tapes can be played back and recorded on deck II.
- Sound can be recorded as adjusted by the graphic equalizer (excluding synchro copy).
- Use a TYPE I (normal) or TYPE II (High/CrO₂) tape.


A : Amplifier section

① POWER STANDBY/ON switch, STANDBY Indicator


This is the switch for electric power.
ON : When set to the ON position, power is supplied and the unit becomes operational.
STANDBY : When set to the STANDBY position, the main power flow is cut and the unit is no longer fully operational. A minute flow of power feeds the unit to maintain operation readiness.
 The unit is in STANDBY when only the STANDBY indicator above the POWER switch is lit.

② REMOTE SENSOR window

③ FUNCTION (DEMO) button and indicators
 Used to select the desired source. Each time this button is pressed, the source switches as follows. The desired indicator lights.



④ Display section



- A Visual display of spectrum analyzer and graphic equalizer.
- B This lights when the GEQ ON/OFF button is on.
- C Display of the memory being recalled with the GEQ MODE button (A, B, C, D or E lights) or SOUND FIELD CONTROL button (A, B or C lights).
- D These under lines indicate the memory (PRESET or PROGRAM) that can be recalled with the PRESET/PGM or GEQ MODE button.

⑤ VOL. (Volume) control

⑥ SOUND FIELD CONTROL buttons and indicators

Used for calling the preset memory (MOVIE, DISCO, HALL) of the sound field control and for setting your own original memory (PROGRAM A, B, C). The SFC will light when MOVIE, DISCO, or HALL is called.

⑨ GEQ MODE button

Use to recall preset equalization settings. Also use to program into memory and recall desired sound field settings.

⑩ SFC OFF button

Press to reset the sound field control to no effect. Turns off SURROUND & WIDE and adjusts GEQ to FLAT.

⑪ MEMORY button

Use to memorize your desired sound field control setting.

⑫ SMART OPERATION buttons

[START/SET]
 Use when programming memory and operating SMART OPERATION.
[MEMORY]
 Use when programming SMART OPERATION into memory.

⑬ PRESET/PGM button


Use to switch between recall of PRESET memory settings and your own original memory settings (PROGRAM) with the GEQ MODE button or SOUND FIELD CONTROL buttons. The memory being recalled is indicated by the indicator in the display section.

⑭ CUSOR EQUALIZER buttons

Use to adjust graphic equalizer settings.
[←, →] : Use these to change the frequency range to be adjusted.
[UP, DOWN] : Use these to adjust the degree of equalization.

⑮ SURROUND & WIDE button and Indicator

By turning this switch ON, you can enjoy surround reproduction when surround speakers are used.
 By turning this button ON, you can enjoy WIDE reproduction with greater left-right spread when surround speakers are not used.
 Each time this button is pressed, WIDE effects switches as follows.



The WIDE effects of the sound intensify in the order of WIDE 1→2→3. The SURROUND & WIDE indicator will light.

NOTE:
 In the case of monaural source, SURROUND & WIDE effects cannot be obtained.

⑯ GEQ ON/OFF button

This switches the graphic equalizer on/off. When it's on, the indicator in the display section lights.

⑰ GEQ MODE printed indicators

Displays of the preset equalization pattern name being recalled with the GEQ MODE button.

⑥ : **Cassette deck section**

① **Deck I cassette door**

② **Deck I operation buttons**

- ▶ (PLAY: FWD) : For playing back a tape in the forward mode.
- ◀ (PLAY: REV) : For playing back a tape in the reverse mode.
- (STOP) : For stopping the tape.
- ▶▶ (FAST) : Fast forward in forward mode, rewind in reverse mode. Music Search can also be carried out.
- ◀◀ (FAST) : Rewind in forward mode, fast forward in reverse mode. Music Search can also be carried out.

③ **Deck II operations buttons**

Same as Deck I operation buttons ②.

④ **Deck II cassette door**

⑤ **Deck I EJECT button (▲)**

⑥ **DOLBY*NR switch**



Only the Dolby B-type NR for XD-J115M.

Manufactured under license from Dolby Laboratories Licensing Corporation.
DOLBY and the double-D symbol are trademarks of Dolby Laboratories Licensing Corporation.

⑦ **PHONES (Head phones) jack**

For stereo headphones.

NOTE:
There is no output from the speakers when headphones are plugged into the PHONES jack.

⑧ **ASES button**

Used for recording a CD on a cassette tape automatically.

- NOTE:**
- FINE is the mode when performing CD player EDIT (Computer Allocated Program Editing).
 - The NORMAL mode provide a blank space of about five seconds between songs.

⑨ **Operation indicators**



- ① **Direction (◀, ▶)**: Indicates direction of tape travel during recording or playback.
- ② **ASES**: Lights when in the ASES mode.
- ③ **REC (MUTE)**: Lights when in REC or REC mute.

⑩ **COPY button**

Used for tape copying.
Copying from the deck I tape to the deck II tape at normal recording/playback speed.

⑪ **Deck II control buttons**

● **II (REC PAUSE)** : Pressing this button sets recording standby mode. Pressing the play button (▶ or ▶▶) next starts recording. Pressing this button during recording sets Rec pause mode.

Temporarily stops tape travel. Cancels pause mode when pressed again or press the play button.

○ **(MUTE)** : Used for creating a blank space between songs. Pressing this button once creates an unrecorded 4-second space. Continuing to press the button creates an unrecorded space as long as the time the button is pressed.

⑫ **Deck II EJECT button (▲)**

⑬ : **CD player section**

① **TIME button**

Use to select the method for displaying the playing time on the display section.

Each time the button is pressed, the indication changes from TIME, REMAIN (track remain) and REMAIN (disc remain): This will not be displayed during programmed playback to TOTAL in that order.


② **REPEAT button**

Press this button for repeat playback. Pressing the button once, twice or three times will change the repeat mode from single track repeat, to all tracks repeat, and repeat playback cancellation respectively.

③ **RANDOM**

Press to begin random playback.

④ **Display section**



- ① **DISC SCAN** : Lights after pressing the HI-LITE SCAN button.
- ② **EDIT (COMPU)** : Normally EDIT COMPU is light. When the EDIT button is pressed, ▶ mark lights up.
- ③ **▶** : Lights during playback.
- ④ **II** : Lights during temporarily interrupted playback.
- ⑤ **C-DISC symbol** : If a nonexistent disc is searched for, the corresponding disc symbol goes off.
- ⑥ **PROGRAM** : Lights after programming (after program has been memorized).
- ⑦ **RANDOM** : Lights during random playback.
- ⑧ **(1) REPEAT** : Lights during repeat playback of one tune. (1) extinguishes during repeat playback of all tunes.
- ⑨ **DELETE** : Lights during delete.
- ⑩ **DISC TRACK** : Indicates the disc and the track currently being heard.
- ⑪ **"SS:SS"** : Displays the minutes and seconds of the elapsed time, total playback time, and remaining time.

NOTE:
When power is tuned on, the CD player section indicators show different indications depending on the condition (disc loaded or not, etc.) prior to when the power was turned off. This is not a malfunction.

⑫ **DISC NUMBER buttons (1—6)**

Use to select disc numbers for playback or programming.

⑬ **EJECT button (▲)**

Press to eject a magazine. When pressed, any magazine inside is expelled forward.

⑭ **HI-LITE SCAN button**

If this button is pressed while the unit is stopped, the first 10 seconds after the first minute of the first tune on each of the discs from DISC 1 to DISC 6 are played back in sequence (DISC SCAN). If this button is pressed during DISC SCAN, the first ten seconds after the first minute of all the tunes on each of discs from DISC 1 to DISC 6 are played back (TRACK SCAN).

To reset the start-up time of HI-LITE SCAN, press the HI-LITE SCAN button during normal playback.

Enter the time of current playback in memory and 10-second passages on all the remaining tracks are played back at the memorized time.

⑮ **EDIT button**

Press this button and designate the number of minutes of tape for recording with the Manual/Track search button. The CD player then selects tunes and programs them automatically for recording so that the unrecorded portion at the end of the tape is at the shortest distance.

⑯ **PROGRAM button**

Use to program a sequence of tracks.

- When this button is pressed, the "PROGRAM" indicator will light. Select a desired disc and track with DISC NUMBER buttons and Manual/Track search buttons. Tunes will be added to the order in which they are specified.
- If only a DISC NUMBER button is pressed, all tracks on the specified disc will be added to the program. The letters "AL" will appear on the indicator.

⑰ **DELETE button**

Pressing this button and then selecting the discs with the DISC NUMBER buttons (1 through 6) of selecting the tracks with the Manual/Track search buttons will result in the selected discs and tracks not being played even when the PLAY/PAUSE button is pressed.

⑱ **Magazine insertion slot**

⑲ **Manual/Track search buttons (◀◀, ▶▶, ▶▶▶, ▶▶▶▶)**

These buttons are used for track search and manual search during normal playback, programmed playback or pause. When these buttons are pressed, either the previous tune or the next tune is established. If they are kept depressed, either fast forward or reverse is established, depending upon the direction of pressing.

⑳ **STOP button (■)**

Press to stop playback. When pressed, the player goes into the stop mode and all operations stop.

[LAST DISC MEMORY]

If no program had been input when the STOP button (■) is pressed to stop the disc, the number of the disc that was just played will be displayed. (the song number is "01").

When the STOP button (■) is pressed another time, the DISC NUMBER displayed will change to "1".

If a program had been input, the disc will be stopped with the DISC NUMBER of the first step and song number displayed.

㉑ **PLAY/PAUSE button (▶/II)**

During stop, press this button to start playback. During playback, press this button to pause.


When this button is pressed during highlight scanning, the highlight scan will be released, and the disc will be played normally.

Remote control unit

① POWER button

② FUNCTION button


The amplifier function automatically switches to the music source being operated when you press the CD playback (▶) cassette deck playback (◀, ▶) or tuner station controls. Use to switch the input. Each time this button is pressed, it switches as follows:



The desired indicator lights.

④ SFC MODE button


Use to select one of the preset sound fields. Each time the button is pressed, one of the preset sound fields will be selected, in the following order:



Turn off SURROUND & WIDE and adjusts GEO to FLAT.

⑤ PGM MODE button

This button is used when selecting one of your own personally created sound fields. Each time the button is pressed, one of the sound fields will be selected, in the following order:



Turn off SURROUND & WIDE and adjusts GEO to FLAT.

⑥ SCAN button

Press to perform automatic scan of the broadcast stations preset in the unit's memory.

⑦ Deck operation buttons.

- ▶ : Begins playback
- ◀, ▶ : Fast forward or rewind
- : Stop
- II : Pressing this button sets recording standby mode. Pressing the play button (▶) next starts recording. Pressing this button during recording sets REC PAUSE mode. Temporarily stops tape travel. Cancels pause mode press the play button.
- SHIFT TAPE I : To operate deck I, press the desired deck operation while pressing this button.

⑧ Timer operation buttons

- SLEEP : Sets the sleep timer.
- SNOOZE : Turns off power if pressed after timer playback begins. Timer playback begins again approx. 5 minutes later.
- WAKE-UP : Timer playback setting/cancellation can be performed when the timer playback time has been set.

⑨ VOLUME + (UP)/- (DOWN) buttons

When pressed, VOLUME on the amplifier is actually moved by a motor.






⑩ TUNER STATION - (DOWN), + (UP) buttons

Used for locating stations. (see page 20)
 - (DOWN) : Stations change in order in the downward direction.
 + (UP) : Stations change in order in the upward direction.

⑫ CD operation buttons

- ▶ : Play
- DISC : DISC selection
- : Stop
- II : Pause (To release, press PAUSE button once more, press PLAY button, or press the PLAY/PAUSE button of the main unit.)
- ◀, ▶ : Track search

XD-J110



FRONT PANEL FACILITIES

CD cassette deck amplifier: XD-J110

- This unit has an automatic tape type selector.
- Tapes can be played back on deck I; tapes can be played back and recorded on deck II.
- Sound can be recorded as adjusted by the graphic equalizer (excluding synchro copy).
- Use a TYPE I (normal) or TYPE II (High/CrO2) tape.

A : Amplifier section


1 POWER STANDBY/ON switch/STANDBY indicator

This is the switch for electric power.
ON : When set to the ON position, power is supplied and the unit becomes operational.
STANDBY : When set to the STANDBY position, the main power flow is cut and the unit is no longer fully operational. A minute flow of power feeds the unit to maintain operation readiness.
 The unit is in STANDBY when only the STANDBY indicator above the POWER switch is lit.


2 REMOTE SENSOR window

3 FUNCTION (DEMO) button and indicators

Used to select the desired source. Each time this button is pressed, the source switches as follows. The desired indicator lights.



4 Display section



- A** Visual display of spectrum analyzer and graphic equalizer.
- B** This lights when the GEQ ON/OFF button is on.
- C** Display of the memory being recalled with the GEQ MODE button (A, B, C, D or E lights) or SOUND FIELD CONTROL button (A, B or C lights).
- D** These under lines indicate the memory (PRESET or PROGRAM) that can be recalled with the PRESET/PGM or GEQ MODE button.

5 VOL. (Volume) control

6 SOUND FIELD CONTROL buttons and indicator (MOVIE/A, DISCO/B, HALL/C)

Used when calling the preset memory (MOVIE, DISCO, HALL) of sound field control and setting your own original memory (PROGRAM-A, B, C).
 The SFC and SURROUND & WIDE indicators will light when MOVIE, DISCO, or HALL is called.

9 GEQ MODE button

Use to recall preset equalization settings. Also use to program into memory desired sound field settings.

10 SFC OFF button

Press to reset the sound field control to no effect.
 Turns off SURROUND & WIDE and adjusts GEQ to FLAT.

11 MEMORY button

Use to memorize your desired sound field control setting.

12 SMART OPERATION buttons

[START/SET]
 Use when programming memory and operating SMART OPERATION.
[MEMORY]
 Use when programming SMART OPERATION into memory.

3 PRESET/PGM (PROGRAM) button


Use to switch between recall of PRESET memory settings and your own original memory settings (PROGRAM) with the GEQ MODE button or SOUND FIELD CONTROL buttons. The memory being recalled is indicated by the indicator in the display section.

4 CUSOR EQUALIZER buttons

Use to adjust graphic equalizer settings.
[←, →] : Use these to change the frequency range to be adjusted.
[UP, DOWN] : Use these to adjust the degree of equalization.

15 SURROUND & WIDE button and indicator

By turning this switch ON, you can enjoy surround reproduction when surround speakers are used.
 By turning this button ON, you can enjoy WIDE reproduction with greater left-right spread when surround speakers are not used.
 Each time this button is pressed, WIDE effects switches as follows.



The WIDE effects of the sound intensify in the order of WIDE 1→2→3. The SURROUND & WIDE indicator will light.

NOTE:
 In the case of monaural source, SURROUND & WIDE effects cannot be obtained.

16 GEQ ON/OFF button

This switches the graphic equalizer ON/OFF. When it's ON the GEQ indicator in the display section lights.

NOTE:
 Sound comes from the surround speakers regardless of whether this button is on or off.

18 GEQ MODE printed indications

Displays of the preset equalization pattern name being recalled with the GEQ MODE button.

B : Cassette Deck Section

1 Deck I cassette door

2 Deck I operation buttons

- ▶ (PLAY: FWD)** : For playing back a tape in the forward mode.
- ◀ (PLAY: REV)** : For playing back a tape in the reverse mode.
- (STOP)** : For stopping the tape.
- ▶▶ (FAST)** : Fast forward in forward mode, rewind in reverse mode. Music Search can also be carried out.
- ◀◀ (FAST)** : Rewind in forward mode, fast forward in reverse mode. Music Search can also be carried out.

3 Deck II operations buttons

Same as Deck I operation buttons 2.

4 Deck II cassette door

5 Deck I EJECT button (▲)

6 DOLBY* NR switch



Only the Dolby B-type NR for XD-J110.

- * *Dolby noise reduction manufactured under license from Dolby Laboratories Licensing Corporation.*
- * *"DOLBY" and the double-D symbol DD are trademarks of Dolby Laboratories Licensing Corporation.*

7 PHONES (Headphones) jack

For stereo headphones.


NOTE:
 There is no output from the speakers when headphones are plugged into the PHONES jack.

8 ASES button

Used for recording a CD on a cassette tape automatically.

- NOTE:**
- *FINE is the mode when performing CD player EDIT (Computer Allocated Program Editing).*
- *The NORMAL mode provides a blank space of about five seconds between songs.*

9 Operation Indicators



- A** **Direction (←, →)** : Indicates direction of tape travel during recording or playback. Flashes slowly in Pause mode. Flashes rapidly during Music Search (MS).

B **ASES:**

Lights when in the ASES mode.

C **REC (MUTE):**

Lights when it flashes during tape copying.

10 COPY button

Used for tape copying.
 Copying from the deck I tape to the deck II tape at normal recording/playback speed.

11 Deck II CONTROL buttons


- II (REC PAUSE)** : Pressing this button sets recording standby mode. Pressing the PLAY button (▶ or ▶▶) next starts recording. Pressing this button during recording sets REC PAUSE mode. Temporarily stops tape travel. Cancels pause mode when pressed again or press the PLAY button.
- O (MUTE)** : Used for creating a blank space between songs. Pressing this button once creates an unrecorded 4-second space. Continuing to press the button creates an unrecorded space as long as the time the button is pressed.

12 Deck II EJECT button (▲)

④ : **CD player section**

① Disc tray

② Display section



- ① **A** : Display when Compu PGM editing is set or used.
- ② **(1) ► REP** : Lights during repeat playback of single track or all tracks.
- ③ **►** : Lights during playback.
- ④ **II** : Lights during temporarily interrupted playback.
- ⑤ **RND** : Lights during random playback.
- ⑥ **SCAN** : Lights during HI-LITE scan playback.
- ⑦ **A/B (music calendar)** : TAPE SIDE A/TAPE SIDE B
After editing, the track numbers that can be recorded on the A (B) side of the tape will light.
- ⑧ **TRACK (figure)** : Displays the current track number (during normal playback and programmed playback) or the track being programmed (during programmed operation).
- ⑨ **PROGRAM** : Lights after programming (after program has been memorized).
- ⑩ **Minutes (figure)** : Displays the minutes of the elapsed time, total playback time, and remaining time.
- ⑪ **Seconds (figure)** : Displays the seconds of the elapsed time, total playback time, and remaining time.
- ⑫ **1-12 (music calendar)** : Displays the track numbers.

NOTE:

- When power is turned ON, the CD player section indicators show different indications depending on the condition (disc loaded or not, etc.) prior to when the power was turned off. This is not a malfunction.

③ **TIME button**

This button selects the display mode. Each time the button is pressed, the display changes from Time, Remain, to Total in that order.

- **Time** : Displays the track number of the track being played (TRACK) and the elapsed time (minutes and seconds).
- **Remain** : Displays the remaining time on the track being played. When the TIME button is pressed again, the remaining time on the disc being played will be displayed.
- **Total** : Displays the total number of tracks on the disc (TRACK) and the total playback time will be displayed. During playback, the display goes on for about 5 seconds before changing to the time display.

④ **RANDOM Play button**

Press to begin random playback.

⑤ **PROGRAM button**

Use to program a sequence of tracks.

- Press this button after selecting a desired track with track search button. Tunes will be added to the program in the order in which they are specified.

⑥ **REPEAT button**

Press this button for repeat playback. Pressing the button once, twice, or three times will change the repeat mode from single track repeat, all tracks repeat, to repeat playback cancellation, respectively.

⑦ **HI-LITE SCAN button**

10 second passages are played starting from the first minute of each track on the CD, in sequence, beginning with the first track. To set the point in the tracks you want to scan, press this button during playback. The elapsed time is memorized, and then ten second passages of all the remaining tracks are played at the memorized time.

⑧ **EDIT button**

Press this button, and with the Manual/Track search buttons (◀◀◀, ▶▶▶) specify the length of tape you want to use for recording. Before recording, the CD player automatically programs the order of tracks to minimize the amount of unused tape at the end of a selected tape length.

⑨ **OPEN/CLOSE button**

Press when you wish to eject a disc. Each time the button is pressed, the tray is alternately pushed out or pulled in.

⑩ **MANUAL/TRACK SEARCH buttons**
(◀◀◀, ▶▶▶)

Use these buttons to perform track search and manual search during regular playback, programmed playback, or during pause. Press a button to skip to the previous or the next track. You will continue moving to the next track in the direction of the button you pressed as long as you continue pressing the button. Keep the button depressed until you come to the part you want to listen to.

⑪ **STOP button (■)**

Press to stop playback. When pressed, the player goes into stop mode and all operations stop. Press to clear a program. When pressed during stop mode, the program stored in memory is cleared.

⑫ **PLAY/PAUSE button (►/II)**


Press to begin playback. When playing back, press to temporarily interrupt playback. When pressed again, the pause mode is canceled and playback resumes.

Remote control unit

① **POWER button**

② **FUNCTION button**

The amplifier function automatically switches to the music source being operated when you press the CD playback (►) cassette deck playback (◀), or tuner station controls. Used to switch the input. Each time this button is pressed, it switches as follows.




The desired indicator lights.

③ **VOLUME + (UP)/- (DOWN) buttons**

When pressed, VOLUME on the amplifier is actually moved by a motor.

④ **SFC MODE button**


Use to select one of the preset sound fields. Each time the button is pressed, one of the preset sound fields will be selected, in the following order:



- Turn off SURROUND & WIDE and adjusts GEQ to FLAT.

⑤ **PGM (PROGRAM) MODE button**

This button is used when selecting one of your own personally created sound fields. Each time the button is pressed, one of the sound fields will be selected, in the following order:



- Turn off SURROUND & WIDE and adjusts GEQ to FLAT.

⑥ **SCAN button**

Use to select the display mode (frequency mode or station mode).

⑦ **TUNER STATION - (DOWN), + (up) buttons**

- Used for locating stations.
- + : Stations change in order in the upward direction.
- : Stations change in order in the downward direction.

⑧ **CD operation buttons**

- : PLAY
- DISC : This button does not function.
- : STOP
- II : PAUSE
- ◀◀◀, ▶▶▶ : TRACK SEARCH

⑨ **TAPE II operation buttons**

[For XD-J110]:

Same as Deck I operation buttons and Deck II control buttons on the CD cassette deck amplifier (Except for MUTE).

- (REC): To set to recording standby mode. The REC indicator lights and the direction indicators (◀ and ▶) flash. Recording begins when you press the PLAY button (▶ or ►).

II(PAUSE): Temporarily stops tape travel. Cancels pause mode when pressed again or press the PLAY button.

⑩ **SHIFT TAPE I button**

To operate Deck I, press the desired deck operation while pressing this button. ●II (REC PAUSE) button does not function.

⑪ **Timer operation buttons**

- SLEEP: Sets the sleep timer.
- WAKE-UP: Timer playback setting/cancellation can be performed when the timer playback time has been set.

SNOOZE: Turns off power if pressed after timer playback begins. Timer playback begins again approx. 5 minutes later.

XD-J115M, XD-J110

9. SPECIFICATIONS

Multi CD double deck amplifier: XD-J115M

Amplifier Section

[XD-J115M]
 Music power (DIN) 60W+60W (1 kHz, T.H.D. 1%, 8Ω)
 Continuous Power Output (DIN) 34W+34W
 (1 kHz T.H.D. 1%, 8Ω)

Graphic equalizer frequency band 60 Hz, 150 Hz,
 400 Hz, 1 kHz, 2.4 kHz, 6 kHz, 15 kHz, ±7 dB
 S/N (DIN, continuous power/50 mW)
 PHONO 68 dB/60 dB
 Total Harmonic Distortion (40 Hz to 20,000 Hz, 22.5W, 8Ω)*
 No more than 0.2%
 Input sensitivity/impedance
 PHONO (MM) 2.5 mV/47 kΩ
 VCR 150 mV/25 kΩ

Double Deck Section

Systems 4 track, 2-channel stereo
 Heads Recording/playback head x 1
 Erasing head x 1
 Playback head x 1
 Motor DC servo 2 speed motor x 2
 Wow and Flutter No more than 0.09% (W.PEAK)
 Fast Winding Time Approximately 105 seconds (C-60 tape)
 Frequency Response (-20 dB recording):
 Type I (Normal) tape 35 Hz to 14,000 Hz ±6 dB (EIAJ)
 Type II (HIGH/CrO₂) tape 35 Hz to 15,000 Hz ±6 dB (EIAJ)
 Signal-to-Noise ratio
 Dolby NR OFF 56 dB
 Noise Reduction Effect
 Dolby B-type NR ON More than 5 dB (at 5 kHz)

CD Section


Type Compact disc digital audio system
 Frequency response 4 Hz—20 kHz
 Number of channels 2 channels (stereo)

Furnished Parts

Operating Instructions 1
 Remote Control Unit 1
 Dry Cell Batteries 2
 Six-Compact disc-Magazine 1
 Power cord 1

Miscellaneous

Power requirements a.c. 220 Volts—, 50/60 Hz
 Power Consumption 275W
 Dimensions 360 (W) x 300.5 (H) x 344 (D) mm
 Weight (without package) 10 kg

The Magazine Type Multi-Play CD Players with  mark and the Magazines with the same mark are compatible for 5-inch (12 cm) discs.

CD double deck amplifier: XD-J110

Amplifier Section

[XD-J110]
 Music Power (DIN) 60W+60W (1 kHz T.H.D. 1%, 8Ω)
 Continuous Power Output 34W+34W
 (1 kHz T.H.D. 1%, 8Ω)

Graphic equalizer frequency band 60 Hz, 150 Hz,
 400 Hz, 1 kHz, 2.4 kHz, 6 kHz, 15 kHz, ±7 dB
 S/N (DIN, continuous power/50mW)
 PHONO 68dB/60dB
 Total Harmonic Distortion (40 Hz to 20,000 Hz, 22.5W, 8Ω)*
 No more than 0.2%
 Input sensitivity/impedance
 PHONO (MM) 2.5 mV/47 kΩ
 VCR 150 mV/22 kΩ

Double Deck Section

Systems 4 track, 2-channel stereo
 Heads Recording/playback head x 1
 Erasing head x 1
 Playback head x 1
 Motor DC servo 2 speed motor x 2
 Wow and Flutter No more than 0.09% (W.PEAK)
 Fast Winding Time Approximately 105 seconds (C-60 tape)
 Frequency Response (-20 dB recording):
 Type I (Normal) tape 35 Hz to 14,000 Hz ±6 dB (EIAJ)
 Type II (HIGH/CrO₂) tape 35 Hz to 15,000 Hz ±6 dB (EIAJ)
 Signal-to-Noise ratio
 Dolby NR OFF 56 dB
 Noise Reduction Effect
 Dolby B-type NR ON More than 5 dB (at 5 kHz)

CD Section

Type Compact disc digital audio system
 Frequency response 4 Hz—20 kHz
 Number of channels 2 channels (stereo)

Furnished Parts

Operating Instructions 1
 Remote Control Unit 1
 Dry Cell Batteries 2
 Power cord 1

Miscellaneous

Power requirements a.c. 220 Volts—, 50/60 Hz
 Power Consumption 275W
 Dimensions 360 (W) x 300.5 (H) x 344 (D) mm
 Weight (without package) 9kg
 XD-J110

- * Specifications and design subject to possible modification without notice due to improvement.
- * Measured By Audio Spectrum Analyzer.