

CDP-302/302ES/520ES

SERVICE MANUAL

Refer to RM-D302/D502 Service Manual issued separately for information of the remote controller supplied with this set.

CDP-302, CDP-520ES:

US Model

CDP-302:

Canadian Model

CDP-302ES:

AEP Model

UK Model

E Model




Photo: CDP-302ES

SPECIFICATIONS

COMPACT DISC PLAYER

System	Compact disc digital audio system
Disc	Compact disc
Laser diode properties	Material: GaAlAs Wavelength: 780 nm Emission duration: Continuous Laser output: Max. 0.6 mW*

*This output is the value measured at a distance of about 1.6 mm from the objective lens surface on the optical pick-up block.

Spindle speed	500 r.p.m. to 200 r.p.m. (CLV)
Scan velocity	1.2 - 1.4 m/sec.
Error correction	Sony Super Strategy Cross Interleave Reed Solomon Code
Number of channels	2
D-A conversion	16-bit linear
Frequency response	2 - 20,000 Hz ±0.5 dB
Harmonic distortion	Less than 0.003 % (1 kHz)
Dynamic range	More than 96 dB
Channel separation	More than 95 dB

SAFETY-RELATED COMPONENT WARNING!!

COMPONENTS IDENTIFIED BY SHADING AND MARK **⚠** ON THE SCHEMATIC DIAGRAMS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.

Wow and flutter Outputs	Below measurable limit Line outputs Output level 2 V rms (at MSB) Load impedance over 10 kilohms
Other jacks	Headphones 28 mW at 32 ohms Remote control connectors (4-pin)
Disc	Other jacks
Track pitch	1.6 µm
Sampling frequency	44.1 kHz
Quantization	16 bit linear quantizing/channel
Modulation system	EFM
Transfer rate	2.03 Mbit/sec. (before modulation)
General	Dimensions
Dimensions	Approx. 430 × 80 × 335 mm (w/h/d) (17 × 3 1/4 × 13 1/4 in.) including projecting parts and controls
Weight	Approx. 6.7 kg (14 lb 13 oz), net

ATTENTION AU COMPOSANT AYANT RAPPORT À LA SÉCURITÉ!

LES COMPOSANTS IDENTIFIÉS PAR UNE TRAME ET UNE MARQUE **⚠** SUR LES DIAGRAMMES SCHÉMATIQUES ET LA LISTE DES PIÈCES SONT CRITIQUES POUR LA SÉCURITÉ DE FONCTIONNEMENT. NE REMPLACER CES COMPOSANTS QUE PAR DES PIÈCES SONY DONT LES NUMÉROS SONT DONNÉS DANS CE MANUEL OU DANS LES SUPPLÉMENTS PUBLIÉS PAR SONY.

COMPACT DISK PLAYER
SONY®




AUD

CDP-302/302ES/520ES


MODEL IDENTIFICATION

CDP-302




US model: AC: 120 V ~ 60 Hz 15 W
Canadian model: AC: 120 V ~ 60 Hz 15 W

CDP-302ES



AEP model: AC: 220 V ~ 50/60 Hz 15 W
G-AEP model: AC: 220 V ~ 50/60 Hz 15 W
UK model: AC: 240 V ~ 50/60 Hz 15 W
E model: AC: 110, 120, 220, 240 V ~ 50/60 Hz 15 W

CDP-520ES



US model: AC: 120 V ~ 60 Hz 15 W

SAFETY CHECK-OUT (US Model)

After correcting the original service problem, perform the following safety check before releasing the set to the customer:

Check the antenna terminals, metal trim, "metallized" knobs, screws, and all other exposed metal parts for AC leakage. Check leakage as described below.

LEAKAGE TEST

The AC leakage from any exposed metal part to earth ground and from all exposed metal parts to any exposed metal part having a return to chassis, must not exceed 0.5 mA (500 microamperes). Leakage current can be measured by any one of three methods.

1. A commercial leakage tester, such as the Simpson 229 or RCA WT-540A. Follow the manufacturers' instructions to use these instruments.
2. A battery-operated AC milliammeter. The Data Precision 245 digital multimeter is suitable for this job.
3. Measuring the voltage drop across a resistor by means of a VOM or battery-operated AC voltmeter. The "limit" indication is 0.75 V, so analog meters must have an accurate low-voltage scale. The Simpson 250 and Sanwa SH-63Trd are examples of a passive VOM that is suitable. Nearly all battery operated digital multimeters that have a 2 V AC range are suitable. (See Fig. A)




Fig. A. Using an AC voltmeter to check AC leakage.

PROTECTION OF EYES FROM LASER BEAM DURING SERVICING

This set employs a laser. Therefore, be sure to follow carefully the instructions below when servicing.

WARNING !!

WHEN SERVICING, DO NOT APPROACH THE LASER EXIT WITH THE EYE TOO CLOSELY. IN CASE IT IS NECESSARY TO CONFIRM LASER BEAM EMISSION, BE SURE TO OBSERVE FROM A DISTANCE OF MORE THAN 30 cm FROM THE SURFACE OF THE OBJECTIVE LENS ON THE OPTICAL PICK-UP BLOCK.

1. Laser Diode Properties

- Material: GaAlAs
- Wavelength: 780 nm
- Emission Duration: continuous
- Laser Output: max. 0.6 mW*
- * This output is the value measured at a distance of about 1.6 mm from the objective lens surface on the Optical Pick-up Block.
- Classification: Class IIIb

2. During service, do not take the Optical Pick-up Block apart, and do not adjust the APC circuit. If there is a breakdown in the APC circuit (including laser diode), replace the entire Optical Pick-up Block (including APC board).

LASER WARNING LABELS

The labels shown below are affixed.


1. Protective Housing Label

DHHS Non-Interlocked Protective Housing Label
..... (US, Canadian model)




2. Interlock defeatable Label

..... (US, Canadian model)



• US, Canadian model




2. Aperture Label..... (AEP, UK, E model)




• See figure on next page for location of label.

3. Caution Label..... (AEP, UK, E model)



• AEP, UK, E model



BESKYTTELSE AF ØJNE MOD LASERSTRÅLING UNDER SERVICE

I dette apparat anvendes laserlys. Derfor skal nedenstående instruktioner nøje følges under service.

Følg iøvrigt instruktionerne i servicemanualen.

ADVARSEL!!

Under service må øjnene ikke komme nær objektiv-linsen på den optiske pick-up enhed. I tilfælde af at det er nødvendigt at kontrollere udsendelsen af laserlys, skal det ske i en afstand af mere end 30 cm fra den optiske pick-up.

1. Data for Laser Diode

- Materiale: GaAlAs
- Bølgelængde: 780 nm
- Udstråling: Kontinuerlig
- Laser Output: max. 0.6 mW*

* målt i 1.6 mm afstand fra overfladen af objektiv-linsen på den optiske pick-up enhed.


- Klassifikation: Svarende til klasse IIIb

2. Adskil aldrig den optiske pick-up enhed under service, og juster ikke APC kredsløbet (Automatic Power Control). Hvis APC kredsløbet (incl. laser-dioden) bryder ned, skal hele den optiske pick-up enhed (incl. APC printkortet) udskiftes.


LASER ADVARSEL MÆRKNING (AEP model)

Følgende mærkning findes indvendig i apparatet:


1. Advarsel Mærkning



2. Aperture Label



• AEP, UK model



— CAUTION FOR ELECTROSTATIC BREAKDOWN —

NOTES ON HANDLING THE OPTICAL PICK-UP BLOCK (BU-1)

The laser diode in the optical pick-up block may suffer electrostatic breakdown because of the potential difference generated by the charged electrostatic load, etc. on clothing and the human body.

The printed matter below is included in the repair parts. During repair, use the procedure in the printed matter.



The following method is an example for reference purposes:

1. Place a conductive sheet on the workbench. (The black sheet used as repair parts wrapping).
2. Place the set on the conductive sheet so that the chassis touches the sheet. (This makes it the same potential as the conductive sheet).
3. Place your hands on the conductive sheet. (This makes them the same potential as the sheet).
4. Remove the optical pick-up block.
5. Perform work on top of the conductive sheet. Be careful that clothing does not touch the optical pick-up block.

Printed Matter Included in the Repair Parts

When opening or repairing a BU-1, the procedure for grounding as follows is required to prevent damage caused by static electricity.

1. Grounding for the human body.
Be sure to put on a wrist-strap for grounding (with impedance lower than $10^8 \Omega$) whose other end is grounded. The strap works to drain away the static electricity built-up on the human body.
2. Grounding for the work table.
Be sure to lay on the table a conductive sheet (with impedance lower than $10^9 \Omega$) such as sheet of copper which is grounded.
3. As static electricity built-up on clothes is not drained away, be careful not to let your clothes touch the BU-1.




- SERVICING NOTE -

NOTES ON LASER DIODE EMISSION CHECK


The laser beam on this model is concentrated so as to be focused on the disc reflective surface by the objective lens in the optical pick-up block. Therefore, when checking the laser diode emission, observe, from more than 30 cm away from the objective lens.

LASER DIODE AND FOCUS SEARCH OPERATION CHECK

1. Make POWER switch on with no disc inserted and disc table closed.
2. Confirm that the following operation is performed while observing the objective lens.



A transit lever is provided at the bottom of the unit to protect the optical system against shock during transportation. Before starting repairing, make following procedures.




- 1 Loosen the screw (red) with the screwdriver.
- 2 Insert the screwdriver into the slot in the lever and move it in the direction of the arrow until it stops.
- 3 Tighten the screw.


FLOW CHART OF BU-1 (BASE UNIT)

TROUBLE SHOOTING



- Confirm all connectors around BU-1 (base unit) are secured before the following check.




MAIN BOARD



BU-1 (BASE UNIT)




LOCATION AND FUNCTION OF CONTROLS



- ① POWER switch
- ② Disc compartment
- ③ OPEN/CLOSE button
- ④ RMS PLAY indicator
- ⑤ REMOTE SENSOR and indicator (for remote control)
- ⑥ II PAUSE button and indicator
- ⑦ ▶ PLAY button and indicator
- ⑧ AMS/RMS buttons
- ⑨ INDEX buttons


- ⑩ HEADPHONES jack (stereo phone jack)
- ⑪ LEVEL (headphones level) control
- ⑫ REPEAT programming buttons
- ⑬ ELAPSED/REMAINING TIME button
- ⑭ RMS buttons
- ⑮ STOP (RESET) button
- ⑯ Manual search buttons

Display window



- ⑰ DISC indicator
- ⑱ TRACK indicator
- ⑲ SCAN indicator
- ⑳ INDEX/RMS indicator
- ㉑ Time counter

Rear panel



- ㉒ LINE OUT jacks

㉓ SUBCODE connector

This connector is provided to extend the utility of this compact disc player by allowing for the connection of optional equipment which will be available in the future.

- ㉔ ㉕ REMOTE OUT (remote control output) connector
- Connect this connector to remote control input connector of optional Sony TC-W7R cassette deck, etc. For details, refer to the operating instructions of the RM-S410 system controller.

- ㉖ REMOTE IN (remote control input) connector
- Connect this connector to remote control output connector of optional, Sony RM-S410 system remote controller. For details, refer to the operating instructions of the RM-S410 system controller.


- ㉗ AC OUTLET

- ㉘ AC power cord

SECTION 1
OUTLINE

CIRCUIT DESCRIPTION

1.1. OUTLINE



Above block diagram shows configuration of this set. Master control IC (IC302) serves as the center of all operation. Master control IC (IC302) assumes interface between man and machine like key input and remote control input. Mechanical control IC (IC303) assumes interface between master control IC (IC302) and machine.

For example, if PLAY button is pressed from key input, master control (IC302) gives mechanical control IC (IC303) a command to make PLAY mode. When this command is given, mechanical control IC (IC303) works in routine operation to make PLAY mode. It gives every kind of commands for IC201, 307 and they are in PLAY mode.


Through IC201 and IC307 use common data bus, they distinguish a command for IC201 or IC307 by a higher rank 4 bit value of each command from mechanical control IC (IC303).

Command for IC201: higher rank 4 bit 0000-0011 (0-3 with sexadecimal number system) are used.

Command for IC307: higher rank 4 bit 1010-1110 (A-E with sexadecimal number system) are used.

IC201 controls servo (focus, tracking, sled) mainly. IC307 checks EFM demodulation and CRC.

The illustration below shows flow chart of simple operation after power is ON.



1.2. MASTER CONTROL IC (IC302)

Master control IC (IC302) controls all of the operations of this set. Besides inputting key input and remote control input and data from mechanism control IC (IC303), it outputs display output and commands to mechanism control IC303.


Pin Functions

Pin. No.	I/O	Pin Name	Operation
1-4	OUT	D0-D3	Data output pin for key scan digit signal and to display tube drive IC (IC801)
5-8	IN	K0-K3	Key scan data input pin.
9	IN	OSC	Clock input pin.
11	IN	RESET	Reset input pin. Goes high about 1.5 seconds after power on.
13	IN	Q INT	Trigger input pin when data is transferred from IC303 to IC302.
14	IN	OUT SW	Input pin, goes low when disc compartment opens. When this pin goes high, IC302 outputs load in command to IC303.
15	-	H. L.	When this pin is low, IC302 does not output load in command to IC303 even if pin 14 is high.
17	IN	REC M	Syncro REC signal input pin.
18	IN	SI CLK	Clock input pin from remote control decoder.
19	IN	IN SW	Input pin, goes low when disc compartment closes.
20	IN	SI DATA	Serial data input pin from remote control decoder.
21	-	GND	Ground
29	OUT	CD F	Direct function output pin. High is output for 600 msec when PLAY, PAUSE button is pressed during STOP mode.
30-33	IN/OUT	CMD0-CMD3	I/O pin for data with IC303.
34	OUT	M REQ	Control (request) signal output pin for commands to IC303.
35	IN	S ACK	IC303 acknowledge signal input pin.
36	OUT	RST	Reset output pin to display tube drive IC (IC810).
37	OUT	CTL	Clock output pin to display tube drive IC (IC801).
38	OUT	IDP	Output pin for data which controls display tube drive IC (IC801) characters.
39	OUT	RMS LED	RMS LED output pin.
40	OUT	PAUSE LED	PAUSE LED output pin.
41	OUT	PLAY LED	PLAY LED output pin.
42	OUT	VDD	Power supply pin (5 V)

When commands are sent from the master control IC (IC302) to the mechanism control IC, the master control IC sets the data to be sent and makes the M REQ pin go low from high, as shown in the figure. When the M REQ pin goes low, the mechanism control IC (IC303) makes the S ACK pin go low from high. At the time data is taken in to the mechanism control IC (IC303).

When the master control IC (IC302) confirms that the S ACK pin has gone low, it sets the next data and makes the M REQ pin high. When the M REQ pin goes high, the mechanism control IC (IC303) makes the S ACK pin high and reads in the data.

Example: CLOSE command. (CH)



Command from master control IC (IC302) to mechanism control IC (IC303).

The above signals are sent from CMD0-CMD3 to the mechanism control IC.

The mechanism control IC executes these commands.

Commands sent from the mechanism control IC (IC303) to the master control IC (IC302).

TOC READ END	A (F)	Sent out when TOC data read-in is finished.
LEAD OUT	B (F)	Sent out when disc ends.
NO DISC	E (F)	Sent out when there is no disc in the disc compartment
OPEN	D (F)	Sent out when the disc compartment is open.

The mechanism control IC (IC303) keeps the TO data and Q data read in from the disc, and sends it to the master control IC (IC302) as required.

1-3. MECHANISM CONTROL IC (IC303)

Mechanism control IC303 sends commands to IC201 (servo IC CX20108) and IC307 (digital processing/CLV servo IC CX23035) via the DATA, CLOCK and LATCH pins, and also memorizes TOC and Q data, and performs direct search, etc. based on this data.

Pin Functions

Pin No.	I/O	Pin Name	Operation
1	OUT	REC MUTE	Synchro REC MUTE signal output pin.
2	OUT	PAUSE	Synchro PAUSE release signal output pin.
3	IN	REC M	Synchro REC signal input pin.
4	-	ADJ	By making this pin low, IC303 will not load the disc out even if servo or other abnormalities are detected. Used for servo and PLL adjustment.
5	OUT	MUTE	Muting control output pin.
6	-	JMP	By making this pin low, direct search is not performed and access is done by track jump. Used for track jump check.
9	IN	OSC	Clock input pin.
11	IN	RESET	Reset input pin. Goes high about 1.5 seconds after power on.
13	IN	SCOR	SUB Q sync signal input pin.
15	IN	IN SW	Input pin; goes low when disc compartment closes.
16	IN	OUT SW	Input pin; goes low when disc compartment opens.
17	IN	FOK	Focus OK signal input pin.
18	IN	WFCK	WFCK (Write Frame Clock) input pin.
19	IN	GFS	Guard Frame Sync input pin. High is input when disc data can be read in normally.
20	IN	SUB Q	SUB Q signal (selection address, emphasis data, etc.) input pin.
21	-	GND	Ground
22	IN	SENSE	IC201, IC301 SENS output input pin.
23	IN	Q CHECK	Input pin for SUB Q CRC results output from IC307.
24	OUT	LATCH	Latch output pin for serial data to IC201, 307.
25	OUT	DIRECT	Output pin to IC201 during track jump. Normally high, reverses track jump pulse direction at low. Next, for high set to normal tracking mode. Outputs low for a set time at detection of TZC rise and fall.
26	OUT	DATA	Serial data output pin to IC201, 307.
27	OUT	CLOCK	Serial data transmission clock output pin to IC201, 307.
28	OUT	SLED G	Output pin; controls sled motor gain. Normally high. Low during access.
29	IN	SLED S	Low when sled motor operates. Inputs high when it stops.
31	OUT	Q INT	Trigger output pin for data sent to IC302.
32	OUT	S ACK	Acknowledge signal output pin for IC302 M REQ signal.
33	IN	M REQ	IC302 M REQ signal input pin.
34-37	IN/OUT	CMD0-CMD3	I/O pin with IC302 data.
38	OUT	LD ON	Output pin; controls laser diode ON/OFF.
39	OUT	LOAD IN	Output pin; drives loading motor to the close side.
40	OUT	LOAD OUT	Output pin; drives loading motor to the open side.
41	OUT	EPS	Detects disc emphasis, switches emphasis ON/OFF. Output pin.
42	-	VDD	Power supply pin (5 V)

The Q data called SUB Q is used for the TOC (Table of Contents) data in the lead-in area, mode control signals such as preemphasis during the selections, and track number (TNO), index number, play time, etc. display and address data.

This data is input to mechanism control IC (IC303) SUB Q pin from IC307, and is written into the RAM by 8 bit units. Data is sent from the mechanism control IC (IC303) to the master control IC (IC302) as required, and is displayed. Data is sent from the mechanism control IC to the master control IC about 8 times in 1 second.

1-4. DIRECT SEARCH

On this set, a linear motor is used for the sled motor, so that besides 100, 10 and 1 track jump, the optical pick-up can be moved directly to the address specified by the microcomputer (direct search). (On the conventional CD player, only the objective lens moves, and the optical pick-up follows it by servo in order to perform 100, 10 and 1 track jump only.) Higher performance access is enabled on this set.

On the conventional CD player, only three data, A0 (MNR of first selection on the disc), A1 (MNR of last selection on the disc) and A2 (leadout track start point) were memorized when TOC data was read in to the microcomputer. However, on this model, the absolute time from the first to the 21st selection is memorized in the microcomputer. This absolute time is converted to track numbers inside the microcomputer, and the track number to be jumped is obtained by subtracting the current address track number from the track number of the selection to be jumped to.


Frame number	POINT	PMIN, PSEC, RFRAME
n	01	00, 02, 32
n + 1	01	00, 02, 32
n + 2	01	00, 02, 32
n + 3	02	10, 15, 12
n + 4	02	10, 15, 12
n + 5	02	10, 15, 12
n + 6	03	16, 28, 63
n + 7	03	16, 28, 63
n + 8	03	16, 28, 63
n + 9	04	• •
n + 10	04	• •
n + 11	04	• •
n + 12	05	• •
n + 13	05	• •
n + 14	05	• •
n + 15	06	49, 10, 03
n + 16	06	49, 10, 03
n + 17	06	49, 10, 03
n + 18	A0	01, 00, 00
n + 19	A0	01, 00, 00
n + 20	A0	01, 00, 00
n + 21	A1	06, 00, 00
n + 22	A1	06, 00, 00
n + 23	A1	06, 00, 00
n + 24	A2	52, 48, 41
n + 25	A2	52, 48, 41
n + 26	A2	52, 48, 41
n + 27	01	00, 02, 32
n + 28	01	00, 03, 32
•	•	• •
•	•	• •
•	•	• •

- Frame number: 98 symbol, 1 block No.
- POINT = For A0, PMIN indicates MNR of first selection on the disc. PSEC, PFRAME are "00".
- POINT = For A1, PMIN indicates MNR of last selection on the disc. PSEC, PFRAME are "00".
- POINT = For A2, PSEC, PFRAME indicate lead-out track start point.
- POINT = For 01-06, PMIN, PSEC indicate the absolute time of the selection.

Table A. TOC Structure (Example of a 6 selection disc)

Direct search is performed as follows:


When the search command is input to the mechanism control IC (IC303) from the master control IC (IC302) due to key input or remote control input, the mechanism control IC303 converts the current address to track number from the data Q of the current address channel Q (Figure 1) data. (This data Q is always input from pin 20 SUB Q during play.) The address to be jumped to is also converted to a track number, the track numbers are compared, and the number of tracks to be jumped is calculated.




SO, SI: parts of sync pattern.
CONTROL: Indicates channel number and preemphasis ON/OFF.
Output from MSB
0000 - 2CH, no pre-emphasis
1000 - 4CH, no pre-emphasis
0001 - 2CH, pre-emphasis
1001 - 4CH, pre-emphasis
LSB = 0 at lead-in and lead-out portions.
ADR: Control bit for DATA-Q. Output from MSB.
DATA-Q: 72 bits of data; output from MSB.
CRC: CRC for CONTROL, ADR, DATA-Q. Refer to PCM-F1 Operation Manual for details on CRC. Output from MSB.
Generation multinomial is $P(x) = X^{16} + X^{12} + X^5 + 1$

Figure 1. Channel Q Structure

— Data Form on Lead-in Track (indicate TOC) —



— Data Form of Music Signal and Lead-out Track —



MNR: Expresses Music Number as 2 digits of BCD.

00 → Lead-in track

01-99 → Music number

AA → Lead-out track

X: MNR index, expressed as 2 digits of BCD.

1 MNR is divided into 100. The method of division is determined by the software, and numbering is in order from "00-99". Does not exist on lead-in track.

00 → Pause encoding

Applies pause. There is 2-3 seconds of pause encoding at the top of the selection.

01-99 → Sub-division number.

X = 01 on the lead-out track, MNR = 01-99 and X ≠ 00 during a selection. Initial value is "01", then increases by ones.

ZERO: All these 8 bits are "0".

MIN, SEC, FRAME: Selection running time is expressed by BCD 6 digits. All "0" at beginning of selection. Time increases during the selection, stops at pause. Become "0" at end of pause. Time increases on lead-in and lead-out tracks. 1MIN = 60 SEC, 1SEC = 75 FRAME (00-74)

AMIN, ASEC, AFRAIME: Disc running time is expressed as BCD 6 digits. At start of disc program area, time is "0" and MNR is the first value of that disc.

1AMIN = 60 ASEC, 1ASEC = 75 AFRAIME (00-74)

POINT, PMIN, PSEC, PFRAIME: Disc table of contents is on this part of the lead-in track. As shown in the table, it is recorded continuously and repeatedly on the lead-in track, or MNR = 00 portion. Also, each content is recorded 3 times each.

PMIN, PSEC, PFRAIME values each express selection start point. There is ±1 second precision on AMIN, ASEC, AFRAIME time axes.

Figure 2. Data Q Structure

Next, the mechanism control IC puts the digital signal processing/CLV servo IC (IC307) CX23035 into counter set mode. By doing this, CX23035 outputs the CNIN pin (17) input signal CNIN/2h (Hz) signal from SENSE pin (18)(COUNT). At this time 41 is set in n, so a signal which is the input signal divided by 82 is output from the SENSE pin.

Then tracking and sled servo go off, focus servo goes on and the optical pick-up is moved quickly by the linear (sled) motor. When this happens the RF amp (IC201) CX20109 MIRR pin (18) mirror output is as shown in Figure 3. (For example, if there are 20000 tracks from the innermost to outermost circumference, and access is done in 0.5 seconds, mirror output is 40 kHz, which is too fast for the mechanism control IC to read.)




Figure 3. Mirror Output for Direct Search





Figure 4. Count Signal Timing

This mirror output is input to CX23035 CNIN pin (17), then is divided into 41 and output from SENSE pin (18) to the mechanism control IC SENS pin (22).

(At this time, it is divided and can be read.) This input signal is counted by the mechanism control IC at rise or fall and is converted to the number of tracks to be jumped. For example, for a 1000 track jump, consecutive comparison, such as 1000/82 = 12 is done and when that value is reached, each servo is turned on and the optical pick-up is braked. Then DATA-Q is read, converted to track number, and if within a certain range, 100, 10, 1 track jump are performed and convergence is done. Outside of that range, direct search is performed again.



1.5. LINEAR MOTOR AND SERVO CIRCUITS

A linear motor is used for optical pick-up transportation mechanism on this model.

Figure a shows the optical pick-up transportation mechanism. The linear motor drive coil (sled coil) is part of the optical pick-up and performs transpor-

tion operation. There is a sensor coil mounted on the opposite side of the linear motor. This detects when the optical pick-up reaches the innermost circumference and stops the linear motor.




Figure a. Optical Pick-up Transportation Mechanism

The linear motor is structured with a coil wound around a yoke plate and a magnet at both ends. Figure b shows the theory of operation. The coil re-

ceives force in the direction of **(A)** when current flows to the coil in the magnetic field.





Figure b. Theory of Linear Motor Operation

The linear motor servo circuit receives a tracking error signal at CX20108 (IC201) servo control in order to prevent the optical pick-up laser spot from leaving the pit track, and outputs a sled signal. This sled signal drive controls the linear motor. Also, to


perform 1, 10, 100 track jump, the signal from IC303 (mechanism control) is controlled at IC201 (CX20108) and the linear motor is driven by the sled signal. This allows 1, 10, 100 track jump to be performed smoothly.



Linear Motor Servo Circuit Structure

CDP-302/302ES/520ES CDP-302/302ES/520ES

SECTION 2 BLOCK DIAGRAM



SECTION 3


DISASSEMBLY

3-1. DISASSEMBLY


Note: Follow the disassembly procedure in the numerical order given.

- Remove case by taking out seven screws:
both sides, 4 pcs.
rear side, 3 pcs.

MAIN BOARD CONNECTOR LAYOUTS




MD SECTION








- Remove bottom plate.
(BVTT3 x 8 8 pcs.)

MAIN BOARD



BSL MOTOR BOARD









Refer to "NOTES ON HANDLING BU-1 (BASE UNIT)" on page 5 to prevent damage caused by static electricity.

Refer to "NOTES ON HANDLING BU-1 (BASE UNIT)" on page 5 to prevent damage caused by static electricity.


FLEXIBLE BOARD

Unsolder • marked portion of ref. no. ③, ⑤, and ⑥ and remove flexible board.




Refer to "NOTES ON HANDLING BU-1 (BASE UNIT)" on page 5 to prevent damage caused by static electricity.

Refer to "NOTES ON HANDLING BU-1 (BASE UNIT)" on page 5 to prevent damage caused by static electricity.

SLED/SENSOR COIL (1)**SLED/SENSOR COIL (2)**

① Perform flexible board removal ①, ②.




Unsolder marked portion.

Open lid of lead retainer (B) as illustrated.




lead secured with contact cement

lead secured with contact cement





SLED/SENSOR COIL (3)

Refer to "NOTES ON HANDLING BU-1 (BASE UNIT)" on page 5 to prevent damage caused by static electricity.

Refer to "NOTES ON HANDLING BU-1 (BASE UNIT)" on page 5 to prevent damage caused by static electricity.




- Remove case by taking out seven screws:
both sides, 4 pcs.
rear side, 3 pcs.




**SECTION 4
ADJUSTMENTS**

3-2. PC BOARD LOCATION



MECHANICAL SECTION




4-1. MECHANICAL ADJUSTMENT

DISC TABLE POINT ADJUSTMENT

Setting:


- Turn power on.
- Keep disc table closed.




CHUCKING ARM HEIGHT ADJUSTMENT

Adjust the height of portion **(A)** with disc inserted and disc table closed.

Repeat loading and confirm that chucking arm does not touch disc pulley.





**4-2. ELECTRICAL ADJUSTMENTS**


1. Perform adjustments in the order given.
2. Use YEDS-1 disc unless otherwise indicated.
3. Use the oscilloscope with more than $10M\Omega$ impedance.

Adjustment Mode


1. Connect main amp board test point ADJ and GND. [This is to prevent the disc table from opening even though pits are not read, by making micro-computer IC303 pin (4) low.]
2. Turn POWER switch on. (To reset microcomputer.)
After adjustment, remove the lead wire connecting test points ADJ and GND.

Adjustment Location: main board.**RF PLL Adjustment****Procedure:**



1. Turn POWER switch ON. (stop mode).
2. Keep disc table opened.
3. Put set into adjustment mode (See page 37.)
4. Connect VTVM to main board test points TP VCO and TP GND.
5. Adjust main board RV301 so that reading on VTVM is $OV \pm 50$ mV.
6. Connect the frequency counter to main board test points TP PLCK and TP GND.
7. Adjust main board L301 so that reading on frequency counter is 4.2818 MHz ± 10 KHz.
8. Reconnect lead wires connected in adjustment mode.
9. Put disc (YEDS-1) in and press ▶ PLAY button.
10. Confirm that reading on frequency counter is 4.3218 MHz.

Adjustment Location: main board.**CLV Phase Lock Check**

Perform this check when replacing BU-1 (base unit) and press pully in chucking arm section.)

Procedure:

1. Put disc (YEDS-1) in.
2. Connect oscilloscope to main board test points TP CLV and TP GND.
3. Press ▶ PLAY button in TRACK 1 mode.
4. Confirm that the waveform is as shown in the figure below.

**Adjustment Location:** main board.

REFERENCE

Focus/Tracking Gain Adjustment

A frequency response analyzer is necessary in order to perform this adjustment exactly.

However, this gain has a margin, so even if it is slightly off, there is no problem. Therefore, do not perform this adjustment.

Focus/tracking gain determines the pick-up follow-up (vertical and horizontal) relative to mechanical noise and mechanical shock when the 2-axis device operate.

However, as these reciprocate, the adjustment is at the point where both are satisfied.

- When gain is raised, the noise when the 2-axis device operates increases.
- When gain is lowered, it is more susceptible to mechanical shock and skipping occurs more easily.
- When gain adjustment is off, the symptoms below appear.


Gain Symptoms	Focus	Tracking
The time until music starts becomes longer for STOP → PLAY or automatic selection (◀◀, ▶▶ buttons pressed. (Normally takes about 2 seconds.)	low	low or high
Music does not start and disc continues to rotate for STOP → PLAY or automatic selection (◀◀, ▶▶ buttons pressed.)	—	low
Disc table opens shortly after STOP → PLAY.	low or high	—
Sound is interrupted during PLAY. Or time counter display stops progressing.	—	low
More noise during 2-axis device operation.	high	high

The following is a simple adjustment method.

Simple Adjustment —

Note: Since exact adjustment cannot be performed, remember the positions of the controls before performing the adjustment. If the positions after the simple adjustment are only a little different, return the controls to the original position.


Procedure:



- Keep the set horizontal.


(If the set is not horizontal, this adjustment cannot be performed due to the gravity against the 2 axis device.)

- Put set in adjustment mode. (see page 37)
- Insert disc (YEDS-1) and press ▷PLAY button.
- Connect oscilloscope to main amp board TP FE.
- Adjustment RV201 so that the waveform is as shown in the figure below. (focus gain adjustment)




- Incorrect Examples (DC level changes more than on adjusted waveform)

low focus gain




high focus gain


VOLT/DIV: 100 mV
TIME/DIV: 2 ms
100 mV
0 VVOLT/DIV: 100 mV
TIME/DIV: 2 ms
100 mV
75 mV
0 V

- Connect oscilloscope to main board TP TE.


- Adjust RV202 so that the waveform is as shown in the figure below. (tracking gain adjustment)




- Incorrect Examples (fundamental wave appears)



low tracking gain
VOLT/DIV: 1 V
TIME/DIV: 2 ms
0 V




high tracking gain
(higher fundamental wave than for low gain)
VOLT/DIV: 1 V
TIME/DIV: 2 ms
0 V




● Semiconductor Lead Layouts


2SD774-5
2SB734-2




2SB740
2SC2001



1SS119




2SA1175
2SC2785-E




KV1236Z




DTA114ES
DTC114ES
DTC144ES
DTC143TS




2SK152




PH302B




2SA874
DTC143TF



21DQ05




THS103A-1




AA5535S
BG5535S




CX20108




MSM6404A-39RS
MSM6404A-41RS




CX20197
NJM4558D-FA
TDB0353DP
μPC4082C
μPC4558C




MB84066B
TC74HCU04P




CX23035




MB8416-20LPF




**SECTION 5
DIAGRAMS**

 5-1. MOUNTING DIAGRAM
 - BU-1 (BASE UNIT) Section -

Semiconductor Lead Layouts


 2SD774-5
 2SB734-2

 10DF2
 10E-2
 HZ5CLL
 RD2.7E-L1
 RD5.1E-B1
 RD8.2E-B2
 RD33E-B3



CX20108




CX23034




NJM79M12A



 2SB740
 2SC2001

 MSM6404A-39RS
 MSM6404A-41RS


1SS119


 2SA1175
 2SC2785-E




M50760-414P



KV1236Z


 DTA114ES
 DTC114ES
 DTC144ES
 DTC143TS


GL-5NG27


 CX20197
 NJM4558D-FA
 TDB0353DP
 μPC4082C
 μPC4558C



2SK152





PH302B


 2SA874
 DTC143TF



21DQ05




THS103A-1

AA5535S
 BG5535S


CX23035




MB8416-20LPF




CX20152




NJM78M05A




μPD4053BC




NJM79M05A




M54940P



NJM4560S




CX20106




M5218L




NJM7805A



NJM7905A




μPC78M12H




SECTION 5
DIAGRAMS


5-1. MOUNTING DIAGRAM
- BU-1 (BASE UNIT) Section -



A
B
C
D
E
F
G
H
I
J



IC151 151 152 IC30
804 801 802 803 303
IC801 851 652 651 306
IC30 201



154 153

[51] [52]

151 152

10780

4

— 1 —

— 1 —

Continued from back cover

• 100 •

52

—
—

—
—
—

卷之三


卷之三


— 10 —

-47-


19 20 21 22 23 24 25 26 27 28 29 30 31 32 33


A
B
C
D
E
F
G
H
I
J





BOARD 1






Note: Les composants identifiés par un trame et une marque  sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

Note: The components identified by shading and mark  are critical for safety. Replace only with part number specified.


5-4. SCHEMATIC/MOUNTING DIAGRAMS

— Power Supply Section —

• See page 44 for Notes.



4 5 6 7 8 9 10 11



Note: Les composants identifiés par un trame et une marque **⚠** sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

Note: The components identified by shading and mark **⚠** are critical for safety. Replace only with part number specified.

SECTION 6

EXPLODED VIEWS AND PARTS LIST

NOTE:

- The mechanical parts with no reference number in the exploded views are not supplied.


- Items marked "★" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

- The construction parts of an assembled part are indicated with a collation number on the remark column.

The components identified by shading and mark **⚠** are critical for safety. Replace only with part number specified.

Les composants identifiés par une trame et une marque **⚠** sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

(1)



No.	Part No.	Description	REMARKS	No.	Part No.	Description	REMARKS
1	*4-884-637-00	SHEET (C), INSULATING		15	*4-908-408-01	PLATE, FIXED, CATCHER, RAY	
2	3-703-710-41	(302ES,520ES)...STICKER, SONY SYMBOL(12)		16	*4-342-118-00	LID, SHIELD CASE, R	
3	3-703-685-21	SCREW (+BV 3X8)		17	*4-342-117-00	CASE, SHIELD (MAIN), R	
4	9-911-840-XX	CUSHION		18	*4-908-600-01	LEVER, LOCK, TRANSPORT	
5	3-318-911-11	KNOB (POWER.L), T MOLD		19	3-323-470-01	SCREW (B3X6), (+ -)	
6	*4-908-425-01	LEVER, POWER SWITCH		20	3-831-441-XX	CUSHION	
7	4-889-321-31	SCREW		21	*4-908-459-01	(302)...PLATE, LIGHT INTERCEPTION	
8	4-908-438-01	CASE		22	*4-908-458-01	(302)...BRACKET, LAMP	
9	4-885-831-00	LABEL, CAUTION		23	4-812-134-00	(302)...RIVET NYLON, 3.5	
10	*4-908-449-01	(302).....LABEL, MODEL NUMBER (U)		24	3-703-079-21	(302ES, UK)...LABEL, CAUTION (BACK)	
	*4-908-450-01	(520ES).....LABEL, MODEL NUMBER (U)		25	3-703-680-00	(302ES,520ES)...LABEL, CAUTION, SUB, NEW UL	
	*4-908-453-01	(302ES;AEP)....LABEL, MODEL NUMBER (AE1)		26	4-908-404-01	(302ES)...LABEL, APARTURTE, LASER, DHHS	
	*4-908-455-01	(302ES;UK)....LABEL, MODEL NUMBER (UK)		27	4-908-402-01	(302,520ES)...LABEL, INTERLOCK, DHHS	
	*4-908-457-01	(302ES;E)....LABEL, MODEL NUMBER (E2/3)		28	4-885-843-02	(302ES)...LABEL, HOUSING, DHHS	
	*4-908-463-01	(302ES;G-AEP)....LABEL, MODEL NUMBER (AE4)		29	*4-885-838-01	(302ES)...LABEL, CAUTION, LASER	
11	*4-908-439-01	(302).....PLATE, BOTTOM		30	7-685-751-09	SCREW +BVTT 3X6 (S)	
12	*4-908-439-11	(302ES,520ES)....PLATE, BOTTOM		31	7-685-872-09	SCREW +BVTT 3X8 (S)	
13	*4-908-447-01	SHEET, INSULATING		32	*4-884-680-00	(302; Canadian)...LABEL	
14	*4-908-409-01	BRACKET, REMOTE CONTROL		902	*1-611-717-11	PC BOARD, N	
				911	*1-614-017-11	(302)....PC BOARD, LAMP	

SECTION 6


EXPLODED VIEWS AND PARTS LIST

NOTE:


- The mechanical parts with no reference number in the exploded views are not supplied.
- Items marked " * " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- The construction parts of an assembled part are indicated with a collation number on the remark column.

The components identified by shading and mark  are critical for safety. Replace only with part number specified.

Les composants identifiés par une trame et une marque sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.





No.	Part No.	Description	REMARKS	No.	Part No.	Description	REMARKS
1	*4-884-637-00	SHEET (C), INSULATING		15	*4-908-408-01	PLATE, FIXED, CATCHER, RAY	
2	3-703-710-41	(302ES,520ES)...STICKER, SONY SYMBOL(12)		16	*4-342-118-00	LID, SHIELD CASE, R	
3	3-703-685-21	SCREW (+BV 3X8)		17	*4-342-117-00	CASE, SHIELD (MAIN), R	
4	9-911-840-XX	CUSHION		18	*4-908-600-01	LEVER, LOCK, TRANSPORT	
5	3-318-911-11	KNOB (POWER.L), T MOLD		19	3-323-470-01	SCREW (B3X6), (+ -)	
6	*4-908-425-01	LEYER, POWER SWITCH		20	3-831-441-XX	CUSHION	
7	4-889-321-31	SCREW		21	*4-908-459-01	(30Z)...PLATE, LIGHT INTERCEPTION	
8	4-908-438-01	CASE		22	*4-908-458-01	(30Z)...BRACKET, LAMP	
9	4-885-831-00	LABEL, CAUTION		23	4-812-134-00	(30Z)...RIVET NYLON, 3.5	
10	*4-908-449-01	(30Z).....LABEL, MODEL NUMBER (U)		24	3-703-079-21	(302ES; UK)....LABEL, CAUTION (BACK)	
	*4-908-450-01	(520ES).....LABEL, MODEL NUMBER (U)			*3-703-680-00	(30Z,520ES)...LABEL, CAUTION, SUB, NEW UL	
	*4-908-453-01	(302ES;AEP)....LABEL, MODEL NUMBER (AE1)		25	4-908-404-01	(302ES)...LABEL, APARTURTE, LASER, DHHS	
	*4-908-455-01	(302ES;UK)....LABEL, MODEL NUMBER (UK)		26	4-908-402-01	(30Z,520ES)...LABEL, INTERLOCK, DHHS	
	*4-908-457-01	(302ES;E).....LABEL, MODEL NUMBER (E2/3)		27	4-908-401-01	(30Z,520ES)...LABEL, HOUSING, DHHS	
	*4-908-463-01	(302ES;G-AEP)....LABEL, MODEL NUMBER (AE4)		28	4-885-843-02	(302ES)...LABEL, CAUTION, LASER	
11	*4-908-439-01	(30Z).....PLATE, BOTTOM		29	*4-885-838-01	(302ES)...LABEL, CLASS 1	
	*4-908-439-11	(302ES,520ES)..PLATE, BOTTOM		30	7-685-751-09	SCREW +BVTT 3X6 (S)	
12	4-887-290-00	LEG, RUBBER		31	7-685-872-09	SCREW +BVTT 3X8 (S)	
13	*4-908-447-01	SHEET, INSULATING		32	*4-884-680-00	(30Z; Canadian) ...LABEL	
14	*4-908-409-01	BRACKET, REMOTE CONTROL		902	*1-611-717-11	PC BOARD, N	
				911	*1-614-017-11	(30Z)....PC BOARD, LAMP	



The components identified by shading and mark  are critical for safety. Replace only with part number specified.

Les composants identifiés par une trame et une marque sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.


No.	Part No.	Description	REMARKS	No.	Part No.	Description	REMARKS
51	*4-908-424-01	BRACKET, TRANSFORMER		68	*4-908-406-01	BRACKET, PC BOARD	
52	*3-703-353-07	SUPPORT, PC BOARD		69	3-703-150-11	CLAMP	
53	*4-908-437-01	PANEL, SUB		70	7-685-872-09	SCREW +BVTT 3X8 (S)	
54	*4-908-432-01	FRAME (LEFT)		71	7-685-880-01	SCREW +BVTT 4X6 (S)	
55	*3-312-427-00	SPACER (3X22)		72	7-685-751-09	SCREW +BVTT 3X6 (S)	
56	3-701-822-00	HOLDER, WIRE		73	7-685-879-01	SCREW +BVTT 3X30 (S)	
57	*4-908-407-01	BRACKET, POWER SWITCH		74	7-682-147-09	SCREW +P 3X6	
58	*4-908-444-01	(302; US).....PLATE, JACK		75	7-621-775-20	SCREW +B 2.6X5	
	*4-908-444-11	(302; Canadian).....PLATE, JACK		76	7-685-134-19	SCREW +BTP 2.6X8 TYPE2 N-S	
	*4-908-444-51	(520ES).....PLATE, JACK		77	3-703-473-00	SCREW, TERMINAL	
	*4-908-444-61	(302ES;AEP,G-AEP)....PLATE, JACK		78	7-685-752-04	SCREW +BVTT 3X8 (S)	
	*4-908-444-71	(302ES;UK).....PLATE, JACK		79	4-308-840-00	HOLDER, WIRE	
	*4-908-444-81	(302ES;E).....PLATE, JACK		80	*3-701-948-14	(302ES;AEP,GAEP)...LABEL, FUSE	
59	3-703-244-00	(302; Canadian, 302ES, 520ES)...BUSHING, CORD		81	3-701-948-18	(302ES;UK).....LABEL, FUSE	
	3-703-571-11	(302; US).....BUSHING (S), CORD		903	*1-614-014-11	PC BOARD, P.SW	
60	*3-322-818-01	HOLDER, CONNECTOR		904	*1-614-016-11	PC BOARD, SIRCS	
61	4-875-455-02	(302ES;AEP,G-AEP,UK)...CAVER (DIA 20), CAPACITOR		905	*1-614-021-11	PC BOARD, ACC	
62	*4-908-431-01	FRAME, (INNER)		906	*1-614-019-11	PC BOARD, LINE OUT	
63	*4-908-430-01	FRAME (RIGHT)		907	*A-4651-033-A	(302).....MOUNTED PCB, MAIN	
64	*3-701-030-00	LABEL, SERIAL NUMBER			A-4651-034-A	(302ES,520ES)....MOUNTED PCB, MAIN	
65	*4-902-345-01	HEAT SINK		921	1-533-131-00	(302ES;AEP,G-AEP,UK)...HOLDER, FUSE	
66	2-259-121-00	SCREW, TR		922	1-526-565-00	(302ES;E)....AC PLUG ADAPTOR	
67	*4-908-502-01	HEAT SINK					




No.	Part No.	Description	REMARKS	No.	Part No.	Description	REMARKS
101	X-4908-410-1	(302ES)...FRONT PANEL ASSY		119	4-908-423-01	SPACER, BUTTON	
	X-4908-411-1	(302)...FRONT PANEL ASSY		120	4-908-554-01	HOLDER, LED	
	X-4908-413-1	(520ES)...FRONT PANEL ASSY		121	4-908-429-01	PLATE (B), SWITCH	
102	3-703-108-21	SCREW +BV 3X6, S TIGHT		122	X-4908-404-1	PLAY KNOB ASSY	
103	4-902-067-11	KNOB, CONTROL		123	X-4908-405-1	PAUSE KNOB ASSY	
104	*4-908-426-01	BRACKET, HEADPHONE		124	4-908-414-41	KNOB (B) (BLACK), T	
105	X-4908-406-1	FROSTED PLATE HOLDER (B) ASSY		125	4-908-436-01	HOLDER, CONTROL BUTTON	
106	X-4908-402-1	BUTTON (B) ASSY, OPEN/CLOSE		126	4-908-415-01	KNOB (AMS), T	
107	9-911-844-XX	RUBBER, BRAKE		127	4-908-415-11	KNOB (AMS), T	
108	4-908-412-01	SHAFT, BUTTON		128	4-908-414-01	KNOB (B) (BLACK), T	
109	4-908-413-01	KNOB (A) (BLACK), T		129	4-908-414-21	KNOB (B) (BLACK), T	
110	4-908-413-11	KNOB (A) (BLACK), T		130	4-908-414-31	KNOB (B) (BLACK), T	
111	4-908-413-21	KNOB (A) (BLACK), T		131	4-908-414-11	KNOB (B) (BLACK), T	
112	4-908-413-31	KNOB (A) (BLACK), T		132	3-831-441-XX	CUSHION	
113	4-908-413-41	KNOB (A) (BLACK), T		133	7-685-646-19	SCREW +BVTP 3X8 TYPE2 N-S	
114	4-908-413-51	KNOB (A) (BLACK), T		134	7-685-751-09	SCREW +BVTT 3X6 (S)	
115	*4-908-446-01	PLATE, GROUND		135	7-685-134-19	SCREW +BTP 2.6X8 TYPE2 N-S	
116	4-908-428-01	PLATE (A), SWITCH		136	7-685-538-14	SCREW +BTP 2.6X16 TYPE2 N-S	
117	3-701-822-00	HOLDER, WIRE		908	*1-614-015-11	PC BOARD, H.P	
118	3-886-569-00	TUBE, RUBBER		909	*1-614-013-11	PC BOARD, DISPLAY	

No.	Part No.	Description	REMARKS	No.	Part No.	Description	REMARKS
301	7-682-553-09	SCREW +B 3X20		325	7-621-257-55	SCREW +P 2.3X8	
302	4-908-592-01	POLE (A), INSULATOR		326	*4-908-522-01	BRACKET (B), SWITCH	
303	4-908-594-01	SPRING, COMPRESSION		327	4-908-556-01	SPRING, TENSION (LOCK LEVER)	
304	4-908-595-01	SPRING, COMPRESSION		328	*X-4908-504-1	LEVER ASSY, LOCK	
305	4-908-596-01	SPRING, COMPRESSION		329	7-685-132-19	SCREW +BTP 2.6X8 TYPE2 N-S	
307	307 A X-4908-203-01 BASE UNIT		(including ● A, B, C)	330	*4-908-521-01	PLATE, SWITCH	
308	A-4675-077-A	PULLEY ASSY, PRESS		331	4-908-570-01	CAM, C	
309	4-908-537-01	FELT, PRESS		332	4-908-513-01	SHAFT, FULCRUM, C ARM	
310	4-908-618-01	SCREW (+BTP) (2X4)		333	7-621-259-80	SCREW +P 2.6X14	
311	4-908-551-01	CUSHION		334	*4-908-532-01	BRACKET (A), SWITCH	
312	*X-4908-510-1	ARM ASSY, C		335	*4-908-508-01	COVER, ROPÉ	
313	4-908-559-01	SPRING, COMPRESSION		336	7-685-751-04	SCREW +PTT 3X6 (S)	
314	7-621-775-80	SCREW +B 2.6X16		337	4-308-840-00	HOLDER, WIRE	
315	X-4908-513-1	PLATE ASSY, ADJUSTMENT, ARM		338	*4-908-597-01	COVER, BELT	
316	7-685-864-01	SCREW +BVTT 2.6X10 (S)		339	*4-908-541-01	BRACKET (C), SWITCH	
317	7-621-284-30	SCREW +P 2.6X8		340	4-908-621-01	SHEET	
318	4-908-555-01	SPRING, TENSION (C ARM)		901	1-452-340-11	MAGNET	
319	7-621-259-10	SCREW +P 2.6X3		912	*1-614-023-11	PC BOARD, L.C SW	
320	3-558-708-21	WASHER, STOPPER		913	*1-614-024-11	PC BOARD, CHUCKING SW	
321	*X-4908-509-1	CHASSIS ASSY, SUB		914	*1-614-025-11	PC BOARD, CHUCKING MOTOR	
322	7-624-106-04	STOP RING 3.0, TYPE -E		917	*1-614-028-11	PC BOARD, LASER SW	
323	4-908-528-01	GEAR (A)		918	*1-614-029-11	PC BOARD, LOAD IN SW	
324	4-908-529-01	GEAR (B)		924	*1-614-030-11	PC BOARD, LOAD OUT SW	

(5)



(6)



No.	Part No.	Description	REMARKS
351	7-685-870-09	SCREW +BVTT 3X5 (S)	
352	*4-908-523-01	BRACKET, MOTOR	
353	7-621-259-10	SCREW +P 2.6X3	
354	4-908-540-01	GUIDE, ASSIST	
355	7-621-775-20	SCREW +B 2.6X5	
356	4-908-571-11	PANEL, LOADING	
357	*4-908-539-01	BRACKET (B), LOADING PANEL	
358	7-685-646-29	SCREW +BVTP 3X8 TYPE2 SLIT	
359	*4-908-538-01	BRACKET (A), LOADING PANEL	
360	X-4908-508-1	PLATE ASSY (LEFT), SIDE, TABLE	
361	4-908-505-01	SHAFT (LEFT), GUIDE	
362	*4-908-530-01	PLATE (LEFT), BEARING	
363	7-685-861-09	SCREW +BVTT 2.6X5 (S)	
364	4-908-572-01	BEARING (LEFT), GUIDE	
365	4-908-552-01	SPRING, COMPRESSION	
366	*4-908-562-01	PLATE (LEFT), CAM, DISK	
367	3-558-708-21	WASHER, STOPPER	
368	3-701-439-11	WASHER	
369	*4-908-609-01	PLATE (B), GROUND	
370	*4-908-533-01	REINFORCEMENT, TABLE	
371	4-908-534-01	LEVER, FUNCTION	
372	4-908-584-01	TABLE, DISK	
373	X-4908-506-1	PLATE ASSY, DISK	
374	4-908-520-01	PLATE, LOCK	
375	*4-908-561-01	PLATE (RIGHT), CAM, DISK	
376	X-4908-507-1	PLATE ASSY (RIGHT), SIDE, TABLE	

No.	Part No.	Description	REMARKS
377	*4-908-608-01	PLATE (A), GROUND	
378	*4-908-531-01	PLATE (RIGHT), BEARING	
379	4-908-574-01	BEARING (RIGHT), GUIDE	
380	4-908-503-01	SHAFT (RIGHT), GUIDE	
381	4-908-544-01	ROPE	
382	7-685-132-19	SCREW +BTP 2.6X5 TYPE2 N-S	
383	*X-4908-502-01	BRACKET ASSY, ROPE	
384	4-908-553-01	SPRING, COMPRESSION (ROPE)	
385	7-624-104-04	STOP RING 2.0, TYPE -E	
386	4-908-550-01	STOPPER, RUBBER	
387	*X-4908-511-01	CHASSIS ASSY, MECHANICAL	
388	3-701-441-21	WASHER	
389	4-908-519-01	PULLEY (A)	
390	4-908-525-01	PULLEY (C)	
391	3-671-077-00	BELT, FF	
392	4-908-591-01	BELT, DRIVING	
393	4-908-524-01	PULLEY (B)	
394	7-624-106-04	STOP RING 3.0, TYPE -E	
395	4-887-175-00	RUBBER, STOPPER	
396	4-908-543-01	RETAINER, DISK	
397	*4-908-598-01	REINFORCEMENT, CHASSIS	
398	4-908-590-01	RETAINER, TABLE	
399	*4-908-964-01	SHEET, PS, DT	
400	*4-908-965-01	SHEET	
401	4-908-622-01	CUSHION (S)	
915	*1-614-026-11	PC BOARD, LOADING MOTOR	

No.	Part No.	Description	REMARKS	No.	Part No.	Description	REMARKS
501	7-621-775-10	SCREW +B 2.6X4		521	*4-908-232-01	LUG	
502	7-685-533-19	SCREW +BTP 2.6X6 TYPE2 N-S		522	4-908-222-01	HOLDER, PC BOARD	
503	A-4675-068-A	BRACKET ASSY, MOTOR (L151,152)		523	4-908-220-01	HOLDER, ROD	
504	2-622-105-01	RETAINER, THRUST		524	4-908-227-01	LEVER, LOCK	
505	A-4675-069-A	ROTOR ASSY		525	4-908-230-01	SPRING	
506	3-701-439-21	WASHER		526	4-908-217-01	RETAINER (B), SLIDE SHAFT	
507	7-621-773-95	SCREW +B 2.6X6		527	7-621-775-20	SCREW +B 2.6X5	
508	4-908-216-01	HOLDER, STATOR		528	*3-548-366-02	CUSHION	
509	4-908-206-01	BEARING, SPINDLE		529	4-908-203-01	YOKE (A)	
510	4-908-205-01	RETAINER (A), SLIDE SHAFT		530	4-908-214-01	YOKE (C)-1	
511	4-908-201-01	SHAFT, SLIDE		531	A-4675-070-A	MAGNET ASSY, LINEAR	
512	2-270-836-00	RUBBER, RETAINER		532	4-908-215-01	YOKE (C)-2	
513	7-621-559-80	SCREW +K 2.6X14		533	4-908-225-01	RETAINER (A), LEAD	
514	7-621-734-09	SET-SCT, HEX. 2.6X3		534	4-908-219-01	RETAINER (B), LEAD	
515	3-558-708-21	WASHER, STOPPER		535	4-908-224-01	HOLDER, BEARING	
516	4-908-212-01	CAP, CENTERING		536	4-908-221-01	BEARING	
517	4-908-213-01	SPRING, COMPRESSION		537	X-4908-202-1	PULLEY ASSY, DISK	
518	3-531-576-01	RIVET		538	4-908-593-01	INSULATOR	
519	4-908-211-02	PULLEY, DISK		919	A-4646-215-A	MONTEED PCB, FLEXIBLE	
520	7-621-259-65	SCREW +P 2.6X10		920	1-614-086-11	PC BOARD, BSL MOTOR	

NOTE:

- Items marked "★" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- If there are two or more same circuits in a set such as a stereophonic machine, only typical circuit parts may be indicated and capacitors and resistors in other same circuits may be omitted.

CAPACITORS:
MF:μF, PF:μμF.

RESISTORS

- All resistors are in ohms.
- F : nonflammable

COILS

- MMH : mH, UH : μH

SEMICONDUCTORS

In each case, U = μ, for example:
 UA...: μA..., UPA...: μPA..., UPC...: μPC,
 UPD...: μPD...

The components identified by shading and mark △ are critical for safety. Replace only with part number specified.

Les composants identifiés par une trame et une marque △ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

ELECTRICAL PARTS

Ref.No.	Part No.	Description					
901	1-452-340-11	MAGNET					
902	*1-611-717-11	PC BOARD, N					
903	*1-614-014-11	PC BOARD, P.SW					
904	*1-614-016-11	PC BOARD, SIRCS					
905	*1-614-021-11	PC BOARD, ACC					
906	*1-614-019-11	PC BOARD, LINE OUT					
907	*A-4651-033-A A-4651-034-A	(302).....MOUNTED PCB, MAIN (302ES,520ES)...MOUNTED PCB, MAIN					
908	*1-614-015-11	PC BOARD, H.P					
909	*1-614-013-11	PC BOARD, DISPLAY					
910	*1-535-139-00	BASE POST 19MM (10MM PITCH) 2P					
911	*1-614-017-11	(302)....PC BOARD, LAMP					
912	*1-614-023-11	PC BOARD, L.C SW					
913	*1-614-024-11	PC BOARD, CHUCKING SW					
914	*1-614-025-11	PC BOARD, CHUCKING MOTOR					
915	*1-614-026-11	PC BOARD, LOADING MOTOR					
916						
917	*1-614-028-11	PC BOARD, LASER SW					
918	*1-614-029-11	PC BOARD, LOAD IN SW					
919	A-4646-215-A	MOUNTED PCB, FLEXIBLE					
920	*1-614-086-11	PC BOARD, BSL MOTOR					
921	1-533-131-00	(302ES;AEP,G-AEP,UK)...HOLDER, FUSE					
922	1-526-565-00	(302ES;E)...AC PLUG ADAPTOR					
923						
924	*1-614-030-11	PC BOARD, LOAD OUT SW					
C51	1-135-008-00	TANTALUM(CHIP)2.2MF	20%	6.3V			
C151	1-162-302-31	CERAMIC 0.0022MF	20%	16V			
C152	1-162-302-31	CERAMIC 0.0022MF	20%	16V			
C153	1-161-494-00	CERAMIC 0.022MF	30%	25V			
C154	1-161-494-00	CERAMIC 0.022MF	30%	25V			
C201	1-136-169-00	FILM 0.22MF	5%	50V			
C202	1-162-302-31	CERAMIC 0.0022MF	30%	16V			
C203	1-136-165-00	FILM 0.1MF	5%	50V			
C204	1-162-290-31	CERAMIC 470PF	10%	50V			
C205	1-130-475-00	MYLAR 0.0022MF	5%	50V			
C206	1-131-371-00	TANTALUM 10MF	10%	16V			
C207	1-136-159-00	FILM 0.033MF	5%	50V			
C208	1-136-169-00	FILM 0.22MF	5%	50V			
C209	1-136-161-00	FILM 0.047MF	5%	50V			
C210	1-162-294-31	CERAMIC 0.001MF	10%	50V			
C211	1-162-302-31	CERAMIC 0.0022MF	30%	16V			
C212	1-130-487-00	MYLAR 0.022MF	5%	50V			
C213	1-162-291-31	CERAMIC 560PF	10%	50V			
C214	1-130-475-00	MYLAR 0.0022MF	5%	50V			
C215	1-136-165-00	FILM 0.1MF	5%	50V			
C216	1-130-487-00	MYLAR 0.022MF	5%	50V			

ELECTRICAL PARTS

Ref.No.	Part No.	Description					
C217	1-136-165-00	FILM 0.1MF	5%	50V			
C218	1-162-304-31	CERAMIC 0.0047MF	30%	16V			
C219	1-136-163-00	FILM 0.068MF	5%	50V			
C221	1-123-318-00	ELECT 33MF	20%	16V			
C222	1-123-318-00	ELECT 33MF	20%	16V			
C223	1-131-369-00	TANTALUM 4.7MF	10%	16V			
C235	1-162-294-31	CERAMIC 0.001MF	10%	50V			
C236	1-136-169-00	FILM 0.22MF	5%	50V			
C237	1-136-161-00	FILM 0.047MF	5%	50V			
C301	1-123-356-00	ELECT 10MF	20%	50V			
C302	1-162-302-31	CERAMIC 0.0022MF	30%	16V			
C303	1-162-302-31	CERAMIC 0.0022MF	30%	16V			
C304	1-102-725-00	CERAMIC 36PF	5%	50V			
C305	1-102-658-00	CERAMIC 180PF	5%	50V			
C306	1-102-647-00	CERAMIC 39PF	5%	50V			
C307	1-102-523-00	CERAMIC 56PF	5%	50V			
C308	1-162-294-31	CERAMIC 0.001MF	10%	50V			
C309	1-102-514-00	CERAMIC 22PF	5%	50V			
C310	1-123-318-00	ELECT 33MF	20%	16V			
C311	1-123-318-00	ELECT 33MF	20%	16V			
C312	1-123-318-00	ELECT 33MF	20%	16V			
C313	1-123-318-00	ELECT 33MF	20%	16V			
C314	1-162-284-31	CERAMIC 150PF	10%	50V			
C315	1-162-284-31	CERAMIC 150PF	10%	50V			
C316	1-123-318-00	ELECT 33MF	20%	16V			
C317	1-162-306-31	CERAMIC 0.01MF	30%	16V			
C318	1-162-306-31	CERAMIC 0.01MF	30%	16V			
C319	1-123-318-00	ELECT 33MF	20%	16V			
C321	1-130-487-00	MYLAR 0.022MF	5%	50V			
C323	1-162-294-31	CERAMIC 0.001MF	10%	50V			
C324	1-123-318-00	ELECT 33MF	20%	16V			
C325	1-123-318-00	ELECT 33MF	20%	16V			
C327	1-123-318-00	ELECT 33MF	20%	16V			
C330	1-101-005-00	CERAMIC 0.022MF	50V				
C331	1-101-005-00	CERAMIC 0.022MF	50V				
C332	1-131-374-00 (302)....TANTALUM	33MF	10%	16V			
C333	1-101-005-00	CERAMIC 0.022MF	50V				
C334	1-101-005-00	CERAMIC 0.022MF	50V				
C348	1-130-483-00	MYLAR 0.01MF	5%	50V			
C349	1-123-380-00	ELECT 1MF	20%	50V			
C351	1-123-380-00	ELECT 1MF	20%	50V			
C353	1-136-165-00	FILM 0.1MF	5%	50V			
C354	1-130-481-00	MYLAR 0.0068MF	5%	50V			
C355	1-136-169-00	FILM 0.22MF	5%	50V			
C356	1-162-290-31	CERAMIC 470PF	10%	50V			
C360	1-136-165-00	FILM 0.1MF	5%	50V			

CDP-302/302ES/520ES

ELECTRICAL PARTS

Ref. No.	Part No.	Description					
C361	1-123-330-00	ELECT	22MF	20%	25V		
C362	1-123-330-00	ELECT	22MF	20%	25V		
C363	1-161-974-00	CERAMIC	0.1MF	20%	16V		
C364	1-161-974-00	CERAMIC	0.1MF	20%	16V		
C365	1-102-114-00	CERAMIC	470PF	10%	50V		
C366	1-161-974-00	CERAMIC	0.1MF	20%	16V		
C367	1-161-974-00	CERAMIC	0.1MF	20%	16V		
C401	1-104-230-00	POLYSTYRENE	0.0015MF	5%	50V		
C402	1-123-384-00	ELECT	10MF	20%	50V		
C403	1-123-384-00	ELECT	10MF	20%	50V		
C404	1-123-384-00	ELECT	10MF	20%	50V		
C405	1-104-233-00	POLYSTYRENE	220PF	5%	125V		
C406	1-123-384-00	ELECT	10MF	20%	50V		
C407	1-130-967-00	FILM	0.0027MF	3%	100V		
C408	1-136-230-00	FILM	0.0022MF	3%	100V		
C409	1-123-318-00	ELECT	33MF	20%	16V		
C410	1-136-257-00	FILM	0.0039MF	3%	100V		
C411	1-136-252-00	FILM	0.0015MF	3%	100V		
C412	1-123-334-00	(302)....ELECT	220MF	20%	25V		
C412	1-123-694-52	(302ES,520ES)...ELECT	220MF	20%	25V		
C413	1-130-955-00	FILM	0.01MF	3%	100V		
C414	1-104-260-11	POLYSTYRENE	510PF	2%	125V		
C415	1-130-340-00	FILM	0.018MF	3%	100V		
C416	1-130-340-00	FILM	0.018MF	3%	100V		
C417	1-136-252-00	FILM	0.0015MF	3%	100V		
C419	1-123-356-00	ELECT	10MF	20%	50V		
C420	1-123-330-00	(302)....ELECT	22MF	20%	25V		
C420	1-123-700-52	(302ES,520ES)...ELECT	22MF	20%	35V		
C421	1-101-005-00	CERAMIC	0.022MF		50V		
C431	1-123-330-00	ELECT	22MF	20%	25V		
C451	1-162-290-00	CERAMIC	470PF	10%	50V		
C501	1-104-230-00	POLYSTYRENE	0.0015MF	5%	50V		
C502	1-123-384-00	ELECT	10MF	20%	50V		
C503	1-123-384-00	ELECT	10MF	20%	50V		
C504	1-123-384-00	ELECT	10MF	20%	50V		
C505	1-104-233-00	POLYSTYRENE	220PF	5%	125V		
C506	1-123-384-00	ELECT	10MF	20%	50V		
C507	1-130-967-00	FILM	0.0027MF	3%	100V		
C508	1-136-230-00	FILM	0.0022MF	3%	100V		
C509	1-123-318-00	ELECT	33MF	20%	16V		
C510	1-136-257-00	FILM	0.0039MF	3%	100V		
C511	1-136-252-00	FILM	0.0015MF	3%	100V		
C512	1-123-334-00	(302)....ELECT	220MF	20%	25V		
C512	1-123-694-52	(302ES,520ES)...ELECT	220MF	20%	25V		

ELECTRICAL PARTS

Ref. No.	Part No.	Description					
C513	1-130-955-00	FILM	0.01MF	3%	100V		
C514	1-104-260-11	POLYSTYRENE	510PF	2%	125V		
C515	1-130-340-00	FILM	0.018MF	3%	100V		
C516	1-130-340-00	FILM	0.018MF	3%	100V		
C517	1-136-252-00	FILM	0.0015MF	3%	100V		
C519	1-123-356-00	ELECT	10MF	20%	50V		
C520	1-123-330-00	(302)....ELECT	22MF	20%	25V		
C520	1-123-700-52	(302ES,520ES)...ELECT	22MF	20%	35V		
C521	1-101-005-00	CERAMIC	0.022MF		50V		
C531	1-123-330-00	ELECT	22MF	20%	25V		
C551	1-162-290-00	CERAMIC	470PF	10%	50V		
C601	1-162-294-31	CERAMIC	0.001MF	10%	50V		
C602	1-162-294-31	CERAMIC	0.001MF	10%	50V		
C651	1-136-157-00	FILM	0.022MF	5%	50V		
C652	1-136-157-00	FILM	0.022MF	5%	50V		
C653	1-136-157-00	FILM	0.022MF	5%	50V		
C654	1-130-479-00	MYLAR	0.0047MF	5%	50V		
C655	1-130-479-00	MYLAR	0.0047MF	5%	50V		
C701	1-162-306-31	CERAMIC	0.01MF	30%	16V		
C702	1-162-113-00	CERAMIC	0.01MF	30%	16V		
C801	1-162-294-31	CERAMIC	0.001MF	10%	50V		
C851	1-123-611-00	ELECT	1MF	20%	50V		
C852	1-123-613-00	ELECT	3.3MF	20%	50V		
C853	1-162-288-31	CERAMIC	330PF	10%	50V		
C854	1-123-821-00	ELECT	47MF	20%	16V		
C902	1-123-339-00	ELECT	3300MF	20%	25V		
C903	1-124-348-00	ELECT	470MF	20%	35V		
C905	1-123-491-51	(302)....ELECT	4700MF	20%	16V		
C905	1-123-327-00	(302ES,520ES)...ELECT	4700MF	20%	16V		
C906	1-123-311-00	ELECT	1000MF	20%	10V		
C911	1-123-346-00	ELECT	220MF	20%	35V		
C912	1-123-360-00	ELECT	100MF	20%	50V		
C913	1-123-345-00	ELECT	100MF	20%	35V		
C951	1-130-789-00	FILM	1MF	10%	100V		
C952	1-123-339-00	ELECT	3300MF	20%	25V		
C953	1-124-348-00	ELECT	470MF	20%	35V		
C955	1-123-326-00	(302)....ELECT	3300MF	20%	16V		
C955	1-123-339-00	(302ES,520ES)...ELECT	3300MF	20%	25V		
C956	1-123-311-00	ELECT	1000MF	20%	10V		
C961	1-136-173-00	FILM	0.47MF	5%	50V		
C962	1-123-307-00	ELECT	100MF	20%	10V		
C991	▲ 1-161-744-00	CERAMIC	0.01MF		400V		
C992	▲ 1-162-742-00	(302ES)...CERAMIC	0.0022MF	20%	400V		
C993	▲ 1-161-742-00	CERAMIC	0.0022MF	20%	400V		
C994	▲ 1-162-742-00	(302ES)...CERAMIC	0.0022MF	20%	400V		
C995	▲ 1-162-742-00	(302ES)...CERAMIC	0.0022MF	20%	400V		

The components identified by shading and mark ▲ are critical for safety. Replace only with part number specified.

Les composants identifiés par une trame et une marque ▲ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

ELECTRICAL PARTS

Ref.No.	Part No.	Description
CNJ301	1-562-677-11	SOCKET, CONNECTOR
CNJ411	1-507-912-11	(302).....JACK, PIN 2P
CNJ411	1-507-912-21	(302ES,520ES)...JACK, PIN 2P
CNJ412	1-507-863-11	JACK, LARGE TYPE, HEADPHONES
CNJ511	1-507-912-11	JACK, PIN 2P
△CNJ991	1-526-609-00	(302-US,302ES,E,520ES)...CONNECTOR AC OUTLET
△CNJ991	1-526-751-11	(302ES,UK).....OUTLET, AC
△CNJ991	1-526-794-11	(302ES,AEP,G-AEP)...OUTLET, AC
△CNJ991	1-526-882-00	(302-Canadian)....OUTLET, AC
CNP151*1-560-073-00	PIN, CONNECTOR (U TYPE)	
CNP201	1-564-710-11	PIN, CONNECTOR (SMALL TYPE) 8P
CNP202*1-564-707-11	PIN, CONNECTOR (SMALL TYPE) 5P	
CNP203*1-564-706-11	PIN, CONNECTOR (SMALL TYPE) 4P	
CNP301*1-564-507-41	PLUG, CONNECTOR 4P	
CNP302	1-564-708-11	(302ES)...PIN, CONNECTOR (SMALL TYPE) 6P
CNP302	1-564-710-11	(302)....PIN, CONNECTOR (SMALL TYPE) 8P
CNP303*1-560-064-00	PIN, CONNECTOR 6P	
CNP304*1-564-712-11	PIN, CONNECTOR (SMALL TYPE)10P	
CNP305	1-564-710-11	PIN, CONNECTOR (SMALL TYPE) 8P
CNP306*1-564-505-11	PLUG, CONNECTOR 2P	
CNP307*1-564-507-21	PLUG, CONNECTOR 4P	
CNP308*1-564-506-11	PLUG, CONNECTOR 3P	
CNP309*1-564-506-11	PLUG, CONNECTOR 3P	
CNP310*1-564-507-31	PLUG, CONNECTOR 4P	
CNP401*1-564-507-41	PLUG, CONNECTOR 4P	
CNP402*1-564-509-11	PLUG, CONNECTOR 6P	
CNP404*1-564-506-11	PLUG, CONNECTOR 3P	
CNP504*1-564-506-11	PLUG, CONNECTOR 3P	
CNP601*1-564-519-11	PLUG, CONNECTOR 4P	
CNP602*1-564-505-11	PLUG, CONNECTOR 2P	
CNP603*1-564-505-21	PLUG, CONNECTOR 2P	
CNP604*1-564-505-31	PLUG, CONNECTOR 2P	
CNP605*1-564-505-41	PLUG, CONNECTOR 2P	
CNP606*1-564-506-11	PLUG, CONNECTOR 3P	
CNP607*1-564-517-11	PLUG, CONNECTOR 2P	
CNP702*1-564-519-21	PLUG, CONNECTOR 4P	
CNP705*1-560-039-00	PIN, CONNECTOR	
CNP706*1-560-039-00	PIN, CONNECTOR	
CNP708*1-564-725-11	PIN, CONNECTOR (SMALL TYPE) 9P	
CNP901*1-564-505-11	PLUG, CONNECTOR 2P	
CNP902*1-564-507-11	PLUG, CONNECTOR 4P	
△CNP991	1-555-386-00	(302ES,E).....CORD, POWER
△CNP991	1-555-701-00	(520ES).....CORD, POWER
△CNP991	1-555-795-11	(302ES,AEP,G-AEP).....CORD, POWER
△CNP991	1-556-035-11	(302ES,UK).....CORD, POWER
△CNP991	1-556-874-00	(302-US).....CORD, POWER
△CNP991	1-557-577-11	(302-Canadian)....CORD, POWER

ELECTRICAL PARTS

Ref.No.	Part No.	Description
D51	8-719-911-19	DIODE 1SS119
D201	8-719-951-13	DIODE HZ5CLL
D202	8-719-911-19	DIODE 1SS119
D205	8-719-911-19	DIODE 1SS119
D211	8-719-911-19	DIODE 1SS119
D213	8-719-101-32	DIODE RD2.7EL1
D301	8-719-911-19	DIODE 1SS119
D302	8-719-902-39	DIODE KV1236Z
D651	8-719-200-02	DIODE 10E-2
D652	8-719-200-02	DIODE 10E-2
D653	8-719-200-02	DIODE 10E-2
D701	8-719-911-19	DIODE 1SS119
D702	8-719-911-19	DIODE 1SS119
D703	8-719-911-19	DIODE 1SS119
D704	8-719-100-29	DIODE RD5.1EB1
D805	8-719-907-81	DIODE BG5535S
D806	8-719-907-80	DIODE AA5535S
D807	8-719-918-57	DIODE GL-5NG27
D809	8-719-907-81	DIODE BG5535S
D851	8-719-110-32	DIODE PH302B
D901	8-719-200-31	DIODE 21DQ05
D902	8-719-200-31	DIODE 21DQ05
D903	8-719-200-31	DIODE 21DQ05
D904	8-719-200-31	DIODE 21DQ05
D905	8-719-210-12	DIODE 10DF2
D906	8-719-210-12	DIODE 10DF2
D907	8-719-210-12	DIODE 10DF2
D908	8-719-210-12	DIODE 10DF2
D909	8-719-200-02	DIODE 10E-2
D910	8-719-200-02	DIODE 10E-2
D911	8-719-911-19	DIODE 1SS119
D912	8-719-911-19	DIODE 1SS119
D913	8-719-101-07	DIODE RD33EB3
D914	8-719-911-19	DIODE 1SS119
D915	8-719-100-48	DIODE RD8.2EB2
F901	A 1-532-078-00	(302ES,AEP,G-AEP)...FUSE, TIME LAG (1A)
F901	A 1-532-286-00	(302ES,UK)....FUSE, TIME LAG (2.5A)
F902	A 1-532-078-00	(302ES,AEP,G-AEP)...FUSE, TIME LAG (1A)
FLD201	1-519-304-00	INDICATOR TUBE, FLUORESCENT
H151	8-719-800-31	DIODE THS103A-1
H152	8-719-800-31	DIODE THS103A-1
IC151	8-759-600-02	IC CX20109
IC201	8-752-010-80	IC CX20108
IC202	8-759-700-58	IC NJM4558D-FA

The components identified by shading and mark △ are critical for safety. Replace only with part number specified.

Les composants identifiés par une trame et une marque △ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

CDP-302/302ES/520ES

ELECTRICAL PARTS

Ref.No.	Part No.	Description
IC301	8-759-602-25	IC M50760-414P
IC302	8-759-913-84	IC MSM6404A-41RS
IC303	8-759-913-82	IC MSM6404A-39RS
IC304	8-759-202-13	IC TC74HCU04P
IC305	8-759-100-82	IC UPC4082C
IC306	8-759-145-58	IC UPC4558C
IC307	8-759-912-52	IC CX23035
IC308	8-759-913-72	IC MB8416-20LPF
IC309	8-759-912-53	IC CX23034
IC310	8-752-015-20	IC CX20152
IC311	8-759-140-53	IC UPD4053BC
IC312	8-759-984-66	IC MB84066B
IC401	8-759-910-75	IC TDB0353DP
IC402	8-759-602-33	IC CX20197
IC403	8-759-602-33	IC CX20197
IC501	8-759-910-75	IC TDB0353DP
IC502	8-759-602-33	IC CX20197
IC503	8-759-602-33	IC CX20197
IC801	8-759-600-35	IC M54940P
IC851	8-752-010-60	IC CX20106
IC901	8-759-700-51	IC NJM7805A
IC902	8-759-700-28	IC NJM7905A
IC903	8-759-170-12	IC UPC78M12H
IC904	8-759-700-24	IC NJM79M12A
IC905	8-759-700-11	IC NJM78M05A
IC906	8-759-700-20	IC NJM79M05A
L51	1-408-563-00	MICRO INDUCTOR 10UH
L301	1-426-212-11	COIL (RF)
L302	1-406-123-11	COIL (OSC)
L303	1-408-597-00	MICRO INDUCTOR 3.3UH
L304	1-408-597-00	MICRO INDUCTOR 3.3UH
L305	1-408-597-00	MICRO INDUCTOR 3.3UH
L601	1-408-117-00	MICRO INDUCTOR 10UH
L901 A	1-421-580-00	(302, 520ES) ... TRANSFORMER, LINE FILTER (R)
L901 A	1-421-340-11	(302ES, AEP, G-AEP, UK) ... LINE FILTER
M53	1-422-197-13	COIL (DRIVE)
M651	X-4902-019-1	MOTOR ASSY, CHUCKING
M652	A-4608-303-A	MOTOR ASSY, LOADING
PL901	1-518-370-00	(302)...LAMP, PILOT
PT901 A	1-448-016-11	(302, 520ES) ... TRANSFORMER, POWER
PT901 A	1-448-017-11	(302ES, E) ... TRANSFORMER, POWER
PT901 A	1-448-018-11	(302ES, AEP, G-AEP, UK) ... TRANSFORMER, POWER
PS301	1-532-685-00	LINK, IC
PS901	1-532-675-00	LINK, IC
PS902	1-532-675-00	LINK, IC

ELECTRICAL PARTS

Ref.No.	Part No.	Description
PS951	1-532-675-00	LINK, IC
PS952	1-532-675-00	LINK, IC
Q151	8-729-177-44	TRANSISTOR 2SD774-5
Q152	8-729-103-43	TRANSISTOR 2SB734-2
Q153	8-729-177-44	TRANSISTOR 2SD774-5
Q154	8-729-103-43	TRANSISTOR 2SB734-2
Q201	8-729-177-44	TRANSISTOR 2SD774-5
Q202	8-729-374-02	TRANSISTOR 2SB740
Q203	8-729-177-44	TRANSISTOR 2SD774-5
Q204	8-729-374-02	TRANSISTOR 2SB740
Q205	8-729-177-44	TRANSISTOR 2SD774-5
Q206	8-729-374-02	TRANSISTOR 2SB740
Q209	8-729-117-54	TRANSISTOR 2SA1175
Q210	8-729-100-13	TRANSISTOR 2SC2001
Q211	8-729-900-74	TRANSISTOR DTC143TS
Q212	8-729-900-74	TRANSISTOR DTC143TS
Q213	8-729-900-89	TRANSISTOR DTC144ES
Q301	8-729-177-44	TRANSISTOR 2SD774-5
Q302	8-729-374-02	TRANSISTOR 2SB740
Q303	8-729-900-81	TRANSISTOR DTC114ES
Q304	8-729-900-81	TRANSISTOR DTC114ES
Q305	8-729-900-81	TRANSISTOR DTC114ES
Q306	8-729-900-81	TRANSISTOR DTC114ES
Q307	8-729-900-62	TRANSISTOR DTA114ES
Q308	8-729-900-81	TRANSISTOR DTC114ES
Q309	8-729-178-55	TRANSISTOR 2SC2785-E
Q310	8-729-900-81	TRANSISTOR DTC114ES
Q401	8-729-800-43	TRANSISTOR 2SK152
Q501	8-729-800-43	TRANSISTOR 2SK152
Q801	8-729-900-46	TRANSISTOR DTC143TF
Q802	8-729-900-46	TRANSISTOR DTC143TF
Q803	8-729-900-46	TRANSISTOR DTC143TF
Q804	8-729-987-42	TRANSISTOR 2SA874
Q901	8-729-177-44	TRANSISTOR 2SD774-5
Q902	8-729-178-55	TRANSISTOR 2SC2785-E
Q903	8-729-178-55	TRANSISTOR 2SC2785-E
Q904	8-729-900-62	TRANSISTOR DTA114ES
Q905	8-729-117-54	TRANSISTOR 2SA1175
Q906	8-729-900-81	TRANSISTOR DTC114ES
R151	1-247-831-00	CARBON 1K 5% 1/6W
R152	1-247-831-00	CARBON 1K 5% 1/6W
R153	1-247-831-00	CARBON 1K 5% 1/6W
R154	1-247-831-00	CARBON 1K 5% 1/6W
R155	1-247-831-00	CARBON 1K 5% 1/6W
R156	1-247-831-00	CARBON 1K 5% 1/6W

The components identified by shading and mark **▲** are critical for safety. Replace only with part number specified.

Les composants identifiés par une trame et une marque **▲** sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

ELECTRICAL PARTS

Ref.No.	Part No.	Description	220K	5%	1/6W
R157	1-247-887-00	CARBON	220K	5%	1/6W
R158	1-247-887-00	CARBON	220K	5%	1/6W
R159	1-247-887-00	CARBON	220K	5%	1/6W
R160	1-247-887-00	CARBON	220K	5%	1/6W
R201	1-247-863-00	CARBON	22K	5%	1/6W
R202	1-247-851-00	CARBON	6.8K	5%	1/6W
R203	1-247-867-00	CARBON	33K	5%	1/6W
R204	1-247-847-00	CARBON	4.7K	5%	1/6W
R205	1-247-819-00	CARBON	330	5%	1/6W
R206	1-247-865-00	CARBON	27K	5%	1/6W
R207	1-247-807-00	CARBON	100	5%	1/6W
R208	1-247-851-00	CARBON	6.8K	5%	1/6W
R209	1-247-864-00	CARBON	24K	5%	1/6W
R210	1-247-851-00	CARBON	6.8K	5%	1/6W
R211	1-247-831-00	CARBON	1K	5%	1/6W
R212	1-247-859-00	CARBON	15K	5%	1/6W
R213	1-247-855-00	CARBON	10K	5%	1/6W
R214	1-247-837-00	CARBON	1.8K	5%	1/6W
R215	1-247-879-00	CARBON	100K	5%	1/6W
R216	1-247-869-00	CARBON	39K	5%	1/6W
R217	1-247-855-00	CARBON	10K	5%	1/6W
R218	1-247-903-00	CARBON	1M	5%	1/6W
R219	1-247-831-00	CARBON	1K	5%	1/6W
R220	1-247-807-00	CARBON	100	5%	1/6W
R221	1-247-863-00	CARBON	22K	5%	1/6W
R222	1-247-857-00	CARBON	12K	5%	1/6W
R223	1-247-841-00	CARBON	2.7K	5%	1/6W
R224	1-247-869-00	CARBON	39K	5%	1/6W
R225	1-247-843-00	CARBON	3.3K	5%	1/6W
R226	1-247-859-00	CARBON	15K	5%	1/6W
R227	1-247-845-00	CARBON	3.9K	5%	1/6W
R228	1-247-815-00	CARBON	220	5%	1/6W
R229	1-247-865-00	CARBON	27K	5%	1/6W
R231	1-247-883-00	CARBON	150K	5%	1/6W
R232	1-247-899-00	CARBON	680K	5%	1/6W
R235	1-247-855-00	CARBON	10K	5%	1/6W
R236	1-247-855-00	CARBON	10K	5%	1/6W
R242	1-247-855-00	CARBON	10K	5%	1/6W
R243	1-247-895-00	CARBON	470K	5%	1/6W
R244	1-247-839-00	CARBON	2.2K	5%	1/6W
R245	1-247-855-00	CARBON	10K	5%	1/6W
R246	1-247-831-00	CARBON	1K	5%	1/6W
R247	1-247-871-00	CARBON	47K	5%	1/6W
R301	1-247-847-00	CARBON	4.7K	5%	1/6W
R302	1-247-841-00	CARBON	2.7K	5%	1/6W

ELECTRICAL PARTS

R303	1-215-453-00	METAL	22K	1%	1/6W
R304	1-215-453-00	METAL	22K	1%	1/6W
R305	1-247-851-00	CARBON	6.8K	5%	1/6W
R306	1-247-857-00	CARBON	12K	5%	1/6W
R307	1-247-867-00	CARBON	33K	5%	1/6W
R308	1-247-831-00	CARBON	1K	5%	1/6W
R309	1-247-879-00	CARBON	100K	5%	1/6W
R310	1-247-879-00	CARBON	100K	5%	1/6W
R311	1-247-879-00	CARBON	100K	5%	1/6W
R313	1-214-741-00	METAL	3.3K	1%	1/4W
R314	1-214-745-00	METAL	4.7K	1%	1/4W
R315	1-214-769-00	METAL	47K	1%	1/4W
R316	1-214-745-00	METAL	4.7K	1%	1/4W
R317	1-247-855-00	CARBON	10K	5%	1/6W
R318	1-247-855-00	CARBON	10K	5%	1/6W
R319	1-247-903-00	CARBON	1M	5%	1/6W
R320	1-247-843-00	CARBON	3.3K	5%	1/6W
R321	1-247-871-00	CARBON	47K	5%	1/6W
R322	1-247-855-00	CARBON	10K	5%	1/6W
R323	1-247-855-00	CARBON	10K	5%	1/6W
R324	1-247-855-00	CARBON	10K	5%	1/6W
R325	1-247-863-00	CARBON	22K	5%	1/6W
R326	1-247-863-00	CARBON	22K	5%	1/6W
R327	1-247-855-00	CARBON	10K	5%	1/6W
R351	1-215-441-00	METAL	6.8K	1%	1/6W
R352	1-215-441-00	METAL	6.8K	1%	1/6W
R353	1-247-903-00	CARBON	1M	5%	1/6W
R354	1-247-856-00	CARBON	11K	5%	1/6W
R355	1-247-856-00	CARBON	11K	5%	1/6W
R357	1-247-863-00	CARBON	22K	5%	1/6W
R358	1-247-843-00	CARBON	3.3K	5%	1/6W
R359	1-247-869-00	CARBON	39K	5%	1/6W
R360	1-215-453-00	METAL	22K	1%	1/6W
R361	1-247-815-00	CARBON	220	5%	1/6W
R362	1-247-815-00	CARBON	220	5%	1/6W
R363	1-247-887-00	CARBON	220K	5%	1/6W
R365	1-247-851-00	CARBON	6.8K	5%	1/6W
R366	1-247-807-00	CARBON	100	5%	1/6W
R367	1-215-449-00	METAL	15K	1%	1/6W
R368	1-247-807-00	CARBON	100	5%	1/6W
R401	1-214-733-00	METAL	1.5K	1%	1/4W
R402	1-214-742-00	METAL	3.6K	1%	1/4W
R403	1-214-759-00	METAL	18K	1%	1/4W
R404	1-214-745-00	METAL	4.7K	1%	1/4W
R405	1-214-741-00	METAL	3.3K	1%	1/4W

CDP-302/302ES/520ES

ELECTRICAL PARTS

Ref. No.	Part No.	Description			
R406	1-214-737-00	METAL	2.2K	1%	1/4W
R407	1-214-737-00	METAL	2.2K	1%	1/4W
R408	1-214-737-00	METAL	2.2K	1%	1/4W
R409	1-214-737-00	METAL	2.2K	1%	1/4W
R410	1-214-738-00	METAL	2.4K	1%	1/4W
R411	1-214-738-00	METAL	2.4K	1%	1/4W
R412	1-214-742-00	METAL	3.6K	1%	1/4W
R413	1-214-731-00	METAL	1.2K	1%	1/4W
R414	1-214-964-00	METAL	1M	1%	1/4W
R415	1-214-742-00	METAL	3.6K	1%	1/4W
R416	1-214-743-00	METAL	3.9K	1%	1/4W
R417	1-214-777-00	METAL	100K	1%	1/4W
R418	1-214-705-00	METAL	100	1%	1/4W
R419	1-214-761-00	METAL	22K	1%	1/4W
R420	1-214-717-00	METAL	330	1%	1/4W
R421	1-247-815-00	CARBON	220	5%	1/6W
R431	1-247-823-00	CARBON	470	5%	1/6W
R432	1-247-831-00	CARBON	1K	5%	1/6W
R433	1-247-847-00	CARBON	4.7K	5%	1/6W
R434	1-247-867-00	CARBON	33K	5%	1/6W
R435	1-247-815-00	CARBON	220	5%	1/6W
R501	1-214-733-00	METAL	1.5K	1%	1/4W
R502	1-214-742-00	METAL	3.6K	1%	1/4W
R503	1-214-759-00	METAL	18K	1%	1/4W
R504	1-214-745-00	METAL	4.7K	1%	1/4W
R505	1-214-741-00	METAL	3.3K	1%	1/4W
R506	1-214-737-00	METAL	2.2K	1%	1/4W
R507	1-214-737-00	METAL	2.2K	1%	1/4W
R508	1-214-737-00	METAL	2.2K	1%	1/4W
R509	1-214-737-00	METAL	2.2K	1%	1/4W
R510	1-214-738-00	METAL	2.4K	1%	1/4W
R511	1-214-738-00	METAL	2.4K	1%	1/4W
R512	1-214-742-00	METAL	3.6K	1%	1/4W
R513	1-214-731-00	METAL	1.2K	1%	1/4W
R514	1-214-964-00	METAL	1M	1%	1/4W
R515	1-214-742-00	METAL	3.6K	1%	1/4W
R516	1-214-743-00	METAL	3.9K	1%	1/4W
R517	1-214-777-00	METAL	100K	1%	1/4W
R518	1-214-705-00	METAL	100	1%	1/4W
R519	1-214-761-00	METAL	22K	1%	1/4W
R520	1-214-717-00	METAL	330	1%	1/4W
R521	1-247-815-00	CARBON	220	5%	1/6W
R531	1-247-823-00	CARBON	470	5%	1/6W
R532	1-247-831-00	CARBON	1K	5%	1/6W
R533	1-247-847-00	CARBON	4.7K	5%	1/6W

ELECTRICAL PARTS

Ref. No.	Part No.	Description			
R534	1-247-867-00	CARBON	33K	5%	1/6W
R535	1-247-815-00	CARBON	220	5%	1/6W
R601	1-247-881-00	CARBON	120K	5%	1/6W
R602	1-247-881-00	CARBON	120K	5%	1/6W
R603	1-247-885-00	CARBON	180K	5%	1/6W
R604	1-247-885-00	CARBON	180K	5%	1/6W
R605	1-247-815-00	CARBON	220	5%	1/6W
R701	1-247-783-00	CARBON	10	5%	1/6W
R702	1-247-783-00	CARBON	10	5%	1/6W
R801	1-247-111-00	CARBON	150	5%	1/4W
R802	1-247-119-00	CARBON	330	5%	1/4W
R803	1-247-111-00	CARBON	150	5%	1/4W
R804	1-247-111-00	CARBON	150	5%	1/4W
R851	1-247-775-00	CARBON	4.7	5%	1/6W
R852	1-214-784-00	METAL	200K	1%	1/4W
R853	1-247-863-00	CARBON	22K	5%	1/6W
R854	1-247-799-00	CARBON	47	5%	1/6W
R901	1-212-865-00	FUSE	22	5%	1/4W
R911	1-212-857-00	FUSE	10	5%	1/4W
R912	1-247-839-00	CARBON	2.2K	5%	1/6W
R913	1-244-837-00	CARBON	33	5%	1/2W
R961	1-247-855-00	CARBON	10K	5%	1/6W
R962	1-247-859-00	CARBON	15K	5%	1/6W
R963	1-247-881-00	CARBON	120K	5%	1/6W
R964	1-247-855-00	CARBON	10K	5%	1/6W
R965	1-247-847-00	CARBON	4.7K	5%	1/6W
RV201	1-226-773-00	RES, ADJ, METAL GLAZE	22K		
RV202	1-226-703-00	RES, ADJ, METAL GLAZE	10K		
RV301	1-226-772-00	RES, ADJ, METAL GLAZE	4.7K		
RV401	1-230-313-00	RES, VAR, CARBON	20K/20K, LEVEL		
RV501	1-230-313-00	RES, VAR, CARBON	20K/20K, LEVEL		
RY901	1-515-529-11	RELAY			
S651	1-554-205-00	SWITCH, PUSH			
S652	1-554-205-00	SWITCH, PUSH			
S653	1-553-636-00	SWITCH, MICRO			
S654	1-553-636-00	SWITCH, MICRO			
S655	1-554-205-00	SWITCH, PUSH			
S656	1-554-205-00	SWITCH, PUSH			
S801	1-553-856-00	SWITCH, KEY BOARD, PLAY			
S802	1-553-856-00	SWITCH, KEY BOARD, PAUSE			
S803	1-553-856-00	SWITCH, KEY BOARD, STOP			
S804	1-553-856-00	SWITCH, KEY BOARD, OPEN			
S805	1-553-856-00	SWITCH, KEY BOARD, CLEAR			
S806	1-553-856-00	SWITCH, KEY BOARD, ◀◀			

The components identified by shading and mark  are critical for safety. Replace only with part number specified.

Les composants identifiés par une trame et une marque  sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

CDP-302/302ES/520ES

ELECTRICAL PARTS

Ref. No.	Part No.	Description
S807	1-553-856-00	SWITCH, KEY BOARD, ►
S808	1-553-856-00	SWITCH, KEY BOARD, START
S809	1-553-856-00	SWITCH, KEY BOARD, ◀◀
S810	1-553-856-00	SWITCH, KEY BOARD, ►►
S811	1-553-856-00	SWITCH, KEY BOARD, ▲▲
S812	1-553-856-00	SWITCH, KEY BOARD, ▶▶
S813	1-553-856-00	SWITCH, KEY BOARD, A↔B
S814	1-553-856-00	SWITCH, KEY BOARD, 1/ALL
S815	1-553-856-00	SWITCH, KEY BOARD, SET
S816	1-553-856-00	SWITCH, KEY BOARD, TIME
S901A	1-553-318-00	SWITCH, PUSH (AC POWER)(1 KEY), POWER
SE51	1-422-198-11	COIL (SENSOR)
TB901	*1-535-121-00	TERMINAL
VS901A 1-552-963-00 (302ES; E) ... SWITCH POWER/VOLTAGE SELECT		
X301	1-527-532-00	OSCILLATOR, CERAMIC
X302	1-567-336-11	VIBRATOR, CRYSTAL

ACCESSORY & PACKING MATERIAL

No.	Part No.	Description
701	A-4600-438-A	COMMANDER COMPLETE ASSY (RM-D902)
702	1-551-315-11	(302ES,520ES)...CORD, CONNECTION (RK-112)
702	1-551-734-11	(302)...CORD, CONNECTION (RK-74A)
703	A 1-564-085-00	(302ES;UK)...PLUG, AC (CM-35)
704	1-556-372-41	CORD, CONNECTION (4 CORE)
705	3-701-630-00	BAG, POLYETHYLENE
706	3-703-390-01	(302,520ES)...INSTRUCTION
706	3-795-629-14	(302ES;AEP)...INSTRUCTION
707	3-760-149-11	(302ES)....MANUAL, INSTRUCTION
707	3-760-149-21	(302).....MANUAL, INSTRUCTION
707	3-760-149-31	(302; Canadian)...MANUAL, INSTRUCTION
707	3-760-149-41	(302ES;AEP,G-AEP)...MANUAL, INSTRUCTION
707	3-760-402-21	(520ES)....MANUAL, INSTRUCTION
708	4-884-695-03	CLEANER, DISK
709	4-907-610-01	JOINT
710	3-304-973-00	SHHEET, PROTECTION
711	4-908-440-11	(302)....INDIVIDUAL CARTON
711	4-908-440-21	(302ES)...INDIVIDUAL CARTON
711	4-908-440-31	(520ES)...INDIVIDUAL CARTON
712	4-908-441-01	CUSHION (RIGHT), UPPER
713	4-908-442-01	CUSHION (LEFT), UPPER
714	4-908-443-01	CUSHION, LOWER
715	4-908-602-01	HOLDER, COMMANDER

The components identified by shading and mark  are critical for safety. Replace only with part number specified.

Les composants identifiés par une trame et une marque  sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.