


CDP-555ESD /705ESD

SERVICE MANUAL



*CDP-555ESD.
AEP Model
UK Model
CDP-705ESD.
US Model*

COMPACT
DISC
DIGITAL AUDIO

SPECIFICATIONS

COMPACT DISC PLAYER CDP-705ESD

System	Compact disc digital audio system
Disc	Compact disc
Laser	Semiconductor laser ($\lambda = 780 \text{ nm}$)
Laser output	Max. 0.4 mW*
	*This output is the value measured at a distance of about 1.6 mm from the objective lens surface on the Optical Pick-up Block.
Spindle speed	200 rpm to 500 rpm (CLV)
Scan velocity	1.2–1.4 m/sec
Error correction	Sony Super Strategy Cross Interleave Reed Solomon Code
Number of channel	Two
D/A conversion	16-bit linear
Frequency response	2–20,000 Hz ± 0.3 dB
Signal to noise ratio	More than 106 dB
Dynamic range	More than 97 dB
Harmonic distortion	Less than 0.0025% (1 kHz)
Channel separation	More than 100 dB (1 kHz)
Wow and flutter	Below measurable limit
Output jacks	

	Max. output level	Load impedance	Output impedance
LINE OUT (FIXED) phono jacks	2 V (50 k Ω)	More than 10 k Ω	200 Ω
LINE OUT (VARIABLE) phono jacks	0–2 Vrms (50 k Ω)	More than 30 k Ω	200–2.5 k Ω
DIGITAL OUT phono jack	0.5 Vp-p (75 Ω)	75 Ω	75 Ω
HEADPHONES Phone jack	28 mW Variable, max	32 Ω	—

Disc

Track pitch	1.6 μm
Sampling frequency	44.1 kHz
Quantization	16 bit linear quantizing/channel
Modulation system	EFM
Transfer rate	2.03 Mbit/sec. (before modulation)


General

Power requirements	120V AC, 60 Hz
Power consumption	20 W
Power requirements	CDP-555ESD (AEP, UK model) 220–240 V AC, 50 Hz
	CDP-705ESD (US model) 120 V AC, 60 Hz
Dimensions	Approx. 430 × 125 × 395 mm (w/h/d) (17 × 5 × 15½ inches)
Weight	Approx. 14.1 kg (31 lb 1 oz), net

SAFETY-RELATED COMPONENT WARNING!!

COMPONENTS IDENTIFIED BY SHADING AND MARK ON THE SCHEMATIC DIAGRAMS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.

COMPACT DISC PLAYER
SONY[®]



CDP-555ESD/705ESD


CONTENTS

Title	Page
SPECIFICATIONS	1
MODEL IDENTIFICATION	2
SAFETY CHECK (US model)	3
NOTES ON HANDLING THE OPTICAL BLOCK	4
FUNCTION OF CONTROLS	5-6
TRABULE CHECK	7
ELECTRICAL ADJUSTMENTS	8-10
IC BLOCK DIAGRAM	11-12
CIRCUIT BOARD LOCATION	13
SCHEMATIC NOTE	14
SEMICONDUCTOR LEAD LAYOUTS	14
MOUNTING DIAGRAM (Flexible Board)	15-16
MOUNTING DIAGRAM (Main)	17-20
SCHEMATIC DIAGRAM	21-25
EXPLODED VIEWS AND PARTS LIST	27-33
ELECTRICAL PARTS LIST	34-38

MODEL IDENTIFICATION

—Specification Label—

CDP-555ESD (AEP, UK, E model)
CDP-705ESD (US model)



CDP-555ESD

AEP, UK, E model: AC 220 - 240 V ~ 50/60 Hz 20 W

CDP-705ESD

US model: AC 120 V ~ 60 Hz 20 W

SAFETY CHECK-OUT (US Model)

After correcting the original service problem, perform the following safety check before releasing the set to the customer:

Check the antenna terminals, metal trim, "metallized" knobs, screws, and all other exposed metal parts for AC leakage. Check leakage as described below.

LEAKAGE TEST

The AC leakage from any exposed metal part to earth ground and from all exposed metal parts to any exposed metal part having a return to chassis, must not exceed 0.5 mA (500 microamper). Leakage current can be measured by any one of three methods.

1. A commercial leakage tester, such as the Simpson 229 or RCA WT-540A. Follow the manufacturers' instructions to use these instruments.
2. A battery-operated AC milliammeter. The Data Precision 245 digital multimeter is suitable for this job.
3. Measuring the voltage drop across a resistor by means of a VOM or battery-operated AC voltmeter. The "limit" indication is 0.75 V, so analog meters must have an accurate low-voltage scale. The Simpson 250 and Sanwa SH-63Trd are examples of a passive VOM that is suitable. Nearly all battery operated digital multimeters that have a 2 V AC range are suitable. (See Fig. A)




Fig. A. Using an AC voltmeter to check AC leakage.


NOTES ON HANDLING THE OPTICAL BLOCK (KSS-121A)

The laser diode inside the optical block may be damaged by static electricity in clothes or the human body.

The following procedures are required when unpacking and repairing KSS-121A in order to avoid static electricity damage.

1. Body grounding
Be sure to wear a ground belt (less than $10^8 \Omega$) in order to release the static electricity stored in the body.
2. Workbench grounding
Place a conductive sheet (less than $10^9 \Omega$) or copper plate on the bench where KSS-121A is to be placed to ground it.
3. Static electricity in the clothing will not be released by the ground belt, so be careful not to let KSS-121A touch clothing.


*During replacement or repair,
be sure to remove the solder
at these locations with a
soldering iron as shown in the
figure (to prevent laser diode
static damage).*




— SERVICING NOTE —

LASER DIODE AND FOCUS SEARCH OPERATION CHECK

1. Remove disc pulley by lifting up chucking arm by hand. (Fig. A, B)
2. Make POWER switch on with no disc inserted and disc table closed.
3. Confirm that the operation indicated in Fig. C is performed while observing the objective lens.



Lift up chucking arm by hand in the direction of arrow.



- ① Confirm that laser beam is spread.
- ② Up and down motion of the objective lens. (3 times)

Fig. C


NOTES ON LASER DIODE EMISSION CHECK

The laser beam on this model is concentrated so as to be focused on the disc reflective surface by the objective lens in the optical pick-up block. Therefore, when checking the laser diode emission, observe more than 25 cm away from the objective lens.

NOTE ON THE TRANSIT LEVER

A transit lever is provided at the bottom of the unit to protect the optical system against shock during transportation. Before operating the CD player, be sure to move the lever in the direction of the arrow and secure it.


- 1 Loosen the red screw with a screwdriver.
- 2 Insert the screwdriver into the slot in the lever and move it in the direction of the arrow until it stops.
- 3 Tighten the red screw.



When transporting the unit again, move the lever in the opposite direction of the arrow and secure it with the screw.

LOCATION OF CONTROLS

DISC PLAYER




Display Window

INDEX/STEP Indicator
Shows the index numbers of the selection being played.
Also, shows the program numbers while programming or checking program.

TRACK Indicator
Shows the track number of the selection being played.
When the disc compartment is closed with a disc in place, this indicator shows for a few seconds the total number of selections on the disc.


Disc Indicator
Illuminates when the disc compartment is closed with a disc in place or when the disc compartment is opened.

TIME/NEXT Indicator
Shows the elapsed time of the selection being played.
When the disc compartment is closed with a disc in place, this indicator shows for a few seconds the total playing time of the disc.
While playing programmed selections, this shows the two preceding programmed selections.



REMOTE COMMANDER

Buttons whose functions are the same as the CDP-705ESD.




TROUBLE CHECKS

The following checks will assist in the correction of most problems which you may encounter with your unit. Should any problem persist after you have made these checks, consult your nearest Sony service facility. Before going through the check list below, first refer back to the connection and operating procedures.

TROUBLE	CAUSES	REMEDY
The disc compartment does not close when a disc is inserted and the ▲ button is pressed.	The disc is not placed correctly.	Center the disc correctly in the disc compartment.
Play does not start.	Dirty disc	Clean the disc.
	The disc is inserted with the label surface downward.	Place the disc with the label surface up.
	The ■ button is engaged.	Press the ■ button again to release it.
	Moisture condensation	Wait for approx. one hour after turning on the unit then start play.
Sound is not heard.	Loose connection	Connect the cords firmly.
	The DIGITAL OUT switch is set to ON while using the LINE OUT jacks.	Set the DIGITAL OUT switch to OFF.
	The LINE OUT/PHONE LEVEL control is set to the minimum (0) while using the VARIABLE LINE OUT jacks.	Turn the LINE OUT/PHONE LEVEL control clockwise.
Display window does not illuminate even when the power turns on.	The AC power cord is disconnected.	Connect the AC power cord firmly.
Play begins when the POWER switch is turned on.	The TIMER switch is set to PLAY or SHUFFLE.	Set the TIMER switch to OFF.
Level of the recorded sound is different from that set on the tape recorder.	When the VARIABLE LINE OUT jacks are used, the LINE OUT/PHONE LEVEL control is turned while recording.	Do not turn the LINE OUT/PHONE LEVEL control while recording.

Note on removal

First of all remove the base retainer when remove the front base retainer panel.




ELECTRICAL ADJUSTMENTS

1. Perform adjustments in the order given.
2. Use YEDS-1 disc unless otherwise indicated.
3. Use the oscilloscope with more than $10 \text{ M}\Omega$ impedance.

Adjustment Mode

1. Connect main board test point ADJ and GND. This is to prevent the disc table from opening even though pits are not read, by making microcomputer IC303 pin 0 low.
2. Turn POWER switch on. (To reset microcomputer.) After adjustment, remove the lead wire connecting test points ADJ and GND.

Adjustment Location: main board




RF PLL Adjustment

Procedure:

1. Connect main board test point ASY and GND.
2. Connect the frequency counter to main board test points TP PLCK and TP GND.
3. Turn POWER switch ON (stop mode).
4. Adjust main board RV201 so that reading on frequency counter is $4.4018 \text{ MHz} \pm 20 \text{ kHz}$.
5. Reconnect lead wires connected in adjustment mode.
6. Put disc (YEDS-18) in and press ▶ PLAY button.
7. Confirm that reading on frequency counter is 4.3218 MHz .

Adjustment Location: main board



REFERENCE

Focus/Tracking Gain Adjustment

A frequency response analyzer is necessary in order to perform this adjustment exactly.

However, this gain has a margin, so even if it is slightly off, there is no problem. Therefore, do not perform this adjustment.

Focus/tracking gain determines the pick-up follow-up (vertical and horizontal) relative to mechanical noise and mechanical shock when the 2-axis device operate.

However, as these reciprocate, the adjustment is at the point where both are satisfied.

- When gain is raised, the noise when the 2-axis device operates increases.
- When gain is lowered, it is more susceptible to mechanical shock and skipping occurs more easily.
- When gain adjustment is off, the symptoms below appear.


Symptoms	Gain	Focus	Tracking
• The time until music starts becomes longer for STOP → ▶PLAY or automatic selection (◀◀▶▶ buttons pressed. (Normally takes about 2 seconds.)	low	low or high	
• Music does not start and disc continues to rotate for STOP → ▶PLAY or automatic selection (◀◀▶▶ buttons pressed.)	-	low	
• Disc table opens shortly after STOP → ▶PLAY.	low or high	-	
• Sound is interrupted during PLAY. Or time counter display stops progressing.	-	low	
• More noise during 2-axis device operation.	high	high	

The following is a simple adjustment method.


Simple Adjustment -

Note: Since exact adjustment cannot be performed, remember the positions of the controls before performing the adjustment. If the positions after the simple adjustment are only a little different, return the controls to the original position.



Procedure:



1. Keep the set horizontal. If the set is not horizontal, this adjustment cannot be performed due to the gravity against the 2 axis device.
2. Put set in adjustment mode. (See page 13.)
3. Insert disc (YEDS-1) and press ▶PLAY button.
4. Connect oscilloscope to servo board TP FE.
5. Adjustment RV203 so that the waveform is as shown in the figure below. (focus gain adjustment)



- Incorrect Examples (DC level changes more than on adjusted waveform)




6. Connect oscilloscope to main board TP TE.

7. Adjust RV304 so that the waveform is as shown in the figure below. (tracking gain adjustment)




- Incorrect Examples (fundamental wave appears)







- high tracking gain
(higher fundamental wave than for low gain)




Adjustment Location: main board




IC BLOCK DIAGRAM



CIRCUIT BOARDS LOCATION



● Semiconductor Lead Layouts




Note: SCHEMATIC DIAGRAM

- : B+ bus.
- - - : B- bus.
- : adjustment for repair.
- Voltages are dc with respect to ground unless otherwise noted.
- Readings are taken under no-signal (detuned) conditions with VOM (50 kΩ/V).
- Voltage variations may be noted due to normal production tolerances.
- Waveforms are taken with respect to ground with oscilloscope.
- Voltage variations may be noted due to normal production tolerances.
- Switches:

Ref. No.	Switch	Position
S480	DIGITAL OUT	OFF
S651	LOAD IN DET	ON
S652	LOAD OUT DET	OFF
S653	MOTOR SELECT	CHUCKING
S654	CHUCKING	MOTOR
S700	1	ON
S701	2	OFF
S702	3	OFF
S703	4	OFF
S704	5	OFF
S705	►	OFF
S706	▲	OFF
S708	6	OFF
S709	7	OFF
S710	8	OFF
S711	9	OFF
S712	10	OFF
S713	II	OFF
S714	A-->B	OFF
S716	11	OFF
S717	12	OFF
S718	13	OFF
S719	14	OFF
S720	15	OFF
S721	■	OFF
S722	DISPLAY TIME/NEXT (PGM)	OFF
S724	16	OFF
S725	17	OFF
S726	18	OFF
S727	19	OFF
S728	20	OFF
S729	PROGRAM	OFF
S730	SHUFFLE	OFF
S732	+10	OFF
S733	0	OFF
S734	CHECK	OFF
S735	CLEAR	OFF
S736	CONTINUE	OFF
S737	SINGLE	OFF
S738	REPEAT	OFF
S739	COUNT	OFF
S740	AMS	OFF
S741	AMS	OFF
S742	INDEX	OFF
S743	INDEX	OFF
S744		OFF
S745		OFF
S746		OFF
S747	AUTO PAUSE	OFF
S748	AUTO SPACE	OFF
S901	POWER	OFF

CDP-555ESD/705ESD CDP-555ESD/705ESD

MOUNTING DIAGRAM
—Flexible board—




CDP-555ESD / 655ESD CDP-555ESD / 705ESD


MOUNTING DIAGRAM

• SEMICONDUCTOR LOCATION


Ref. No.	Location	Ref. No.	Location	Ref. No.	Location
D200	I-17	D885	D-17	IC812	J-22
D302	H-21	D890	D-18	IC852	C-17
D303	C-22	IC201	F-17	IC853	D-17
D304	F-22	IC202	I-16	Q200	E-19
D305	F-26	IC203	H-16	Q201	H-18
D307	G-23	IC301	F-19	Q202	H-18
D309	A-10	IC301	G-20	Q203	E-18
D700	G-13	IC302	I-20	Q204	E-18
D701	G-14	IC303	I-21	Q301	G-22
D702	G-14	IC304	I-19	Q302	G-22
D703	G-11	IC305	E-20	Q303	H-22
D704	G-9	IC307	G-22	Q700	H-6
D705	I-8	IC308	G-21	Q701	H-5
D800	I-23	IC309	A-9	Q702	H-5
D801	J-23	IC310	E-22	Q703	H-4
D810	I-24	IC390	C-20	Q704	H-4
D811	I-25	IC401	E-21	Q800	H-25
D812	J-24	IC402	E-24	Q801	H-25
D816	J-25	IC403	E-25	Q802	I-24
D870	B-15	IC410	G-24	Q803	I-25
D871	B-16	IC411	J-4	Q810	K-25
D872	B-16	IC412	C-25	Q811	K-25
D873	B-17	IC413	C-25	Q812	J-24
D874	C-15	IC480	D-25	Q813	J-25
D875	C-15	IC511	I-10	Q861	D-16
D876	B-15	IC512	J-6	Q864	B-17
D877	B-15	IC700	I-22	Q865	C-15
D878	C-15	IC710	D-21	Q866	D-17
D882	B-17	IC801	E-21		
D883	B-18	IC802			
D884	D-16	IC811			

Note:
 • : parts extracted from the conductor side.
 • ■ : part mounted on the conductor side.






SCHEMATIC DIAGRAM





17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33


**Note:**

- All capacitors are in μF unless otherwise noted. pF: μF 50WV or less are not indicated except for electrolytics and tantalums.
- All resistors are in Ω and $1/4\text{W}$ or less unless otherwise specified.
- : fusible resistor.

—Continued on page 14—

Note: The components identified by shading and mark are critical for safety. Replace only with part number specified.

**POWER SWITCH BOARD**



A

B

C

D

E

F

G

H

ARDI

I

J

EXPLODED VIEWS AND PARTS LIST

NOTE:

- The mechanical parts with no reference number in the exploded views are not supplied.

- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.


- The construction parts of an assembled part are indicated with a callout number in the remark column.

- Color Indication of Appearance Parts
Example: (RED) KNOB, BALANCE
(WHITE)



Cabinet's Color Parts' Color

The components identified by shading and mark **A** are critical for safety. Replace only with part number specified.

(1).




No.	Part No.	Description	Remarks	No.	Part No.	Description	Remarks
1	3-703-710-41	STICKER, SONY SYMBOL (12)		10	*A-4675-207-A	CHASSIS ASSY, G	
2	*4-913-181-01	PLATE, BOTTOM, SHIELD		11	4-913-189-11	FELT (B), ACOUSTIC ABSORBENT	
3	7-682-153-09	SCREW +P 3X20		12	*4-919-203-01	SCREW (3.5X12), + BVTP	
4	7-685-647-79	SCREW +BVTP 3X10 TYPE2 SLIT		13	*4-913-155-01	LEVER (B), TRANSPORT LOCK	
5	4-913-178-01	FOOT (B)		14	3-323-470-01	SCREW (B3X6), (+ -)	
6	*4-913-180-01	PLATE, LOCK, TRANSPORT		16	4-919-216-01	PLATE (B), BOTTOM, SHIELD	
7	7-685-646-79	SCREW +BVTP 3X8 TYPE2 SLIT		17	4-919-217-01	CUSHION (A)	
8	4-890-173-00	WASHER		18	4-919-218-01	CUSHION (B)	
9	7-684-023-04	N 3, TYPE 2					




No.	Part No.	Description	Remarks	No.	Part No.	Description	Remarks
51	X-4908-930-1	BASE ASSY (B), PANEL		72	7-685-871-01	SCREW +BVTT 3X6 (S)	
52	4-913-131-01	PLATE, TRANSPARENT		73	*4-913-146-01	RETAINER (B), BASE	
53	4-913-150-01	PANEL, CONTROL BUTTON		74	3-888-002-00	CUSHION, LED	
54	*4-913-136-01	BRACKET (A), PANEL		75	*3-324-837-01	CUSHION	
55	7-685-534-11	SCREW +BTP 2.6X8 TYPE2 N-S		76	3-703-685-31	SCREW (+BV 3X8)	
56	*4-913-128-01	PLATE, SHIELD		77	4-913-192-11	FELT (A), ACOUSTIC ABSORBENT	
57	4-912-950-21	BUTTON, 10 GANG		78	*4-913-188-01	FELT (C), ACOUSTIC ABSORBENT	
58	4-912-950-31	BUTTON, 10 GANG		79	4-913-173-01	PLATE, TOP	
59	4-912-949-01	BUTTON, 4 GANG		80	*4-913-194-01	CUSHION (A), TOP BOARD	
60	4-913-135-01	BUTTON, MODE		81	4-913-149-21	KNOB (PAUSE), T	
61	X-4908-922-1	BUTTON ASSY, PAUSE		82	4-913-149-11	KNOB (PAUSE), T	
62	X-4908-923-1	BUTTON ASSY, PLAY		83	4-913-170-01	RING, FIXED	
63	*4-913-156-01	RETAINER, BUTTON		84	7-682-549-09	SCREW +B 3X10	
65	4-913-142-01	BUTTON, REPEAT		85	*4-919-207-11	CUSHION, BASE RETAINER	
66	*4-913-132-01	RETAINER, BUTTON		86	*4-913-139-01	SPACER (A), LED	
67	*4-913-126-01	FILTER		87	*4-913-141-01	HOLDER, LED	
68	X-4908-932-2	(US).....PANEL ASSY		88	*4-913-140-01	PLATE, GROUND	
	X-4908-934-1	(AEP/UK)...PANEL ASSY		89	*4-913-186-01	CUSHION, RUBBER	
69	7-685-134-19	SCREW +BTP 2.6X8 TYPE2 N-S		90	*3-846-311-00	SPACER (D)	
70	3-831-441-XX	CUSHION, SPEAKER		903	*1-620-818-11	PC BOARD, DISPLAY	
71	*4-913-147-01	RETAINER (A), BASE		904	*1-620-819-11	PC BOARD, REMOCON RAY CATCHER	

No.	Part No.	Description	Remarks	No.	Part No.	Description	Remarks
101	*3-309-144-01	HEAT SINK		126	7-683-412-05	BOLT, HEXAGON SOCKET 2.6X6	
102	*4-886-555-00	HEAT SINK		127	4-884-635-00	BASE, ORNAMENTAL	
103	4-870-272-00	HEAT SINK		128	*4-912-948-01	CUSHION, LOADING PANEL	
104	2-259-121-00	SCREW, TR		129	4-913-172-01	PLATE (RIGHT), SIDE	
105	2-259-121-11	SCREW, TR		130	4-913-171-01	PLATE (LEFT), SIDE	
106	4-919-215-01	BRACKET (H)		131	3-703-685-31	SCREW (+BV 3X8)	
107	*4-908-502-01	HEAT SINK		132	*4-919-201-01	CUSHION (E), CHASSIS	
108	7-685-752-04	SCREW +BVTT 3X8 (S)		133	*4-913-198-01	CUSHION (C), CHASSIS	
109	*4-909-140-01	REINFORCEMENT, MOLD		134	*4-913-138-01	BRACKET, MD	
110	4-908-963-01	NUT, SPECIAL		135	*4-919-208-01	REINFORCEMENT (B), IC	
111	*4-913-168-01	PLATE, SHIELD		136	4-870-539-00	PLATE GROUND	
112	4-911-049-01	SCREW (3X8)		137	3-564-542-11	WASHER, FIBER	
113	3-655-653-21	BAND (TAITON), BINDING		138	*3-661-588-00	SPACER (3X5)	
114	*4-913-197-01	CUSHION (B), CHASSIS		139	4-302-211-00	BUSHING, RUBBER	
115	7-685-871-01	SCREW +BVTT 3X6 (S)		140	7-685-873-01	SCREW +BVTT 3X10 (S)	
116	9-911-839-XX	RETAINER (B), MICROPHONE		141	*4-912-962-01	COVER (1P), TERMINAL	
117	4-909-982-11	SCREW, TAPPING		142	*4-912-963-01	COVER (2P), TERMINAL	
119	4-908-961-01	WASHER		902	*A-4651-124-A	MONTEED PCB, MAIN	
120	*4-917-459-01	LEVER, POWER SWITCH		905	*1-620-820-11	PC BOARD, POWER SWITCH	
121	4-917-460-01	KNOB, POWER		906	*1-621-022-11	PC BOARD, POWER	
122	*4-913-190-01	DUMPER (LEVER)		908	*1-621-025-11	PC BOARD, REMOTE CONTROL VOL	
123	4-913-169-01	KNOB, VOLUME		909	*1-621-026-11	PC BOARD, REMOTE CONTROL MOTOR	
124	3-701-505-00	SET SCREW, DOUBLE POINT 3X3		910	*1-622-225-11	PC BOARD, HEADPHONE	
125	4-913-154-01	PANEL, LOADING		920	*1-622-226-11	PC BOARD, TIMER	

(4).




(6). CDM4A-IE



No.	Part No.	Description	Remarks	No.	Part No.	Description	Remarks
251	*4-908-523-01	BRACKET, MOTOR		277	4-912-538-01	BEARING (RIGHT), GUIDE	
252	4-908-540-01	GUIDE, ASSIST		278	4-912-521-01	SHAFT (RIGHT), GUIDE	
253	*X-4912-508-1	BRACKET ASSY, TABLE		279	*4-912-520-01	BRACKET, ROPE	
254	*X-4912-507-1	CHASSIS ASSY, MECHANICAL		280	4-912-517-01	ROPE	
255	*4-912-568-01	PLATE (A), GROUND		281	4-908-553-01	SPRING, COMPRESSION (ROPE)	
257	*4-912-566-01	BRACKET, L PANEL		282	4-912-512-01	CUSHION (A)	
258	*4-912-544-01	PLATE, FIXED		283	X-4912-511-1	PLATE ASSY, DISK	
259	*4-912-529-01	GUIDE, LOADING		284	*4-908-964-01	SHEET, PS, DT	
260	*4-912-527-01	RETAINER, TABLE		285	4-908-519-01	PULLEY (A)	
261	*4-912-534-01	GUIDE, SUB		286	4-908-525-01	PULLEY (C)	
262	*X-4912-504-1	BRACKET (LEFT) ASSY, TABLE		287	3-671-077-00	BELT, FF	
263	3-558-708-21	WASHER, STOPPER		288	4-908-591-01	BELT, DRIVING	
264	*4-912-531-01	PLATE (LEFT), CAM, DISK		289	4-908-524-01	PULLEY (B)	
265	3-701-439-11	WASHER		291	7-624-106-04	STOP RING 3.0, TYPE -E	
266	4-908-584-03	TABLE, DISK		292	7-621-775-00	SCREW +B 2.6X3	
267	4-908-534-01	LEVER, FUNCTION		293	7-621-759-60	+PSW, 2.6X8	
268	*4-912-532-01	REINFORCEMENT, TABLE		294	3-554-222-00	WASHER (2), CAPSTAN	
269	*4-912-526-01	SHET		295	7-682-546-04	SCREW +BVTT 3X5 (S)	
270	*4-912-522-01	PLATE. SW		296	7-685-132-19	SCREW +BTP 2.6X5 TYPE2 N-S	
271	4-912-516-01	SPRING (DISK CAM), TENSION		297	7-685-646-79	SCREW +BVTP 3X8 TYPE2 SLIT	
272	*X-4912-506-1	PLATE (RIGHT) ASSY, CAM, DISK		298	7-685-791-04	SCREW +BVTT 2.6X5 (S)	
273	4-887-175-00	RUBBER, STOPPER		299	7-685-876-01	SCREW +BVTT 3X16 (S)	
274	*X-4912-505-1	BRACKET (RIGHT) ASSY, TABLE		300	7-682-646-09	SCREW +PS 3X5	
275	*4-912-513-01	STOPPER, TABLE		912	*1-617-230-11	PC BOARD, LOADING MOTOR	
276	*4-912-519-01	RETAINER (RIGHT). SHAFT		M652	A-4608-303-A	MOTOR ASSY, LOADING	

7). BU-1E



No.	Part No.	Description	Remarks	No.	Part No.	Description	Remarks
301	A-4675-068-A	BRACKET ASSY, MOTOR		323	7-685-134-19	SCREW +P 2.6X8 TYPE2 SLIT	
302	2-622-105-01	RETAINER, THRUST		324	7-621-284-00	SCREW +B 2.6X4	
304	A-4675-069-A	ROTOR ASSY		325	7-621-775-20	SCREW +B 2.6X5	
305	3-701-439-21	WASHER		326	7-685-793-04	SCREW +BVTT 2.6X8 (S)	
306	4-908-201-03	SHAFT, SLIDE		327	7-621-734-09	SET-SCT, HEX. 2.6X3	
307	4-908-593-01	INSULATOR		328	*4-908-232-01	LUG, GROUND	
308	X-4908-202-1	PULLEY ASSY, DISK		329	7-685-864-01	SCREW +BVTT 2.6X10 (S)	
309	4-908-213-01	SPRING, COMPRESSION		331	7-685-867-01	SCREW +BVTT 2.6X16 (S)	
310	4-915-217-01	CAP, CENTERING		332	X-4915-033-1	BU-1E	
311	3-558-708-21	WASHER, STOPPER		333	7-624-105-04	STOP RING 2.3, TYPE -E	
312	3-531-576-01	RIVET		334	4-908-245-01	RETAINER (C , SHAFT, SLIDE	
313	4-908-227-01	LEVER, LOCK		335	*4-908-254-01	RETAINER BOARD	
314	4-908-230-01	SPRING		336	*4-908-255-01	SUPPORT, PC BOARD	
315	4-908-220-01	HOLDER, ROD		337	7-682-546-09	SCREW +B 3X6	
316	*A-4675-110-A	MAGNET ASSY, LINEAR		338	*4-919-205-01	CUSHION	
317	4-908-224-01	HOLDER, BEARING		339	7-688-002-01	W 2.6, SMALL	
318	4-908-221-01	BEARING		340	*4-908-269-01	CUSHION, SLIDE	
319	4-908-225-01	RETAINER (A), LEAD		918	*1-620-663-11	PC BOARD, BSL MOTOR	
320	4-908-219-01	RETAINER (B), LEAD		919	A-4646-215-A	MOUNTED PCB, FLEXIBLE	
321	*A-4675-112-A	BASE ASSY		M53	1-422-197-14	COIL (DRIVE)	
322	4-908-208-01	BEARING (NO-FLANGE), BALL		SE51	1-422-198-11	COIL (SENSOR)	

CDP-555ESD/705ESD

ELECTRICAL PARTS LIST

NOTE:

- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- If there are two or more same circuits in a set such as a stereophonic machine, only typical circuit parts may be indicated and capacitors and resistors in other same circuits may be omitted.

CAPACITORS:
MF:μF, PF:μμF.

RESISTORS

- All resistors are in ohms.
- F : nonflammable

COILS

- MMH : mH, UH : μH

SEMICONDUCTORS

In each case, U : μ, for example:
UA...: μA..., UPA...: μPA..., UPC...: μPC,
UPD...: μPD...

The components identified by shading and mark are critical for safety. Replace only with part number specified.

ELECTRICAL PARTS

Ref.No.	Part No.	Description
901	A-1-555-765-11	(AEP)...CORD, POWER
	A-1-556-035-11	(UK)...CORD, POWER
	A-1-557-577-11	(US)...CORD, POWER
902	*A-4651-124-A	MOUNTED PCB, MAIN
903	*1-620-818-11	PC BOARD, DISPLAY
904	*1-620-819-11	PC BOARD, REMOCON RAY CATCHER
905	*1-620-820-11	PC BOARD, POWER SWITCH
906	*1-621-022-11	PC BOARD, POWER
907	*1-622-227-11	PC BOARD, DIGITAL OUT
908	*1-621-025-11	PC BOARD, REMOTE CONTROL VOL
909	*1-621-026-11	PC BOARD, REMOTE CONTROL MOTOR
910	*1-622-225-11	PC BOARD, HEADPHONE
911	*1-617-229-11	PC BOARD, LOAD OUT SW
912	*1-617-230-11	PC BOARD, LOADING MOTOR
913	*1-617-231-11	PC BOARD, CHACKING MOTOR
914	*1-617-232-11	PC BOARD, L.C. SWITCH
915	*1-617-233-11	PC BOARD, IN SWITCH
918	*1-620-663-11	PC BOARD, BSL MOTOR
919	A-4646-215-A	MOUNTED PCB, FLEXIBLE
920	*1-622-226-11	PC BOARD, TIMED
C201	1-136-159-00	FILM
C202	1-126-043-11	ELECT
C203	1-162-294-31	CERAMIC
C204	1-126-049-11	ELECT
C205	1-130-479-00	MYLAR
C206	1-126-048-11	ELECT
C207	1-126-044-11	ELECT
C208	1-136-168-00	FILM
C209	1-130-479-00	MYLAR
C210	1-162-199-31	CERAMIC
C211	1-136-165-00	FILM
C212	1-131-368-00	TANTALUM
C214	1-136-159-00	FILM
C215	1-136-165-00	FILM
C216	1-161-379-00	CERAMIC
C217	1-161-379-00	CERAMIC
C218	1-161-379-00	CERAMIC
C219	1-161-379-00	CERAMIC
C220	1-161-379-00	CERAMIC
C221	1-136-164-00	FILM
C222	1-136-159-00	FILM
C223	1-161-379-00	CERAMIC
C224	1-130-479-00	MYLAR
C225	1-123-335-00	ELECT

ELECTRICAL PARTS

Ref.No.	Part No.	Description	Value	tolerance	Voltage	Power	Capacitance	Inductance
C226	1-123-335-00	ELECT			330MF	20%	25V	
C227	1-161-375-00	CERAMIC			0.0022MF	30%	16V	
C251	1-123-332-00	ELECT			47MF	20%	25V	
C252	1-124-994-11	ELECT			100MF	20%	10V	
C253	1-162-179-11	CERAMIC			0.1MF	50%	50V	
C256	1-162-179-11	CERAMIC			0.1MF	50%	50V	
C257	1-123-335-00	ELECT			330MF	20%	25V	
C258	1-123-333-00	ELECT			100MF	20%	25V	
C259	1-123-335-00	ELECT			330MF	20%	25V	
C260	1-123-335-00	ELECT			330MF	20%	25V	
C301	1-136-153-00	FILM			0.01MF	5%	50V	
C302	1-126-043-11	ELECT			0.47MF	20%	50V	
C315	1-162-294-31	CERAMIC			0.001MF	10%	50V	
C323	1-162-179-11	CERAMIC			0.1MF	50%	50V	
C324	1-123-335-00	ELECT			330MF	20%	25V	
C325	1-123-333-00	ELECT			100MF	20%	25V	
C326	1-162-179-11	CERAMIC			0.1MF	50%	50V	
C327	1-123-335-00	ELECT			330MF	20%	25V	
C328	1-162-179-11	CERAMIC			0.1MF	50%	50V	
C351	1-107-322-00	MICA			22PF	5%	500V	
C352	1-107-322-00	MICA			22PF	5%	500V	
C362	1-123-335-00	ELECT			330MF	20%	25V	
C363	1-124-130-00	ELECT			100MF	20%	63V	
C375	1-123-335-00	ELECT			330MF	20%	25V	
C376	1-162-179-11	CERAMIC			0.1MF	50%	50V	
C377	1-161-974-00	CERAMIC			0.1MF	20%	16V	
C390	1-124-994-41	ELECT			100MF	20%	10V	
C391	1-124-994-41	ELECT			100MF	20%	10V	
C392	1-161-379-00	CERAMIC			0.01MF	20%	16V	
C393	1-161-379-00	CERAMIC			0.01MF	20%	16V	
C401	1-104-294-11	POLYSTYRENE			470PF	5%	50V	
C406	1-162-294-31	CERAMIC			0.001MF	10%	50V	
C407	1-162-294-31	CERAMIC			0.001MF	10%	50V	
C411	1-136-165-00	FILM			0.1MF	5%	50V	
C412	1-136-165-00	FILM			0.1MF	5%	50V	
C413	1-136-165-00	FILM			0.1MF	5%	50V	
C414	1-136-165-00	FILM			0.1MF	5%	50V	
C415	1-136-165-00	FILM			0.1MF	5%	50V	
C416	1-136-165-00	FILM			0.1MF	5%	50V	
C417	1-136-165-00	FILM			0.1MF	5%	50V	
C418	1-136-256-11	FILM			0.0033MF	3%	100V	
C419	1-130-892-00	FILM			0.015MF	3%	100V	
C420	1-130-848-00	FILM			0.0082MF	3%	100V	
C421	1-107-317-00	MICA			33PF	5%	500V	
C422	1-130-967-00	FILM			0.0027MF	3%	100V	

ELECTRICAL PARTS

<u>Ref.No.</u>	<u>Part No.</u>	<u>Description</u>
C423	1-130-967-00	FILM
C424	1-136-230-00	FILM
C425	1-107-309-00	MICA
C426	1-126-164-51	ELECT
C428	1-124-484-11	ELECT
C430	1-124-484-11	ELECT
C431	1-107-322-00	MICA
C432	1-136-250-11	FILM
C433	1-107-277-00	MICA
C439	1-162-290-31	CERAMIC
C480	1-124-688-31	ELECT
C481	1-162-179-11	CERAMIC
C482	1-124-724-31	ELECT
C483	1-130-955-00	FILM
C484	1-161-494-00	CERAMIC
C485	1-161-974-00	CERAMIC
C486	1-162-282-31	CERAMIC
C501	1-123-335-00	ELECT
C502	1-123-335-00	ELECT
C503	1-124-929-11	ELECT
C504	1-124-929-11	ELECT
C511	1-136-165-00	FILM
C512	1-136-165-00	FILM
C513	1-136-165-00	FILM
C514	1-136-165-00	FILM
C515	1-136-165-00	FILM
C516	1-136-165-00	FILM
C517	1-136-165-00	FILM
C518	1-136-256-11	FILM
C519	1-130-892-00	FILM
C520	1-130-848-00	FILM
C521	1-107-317-00	MICA
C522	1-130-967-00	FILM
C523	1-130-967-00	FILM
C524	1-136-230-00	FILM
C525	1-107-309-00	MICA
C526	1-126-164-51	ELECT
C528	1-124-484-11	ELECT
C530	1-124-484-11	ELECT
C531	1-107-322-00	MICA
C532	1-136-250-11	FILM
C533	1-107-277-00	MICA
C534	1-162-290-31	CERAMIC
C701	1-162-179-11	CERAMIC
C702	1-162-179-11	CERAMIC
C703	1-162-179-11	CERAMIC
C710	1-124-225-00	ELECT
C800	1-136-165-00	FILM
C801	1-130-673-00	FILM
C802	1-126-129-11	ELECT
C803	1-126-129-11	ELECT
C804	1-124-130-00	ELECT
C806	1-107-322-00	MICA
C807	1-123-378-00	ELECT
C808	1-123-334-00	ELECT
C814	1-124-130-00	ELECT
C816	1-107-322-00	MICA

ELECTRICAL PARTS

Ref.No.	Part No.	Description				
C817	1-123-378-00	ELECT	1000MF	20%	63V	
C818	1-123-334-00	ELECT	220MF	20%	25V	
C819	1-124-738-41	ELECT	220MF	20%	63V	
C820-1	1-124-738-41	ELECT	220MF	20%	63V	
C820-2	1-131-450-00	TANTALUM	1MF	20%	50V	
C821	1-131-450-00	TANTALUM	1MF	20%	50V	
C822	1-123-369-00	ELECT	4.7MF	20%	63V	
C823	1-123-369-00	ELECT	4.7MF	20%	63V	
C850	1-126-122-11	ELECT	12000MF	20%	16V	
C851	1-124-636-00	ELECT	3300MF	20%	25V	
C852	1-136-173-00	FILM	0.47MF	5%	50V	
C853	1-126-048-11	ELECT	10MF	20%	50V	
C854	1-126-038-11	ELECT	330MF	20%	35V	
C855	1-126-038-11	ELECT	330MF	20%	35V	
C856	1-126-047-11	ELECT	4.7MF	20%	50V	
C857	1-124-997-11	ELECT	470MF	20%	10V	
C858	1-125-367-11	CAP,DOUBLE LAYERS 0.1F				5.5V
C859	1-136-157-00	FILM	0.022MF	5%	50V	
C860	1-130-673-00	FILM	3.3MF	10%	125V	
C861	1-136-165-00	FILM	0.1MF	5%	50V	
C864	1-126-053-11	ELECT	220MF	20%	50V	
C865	1-126-053-11	ELECT	220MF	20%	50V	
C866	1-126-038-11	ELECT	330MF	20%	35V	
C900	1-126-017-11	ELECT	6800MF	20%	16V	
C901-1	1-161-744-00	CERAMIC	0.01MF	20%	400V	
C901-2	1-124-636-00	ELECT	3300MF	20%	25V	
C902	△1-161-744-00	CERAMIC	0.01MF	20%	400V	
C903	△1-161-744-00	(US) CERAMIC	0.01MF	20%	400V	
C904	△1-161-742-00	(555ESD). CERAMIC	0.022MF	20%	400V	
C905	△1-161-742-00	(555ESD). CERAMIC	0.022MF	20%	400V	
C906	△1-161-742-00	(555ESD). CERAMIC	0.022MF	20%	400V	
C907	△1-161-742-00	(555ESD). CERAMIC	0.022MF	20%	400V	
C908	1-161-742-00	(555ESD)...CERAMIC	0.022MF	20%	400V	
C909	1-161-742-00	(555ESD)...CERAMIC	0.022MF	20%	400V	
CNP200*1	564-709-11	PIN, CONNECTOR (SMALL TYPE)	7P			
CNP201*1	564-710-11	PIN, CONNECTOR (SMALL TYPE)	8P			
CNP202*1	564-506-11	PLUG, CONNECTOR 3P				
CNP203*1	564-706-31	PIN, CONNECTOR (SMALL TYPE)	4P			
CNP300*1	564-707-11	PIN, CONNECTOR (SMALL TYPE)	5P			
CNP301*1	564-509-11	PLUG, CONNECTOR 6P				
CNP302*1	564-503-11	PIN, CONNECTOR 9P				
CNP303*1	564-508-11	PLUG, CONNECTOR 5P				
CNP304*1	564-337-00	PIN, CONNECTOR 3P				
CNP305*1	564-337-00	PIN, CONNECTOR 3P				
CNP306*1	564-338-00	PIN, CONNECTOR 4P				
CNP307*1	564-336-00	PIN, CONNECTOR 2P				
CNP390*1	564-497-11	PIN, CONNECTOR 4P				
CNP391*1	564-507-41	PLUG, CONNECTOR 4P				
CNP392*1	564-507-21	PLUG, CONNECTOR 4P				
CNP400*1	564-507-41	PLUG, CONNECTOR 4P				
CNP401*1	564-507-21	PLUG, CONNECTOR 4P				
CNP402*1	564-507-11	PLUG, CONNECTOR 4P				
CNP480*1	564-704-11	PIN, CONNECTOR (SMALL TYPE)	2P			
CNP481*1	564-505-11	PLUG, CONNECTOR 2P				
CNP482*1	564-705-11	PIN, CONNECTOR (SMALL TYPE)	3P			

The components identified by shading and mark  are critical for safety. Replace only with part number specified.

CDP-555ESD/705ESD

ELECTRICAL PARTS

Ref.No.	Part No.	Description
CNP500*	1-564-507-11	PLUG, CONNECTOR 4P
CNP705*	1-564-496-11	PIN, CONNECTOR 3P
CNP800*	1-535-116-00	TERMINAL
CNP801*	1-535-116-00	TERMINAL
CNP802*	1-535-116-00	TERMINAL
CNP802*	1-535-116-00	TERMINAL
CNP850*	1-564-341-11	PIN, CONNECTOR 7P
CP700	1-232-967-11	COMPOSITION CIRCUIT BLOCK
D200	8-719-940-76	DIODE 1SS132
D302	8-719-940-76	DIODE 1SS132
D303	8-719-940-76	DIODE 1SS132
D304	8-719-940-76	DIODE 1SS132
D305	8-719-940-76	DIODE 1SS132
D307	8-719-940-76	DIODE 1SS132
D390	8-719-200-23	DIODE 11E2
D700	8-719-939-87	DIODE VR3638S
D701	8-719-939-85	DIODE AY3638S
D702	8-719-939-84	DIODE PG3422SY-1
D703	8-719-907-75	DIODE AA5534S
D704	8-719-921-05	DIODE EBG5534S
D705	8-719-940-76	DIODE 1SS132
D800	8-719-200-68	DIODE C10P20FU
D801	8-719-200-69	DIODE C10P20FUR
D810	8-719-224-11	DIODE 10YD2.4A
D811	8-719-902-87	DIODE EQB01-08Q
D812	8-719-224-11	DIODE 10YD2.4A
D816	8-719-902-87	DIODE EQB01-08Q
D870	8-719-200-23	DIODE 11E2
D871	8-719-200-23	DIODE 11E2
D872	8-719-200-23	DIODE 11E2
D873	8-719-200-23	DIODE 11E2
D874	8-719-940-76	DIODE 1SS132
D875	8-719-940-76	DIODE 1SS132
D876	8-719-200-31	DIODE 21DQ05
D877	8-719-200-31	DIODE 21DQ05
D878	8-719-200-31	DIODE 21DQ05
D879	8-719-200-31	DIODE 21DQ05
D882	8-719-934-22	DIODE HZS30-2L
D883	8-719-933-50	DIODE HZS7C2L
D884	8-719-940-76	DIODE 1SS132
D885	8-719-940-76	DIODE 1SS132
D890	8-719-210-12	DIODE 10DF2-TA2
IC201	8-752-030-94	IC CXA1082Q
IC202	8-759-202-01	IC TA7256P
IC203	8-759-202-01	IC TA7256P
IC301	8-752-322-04	IC CXD1125Q
IC302	8-759-910-36	IC MSM5128-20GS
IC303	8-759-940-64	IC MSM6404A-181RS
IC304	8-759-804-47	IC LC6523H-3270
IC305	8-759-202-12	IC TC74HC02P
IC307	8-759-939-35	IC CXD1088Q
IC308	8-719-939-51	MCA11G2
IC309	8-719-939-51	MCA11G2
IC310	8-759-202-14	IC TC74HC08P
IC390	8-759-600-24	IC M54543L
IC401	8-759-939-94	IC TDA1541-N5
IC402	8-759-000-99	IC MC74HC74N
IC403	8-759-202-74	IC TC74HC04P

ELECTRICAL PARTS

Ref.No.	Part No.	Description
IC410	8-759-603-97	IC M5240PS
IC411	8-759-701-21	IC NJM5532D-D
IC412	8-759-905-42	IC NE5534P
IC413	8-759-701-21	IC NJM5532D-D
IC480	8-759-202-13	IC TC74HC04P
IC511	8-759-701-21	IC NJM5532D-D
IC512	8-759-905-42	IC NE5534P
IC700	8-752-801-26	IC CXP5016M-178S
IC710	8-749-900-36	IC BX-1393
IC800	8-759-170-12	IC UPC78M12H
IC801	8-759-700-51	IC NJM7805A
IC802	8-759-700-51	IC NJM7805A
IC811	8-759-700-28	IC NJM7905A
IC812	8-759-700-24	IC NJM79M12A
IC852	8-759-700-51	IC NJM7805A
IC853	8-759-604-02	IC M5278L56
IC862	8-759-700-28	IC NJM7905A
J400	1-563-966-11	JACK, PIN 4P
J480	1-507-557-71	JACK, PIN 1P
J501	1-507-863-21	JACK, LARGE TYPE (HEADPHONES)
L350	1-408-684-00	(US)...MICRO INDUCTOR 1.2MMH
L901	△1-421-340-00	(AEP/UK)...LINE FILTER
L901	△1-421-395-00	(US)...COIL LINE FILTER
LP901	*1-535-476-11	TERMINAL
LP902	*1-535-476-11	TERMINAL
LP903	*1-535-139-00	BASE POST 22MM (10MM PITCH) 2P
LP904	1-535-139-00	(AEP/UK)...BASE POST 22MM(10MM PITCH) 2P
M53	1-422-197-14	COIL (DRIVE)
M651	X-4902-019-1	CHUCKING MOTOR ASSY
M652	A-4608-303-A	MOTOR ASSY, LOADING
ND701	1-519-412-11	INDICATOR TUBE, FLUORESCENT
PS200	1-532-675-00	(AEP/UK)...LINK, IC
PS201	1-532-675-00	(AEP/UK)...LINK, IC
PS801	1-532-679-00	(AEP/UK)...LINK, IC
PS802	1-532-679-00	(AEP/UK)...LINK, IC
PS803	1-532-679-00	(AEP/UK)...LINK, IC
PS851	△1-532-675-00	(AEP/UK)...LINK, IC
Q200	8-729-900-61	TRANSISTOR DTA114ES
Q201	8-729-900-80	TRANSISTOR DTC114ES
Q202	8-729-900-80	TRANSISTOR DTC144ES
Q203	8-729-245-82	TRANSISTOR 2SC2458-Y
Q204	8-729-900-61	TRANSISTOR DTA114ES
Q301	8-729-245-82	TRANSISTOR 2SC2458-Y
Q302	8-729-900-80	TRANSISTOR DTA114ES
Q303	8-729-900-80	TRANSISTOR DTC114ES
Q700	8-729-900-80	TRANSISTOR DTC114ES
Q701	8-729-900-80	TRANSISTOR DTC114ES
Q702	8-729-900-80	TRANSISTOR DTC114ES
Q703	8-729-900-80	TRANSISTOR DTC114ES
Q704	8-729-900-80	TRANSISTOR DTC114ES
Q800	8-729-113-82	TRANSISTOR 2SA1138-E
Q801	8-729-167-62	TRANSISTOR 2SC2676-E
Q802	8-729-127-53	TRANSISTOR 2SC2275-P
Q803	8-729-167-62	TRANSISTOR 2SC2676-E
Q810	8-729-167-62	TRANSISTOR 2SC2676-E

The components identified by shading and mark △ are critical for safety. Replace only with part number specified.

ELECTRICAL PARTS

Ref.No.	Part No.	Description			
Q811	8-729-113-82	TRANSISTOR	2SA1138-E		
Q812	8-729-118-53	TRANSISTOR	2SA985-P		
Q813	8-729-113-82	TRANSISTOR	2SA1138-E		
Q861	8-729-245-82	TRANSISTOR	2SC2458-Y		
Q864	8-729-103-43	TRANSISTOR	2SB734-2		
Q865	8-729-245-82	TRANSISTOR	2SC2458-Y		
Q866	8-729-204-83	TRANSISTOR	2SA1048		
R200	1-249-441-11	CARBON	100K 5%	1/6W	
R201	1-215-493-00	CARBON	1M 5%	1/6W	
R202	1-215-452-00	CARBON	20K 5%	1/6W	
R203	1-249-441-11	CARBON	100K 5%	1/6W	
R204	1-215-435-00	METAL	3.9K 1%	1/6W	
R205	1-215-471-00	CARBON	120K 5%	1/6W	
R206	1-249-429-11	CARBON	10K 5%	1/6W	
R207	1-249-433-11	CARBON	22K 5%	1/6W	
R208	1-249-429-11	CARBON	10K 5%	1/6W	
R210	1-249-425-11	CARBON	4.7K 5%	1/6W	
R211	1-247-880-00	CARBON	110K 5%	1/6W	
R212	1-215-491-00	CARBON	820K 5%	1/6W	
R213	1-249-441-11	CARBON	100K 5%	1/6W	
R214	1-215-466-00	CARBON	75K 5%	1/6W	
R215	1-215-471-00	CARBON	120K 5%	1/6W	
R216	1-215-471-00	CARBON	120K 5%	1/6W	
R217	1-247-885-00	CARBON	180K 5%	1/6W	
R218	1-249-405-11	CARBON	100 5%	1/6W	
R219	1-247-885-00	CARBON	180K 5%	1/6W	
R220	1-249-405-11	CARBON	100 5%	1/6W	
R221	1-249-405-11	CARBON	100 5%	1/6W	
R222	1-247-864-00	CARBON	24K 5%	1/6W	
R223	1-249-439-11	CARBON	68K 5%	1/6W	
R224	1-249-432-11	CARBON	18K 5%	1/6W	
R225	1-249-405-11	CARBON	100 5%	1/6W	
R226	1-215-486-00	CARBON	510K 5%	1/6W	
R227	1-249-429-11	CARBON	10K 5%	1/6W	
R228	1-249-429-11	CARBON	10K 5%	1/6W	
R229	1-249-429-11	CARBON	10K 5%	1/6W	
R230	1-249-441-11	CARBON	100K 5%	1/6W	
R231	1-249-417-11	CARBON	1K 5%	1/6W	
R244	1-249-417-11	CARBON	1K 5%	1/6W	
R301	1-249-429-11	CARBON	10K 5%	1/6W	
R302	1-249-441-11	CARBON	100K 5%	1/6W	
R303	1-249-437-11	CARBON	47K 5%	1/6W	
R304	1-215-481-00	CARBON	330K 5%	1/6W	
R305	1-215-493-00	CARBON	1M 5%	1/6W	
R307	1-215-469-00	METAL	100K 1%	1/6W	
R308	1-215-469-00	METAL	100K 1%	1/6W	
R310	1-249-417-11	CARBON	1K 5%	1/6W	
R311	1-249-413-11	CARBON	470 5%	1/6W	
R312	1-249-405-11	CARBON	100 5%	1/6W	
R350	1-249-417-11	CARBON	1K 5%	1/6W	
R351	1-249-413-11	CARBON	470 5%	1/6W	
R352	1-249-745-11	CARBON	1M 1/2W		
R356	1-249-417-11	CARBON	1K 5%	1/6W	
R360	1-249-417-11	CARBON	1K 5%	1/6W	
R361	1-249-425-11	CARBON	4.7K 5%	1/6W	
R362	1-249-417-11	CARBON	1K 5%	1/6W	
R363	1-249-405-11	CARBON	100 5%	1/6W	
R364	1-249-413-11	CARBON	470 5%	1/6W	

ELECTRICAL PARTS

Ref.No.	Part No.	Description			
R365	1-249-417-11	CARBON	1K 5%	1/6W	
R366	1-249-413-11	CARBON	470 5%	1/6W	
R402	1-249-433-11	CARBON	22K 5%	1/6W	
R403	1-249-425-11	CARBON	4.7K 5%	1/6W	
R411	1-259-022-11	CARBON	1.5K 1%	1/2W	
R412	1-247-713-11	CARBON	1K 1%	1/4W	
R413	1-246-545-00	CARBON	1M 1%	1/4W	
R414	1-259-040-11	CARBON	1.8K 1%	1/2W	
R415	1-249-929-11	CARBON	1.8K 1%	1/4W	
R416	1-249-929-11	CARBON	1.8K 1%	1/4W	
R417	1-249-929-11	CARBON	1.8K 1%	1/4W	
R418	1-247-739-11	CARBON	100 2%	1/2W	
R419	1-249-983-91	CARBON	330K 1%	1/4W	
R420	1-259-025-11	CARBON	470 1%	1/2W	
R421	1-247-700-11	CARBON	100 1%	1/4W	
R422	1-249-465-11	CARBON	47K 1%	1/4W	
R423	1-249-465-11	CARBON	47K 1%	1/4W	
R424	1-247-721-11	CARBON	4.7K 1%	1/4W	
R425	1-249-951-11	CARBON	15K 1%	1/4W	
R426	1-247-700-11	CARBON	100 1%	1/4W	
R427	1-249-983-11	CARBON	330K 1%	1/4W	
R428	1-249-915-11	CARBON	470 1%	1/4W	
R429	1-249-909-11	CARBON	270 1%	1/4W	
R430	1-247-700-11	CARBON	100 1%	1/4W	
R480	1-249-896-11	CARBON	75 1%	1/4W	
R481	1-249-405-11	CARBON	100 5%	1/6W	
R511	1-259-022-11	CARBON	1.5K 1%	1/2W	
R512	1-247-713-11	CARBON	1K 1%	1/4W	
R513	1-246-545-00	CARBON	1M 1%	1/4W	
R514	1-259-040-11	CARBON	1.8K 1%	1/2W	
R515	1-249-929-11	CARBON	1.8K 1%	1/4W	
R516	1-249-929-11	CARBON	1.8K 1%	1/4W	
R517	1-249-929-11	CARBON	1.8K 1%	1/4W	
R518	1-247-739-11	CARBON	100 2%	1/2W	
R519	1-249-983-11	CARBON	330K 1%	1/4W	
R520	1-259-025-91	CARBON	470 1%	1/2W	
R521	1-247-700-11	CARBON	100 1%	1/4W	
R522	1-249-465-11	CARBON	47K 1%	1/4W	
R523	1-249-465-11	CARBON	47K 1%	1/4W	
R524	1-247-721-11	CARBON	4.7K 1%	1/4W	
R525	1-249-951-11	CARBON	15K 1%	1/4W	
R526	1-247-700-11	CARBON	100 1%	1/4W	
R527	1-249-983-11	CARBON	330K 1%	1/4W	
R528	1-249-915-11	CARBON	470 1%	1/4W	
R529	1-249-909-11	CARBON	270 1%	1/4W	
R530	1-247-700-11	CARBON	100 1%	1/4W	
R703	1-249-433-11	CARBON	22K 5%	1/6W	
R704	1-249-433-11	CARBON	22K 5%	1/6W	
R705	1-247-818-00	CARBON	300 5%	1/6W	
R706	1-249-406-11	CARBON	120 5%	1/6W	
R707	1-249-405-11	CARBON	100 5%	1/6W	
R708	1-249-409-11	CARBON	220 5%	1/6W	
R709	1-249-407-11	CARBON	150 5%	1/6W	
R710	1-249-441-11	CARBON	100K 5%	1/6W	
R711	1-249-441-11	CARBON	100K 5%	1/6W	
R800	Δ 1-217-434-00	FUSIBLE	10 5%	1/2W	E
R801	1-249-789-11	CARBON	300 1%	1/2W	

The components identified by shading and mark **Δ** are critical for safety. Replace only with part number specified.

ELECTRICAL PARTS

Ref.No.	Part No.	Description	560	1%	1/2W
R802	1-249-796-11	CARBON	3.3K	1%	1/2W
R803	1-249-814-11	CARBON	680	1%	1/2W
R804	1-259-038-11	CARBON	820	1%	1/2W
R805	1-259-039-11	CARBON	56K	1%	1/2W
R806	1-249-844-11	CARBON	300	1%	1/2W
R811	1-249-789-11	CARBON	560	1%	1/2W
R812	1-249-796-11	CARBON	3.3K	1%	1/2W
R813	1-249-814-11	CARBON	680	1%	1/2W
R814	1-259-038-11	CARBON	820	1%	1/2W
R815	1-259-039-11	CARBON	56K	1%	1/2W
R816	1-249-844-11	CARBON	300	1%	1/2W
R820	▲1-212-960-00 (AEP/UK) FUSIBLE	12V 5A 1/2W			
R820	1-249-756-11 (US).....CARBON	12	1%	1/2W	
R830	▲1-212-960-00 (AEP/UK) FUSIBLE	12V 5A 1/2W			
R830	1-249-756-11 (US).....CARBON	12	1%	1/2W	
R840	1-247-700-11	CARBON	100	1%	1/4W
R841	1-247-700-11	CARBON	100	1%	1/4W
R842	1-247-700-11	CARBON	100	1%	1/4W
R843	1-247-700-11	CARBON	100	1%	1/4W
R852	▲1-212-954-11 FUSIBLE	12V 8A 1/2W			
R853	1-249-433-11	CARBON	22K	5%	1/6W
R854	1-249-435-11	CARBON	33K	5%	1/6W
R855	1-215-471-00	CARBON	120K	5%	1/6W
R856	1-249-432-11	CARBON	18K	5%	1/6W
R857	1-249-430-11	CARBON	12K	5%	1/6W
R858	1-249-429-11	CARBON	10K	5%	1/6W
R859	1-249-441-11	CARBON	100K	5%	1/6W
R860	1-249-441-11	CARBON	100K	5%	1/6W
R861	1-249-405-11	CARBON	100	5%	1/6W
R862	1-249-435-11	CARBON	33K	5%	1/6W
R863	1-249-429-11	CARBON	10K	5%	1/6W
RV201	1-228-990-00	RES, ADJ, METAL GLAZE 1K			
RV202	1-228-995-00	RES, ADJ, METAL GLAZE 22K			
RV203	1-228-995-00	RES, ADJ, METAL GLAZE 22K			
RV400	1-237-081-11	RES, VAR CARBON 10K/10K (LINE OUT PHONE LEVEL)			
RV500	1-237-081-11	RES, VAR, CARBON 10K/10K (LINE OUT PHONE LEVEL)			
RY1	1-515-642-11	RELAY			
RY2	1-515-642-11	RELAY			
RY3	1-515-642-11	RELAY			
RY5	1-515-642-11	RELAY			
S310	1-570-908-11	SWITCH, ROTARY (TIMER)			
S480	1-516-778-XX	SWITCH, SLIDE (DIGITAL OUT)			
S700	1-554-303-21	SWITCH, KEY BOARD (1)			
S701	1-554-303-21	SWITCH, KEY BOARD (2)			
S702	1-554-303-21	SWITCH, KEY BOARD (3)			
S703	1-554-303-21	SWITCH, KEY BOARD (4)			
S704	1-554-303-21	SWITCH, KEY BOARD (5)			
S705	1-554-303-21	SWITCH, KEY BOARD (►)			
S706	1-554-303-21	SWITCH, KEY BOARD (▲)			
S708	1-554-303-21	SWITCH, KEY BOARD (6)			
S709	1-554-303-21	SWITCH, KEY BOARD (7)			
S710	1-554-303-21	SWITCH, KEY BOARD (8)			
S711	1-554-303-21	SWITCH, KEY BOARD (9)			
S712	1-554-303-21	SWITCH, KEY BOARD (10)			
S713	1-554-303-21	SWITCH, KEY BOARD (■)			
S714	1-554-303-21	SWITCH, KEY BOARD (A↔B)			

The components identified by shading and mark ▲ are critical for safety. Replace only with part number specified.

ELECTRICAL PARTS

Ref.No.	Part No.	Description
S716	1-554-303-21	SWITCH, KEY BOARD (11)
S717	1-554-303-21	SWITCH, KEY BOARD (12)
S718	1-554-303-21	SWITCH, KEY BOARD (13)
S719	1-554-303-21	SWITCH, KEY BOARD (14)
S720	1-554-303-21	SWITCH, KEY BOARD (15)
S721	1-554-303-21	SWITCH, KEY BOARD (■)
S722	1-554-303-21	SWITCH, KEY BOARD (DISPLAY)
S724	1-554-303-21	SWITCH, KEY BOARD (16)
S725	1-554-303-21	SWITCH, KEY BOARD (17)
S726	1-554-303-21	SWITCH, KEY BOARD (18)
S727	1-554-303-21	SWITCH, KEY BOARD (19)
S728	1-554-303-21	SWITCH, KEY BOARD (20)
S729	1-554-303-21	SWITCH, KEY BOARD (PROGRAM)
S730	1-554-303-21	SWITCH, KEY BOARD (SHUFFLE)
S732	1-554-303-21	SWITCH, KEY BOARD (+10)
S733	1-554-303-21	SWITCH, KEY BOARD (0)
S734	1-554-303-21	SWITCH, KEY BOARD (CHECK)
S735	1-554-303-21	SWITCH, KEY BOARD (CLEAR)
S736	1-554-303-21	SWITCH, KEY BOARD (CONTINUE)
S737	1-554-303-21	SWITCH, KEY BOARD (SINGLE)
S738	1-554-303-21	SWITCH, KEY BOARD (REPEAT)
S739	1-554-303-21	SWITCH, KEY BOARD (COUNT)
S740	1-554-303-21	SWITCH, KEY BOARD (◀)
S741	1-554-303-21	SWITCH, KEY BOARD (▶)
S742	1-554-303-21	SWITCH, KEY BOARD (←)
S743	1-554-303-21	SWITCH, KEY BOARD (→)
S744	1-554-303-21	SWITCH, KEY BOARD (◀)
S745	1-554-303-21	SWITCH, KEY BOARD (►)
S746	1-554-303-21	SWITCH, KEY BOARD (AUTO PAUSE)
S747	1-554-303-21	SWITCH, KEY BOARD (AUTO SPACE)
S901	1-553-318-00	SWITCH, PUSH (AC POWER)(1 KEY)
SE51	1-422-198-11	COIL (SENSOR)
T480	1-459-587-11	COIL (WITH CORE)
T901	▲1-448-882-11 (US) TRANSFORMER POWER	
T901	▲1-448-884-11 (AEP/UK) TRANSFORMER POWER	
T902	▲1-448-883-11 (US) TRANSFORMER POWER	
T902	▲1-448-885-11 (AEP/UK) TRANSFORMER POWER	
X300	1-567-539-11	VIBRATOR, CRYSTAL (16.934MHz)
X301	1-567-686-11	OSCILLATOR, CERAMIC (4MHz)
X700	1-567-686-11	OSCILLATOR, CERAMIC (4MHz)
ACCESSORY & PACKING MATERIAL		
Part No.	Description	
1-463-816-11	REMOTE COMMANDER (RM-D502A)	
1-558-271-11	CORD, CONNECTION	
3-701-630-01	BAG, POLYETHYLENE	
3-703-390-01	(US)....INSTRUCTION	
3-703-710-41	STICKER, SONY SYMBOL (12)	
3-765-688-11	(AEP/UK)...MANUAL, INSTRUCTION	
3-765-688-21	(US).....MANUAL, INSTRUCTION	
3-765-688-41	(AEP).....MANUAL, INSTRUCTION	
*3-795-629-15	(AEP)...INSTRUCTION	
4-913-941-01	HOLDER, COMMANDER	
4-917-494-01	BATTERY CASE	
4-919-212-01	(US).....INDIVIDUAL CARTON	
4-919-212-11	(AEP/UK)..INDIVIDUAL CARTON	
4-919-213-01	CUSHION	

Sony Corporation
Audio Group