


Service Manual

Direct Drive Automatic Turntable System

SL-6

[M], [MC]



* The cartridge shown here is an option.

Areas

- * [M] is available in U.S.A.
- * [MC] is available in Canada.

Specifications

Specifications are subject to change without notice for further improvement.
Weight and dimensions shown are approximate.

■ General

Power supply:	120 V AC, 60 Hz
Power consumption:	12 W
Dimensions: (W×H×D)	31.5 × 8.8 × 31.5 cm (12-1/2" × 3-1/2" × 12-1/2") 31.5 × 39 × 31.5 cm (12-1/2" × 15-23/64" × 12-1/2") (Maximum height when top (dust cover) is open.)
Weight:	4.7 kg (10.4 lb.)

■ Turntable section

Type:	Direct drive Fully automatic turntable
Features:	Auto start/Auto lead-in Auto return Auto stop Programmable band selection Repeat play Auto speed select Manual speed selection possible Auto size select Record presence detection
Drive method:	Direct drive
Motor:	Brushless DC motor

Drive control method:	F-G servo control
Turntable platter:	Aluminum die-cast Diameter 30 cm (12")
Turntable speeds:	33-1/3 rpm and 45 rpm Auto speed select (Manual selection possible)
Wow and flutter:	0.012% WRMS* 0.025% WRMS (JIS C5521) ±0.035% peak (IEC 98A Weighted)
* Measured by obtaining signal from built-in frequency generator of motor assembly.	
Rumble:	-56 dB (IEC 98A Unweighted) -78 dB (IEC 98A Weighted)

■ Tonearm section

Type:	Dynamic balanced type Linear tracking tonearm 4-pivot gimbal suspension
Effective length:	10.5 cm (4-1/8")
Tracking error angle:	Within ±0.1°
Effective mass:	9 g (including cartridge)
Resonance frequency:	12 Hz
Tonearm drive motor:	DC motor
Phono cable capacitance:	150 pF

Technics

Panasonic Company
Division of Matsushita Electric
Corporation of America
One Panasonic Way, Secaucus,
New Jersey 07094

Panasonic Hawaii Inc.
91-238 Kauhi St. Ewa Beach
P.O. Box 774
Honolulu, Hawaii 96808-0774



Panasonic Sales Company,
Division of Matsushita Electric
of Puerto Rico, Inc.
Ave. 65 De Infanteria, KM 9.7
Victoria Industrial Park
Carolina, Puerto Rico 00630


Panasonic Canada
Division of Matsushita Electric
of Canada Limited
5770 Ambler Drive, Mississauga,
Ontario L4W 2T2

CONTENTS



	Page		Page
LOCATION OF CONTROLS	2, 3	BLOCK DIAGRAM	14, 15
DISASSEMBLY INSTRUCTIONS	4 ~ 7	CIRCUIT BOARD AND WIRING CONNECTION DIAGRAM	16 ~ 18
HOW TO SET THE TONEARM DRIVE ROPE	8	SCHEMATIC DIAGRAM	19 ~ 22
HOW TO REPLACE CHIPS (RESISTOR)	8	EXPLODED VIEW	23, 24
CHECKING METHOD OF THE UNIT	9	REPLACEMENT PARTS LIST (Cabint and Chassis Parts)	25
MEASUREMENTS AND ADJUSTMENTS	10 ~ 12	PACKINGS	26
REPLACEMENT PARTS LIST (Electric Parts)	12, 13		

LOCATION OF CONTROLS





Synchro-rec jack
Phono output terminals (R) (L)
AC input socket
Ground



DISASSEMBLY INSTRUCTIONS

How to remove the turntable platter

1. Open the upper cabinet.
2. Remove the turntable mat and lift the turntable platter. (Fig. 1)

Note:

- (1) When removing the turntable platter, it is not necessary to remove the 45 r.p.m. adaptor.
- (2) The turntable platter is tight fitted onto the center spindle. When removing the turntable platter, take care not to give damage to the upper cabinet, arm motor cover and tonearm cover.




Fig. 1

How to remove the bottom board

1. Remove the turntable platter.
2. Remove the 4 screws. (Fig. 2 : ① ~ ④)




Fig. 2

How to remove the operation circuit P.C.B.

1. Remove the bottom board.
2. Remove the 7 setscrews (Fig. 3 : ⑤ ~ ⑪) of the printed circuit board.
3. Remove the optical sensor sensitivity selector switch and speed selector switch from the knob. (Fig. 3-A)
4. Remove the printed circuit board in the direction to the arrow (A).

Note:

The printed circuit board is grounded to the chassis by screw ⑩. When checking for conduction removing the screw ⑩, connect the earth terminal of P.C.B. to the chassis (stator frame).




Fig. 3

How to remove the switch (S301 ~ S312)

(Program keys, repeat and cueing control switches)

1. Remove the operation circuit P.C.B.
2. When removing S301 ~ S305, cut off the 2 claws (Fig. 4 : ⑫, ⑬) of LED holder. (Fig. 4-A)
3. Remove the LED from the holder, and raise the LED. (Fig. 5)
4. Release the claw (A) of LED holder and remove the LED holder from the printed circuit board. (Fig. 4)
5. Unsolder to remove the switch terminals.
6. To remove S306 ~ S310, cut off claws ⑭ and ⑮.
7. To remove S311 and S312, cut off claws ⑯ and ⑰.




Fig. 4

● **How to remove the drive circuit P.C.B. and stator frame.**

1. Remove the operation circuit P.C.B.
2. Remove the 5 setscrews (Fig. 6 : 18 ~ 22) of the drive circuit P.C.B. and stator frame.
3. Pull out the connector. Then the drive circuit P.C.B. and stator frame can be removed.
4. Remove the 4 setscrews (Fig. 7 : 23 ~ 26) to separate the drive circuit P.C.B. and stator frame.




Fig. 6

● **How to remove the arm motor cover**

1. Open the upper cabinet.
2. Remove the 4 screws of the arm motor cover (Fig. 8 : 27 ~ 30) and detach the arm motor cover in the direction of the arrow.




Fig. 5

● **How to remove the dust cover**

1. Open the upper cabinet and arm motor cover.
2. Turn the worm gear by hand to shift the tonearm a little inward.
3. Remove the 3 screws (Fig. 9 : 34 ~ 36) of the dust cover.
4. Remove the 2 setscrews (Fig. 10 : 37 , 38) of the dust cover. Then the dust cover can be removed.

● **How to remove the blank detecting sensor**

1. Open the upper cabinet and remove the arm motor cover.
2. Unsolder the lead wires of the blank detecting sensor.
3. Remove the screw of the guide plate. (Fig. 9 : 39)
4. Remove the rope fixture of the sensor. (Fig. 9)
5. Remove the guide rod fitting clip 40 and remove the guide rod. (Fig. 9)
6. Pull out the sensor in the direction of the arrow (A). (Fig. 9)




Fig. 9

● **How to remove the upper cabinet (Separation of upper cabinet and lower cabinet)**

1. Remove the bottom board.
2. Unsolder the lead wires of output terminal and remove the output terminal from the lower cabinet.
3. Pull out the 2 connectors (CN301, CN401) of the operation circuit P.C.B.
4. Remove the 4 screws (Fig. 11, 12 : 41 ~ 44) of the hinge.
5. The hinge claws are engaged with the lower cabinet. Release the claws and slowly lift the lower cabinet to separate it from the upper cabinet.




Fig. 11

- **How to remove the tonearm cover**
1. Open the upper cabinet.
 2. Remove the 3 screws of the tonearm cover (Fig. 8 : 31 ~ 33) and detach the tonearm cover in the direction of the arrow.




Fig. 8

● **How to remove the tonearm**



1. Remove the dust cover and tonearm cover.
2. Turn the worm gear by hand to move the tonearm inwards.
3. Unsolder the 5 lead wires of the cartridge. (Fig. 13)
4. Remove the screw of the tonearm. (Fig. 14 : 48)

● **How to remove the cueing control ass'y**

1. Remove the tonearm cover.
2. Unsolder the 2 lead wires of the cueing plunger. (Fig. 13)
3. Remove the 2 screws (Fig. 13 : 46 , 47) of the cueing control ass'y, and remove th ass'y in the direction of the arrow **A**.

● **How to remove the tonearm position indicator board**


1. Remove the tonearm cover.
2. Unsolder the 2 lead wires of the indicator. (Fig. 13)
3. Remove the screw of the tonearm position indicator board. (Fig. 13 : 48)



● **How to remove the Hall element**

1. Remove the turntable platter.
2. Remove the terminal solder by use of solder sucker.
3. Hold the Hall element with a tweezers and remove it while touching the soldering iron to the terminal. (Fig. 15)

Note: Fit the Hall element with the part No. print up. The reverse in terminal position is allowable provided that the printed side is up.



● **How to remove the 45 rpm adaptor**

1. Remove the turntable platter.
2. The adaptor claw catches the turntable platter. Remove the adaptor by pushing it in the direction of the arrow. (Fig. 16)

Note: When removing the adaptor, be sure to remove the turntable platter beforehand. Otherwise, the adaptor claw will be broken.

* The turntable platter of this unit is greased. (Fig. 17) After replacing the turntable platter or when the adaptor operation is not smooth, apply grease to the platter. (It is recommended to use Grease 3 of Kit No. SZE1003C.)

Note: Do not apply grease to parts other than those specified (outside surfaces of adaptor in particular). Also, apply a proper amount of grease so that it will not run into the set.

45-rpm adaptor




Fig. 16

Fig. 17

- A: Side of spring
- B: Bosses (3 portions) of turntable platter
- C: Bottom of turntable platter
- D: Notches (2 portions) of turntable platter

■ **HOW TO SET THE TONEARM DRIVE ROPE**

Set the rope according to the following procedure.

1. Remove the dust cover. (Refer to "How to remove the dust cover".)
2. Remove the lead wire holder. (See Fig. 18)
3. Remove the C-ring of the arm drive wheel and remove the drive wheel. (See Fig. 18 : 49)
4. Turn over the arm drive wheel, and set the rope in the order of 1 ~ 2. (Fig. 19)
5. Holding the rope with the hand, set the drive wheel and rope in the order of 3 ~ 8 of Fig. 20.
6. After setting the rope, match in tonearm and sensor with the position of rope fixture, and secure the parts.
7. Turn the worm gear by hand to see that the tonearm and sensor move, then set the C-ring.




Fig. 18




Fig. 19




Fig. 20

■ **HOW TO REPLACE CHIPS (RESISTOR)**

1. Unsolder from chip by using solder sucker.
2. Remove chip with tweezers by rotating it while removing solder as shown in Fig. 21.
3. Solder circuit board first and then solder chip in the direction of the arrow as shown in Fig. 22.

- Notes:**
1. Do not use chip again which is removed from printed circuit board.
 2. Use lead wire with insulator for replacement instead of chip jumper.

● **Note for replacing chips**

1. Do not heat chips more than three (3) seconds.
2. Be careful not to damage the electrode of chips.
3. Use soldering iron (less than 60W) and tweezers for replacing chips.




Fig. 21




Fig. 22

■ CHECKING METHOD OF THE UNIT

1. How to use the repair table (Fig. 23)

- ① Remove the bottom board.
- ② Remove the operation circuit P.C.B. and connect the P.C.B. earth terminal to the chassis (Stator frame).
- ③ Put the set on the repair table.
- ④ Fit the turntable platter and put on the turntable mat.
- ⑤ Put on the record and check the circuits from under the set.




Fig. 23

2. How to raise the set (Fig. 24)

Note: Turntable platter is not fixed on the center spindle. Take care so that the turntable platter will not come loose. Also, take care allow the set to fall down.

- ① Remove the bottom board.
- ② Completely open the upper cabinet.
- ③ Hold the cabinet switch with tape.
- ④ Fit the turntable platter.
- ⑤ Raise the set and check the circuits.




Fig. 24

3. How to turn over the set (Fig. 25)

Note: This purpose is to check the voltage of each circuit during stop of the turntable.

- ① Remove the turntable platter and turn over the set.
- ② Remove the bottom board.
- ③ Turn the power switch "on" and check the voltage.

Note: Do not push other switches.

[If the unit is operated under no-load condition (with turntable removed) for a long period of time, the drive IC will be damaged.]




Fig. 25

MEASUREMENTS AND ADJUSTMENT

Adjustment points




Fig. 26




Fig. 28




Fig. 29

Pin No.	Color	Description
1	Black	Ground
2	Red	Muting signal
3	Orange	Cueing signal
6	Blue	Sensor amp. output signal
7	Violet	Filter amp. output signal





Fig. 33



* Connect between Q1 (E) and IC301 (14) pin for clock frequency adjustments.

Fig. 27




Fig. 30




Fig. 31




Fig. 32

● Equipment used and condition of the set

1. Oscilloscope (two channels)
2. DC voltmeter.
3. Record (SFTR007) for adjustment.
4. Connector for adjustment.
5. Remove the bottom board and remove the cover. (Fig. 29)
6. Set the optical sensor sensitivity selector to "M".

Step	Item	Preparations for adjustment	Adjusting portion	Adjusting method
1	Start position	<ol style="list-style-type: none"> 1. Open the upper cabinet and put on the record. 2. Turn the power switch on. 3. Push the "Start" switch. 	Descending position adjusting screw. (Fig. 26)	<ol style="list-style-type: none"> 1. Turn the descending position adjusting screw. If it descends between tunes, turn the screw clockwise. If it descends outside the disc, turn the screw counterclockwise.
2	Clock frequency	<ol style="list-style-type: none"> 1. Connect Q1 emitter to IC301 14-pin. (Fig. 27) 2. Connect the oscilloscope to IC301 13-pin. 	VR301	<ol style="list-style-type: none"> 1. Turn the power switch on. 2. Adjust VR301 so that the cycle of output waveform is $40\mu\text{s} \pm 2\mu\text{s}$. (Fig. 28)
3	Sensor gain	<ol style="list-style-type: none"> 1. Remove the cover and insert the connector for adjustment into terminal CN901. (Fig. 29) 2. Connect the oscilloscope to 6-pin (+) and 1-pin (-). 3. Put on the record for adjustment with side A up. 	VR901 (Fig. 26)	<ol style="list-style-type: none"> 1. Turn the power switch on and move the tonearm to the blank area of the record. 2. Adjust VR901 so that the output voltage is $4\text{V} \pm 0.4\text{V}$.
4	Sensor resolution	<ol style="list-style-type: none"> 1. Remove the cover and insert the connector for adjustment into terminal CN901. (Fig. 29) 2. Connect the oscilloscope to 7-pin (+) and 1-pin (-). 3. Put on the record for adjustment with side A up. 	(VR902) (Fig. 26)	<ol style="list-style-type: none"> 1. Turn the power switch on. 2. Push the program key to let it search the tonearm. (Output is delivered between the tunes.) 3. Adjust VR902 so that the peak output between tunes is $2.7\text{V} \pm 0.27\text{V}$. (Fig. 30)
5	Cueing timer	<ol style="list-style-type: none"> 1. Remove the cover and insert the connector for adjustment into terminal CN901. (Fig. 29) 2. Connect the unit to the amplifier. (Phono output) 3. Connect 3-pin (+) and 1-pin (-) to the channel (1) of two channel oscilloscope. 4. Connect the speaker terminal of amplifier to the channel (2) of two channel oscilloscope. 5. Connect the 2-pin and 1-pin. (Muting operation stops.) 6. Put on the record for adjustment with side B up. 	VR903 (Fig. 26)	<ol style="list-style-type: none"> 1. Turn the power switch on. 2. Move the tonearm to a recorded (groove) part of the record, and push the cueing switch for cueing down. 3. Check the time until completion of cueing (rise of cueing signal) after the stylus touches the record surface. 4. Adjust VR903 so that the time until completion of cueing is $0.3 \sim 0.5$ sec. (Fig. 31) <p>Note: Set the sweep time of oscilloscope to 0.2 sec/cm or 0.5 sec/cm. For example, in the case of 0.2 sec/cm range, adjust it so that the cueing completion signal is delivered 2 scale (0.4 sec) later than delivery of phono output signal.</p>
6	Descending between tunes	<ol style="list-style-type: none"> 1. Open the upper cabinet and hold the cabinet switch with tape. 2. Put on the record for adjustment with side B up. 3. Close the upper cabinet. 4. Connect the unit to the amplifier. (Connect the speakers to speaker terminals.) 	Sensor shifting screw (Fig. 32)	<ol style="list-style-type: none"> 1. Turn the power switch on. 2. Push the program key 2, followed by start switch. 3. After completion of cueing down, push the program key 2 for the purpose of skipping. 4. Make sure that descending position is at count "20 ~ 21". 5. If the descending position is wrong, open the upper cabinet and turn the sensor shifting screw. 6. Close the upper cabinet and push the program key 2. 7. Adjust so that the descending position is at count "20 ~ 21". Repeat steps 4 ~ 7.
7	Tonearm offset angle	<ol style="list-style-type: none"> 1. Open the upper cabinet and hold the cabinet switch with tape. 2. Close the upper cabinet. 	Adjusting screw (Fig. 33)	<ol style="list-style-type: none"> 1. Turn the power switch on and push the start switch to shift the tonearm inward. 2. Open the upper cabinet. 3. Turn the adjusting screw so that the arm center matches the V-groove of the lift bar.

Step	Item	Preparations for adjustment	Adjusting portion	Adjusting method
8	Servo gain and offset voltage	<ol style="list-style-type: none"> Open the upper cabinet and hold the cabinet switch with the tape. Close the upper cabinet. Connect the DC voltmeter to CN301 terminal 3 and ground terminal. Remove the label of the tonearm cover. 	VR501 (Servo gain) P.C.B. (Offset voltage) (Fig. 32)	<ol style="list-style-type: none"> Turn the power switch on and push the start switch to shift the tonearm inward. Open the upper cabinet. Completely shift the tonearm to the right. Then, adjust VR501 so that the voltage is 3.6V. (Servo gain) Set the tonearm to the center and make sure that the output voltage is 1.8V. If the voltage is not 1.8V, loosen the printed circuit board screw and move the board to the right or left with a screwdriver so that the output voltage becomes 1.8V. After the adjustment, tighten the printed circuit board screw. (Offset adjustment)
9	Rotation speed	<ol style="list-style-type: none"> Open the upper cabinet and put on the record. 	VR201 (45 rpm) VR202 (33 rpm)	<ol style="list-style-type: none"> Turn the power switch on. Set the speed selector switch to 45 rpm. Turn VR201 to adjust the speed to the speed to the rated speed (45 rpm). Set the speed selector switch to 33 rpm. Turn VR202 to adjust the speed to the rated speed (33-1/3 rpm). Note: Be sure to adjust 45 rpm. first.

REPLACEMENT PARTS LIST... Electric Parts

- Notes:**
- Part numbers are indicated on most mechanical parts. Please use this part number for parts orders.
 - Important safety notice: Components identified by Δ mark have special characteristics important for safety. When replacing any of these components use only manufacturer's specified parts.
 - This "S" mark is service standard parts and may differ from production parts.
 - Unless otherwise specified.
All resistors are in OHMS (Ω) K = 1000 Ω , M = 1000k Ω
All capacitors are in MICROFARADS (μ F) P = μ μ F
 - Bracketed indications in Ref. No. columns specify the area. Parts without these indications can be used for all areas.

Areas

- * [M] is available in U.S.A.
- * [MC] is available in Canada.

Ref. No.	Part No.	Description
INTEGRATED CIRCUITS		
IC1 IC101 IC201	AN7812 AN6636 AN6552	Regulator Drive FG Amplifier & Constant Voltage (Hall Element)
IC301 IC401	MN1425FPE AN6562	Micro Computer Arm Motor Control
IC801	AN6562	DC amplifier & Band Pass Filter
IC802	AN6912	Comparator
TRANSISTORS		
Q1 Q301 Q302	S 2SC1383Q 2SD636 2SD636	Regulator Speed Select Muting Relay Drive
Q303 Q304 Q305 Q306 Q308, 309	2SD636 2SD892 2SB641 2SD636 2SB641	Cueing Drive Cueing Drive Switching Converter Waveform
Q310 Q311	2SB641 2SD636	Shaping Speed Select Start/Stop Select

Ref. No.	Part No.	Description
Q312 Q401, 402	2SD636 2SD592	Switching Arm Motor Control
Q403, 404	2SD638	Arm Motor Control
Q801	2SB641	Biass
DIODES		
D1 D2 D301 ~ 311	Δ SVDS1RBA20F S MA1056 SVDPR5704SF	Rectifier 5.6V Zener Light Emitting Diode
D312 ~ 317 D319 D320	MA162A S RVDPR7R5FB SVDPR5704SF	Switching 7.5V, Zener Light Emitting Diode
D321	SVDPG5724SYF	Light Emitting Diode
D501 D502 D503	MA162A MA162A SVDPR3432S	Light Emitting Diode
D801, 802 D803 D804, 805 D806	MA162A MA1047TA MA162A S RVDPR7R5FB	Slide & Integration 4.7V, Zener Biass 7.5V, Zener

Ref. No.	Part No.	Description
SWITCHES		
S1 S301 ~ 314	Δ SFDSC05N08 EVQQSH03B	Power Program, Reset, Cueing, Start & Stop
S315 S601 S701 S801	SFDSHSW0699 SFDS2M5L-C SFDSC05N01 SFDSHSW0699	Speed Selector Rest Cabinet Gain Selector
VARIABLE RESISTORS		
VR201, 202	EVTS3MA00B54	Speed Adj., 50k Ω (B)
VR301	EVNK6AA00B24	Clock Frequency Adj., 20k Ω (B)
VR501	EVNK6AA00B54	Servo Gain Adj., 50k Ω (B)
VR901	EVNK6AA00B15	Gain Adj., 100k Ω (B)
VR902	EVNK6AA00B15	Detecting Sensitivity Adj., 100k Ω (B)
VR903	EVNK6AA00B24	Cueing Timer Adj., 20k Ω (B)

Ref. No.	Part No.	Description
COMPONENT COMBINATION		
Z301	EXBT44471K	470Ω x 4
Z302	EXBRB7471K	470Ω x 7
Z303	EXBP84333K	33kΩ x 4
Z304	EXBP84103K	10kΩ x 4
Z305	EXBP84332K	3.3kΩ x 4

Ref. No.	Part No.	Description
PHOTO INTERRUPTERS		
PC501	ON1186	Arm Position Offset Angle Blank Groove
PC601	ON1161	
PC701	ON2159	
RELAY		
RL501	SFDYQ11N01	Muting

Ref. No.	Part No.	Description
HALL ELEMENT		
H1, 2	OH-002	Turntable Posistor Detector
POWER TRANSFORMER		
T1 [M]	Δ SLT48DTL3A	Power Source
T1 [MC]	Δ SLT48DT11C	Power Source
FUSE		
F1 [MC] only	Δ XBA2F08NU100	800mA, 250V

Ref. No.	Part No.	Value
RESISTORS		
R1	S ERD25FJ471	470
R2	S ERD25FJ101	100
R3	S ERX1ANJ270	27
R4	S ERD25FJ102	1K
R101	ERD10TLJ270U	27
R102	S ERX1ANJ2R7	2.7
R105	ERD10TLJ153U	15K
R106	ERD10TLJ223U	22K
R201	ERD10TLJ102U	1K
R202	ERD10TLJ153U	15K
R203	ERD10TLJ333U	33K
R204	ERD10TLJ104U	100K
R205	ERD10TLJ683U	68K
R206	ERO10MKG1913	191K
R207	ERO10MKG5622	56.2K
R221	ERD10TLJ102U	1K
R222	ERD10TLJ153U	15K
R320	S ERD25TJ333	33K
R321	S ERD25FJ471	470
R322	S ERD25FJ102	1K
R323	S ERD25FJ103	10K
R324, 325	S ERD25FJ472	4.7K
R326, 327	S ERD25FJ152	1.5K
R328	S ERD25FJ472	4.7K
R329	S ERD25FJ392	3.9K
R330	S ERD25FJ103	10K
R331	S ERD25FJ472	4.7K
R334, 335	S ERD25FJ331	330
R336	S ERD25FJ103	10K
R337	S ERD25TJ223	22K

Ref. No.	Part No.	Value
R338	S ERD25FJ272	2.7K
R341	S ERD25TJ563	56K
R343	S ERD25FJ103	10K
R345	S ERD25FJ472	4.7K
R346	S ERD25TJ333	33K
R347	S ERD25TJ563	56K
R348	S ERD25FJ103	10K
R349	S ERD25FJ471	470
R350	S ERD25FJ472	4.7
R351	S ERD25FJ471	470
R352, 353	S ERD25FJ222	2.2K
R354	S ERD25TJ223	22K
R355	S ERD25FJ103	10K
R356	S ERD25FJ152	1.5K
R357	S ERD25TJ223	22K
R358	S ERD25TJ333	33K
R359	S ERD25FJ561	560
R401	S ERD25TJ683	68K
R402	S ERD25FJ152	1.5K
R403	S ERD25FJ102	1K
R404	S ERD25TJ224	220K
R405	S ERD25TJ683	68K
R406	S ERD25FJ152	1.5K
R407	S ERD25FJ102	1K
R408	S ERD25TJ224	220K
R409	S ERD25TJ273	27K
R410	S ERD25FJ103	10K
R413	Δ ERD2FCG180	18
R501	S ERD25FJ561	560
R502	S ERD25FJ391	390
R601	S ERD25FJ681	680
R801	S ERD25TJ154	150

Ref. No.	Part No.	Value
R802	S ERD25FJ472	4.7K
R803	S ERD25TJ154	150K
R805	S ERD25FJ222	2.2K
R806	S ERD25FJ472	4.7K
R807	S ERD25FJ332	3.3K
R808	S ERD25FJ682	6.8K
R809	S ERD25FJ102	1K
R810	S ERD25FJ103	10K
R811	S ERD25TJ684	680K
R812	S ERD25TJ223	22K
R813	S ERD25TJ104	100K
R814	S ERD25TJ684	680K
R815	S ERD25TJ224	220K
R816	S ERD25FJ221	220
R817	S ERD25TJ104	100K
R818	S ERD25FJ102	1K
R820	S ERD25FJ222	2.2K
R821	S ERD25FJ272	2.7K
R822	S ERD25FJ220	22
R823	S ERD25FJ103	10K
R825	S ERD25FJ101	100
R826	S ERD25TJ223	22K
R828	S ERD25TJ223	22K
R829	S ERD25FJ682	6.8K
CAPACITORS		
C1	Δ S ECQM1223KZ	0.022
C2, 3	Δ S ECKD1H223PF	0.022
C4	S ECEB1VS222	2200
C5	S ECEA1CS330	33
C101	ECUV1E333KBM	0.033

Ref. No.	Part No.	Value
C102, 103	Δ S ECEA1CN470S	47
C104	S ECEA1CS101	100
C105	S ECEA1CS330	33
C201	S ECEA1HS3R3	3.3
C202	S ECQM1H104KV	0.1
C203	S ECQM1H333KV	0.033
C205	ECUV1E473KBM	0.047
C206	S ECQM1H104JV	0.1
C207	S ECQM1H104KV	0.1
C208	S ECEA1ES4R7	4.7
C209	S ECQM1H104KV	0.1
C210	S ECEA1HSR22	0.22
C212, 213	ECUV1H102MBM	0.001
C301	S ECCD1H680K	68P
C302	S ECQM1H104KV	0.1
C303	S ECKF1E104ZVD	0.1
C304	S ECEA0JS330	33
C305	S ECKD1H223PF	0.022
C306	S ECKD1H102KB	0.001
C401, 402	S ECQM1H223KZ	0.022
C501	S ECEA1CS101	100
C801	S ECFB1B104ZRM	0.1
C801	S ECQM1H103KV	0.01
C802, 803	S ECQM1H104KV	0.1
C804	S ECEA1CS220	22
C805	S ECEA1CS470	47
C806	S ECQM1H473KV	0.047

Numbering System of Resistor

Example

ERD	25	F	J	101
Type	Wattage	Shape	Tolerance	Value
ERX	2	AN	J	2R2
Type	Wattage	Shape	Tolerance	Value

Numbering System of Capacitor


Example

ECKD	1H	102	Z	F
Type	Voltage	Value	Tolerance	Peculiarity
ECEA	50	M	R47	R
Type	Voltage	Peculiarity use	Value	Special use

Resistor Type	Wattage	Tolerance
ERD : Carbon	10 : 1/8W	J : ± 5%
ERX : Metal Film	25 : 1/4W	G : ± 2%
ERO : Metal Film	1 : 1W	

ERD10TLJ□□□ → Chip type carbon
 ERO10MKG□□□ → Chip type metal film
 ECUV1H□□□ → Chip type ceramic


Capacitor Type	Voltage		Tolerance
	ECEA Type	Others	
ECEA : Electrolytic	0J : 6.3V	1H : 50V DC	J : ± 5%
ECEA...N : Non Polar Electrolytic	1A : 10V	2H : 500V DC	K : ± 10%
ECKD : Ceramic	1C : 16V		Z : +80%, -20%
ECQM : Polyester	1E : 25V		P : +100%, -0%
ECEB : Electrolytic	1H : 50V		M : ± 20%
ECUV : Ceramic	1J : 63V		
ECKF : Ceramic	50 : 50V		
	25 : 25V		



BLOCK DIAGRAM


• Description of each terminal of MN1425FPE

Pin No.	Symbol	Description
1	VSS	Ground terminal
2	CO1	Turntable speed select output terminal (45 rpm at "H", 33 rpm at "L".)
3	CO10	Program LED display output terminal (LED ON at "L".)
4	CO9	
5	CO8	
6	CO7	
7	CO6	Repeat LED display output terminal (LED ON at "L".)
8	CO5	
9	CO4	
10	CO3	
11	CO2	Repeat LED display output terminal (LED ON at "L".)
12	CO1	
13	CO0	(LED ON at "L".)
14	A13	Key scan input terminal (Each key is read in through key scan with Export.)
15	A12	
16	A11	
17	A10	Rest position detection input terminal ("L" when tonearm is on rest.)
18	B13	
19	B12	
20	B11	Turntable speed select and cabinet opening/closing detection terminal (Each operation is done through key scan with Export.)
21	B10	
22	EO1	
23	EO1	Key scan output terminal (Each key's read in through key scan with A-port.)
24	EO2	
25	EO3	
26	TST	Test terminal (connected to Ground not used)
27	RST	Reset terminal (The microcomputer is reset at "L", and is not reset at "H".)
28	SLCT	Select terminal (The level is set to "H" by the select terminal of the inside counter.)
29	SNSO	Offset angle detection signal input terminal
30	SNSI	Arm position detection signal input terminal
31	DO0	Turntable start/stop select terminal (Start at "L", stop at "H".)
32	DO1	Arm motor drive control terminal
33	DO2	
34	DO3	
35	DO4	
36	DOS	Muting control terminal
37	DO6	Cueing control terminal ("H" during cueing and cueing down.)
38	DO7	Cueing control terminal ("H" only during cueing down.)
39	VDD	Power supply terminal
40	OSC	Oscillation terminal



• Arm motor control (D-port)

Pin No.	STOP	Forward	Reverse
32	H	L	L
33	H	H	L
34	L	L	H
35	L	H	H



REPLACEMENT PARTS LIST... Cabinet & Chassis Parts

- Notes: 1. Part numbers are indicated on most mechanical parts. 2. Important safety notice: Components identified by **Δ** mark have special characteristics important for safety. When replacing any of these components, use only manufacturer's specified parts. 3. Bracketed indications in Ref. No. columns specify the area. Parts without these indications can be used for all areas.
4. The "S" mark is service standard parts and may differ from production parts. 5. The parenthesized numbers in the column of description stand for the quantity per set.


Areas

* [M] is available in U.S.A.
* [MC] is available in Canada.


Ref. No.	Part No.	Description	Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
CABINET and CHASSIS PARTS								
1	SFWE006N01	45-r.p.m. Adaptor	47	SFATC05N01A	Hinge, (Right)	A1 [M]	SFNUC06M01	Instruction Book
2	SFGAC06N01	Spring	48	SFULM05N20	Guide, Lead Wire	A1 [MC]	SFNUC06C01E	Instruction Book
3	SFTGC06N01	Turntable Mat	49	SFUJZ05N03	Latch	A2	SFDHC05N01	Phono Cord
4	SFTFC06N01A	Turntable	50	SFADCC06N01E	Dust Cover	A3	SFDLUC05N01	Ground Wire
5	SFAC006N01	Cabinet	51	SFGCC05N03	Cushion Rubber	A4	RAA2ZY	AC Cord
6 [M]	SFNNCC06M01	Name Plate	52	SFGCC05N06	Cushion Cover	A5	SFNZC06N01	Caution Sheet
6 [MC]	SFNNCC06C01	Name Plate	53	SFKKC06N03	Surface Plate			
7	SFKKCO6N02	Plate, Front	54	SFNUC06M02	Felt, Front Panel			
8	SFKTTC06N03	Knob, Speed Selector	55	SFUJPC06N04	Felt, Front Panel			
9	SFKTTC06N02	Knob, Start and Stop	56	SFDJUC06N02	Jack, Synchro-Rec			
10	SFKTTC06N01	Knob, Music Selector	TONERARM PARTS					
11	SFUUMC06N01	Rod, Power Switch	60	SFPAM00501A	Tonerarm	P1 [M]	SFHPC06M01	Carton Box
12	SFKKTC06N04	Label, Power Switch	61	SFPAB00501E	Indicator	P1 [MC]	SFHPC06C01	Carton Box
13	SFKKTC06N01	Label, Sensitivity	62	SFPZB00605E	Lift Plate Assy	P2	SFHHC05N01	Pad, Front
14	SFKKCO05N02	Label, Speed Selector	63	SFPAB00602	Bracket, Tonerarm	P3	SFHHC05N02	Pad, Rear
15	SFOPO05N01	Spring	64	SFSPR00503	Spring, Lead Wire	P4	SFHKC05N01	Clamper, Turntable
16	SFDJHSC0491	Socket, AC	65	SFPC300601	Cover, Tonerarm Base	P5	SFHSC05N02	Spacer, Tonerarm
17	SFDHC05N02E	Socket, Input	66	SFSPB00602	Spring, Adjustment	P6	SFHSC06N01	Spacer, Dust Cover
18	SFMG034N01	Film, Stator Frame Assy	67	SFSP00602	Cam	P7	SFYH45X50	Polyethylene Bag, Unit
19	SFMZC06N01R	Stator Frame Assy	68	SFPZB00603	Wheel, ADJAdjustment	P8	SFYH17X16	Polyethylene Bag, Cord
20	SFUUMC06N06	Holder, L.E.D.	69	SFPJIK00601	Cam			
21	SFUUMC06N07	Holder, L.E.D.	70	SFPZB00604	Shaft, Wheel Worm			
22	SFAUC06N01	Bottom Board	SCREWS, WASHERS and NUT					
23	SFOCC05N01	Spring, Audio Insulator	N1	XTN3+20JFZ	Screw	N1	XTN3+20JFZ	Screw
24	SFGAC05N02	Audio Insulator	N2	XTN3+10JFZ	Screw	N2	XTN3+10JFZ	Screw
25	SFGCC06N01	Cushion Rubber, Power Transformer Cover	N3	XTV3+10G	Screw	N3	XTV3+10G	Screw
26	SFUUMC06N04E	Power Transformer Cover	N4	XTV3+6JFZ	Screw	N4	XTV3+6JFZ	Screw
27	SFUUMC06N10	Shutter	N5	XTV3+20G	Screw	N5	SFXGC05N02	Screw
28	SFUUMC06N08	Bracket, Shutter	N6	SFXGC05N02	Screw	N6	SFXGC05N04	Screw
29	SFUUMC06N11	Holder, Lead Wire	N7	SFXGC05N04	Washer	N7	SFXGC05N03	Washer
30	SFUUMC05N17	Arm Drive Wheel	N8	SFXGC05N03	Screw	N8	XNC3HS	Nut, φ3
31	SFUUMC05N16A	Worm Assy	N9	XNC3HS	Screw	N9	XTW3+14QFYR	Screw
32	SFGBC10-01	Bel, Arm Drive	N10	XTW3+14QFYR	Screw	N10	XTV3+20G	Screw
33	SFMHC05N01E	Arm Drive Motor (with Pulley)	N11	XTV3+20G	Screw	N11	XTV3+8BFZ	Screw
34	SFUUMC05N02E	Plate, Rest Switch	N12	XTV3+8BFZ	Screw	N12	XSN3+HS	Screw
35	SFUZC05N01	Rod, Rest Switch	N13	XSN3+HS	Screw	N13	XUC3FT	Washer
36	SFUUMC05N06	Guide, Rod Rest Switch	N14	XUC3FT	Washer	N14	SFPEV00502	Screw
37	SFUUMC06N05E	Sensor Assy	N15	SFPEV00502	Screw	N15	XTV3+10BFZ	Screw
38	SFXJUC06N01	Guide Rail, Sensor Assy	N16	XTV3+10BFZ	Screw	N16	XSND6+10BV	Screw
39	SFUUMC05N22	Pulley	N17	XSND6+10BV	Screw	N17		
40	SFUUMC05N23	Cap, Pulley						
41	SFUZC06N01E	Arm Drive Loop Assy						
42	SFUUMC05N03	Bracket, Guide Rail						
43	SFXJUC05N01	Guide Rail, Arm Drive						
44	SFGCC05N05	Cushion Rubber, Guide Rail						
45	SFUUMC06N01A	Plate Assy						
46	SFATC05N02A	Hinge, (Left)						

PACKINGS



1. Set the tonerarm to the start position.
2. Attach the arm spacer.




3. Attach the clamper and dust cover spacer.
4. Stick the protection sheet on the top of dust cover.




5. Put the set into the polyethylene bag and then pack it as illustrated.



6. Place the unit (with cushions attached) as illustrated.
7. Fold the flaps according to the line marks.
8. Seal the top with adhesive tape.
9. For the edges, first fold the flap "a" and then flap "b", and staple. Remember to staple only flap "b". (Use 15 or 16mm staple)



* Stapling positions are shown below.




SCHEMATIC DIAGRAM

(The schematic diagram may be modified at any time with the development of new technology.)

Notes:

1. **S1** : Power switch in "on" position.
2. **S301 ~ S310** : Program switch (Program key 1 ~ 10).
3. **S311** : Repeat switch.
4. **S312** : Cueing control switch.
5. **S313** : Start switch.
6. **S314** : Stop/clear switch.
7. **S315** : Speed selector switch in "auto" position.
8. **S601** : Rest switch in "off" position.
(Tonearm is off the rest position.)
9. **S701** : Cabinet switch in "on" position.
(Upper cabinet is closed.)
10. **S801** : Optical sensor sensitivity selector switch in "M" position.

11. The voltage value and waveform are the standard values of this measured by DC electronic voltmeter (high impedance) and oscilloscope on the basis of chassis. Therefore, the voltage value and waveform may include some error due to the internal impedance of the tester or the measuring set.
 - * () is the voltage when turntable is in stop.
 - * () is the voltage when turntable is in lead-in mode.
 - * () is the voltage when tonearm is in return mode.
 - * () is the voltage at 45 rpm.
12. Positive voltage lines.



IMPORTANT SAFETY NOTICE

The shaded area on this schematic diagram incorporates special features important for protection from fire and electrical shock hazards. When servicing it is essential that only manufacturer's specified parts be used for the critical components in the shaded areas of the schematic.

Product for MC only

FUSE REPLACEMENT

Symbol located near the fuse indicates fast operating type. For continued protection against fire hazard, replace with same type fuse. Refer to the symbol for fuse rating.

FUSIBLE REMPLACEMENT

Le symbole qui se trouve près du fusible signifie un fusible à action rapide. Pour une protection continue contre les risques d'incendie, n'utiliser que des fusibles du même type. Se reporter au symbole pour la valeur des fusibles.

Power Source circuit for [MC] only.

