

Service Manual


Stereo Integrated Amplifier

Amplifier

SU-A700MK2

Colour

(K) Black Type



Areas

Suffix for Model No.	Area	Colour
(E)	Europe	(K)
(EB)	Great Britain	
(EG)	Germany and Italy	
(EO)	Switzerland	

Specifications (DIN 45 500)

20 Hz – 20 kHz continuous power output both channels driven	2 x 45 W (8 Ω)	Frequency response PHONO MM	RIAA standard curve ±1 dB (30 Hz – 15 kHz)
1 kHz continuous power output both channels driven (THD: 1%)	2 x 55 W (8 Ω) 2 x 80 W (4 Ω)	TUNER, CD, AUX, TAPE 1, TAPE 2/DCC	3 Hz – 80 kHz (+0, -3 dB) +0 dB, -0.3 dB (20 Hz – 20 kHz)
63 Hz – 12.5 kHz continuous power output both channels driven (THD: 0.7%)	2 x 50 W (8 Ω) 2 x 70 W (4 Ω)	Tone controls BASS TREBLE	50 Hz, +10 to -10 dB 20 kHz, +10 to -10 dB
Total harmonic distortion rated power at 20 Hz – 20 kHz	0.01% (8 Ω)	Output voltage TAPE 1, TAPE 2/DCC REC OUT	150 mV
Intermodulation distortion (50 Hz: 7 kHz = 4:1, SMPTE) rated power	0.007% (8 Ω)	Channel balance (AUX 250 Hz – 6.3 kHz)	±1 dB
Residual hum and noise	1 mV	Channel separation (AUX 1 kHz)	50 dB
Damping factor	60 (8 Ω) 30 (4 Ω)		
Headphones output level/impedance	540 mV/330 Ω	GENERAL	
Load impedance		Power consumption	200 W
A or B	4 – 16 Ω	Power supply	
A and B	8 – 16 Ω	For (E), (EG), and (EO) areas	50 Hz/60 Hz AC, 230 V
Input sensitivity/impedance		For (EB) area	50 Hz/60 Hz AC, 230 V – 240 V
PHONO MM	2.5 mV/47 kΩ	Dimensions (W × H × D)	430 × 125 × 318 mm
TUNER, CD, AUX, TAPE 1, TAPE 2/DCC	150 mV/22 kΩ	Weight	6.7 kg
Phono maximum input voltage (1 kHz, RMS)			
MM	150 mV (150 mV, IHF '66)	Notes:	
S/N (rated power, 4 Ω)		1. Specifications are subject to change without notice. Weight and dimensions are approximate.	
PHONO MM	76 dB (78 dB, IHF '66)	2. Total harmonic distortion is measured by the digital spectrum analyzer.	
TUNER, CD, AUX, TAPE 1, TAPE 2/DCC	91 dB (99 dB, IHF '66)	3. For areas except Europe The specification values given have been measured while using a 240 V power supply.	
S/N at – 26 dB power (4 Ω)		For (EB) area only	
PHONO MM	68 dB	This apparatus was produced to BS 800.	
TUNER, CD, AUX, TAPE 1, TAPE 2/DCC	70 dB		
S/N at 50 mW power (4 Ω)			
PHONO MM	64 dB		
TUNER, CD, AUX, TAPE 1, TAPE 2/DCC	64 dB		

Technics

■ Contents

	Page	Page	
● Before Repair	2	● Schematic Diagram	14~20
● Protection Circuitry	2	● Printed Circuit Board Diagram	21~24
● Accessories	2	● Wiring Connection Diagram	25
● Caution for Mains Lead	3	● Block Diagram	26
● Front Panel Controls	4	● Function of IC Terminals	27
● Connections	5, 6	● Replacement Parts List	28~34
● Listening to Sound	7, 8	● Cabinet Parts Location	31, 32
● Recording	9	● Packaging	34
● Operation Check and Main Component Replacement Procedures	10~13		

■ Before Repair

- (1) Turn off the power supply. Using a 10 Ω, 10 W resistor, connect both ends of power supply capacitors (C701, C702) in order to discharge the voltage.
 (2) Before turning the power supply on, after completion of repair, slowly apply the primary voltage by using a power supply voltage controller to make sure that the consumed current at 50/60 Hz in NO SIGNAL mode should be shown below with respect to supply voltage 230 V—240 V.

Power supply voltage	AC 230 V	AC 240 V
Consumed current 50Hz	50~250 mA	40~240 mA

■ Protection circuitry

The protection circuitry may have operated if either of the following conditions is noticed:

- * No sound is heard when the power is switched ON.
- * Sound stops during a performance.

The functions of this circuitry is to prevent circuitry damage if, for example, the positive and negative speaker connection wires are "shorted", or if speaker systems with an impedance less than the indicated rated impedance of this unit are used.

If this occurs, follow the procedure outlined below:

1. Switch OFF the power.
2. Determine the cause of the problem and correct it.
3. Switch ON the power once again.

Note:



When the protection circuitry functions, the unit will not operate unless the power is first switched OFF and then ON again.

■ Accessories


- AC power supply cord 1

for (E), (EG) and (EO) areas : (RJA0019-2K)

for (EB) area : (VJA0733)



- Remote control transmitter
(RAK-SU129WH) 1



- Batteries
(UM-4, "AAA", R03) 2

Note: These are available on sales route.



Caution for AC Mains Lead (For United Kingdom)

(“EB” area code model only)

For your safety, please read the following text carefully.

This appliance is supplied with a moulded three pin mains plug for your safety and convenience.

A 5-ampere fuse is fitted in this plug.

Should the fuse need to be replaced please ensure that the replacement fuse has a rating of 5-ampere and that it is approved by ASTA or BSI to BS1362. Check for the ASTA mark  or the BSI mark  on the body of the fuse.

If the plug contains a removable fuse cover you must ensure that it is refitted when the fuse is replaced.

If you lose the fuse cover the plug must not be used until a replacement cover is obtained.

A replacement fuse cover can be purchased from your local dealer.

CAUTION!

IF THE FITTED MOULDED PLUG IS UNSUITABLE FOR THE SOCKET OUTLET IN YOUR HOME THEN THE FUSE SHOULD BE REMOVED AND THE PLUG CUT OFF AND DISPOSED OF SAFELY.

THERE IS A DANGER OF SEVERE ELECTRICAL SHOCK IF THE CUT OFF PLUG IS INSERTED INTO ANY 13-AMPERE SOCKET.

If a new plug is to be fitted please observe the wiring code as shown below.

If in any doubt please consult a qualified electrician.

IMPORTANT

The wires in this mains lead are coloured in accordance with the following code:

Blue: Neutral

Brown: Live

As the colours of the wires in the mains lead of this appliance may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows:


The wire which is coloured BLUE must be connected to the terminal in the plug which is marked with the letter N or coloured BLACK.

The wire which is coloured BROWN must be connected to the terminal in the plug which is marked with the letter L or coloured RED.

Under no circumstances should either of these wires be connected to the earth terminal of the three pin plug, marked with the letter E or the Earth Symbol .


Before use

Remove the connector cover as follows.




How to replace the fuse


1. Remove the fuse cover with a screwdriver.



2. Replace the fuse and attach the fuse cover.



■ Front Panel Controls



No.	Name
-----	------

**① Power "STANDBY ⏪ /ON" switch
(POWER, STANDBY ⏪ /ON)**

Press to switch the unit from on to standby mode or vice versa. In standby mode, the unit is still consuming a small amount of power.

② "STANDBY" Indicator (STANDBY)

When the unit is connected to the AC mains supply, this indicator lights up in standby mode and goes out when the unit is turned on.

③ Operation indicator (OPERATION)

When the power is switched ON, this indicator illuminates after about 3 seconds when the unit is in the operating condition.

If an abnormal condition in the circuitry is detected, such as DC voltage appearing in the output or a short-circuit of the positive (+) and negative (-) wires from the speaker terminals, the protection circuit functions and this indicator will not illuminate.

④ Volume control (VOLUME)

**⑤ Tape-monitor button/indicators
(TAPE MONITOR)**

No.	Name
-----	------

**⑥ Remote control signal receptor
(SENSOR)**

Receives the signals from the remote control.

⑦ Headphones jack (PHONES)

**⑧ Speaker select buttons/indicators
(SPEAKERS)**

⑨ Tone controls (BASS/TREBLE)

⑩ Balance control (BALANCE)


⑪ Tone control button (TONE)

⑫ Input select buttons/indicators

■ Connections

To connect to each terminal

Make connections to each component in the system by using stereo connection cables (not included).




A "REMOTE CONTROL OUT" terminal

Connect the connection cable for the remote control to a Technics tape deck and/or CD player (or CD changer) which has the appropriate remote control terminal as shown at the right.


If a tape deck is not being used, the CD player (or CD changer) can be connected directly (dotted line).

Note

For a tape deck and/or CD player (or CD changer) with a remote control sensor, this connection is not necessary.



To connect the speakers



- ① Strip off the outer covering, and twist the center conductor.
 - ② Turn completely to the left.
 - ③ Insert the wire and turn completely to the right. Pull the cord to assure a proper connection.
- Note** Be sure to only connect positive (+) cords to positive (+) terminals, and negative (-) cords to negative (-) terminals.
- Note** To prevent damage to circuitry, never short-circuit the positive (+) and negative (-) speaker wires.

■ "B" terminals


For connection to a second pair of speakers.

■ Speaker impedance

- When only the "A" or only the "B" terminals are used: 4–16 ohms
- When both the "A" and the "B" terminals are used simultaneously: 8–16 ohms


About the cooling fan

The cooling fan operates at high power output levels only. (There is no cooling fan for some countries.)




To connect the AC power supply cord

FOR UNITED KINGDOM ONLY
BE SURE TO READ THE CAUTION FOR THE
AC POWER SUPPLY CORD ON PAGE 3
BEFORE CONNECTING THE AC POWER
SUPPLY CORD.




Insertion of Connector

Even when the connector is perfectly inserted, depending on the type of inlet used, the front part of the connector may jut out as shown in the drawing. However there is no problem using the unit.




Note The configuration of the AC power supply cord differs according to area.


■ Listening to Sound



Before operation, set VOLUME to the "MIN" position.



Press POWER to switch on the power.



Press to select the desired source.

The corresponding indicator above will illuminate to indicate which button is selected.


TAPE 1: To listen to tape (TAPE 1).
TAPE 2/DCC: To listen to tape (TAPE 2) or digital compact cassette (DCC).

AUX: To listen to equipment connected to the "AUX" terminals.

CD: To listen to compact discs.

TUNER: To listen to radio broadcasts.

PHONO: To listen to phono discs.



Press A and/or B to select the speaker system(s) to be used.

A and B refer to the speaker terminals at the rear of the unit.

The corresponding indicator above will illuminate to indicate which speaker system is selected.

A: Sound can be heard from the speakers connected to the "A" terminals.

B: Sound can be heard from the speakers connected to the "B" terminals.


A and B: Sound can be heard simultaneously from the speakers connected to the "A" terminals and the "B" terminals.

off: No sound will be heard from the speakers.
(Both indicators will turn off.)




Start the desired source.

(Refer to the appropriate operating instructions for details.)




Turn VOLUME to adjust the volume level.




Press TAPE MONITOR so that the "SOURCE" indicator illuminates.

Note
When a graphic equalizer connected to the "TAPE 1" or "TAPE 2/DCC" terminals is used, set the selector to the "TAPE 1" or "TAPE 2/DCC" position.



After listening is finished

Be sure to reduce the volume level, and switch the power to the standby condition by pressing POWER.




Headphones (not included)
Plug type:
6.3 mm phone plug stereo type

To adjust the tone quality



Set TONE to the "ON" position.


If set to the "DEFEAT" position, tone controls have no effect.



Turn BASS to adjust the low-frequency sound.

Turn TREBLE to adjust the high-frequency sound.

To adjust the sound balance



Turn BALANCE to adjust the left/right sound balance.

When listening through headphones

Use VOLUME to reduce the volume level, and connect the headphones.

If sound from speakers is not wanted, press SPEAKERS (A) and/or (B) to turn off the speaker select indicators.


Note

Avoid listening for prolonged periods of time to prevent hearing damage.

■ Recording

To record from compact discs, etc.

It is possible to record from units which are connected to the rear "AUX", "CD", "TUNER" or "PHONO" terminals to cassette tape decks or DCC decks which are connected to the "TAPE 1" or "TAPE 2/DCC" terminals.



Before recording, prepare the tape deck or DCC for recording (recording level adjustment, etc.).

See the tape deck's or DCC's operating instructions for details.

1 Press TAPE MONITOR so that the "SOURCE" indicator illuminates.

2 Select the program source to be recorded.

AUX: To record from equipment connected to the "AUX" terminals.

CD: To record from compact discs.

TUNER: To record from radio broadcasts.

PHONO: To record from phono discs.

3 Begin recording.

Follow your tape deck's or DCC's operating instructions.


4 Begin the source to be recorded.

To check the sound recorded while recording is being made

If a cassette tape deck with 3 heads is connected to the "TAPE 1" or "TAPE 2/DCC" terminals, it is possible to check the sound being recorded onto the tape.

Tape-to-tape recording

It is possible to record from tape deck 1 (the cassette tape deck which is connected to the "TAPE 1" terminals) to tape deck 2 (the cassette tape deck or DCC deck which is connected to the "TAPE 2/DCC" terminals) and vice versa.



Preparation

- Before recording, prepare the tape deck or DCC for recording (recording level adjustment, etc.).
- See the tape deck's or DCC's operating instructions for details.
- Load tapes which have been advanced to the end of the leader tape into both decks.

To record from tape deck 2 to 1

1 Press TAPE MONITOR so that the "SOURCE" indicator illuminates.

2 Press "TAPE 2/DCC".

3 Begin tape deck 1 for recording and tape deck 2 for playback.

To record from tape deck 1 to 2

1 Press TAPE MONITOR so that the "SOURCE" indicator illuminates.

2 Press "TAPE 1".

3 Begin tape deck 2 for recording and tape deck 1 for playback.

TAPE 1 TAPE 2/DCC SOURCE TAPE MONITOR Press TAPE MONITOR to select the deck (tape deck 1 or 2) and set the monitor switch on the tape deck to "TAPE".



TAPE 1: when recording on tape deck 1

TAPE 2/DCC: when recording on tape deck 2

■ Operation Check and Main Component Replacement Procedures


NOTE

1. This section describes procedures for checking the operation of the major printed circuit boards and replacing the main components.
2. For reassembly after operation checks or replacement, reverse the respective procedures. Special reassembly procedures are described only when required.
3. Select items from the following index when checks or replacement are required.
4. Illustrated screws are equivalent to actual size.
5. [] indicates parts No.


● Contents

	Page
1. Checking for the Volume P.C.B. /Operation P.C.B. /Tone AMP P.C.B.	11.
2. Checking for the Main P.C.B.	12.
3. Replacement for power IC.	13.

1. Common disassembly procedures (Follow this procedure prior to other disassembly.)



※ (E, EG) : RKM0114A-K
※ (EB, EO): RKM0114B-K




[RHD30035-K1] (Black)



[XTBS3+8JFZ1] (Black)


2. Checking for the Volume P.C.B. / Operation P.C.B. / Tone AMP P.C.B.

To check the operation of each P.C.B., use item 1 of page 10.




To remove each P.C.B.

Step 1 Remove the 3 screws.




Step 2 Remove the knob and nut.


Step 3 Remove the volume P.C.B.





Step 4 Remove the knobs and nuts.



Step 5 Remove the 13 screws.




Adhesive tape Pull out the knobs with using adhesive tape when the knob is hardly removed.




3. Checking for the Main P.C.B.

Step 1 Follow the disassembly procedure described in item 1 on page 10.




※ (E, EG) : RGR0170A-CB
※ (EO) : RGR0170H-BB
※ (EB) : RGR0170B-BB


Step 2 Remove the 13 screws.



Step 3 Remove the 3 screws.




Step 4 Remove the 7 screws.




Step 5 Lift the main P.C.B. off the retention post on the bottom chassis.



Step 6 Remove the main P.C.B. in the direction of arrow ①, ②.



Step 7 Install the rear panel temporarily on the main P.C.B. again.





Step 8 Connect the front panel ass'y of the P.C.B. connectors to the main P.C.B. and set it as the illustration below.





4. Replacement for power IC.

Step 1 Follow the disassembly procedure described in item 1 on page 10.



Step 2 Cut the joints as shown below. (4 portions)



Step 3 Fold the joints. (4 portions)




Step 4 Remove the solder of power IC.




CAUTION

- After replacing the power IC, apply a sufficient quantity of compound grease (RFKX0002/SZZ0L15) between the heat sink and the power IC (Radiation of power IC).
- Tighten enough the screws (①~④) after replacing the power IC. Otherwise, the heat radiation works little.



Schematic Diagram • Main/Operation/Volume/Tone Amp. Circuit (Parts list on page 28~34.)



• Power Switch/Headphones Jack/Power Supply/Power Transformer Circuit

(Parts list on page 28~34.)

16

17

18

19

20

21

22

23

24

25

26

27

28

29

30


31

32

33

34

35



Notes:

- S1 : Power Standby \ominus /ON switch.
- S204: TONE control switch (ON/DEFET).
- S801: TAPE MONITOR switch.
- S802: Input selector switch (TAPE 1).
- S803: Input selector switch (TAPE 2/DCC).
- S804: Input selector switch (AUX).
- S805: Input selector switch (CD).
- S806: Input selector switch (TUNER).
- S807: Input selector switch (PHONO).
- S810: Speaker select switch (SPEAKER A).
- S811: Speaker select switch (SPEAKER B).

• Indicated voltage values are the standard values for the unit measured by the DC electronic circuit tester (high-impedance) with the chassis taken as standard. Therefore, there may exist some errors in the voltage values, depending on the internal impedance of the DC circuit tester.

• Important safety notice: No mark: Power ON

Components identified by Δ mark have special characteristics important for safety. Furthermore, special parts which have purposes of fire-retardant (resistors), high-quality sound (capacitors), low-noise (resistors), etc. are used. When replacing any of components, be sure to use only manufacturer's specified parts shown in the parts list.

• This schematic diagram may be modified at any time with the development of new technology.

• Caution!

IC and LSI are sensitive to static electricity. Secondary trouble can be prevented by taking care during repair. Cover the parts boxes made of plastics with aluminum foil. Ground the soldering iron. Put a conductive mat on the work table. Do not touch the legs of IC or LSI with the fingers directly.

• Voltage and signal line







- : Positive voltage line.
- : Negative voltage line.
- : Phono signal line.
- : Recording output signal line.

• The supply part number is described alone in the replacement parts list.

Part No.	Production Part No.	Supply Part No.
Z801	RCDHC-237-E	RCDHC-237

■ Printed Circuit Board Diagram


• This circuit board diagram may be modified at any time with the development of new technology.




• Terminal guide of IC's, transistors and diodes

M5218AP	AN8558-FSG	UPC4570C AN7062N NJU7312AL	TC74HC42AP MS7470M22S2S
BA6218	RSN6000A SVI3205B	MN1381STA	2SA933QRSTA 2SA992EPFTA 2SA1123RSTTA 2S3621A-R 2SC2631RSTTA 2SD592ANCQ
2SA1309A-R 2SC3311A-Q UN421FTA UN4111 UN4211	2SD2037DEFTA	MA165 MA167 MA29WA MA700 1SS291TA 1SP35200TB	2SK301QRS P300D5002T
MA4036MTA MA4056MTA MA4068L MA4082MTA	MA4160M MA4120 MA4270	LN014304P LN018304P	
		Anode Cathode A Cathode Anode Cathode A Cathode Anode Cathode A Cathode	

■ Wiring Connection Diagram



■ Block Diagram



■ Function of IC Terminals

IC801 (M37470M2232S)

Pin No.	Terminal Name	I/O	Function
1	P17/SRDY	O	Relay (Power SW) drive signal output.
2	P16/CLK	O	Remote control signal output.
3	P15/SOUT	O	LED (TAPE 1) drive signal output.
4	P14/SIN	O	LED (TAPE 2) drive signal output.
5	P13/TI	O	LED (SOURCE) drive signal output.
6	P12/TO	O	Input select LED drive signal output.
7	P11	O	
8	P10	O	
9	P23/IN3	O	Motor (volume control) drive signal output.
10	P22/IN2		Switch (POWER, SPEAKER A, SPEAKER B) signal input.
11	P21/IN1	I	
12	P20/INO	I	
13	VREF	I	Reference voltage input.
14	XIN	I	Oscillator signal I/O terminal. (4 MHz)
15	XOUT	O	
16	VSS	—	GND terminal.
17	VCC	I	Power supply (+5V).

Pin No.	Terminal Name	I/O	Function
18	RESET	I	System reset signal input.
19	P30/INTO	I	Back-up detect signal input.
20	P31/INTI	I	Remote control receive signal input.
21	P32/CNRO	I	Power SW signal input.
22	P33/CNRI	—	No used. Connected to GND.
23	P40	O	Strobe signal input for Input Selector IC (IC201).
24	P41	O	Clock signal input for Input Selector IC (IC201).
25	P00	O	Data signal input for Input Selector IC (IC201).
26	P01	O	SPEAKER A select signal output.
27	P02	O	SPEAKER B select signal output.
28	P03	O	Selector Relay drive signal output.
29	P04	O	
30	P05	O	
31	P06	O	
32	P07	O	Audio muting control signal output.

■ Replacement Parts List

Notes: *Important safety notice:
Components identified by Δ mark have special characteristics important for safety.
Furthermore, special parts which have purposes of fire-retardant (resistors), high-quality sound (capacitors), low-noise (resistors), etc. are used.
When replacing any of components, be sure to use only manufacturer's specified parts shown in the parts list.
*The parenthesized indications in the Remarks columns specify the areas. (Refer to the cover page for area.)
Parts without these indications can be used for all areas.
*Remote Control Ass'y: Supply period for three years from termination of production.
*The "(SF)" mark denotes the standard part.

Ref. No.	Part No.	Part Name & Description	Remarks
		INTEGRATED CIRCUIT(S)	
IC101	AN6558-FSG	I. C. PHONO EQ AMP.	
IC201	NJU7312AL	I. C. INPUT SELECTOR	
IC251	BA6218	I. C. VOLUME MOTOR DRIVE	
IC301	UPC4570C	I. C. TONE AMP.	
IC401	AN7062N	I. C. VOLTAGE AMP.	
IC501	SV13205B	I. C. POWER AMP.	Δ
IC502	RSN000A	I. C. V-AMP.	
IC608	M5218AP	I. C. FUN MOTOR DRIVE	(EB, EO)
IC801	M37470M2232S	I. C. MICRO COMPUTER	
IC802	MN1381STA	I. C. RESET	
IC803	TC74HC42AP	I. C. LED DRIVE	
		TRANSISTOR(S)	
Q401, 402	2SA1123RSTA	TRANSISTOR	
Q451, 452	2SC2631RSTA	TRANSISTOR	
Q453, 454	2SC3311A-Q	TRANSISTOR	
Q455, 456	2SA1309A-R	TRANSISTOR	
Q501-503	2SA992EFPTA	TRANSISTOR	
Q601	2SD592ANQ	TRANSISTOR	(EB, EO)
Q605, 606	2SC3311A-Q	TRANSISTOR	(EB, EO)
Q607	UN4111	TRANSISTOR	(EB, EO)
Q608	UN4211	TRANSISTOR	(EB, EO)
Q610	2SC3311A-Q	TRANSISTOR	
Q611	UN421FTA	TRANSISTOR	
Q701	2SB621A-R	TRANSISTOR	
Q801-804	UN4111	TRANSISTOR	
Q806-809	UN4211	TRANSISTOR	
Q811, 812	UN4211	TRANSISTOR	
Q813, 814	UN4111	TRANSISTOR	
Q815, 816	UN4211	TRANSISTOR	
Q817	2SC3311A-Q	TRANSISTOR	
Q818	2SD2037DEFTA	TRANSISTOR	Δ
Q819-821	UN4211	TRANSISTOR	
Q822, 823	UN4111	TRANSISTOR	
Q824, 825	2SK301QRS	TRANSISTOR	
Q826	2SA933QRSTA	TRANSISTOR	
Q827	2SC3311A-Q	TRANSISTOR	
Q828	UN4111	TRANSISTOR	
		DIODE(S)	
D401, 402	MA167	DIODE	
		VARIABLE RESISTOR(S)	
VR201	RRV16B03B15A	V. R. MAIN VOLUME	
VR202	EVJ02QF04G15	V. R. BALANCE	
VR301	EVJY1F04C15	V. R. BASS	
VR302	EVJY1F04C15	V. R. TREBLE	
		THERMISTOR(S)	
TH201, 202	ERTD2ZHL104T	THERMISTOR	

Ref. No.	Part No.	Part Name & Description	Remarks	Ref. No.	Part No.	Part Name & Description	Remarks
		COMPONENT COMBINATION(S)		CP301, 302	RJT003K008-1	CONNECTOR(8P)	
				CP401	RJT057W007 1	CONNECTOR(7P)	
2801	RCDHC-237	REMOTE SENSOR		CP801, 802	RJT003K008 1	CONNECTOR(8P)	
		COIL(S)				EARTH TERMINAL	
L1	RLQZ271M	COIL	△	E501	SNE1004-2	GND PLATE	
L251, 252	ELEXT1ROKA9	COIL		E701	SNE1004-2	GND PLATE	
L501-504	SLQY18G-10	COIL					
L551	ELEPK2R2MA	COIL				FUSE	
L801	ELEXT101KA9	COIL		FC1, 2	EYF52BC	FUSE HOLDER	
		TRANSFORMER(S)				RELAY(S)	
T1	RTP7K5B005-W	POWER TRANSFORMER	△(EB)	RL201-204	RSY0020M-R	RELAY	
T1	RTP7K5E009-W	POWER TRANSFORMER	△(E, EG, EO)	RL501, 502	RSY0013M-0	RELAY	△
		OSCILLATOR(S)		RL503	RSY0020M-R	RELAY	
X801	EF0GC4004A4	OSCILLATOR(4MHz)		RL701, 702	RSY0012M-0	RELAY	△
		FUSE(S)				JACK(S)	
F1	XBA2C20TB0	FUSE, 250V, 2A	△	JK1	SJS9236	AC INLET	△
		SWITCH(ES)		JK201	SJF3069N	INPUT TERMINAL (PHONO/TUNER)	
S1	EVQ21405R	SW, POWER		JK202	SJF3069N	INPUT TERMINAL (CD/AUX)	
S204	ESB68046	SW, TONE CONTROL		JK203	SJF3069N	IN/OUTPUT TERMINAL	
S801	EVQ21405R	SW, TAPE MONITOR		JK204	SJF3069N	IN/OUTPUT TERMINAL	
S802	EVQ21405R	SW, TAPE 1		JK501	RJH4801M-2	SPEAKERS TERMINAL	(EB)
S803	EVQ21405R	SW, TAPE 2/DCC		JK501	RJH4801M-1	SPEAKERS TERMINAL	(E, EG, EO)
S804	EVQ21405R	SW, AUX		JK502	RJJ63TA01	HEADPHONE JACK	
S805	EVQ21405R	SW, CD		JK801	RJJ33TR01	REMOTE CONTROL JACK	
S806	EVQ21405R	SW, TUNER					
S807	EVQ21405R	SW, PHONO					
S810	EVQ21405R	SW, SPEAKER A					
S811	EVQ21405R	SW, SPEAKER B					
		CONNECTOR(S)					
CN201	RJU003K010M1	SOCKET(10P)					
CN202	RJU003K008M1	SOCKET(8P)					
CN301, 302	RJU003K008M1	SOCKET(8P)					
CN401	RJT057W007	SOCKET(7P)					
CN601	SJT3213	CONNECTOR(2P)	(EB, EO)				
CN703-710	RJS1AI101T1	SOCKET(1P)					
CN801, 802	RJU003K008M1	SOCKET(8P)					
CN702A	RJS1A6604	CONNECTOR(4P)					
CN702B	RJS1A6603	CONNECTOR(3P)					
CP201	RJT003K010-1	CONNECTOR(10P)					
CP202	RJT003K008-1	CONNECTOR(8P)					

Ref. No.	Part No.	Part Name & Description	Remarks
		CABINET PARTS	
1	RKM0114B-K	CABINET	(EB, EO)
1	RKM0114A-K	CABINET	(E, EG)
2	RHD30035-K1	SCREW	
3	XTBS3+8JFZ1	SCREW	
4	RGK0550-T	ORNAMENT RUBBER	
5	RGR0170A-CB	REAR PANEL	(E, EG)
5	RGR0170H-BB	REAR PANEL	(EO)
5	RGR0170B-BB	REAR PANEL	(EB)
6	RGD0202-K	KNOB, VOLUME	
7	RGD0177A-K	KNOB, TONE	
8	RKA0053-A	FOOT	
9	RKU0049-K	CHASSIS BASE	
10	RMK0202-2	BOTTOM CHASSIS	
11	RSC0105-2	SHIELD PLATE (PHONO)	
15	RFKGA700MKEB	FRONT PANEL ASS'Y	
16	RGK0549-S	ORNAMENT RING	
17	RGL0184-Q1	PANEL LIGHT (A)	
18	RGL0185-Q	PANEL LIGHT (B)	
19	RGL0186-Q	PANEL LIGHT (C)	
20	RGL0187-Q	PANEL LIGHT (D)	
21	RGL0188-Q	PANEL LIGHT (E)	
22	RGU0886A-K	BUTTON, SELECT	
23	RGU0887-K	BUTTON, SPEAKER	
24	RGU0888-K	BUTTON, TAPE MONITOR	
25	RGU0889-K	BUTTON, TONE	
26	RGU1042-K	BUTTON, POWER	
27	RHN90001	NUT	
28	RSC0323	SHIELD PLATE (VOLUME)	
29	XTBS26+8J	SCREW	
30	XTWS3+10T	SCREW	
31	RKQ0089	P. C. B. SUPPORT	
32	SHR8006	SPACER	
33	SNE2123	GND SCREW	
34	XTBS3+8JFZ1	SCREW	
35	XTB3+10G	SCREW	
36	XTB3+16CFN	SCREW	
37	XTB3+20JFZ	SCREW	
38	XTB3+8JFZ	SCREW	
39	XTW3+15T	SCREW	
40	REM0040	FAN MOTOR	(EB, EO)
41	RWJ3907290QQ	FLAT CABLE (7P)	
43	RWZ120UNW240	TUBE	

■ Cabinet Parts Location

