

# Service Manual


Computer Drive New Class A  
Stereo Integrated Amplifier

Amplifier

## SU-V10X

Color

(K).....Black Type



Color	Areas
(K)	[D].....Scandinavia
(K)	[EF].....France
(K)	[Ei].....Italy
(K)	[EW].....Switzerland
(K)	[EK].....United Kingdom
(K)	[EH].....Holland
(K)	[EGA].....F. R. Germany
(K)	[EB].....Belgium
(K)	[XA].....Southeast, Asia, Oceania, Africa, Middle Near East and Central South America
(K)	[XL].....Australia

## SPECIFICATIONS

(DIN 45 500)

### ■ MAIN AMPLIFIER SECTION

(Input Signal: EXT. INPUT)

1 kHz continuous power output both channels driven	2 × 120W (4Ω) 2 × 120W (8Ω)
40 Hz~16 kHz continuous power output both channels driven	2 × 120W (4Ω) 2 × 120W (8Ω)
20 Hz~20 kHz continuous power output both channels driven	2 × 120W (4Ω) 2 × 120W (8Ω)
Total harmonic distortion	
rated power at 20 Hz~20 kHz	0.007% (4Ω) 0.003% (8Ω)
rated power at 40 Hz~16 kHz	0.007% (4Ω) 0.003% (8Ω)
rated power at 1 kHz	0.0015% (4Ω) 0.001% (8Ω)
half power at 20 Hz~20 kHz	0.002% (8Ω)
half power at 1 kHz	0.001% (8Ω)
Intermodulation distortion	
rated power at 250 Hz: 8 kHz=4:1, 8Ω	0.01%
rated power at 60 Hz: 7 kHz=4:1, SMPTE, 8Ω	0.007%
Power bandwidth	
both channels driven, -3 dB	5 Hz~70 kHz (4Ω, 0.03%) 5 Hz~70 kHz (8Ω, 0.02%)
Residual hum and noise	0.5 mV
Damping factor	40 (4Ω), 80 (8Ω)
Headphones output level and impedance	740 mV/330Ω
Load impedance	
MAIN or REMOTE	4Ω~16Ω
MAIN and REMOTE	8Ω~16Ω

### ■ PRE AMPLIFIER SECTION

Input sensitivity and impedance

PHONO MM	2.5 mV/47kΩ
MC	170 μV/220Ω
TUNER, CD, TV/AUX 1, VIDEO/AUX 2, TAPE 1/DA TAPE, TAPE 2/VCR	150 mV/18kΩ
PHONO maximum input voltage (1 kHz, RMS)	
MM	170 mV
MC	12 mV
S/N	
rated power (4Ω)	
PHONO MM	79 dB (IHF, A: 90 dB)
MC	72 dB (IHF, A: 72 dB (250 μV))
TUNER, CD, TV/AUX 1, VIDEO/AUX 2, TAPE 1/DA TAPE, TAPE 2/VCR	98 dB (IHF, A: 110 dB)

Frequency response

PHONO	RIAA standard curve ±0.2 dB (30 Hz~15 kHz)
TUNER, CD, TV/AUX 1, VIDEO/AUX 2, TAPE 1/DA TAPE, TAPE 2/VCR	-3 dB (2 Hz~140 kHz) +0 dB, -0.1 dB (20 Hz~20 kHz)

Tone controls

BASS	50 Hz, +10 dB~-10 dB
TREBLE	20 kHz, +10 dB~-10 dB

Turnover frequency

BASS	125 Hz, 250 Hz, 500 Hz
TREBLE	2 kHz, 4 kHz, 8 kHz
Muting	-20 dB

Subsonic filter

Loudness control (volume at -30 dB)	20 Hz, -6 dB/oct.
-------------------------------------	-------------------

Output voltage and impedance

TAPE 1, 2, REC OUT	150 mV
Channel balance, CD, AUX 1, 2	250 Hz~6,300 Hz ±1 dB
Channel separation, CD, AUX 1, 2	1 kHz 55 dB

# Technics

Matsushita Electric Trading Co., Ltd.

P.O. Box 288, Central Osaka Japan

## VIDEO SECTION

(TV/AUX 1, VIDEO/AUX 2, TAPE 2/VCR)

Output voltage (at 1V input 75 ohms unbalanced)  $1 \pm 0.1$  Vp-p  
 Maximum input voltage 1.5 Vp-p  
 Input/output impedance 75 ohms unbalanced

### Notes:

- Total harmonic distortion is measured by the digital spectrum analyzer (H.P. 3045 system).

## CONTENTS

	Page
SAFETY PRECAUTION .....	2
LOCATION OF CONTROL .....	3, 4
VOICE AND VIDEO SIGNAL TERMINAL .....	4
OPERATION .....	5
RECORDING .....	6, 7
PROTECTION CIRCUITRY .....	7
BEFORE REPAIR AND ADJUSTMENT .....	7
DISASSEMBLY INSTRUCTIONS .....	7~10
FUNCTION OF TERMINAL (IC801: MN1421STA) .....	10, 11
FUNCTION OF TERMINAL (IC251: $\mu$ PD7506C043) .....	11, 12

## GENERAL

Power consumption 670W  
 Power supply AC 50 Hz/60 Hz, 110V/127V/220V/240V  
 Dimensions (W×H×D) 430 × 147 × 392 mm  
 (16-15/16" × 5-25/32" × 15-13/32")  
 Weight 13.5 kg  
 (29.8 lb.)

- Specifications are subject to change without notice. Weight and dimensions shown are approximate.

	Page
TERMINAL GUIDE OF TRANSISTORS, DIODES AND IC'S .....	12
HOW TO REPLACE IC'S (Small outline type) .....	13
WIRING CONNECTION DIAGRAM .....	14 ~ 16
PRINTED CIRCUIT BOARDS .....	17 ~ 22
MEASUREMENT AND ADJUSTMENTS .....	23
BLOCK DIAGRAM .....	24, 25
SCHEMATIC DIAGRAM .....	26 ~ 33
CIRCUITS TO BE CHANGED AND THE AREAS .....	34
REPLACEMENT PARTS LIST .....	35, 36
EXPLODED VIEW .....	37, 38

## SAFETY PRECAUTION


(thes "safety precaution" is applied only in U.S.A.)

1. Before servicing, unplug the power cord to prevent an electric shock.
2. When replacing parts, use only manufacturer's recommended components for safety.
3. Check the condition of the power cord. Replace if wear or damage is evident.
4. After servicing, be sure to restore the lead dress, insulation barriers, insulation papers, shields, etc.
5. Before returning the serviced equipment to the customer, be sure to make the following insulation resistance test to prevent the customer from being exposed to a shock hazard.


### INSULATION RESISTANCE TEST

1. Unplug the power cord and short the two prongs of the plug with a jumper wire.
2. Turn on the power switch.
3. Measure the resistance value with ohmmeter between the jumpered AC plug and each exposed metal cabinet part, such as screwheads antenna, control shafts, handle brackets, etc. Equipment with antenna terminals should read between  $3M\Omega$  and  $5.2M\Omega$  to all exposed parts. (Fig. A) Equipment without antenna terminals should read approximately infinity to all exposed parts. (Fig. B)

**Note:** Some exposed parts may be isolated from the chassis by design. These will read infinity.




(Fig. A)  
Resistance =  $3M\Omega - 5.2M\Omega$



(Fig. B)  
Resistance = Approx  $\infty$


4. If the measurement is outside the specified limits, there is a possibility of a shock hazard. The equipment should be repaired and rechecked before it is returned to the customer.

# LOCATION OF CONTROLS



**1** When the power is switched ON, this indicator flashes for about 5 seconds, and then illuminates steadily when the unit is in the operation condition.  
 If an abnormal condition in the circuitry is detected, such as DC voltage appearing in the output, or a short-circuit of the positive (+) and negative (-) wires from the speaker terminals, the protection circuit functions and this indicator flashes rapidly. If this occurs, switch the power OFF, find the cause of the trouble and correct it, and then switch the power ON once again.

**2** These selectors are used to select the range within which changes of tone control characteristics occur.



**3** This switch is used to switch the tone control circuit (bass, treble) ON or OFF.  
**defeat:** Set to this position to switch the bass/ treble tone control circuit OFF. Regardless of the positions of the tone controls, the characteristics will remain flat.  
**tone on:** Set to this position for adjustment of the tone quality with the tone controls.

**4** This button can be used to switch the mode to the source to be heard (or watched) as selected by one of the source selectors, or to the source to be recorded.  
 When this button is pressed, the recording-mode indicator flashes, and, when one of the source selectors is pressed, the indicator illuminates steadily. If the indicator flashes, the flashing can be stopped by pressing this button once again.

**When the recording-mode indicator is not illuminated:**  
 If one of the source selectors is pressed, the program source to be heard or watched and the recording source will both be switched at the same time.


Note, however, that only the program source to be heard or watched will be switched, and the tape can be monitored during recording, if the "tape 1/DA tape" or "tape 2/VCR" source selector is pressed.

**When the recording-mode indicator is flashing:**  
 This is the mode for selection of the source you want to record. If one of the source selectors is pressed, only the recording program source will be switched.

**When the recording-mode indicator is illuminated:**  
 This is the mode for listening to (or watching) one source while recording another source. If one of the source selectors is pressed, only the program source to be heard or watched will be switched.

**5** These buttons have two functions:  
 When the recording-mode indicator is not flashing or not illuminated, these buttons are used to select the program source to be heard or watched. (The signal is available at the speaker terminals and headphones jack.)  
 When the recording-mode indicator is flashing, these buttons are used to select the program source to be recorded. (The signal is available at the REC OUT terminals.)

# SU-V10X



★ [EGA] area is provided without voltage selector.  
 ★ Phono input capacitance it adout 150pF.


※ If only the main or the remote speaker system is used (4~16Ω):

- 4~6Ω (■ — ■):  
For speaker impedance of 4~6Ω.
- 8~16Ω (■ — ■):  
For speaker impedance of 8~16Ω.

■ If both the main and remote speaker systems (8~16Ω each speaker) are used:

- 1) If the impedance of both systems is 16 ohms, set the speaker impedance selector to "16Ω".
- 2) If the impedance of both systems is 8 ohms, or one is 8 ohms and the other is 16 ohms, set the speaker impedance selector to "8Ω".


## ■ VOICE AND VIDEO SIGNAL TERMINAL



**OPERATION**

**Standard operating procedures**

- 1 Power: "on" (I → II)**  
Be sure to reduce the volume level to a low ("∞ → 60") position before switching ON the power.
- 2 Select the speaker systems to be used.**  
If sound from speakers is not wanted, set the speaker selectors to the "off" position.  
Headphones (option) **Note:** Set volume control to the minimum ("∞") position before connecting headphones.  
Plug type: 1/4-inch phone plug, stereo type




- 3 Select the program source.**  
(The picture and sound can be switched at the same time.)  
**tape 1/DA tape:**  
Press this button to listen to a tape or a digital-audio processor.  
**tape 2/VCR:**  
Set to this position for playback from a VCR or tape deck.  
**aux 1/TV:**  
Press this button to watch a TV.  
**aux 2/video:**  
Press this button to watch a video disc player, etc., is connected to the "VIDEO/AUX 2" terminals (on the front or rear panel).  
**CD:**  
Press this button to listen to a compact-disc.  
**tuner:**  
Press this button to listen to radio broadcasts.  
**phono:**  
Press this button to listen to phono discs.

- 4 Operate each component.**  
(Refer to the operating instructions for the other equipment used.)

- 5 Adjust the volume level and the tone quality.**

**After disc play or radio broadcast, etc. has started**

- Adjust left/right volume balance.
- Press inward to the "20 Hz" position to eliminate ultra-low-frequency noise (turntable motor "rumble", etc.).
- Press inward to the "on" position when listening to music at a low volume level (for compensation of the bass range).
- Press inward to the "mono" position to listen to sound monaurally (when adjusting left/right volume balance, etc.).
- Press inward to the "-20 dB" position to temporarily reduce the volume level or for more precise control of the volume level.
- Adjust the tone quality as desired.**
- Select either "MM" or "MC" when listening to phono discs.**
- "tone on"**  
If set to the "defeat" position, tone controls have no effect, and frequency response becomes flat.
- Select the tone range.**
- Adjust the tone quality.**



**Suggestions**


- If noise is very annoying while listening to an FM or AM broadcast, switch OFF the TV, compact-disc player and turntable.
- Switch OFF the TV power if noise is excessive while listening to an audio tape, compact disc or regular phono disc.
- If a striped pattern appears and makes viewing difficult, switch OFF the digital audio processor.

**After use**

After listening is finished, power switches of all equipment should be switched OFF.

**RECORDING**

With this unit, you can record an FM broadcast, etc. while watching TV, or record one sound source while listening to another. In addition, the "aux 2/video" terminals on the front panel can be used for easy audio or video tape editing.



**1 Power: "on" (I→II)**  
Be sure to reduce the volume level to a low ("∞→60") position switching ON the power.

**2 Select the speaker systems to be used.**

●Recording-mode selector

**3 Press.**  
The recording mode indicator will flash. (Refer to note 1.)

**4 Select the desired program source for recording.**  
(The recording mode indicator and recording output signal indicator will illuminate.)

●Press this button in order to record from a tape deck connected to the "TAPE 1/DA TAPE" terminals to a tape deck connected to the "TAPE 2/VCR" terminals.

●Press this button in order to record from a tape deck connected to the "TAPE 2/VCR" terminals to a tape deck connected to the "TAPE 1/DA TAPE" terminals.

**6 Set to the position corresponding to the program source to be heard.**  
(One of the input signal indicators will illuminate.)

- if the program source being recorded is selected:  
The sound going to the tape deck will be heard.
  - if the tape deck making the recording is selected:  
The sound going through the tape deck will be heard.
  - if some other sound source is selected:  
The sound of the selected source can be heard. (This will not effect the recording which is being made.)
- To record one program source and listen to another:**  
Follow steps 3 through 6.

**5 Begin recording.**  
By using the controls on the tape deck, adjust the recording level. Then begin recording.


**Tape-to-tape recording of video tapes**

A copy of a video tape can be made by connecting a video deck for playback to the "aux 2/video" terminals on the front panel.

**Note:**  
Follow these steps in addition to step 4 above.

- 1** Connect the VCR to be used for playback to the "aux 2/video" terminals on the front panel.

- Notes:**
1. While a recording is in progress:  
Do not press the recording-mode selector, because the recording will be interrupted and the recording source will be changed.
  2. For timer recordings:  
Be sure to check that the recording-mode indicator is illuminated steadily (not flashing).  
Note that the recording might not be made if the recording-mode indicator is flashing.



● Placement on top of other equipment

To accommodate equipment of different depths, use the additional feet (included) to support this unit.

Bottom of this unit    ↓    Rear



● If a TV is connected to this unit

● If speakers are placed near the television

Move the speakers away from the TV to a position where the picture is improved if the TV's picture color changes or distortion appears on the TV screen.

(This is not necessary, however, for shielded speakers.)

● If a turntable is placed near the TV

Place it on the right side of the TV.

TV magnetism might otherwise affect the record player's cartridge performance, causing interference noise.

■ PROTECTION CIRCUITRY

The protection circuitry may have operated if either of the following conditions is noticed:

- No sound is heard when the power is switched ON.
- Sound stops during a performance.

The function of this circuitry is to prevent circuitry damage if, for example, the positive and negative speaker connection wires are "shorted", or if speaker systems with an impedance less than the indicated rated impedance of this unit are used.

If this occurs, follow the procedure outlined below:

1. Switch OFF the power.
2. Determine the cause of the problem and correct it.
3. Switch ON the power once again.

**Note:**

When the protection circuitry functions, the unit will not operate unless the power is first switched OFF and then ON again.


■ BEFORE REPAIR AND ADJUSTMENT






- (1) Turn off the power supply. Using a 10Ω, 5W resistor, shortcircuit both ends of power supply capacitors(C901~ 904, 10000μF) in order to discharge the voltage.
- (2) Before turning the power supply on, after completion of repair, slowly apply the primary voltage by using a power supply voltage controller to make sure that the consumed current at 50/60 Hz in NO SIGNAL mode should be shown below with respect to supply voltage 110V/127V/220V/240V.

Power supply voltage		AC110V	AC127V	AC220V	AC240V
Consumed current	50/60Hz	270 ~ 730mA	250 ~ 670mA	135 ~ 370mA	125 ~ 340mA

■ DISASSEMBLY INSTRUCTIONS

Ref. No. 1	How to remove the cabinet
Procedure 1	1. Remove the 7 screws (①~⑦)




<p><b>Ref. No.</b> 2</p>	<p><b>How to remove the front panel</b></p>	<p>2. Remove the front panel (refer to the arrow).</p>
<p><b>Procedure</b> 1 → 2</p>	<p>Remove the 5 screws (① ~ ⑤) and 4 nuts (⑥ ~ ⑨).</p>	
 <div data-bbox="1228 436 1492 851" style="border: 1px solid black; padding: 5px;"> <p><b>Note</b> Remove the flat cable</p>  <p>Pushing the connector and extract the flat cable</p> </div>		
<p><b>Ref. No.</b> 3</p>	<p><b>How to remove the sub panel</b></p>	
<p><b>Procedure</b> 1 → 2 → 3</p>	<p>1. Push down the 10 tabs (up side) and Push up the (under side) of sub panel.</p>	
		
<p><b>Ref. No.</b> 4</p>	<p><b>How to remove the AUX2/VIDEO P.C.B and speaker selector P.C.B</b></p>	<p>2. Pull the tab (up side) and 2 tabs (under side) of Speaker selector P.C.B.</p>
<p><b>Procedure</b> 2 → 3 → 4</p>	<p>1. Pull the 3 tabs (up side) and 4 tabs (under side) of AUX2/VIDEO Input P.C.B.</p>	
		



**Ref. No. 5**  
**How to remove the indicator panel**

**Procedure**  
1 → 2 → 3 → 4 → 5


1. Pull the 4 tabs of indicator panel.



**Ref. No. 6**  
**How to remove the selector button and selector P.C.B**

**Procedure**  
1 → 2 → 3 → 4 → 5 → 6


1. Remove the 3 screws ( ❶ ~ ❸ ) of selector button.  
2. Remove the 3 screws ( ❹ ~ ❻ ) of selector P.C.B.




**Ref. No. 7**  
**How to remove the bottom board**

**Procedure**  
7

1. Remove the 4 screws ( ❶ ~ ❹ ).




<b>Ref. No.</b> 8	<b>How to remove the power transistor</b>	2. Unsolder the power transistor. 3. Remove the 2 screws (④, ⑤) of heat sink.
<b>Procedure</b> 1 → 7 → 8	1. Remove the 2 screws (①, ②) of bracket and screw (③) of hold bracket.	



Labels: Hold bracket, Heat sink, Bracket, ①, ②, ③

➔



Labels: Silicone compound, Heat sink, Power transistor, (Red) (Inside) ④, (Red) ⑤, Heat sink

● When mounting the power transistor, apply silicone compound (SZZ0L15) to the rear side of power transistor.

## ■ FUNCTION OF TERMINAL (I<sub>CC</sub> Controller IC801 : MN1421STA)


Pin No.	Mark	Name of block	Description of terminal
1	V <sub>SS</sub>	Power supply input terminal	Ground
2	CO <sub>9</sub>	Output	It delivers I <sub>CC</sub> control signal through input port A (⑨) (thermal sensor) and input port B (⑪, ⑫) (signal sensor). [Output "H"]
3	CO <sub>8</sub>		
4	CO <sub>7</sub>		
5	CO <sub>6</sub>		
6	CO <sub>5</sub>		
7	AI <sub>3</sub>		
8	AI <sub>2</sub>		
9	AI <sub>1</sub>	Input	When 60°C (140°F) sensor of power amplifier operates, the input level becomes "L".
10	AI <sub>0</sub>	—	Ground
11	BI <sub>3</sub>	Input	Input level changes to "L" as effective output 2V signal sensor of power amplifier operates.
12	BI <sub>2</sub>		Input level changes to "L" as effective output 5V signal sensor of power amplifier operates.
13	BI <sub>1</sub>	—	—
14	BI <sub>0</sub>	—	—
15	EO <sub>0</sub>	Output	Indicator "Computer drive auto operation" light up at "H" output.
16	EO <sub>1</sub>		
17	EO <sub>2</sub>		
18	EO <sub>3</sub>	Output	Indicator "Computer drive auto operation" light up at "H" output.
19	TST	Test input terminal	Terminal for testing LSI (Grounded)
20	RST	Reset input terminal	All outputs are cleared or reset with input at "L" (It is connected to power supply circuit)
21	SNS <sub>0</sub>	—	Not used in this unit
22	SNS <sub>1</sub>	Input	Input level changes to "H" as power amplifier output short-circuit operates.

Pin No.	Mark	Name of block	Description of terminal
23	PRE HEAT	—	No used
24	DO1	—	Ground
25	DO2	—	
26	DO3	Output	
27	VDD	Power supply input terminal	Apply 5V.
28	OSC	OSC input terminal	Clock signal (about 300 kHz) can be obtained by internal oscillation circuit.

### FUNCTION OF TERMINAL (Analog Function Control IC251 : $\mu$ PD7506C043)

Pin No.	Symbol	Input/Output	Active	Description of terminal
1	P43	—	—	Not used in this unit.
2	x 2	—	—	Not used in this unit.
3	P03/x 1	Input	—	It detects the level of pin ⑤. Push (once) the "rec selector"  Selection of input 4.3V selector 0V
4	P20/PSTB	Output	H	Clock output port for analog switch. Clock signal output to IC201 pin ⑮ and IC202 pin ⑮ during data transmission. [Refer to A]
5	P21/PTOUT	Output	H	Indicator "rec selector" light up at "H". Push (once) the "rec selector"  Selection of input 4.3V selector 0V
6	P22	Output	H	Data output for analog switch. Data signal output to IC201 pin ⑯ and IC202 pin ⑯. [Refer to A]
7	P23	Output	H	Strobe output port for analog switch. Strobe signal output to IC201 pin ⑬ and IC202 pin ⑬ during data transmission. [Refer to A]
8	P60	Output	H	Rec side indicator 3-bit output. Rec indicator drive signal output to IC253 pins ⑬ ~ ⑮. [Refer to E]
9	P61			
10	P62			
11	P63	Input	H	Stop mode sensing input. With high pulse signal input, the stop command is executed and the mode is shifted to standby.  4.4V 0V Power switch "OFF"
12	CL1	—	—	External clock oscillation frequency (400KHz) input port. [Refer to C]
13	CL2	—	—	Not used in this unit.
14	VDD	—	—	Power supply input terminal. (Apply 4.4V)
15	RESET	Input	H	Input terminal for reset signal. Power switch "ON" 4.3V 0V Power switch "OFF" 1V 0V
16	P10	Input	H	Input terminal for key return signal from external key matrix. [Refer to D]
17	P11			
18	P12			
19	P13			
20	P50			
21	P51	Output	H	Output terminal for key scan signal for external key matrix. (Output voltage is 4.3V)
22	P52			
23	P53	Output	H	Muting signal output during input switch or Rec switch operation. Push the each input selector or muting switch.  4.3V 0V
24	P00	Input	—	Mode shifting port. H = Function 1 mode L = Function 2 mode The input of this unit is "H" (4.9V) because the mode used is Function 1.
25	P40	Output	H	Input side indicator 3-bit output. Input indicator drive signal to IC254 pins ⑬ ~ ⑮. [Refer to E]
26	P41			
27	P42			
28	VSS	—	—	Ground terminal.

C IC251 ⑫ 2V DIV/1  $\mu$ SEC




- Push the rec selector switch. ("rec indicator" blinking)
- Push the each input selector switch.

B L = 0V, H = 4.3V

Pin No. of IC251	⑧	⑨	⑩
Input selector	L	H	L
phono	L	H	L
tuner	H	L	L
CD	L	H	L
video/aux	H	H	L
tape 2	H	L	H
tape 1/DA tape	L	L	H

D L = 0V, H = 4.3V

Pin No. of IC251	⑬	⑭	⑮	⑯
Input selector	L	L	L	H
phono	L	L	L	H
tuner	L	L	H	L
CD	L	H	L	L
video/aux	H	L	L	L
tape 2	L	L	H	L
tape 1/DA tape	L	L	L	H
rec selector	H	L	L	L



E

Pin No. of IC251	⑮	⑯	⑰
Input selector	L	L	L
phono	L	L	L
tuner	H	L	L
CD	L	H	L
video/aux	H	H	L
tape 2	H	L	H
tape 1/DA tape	L	L	H
rec selector	L	L	L
muting	L	4.3V 0V	L

### TERMINAL GUIDE OF TRANSISTORS, DIODES AND IC'S

<table border="1"> <tr><td>TC9163N</td><td>28 Pin</td></tr> <tr><td>TC9164N</td><td>28 Pin</td></tr> <tr><td>MN1421STA</td><td>28 Pin</td></tr> <tr><td><math>\mu</math>PD7506C043</td><td>28 Pin</td></tr> <tr><td>AN7062</td><td>18 Pin</td></tr> <tr><td>DN74LS145</td><td>16 Pin</td></tr> <tr><td>MN4069UB</td><td>14 Pin</td></tr> <tr><td><math>\mu</math>PD4066BC</td><td>14 Pin</td></tr> </table>	TC9163N	28 Pin	TC9164N	28 Pin	MN1421STA	28 Pin	$\mu$ PD7506C043	28 Pin	AN7062	18 Pin	DN74LS145	16 Pin	MN4069UB	14 Pin	$\mu$ PD4066BC	14 Pin			
TC9163N	28 Pin																		
TC9164N	28 Pin																		
MN1421STA	28 Pin																		
$\mu$ PD7506C043	28 Pin																		
AN7062	18 Pin																		
DN74LS145	16 Pin																		
MN4069UB	14 Pin																		
$\mu$ PD4066BC	14 Pin																		

## HOW TO REPLACE IC'S (Small outline type)

Replacing procedure		Cautions
1	Reduce the amount of solder on each pin of the integrated circuit by use of a solder sucker.	<ul style="list-style-type: none"> <li>● <b>Recommended tool</b> .....Special soldering iron *H605M and H-130. *H605E and H-130.</li> <li>● Do not touch the soldering iron to the area for a long time. It may otherwise cause removal of the print foil.</li> <li>● When shifting the pin upward, do the job quickly while the solder is melting. If the solder is hard, it may cause removal or breakage of the print foil.</li> <li>● When using a pencil type soldering iron.                             <ol style="list-style-type: none"> <li>1. Completely remove the solder from each IC pin by use of solder sucker.</li> <li>2. Raise each pin by means of an eyeleteer, hold the pliers then remove IC package from P.C.B.</li> </ol> </li> </ul>
2	Melt the solder on the pin (one electrode) with the soldering iron.	
3	While the solder is melting, shift the pin upward by the soldering iron to remove it from the foil.	
4	Remove each pin from the foil according to the above-mentioned procedure.	


\* **Special soldering iron**

(Refer to Technical Information, ORDER NO. GAD84125486T1)... For U.S.A. and Canada  
(Refer to Technical Information, ORDER NO. GAD84115476T8)... For others

● **H-605 Spot Heater (hot-air solder iron)**

This device that uses hot air to melt solder was developed to remove Flat-Package ICs, RHCs and chip parts.

- H-605M (For 120V power source)
- H-605E (For 200V/220V/240V power source)



● **H-617 Twin Nozzle (for spot heater)**

Special nozzle for the removal of RHCs and chip resistors.  
(Nozzle diameter : 1.0 mm x 2)

● **H-130 Slim Pencil Solder Iron**

An ultrasmall ceramic heater solder iron is extremely handy for soldering chip parts, RHCs, ICs, etc., to high-density circuit boards.


Features:

- Rated power: 100V, 15W
- Max. temp.: 400°C
- Heater: ceramic (long life)
- Insulation resistance: 100MΩ
- Length: 178 mm
- Weight: 16 g (not including cord)


● **H-131, H-V13 Cap Bits**

Solder tip for the slim pencil Solder Iron and is composed of a bit holder and a corrosion resistance solder tip. Permits changing of solder tips even while still hot.


- Solder tip: 0.3 mm



WIRING CONNECTION DIAGRAM




# SU-V10X




PRINTED CIRCUIT BOARDS


**N** SPEAKER SELECTOR P.C.B.






**K** (defect ind.) (tone on ind.)




**I**




**P** POWER P.C.B.




**B** AUDIO/VIDEO INPUT SELECTOR P.C.B.




**C** AUDIO/VIDEO INPUT LED P.C.B.



**M** RECTIFIER/POWER AMP/IC BIAS/REGULATOR/DC DET P.C.B.




**J** BALANCE/TREBLE, BASS P.C.B.









**E** AUX 2/VIDEO INPUT P.C.B.




TAPE1/DA TAPE  
(PLAYBACK) (REC OUT)




GRAPHIC EQ/EXT  
(OUT) (1N)




**F** AUDIO MUTING P.C.B.




**G** VOLUME P.C.B.



**H** REC MODE/LOUDNESS P.C.B.




GND PHONO TUNER CD VIDEO TV TAPE2/VTR  
(MM/MC) (REC OUT) (PLAYBACK)




**A** INPUT SELECTOR/REC(VIDEO)SELECTOR/MUTING /LED DRIVE P.C.B.


**Q** MPEDANC




**Q** IMPEDANCE SELECTOR P.C.B.




**R** TV/AUX1 INPUT FILTER P.C.B.



**U** FUSE P.C.B.



**S** VIDEO SIGNAL P.C.B.




## MEASUREMENT AND ADJUSTMENTS

### Control positions and equipment used

- Volume knob . . . . . ∞
- Main speaker selector . . . . . off
- Remote speaker selector . . . . . off
- Recording selector . . . . . aux 1/TV
- Speaker impedance swith. . . . . 16Ω
- AC and DC electronic voltmeter (EVM)
- Signal generator
- Resistor (0.33Ω)


### Idling (ICQ) Adjustment

1. Test equipment connection is shown in figure.
2. Turn the ICQ control volume (VR601, VR602) counter-clockwise.
3. After turning the power switch "on", adjust VR601 (left channel) and VR602 (right channel) about 20mV respectively as in Fig. 1.




### Overload detection circuit check

1. Test equipment connection is shown in figure
2. Apply 1 kHz, 8 mV (output about 5 V) signal to the aux. input terminal (aux 1/TV).
3. The speaker switch turned "off".
4. Connect 0.33 Ω (about 1 W) resistor to main speaker terminal.
5. With main speaker switch turned "on", make sure that
  - relay is "OFF" and
  - computer drive auto operation blinks.
6. Also check the right (R) channel in the same manner as mentioned above.




**(Note)** When turning the relay on again, wait for a while after turning the power supply OFF. Otherwise, it will not be reset even when the circuit and load are in normal conditions.





[Fig. 1]


### Adjustment points



■ BLOCK DIAGRAM



ICQ adjustment  
 VR602 (Rch)  
 VR601 (Lch)  
 ICQ adjustment




• Function of IC201 and IC202 by input selector position (off:-)

select	Sa	Sb	Sc	Sd	Se	Sf	Sg	Sh	Si	Sj	Sk	Sl	Sm	Sn	So
PHONO	on	-	-	-	on	-	-	on	-	-	-	-	-	-	-
TUNER	-	on	-	-	on	-	-	on	-	-	-	-	-	-	-
CD	-	-	on	-	on	-	-	on	-	-	-	-	-	-	-
AUX/TV	-	-	-	on	on	-	-	-	-	-	-	-	on	-	-
TAPE1/DAT	-	-	-	-	on	-	-	-	-	-	-	-	-	on	-
TAPE2/VCR	-	-	-	-	-	on	-	-	-	-	-	-	-	-	on
AUX2/VIDEO	-	-	-	-	-	-	on	on	-	-	-	-	-	-	on


IC201 TC9163N ANALOG FUNCTION SWITCH (INPUT)  
 IC202 TC9164N ANALOG FUNCTION SWITCH (REC)




1 2 3 4 5 6 7 8 9 10

A B C D E F










**K**

D576, 575  
LN846RP  
INDICATOR



**J**

Q501~504  
2SK170  
DIFFERENTIAL AMP

IC501  
M5219P  
TONE AMP

Treble control

Bass control

Treble control

Bass control


TONE CONTROL SWITCH/TURNOVER  
FREQUENCY SELECTOR CIRCUIT

BALANCE/TREBLE, BASS CONTROL

**M**

SYNCHRO BIAS/POWER AMPLIFIER CIRCUIT


Q607, 608 2SC3467 DRIVE  
Q611, 612 2SC3298A DRIVE  
Q617, 618 2SC3280 POWER  
Q615, 616 2SC3280 POWER



VOLTAGE AMPLIFIER

DC SERVO






### SCHEMATIC DIAGRAM

• The part No. of transistors, IC and diodes mentioned in the schematic diagram stand for production part No. Regarding the part No. with  $\star$  mark, the production part No. are different from the replacement part No. Therefore, when placing an order for replacement part, please use the part No. in the replacement parts list.

1. **S1:** Phono selection switch in "MM" position.  
MM  $\leftrightarrow$  MC
2. **S2:** AUX 2 / Video selection switch in "rear" position.  
front  $\leftrightarrow$  rear
3. **S3:** Muting switch in "off" position.  
off  $\leftrightarrow$  on (-20dB)
4. **S4:** Mode switch in "stereo" position.  
stereo  $\leftrightarrow$  mono
5. **S5:** Loudness switch in "off" position.  
off  $\leftrightarrow$  on
6. **S6:** Subsonic switch in "off" position.  
off  $\leftrightarrow$  -20Hz
7. **S7-1, 7-2:** Tone control switch in "on" position.  
tone on  $\leftrightarrow$  defeat
8. **S8:** Bass turnover switch in "500Hz" position.  
500Hz  $\leftrightarrow$  250Hz  $\leftrightarrow$  125Hz
9. **S9:** Treble turnover switch in "8kHz" position.  
8kHz  $\leftrightarrow$  4kHz  $\leftrightarrow$  2kHz
10. **S10-S17:** Input selection switch  
**S10:** Phono, **S11:** tuner, **S12:** CD,  
**S13:** AUX 2 / Video, **S14:** AUX 1 / TV,  
**S15:** TAPE 2 / VCR,  
**S16:** TAPE 1 / DA TAPE, **S17:** REC mode
11. **S18:** Main speaker switch in "on" position.  
on  $\leftrightarrow$  off
12. **S19:** Remote speaker switch in "off" position.  
on  $\leftrightarrow$  off
13. **S20:** Power switch in "on" position.
14. **S21:** Impedance selection switch in "4 ~ 6 $\Omega$  / 8 $\Omega$ " position.  
4 ~ 6 $\Omega$   $\leftrightarrow$  8 ~ 16 $\Omega$   
8 $\Omega$   $\leftrightarrow$  16 $\Omega$
15. **S22 (Except for [EGA]):** Voltage selector switch "220V" position.  
127  $\leftrightarrow$  110V  $\leftrightarrow$  220V  $\leftrightarrow$  240V
16. **S23:** TV/AUX 1 input filter switch in "on(TV)" position.  
off  $\leftrightarrow$  on(TV)
17. Indicated voltage values are the standard values for the unit measured by the DC electronic circuit tester (high-impedance) with the chassis taken as standard. Therefore, there may exist some errors in the voltage values, depending on the internal impedance of the DC circuit tester.
18.  $\text{---} \text{---} \text{---}$  Phono signal (Lch)
19.  $\text{---}$  Positive voltage lines or Negative voltage lines.
20. Important safety notice:  
Components identified by  $\Delta$  mark have special characteristics important for safety. When replacing any of these components use only manufacturer's specified parts.

CIRCUITS TO BE CHANGED AND THE AREA

[EGA] area



[XA] area




Table with 3 columns: Ref.No., Part No., Value. Lists components like C1, C3.4, C5.6, C101.102, etc.

Table with 3 columns: Ref.No., Part No., Value. Lists components like C213.214, C215.216, C217.218, etc.

REPLACEMENT PARTS LIST

- Notes: 1. Part numbers are indicated on most mechanical parts. Please use this part number for parts orders. 2. Important safety notice: Components identified by Δ mark have special characteristics important for safety. When replacing any of these components use only manufacturer's specified parts. 3. Bracketed indications in Ref. No. columns specify the area. Parts without these indications can be used for all areas. 4. The "S" mark is service standard parts and may differ from production parts. 5. The unit of resistance is OHM (Ω). K = 1000Ω, M = 1000KΩ. 6. The unit of capacitance is MICROFARAD (μF). P = 10^-6 μF. 7. The parenthesized numbers in the column of description stand for the quantity per set.

Table with 3 columns: Resistor Type, Wattage, Tolerance. Lists types like ERD: Carbon, ERG: Metal Oxide, ERC: Solid.

Table with 4 columns: Capacitor Type, Voltage, Tolerance. Lists types like ECEA, ECEA, ECKD, ECOM, etc.

RESISTORS AND CAPACITORS

Large table with 5 columns: Ref.No., Part No., Value. Lists various resistors and capacitors with their specifications.


Table with 3 columns: Ref.No., Part No., Description. Lists integrated circuits, transistors, diodes, and transformer components.


Table with 3 columns: Ref.No., Part No., Description. Lists crystal, variable resistors, component combinations, thermal detectors, lamps, fuses, switches, and cabinet/chassis parts.

**EXPLODED VIEW**

Part No.	Description	Ref. No.	Part No.	Description
<b>CRYSTAL</b>				
X251	SVFCSB400P-M Crystal			
<b>VARIABLE RESISTORS</b>				
VR351	EWJKA054B15 Volume, 100kΩ (B)	26	SKL295	Foot (4)
VR501	EWHPKA002G15 Balance, 100kΩ (G)	27	SHR9755	Holder (1)
VR502, 503	EWXEA000C15 Tone, 100kΩ (C)	28	SUWUV10X-KM	Bracket (1)
VR601, 602	EVNKGAA00B13 1CQ Adj, 1kΩ (B)	29	SUW2910-1	Bracket (1)
<b>COMPONENT COMBINATIONS</b>				
Z401	EXBP85223K 22kΩ	30	SML107-12	Bracket, Power Transformer (1)
Z601~604	ERF3GBKR22N 0.22Ω (×2)	31	SHG6355	Rubber, Power Transformer (2)
Z901	Δ SXRF5203ZSM 0.01μF (×2)	32	SUW2909	Bracket (1)
[EGA] except		33	SHG1635	Rubber (2)
<b>THERMISTERS</b>				
TH601, 602	ERTD2ZHL103S Thermistor, 10kΩ	34	SMM1953	Bracket (1)
<b>RELAY</b>				
RLY701	Δ SSY124 Speaker	35	SUW2915	Bracket (1)
<b>THERMAL DETECTOR</b>				
PS801	SRPBG47101 Posistor	36 [EX]	SHR129	Bushing, AC Cord (1)
<b>LAMP</b>				
PL801	XAMS12S500 Safety Ind.	36 [other]	SHR127	Bushing, AC Cord (1)
<b>FUSE</b>				
F1 [EK]	Δ XBA2C63T80 250V, T 6.3A	37 [EV, XA]	Δ SJA111	AC Cord (1)
F1 [EGA]	Δ XBA2C31T80 250V, T 3.15A	37 [EK]	Δ QFC1205M	AC Cord (1)
F1 [other]	Δ XBA2C63T80 250V, T 6.3A	37 [XL]	Δ RJA79ZA	AC Cord (1)
F2 [EK]	Δ XBA2C31T80 250V, T 3.15A	37 [other]	Δ SJA97	AC Cord (1)
F2 [EGA]	Δ XBA2C31T80 250V, T 3.15A	38 [XA]	Δ SJS601-3	AC Outlet (1)
except		only		
<b>SWITCHES</b>				
S1, 4~6	SSH486 Phono Selector, Mode, Loudness, Filter	39 [D]	SGP6390-7A	Rear Panel (1)
S2	SSH1183 Aux2	39 [EGA]	SGP6390-8A	Rear Panel (1)
S3	SSH1184 Muting	39 [XA]	SGP6390-9A	Rear Panel (1)
S7	SSH2090 Tone Control	39 [EK]	SGPUV10X-KK	Rear Panel (1)
S8, 9	SSR225 Turnover	39 [other]	SGPUV10X-KF	Rear Panel (1)
S10~17	SSG13 Frequency	40	SJF4817	Terminal Board, Speaker (1)
S18, 19	SSH2089 Input Selector	41	SJF3059N	Terminal Board (1)
S20 [EGA]	Δ ESB90227S Power Source	42	SJF3057N	Terminal Board (2)
S20 [other]	Δ SSH1109 Power Source	43	SJS104	Socket (5)
S21	Δ SSH1158 Impedance Selector	44	SJP9205-2	Pin (2)
S22 [EGA]	Δ ESE37262 Voltage seletor	45	SBC165	Button (1)
S22 [other]		46	SHR9766	Holder (1)
S23	RSS42A Filter	47	SHR9767	Holder (1)
<b>DIODES</b>				
1	SGE1729 Terminal Cover (1)	48	SUW2951	Bracket (1)
2	SGWUV10X-KM Front Panel Ass'y (1)	49	SHR401-1	Look Pin (1)
3	SGWUV10X-KM1 Indication Plate (1)	50	SMC1206	Shield Plate (1)
4	SDU270 Filter (1)	51	SUW2828	Bracket (1)
5	SBCUV10X-KM Button, Input Selector (1)	52	SUW2952	Bracket (1)
6	SUS782 Spring (1)	53	SHR401-1	Look Pin (4)
7	SBN1192 Knob, Volume (1)	<b>SCREWS, NUT and WASHERS</b>		
8	SGXUV10X-KN Sub panel Ass'y (1)	N1	XTB3+8JFZ	Tapping, ∅3×8 (7)
9	SGXUV10X-KN1 Sub panel Ass'y (1)	N2	XTB3+8GFZ	Tapping, ∅3×8 (6)
10	SBN1193 Knob, Balance (3)	N3	SNE4021	Nut (4)
11	SBC439-2 Button, Speaker (2)	N4	∅XSN3+6BVS	∅3×6 (12)
12	SJG63B Headphone Jack (1)	N5	∅XVA3BFZ	Washer, ∅3 (12)
13	SBC686 Button, Power Source (1)	N6	XTB3+8JFZ1	Tapping with Detent, ∅3×8 (15)
14	SMCIV10X-KM Shield Cover (1)	N7	SNE2095-5	Cabinet (6)
15	SDU268 Filter, Lamp (1)	N8	XTV3+8T	Tapping with Washer, ∅3×8 (10)
16	SMP388 Lamp Case (1)	N9	XTB3+8BFR1	Tapping with Detent, ∅3×8 (4)
17	SMP387-1 LED Case (1)	N10	XTV3+8TFR	Tapping with Washer, ∅3×8 (4)
18	SBC719-1 Button, Muting (7)	N11	XTV3+8TFZ	Tapping with Washer, ∅3×8 (2)
19	SJF3061-2N Terminal Board (1)	N12	SNE2117-1	Transistor (8)
20	SBC708 Button, Muting (1)	N13	XTB4+8F	Tapping, ∅4×8 (4)
21	SHR9756 Spacer (1)	N14	∅XSN3+6BVS	Tapping, ∅3×6 (4)
22	SBN1194 Knob (2)	N15	∅XVA3BFZ	Washer, ∅3 (4)
23 [EK]	SKCUV10X-KK Cabinet (1)	N16	SHW40L150	Washer (1)
23 [other]	SKCUV10X-KM Cabinet (1)	N17 [EGA]	XTB3+8JFZ1	Tapping with Detent, ∅3×8 (1)
24 [EGA]	SJT347 Fuse Holder (2)	N17 [other]	XTV3+8T	Tapping with Washer, ∅3×8 (1)
24 [other]	SJT347 Fuse Holder (4)			
25	SKU8990-5 Bottom Board (1)			

Ref. No.	Part No.	Description
<b>ACCESSORIES</b>		
A1 [XA]	SQF12429	Instruction Book (1)
A1 [EGA]	SQF12430	Instruction Book (1)
A1 [other]	SQF12428	Instruction Book (1)
A2	SKL281-1	Foot (2)
A3	SHW39K50	Washer (2)
A4	XTB3+14J	Tapping Screw, ∅3×14 (2)
A6 [XA] only	Δ SJP5213-1	Plug (1)
A7 [XA] only	Δ SJP5215	Plug (1)
<b>PACKING PARTS</b>		
P1 [EV, XA]	SPG5334	Carton Box (1)
P1 [EP]	SPG5337	Carton Box (1)
P1 [EK]	SPG5338	Carton Box (1)
P1 [other]	SPG5336	Carton Box (1)
P2 [EV, EK, XA]	SPS4553-1	Pad, Left (1)
P2 [other]	SPS4553-3	Pad, Left (1)
P3 [EV, EK, XA]	SPS4554-1	Pad, Right (1)
P3 [other]	SPS4554-3	Pad, Right (1)
P4	SPS4488	Pad, Upper (1)
P5	SPP730	Polyethylene Bag (1)





24	32	51	33	32	34	33	39	36	45	35	38	37	52	
18	30	31	46	29	26	27	28	46	42	41	40	43	44	53
25	26	26						26						