










## ■ REMOTE-CONTROL TRANSMITTER

•EUR64751 For (M) and (MC) areas



•EUR64752 For (M5) and (MC5) areas

**Power control button**

**Numeric buttons**


**Compact disc controls**

- ▶ play play button
- stop stop button
- disc disc button
- ◀◀- backward skip button
- ▶▶ forward skip button
- program/ continue program/ continue button

**VCR controls**

- ▶ play play button
- stop stop button

**VCR 1 selector button**



**Amplifier controls**

- muting button
- volume down button
- volume up button

**Function controls**

- tuner tuner button
- CD CD button
- TV TV button
- VCR VCR button

**Graphic equalizer controls**

- on/off on/off button
- preset preset button


**Cassette deck controls**


- stop stop button
- ▶ play play button







8 9 10 11 12 13 14 15 16 17 18 19 20 21








POWER AMP CIRCUIT



MOTOR DRIVE CIRCUIT











## ■ BLOCK DIAGRAM



## ■ EXPLODED VIEWS

SU-V98 SU-V98

### •CABINET PARTS



### •REMOTE CONTROL UNIT PARTS

