

COMPACT DISC PLAYER

CDX-520/CD-1050

SERVICE MANUAL

CDX-520/
CD-1050

IMPORTANT NOTICE

This manual has been provided for the use of authorized Yamaha Retailers and their service personnel. It has been assumed that basic service procedures inherent to the industry, and more specifically Yamaha Products, are already known and understood by the users, and have therefore not been restated.

WARNING: Failure to follow appropriate service and safety procedures when servicing this product may result in personal injury, destruction of expensive components and failure of the product to perform as specified. For these reasons, we advise all Yamaha product owners that all service required should be performed by an authorized Yamaha Retailer or the appointed service representative.

IMPORTANT: The presentation or sale of this manual to any individual or firm does not constitute authorization, certification or recognition of any applicable technical capabilities, or establish a principle-agent relationship of any form.

The data provided is believed to be accurate and applicable to the unit(s) indicated on the cover. The research, engineering, and service departments of Yamaha are continually striving to improve Yamaha products. Modifications are, therefore, inevitable and specifications are subject to change without notice or obligation to retrofit. Should any discrepancy appear to exist, please contact the distributor's Service Division.

WARNING: Static discharges can destroy expensive components. Discharge any static electricity your body may have accumulated by grounding yourself to the ground buss in the unit (heavy gauge black wires connect to this buss).

IMPORTANT: Turn the unit OFF during disassembly and parts replacement. Recheck all work before you apply power to the unit.

CONTENTS

TO SERVICE PERSONNEL	1/2
INTERLOCK OPERATION	3
PANELS & REMOTE CONTROL TRANSMITTER .	4
SPECIFICATIONS	5
INTERNAL VIEW	5
BLOCK DIAGRAM	6
DISASSEMBLY PROCEDURES	7/8
ADJUSTMENTS	9 ~ 19

IC DATA	19 ~ 26
TEST PROGRAM	27
DISPLAY DATA	28
INTERCONNECT WIRING DIAGRAM	29
PRINTED CIRCUIT BOARD	30 ~ 33
SCHEMATIC DIAGRAM	34
PS-CDX520 REMOTE CONTROL TRANSMITTER .	35
PARTS LIST	36 ~ 45

■ TO SERVICE PERSONNEL

1. Critical Components Information.

Components having special characteristics are marked and must be replaced with parts having specifications equal to those originally installed.


2. Leakage Current Measurement (For 120V Model Only).

When service has been completed, it is imperative that you verify that all exposed conductive surfaces are properly insulated from supply circuits.

- Meter impedance should be equivalent to 1500 ohm shunted by 0.15 μ F
- Leakage current must not exceed 0.5mA.
- Be sure to test for leakage with the AC plug in both polarities.

• POLARIZATION (U. C models)


This CD player product is equipped with a polarized alternating-current line plug (a plug having one blade wider than the other). This plug will fit into the power outlet only one way. This is a safety feature.



CAUTION — USE OF CONTROLS, ADJUSTMENTS, OR PERFORMANCE OF PROCEDURES OTHER THAN THOSE SPECIFIED HEREIN, MAY RESULT IN HAZARDOUS RADIATION EXPOSURE.

THE COMPACT DISC PLAYER SHOULD NOT BE ADJUSTED OR REPAIRED BY ANYONE EXCEPT PROPERLY QUALIFIED SERVICE PERSONNEL.

G. B models



English

- ① THIS LABEL IS ATTACHED AT THE PLACE ILLUSTRATED TO INFORM THAT THE APPARATUS CONTAINS A LASER COMPONENT.
- ② THIS LABEL IS ATTACHED IN THE POSITION SHOWN IN THE ILLUSTRATION TO WARN THAT ANY FURTHER PROCEDURE WILL BRING THE USER INTO EXPOSURE WITH THE LASER BEAM.
- ③ THE WARNING LABEL INFORMING OF RADIATION IS PLACED INSIDE THE UNIT AS SHOWN IN THE ILLUSTRATION, TO WARN AGAINST FURTHER MEASURES ON THE UNIT. THE EQUIPMENT CONTAINS A LASER COMPONENT RADIATING LASER RAYS EXCEEDING THE LIMIT OF LASER PRODUCTS OF CLASS 1.

CAUTION—USE OF CONTROLS, ADJUSTMENTS OR PERFORMANCE OF PROCEDURES OTHER THAN THOSE SPECIFIED HEREIN, MAY RESULT IN HAZARDOUS RADIATION EXPOSURE.

Swedish

- ① PÅSKRIFTEN SITTER PÅ APPARATEM SOM VISAS SOM EN UPPMANING OM ATT APPARATEN OMFATTAR EN INBYGGD LASERKOMPONENT.
- ② TEXTSKYLTEN FÖR LASERN ÄR PLACERAD PÅ APPARATEN SOM EN UPPMANING OM ATT APPARATEN INNEHÅLLER EN LASERKOMPONENT.
- ③ VARNINGSSKYLTEN FÖR STRÅLNING HAR PLACERATS I APPARATEN, SOM BILDEN VISAR, SOM EN VARNING OM YTTERLIGARE INGREPP I APPARATEN. MATERIELEN INNEHÅLLER EN LASERKOMPONENT SOM AVGER LASERSTRÅLNING ÖVERSTIGANDE GRÄNSEN FÖR LASERKLASS 1.

VARNING—INGREPP I APPARATEN BÖR ENDAST FÖRETAS AV FACKMAN MED KUNSKAP OM ATT RISK FÖRELIGGER FÖR RADIOAKTIV ATRÄLNING.

Danish

- ① DETTE MÆRKAT ER ANBRAGT SOM VIST I ILLUSTRATIONEN FOR AT ADVARE BRUGEREN OM AT APPARATET INDEHOLDER EN LASERKOMPONENT.
- ② DETTE MÆRKAT OM LASEREN ER ANBRAGT PÅ APPARATET SOM EN OPLYSNING OM AT APPARATET INDEHOLDER ET LASERKOMPONENT.
- ③ ADVARSELSKILTET OM STRÅLING ER PLACERET INDENI APPARATET, SOM VIST I ILLUSTRATIONEN, SOM EN ADVARSEL OM YDERLIGERE INDGREB I APPARATET. APPARATET INDEHOLDER ET LASERKOMPONENT SOM AVGIVER LASESTRÅLING DER OVERSTIGER GÆNSEVERDIEN FOR LASERKLASSE 1.

ADVARSEL! INDGREB BØR KUN FORETAGES AF EN FAGMAND DA DER ER RISIKO FOR RADIOAKTIV STRÅLING.

Finnish

- ③ "VAROITUS! LAITE SISÄLTÄÄ LASERDIODIN, JOKA LÄHETTÄÄ (NÄKYMÄTÖNTÄ) SILMILLE VAARALLISTA LASERSÄTEILYÄ:"

INTERLOCK OPERATION

The Digital Compact Disc Player reads the disc signals by laser beam detection. It must be avoided for the human body to be directly exposed to the laser beam. Human eyes are especially badly affected by the laser beam. This unit is therefore equipped with an interlock to prevent unnecessary laser output.


Laser output is controlled by the injection or cutoff of the constant voltage source to the laser diode at Pin 14 (LS) of IC113 (M50747), and also by Automatic Laser Power Control Circuit. When Pin 14 is in "H" (High) level, the laser emits the beam. When Pin 14 is in "L" (Low) level, the laser does not emit the beam.

Pin 14 is set in "H" level when the unit is loaded with the disc and it reads the index signals or when the unit is set in the play mode after that. When the unit reads the index signals and the following two conditions are met, the laser emits the beam.


- 1) When the Loading Limit Switch is set in "CL" side. (The disc tray is closed.)
- 2) The pickup is located at the area of minimum internal circumference.

After the above conditions are met and the index signals have been read, the laser emits the beam when the following two conditions are met.


- 1) when the PLAY key (SW407) or that of Remote Control Transmitter is pressed.
- 2) when the **PLAY** display is ON.




PANELS & REMOTE CONTROL TRANSMITTER



General and PX models only



CDX-520/
CD-1050



SPECIFICATIONS

AUDIO SECTION

Frequency Response	5Hz ~ 20kHz ± 0.5 dB
De-Emphasis Equalization	± 0.5 dB (EIAJ)
Harmonic Distortion + Noise	Less than 0.005%, 1kHz (EIAJ)
S/N Ratio	106dB (EIAJ)
Dynamic Range	More than 96dB (EIAJ)
Wow & Flutter	Unmeasurable
Channel Separation	More than 90dB, 1kHz (EIAJ)
Output Voltage	2V (EIAJ)
Output Impedance	2.2k Ω
Headphone Output (-20dB)	620mV/150 Ω

INTERNAL SYSTEMS

Optical Pick-up	3-beam laser
Error Correction System	CIRC
D/A Conversion	High-speed 18-bit (L, R twin)
Filter	Hi-Bit 8-Fold Oversampling Digital filter 3rd Order New Active Filter


GENERAL

Power Requirements	
U, C models	120V AC, 60Hz
G, B models	220-240V AC, 50Hz
A model	240V AC, 50Hz
R, P models	110-120/220-240V AC, 50/60Hz
Power Consumption	20W
Dimensions (W x H x D)	435 x 101 x 296.8 (17-1/8" x 4" x 11-11/16")
Weight	4.5kg (9 lbs 14 oz.)
Accessories	Pin plug cord Remote control transmitter Dry-cell: X2 (Size "AAA", R03)

*Specification subject to change without notice.


U U. S. A. model
C Canadian model
B British model
A Australian model
G European model
R General model
P PX model

INTERNAL VIEW




- ① POWER TRANSFORMER
- ② MAIN CIRCUIT BOARD (1)
- ③ DISC MECHANISM UNIT (DM-720B)
- ④ MAIN CIRCUIT BOARD (2)
- ⑤ μ -COM IC (IC113)

DIMENSION



Unit : mm (inch)

BLOCK DIAGRAM



DISASSEMBLY PROCEDURES

(Remove parts in disassembly order as numbered.)

1. Removal of Top Cover

- Remove 5 screws (①) in Fig. 1.
- Lift the Top Cover to the back side and move it rearward slantingly.

2. Removal of Front Panel

- Remove 3 screws (②) in Fig. 1, and pull the Front Panel forward.




Fig. 1

3. Removal of Disc Tray Ass'y

- Pull out the Disc Tray Ass'y by turning the loading cam and remove it by pressing the hook.




Fig. 2

4. Removal of Disc Mechanism Unit

- Remove 4 screws (③) in Fig. 4.




Fig. 4




Fig. 3

5. Removal of Disc Motor

- a. Remove 2 screws (④) fixing Flapper in Fig. 5 and then remove the flapper.




Fig. 5

- b. Pull off the disc table and remove 2 screws (⑤) in Fig. 6.





Fig. 6


● Installation of disc table

※ The following tools are necessary for installation.

Height adjustment gauge (TX913130)



Disc table installer (TX913140)



- a. Install the height adjustment gauge as shown in Fig. 7.




Fig. 7

- b. Carefully apply a small amount of anaerobic glue to motor shaft (Loc-Tite # 638).
c. Install turntable onto motor shaft with disc table installer as shown in Fig. 8.
d. Clean excess glue from top of turntable.
e. Allow 5 minutes for glue to cure before removing disc table installer and height gauge.




Fig. 8

- f. Check that the disc table height is as specified below.




Fig. 9

■ ADJUSTMENTS

● Necessary items

Measuring instruments

Oscilloscope	: x 2
(At least one shall have a bandwidth of 50 MHz or more)	
Audio frequency oscillator (A.F. OSC)	: x 1
Laser power meter	: x 1
(LEADER LPM-8000 (P/N TX915140) or equivalent)	
AC voltmeter (ACVM)	: x 2
(One dual channel or two single channel meters)	
DC voltmeter (DCVM)	: x 1
Frequency counter (FC)	: x 1

Jigs

Test disc	: x 1
(YEDS-18 P/N TX911730 or YEDS-7 P/N TX911320)	
Filter (See Fig. A)	: x 1
Shorting cord	: x 1

Tools

Screwdriver	: x 1
(For-Pre-Set Potentiometer adjustment)	
Core screwdriver	: x 1

● Adjustment jig (with internal filter)

Connect the filter in Fig. A before measurement.





Fig. A

SW1 : FOCUS gain and TRACKING gain switching
SW2 : Filter ON/OFF switch

● Precautions or Special Notes

1. Measure the output level at the output terminal of the AF oscillator.
2. When disc tray has been removed from the mechanism, make sure the position of the loading cam and the leaf switch are correct.
3. The unit should always be in a horizontal position while performing adjustments.

• Test Points



CDX-520/
CD-1050

★ Carry out following adjustments in order as numbered.

Step 1. Confirmation of Laser Output.

Step 2. Confirmation of Focus Actuator Operation.

Step 3. Adjustment of VCO.

Step 4. Adjustment of Tracking Gain

Step 5. Adjustment of Focus Gain

Step 6. Adjustment of Tracking Offset

Step 7. Adjustment of Focus Offset

Step 8. Adjustment of Kick Gain

Step 9. Confirmation of Jitter

Step 10. Confirmation of Skip Search Operation

Confirmation of Laser Output (Step 1)

- ① Do not load the disc.
- ② Remove the disc tray.
- ③ Remove the flapper.
- ④ Apply the laser power meter's sensor to the pick-up head as shown in Fig. B.

⑤ Press POWER key. (POWER ON)

⑥ Measure the laser output during the 5 seconds of FOCUS search mode.

Rating: Laser output = 0.1mW to 0.5mW




Fig. B

Precautions in handling pick-up head



- (1) No soldering necessary for the unit.
- (2) Since laser light is near-infrared, visual confirmation is difficult. While light is emitted, for safety make sure your eyes are at least 30 cm (12 inches) away from the objective lens.
- (3) Do not disassemble it.
- (4) Do not drop or apply shock to it.
- (5) Do not leave it under high temperature or humidity.
- (6) Do not touch the objective lens. Should there be dirt on the lens, clean using a blower for cameras.

Confirmation of Focus Actuator Operation (Step 2)

Oscilloscope (1) setting

- DC coupling
- 1V/div range (Vertical)
(0.1/div when 10:1 probe is used)
- 0.5 sec/div or 1 msec/div time (Horizontal)

- ① Do not load a disc.
- ② Connect the oscilloscope (1) to **R** and **GND** terminals.
- ③ Press POWER key. (POWER ON)
- ④ After confirming that loading cam position is correct press OPEN/CLOSE key for CLOSE operation.
- ⑤ During 5 seconds of FOCUS search, confirm that the waveform is as shown in Fig. C.
- ⑥ Confirm that the pick-up head's objective lens moves smoothly between the lowest and highest points.



Adjustment of VCO (Step 3)

- ① Connect the shorting cord and measuring instruments, as shown in Fig. D.
- ② Do not load a disc.
- ③ Press POWER key. (POWER ON)
- ④ While observing the frequency counter indication (F_{VCO}), adjust L101 so that it satisfies the rating.
Rating: $F_{VCO} = 4.3218 \text{ MHz} \pm 10 \text{ kHz}$




Fig. D

Adjustment of Tracking Gain (Step 4)

* This adjustment requires two single channel AC voltmeters or one dual channel AC voltmeter.

- ① Connect the filter and measuring instruments, as shown in Fig. E.

Apply a 800 Hz, 100 mVrms signal from the AF oscillator to **TDI** terminal via the resistor (330 kilohms) in the filter.

- ② Set SW2 to OFF.
- ③ Set SW1 to T (TRACKING).
- ④ Press POWER key. (POWER ON)
- ⑤ Load the test disc.
- ⑥ Press PLAY key.

- ⑦ Set SW2 to ON.

- ⑧ While observing the indications of the AC voltmeters (CH1: E_{TE} , CH2: E_Q), adjust VR103 (TRACKING GAIN) so that they satisfy the rating.

Rating: $E_{TE} - E_Q = 17\text{dB}$

Example [0dBV = 1V]


$$E_Q = -30\text{dBV} \text{ (30mV)}$$
$$E_{TE} = -13V \text{ (223mV)}$$


Fig. E

Adjustment of Focus Gain (Step 5)

* This adjustment requires two single channel voltmeter or one dual channel AC voltmeter.

- ① Connect the filter and measuring instruments, as shown in Fig. F.

Apply an 800 Hz, 4.5 Vrms signal from the AF oscillator to **FDI** terminal via the resistor (220 kilohms) in the filter.

- ② Set SW2 to OFF.
- ③ Set SW1 to F (FOCUS).
- ④ Press POWER key. (POWER ON)
- ⑤ Load the test disc.

- ⑥ Press PLAY Key.

- ⑦ Set SW2 to ON.

- ⑧ Read the indications of the AC voltmeters (CH1: E_{FO} , CH2: E_R), adjust VR104 (FOCUS GAIN) so that they satisfy the rating.

Rating: $E_{FO} - E_R = -8\text{dB}$

Example [0dBV = 1V]

$E_{FO} = -24\text{dBV}$ (63mV)

$E_R = -16\text{dBV}$ (160mV)





Fig. F

Adjustment of Kick Gain (Step 8)


Oscilloscope (1) (2-ch oscilloscope) Settings

- DC coupling
- CH1 → **TER** terminal: 0.1V/div (Vertical)
(10 mV/div when 10 : 1 probe is used)
- CH2 → **TRHD** terminal: 5V/div (Vertical)
(0.5V/div when 10 : 1 probe is used)
- TRIGGER MODE: 2 CH
- 0.2msec/div time (Horizontal)


- ① Connect the measuring instruments, as shown in Fig. H.
- ② Press POWER key. (POWER ON)
- ③ Load the test disc.
- ④ Press PLAY key.
- ⑤ Observe waveform while pressing Fast Forward mode key (▶▶) for 3 seconds.
- ⑥ Adjust VR105 (KICK GAIN) so that the **TER** signal cycle is 1.0 ± 0.5 when **TRHD** signal level is High.
* Adjust at the inner circumference of the disc.
- ⑦ Press Reverse mode key (◀◀) for 3 seconds and confirm that **TER** signal cycle is within the above specification but in reverse phase.



This shows about 0.75 cycle which is incorrect




This shows about 1.25 cycle which is within specification.



This shows about 1.75 cycle which is incorrect

* The TER waveform after the TRHD rise should converge gently.



Not converging gently




Fig. H

Confirmation of Jitter (Step 9)

Oscilloscope (2) Settings

- AC coupling
- 0.4 V/div range (Vertical)
(40 mV/div when 10 : 1 probe is used)
- 0.2 ~ 0.5 μ sec/div time (Horizontal)

- ① Connect oscilloscope (2) to **EFMI** terminal, as shown in Fig. F.
 - ② Press **POWER** key. (POWER ON)
 - ③ Load the specified disc (YEDS-18 or Philips test disc).
 - ④ Press **PLAY** key.
 - ⑤ Confirm that the **EFMI** signal (eye-pattern) waveform is distinct and clear.
- * Confirm at the center of the disc.

Oscilloscope (2)

Eye pattern






Fig. I

Waveforms 3T – 11T.




This portion is referred to as the eye pattern.

The abnormal eye pattern has less distinct lines and smaller amplitude than that of the good waveform.

Good waveform



Abnormal waveform




Confirmation of Skip Search Operation (Step 10)

- ① Load the disc.
- ② Press the PLAY key.
- ③ Press the skip key ($\boxtimes$) or 10 key to start searching.
- ④ Confirm that the skip is searched properly.

■ IC DATA

IC113: M50747-731SP
8 bit μ -COM





Pin No.	Pin Name	Description	I/O	Active	Function
1	Vcc				5V
2	P67				N. C.
3	P66				
4	P65				
5	P64				
6	P63				
7	P62				
8	P61				
9	P60				
10	P47	OP. SW	I	L	END Switch (OPEN/CLOSE)
11	P46	CL. SW	I	L	
12	P45	OPEN	O	H	LOADING MOTOR drive OPEN CLOSE
13	P44	CLOSE	O	H	
14	P43	LASER	O	H	Laser switch
15	P42	REMRRES	O	H	Remote control reset
16	P41	PLAY	O	H	PLAY signal DIT VCO
17	P40	PLAY	O	H	
18	P37/SRDY				N. C.
19	P36/CLK	CLK	I/O		SPC Interface
20	P35/TXD	SO	O		
21	P34/RXD	SI	I		
22	P33/CNTR	R/W	O		
23	P32/INT2	AO			N. C.
24	P30	WQ	I		SPC Interface
25	P31	CLK	O		
26	INT1	INT			5V
27	CNVSS	CNVSS			GND
28	RESET	RESET	I		Reset
29	XIN	XIN	I		8 MHz Clock
30	XOUT	XO	O		
31	ϕ	$\phi 2$	O		Timing output
32	VSS	VSS			GND
33	P57	PDET			GND
34	P56				
35	P55	RM5	I		Remote control interface
36	P54	RM4	I		
37	P53	RM3	I		
38	P52	RM2	I		
39	P51	RM1	I		
40	P50	RM0	I		
41	P17	D7			N. C.
42	P16	D6	O		Digit line
43	P15	D5	O		
44	P14	D4	O		
45	P13	D3	O		
46	P12	D2	O		
47	P11	D1	O		
48	P10	D0	O		
49	P07	K3	I		Key input line
50	P06	K2	I		
51	P05	K1	I		
52	P04	K0	I		
53	P03	DATA	O		LCD Display drive interface
54	P02	CLK	I/O		
55	P01	CE	O		
56	P00	INH	O		
57	P27				N. C.
58	P26	FIBIT	I		HI BIT Control
59	P25	HIBIT	O	H	Key input line (HI BIT)
60	P24				DIT VCO switch
61	P23	P, PLAY			GND
62	P22	REPLAY			
63	P21	STOP			
64	P20	PLAY			

IC113 : YM3616

Signal Processor & Controller

YM-3816 is a CMOS LSI for signal processing and servo control of the compact disc player.


It executes such signal processing as demodulation of the EFM signal from the optical pick-up, detection and correction of the erroneous signal and digital filtering which helps to improve the sound quality, as well as such intelligent servo controlling as focus, disc, tracking and feeding.



Pin No.	Pin Name	I/O	Function
1	VDD		Power Supply
2	VCOX	O	Clock Playback Circuit 4PCO
3	VCOI	I	
4	PCO	O	GND
5	VSS		
6	EFMX	O	EFM Signal External Circuit
7	EFMX	O	
8	EFMI	I	GND
9	VSS		
10	SYEQ	O	Synchronized Uniform Signal
11	N.C.		Not Use
12	DM	O	Disc Servo { LOW (0V): FORWARD OPEN (2.5V): STOP HIGH (5V): REVERSE
13	FCS	O	Focus Servo System Input
14	FZC	I	
15	FRF	I	
16	HF	I	Tracking Servo System Input
17	TER	I	
19	TROF	O	
20	TRGL	O	
21	TRHD	O	
22	KP	O	{ LOW (0V): REW OPEN (2.5V): STOP HIGH (5V): FF


Pin No.	Pin Name	I/O	Function
23	CK		EFM Demodulated Signal Check Output (4.3218MHz, clock)
24	FEOF	O	Feed Servo System
25	FEM+	O	
26	FEM-	O	
23	CK	I/O	EFM Demodulated Signal Check Output (4.3218MHz clock)
27	DATA	I/O	
28	DSY	I/O	
29	SUB	O	Sub-code Output
30	VFSY	O	
31	RCK	I	
32	VDD		Power Supply
33	NC	I	Not Use
34	$\phi 4$		4.3218 MHz Clock
35	WQ	O	Q Code Output System
37	DOUT	O	
36	R/W	I	
39	SCK	I	
38	DIN	I	Data Output to μ COM Data I/O Control Signal Clock for Data I/O Data I/O from μ COM
41	VSS		
40	A0	O	
42	A1	O	RAM Connections
43	A2	O	
44	A3	O	
45	A4	O	
46	A5	O	
47	A6	O	
48	A7	O	
49	A8	O	
50	A9	O	
51	WE	O	
52	OE	O	
53	A10	O	
54	D8	I O	
55	D7	I O	
56	D6	I O	
57	D5	I O	
58	D4	I O	
59	D3	I O	
60	D2	I O	
61	D1	I O	
62	DEP	O	Deemphasis Signal
63	DTFLG	O	Data Error Signal
66	SDO	O	Digital Data Output LSB first/MSB first
67	SDSY	O	Data Control Circuit Board Serial Signal Output
68	$\phi 2$	O	
69	L/M	I	
71	TESTC	I	2.1659MHz Clock SB first (H)/MSB first (L) Switch for SDO Test Terminal
64	NC	O	DAC Interface
65	SDSYMD	O	
76	SAMPR	O	
77	SAMPL	O	
34	$\phi 4$	O	4.3218MHz Clock
18	TESTD	I	
70	TESTB	I	Test Terminal
74	TCL	I	
72	VDD		
73	EFLG	O	Power Supply
75	XFSY	I/O	C1, C2 Error Correction Check Signal
78	VSS		Synchronized Clock Signal
79	XIN	I	GND
80	XOUT	O	Clock Oscillation

IC109: YM3414
Digital Filter





IC101 ~ 104, 123: NJM4558S
IC105: NJM2043S
IC106, 120: μ PC4570HA
Dual Ope-amp.



IC111: STA341M Transistor Array




Digital Audio Interface Transmitter (DIT)




LCD Driver




IC114: BA6218
Motor Driver



IC115: TC74HC00P
Quad 2-Input NAND Gate



U901: GP1U501X



■ TEST PROGRAM

1. Starting the test program

Turn power on while holding down the [4] and [7] keys.

2. Contents of test program

All elements in the LCD light for the first four seconds after the test program is activated.

(Pressing any key other than [1] — [9] and [0], even during the initial four seconds, will cause the next step to begin immediately.)

a. LCD test

[+10] key

1 — 9 and 0 are displayed, in that order, in each of the six seven-segment display blocks.

DISC, TRACK, time mode brackets, TOTAL, SINGLE, REMAIN, INDEX, : , SCAN, MANUAL, RANDOM, play triangle, tape display, A, B, repeat brackets, SINGLE, FULL and REPEAT light and the go out, in that order.

After the calendar brackets light, the calendar numbers 1 through 20 light in order.

All segments light, then go out.

b. Hi-bit test

The hi-bit switch turns the hi-bit LED on and off.

c. SPC test

Commands can be sent to the SPC by means of key input.

Key commands	SPC commands
[OPEN/CLOSE] . .	FOCUS START
[PLAY]	PLAY
[PAUSE]	SEARCH (PAUSE)
[STOP]	STOP (INIT)
[SKIP+]	FFF
[SKIP-]	FFB
[SEARCH+]	FF
[SEARCH-]	FB
[REPEAT]	FEED FORWARD
[TAPE]	FEED RETURN
[AUTO]	DISC START
[MANUAL]	DISC BRAKE
[DISPLAY]	TIME INDICATOR SWITCH
	SINGLE MIN : SEC
	TOTAL AMIN : ASEC

Display description

These commands and the internal state of the SPC can be read from the LCD display.

DISC Lights when focusing.

Track indicator . . . Shows the track number (TNO) read in.

Time indicator . . . Shows the time read in (MIN : SEC or AMIN : ASEC).

Play indicator . . . While focusing, lights at the point at which play commences.


Calendar 1 — 8: Displays the SPC internal state.
11 — 18: Displays the transmitted command.

Internal state display

- 1 NQ New Q code (lit: new Q code set)
- 2 FCO Focus out (lit: focus out)
- 3 MZ Disc motor stopped (lit: disc motor stopped)
- 4 4F Frame error (1/16 second)
- 5 8F Frame error (1/8 second)
- 6 S1 Search mode
- 7 S2 (00: -1/4, 01: 1/4 — 4, 10: 4 — 128, 11: 128 —)
- 8 SIGN . . . Search polarity (lit: —)


Command display/illuminated numbers (—: not lit)

	11	12	13	14	15	16	17	18
STOP	—	—	—	14	—	—	—	—
FEED FORWARD	—	—	—	—	—	16	—	—
FEED RETURN	—	—	—	—	15	16	—	—
FOCUS START	—	—	—	—	—	—	17	—
DISC START	—	—	—	—	—	16	17	—
DISC BRAKE	—	—	—	—	15	16	17	—
PLAY	—	—	—	—	—	—	—	18
FF	—	—	—	—	—	16	—	18
FB	—	—	—	—	15	16	—	18
FFF	—	—	—	—	—	—	17	18
FFB	—	—	—	—	15	—	17	18
SEARCH (PAUSE)	—	—	—	—	—	16	17	18




■ PRINTED CIRCUIT BOARD (Foil side)


Main Circuit Board (2)




Operation Circuit Board



Main Circuit Board (3)



Main Circuit Board (5)




8



RS-CDX520 REMOTE CONTROL TRANSMITTER

■ SCHEMATIC DIAGRAM



CUSTOM CODE

KEY No.	DATA CODE								FUNCTION
	D0	D1	D2	D3	D4	D5	D6	D7	
2	1	0	0	0	0	0	0	0	OPEN/CLOSE
3	0	1	0	0	0	0	0	0	PLAY
4	1	1	0	0	0	0	0	0	SKIP <<
6	1	0	1	0	0	0	0	0	SEARCH <<
7	0	1	1	0	0	0	0	0	SEARCH >>
8	1	1	1	0	0	0	0	0	SKIP >>
9	0	0	0	1	0	0	0	0	REPEAT
11	0	1	0	1	0	0	0	0	DISPLAY
13	0	0	1	1	0	0	0	0	PROGRAM MANUAL
17	0	0	0	0	1	0	0	0	0
18	1	0	0	0	1	0	0	0	1
19	0	1	0	0	1	0	0	0	2
20	1	1	0	0	1	0	0	0	3
21	0	0	1	0	1	0	0	0	4
22	1	0	1	0	1	0	0	0	5
23	0	1	1	0	1	0	0	0	6
24	1	1	1	0	1	0	0	0	7
25	0	0	0	1	1	0	0	0	8
26	1	0	0	1	1	0	0	0	9
27	0	1	0	1	1	0	0	0	+10
28	1	1	0	1	1	0	0	0	PROGRAM RANDOM
51	0	1	0	0	1	0	1	0	INTRO SCAN
54	1	0	1	0	1	0	1	0	PAUSE
55	0	1	1	0	1	0	1	0	STOP
56	1	1	1	0	1	0	1	0	PROGRAM TAPE EDIT

■ PARTS LIST

Ref. No.	Part No.	Description	部 品 名	Remarks	Common Model	Markets	ランク
※	VH 03 01 00	Remote Control Transmitter	リモートコントロールトランスミッター				
	CX 60 72 00	Lid	電 池 ケ ー ス				
		Dry Cell	AAA,R03	単 4 乾 電 池			

※ New Parts (新規部品) NR

CDX-520/CD-1050 PARTS LIST

ELECTRICAL PARTS

■WARNING

Components having special characteristics are marked $\triangle$ and must be replaced with parts having specifications equal to those originally installed.

●Carbon resistors (1/6W or 1/4W) are not included in the ELECTRICAL PARTS list. For the parts No. of the carbon resistor, refer to p. 45.

Ref. No.	Part No.	Description	部 品 名	Remarks	Common Model	Markets	ランク
※	VG 95 21 00	Main Circuit Board	メ イ ン シ ー ト	Black		J	
※	VG 95 22 00	"	"	"		U,C	
※	VG 95 23 00	"	"	"		R,P	
※	VG 95 24 00	"	"	"		A,B	
※	VG 95 25 00	"	"	"		G	
※	VG 95 26 00	"	"	Silver		J	
※	VG 95 27 00	"	"	"		U,C	
※	VG 95 28 00	"	"	"		R,P	
※	VG 95 29 00	"	"	"		A,B	
※	VG 95 30 00	"	"	"		G	
	FA 15 31 00	Mylar Cap.	1000pF 50V	マ イ ラ ー コ ン	C134, 141		
	UA 25 26 80	"	680pF 50V	"	C191, 192		
	FA 15 32 20	"	2200pF 50V	"	C105, 164, 165		
	FA 15 34 70	"	4700pF 50V	"	C179, 182		
	FA 15 41 00	"	0.01 μ F 50V	"	C136		
	FA 15 41 20	"	0.012 μ F 50V	"	C104		
	FA 15 41 80	"	0.018 μ F 50V	"	C135		
	FA 15 43 30	"	0.033 μ F 50V	"	C109		
	FA 15 44 70	"	0.047 μ F 50V	"	C101, 124, 125		
	FA 15 46 80	"	0.068 μ F 50V	"	C102, 155, 156		
	FA 15 51 00	"	0.1 μ F 50V	"	C106		
	FA 15 52 40	"	0.24 μ F 50V	"	C133		
	FA 15 52 70	"	0.27 μ F 50V	"	C114		
	FA 15 53 90	"	0.39 μ F 50V	"	C111		
	FA 15 58 20	"	0.82 μ F 50V	"	C110		
	FZ 00 41 30	Semiconductive Ceramic Cap.	0.1 μ F 25V	半 導 体 セ ラ コ ン	C107, 128, 144, 148, 151, 160, 178, 193, 194, 204, 216, 217, 220, 221		
	VA 76 21 00	Ceramic Cap.	0.1 μ F 25V	積 層 セ ラ コ ン	C126		
	VA 76 11 00	"	27pF 50V (CH)	セ ラ コ ン	C146, 147		
	FG 21 11 50	"	15pF 50V	"	C123		
	FG 21 12 20	"	22pF 50V	"	C122, 127, 201		
	FG 21 12 70	"	27pF 50V	"	C117, 203, 205		
	FG 21 13 30	"	33pF 50V	"	C140, 212, 213		
	FG 21 21 00	"	100pF 50V	"	C108		
	FG 21 25 60	"	560pF 50V	"	C113, 163		
	FG 21 26 80	"	680pF 50V	"	C112		
	FG 21 31 00	"	1000pF 50V	"	C167		
	FG 24 41 00	"	0.01 μ F 50V	"	C118, 121, 218, 219		
	FG 24 44 70	"	0.047 μ F 50V	"	C137, 149, 150		
	UJ 11 82 20	Electrolytic Cap.	220 μ F 6.3V	ケ ミ コ ン	C129, 166		
	UJ 11 91 00	"	1000 μ F 6.3V	"	C132		
	UJ 12 81 00	"	100 μ F 10V	"	C115, 120, 202		
	UJ 12 84 70	"	470 μ F 10V	"	C207		
	UJ 12 82 20	"	220 μ F 10V	"	C175		
	UJ 13 71 00	"	10 μ F 16V	"	C116, 195, 198, 211		
	UJ 13 73 30	"	33 μ F 16V	"	C143, 157~159, 161, 168~171, 185, 186, 189, 210		
	UJ 13 82 20	"	220 μ F 16V	"	C172, 174, 183, 188		
	UJ 16 61 00	"	1 μ F 50V	"	C173, 190		
	UH 16 62 20	"	2.2 μ F 50V	"	C103, 119, 209		
	UJ 16 64 70	"	4.7 μ F 50V	"	C208		
	UJ 12 82 20	"	220 μ F 10V	"	C152~154		
	UJ 13 72 20	"	22 μ F 16V	"	C180, 181		
	UH 13 93 30	"	3300 μ F 16V	"	C184, 187		

※New Parts (新規部品) NR

Ref. No.	Part No.	Description	部 品 名	Remarks	Common Model	Markets	ランク
	VE 22 24 00	Ceramic Oscillator	8MHz	セラミック発振子	XL101		
	VC 39 88 00	Quartz Crystal Unit	16.93MHz	水晶振動子	XL103		
	VD 47 37 00	SB Coil	60 μ H	S B コ イ ル	L103,104		
	GE 90 20 00	OSC Coil	3.3 μ H	O S C コ イ ル	L101		
※	XF 41 3A 00	Power Transformer		電 源 ト ラ ン ス	T101	J	△
※	XF 41 4A 00	//		//	//	U,C	△
※	XF 41 5A 00	//		//	//	R,P	△
※	XF 41 6A 00	//		//	//	G	△
※	XF 91 0A 00	//		//	//	A,B	△
	VC 54 82 00	Pulse Trans		パルストランス	L102		
	HX 60 07 60	Carbon Resistor	470 Ω 1/4W	カーボン抵抗	R336		
	HV 45 34 70	Flame Proof Carbon Resistor	4.7 Ω 1/4W	不燃化カーボン抵抗	R290,293		
	HV 45 61 00	//	1k Ω 1/4W	//	R294		
	VF 45 91 00	Metal Film Resistor	2.2k Ω 1/4W	金属被膜抵抗	R226,230		
	VF 45 92 00	//	22k Ω 1/4W	//	R225,228		
	HL 31 34 70	Metal Oxide Film Resistor	4.7 Ω 1W	酸化金抵抗	R304		
	VC 61 25 00	Pre-Set Potentiometer	B68k Ω	半固定抵抗	VR104		
	VB 86 19 00	//	B100k Ω	//	VR101,102		
	VB 86 21 00	//	B330k Ω	//	VR103		
	VB 86 22 00	//	B470k Ω	//	VR105		
※	VG 86 13 00	Potentiometer	A50k Ω × 2	二連ロータリーボリューム	VR106		
	iA 09 33 00	Transistor	2SA933S(Q,R)	トランジスタ	Q104,117,122,126,127,137	Inter- changeable	
	iA 11 15 10	//	2SA1115(E,F)	//	//		
	iA 13 10 00	//	2SA1310(R,S,T)	//	//		
	iA 09 34 10	//	2SA934	//	Q102,115	Inter- changeable	
	iB 05 44 00	//	2SB544	//	//		
	iC 17 40 00	//	2SC1740S(R,S)	//	Q106,107,116,118~121, 123,128,132,134,135	Inter- changeable	
	iC 26 03 10	//	2SC2603(E,F)	//	//		
	iC 33 12 00	//	2SC3312(R,S,T)	//	//		
	iC 20 60 00	//	2SC2060	//	Q101,114,143	Inter- changeable	
	iD 04 00 00	//	2SD400	//	//		
	iC 28 78 20	//	2SC2878(A,B)	//	Q103,105,108,109,124,125, 129,130,138~140,144~146		
	iC 33 27 00	//	2SC3327	//	//		
	VC 50 21 00	//	2SD1915	//	//		
	VB 31 14 00	//	2SB889(P,Q,R)	//	Q133		
	VB 31 13 00	//	2SD1200(P,Q,R)	//	Q136		
	iF 00 34 50	Diode	ISS133	ダイオード	D101,105,109,114,117,118		
	iH 00 14 30	//	ISR35-100A	//	D108,110~113		
	VG 43 62 00	Zener Diode	MTZJ3.6A	ツェナーダイオード	D103,104		
	VG 43 77 00	//	MTZJ5.6B	//	D107		
※	VG 43 88 00	//	MTZJ8.2A	//	D102,116		
※	VG 43 98 00	//	MTZJ11A	//	D106		
	iF 00 49 10	Varactor Diode	ISV55	F Mバクターダイオード	D115	Inter- changeable	
	iF 00 49 20	//	SVC211	//	//		
※	VG 93 38 00	LCD Display		L C D 表示器	VI01		


※New Parts (新規部品) NR

Ref. No.	Part No.	Description	部 品 名	Remarks	Common Model	Markets	ランク
	iG 07 68 00	IC	NJM4558S	I C	IC101~104,123		
	iG 08 02 00	//	NJM2043S	//	IC105		
	iG 11 92 00	//	μPD4016-CX	//	IC110	Inter-changeable	
	XD 84 30 01	//	TMM2016BP	//	//		
	XD 87 60 01	//	CXK5816PM	//	//		
	XE 09 70 01	//	CXK5816PS	//	//		
	iG 05 82 10	//	M5218L	//	IC121		
	iG 15 35 00	//	BA6218	//	IC114		
	iR 00 00 00	//	TC74HC00P	//	IC115		
	VC 16 07 00	//	STA341M	//	IC111		
	XB 24 70 01	//	μPC4570HA	//	IC106,120		
	XB 41 70 01	//	LC7582	//	IC122		
	XC 43 50 01	//	μPC7805HF	//	IC125	Inter-changeable	
	XD 33 80 01	//	AN7805F	//	//		
	XF 31 1A 00	//	LU59526	//	IC112		
※	XF 94 2A 00	//	M50747-731SP	//	IC113		
	XD 89 80 01	//	PCM56L	//	IC118,119		
	XB 69 80 01	//	YM3616	//	IC107		
	XC 85 30 01	//	YM3613B	//	IC108		
	XD 71 20 01	//	YM3414	//	IC109		
	VG 38 81 00	Voltage Selector	電 圧 切 換 器	SW101		R,P	△
※	VH 50 75 00	Push Switch	プッシュスイッチ	SW102			△
	LB 30 24 20	Phone Jack	Gray	ホ ー ン ジャ ッ ク	JK102 Silver		
	LB 30 24 30	//	Black	//	// Black		
	VF 09 65 00	Pin Jack	2P	ピ ン ジャ ッ ク	PJ102		
	VG 02 01 00	//	1P	//	PJ101		
	LB 20 13 90	Base Pin	2P TE-Type	2, 5 ピッチベースピン	CB101,102		
	LB 40 05 70	//	4P TE-Type	//	CB103		
	LB 50 02 50	//	5P TE-Type	//	CB104		
	VD 00 45 00	//	2P i-Type	P H ベ ー ス ピ ン	CB105		
	VD 00 46 00	//	3P i-Type	//	CB106		
	VD 00 47 00	//	4P i-Type	//	CB107		
	VD 00 48 00	//	5P i-Type	//	CB108		
	VD 00 49 00	//	6P i-Type	//	CB109~112		
	VD 00 53 00	//	10P i-Type	//	CB113,114		
	LA 00 21 40	Lapping Terminal	2P P=10 i-Type	i 型ラッピング端子板		U,C,G	
	VE 22 57 00	Base Post	2P	ベ ー ス ポ ス ト		J,R,A,B,P	
	LA 00 41 20	Test Point Pin	1P	テストポイントピン			
	VB 96 69 00	Pin		ス タ イ ル ピ ン		J,R,A,B,P	
	BA 08 40 00	Heat Sink		放 熱 板			
	BB 06 62 90	Ground Washer		アースワッシャー			
	VG 33 58 00	Reflector		リ フ レ ク タ			
	VH 04 12 00	Sheet Diffusion		シート, ディフュージョン			
	CB 60 56 20	Plastic Rivet		プラスチックリベット			
	Ei 33 00 86	Binding Head Tapping Screw	3×8 FCRM3-BI	バインドタッピングネジ	PACK		

※New Parts (新規部品) NR

※New Parts (新規部品) NR

EXPLODED VIEW




MECHANISM PARTS Note) φ : Diameter

Ref. No.	Part No.	Description	部 品 名	Remarks	Common Model	Markets	リンク
※ 1	VG 95 79 00	Front Panel Ass'y	フ ロ ン ト パ ネ ル A s s ' y	Black CDX-520		J,U,C,G,P	
※ //	VG 95 80 00	//	//	// CD-1050		R,A,B	
※ //	VG 95 81 00	//	//	Silver CDX-520		J,U,C,G,P	
※ //	VG 95 82 00	//	//	// CD-1050		R,A,B	
※ 2	VG 95 11 00	Operation Circuit Board	オ ペ レ ー シ ョ ン シ ー ト				
※ 3	VG 70 43 00	Button 4P	ボ タ ン	Black			
※ //	VG 70 44 00	// 4P	//	Silver			
※ 4	VG 39 72 00	//	//	Black 10key			
※ //	VG 39 73 00	//	//	Silver //			
※ 5	VD 81 25 00	//	//	Black SKIP,SEARCH			
※ //	VG 70 47 00	//	//	Silver //			
※ 6	VG 70 49 00	//	//	Black PROGRAM,REPEAT			
※ //	VG 70 50 00	//	//	Silver //			
7	VD 37 07 00	// IP	//	Black			
//	VE 51 46 00	// IP	//	Silver	CDX-510		
8	Ei 33 00 86	Binding Head Tapping Screw 3×8 FCRM3-BI	バ イ ン ド タ ッ ピ ン グ ネ ジ	PACK			
※ 9	VH 55 45 00	Disc Mechanism Unit DM-720B	D M ユ ニ ッ ト				
10	KA 90 63 70	End Switch	エ ン ド ス イ ッ チ				
11	Ei 32 61 06	Binding Head Tapping Screw 2.6×10 ZMC2-BI	バ イ ン ド タ ッ ピ ン グ ネ ジ	PACK			
※ 12	VG 95 21 00	Main Circuit Board	メ イ ン シ ー ト	Black		J	
※ //	VG 95 22 00	//	//	//		U,C	
※ //	VG 95 23 00	//	//	//		R,P	
※ //	VG 95 24 00	//	//	//		A,B	
※ //	VG 95 25 00	//	//	//		G	
※ //	VG 95 26 00	//	//	Silver		J	
※ //	VG 95 27 00	//	//	//		U,C	
※ //	VG 95 28 00	//	//	//		R,P	
※ //	VG 95 29 00	//	//	//		A,B	
※ //	VG 95 30 00	//	//	//		G	
13	CB 61 68 10	Cord Stopper CM-22A	コ ー ド ス ト ッ パ ー			J	
//	CB 62 02 00	// CM-22C	//			U,C	
//	CB 62 01 90	// CM-22B	//			R,A,B,G,P	
※ 14	VG 93 36 00	Lamp 8V 150mA	ラ ン プ				
15	VE 22 30 00	Power Cord Ass'y 125V	電 源 コ ー ド A s s ' y			J	△
//	MG 00 22 20	Power Cord 10A 125V	電 源 コ ー ド			U,C	△
//	VE 22 29 00	Power Cord Ass'y 250V	電 源 コ ー ド A s s ' y			R,P	△
//	VE 04 29 00	// 250V	//			A	△
//	VE 04 31 00	//	//			B	△
//	MG 00 23 20	Power Cord 2.5A 250V	電 源 コ ー ド			G	△
※ 16	VG 39 79 00	Top Cover	ト ッ プ カ バ ー	Black			
※ //	VG 39 80 00	//	//	Silver			
17	VF 48 64 00	Support, E	サ ポ ー ト / E		CDX-710		
18	VA 75 72 00	Leg	脚				
19	VF 44 45 00	Cap, Lamp	ラ ン プ キ ャ ッ プ				
20	VE 30 92 00	Damper	ダ ン パ ー		CDX-910		
※ 21	VG 87 28 00	Tray Ass'y	ト レ イ A s s ' y				
21-1	VE 04 12 00	Tray, Disc	ト レ イ / デ ィ ス ク				
21-2	VE 26 98 00	Lifter Ass'y (L)	リ フ タ ー A s s ' y (L)				
21-3	VE 26 99 00	// (R)	// (R)				
21-4	VE 04 16 00	Pad, Disc	パ ッ ド / デ ィ ス ク				
21-5	CB 62 79 60	Cushion Rubber	ク ッ シ ョ ン ゴ ム				
21-6	VE 04 18 00	Spring, BE	ス プ リ ン グ / B E				
21-7	VE 30 60 00	Plate	プ レ ー ト / 7 1 0				

※New Parts (新規部品) NR

※New Parts (新規部品) NR

EXPLODED VIEW (DM-720B)

MECHANISM PARTS (DM-720B)

[illegible]


※New Parts (新規部品) NR

Parts List for Carbon Resistors

Value	1/4W Type Part No.	1/6W Type Part No.	Value	1/4W Type Part No.	1/6W Type Part No.
1.0 Ω	HJ353100	HF853100	12K Ω	HJ357120	HF857120
1.8 "	HJ353180	※	15 "	HJ357150	HF857150
2.2 "	HJ353220	HF853220	18 "	HJ357180	HF857180
3.3 "	HJ353330	HF853330	22 "	HJ357220	HF857220
4.7 "	HJ353470	HF853470	27 "	HJ357270	HF857270
5.6 "	HJ353560	HF853560	33 "	HJ357330	HF857330
10 "	HJ354100	HF854100	39 "	HJ357390	HF857390
15 "	HJ354150	HF854150	47 "	HJ357470	HF857470
22 "	HJ354220	HF854220	56 "	HJ357560	HF857560
27 "	HJ354270	HF854270	68 "	HJ357680	HF857680
33 "	HJ354330	HF854330	82 "	HJ357820	HF857820
39 "	HJ354390	HF854390	91 "	HJ357910	HF857910
47 "	HJ354470	HF854470	100 "	HJ358100	HF858100
56 "	HJ354560	HF854560	120 "	HJ358120	HF858120
68 "	HJ354680	HF854680	150 "	HJ358150	HF858150
82 "	HJ354820	HF854820	180 "	HJ358180	HF858180
100 "	HJ355100	HF855100	220 "	HJ358220	HF858220
110 "	HJ355110	HF855110	270 "	HJ358270	HF858270
120 "	HJ355120	HF855120	330 "	HJ358330	HF858330
150 "	HJ355150	HF855150	390 "	HJ358390	HF858390
160 "	HJ355160	※	470 "	HJ358470	HF858470
180 "	HJ355180	HF855180	560 "	HJ358560	HF858560
220 "	HJ355220	HF855220	680 "	HJ358680	HF858680
270 "	HJ355270	HF855270	820 "	HJ358820	HF858820
330 "	HJ355330	HF855330	1.0M Ω	HJ359100	HF859100
390 "	HJ355390	HF855390	1.2 "	HJ359120	※
470 "	HJ355470	HF855470	1.5 "	HJ359150	HF859150
510 "	※	HF855510	1.8 "	HJ359180	HF859180
560 "	HJ355560	HF855560	2.2 "	HJ359220	HF859220
680 "	HJ355680	HF855680	3.3 "	HJ359330	HF859330
820 "	HJ355820	HF855820	3.9 "	HJ359390	※
910 "	HJ355910	HF855910	4.7 "	HJ359470	HF859470
1.0K Ω	HJ356100	HF856100			
1.2 "	HJ356120	HF856120			
1.5 "	HJ356150	HF856150			
1.8 "	HJ356180	HF856180			
2.0 "	HJ356200	HF856200			
2.2 "	HJ356220	HF856220			
2.4 "	HJ356240	HF856240			
2.7 "	HJ356270	HF856270			
3.0 "	HJ356300	HF856300			
3.3 "	HJ356330	HF856330			
3.6 "	HJ356360	HF856360			
3.9 "	HJ356390	HF856390			
4.7 "	HJ356470	HF856470			
5.1 "	HJ356510	HF856510			
5.6 "	HJ356560	HF856560			
6.8 "	HJ356680	HF856680			
8.2 "	HJ356820	HF856820			
9.1 "	HJ356910	HF856910			
10 "	HJ357100	HF857100			


1/4W Type

HJ35○○○○



1/6W Type

HF85○○○○



CDX-520/CD-1050

YAMAHA

CDX-520/
CD-1050