SANSUI AU-777D 回 路 図

S11(a~f) SELECTOR SW
1. MIC
2. PHONO 1
3. PHONO 2
4. TUNER
5. AUX

S21(a~b) PICK UP LOAD SW
1. 30KΩ
2. 50KΩ
3. 100KΩ

S31(a~b) TAPE MONITOR SW
1. SOURCE
2. PLAY BACK

S4(a~c) MODE SW
1. STEREO REVERSE
2. STEREO NORMAL
3. MONO L
4. MONO R
5. MONO L+R

S11(a~b) LOUDNESS SW
1. OFF
2. ON

S12(a~b) MUTING SW
1. OFF
2. -20 dB

S13(a~b) LOW FILTER SW
1. OFF
2. ON

S14(a~b) HIGH FILTER SW
1. OFF
2. ON

S15(a~b) BALANCE CHECK
1. NORMAL
2. TEST

S16(a~d) SPEAKER SW
1. SPEAKER OFF
2. SYSTEM A
3. SYSTEM B
4. SYSTEM A+B

S17 POWER SW
1. OFF
2. ON

VR701, 702 VOLUME
VR703 BALANCE

S5, S8 MID RANGE SW
1~5 CUT
6 FLAT
7~11 BOOST

S6, S9 TREBLE SW
1~5 CUT
6 FLAT
7~11 BOOST

S7, S10 BASS SW
1~5 CUT
6 FLAT
7~11 BOOST

SYMBOL
○ OIL
□ MICA
△ CERAMIC
○ MYLAR
⊗ TANTAL
⊠ POLYSTYLENE

TR601 2SC458LG
TR603 2SC458LG ©
TR602
TR604
TR701 2SC458LG
TR703 2SC458LG
TR704
TR705 2SC458LG
TR707 2SC458LG
TR708
TR709 2SC458LG
TR710
TR801 2SC458LG
TR803 2SC283
TR802
TR804
TR805 2SD152
TR807, TR809 2SD143 ×2
TR811, TR813 2SD218 ×2
TR806
TR808 TR810 TR812 TR814
TR815 2SC281 ©
TR001 2SD224
D001
2SF-656
10D-1 ×2
SCH001
OA-91 ×2
PU601
PL001
PL002
T001

F-1207
F-1194
F-1170
F-11831
F-1153

MIC
PHONO 1
PHONO 2
TUNER
AUX
TAPE REC
TAPE MON

A.C. 100V (50、60Hz)
100V RED
BROWN
BLACK

L+R OUT PUT
HIGH CUT

※改良のため予告なく意匠および規格を一部変更することがあります

山水電気株式会社
東京都杉並区和泉2-14-1 電話 東京 (03) 323-1111
(99020M2)