

MODIFICATION

PROBLEM:

When the headphones are plugged in the subwoofer is not muting.

CAUSE:

Mute line on subwoofer does not activate when the headphones are plugged in.

SOLUTION:

The headphones, On line(h/p on) from the control (front panel) board can be connected via a wire and a 4.7k ohm resistor to the base of Q302 on the surround pc board. See diagram 1 ,2 and 3. Glue resistor to surround pc board after to prevent wire and resistor from moving.

Diagram 1

L75 FRONT PANEL PC BOARD (PARTIAL REAR VIEW)

L75 SURROUND PC BOARD
(PARTIAL REAR VIEW)

