CONFIDENTIAL



Tips & Tricks

No. 20060906

Date: September 6, 2006

Model: DTR4.6 / 5.6 /6.6/7.6 TX-SR573/TX-SR603X

Subject: XM ANT Jack

Symptom: XM ANT JACK broken lose from PCB board.

Solution: ADD TRM Terminal support hold Xm Satellite ANT Jack mounting on board. Solder jump wires for connection see next page two pictures.

Parts:

Ref#	Description	Part Number
	TRM (NTM-1P243)	25060312
	Xm Satellite Ant Jack	25053104R2





