

aiwa



CS-P70

STEREO RADIO CASSETTE
RECORDER

• BASIC TAPE MECHANISM: TN-9ZR-202

• TYPE: HRJ,AK,AEZ

SIMPLE MANUAL

• Replace this Service Manual with "Revision Publishing" when it is issued.

PARTS LIST - 1

NOTE: The characters in the suffix column indicate the part usage.

AEZSXX.....A.....
 AKBXX.....B.....
 HRJSXX.....C.....
 AEZBXX.....D.....

REF.NO	PARTS NO.	KANRI NO.	DESCRIPTION	SUFFIX
	82-135-799-010	0E	DIODE, IN4148	ABCD.....
	82-596-799-010	0E	DI, 1N4001B	ABCD.....
	86-NFZ-657-080	0E	TR, 2SC1923(0)	ABCD.....
	87-001-145-080	1B	IC, TA8126F	ABCD.....
	87-005-196-080	0E	INDUCTOR, 10UH	ABCD.....
	87-005-730-080	0E	INDUCTOR, 10UH	ABCD.....
	87-010-035-010	0E	CAP, E 2.2-50V	ABCD.....
	87-010-053-810	0E	CAP, E 1-50V	ABCD.....
	87-010-079-010	0E	CAP, E 100-6.3V	ABCD.....
	87-010-221-010	0E	CAP, E 470-10V	ABCD.....
	87-010-236-010	1A	CAP, E 1000-10V	ABCD.....
	87-010-248-080	0E	ELECT CAP 220-10V	ABCD.....
	87-010-263-080	0E	ELECT CAP 100-10V	ABCD.....
	87-010-265-010	0E	CAP, E 33-16V	ABCD.....
	87-010-375-010	0E	CAP, E 330-10V	ABCD.....
	87-010-380-010	0E	CAP, E 47-16V	ABCD.....
	87-010-400-010	0E	CAP, E 0.47-50V	ABCD.....
	87-010-403-010	0E	CAP, E 3.3-50V	ABCD.....
	87-010-404-010	0E	CAP, E 4.7-50V	ABCD.....
	87-010-498-010	0E	CAP, E 10-16V	ABCD.....
	87-010-545-010	0E	CAP, E 0.22-50V	ABCD.....
	87-010-782-010	1C	CAP, E 47000-5.5V	ABCD.....
	87-017-567-080	1C	DIODE, SVC342M-V	ABCD.....
	87-020-465-010	0E	DIODE, 1SS133	ABCD.....
	87-026-447-080	0E	TR, 2SC1740S	ABCD.....
	87-026-572-080	0E	TR, DTA114TS	ABCD.....
	87-067-643-410		SCREW, ST2-10	ABCD.....
	87-070-106-010		LED, SE3001 RED	ABCD.....
	87-261-031-410	0E	SCREW, 2-2	ABCD.....
	87-261-094-410	0E	SCREW, M3-6	ABCD.....
	87-261-095-010		SCREW, ST3-8MM HEAD V5.9-6.3 BB	ABCD.....
	87-341-038-210	0E	SCREW, ST2-12	ABCD.....
	87-352-095-010	0E	SCREW, ST3-8	ABCD.....
	87-357-529-310	0E	SCREW, ST1.7-4	ABCD.....
	87-741-096-410	0E	SCREW, ST3-10MM	ABCD.....
	87-743-073-410	0E	SCREW, ST2.6-6MM	ABCD.....
	87-743-074-410	0E	SCREW, ST2.6-8	ABCD.....
	87-A20-946-040	1D	IC, MM1434XFBE	ABCD.....
	87-A30-092-080	0E	FET, 2SK439E/F	ABCD.....
	87-A40-226-080	0E	DIODE, SVC251SPA	ABCD.....
	87-B10-071-010	0E	SCREW, ST3-15	ABCD.....
	89-113-625-080	0E	C-TR, 2SA1362GR	ABCD.....
	S0-000-020-010	0E	RUBBER MIC HOLDER	ABCD.....
	S0-001-070-010	1A	CER, FILTER	ABCD.....
	S0-001-650-070		IFT, S7N7B165N	ABCD.....
	S0-004-500-130		CER, FILTER PFS450A	ABCD.....
	S0-012-730-070		IFT, 5M4A1273R	ABCD.....
	S0-014-920-070		IFT, 5M1A1492N	ABCD.....
	S0-015-270-070		IFT, 5M7A1527N	ABCD.....
	S0-020-003-510		JACK, HP ST 3.5MM	ABCD.....
	S0-027-900-050		IFT, 5M7A279R 5MM	ABCD.....
	S0-036-300-100	0E	IFT, 4A363R(B)	ABCD.....
	S0-073-270-000		LCD DISPLAY	ABCD.....
	S0-100-401-200	0E	ZENER, 4.0V 1/2W	ABCD.....
	S0-169-383-500	1B	ANT, ROD TELESCOP	ABCD.....


PARTS LIST - 2

S0-206-020-020	APD-EI41NOR&500MA/DO 115/230V:	..C.....
S0-206-020-030	APD-EI41JIS&500MA/SO	A.....
S0-206-020-040	APD-EI41EN&&500MA/SO 230V:6VDC	...D.....
S0-510-305-000	1E IC, TA7417AP	ABCD.....
S1-018-280-000	IC, LA1828	ABCD.....
S1-065-010-000	JACK, DC	ABCD.....
S1-203-120-000	SW, PUSH 1P2T	ABCD.....
S1-291-000-600	1A MIC, CONDENSER	ABCD.....
S1-330-206-020	APD-EI41BABT500MA/SO 230V:6VDC	.B.....
S1-491-210-000	IC, PST9121	ABCD.....
S1-926-180-000	COIL ANT ASSY 5-8-60	ABCD.....
S2-001-690-000	1A TRIMMER TZ03R300FR169	ABCD.....
S2-020-850-000	0E SFR, 2K/2.2K	ABCD.....
S2-206-220-000	SW, PUSH 2P2T	ABCD.....
S2-240-010-200	SPK 02.25 0040HM00.5W	ABCD.....
S2-524-023-000	1B IC, KA2402	ABCD.....
S3-009-820-000	1A TR, 2SC982TM	ABCD.....
S3-022-090-000	1B IC, KA2209	ABCD.....
S3-245-800-000	0E TR, 2SC2458-Y	ABCD.....
S3-327-682-000	X'TAL, 32.768 KHZ	ABCD.....
S4-300-710-000	SW, SLIDE 4P3T	ABCD.....
S6-010-000-000	CER, RESONATOR 1000KHZ	ABCD.....
S6-072-002-000	1C X'TAL, 7.2MHZ	ABCD.....
S6-938-250-000	0E PLATE, DOOR CASS	ABCD.....
S6-938-260-000	0E PLATE, SPR CASS	ABCD.....
S6-938-270-000	0E PLATE, SPR REC	ABCD.....
S6-938-280-000	0E SPR, BATT A(-)	ABCD.....
S7-805-000-020	0E TR, PE8050B, C, D	ABCD.....
S7-855-000-020	1A TR, PE8550B, C	ABCD.....
S8-CS7-010-100	CAB, FRONT	
S8-CS7-010-300	CAB, FRONT	A.C.....
S8-CS7-010-400	CAB, FRONT	.B.D.....
S8-CS7-020-010	CAB, REAR	A.C.....
S8-CS7-020-020	CAB, REAR	.B.D.....
S8-CS7-030-100	DOOR, CASS	
S8-CS7-030-200	DOOR, CASS	.B.D.....
S8-CS7-030-300	DOOR, CASS	A.C.....
S8-CS7-040-100	WINDOW, DOOR CASS	
S8-CS7-040-200	WINDOW, DOOR CASS	ABCD.....
S8-CS7-050-010	PANEL, CASS	ABCD.....
S8-CS7-060-010	DOOR, BATT	A.C.....
S8-CS7-060-020	DOOR, BATT	.B.D.....
S8-CS7-070-000	HOLDER, LED	ABCD.....
S8-CS7-080-000	KNOB, STOP	ABCD.....
S8-CS7-090-000	KNOB, F. FWD	ABCD.....
S8-CS7-100-000	KNOB, REWIND	ABCD.....
S8-CS7-110-000	KNOB, PLAY	ABCD.....
S8-CS7-120-000	KEY, RECORD	ABCD.....
S8-CS7-130-000	KNOB, SLIDE FUNCTION	ABCD.....
S8-CS7-140-000	KNOB, VOLUME	ABCD.....
S8-CS7-150-010	SPKR, PANEL(L)	ABCD.....
S8-CS7-160-010	SPKR, PANEL(R)	ABCD.....
S8-CS7-170-010	HANDLE	A.C.....
S8-CS7-170-020	HANDLE	.B.D.....
S8-CS7-180-010	KNOB, TUNING	A.C.....
S8-CS7-180-020	KNOB, TUNING	.B.D.....
S8-CS7-190-000	BRACKET DISPLAY	ABCD.....
S8-CS7-220-010	SPKR, GRILL(L)	A.C.....
S8-CS7-220-020	SPKR, GRILL(L)	.B.D.....
S8-CS7-230-010	SPKR, GRILL(R)	A.C.....
S8-CS7-230-020	SPKR, GRILL(R)	.B.D.....
S8-CS7-250-000	ADAPTOR KNOB SLIDE	ABCD.....
S8-CS7-910-100	INSTRUCTION BOOK	
S8-CS7-910-200	INSTRUCTION BOOK(ECA)	..C.....


PARTS LIST - 3

S8-CS7-910-300	INSTRUCTION BOOK	AB.D.....
S8-CS8-190-000	KNOB, SW Q SOUND	ABCD.....
S8-CS8-300-000	HOLDER BAR ANT	ABCD.....
S8-RU5-190-000 0E	PLATE, CONTACT	ABCD.....
SE-145-031-050 1B	RES, VAR RK14K1210	ABCD.....

SCHEMATIC DIAGRAM - 1



SCHEMATIC DIAGRAM - 2





サービス技術ニュース	
番号	連絡内容
Gー ー	
Gー ー	
Gー ー	

アイワ株式会社
AIWA CO.,LTD.

737004

Tokyo Japan