


aiwa

NSX - 2500 NSX - 250



COMPACT DISC STEREO SYSTEM

- BASIC TAPE MECHANISM : TN - 21ZSW / TN - 521ZSW
- BASIC CD MECHANISM : KSL - 2101A
- TYPE. U.C (NSX - 2500)
- TYPE. HE.LH.HR.E.K (NSX - 250)

[SUPPLEMENT]

- Only the modifications are stated in this manual.
Use this manual with XG - 220, NSX - 220 service manual
(S/M Code No.0212).

ALTERNATION PARTS LIST


ELECTRICAL MAIN PARTS LIST


REF. NO.	PART NO.	DESCRIPTION
===IC===		
	S3-131-521-80A	IC, BA15218N
===DIODE===		
	S3-313-510-000	DIODE, 1N4002
===PHONE AMP CIRCUIT BOARD SECTION(HE, HR ONLY)===		
C201	S2-422-700-21A	CAP, E 220UF-16V(HE, HR)
C203	87-010-403-010	CAP, E 3. 3UF-50V(HE, HR)
C205	87-010-403-010	CAP, E 3. 3UF-50V(HE, HR)
C206	87-010-403-010	CAP, E 3. 3UF-50V(HE, HR)
C213	87-010-403-010	CAP, E 3. 3UF-50V(HE, HR)
C214	87-010-403-010	CAP, E 3. 3UF-50V(HE, HR)
C216	87-010-403-010	CAP, E 3. 3UF-50V(HE, HR)
C217	S2-410-500-51A	CAP, E 1UF-50V(HE, HR)
C218	S2-410-500-51A	CAP, E 1UF-50V(HE, HR)
C219	S2-422-700-21A	CAP, E 220UF-16V(HE, HR)
C220	87-010-402-010	CAP, E 2. 2UF-50V(HE, HR)
C221	S2-410-500-51A	CAP, E 1UF-50V(HE, HR)
C222	S2-410-500-51A	CAP, E 1UF-50V(HE, HR)
C223	87-010-402-010	CAP, E 2. 2UF-50V(HE, HR)
C224	S2-433-700-21A	CAP, E 33UF-25V(HE, HR)
C225	S2-410-700-31A	CAP, E 100UF-25V(HE, HR)
C226	S2-410-700-31A	CAP, E 100UF-25V(HE, HR)
C227	S2-447-600-31A	CAP, E 47UF-50V(HE, HR)
C228	S2-410-700-31A	CAP, E 100UF-25V(HE, HR)
C229	87-010-403-010	CAP, E 3. 3UF-50V(HE, HR)
C230	87-010-403-010	CAP, E 3. 3UF-50V(HE, HR)
C235	87-010-404-010	CAP, E 4. 7UF-50V(HE, HR)

REF. NO.	PART NO.	DESCRIPTION
===MAIN AMP CIRCUIT BOARD SECTION===		
C217	S2-410-500-51A	CAP, E 1UF-50V(LH, U, C, E, K)
C218	S2-410-500-51A	CAP, E 1UF-50V(LH, U, C, E, K)
C219	S2-422-700-21A	CAP, E 220UF-16V(LH, U, C, E, K)
C220	87-010-402-010	CAP, E 2. 2UF-50V(LH, U, C, E, K)
C221	S2-410-500-51A	CAP, E 1UF-50V(LH, U, C, E, K)
C222	S2-410-500-51A	CAP, E 1UF-50V(LH, U, C, E, K)
C223	87-010-402-010	CAP, E 2. 2UF-50V(LH, U, C, E, K)
C224	S2-433-700-21A	CAP, E 33UF-25V(LH, U, C, E, K)
C225	S2-410-700-31A	CAP, E 100UF-25V(LH, U, C, E, K)
C226	S2-410-700-31A	CAP, E 100UF-25V(LH, U, C, E, K)
C227	S2-447-600-31A	CAP, E 47UF-50V(LH, U, C, E, K)
C228	S2-410-700-31A	CAP, E 100UF-25V(LH, U, C, E, K)
C235	87-010-404-010	CAP, E 4. 7UF-50V(LH, U, C, E, K)
===POWER CIRCUIT BOARD SECTION===		
△	S5-323-399-10B	FUSE CLIP 5A 250V VDE
△	S5-321-119-10B	FUSE CLIP 6A 250V UL CSA(U, C)
△F501	S5-310-632-51B	FUSE AGC 6. 3A 250V(EXCEPT U, C)
△F501	S5-310-702-50B	FUSE 7A 250V(U, C)
△F502	S5-310-202-50B	FUSE 2A 250V
===MISCELLANEOUS===		
△	S5-795-810-02M	AC CORD 2. 5M 2X0. 75MM(HE, HR)
△	S5-795-810-01M	AC CORD 2M BLK(U, C)
△	S5-795-810-03H	AC CORD 2M(LH)
△	S5-795-810-02H	AC CORD 2. 5M PLUG E VER(E)
△PT1	S5-235-840-08T	TRANS, 115/230V(HE, LH, HR)
△PT1	S5-235-840-01T	TRANS, 120/240V(U, C)
△PT1	S5-235-840-02T	TRANS, 230V(E)

ACCESSORIES/PACKAGE LIST

PART NO. CHANGED TO	REF. NO.	PART NO.	DESCRIPTION	COMMON MODEL	Q.TY
	1	S5-715-810-010	AM LOOP ANTENNA		1
	2	S6-015-810-080	I. B. (E, K)		1
	2	S6-015-810-010	I. B. (U, C)		1
	2	S6-015-810-090	I. B. (HE, LH, HR)		1
	3	S9-158-401-040	REMOCON ASSY (HE, HR, U, C, E, K)		1
	3	S9-158-408-040	REMOCON ASSY (LH)		1
	4	S5-070-020-01S	AC PLUG ADAPTOR (HE, HR)		1
	4	S5-070-000-080	AC PLUG ADAPTOR FLAT (LH)		1





ALTERNATION PARTS LIST

MECHANICAL PARTS LIST

PART NO. CHANGED TO	REF. NO.	PART NO.	DESCRIPTION	COMMON MODEL	Q'TY
	1-1	S7-358-410-040	REVERSE DOOR COVER (HE, HR, LH, E)		1
	1-1	S7-358-410-020	DOOR COVER B (U, C)		1
	1-5	S7-358-410-010	DOOR COVER A		1
	1-6	S7-358-000-160	CASS DOOR B		1
	1-8	S4-525-830-011	CASS DOOR SPR		2
	1-10	S4-058-010-010	CASS TAPE HOLD SPR		4
	1-11	S6-045-840-150	CASS FUNCTION REVERSE OVERLAY (HE, HR, LH, E)		1
	1-11	S6-045-840-040	CASS FUNCTION B OVERLAY (U, C)		1
	1-12	S6-045-840-030	CASS FUNCTION A OVERLAY		1
	1-13	S7-358-430-010	LCD DISPLAY LENS		1
	1-14	S7-358-401-040	FRONT PANEL (HE, HR)		1
	1-14	S7-358-401-050	FRONT PANEL (LH, E)		1
	1-14	S7-358-401-030	FRONT PANEL (U, C)		1
	1-20	S7-358-410-030	CD DOOR		1
	1-25	S7-358-420-030	BAND BUTTON		1
	1-30	S7-358-420-020	FM MODE BUTTON		1
	1-32	S7-358-420-040	VOL KNOB		1
	1-33	S7-358-100-200	CASS BUTTON SMALL	12 (EXCEPT U, C)	
	1-34	S7-358-000-200	CASS BUTTON LARGE (U, C)	10 (U, C)	1
	2-13	S4-058-100-050	REAR CABINET		1
	2-14	S5-795-810-02H	AC CORD 2.5M PLUG E VER (HE, HR, E)		1
	2-14	S5-795-810-010	AC CORD 2M BLK (U, C)		1
	2-26	S7-358-420-010	FUNC BUTTON		1
	8-2	S7-358-401-010	FRONT SPEAKER PANEL (HE, HR, LH)		2
	8-2	S7-358-401-020	FRONT SPEAKER PANEL (U, C, E)		2
	8-5	S5-615-810-000	SPEAKER 4 - 20W		2
	8-6	S8-026-581-010	WOODEN SPEAKER BOX		2

サービス技術ニュース	
番号	連絡内容
G - -	
G - -	
G - -	

アイワ株式会社
AIWA CO.,LTD.

912162 750038

Tokyo Japan