



TP-M140
TP-M240

Y,YL,YU

YH

SERVICE MANUAL

MICROCASSETTE RECORDER

BASIC TAPE MECHANISM : M-187

- Replace this Service manual with "Revision Publishing" when it is issued.

aiwa

S/M Code No. 09-012-443-2T1

SIMPLE

DATA

PARTS LIST

! = Δ SAFTY PARTS
 C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use Japanese.

! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME
X	ACCESSORY		84-TM1-637-010	--	TAPE, MICRO 30	YBC	TP-M140
X	ACCESSORY		87-B30-322-010	--	TAPE, MICRO 60	YUB3SC	TP-M140
X	ACCESSORY		87-B30-322-010	--	TAPE, MICRO 60	YUBSC	TP-M140
X	ACCESSORY		87-B30-324-010	1B	BAT, LR6 1P	YUB3SC	TP-M140
X	ACCESSORY		87-B30-324-010	1B	BAT, LR6 1P	YUBSC	TP-M140
O	APPEARANCE		8A-HX8-002-110	--	CABI, REAR B M115 YU	YBC	TP-M140
O	APPEARANCE		8A-HX8-002-110	--	CABI, REAR B M115 YU	YLBCC	TP-M140
O	APPEARANCE		8B-HX6-004-010	--	COVER, MIC	YUB3SC	TP-M140
O	APPEARANCE		8B-HX6-004-010	--	COVER, MIC	YUBSC	TP-M140
O	APPEARANCE		8B-HX7-001-010	--	CABI, FRONT	YUB3SC	TP-M140
O	APPEARANCE		8B-HX7-001-010	--	CABI, FRONT	YUBSC	TP-M140
O	APPEARANCE		8B-HX7-002-010	--	LID, CASSETTE	YUB3SC	TP-M140
O	APPEARANCE		8B-HX7-002-010	--	LID, CASSETTE	YUBSC	TP-M140
O	APPEARANCE		8B-HX7-005-010	--	CABI, FRONT B	YBC	TP-M140
O	APPEARANCE		8B-HX7-005-010	--	CABI, FRONT B	YLBCC	TP-M140
O	APPEARANCE		8B-HX7-006-010	--	LID, CASSETTE B	YBC	TP-M140
O	APPEARANCE		8B-HX7-006-010	--	LID, CASSETTE B	YLBCC	TP-M140
O	APPEARANCE		8B-HX7-007-010	--	COVER, MIC B	YBC	TP-M140
O	APPEARANCE		8B-HX7-007-010	--	COVER, MIC B	YLBCC	TP-M140
O	APPEARANCE		8B-HX7-008-010	--	WINDOW, CASSETTE B	YBC	TP-M140
O	APPEARANCE		8B-HX7-008-010	--	WINDOW, CASSETTE B	YLBCC	TP-M140
O	APPEARANCE		8B-HX7-008-010	--	WINDOW, CASSETTE B	YUB3SC	TP-M140
O	APPEARANCE		8B-HX7-008-010	--	WINDOW, CASSETTE B	YUBSC	TP-M140
O	APPEARANCE		8B-HX7-011-010	--	LENS, COUNTER M140 B	YBC	TP-M140
O	APPEARANCE		8B-HX7-011-010	--	LENS, COUNTER M140 B	YLBCC	TP-M140
O	APPEARANCE		8B-HX7-011-010	--	LENS, COUNTER M140 B	YUB3SC	TP-M140
O	APPEARANCE		8B-HX7-011-010	--	LENS, COUNTER M140 B	YUBSC	TP-M140
O	APPEARANCE		8Z-HX5-006-010	1A	LID, BATT	YUB3SC	TP-M140
O	APPEARANCE		8Z-HX5-006-010	1A	LID, BATT	YUBSC	TP-M140
O	APPEARANCE		8Z-HX5-020-010	--	LENS, LED	YLBCC	TP-M140
O	APPEARANCE		8Z-HX5-020-010	0E	LENS, LED	YBC	TP-M140
O	APPEARANCE		8Z-HX5-020-010	0E	LENS, LED	YUB3SC	TP-M140
O	APPEARANCE		8Z-HX5-020-010	0E	LENS, LED	YUBSC	TP-M140
O	APPEARANCE		8Z-HX7-004-110	--	CABI, REAR Y	YUB3SC	TP-M140
O	APPEARANCE		8Z-HX7-004-110	--	CABI, REAR Y	YUBSC	TP-M140
O	APPEARANCE		8Z-HX7-007-010	1A	LID, BATT YU	YBC	TP-M140
O	APPEARANCE		8Z-HX7-007-010	1A	LID, BATT YU	YLBCC	TP-M140
O	KNOB		8B-HX4-007-010	--	KNOB, SL MIC	YUB3SC	TP-M140
O	KNOB		8B-HX4-007-010	--	KNOB, SL MIC	YUBSC	TP-M140
O	KNOB		8B-HX7-010-010	--	KNOB, SL MIC B	YBC	TP-M140
O	KNOB		8B-HX7-010-010	--	KNOB, SL MIC B	YLBCC	TP-M140
O	KNOB		8Z-HX5-015-010	--	KNOB, SL FF/REW	YUB3SC	TP-M140
O	KNOB		8Z-HX5-015-010	--	KNOB, SL FF/REW	YUBSC	TP-M140
O	KNOB		8Z-HX5-016-010	--	KNOB, SL PAUSE	YUB3SC	TP-M140
O	KNOB		8Z-HX5-016-010	--	KNOB, SL PAUSE	YUBSC	TP-M140
O	KNOB		8Z-HX5-017-010	0E	KNOB, SL 1.2/2.4	YUB3SC	TP-M140
O	KNOB		8Z-HX5-017-010	0E	KNOB, SL 1.2/2.4	YUBSC	TP-M140
O	KNOB		8Z-HX5-019-010	0E	KNOB, SL V-SENSOR/ NFR	YUB3SC	TP-M140
O	KNOB		8Z-HX5-019-010	0E	KNOB, SL V-SENSOR/ NFR	YUBSC	TP-M140
O	KNOB		8Z-HX7-013-010	0E	BTN, CASS REC YU	YBC	TP-M140
O	KNOB		8Z-HX7-013-010	0E	BTN, CASS REC YU	YLBCC	TP-M140
O	KNOB		8Z-HX7-014-010	0E	BTN, CASS PLAY YU	YBC	TP-M140
O	KNOB		8Z-HX7-014-010	0E	BTN, CASS PLAY YU	YLBCC	TP-M140
O	KNOB		8Z-HX7-015-010	0E	BTN, CASS STOP YU	YBC	TP-M140
O	KNOB		8Z-HX7-015-010	0E	BTN, CASS STOP YU	YLBCC	TP-M140
O	KNOB		8Z-HX7-016-010	--	BTN, CASS REC Y	YUB3SC	TP-M140
O	KNOB		8Z-HX7-016-010	--	BTN, CASS REC Y	YUBSC	TP-M140
O	KNOB		8Z-HX7-017-010	--	BTN, CASS PLAY Y	YUB3SC	TP-M140
O	KNOB		8Z-HX7-017-010	--	BTN, CASS PLAY Y	YUBSC	TP-M140
O	KNOB		8Z-HX7-018-010	--	BTN, CASS STOP Y	YUB3SC	TP-M140
O	KNOB		8Z-HX7-018-010	--	BTN, CASS STOP Y	YUBSC	TP-M140
O	KNOB		8Z-HX7-019-010	--	KNOB, SL FF/REW YU	YBC	TP-M140
O	KNOB		8Z-HX7-019-010	--	KNOB, SL FF/REW YU	YLBCC	TP-M140
O	KNOB		8Z-HX7-020-010	--	KNOB, SL PAUSE YU	YBC	TP-M140
O	KNOB		8Z-HX7-020-010	--	KNOB, SL PAUSE YU	YLBCC	TP-M140
O	KNOB		8Z-HX7-021-010	0E	KNOB, SL 1.2/2.4 YU	YBC	TP-M140
O	KNOB		8Z-HX7-021-010	0E	KNOB, SL 1.2/2.4 YU	YLBCC	TP-M140
O	KNOB		8Z-HX7-035-010	0E	KNOB, SL V-SENSOR YU	YBC	TP-M140
O	KNOB		8Z-HX7-035-010	0E	KNOB, SL V-SENSOR YU	YLBCC	TP-M140
X	LBL, POP		8B-HX7-970-010	--	LBL, POP Y	YBC	TP-M140

PARTS LIST

! = Δ SAFTY PARTS
 C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use Japanese.

! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME
X	LBL, POP		8B-HX7-972-010	--	LBL, POP YL	YLBCC	TP-M140
O	OTHERS		85-TM5-203-010	--	SPR, BAT (+/-)	YBC	TP-M140
O	OTHERS		85-TM5-203-010	--	SPR, BAT (+/-)	YLBCC	TP-M140
O	OTHERS		85-TM5-203-010	--	SPR, BAT (+/-)	YUB3SC	TP-M140
O	OTHERS		85-TM5-203-010	--	SPR, BAT (+/-)	YUBSC	TP-M140
O	OTHERS		85-TM5-204-010	--	SPR, BAT (+)	YBC	TP-M140
O	OTHERS		85-TM5-204-010	--	SPR, BAT (+)	YLBCC	TP-M140
O	OTHERS		85-TM5-204-010	--	SPR, BAT (+)	YUB3SC	TP-M140
O	OTHERS		85-TM5-204-010	--	SPR, BAT (+)	YUBSC	TP-M140
O	OTHERS		85-TM5-205-010	--	SPR, BAT (-)	YBC	TP-M140
O	OTHERS		85-TM5-205-010	--	SPR, BAT (-)	YLBCC	TP-M140
O	OTHERS		85-TM5-205-010	--	SPR, BAT (-)	YUB3SC	TP-M140
O	OTHERS		85-TM5-205-010	--	SPR, BAT (-)	YUBSC	TP-M140
O	OTHERS		8Z-HX5-200-010	--	HLDR, JACK	YBC	TP-M140
O	OTHERS		8Z-HX5-200-010	--	HLDR, JACK	YLBCC	TP-M140
O	OTHERS		8Z-HX5-200-010	--	HLDR, JACK	YUB3SC	TP-M140
O	OTHERS		8Z-HX5-200-010	--	HLDR, JACK	YUBSC	TP-M140
O	OTHERS		8Z-HX5-201-010	--	SPR, CASS	YLBCC	TP-M140
O	OTHERS		8Z-HX5-201-010	OE	SPR, CASS	YBC	TP-M140
O	OTHERS		8Z-HX5-201-010	OE	SPR, CASS	YUB3SC	TP-M140
O	OTHERS		8Z-HX5-201-010	OE	SPR, CASS	YUBSC	TP-M140
X	OTHERS		8Z-HX5-202-010	--	SH, INSULATION	YBC	TP-M140
X	OTHERS		8Z-HX5-202-010	--	SH, INSULATION	YLBCC	TP-M140
X	OTHERS		8Z-HX5-202-010	--	SH, INSULATION	YUB3SC	TP-M140
X	OTHERS		8Z-HX5-202-010	--	SH, INSULATION	YUBSC	TP-M140
X	OTHERS 1		8B-HX4-605-010	--	WIRE, B-2-7-2/2 AWG28#1571	YBC	TP-M140
X	OTHERS 1		8B-HX4-605-010	--	WIRE, B-2-7-2/2 AWG28#1571	YLBCC	TP-M140
X	OTHERS 1		8B-HX4-605-010	--	WIRE, B-2-7-2/2 AWG28#1571	YUB3SC	TP-M140
X	OTHERS 1		8B-HX4-605-010	--	WIRE, B-2-7-2/2 AWG28#1571	YUBSC	TP-M140
X	OTHERS 1		8B-HX4-606-010	--	WIRE, B+0-7-2/2 AWG28#1571	YBC	TP-M140
X	OTHERS 1		8B-HX4-606-010	--	WIRE, B+0-7-2/2 AWG28#1571	YLBCC	TP-M140
X	OTHERS 1		8B-HX4-606-010	--	WIRE, B+0-7-2/2 AWG28#1571	YUB3SC	TP-M140
X	OTHERS 1		8B-HX4-606-010	--	WIRE, B+0-7-2/2 AWG28#1571	YUBSC	TP-M140
X	OTHERS 1		8B-HX4-607-010	--	WIRE, MIC-1-7-2/2 #30	YBC	TP-M140
X	OTHERS 1		8B-HX4-607-010	--	WIRE, MIC-1-7-2/2 #30	YLBCC	TP-M140
X	OTHERS 1		8B-HX4-607-010	--	WIRE, MIC-1-7-2/2 #30	YUB3SC	TP-M140
X	OTHERS 1		8B-HX4-607-010	--	WIRE, MIC-1-7-2/2 #30	YUBSC	TP-M140
X	OTHERS 1		8B-HX4-608-010	--	WIRE, MIC+0-7-2/2 #30	YBC	TP-M140
X	OTHERS 1		8B-HX4-608-010	--	WIRE, MIC+0-7-2/2 #30	YLBCC	TP-M140
X	OTHERS 1		8B-HX4-608-010	--	WIRE, MIC+0-7-2/2 #30	YUB3SC	TP-M140
X	OTHERS 1		8B-HX4-608-010	--	WIRE, MIC+0-7-2/2 #30	YUBSC	TP-M140
X	OTHERS 1		8B-HX4-609-010	--	WIRE, SP-0-10-2/2 #30	YBC	TP-M140
X	OTHERS 1		8B-HX4-609-010	--	WIRE, SP-0-10-2/2 #30	YLBCC	TP-M140
X	OTHERS 1		8B-HX4-609-010	--	WIRE, SP-0-10-2/2 #30	YUB3SC	TP-M140
X	OTHERS 1		8B-HX4-609-010	--	WIRE, SP-0-10-2/2 #30	YUBSC	TP-M140
X	OTHERS 1		8B-HX4-610-010	--	WIRE, SP+1-10-2/2 #30	YBC	TP-M140
X	OTHERS 1		8B-HX4-610-010	--	WIRE, SP+1-10-2/2 #30	YLBCC	TP-M140
X	OTHERS 1		8B-HX4-610-010	--	WIRE, SP+1-10-2/2 #30	YUB3SC	TP-M140
X	OTHERS 1		8B-HX4-610-010	--	WIRE, SP+1-10-2/2 #30	YUBSC	TP-M140
X	OTHERS 1		8B-HX4-611-010	--	WIRE, 140 8 32#UL2851 R/P HEAD	YBC	TP-M140
X	OTHERS 1		8B-HX4-611-010	--	WIRE, 140 8 32#UL2851 R/P HEAD	YLBCC	TP-M140
X	OTHERS 1		8B-HX4-611-010	--	WIRE, 140 8 32#UL2851 R/P HEAD	YUB3SC	TP-M140
X	OTHERS 1		8B-HX4-611-010	--	WIRE, 140 8 32#UL2851 R/P HEAD	YUBSC	TP-M140
X	OTHERS 1		8B-HX4-612-010	--	TUBE, SPACER 0.86-3 4	YBC	TP-M140
X	OTHERS 1		8B-HX4-612-010	--	TUBE, SPACER 0.86-3 4	YLBCC	TP-M140
X	OTHERS 1		8B-HX4-612-010	--	TUBE, SPACER 0.86-3 4	YUB3SC	TP-M140
X	OTHERS 1		8B-HX4-612-010	--	TUBE, SPACER 0.86-3 4	YUBSC	TP-M140
X	OTHERS 1		8B-HX4-613-010	--	WIRE, MIC-SENS	YBC	TP-M140
X	OTHERS 1		8B-HX4-613-010	--	WIRE, MIC-SENS	YLBCC	TP-M140
X	OTHERS 1		8B-HX4-613-010	--	WIRE, MIC-SENS	YUB3SC	TP-M140
X	OTHERS 1		8B-HX4-613-010	--	WIRE, MIC-SENS	YUBSC	TP-M140
X	PACKING		84-TM1-868-010	--	P. P SHEET	YBC	TP-M140
X	PACKING		84-TM1-868-010	--	P. P SHEET	YLBCC	TP-M140
X	PACKING		84-TM1-868-010	--	P. P SHEET	YUB3SC	TP-M140
X	PACKING		84-TM1-868-010	--	P. P SHEET	YUBSC	TP-M140
X	PACKING		87-B40-341-010	OE	LBL, S YUB3	YUB3SC	TP-M140
X	PACKING		8B-HX4-851-010	--	COVER, TOP AUBSC	YUB3SC	TP-M140
X	PACKING		8B-HX4-851-010	--	COVER, TOP AUBSC	YUBSC	TP-M140
X	PACKING		8B-HX4-852-010	--	COVER, BOTTOM AUBSC	YUB3SC	TP-M140
X	PACKING		8B-HX4-852-010	--	COVER, BOTTOM AUBSC	YUBSC	TP-M140

PARTS LIST

! = Δ SAFTY PARTS
 C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use Japanese.

! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME
O	PRE-MAIN AMP	C 0010	87-010-075-010	0E	CAP,E 10-16 M 5L SRE	YUBSC	TP-M140
O	PRE-MAIN AMP	C 0011	87-010-490-010	0E	CAP,E 0.1-50 M KS	YBC	TP-M140
O	PRE-MAIN AMP	C 0011	87-010-490-010	0E	CAP,E 0.1-50 M KS	YLBCC	TP-M140
O	PRE-MAIN AMP	C 0011	87-010-490-010	0E	CAP,E 0.1-50 M KS	YUB3SC	TP-M140
O	PRE-MAIN AMP	C 0011	87-010-490-010	0E	CAP,E 0.1-50 M KS	YUBSC	TP-M140
O	PRE-MAIN AMP	C 0012	87-A10-952-080	0E	C-CAP,TN 22-4 M A MCM	YBC	TP-M140
O	PRE-MAIN AMP	C 0012	87-A10-952-080	0E	C-CAP,TN 22-4 M A MCM	YLBCC	TP-M140
O	PRE-MAIN AMP	C 0012	87-A10-952-080	0E	C-CAP,TN 22-4 M A MCM	YUB3SC	TP-M140
O	PRE-MAIN AMP	C 0012	87-A10-952-080	0E	C-CAP,TN 22-4 M A MCM	YUBSC	TP-M140
O	PRE-MAIN AMP	C 0013	87-010-082-010	0E	CAP,E 220-4 M 5L SRE	YBC	TP-M140
O	PRE-MAIN AMP	C 0013	87-010-082-010	0E	CAP,E 220-4 M 5L SRE	YLBCC	TP-M140
O	PRE-MAIN AMP	C 0013	87-010-082-010	0E	CAP,E 220-4 M 5L SRE	YUB3SC	TP-M140
O	PRE-MAIN AMP	C 0013	87-010-082-010	0E	CAP,E 220-4 M 5L SRE	YUBSC	TP-M140
O	PRE-MAIN AMP	C 0014	87-010-082-010	0E	CAP,E 220-4 M 5L SRE	YBC	TP-M140
O	PRE-MAIN AMP	C 0014	87-010-082-010	0E	CAP,E 220-4 M 5L SRE	YLBCC	TP-M140
O	PRE-MAIN AMP	C 0014	87-010-082-010	0E	CAP,E 220-4 M 5L SRE	YUB3SC	TP-M140
O	PRE-MAIN AMP	C 0014	87-010-082-010	0E	CAP,E 220-4 M 5L SRE	YUBSC	TP-M140
O	PRE-MAIN AMP	C 0015	87-010-082-010	0E	CAP,E 220-4 M 5L SRE	YBC	TP-M140
O	PRE-MAIN AMP	C 0015	87-010-082-010	0E	CAP,E 220-4 M 5L SRE	YLBCC	TP-M140
O	PRE-MAIN AMP	C 0015	87-010-082-010	0E	CAP,E 220-4 M 5L SRE	YUB3SC	TP-M140
O	PRE-MAIN AMP	C 0015	87-010-082-010	0E	CAP,E 220-4 M 5L SRE	YUBSC	TP-M140
O	PRE-MAIN AMP	C 0016	87-012-274-080	0E	C-CAP,U 1000P-50 K B	YBC	TP-M140
O	PRE-MAIN AMP	C 0016	87-012-274-080	0E	C-CAP,U 1000P-50 K B	YLBCC	TP-M140
O	PRE-MAIN AMP	C 0016	87-012-274-080	0E	C-CAP,U 1000P-50 K B	YUB3SC	TP-M140
O	PRE-MAIN AMP	C 0016	87-012-274-080	0E	C-CAP,U 1000P-50 K B	YUBSC	TP-M140
O	PRE-MAIN AMP	C 0017	87-010-505-080	0E	C-CAP,TN 1-16 M ECS	YBC	TP-M140
O	PRE-MAIN AMP	C 0017	87-010-505-080	0E	C-CAP,TN 1-16 M ECS	YLBCC	TP-M140
O	PRE-MAIN AMP	C 0017	87-010-505-080	0E	C-CAP,TN 1-16 M ECS	YUB3SC	TP-M140
O	PRE-MAIN AMP	C 0017	87-010-505-080	0E	C-CAP,TN 1-16 M ECS	YUBSC	TP-M140
O	PRE-MAIN AMP	C 0018	87-010-504-080	0E	C-CAP,TN 0.47-25 M ECS	YBC	TP-M140
O	PRE-MAIN AMP	C 0018	87-010-504-080	0E	C-CAP,TN 0.47-25 M ECS	YLBCC	TP-M140
O	PRE-MAIN AMP	C 0018	87-010-504-080	0E	C-CAP,TN 0.47-25 M ECS	YUB3SC	TP-M140
O	PRE-MAIN AMP	C 0018	87-010-504-080	0E	C-CAP,TN 0.47-25 M ECS	YUBSC	TP-M140
O	PRE-MAIN AMP	C 0019	87-A11-056-080	0E	C-CAP,U 1-10 Z F	YBC	TP-M140
O	PRE-MAIN AMP	C 0019	87-A11-056-080	0E	C-CAP,U 1-10 Z F	YLBCC	TP-M140
O	PRE-MAIN AMP	C 0019	87-A11-056-080	0E	C-CAP,U 1-10 Z F	YUB3SC	TP-M140
O	PRE-MAIN AMP	C 0019	87-A11-056-080	0E	C-CAP,U 1-10 Z F	YUBSC	TP-M140
O	PRE-MAIN AMP	C 0020	87-A10-025-080	0E	C-CAP,U 0.22-16 Z F	YBC	TP-M140
O	PRE-MAIN AMP	C 0020	87-A10-025-080	0E	C-CAP,U 0.22-16 Z F	YLBCC	TP-M140
O	PRE-MAIN AMP	C 0020	87-A10-025-080	0E	C-CAP,U 0.22-16 Z F	YUB3SC	TP-M140
O	PRE-MAIN AMP	C 0020	87-A10-025-080	0E	C-CAP,U 0.22-16 Z F	YUBSC	TP-M140
O	PRE-MAIN AMP	C 0021	87-A10-025-080	0E	C-CAP,U 0.22-16 Z F	YBC	TP-M140
O	PRE-MAIN AMP	C 0021	87-A10-025-080	0E	C-CAP,U 0.22-16 Z F	YLBCC	TP-M140
O	PRE-MAIN AMP	C 0021	87-A10-025-080	0E	C-CAP,U 0.22-16 Z F	YUB3SC	TP-M140
O	PRE-MAIN AMP	C 0021	87-A10-025-080	0E	C-CAP,U 0.22-16 Z F	YUBSC	TP-M140
O	PRE-MAIN AMP	C 0022	87-A11-791-080	1A	C-CAP,TN 10-4 M F93 A	YBC	TP-M140
O	PRE-MAIN AMP	C 0022	87-A11-791-080	1A	C-CAP,TN 10-4 M F93 A	YLBCC	TP-M140
O	PRE-MAIN AMP	C 0022	87-A11-791-080	1A	C-CAP,TN 10-4 M F93 A	YUB3SC	TP-M140
O	PRE-MAIN AMP	C 0022	87-A11-791-080	1A	C-CAP,TN 10-4 M F93 A	YUBSC	TP-M140
O	PRE-MAIN AMP	C 0023	87-010-494-010	0E	CAP,E 1-50 M KS	YBC	TP-M140
O	PRE-MAIN AMP	C 0023	87-010-494-010	0E	CAP,E 1-50 M KS	YLBCC	TP-M140
O	PRE-MAIN AMP	C 0023	87-010-494-010	0E	CAP,E 1-50 M KS	YUB3SC	TP-M140
O	PRE-MAIN AMP	C 0023	87-010-494-010	0E	CAP,E 1-50 M KS	YUBSC	TP-M140
O	PRE-MAIN AMP	C 0024	87-010-757-080	0E	C-CAP,U 0.047-25 Z F	YBC	TP-M140
O	PRE-MAIN AMP	C 0024	87-010-757-080	0E	C-CAP,U 0.047-25 Z F	YLBCC	TP-M140
O	PRE-MAIN AMP	C 0024	87-010-757-080	0E	C-CAP,U 0.047-25 Z F	YUB3SC	TP-M140
O	PRE-MAIN AMP	C 0024	87-010-757-080	0E	C-CAP,U 0.047-25 Z F	YUBSC	TP-M140
O	PRE-MAIN AMP	C 0025	87-A11-056-080	0E	C-CAP,U 1-10 Z F	YBC	TP-M140
O	PRE-MAIN AMP	C 0025	87-A11-056-080	0E	C-CAP,U 1-10 Z F	YLBCC	TP-M140
O	PRE-MAIN AMP	C 0025	87-A11-056-080	0E	C-CAP,U 1-10 Z F	YUB3SC	TP-M140
O	PRE-MAIN AMP	C 0025	87-A11-056-080	0E	C-CAP,U 1-10 Z F	YUBSC	TP-M140
O	PRE-MAIN AMP	C 0027	87-012-282-080	0E	C-CAP,U 4700P-50 K B	YBC	TP-M140
O	PRE-MAIN AMP	C 0027	87-012-282-080	0E	C-CAP,U 4700P-50 K B	YLBCC	TP-M140
O	PRE-MAIN AMP	C 0027	87-012-282-080	0E	C-CAP,U 4700P-50 K B	YUB3SC	TP-M140
O	PRE-MAIN AMP	C 0027	87-012-282-080	0E	C-CAP,U 4700P-50 K B	YUBSC	TP-M140
S	PRE-MAIN AMP	D 0001	87-001-167-080	0E	C-DIODE,1SS302	YBC	TP-M140
S	PRE-MAIN AMP	D 0001	87-001-167-080	0E	C-DIODE,1SS302	YLBCC	TP-M140
S	PRE-MAIN AMP	D 0001	87-001-167-080	0E	C-DIODE,1SS302	YUB3SC	TP-M140
S	PRE-MAIN AMP	D 0001	87-001-167-080	0E	C-DIODE,1SS302	YUBSC	TP-M140
S	PRE-MAIN AMP	D 0002	87-A40-822-040	0E	C-DIODE,CRS01	YBC	TP-M140

PARTS LIST

! = Δ SAFTY PARTS
 C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use Japanese.

! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME
S	PRE-MAIN AMP	D 0002	87-A40-822-040	0E	C-DIODE, CRS01	YLBCC	TP-M140
S	PRE-MAIN AMP	D 0002	87-A40-822-040	0E	C-DIODE, CRS01	YUB3SC	TP-M140
S	PRE-MAIN AMP	D 0002	87-A40-822-040	0E	C-DIODE, CRS01	YUBSC	TP-M140
S	PRE-MAIN AMP	IC 0001	85-TM5-604-010	1E	IC, LA4165M	YBC	TP-M140
S	PRE-MAIN AMP	IC 0001	85-TM5-604-010	1E	IC, LA4165M	YLBCC	TP-M140
S	PRE-MAIN AMP	IC 0001	85-TM5-604-010	1E	IC, LA4165M	YUB3SC	TP-M140
S	PRE-MAIN AMP	IC 0001	85-TM5-604-010	1E	IC, LA4165M	YUBSC	TP-M140
S	PRE-MAIN AMP	IC 0002	87-017-643-080	1B	C-IC, MM1206XF	YBC	TP-M140
S	PRE-MAIN AMP	IC 0002	87-017-643-080	1B	C-IC, MM1206XF	YUB3SC	TP-M140
S	PRE-MAIN AMP	IC 0002	87-017-643-080	1B	C-IC, MM1206XF	YUBSC	TP-M140
O	PRE-MAIN AMP	J 0001	87-A61-294-010	0E	JACK, 3.5 MONO W/SW	YBC	TP-M140
O	PRE-MAIN AMP	J 0001	87-A61-294-010	0E	JACK, 3.5 MONO W/SW	YLBCC	TP-M140
O	PRE-MAIN AMP	J 0001	87-A61-294-010	0E	JACK, 3.5 MONO W/SW	YUB3SC	TP-M140
O	PRE-MAIN AMP	J 0001	87-A61-294-010	0E	JACK, 3.5 MONO W/SW	YUBSC	TP-M140
O	PRE-MAIN AMP	J 0002	87-A61-124-110	0E	JACK, DC DIA2.75 BLK TC	YBC	TP-M140
O	PRE-MAIN AMP	J 0002	87-A61-124-110	0E	JACK, DC DIA2.75 BLK TC	YLBCC	TP-M140
O	PRE-MAIN AMP	J 0002	87-A61-124-110	0E	JACK, DC DIA2.75 BLK TC	YUB3SC	TP-M140
O	PRE-MAIN AMP	J 0002	87-A61-124-110	0E	JACK, DC DIA2.75 BLK TC	YUBSC	TP-M140
O	PRE-MAIN AMP	J 0002	87-A61-294-010	0E	JACK, 3.5 MONO W/SW	YBC	TP-M140
O	PRE-MAIN AMP	J 0002	87-A61-294-010	0E	JACK, 3.5 MONO W/SW	YLBCC	TP-M140
O	PRE-MAIN AMP	J 0002	87-A61-294-010	0E	JACK, 3.5 MONO W/SW	YUB3SC	TP-M140
O	PRE-MAIN AMP	J 0002	87-A61-294-010	0E	JACK, 3.5 MONO W/SW	YUBSC	TP-M140
X	PRE-MAIN AMP	JR 0001	88-128-000-080	0E	C-JUMPER, 3216	YBC	TP-M140
X	PRE-MAIN AMP	JR 0001	88-128-000-080	0E	C-JUMPER, 3216	YLBCC	TP-M140
X	PRE-MAIN AMP	JR 0001	88-128-000-080	0E	C-JUMPER, 3216	YUB3SC	TP-M140
X	PRE-MAIN AMP	JR 0001	88-128-000-080	0E	C-JUMPER, 3216	YUBSC	TP-M140
X	PRE-MAIN AMP	JR 0002	88-128-000-080	0E	C-JUMPER, 3216	YBC	TP-M140
X	PRE-MAIN AMP	JR 0002	88-128-000-080	0E	C-JUMPER, 3216	YLBCC	TP-M140
X	PRE-MAIN AMP	JR 0002	88-128-000-080	0E	C-JUMPER, 3216	YUB3SC	TP-M140
X	PRE-MAIN AMP	JR 0002	88-128-000-080	0E	C-JUMPER, 3216	YUBSC	TP-M140
X	PRE-MAIN AMP	JR 0003	88-128-000-080	0E	C-JUMPER, 3216	YBC	TP-M140
X	PRE-MAIN AMP	JR 0003	88-128-000-080	0E	C-JUMPER, 3216	YLBCC	TP-M140
X	PRE-MAIN AMP	JR 0003	88-128-000-080	0E	C-JUMPER, 3216	YUB3SC	TP-M140
X	PRE-MAIN AMP	JR 0003	88-128-000-080	0E	C-JUMPER, 3216	YUBSC	TP-M140
X	PRE-MAIN AMP	JR 0004	88-128-000-080	0E	C-JUMPER, 3216	YBC	TP-M140
X	PRE-MAIN AMP	JR 0004	88-128-000-080	0E	C-JUMPER, 3216	YLBCC	TP-M140
X	PRE-MAIN AMP	JR 0004	88-128-000-080	0E	C-JUMPER, 3216	YUB3SC	TP-M140
X	PRE-MAIN AMP	JR 0004	88-128-000-080	0E	C-JUMPER, 3216	YUBSC	TP-M140
X	PRE-MAIN AMP	JR 0005	88-128-000-080	0E	C-JUMPER, 3216	YBC	TP-M140
X	PRE-MAIN AMP	JR 0005	88-128-000-080	0E	C-JUMPER, 3216	YLBCC	TP-M140
X	PRE-MAIN AMP	JR 0005	88-128-000-080	0E	C-JUMPER, 3216	YUB3SC	TP-M140
X	PRE-MAIN AMP	JR 0005	88-128-000-080	0E	C-JUMPER, 3216	YUBSC	TP-M140
X	PRE-MAIN AMP	JR 0006	88-128-000-080	0E	C-JUMPER, 3216	YBC	TP-M140
X	PRE-MAIN AMP	JR 0006	88-128-000-080	0E	C-JUMPER, 3216	YLBCC	TP-M140
X	PRE-MAIN AMP	JR 0006	88-128-000-080	0E	C-JUMPER, 3216	YUB3SC	TP-M140
X	PRE-MAIN AMP	JR 0006	88-128-000-080	0E	C-JUMPER, 3216	YUBSC	TP-M140
X	PRE-MAIN AMP	JR 0007	88-128-000-080	0E	C-JUMPER, 3216	YBC	TP-M140
X	PRE-MAIN AMP	JR 0007	88-128-000-080	0E	C-JUMPER, 3216	YLBCC	TP-M140
X	PRE-MAIN AMP	JR 0007	88-128-000-080	0E	C-JUMPER, 3216	YUB3SC	TP-M140
X	PRE-MAIN AMP	JR 0007	88-128-000-080	0E	C-JUMPER, 3216	YUBSC	TP-M140
X	PRE-MAIN AMP	JR 0008	88-128-000-080	0E	C-JUMPER, 3216	YBC	TP-M140
X	PRE-MAIN AMP	JR 0008	88-128-000-080	0E	C-JUMPER, 3216	YLBCC	TP-M140
X	PRE-MAIN AMP	JR 0008	88-128-000-080	0E	C-JUMPER, 3216	YUB3SC	TP-M140
X	PRE-MAIN AMP	JR 0008	88-128-000-080	0E	C-JUMPER, 3216	YUBSC	TP-M140
X	PRE-MAIN AMP	JR 0009	88-128-000-080	0E	C-JUMPER, 3216	YBC	TP-M140
X	PRE-MAIN AMP	JR 0009	88-128-000-080	0E	C-JUMPER, 3216	YLBCC	TP-M140
X	PRE-MAIN AMP	JR 0009	88-128-000-080	0E	C-JUMPER, 3216	YUB3SC	TP-M140
X	PRE-MAIN AMP	JR 0009	88-128-000-080	0E	C-JUMPER, 3216	YUBSC	TP-M140
X	PRE-MAIN AMP	JR 0010	88-128-000-080	0E	C-JUMPER, 3216	YBC	TP-M140
X	PRE-MAIN AMP	JR 0010	88-128-000-080	0E	C-JUMPER, 3216	YLBCC	TP-M140
X	PRE-MAIN AMP	JR 0010	88-128-000-080	0E	C-JUMPER, 3216	YUB3SC	TP-M140
X	PRE-MAIN AMP	JR 0010	88-128-000-080	0E	C-JUMPER, 3216	YUBSC	TP-M140
X	PRE-MAIN AMP	JR 0011	88-128-000-080	0E	C-JUMPER, 3216	YBC	TP-M140
X	PRE-MAIN AMP	JR 0011	88-128-000-080	0E	C-JUMPER, 3216	YLBCC	TP-M140
X	PRE-MAIN AMP	JR 0011	88-128-000-080	0E	C-JUMPER, 3216	YUB3SC	TP-M140
X	PRE-MAIN AMP	JR 0011	88-128-000-080	0E	C-JUMPER, 3216	YUBSC	TP-M140
X	PRE-MAIN AMP	JR 0012	88-128-000-080	0E	C-JUMPER, 3216	YBC	TP-M140
X	PRE-MAIN AMP	JR 0012	88-128-000-080	0E	C-JUMPER, 3216	YLBCC	TP-M140
X	PRE-MAIN AMP	JR 0012	88-128-000-080	0E	C-JUMPER, 3216	YUB3SC	TP-M140
X	PRE-MAIN AMP	JR 0012	88-128-000-080	0E	C-JUMPER, 3216	YUBSC	TP-M140

PARTS LIST

! = Δ SAFTY PARTS
 C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use Japanese.

! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME
X	PRE-MAIN AMP	JR 0013	88-128-000-080	0E	C-JUMPER, 3216	YBC	TP-M140
X	PRE-MAIN AMP	JR 0013	88-128-000-080	0E	C-JUMPER, 3216	YLBCC	TP-M140
X	PRE-MAIN AMP	JR 0013	88-128-000-080	0E	C-JUMPER, 3216	YUB3SC	TP-M140
X	PRE-MAIN AMP	JR 0013	88-128-000-080	0E	C-JUMPER, 3216	YUBSC	TP-M140
X	PRE-MAIN AMP	JR 0014	88-128-000-080	0E	C-JUMPER, 3216	YBC	TP-M140
X	PRE-MAIN AMP	JR 0014	88-128-000-080	0E	C-JUMPER, 3216	YLBCC	TP-M140
X	PRE-MAIN AMP	JR 0014	88-128-000-080	0E	C-JUMPER, 3216	YUB3SC	TP-M140
X	PRE-MAIN AMP	JR 0014	88-128-000-080	0E	C-JUMPER, 3216	YUBSC	TP-M140
X	PRE-MAIN AMP	JR 0015	88-128-000-080	0E	C-JUMPER, 3216	YBC	TP-M140
X	PRE-MAIN AMP	JR 0015	88-128-000-080	0E	C-JUMPER, 3216	YLBCC	TP-M140
X	PRE-MAIN AMP	JR 0015	88-128-000-080	0E	C-JUMPER, 3216	YUB3SC	TP-M140
X	PRE-MAIN AMP	JR 0015	88-128-000-080	0E	C-JUMPER, 3216	YUBSC	TP-M140
X	PRE-MAIN AMP	JR 0016	88-128-000-080	0E	C-JUMPER, 3216	YBC	TP-M140
X	PRE-MAIN AMP	JR 0016	88-128-000-080	0E	C-JUMPER, 3216	YLBCC	TP-M140
X	PRE-MAIN AMP	JR 0016	88-128-000-080	0E	C-JUMPER, 3216	YUB3SC	TP-M140
X	PRE-MAIN AMP	JR 0016	88-128-000-080	0E	C-JUMPER, 3216	YUBSC	TP-M140
X	PRE-MAIN AMP	JR 0017	88-128-000-080	0E	C-JUMPER, 3216	YBC	TP-M140
X	PRE-MAIN AMP	JR 0017	88-128-000-080	0E	C-JUMPER, 3216	YLBCC	TP-M140
X	PRE-MAIN AMP	JR 0017	88-128-000-080	0E	C-JUMPER, 3216	YUB3SC	TP-M140
X	PRE-MAIN AMP	JR 0017	88-128-000-080	0E	C-JUMPER, 3216	YUBSC	TP-M140
X	PRE-MAIN AMP	JR 0018	88-128-000-080	0E	C-JUMPER, 3216	YBC	TP-M140
X	PRE-MAIN AMP	JR 0018	88-128-000-080	0E	C-JUMPER, 3216	YLBCC	TP-M140
X	PRE-MAIN AMP	JR 0018	88-128-000-080	0E	C-JUMPER, 3216	YUB3SC	TP-M140
X	PRE-MAIN AMP	JR 0018	88-128-000-080	0E	C-JUMPER, 3216	YUBSC	TP-M140
X	PRE-MAIN AMP	JR 0019	88-128-000-080	0E	C-JUMPER, 3216	YBC	TP-M140
X	PRE-MAIN AMP	JR 0019	88-128-000-080	0E	C-JUMPER, 3216	YLBCC	TP-M140
X	PRE-MAIN AMP	JR 0019	88-128-000-080	0E	C-JUMPER, 3216	YUB3SC	TP-M140
X	PRE-MAIN AMP	JR 0019	88-128-000-080	0E	C-JUMPER, 3216	YUBSC	TP-M140
X	PRE-MAIN AMP	JR 0020	88-128-000-080	0E	C-JUMPER, 3216	YBC	TP-M140
X	PRE-MAIN AMP	JR 0020	88-128-000-080	0E	C-JUMPER, 3216	YLBCC	TP-M140
X	PRE-MAIN AMP	JR 0020	88-128-000-080	0E	C-JUMPER, 3216	YUB3SC	TP-M140
X	PRE-MAIN AMP	JR 0020	88-128-000-080	0E	C-JUMPER, 3216	YUBSC	TP-M140
X	PRE-MAIN AMP	JR 0021	88-128-000-080	0E	C-JUMPER, 3216	YBC	TP-M140
X	PRE-MAIN AMP	JR 0021	88-128-000-080	0E	C-JUMPER, 3216	YLBCC	TP-M140
X	PRE-MAIN AMP	JR 0021	88-128-000-080	0E	C-JUMPER, 3216	YUB3SC	TP-M140
X	PRE-MAIN AMP	JR 0021	88-128-000-080	0E	C-JUMPER, 3216	YUBSC	TP-M140
X	PRE-MAIN AMP	JR 0022	88-128-000-080	0E	C-JUMPER, 3216	YBC	TP-M140
X	PRE-MAIN AMP	JR 0022	88-128-000-080	0E	C-JUMPER, 3216	YLBCC	TP-M140
X	PRE-MAIN AMP	JR 0022	88-128-000-080	0E	C-JUMPER, 3216	YUB3SC	TP-M140
X	PRE-MAIN AMP	JR 0022	88-128-000-080	0E	C-JUMPER, 3216	YUBSC	TP-M140
X	PRE-MAIN AMP	JR 0023	88-128-000-080	0E	C-JUMPER, 3216	YBC	TP-M140
X	PRE-MAIN AMP	JR 0023	88-128-000-080	0E	C-JUMPER, 3216	YLBCC	TP-M140
X	PRE-MAIN AMP	JR 0023	88-128-000-080	0E	C-JUMPER, 3216	YUB3SC	TP-M140
X	PRE-MAIN AMP	JR 0023	88-128-000-080	0E	C-JUMPER, 3216	YUBSC	TP-M140
X	PRE-MAIN AMP	JR 0024	88-128-000-080	0E	C-JUMPER, 3216	YBC	TP-M140
X	PRE-MAIN AMP	JR 0024	88-128-000-080	0E	C-JUMPER, 3216	YLBCC	TP-M140
X	PRE-MAIN AMP	JR 0024	88-128-000-080	0E	C-JUMPER, 3216	YUB3SC	TP-M140
X	PRE-MAIN AMP	JR 0024	88-128-000-080	0E	C-JUMPER, 3216	YUBSC	TP-M140
X	PRE-MAIN AMP	JR 0025	88-128-000-080	0E	C-JUMPER, 3216	YBC	TP-M140
X	PRE-MAIN AMP	JR 0025	88-128-000-080	0E	C-JUMPER, 3216	YLBCC	TP-M140
X	PRE-MAIN AMP	JR 0025	88-128-000-080	0E	C-JUMPER, 3216	YUB3SC	TP-M140
X	PRE-MAIN AMP	JR 0025	88-128-000-080	0E	C-JUMPER, 3216	YUBSC	TP-M140
X	PRE-MAIN AMP	JR 0026	88-128-000-080	0E	C-JUMPER, 3216	YBC	TP-M140
X	PRE-MAIN AMP	JR 0026	88-128-000-080	0E	C-JUMPER, 3216	YLBCC	TP-M140
X	PRE-MAIN AMP	JR 0026	88-128-000-080	0E	C-JUMPER, 3216	YUB3SC	TP-M140
X	PRE-MAIN AMP	JR 0026	88-128-000-080	0E	C-JUMPER, 3216	YUBSC	TP-M140
X	PRE-MAIN AMP	JR 0027	88-128-000-080	0E	C-JUMPER, 3216	YBC	TP-M140
X	PRE-MAIN AMP	JR 0027	88-128-000-080	0E	C-JUMPER, 3216	YLBCC	TP-M140
X	PRE-MAIN AMP	JR 0027	88-128-000-080	0E	C-JUMPER, 3216	YUB3SC	TP-M140
X	PRE-MAIN AMP	JR 0027	88-128-000-080	0E	C-JUMPER, 3216	YUBSC	TP-M140
X	PRE-MAIN AMP	JR 0028	88-128-000-080	0E	C-JUMPER, 3216	YBC	TP-M140
X	PRE-MAIN AMP	JR 0028	88-128-000-080	0E	C-JUMPER, 3216	YLBCC	TP-M140
X	PRE-MAIN AMP	JR 0028	88-128-000-080	0E	C-JUMPER, 3216	YUB3SC	TP-M140
X	PRE-MAIN AMP	JR 0028	88-128-000-080	0E	C-JUMPER, 3216	YUBSC	TP-M140
X	PRE-MAIN AMP	JR 0029	88-128-000-080	0E	C-JUMPER, 3216	YBC	TP-M140
X	PRE-MAIN AMP	JR 0029	88-128-000-080	0E	C-JUMPER, 3216	YLBCC	TP-M140
X	PRE-MAIN AMP	JR 0029	88-128-000-080	0E	C-JUMPER, 3216	YUB3SC	TP-M140
X	PRE-MAIN AMP	JR 0029	88-128-000-080	0E	C-JUMPER, 3216	YUBSC	TP-M140
X	PRE-MAIN AMP	JR 0030	88-128-000-080	0E	C-JUMPER, 3216	YBC	TP-M140
X	PRE-MAIN AMP	JR 0030	88-128-000-080	0E	C-JUMPER, 3216	YLBCC	TP-M140

PARTS LIST

! = Δ SAFTY PARTS
 C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use Japanese.

! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME	
X	PRE-MAIN AMP	JR 0030	88-128-000-080	0E	C-JUMPER, 3216	YUB3SC	TP-M140	
X	PRE-MAIN AMP	JR 0030	88-128-000-080	0E	C-JUMPER, 3216	YUBSC	TP-M140	
X	PRE-MAIN AMP	JR 0031	88-128-000-080	0E	C-JUMPER, 3216	YBC	TP-M140	
X	PRE-MAIN AMP	JR 0031	88-128-000-080	0E	C-JUMPER, 3216	YLBCC	TP-M140	
X	PRE-MAIN AMP	JR 0031	88-128-000-080	0E	C-JUMPER, 3216	YUB3SC	TP-M140	
X	PRE-MAIN AMP	JR 0031	88-128-000-080	0E	C-JUMPER, 3216	YUBSC	TP-M140	
X	PRE-MAIN AMP	JR 0032	88-108-000-080	0E	C-JUMPER, U	YBC	TP-M140	
X	PRE-MAIN AMP	JR 0032	88-108-000-080	0E	C-JUMPER, U	YLBCC	TP-M140	
X	PRE-MAIN AMP	JR 0032	88-108-000-080	0E	C-JUMPER, U	YUB3SC	TP-M140	
X	PRE-MAIN AMP	JR 0032	88-108-000-080	0E	C-JUMPER, U	YUBSC	TP-M140	
O	PRE-MAIN AMP	LED0001	8Z-HX5-601-010	--	LED, KM2520A01SRC001	RED	YBC	TP-M140
O	PRE-MAIN AMP	LED0001	8Z-HX5-601-010	--	LED, KM2520A01SRC001	RED	YLBCC	TP-M140
O	PRE-MAIN AMP	LED0001	8Z-HX5-601-010	--	LED, KM2520A01SRC001	RED	YUB3SC	TP-M140
O	PRE-MAIN AMP	LED0001	8Z-HX5-601-010	--	LED, KM2520A01SRC001	RED	YUBSC	TP-M140
O	PRE-MAIN AMP	MIC0001	87-A91-891-010	1A	MIC, ECM OBO-54LN-OB		YBC	TP-M140
O	PRE-MAIN AMP	MIC0001	87-A91-891-010	1A	MIC, ECM OBO-54LN-OB		YLBCC	TP-M140
O	PRE-MAIN AMP	MIC0001	87-A91-891-010	1A	MIC, ECM OBO-54LN-OB		YUB3SC	TP-M140
O	PRE-MAIN AMP	MIC0001	87-A91-891-010	1A	MIC, ECM OBO-54LN-OB		YUBSC	TP-M140
S	PRE-MAIN AMP	Q 0001	87-A30-288-040	0E	C-TR, DTC114YKA		YBC	TP-M140
S	PRE-MAIN AMP	Q 0001	87-A30-288-040	0E	C-TR, DTC114YKA		YLBCC	TP-M140
S	PRE-MAIN AMP	Q 0001	87-A30-288-040	0E	C-TR, DTC114YKA		YUB3SC	TP-M140
S	PRE-MAIN AMP	Q 0001	87-A30-288-040	0E	C-TR, DTC114YKA		YUBSC	TP-M140
S	PRE-MAIN AMP	Q 0002	87-A30-288-040	0E	C-TR, DTC114YKA		YBC	TP-M140
S	PRE-MAIN AMP	Q 0002	87-A30-288-040	0E	C-TR, DTC114YKA		YLBCC	TP-M140
S	PRE-MAIN AMP	Q 0002	87-A30-288-040	0E	C-TR, DTC114YKA		YUB3SC	TP-M140
S	PRE-MAIN AMP	Q 0002	87-A30-288-040	0E	C-TR, DTC114YKA		YUBSC	TP-M140
S	PRE-MAIN AMP	Q 0003	87-A30-283-040	0E	C-TR, DTA114YKA		YBC	TP-M140
S	PRE-MAIN AMP	Q 0003	87-A30-283-040	0E	C-TR, DTA114YKA		YLBCC	TP-M140
S	PRE-MAIN AMP	Q 0003	87-A30-283-040	0E	C-TR, DTA114YKA		YUB3SC	TP-M140
S	PRE-MAIN AMP	Q 0003	87-A30-283-040	0E	C-TR, DTA114YKA		YUBSC	TP-M140
S	PRE-MAIN AMP	Q 0004	89-327-125-080	0E	C-TR, 2SC2712GR		YBC	TP-M140
S	PRE-MAIN AMP	Q 0004	89-327-125-080	0E	C-TR, 2SC2712GR		YLBCC	TP-M140
S	PRE-MAIN AMP	Q 0004	89-327-125-080	0E	C-TR, 2SC2712GR		YUB3SC	TP-M140
S	PRE-MAIN AMP	Q 0004	89-327-125-080	0E	C-TR, 2SC2712GR		YUBSC	TP-M140
S	PRE-MAIN AMP	Q 0005	89-327-125-080	0E	C-TR, 2SC2712GR		YBC	TP-M140
S	PRE-MAIN AMP	Q 0005	89-327-125-080	0E	C-TR, 2SC2712GR		YLBCC	TP-M140
S	PRE-MAIN AMP	Q 0005	89-327-125-080	0E	C-TR, 2SC2712GR		YUB3SC	TP-M140
S	PRE-MAIN AMP	Q 0005	89-327-125-080	0E	C-TR, 2SC2712GR		YUBSC	TP-M140
S	PRE-MAIN AMP	Q 0006	89-327-125-080	0E	C-TR, 2SC2712GR		YBC	TP-M140
S	PRE-MAIN AMP	Q 0006	89-327-125-080	0E	C-TR, 2SC2712GR		YLBCC	TP-M140
S	PRE-MAIN AMP	Q 0006	89-327-125-080	0E	C-TR, 2SC2712GR		YUB3SC	TP-M140
S	PRE-MAIN AMP	Q 0006	89-327-125-080	0E	C-TR, 2SC2712GR		YUBSC	TP-M140
S	PRE-MAIN AMP	Q 0007	87-A30-283-040	0E	C-TR, DTA114YKA		YBC	TP-M140
S	PRE-MAIN AMP	Q 0007	87-A30-283-040	0E	C-TR, DTA114YKA		YLBCC	TP-M140
S	PRE-MAIN AMP	Q 0007	87-A30-283-040	0E	C-TR, DTA114YKA		YUB3SC	TP-M140
S	PRE-MAIN AMP	Q 0007	87-A30-283-040	0E	C-TR, DTA114YKA		YUBSC	TP-M140
S	PRE-MAIN AMP	Q 0009	89-327-125-080	0E	C-TR, 2SC2712GR		YBC	TP-M140
S	PRE-MAIN AMP	Q 0009	89-327-125-080	0E	C-TR, 2SC2712GR		YLBCC	TP-M140
S	PRE-MAIN AMP	Q 0009	89-327-125-080	0E	C-TR, 2SC2712GR		YUB3SC	TP-M140
S	PRE-MAIN AMP	Q 0009	89-327-125-080	0E	C-TR, 2SC2712GR		YUBSC	TP-M140
X	PRE-MAIN AMP	R 0001	88-108-392-080	0E	C-RES, U 3.9K-1/16W J		YBC	TP-M140
X	PRE-MAIN AMP	R 0001	88-108-392-080	0E	C-RES, U 3.9K-1/16W J		YLBCC	TP-M140
X	PRE-MAIN AMP	R 0001	88-108-392-080	0E	C-RES, U 3.9K-1/16W J		YUB3SC	TP-M140
X	PRE-MAIN AMP	R 0001	88-108-392-080	0E	C-RES, U 3.9K-1/16W J		YUBSC	TP-M140
X	PRE-MAIN AMP	R 0002	88-108-822-080	0E	C-RES, U 8.2K-1/16W J		YBC	TP-M140
X	PRE-MAIN AMP	R 0002	88-108-822-080	0E	C-RES, U 8.2K-1/16W J		YLBCC	TP-M140
X	PRE-MAIN AMP	R 0002	88-108-822-080	0E	C-RES, U 8.2K-1/16W J		YUB3SC	TP-M140
X	PRE-MAIN AMP	R 0002	88-108-822-080	0E	C-RES, U 8.2K-1/16W J		YUBSC	TP-M140
X	PRE-MAIN AMP	R 0003	88-108-223-080	0E	C-RES, U 22K-1/16W J		YBC	TP-M140
X	PRE-MAIN AMP	R 0003	88-108-223-080	0E	C-RES, U 22K-1/16W J		YLBCC	TP-M140
X	PRE-MAIN AMP	R 0003	88-108-223-080	0E	C-RES, U 22K-1/16W J		YUB3SC	TP-M140
X	PRE-MAIN AMP	R 0003	88-108-223-080	0E	C-RES, U 22K-1/16W J		YUBSC	TP-M140
X	PRE-MAIN AMP	R 0004	88-108-470-080	0E	C-RES, U 47-1/16W J		YBC	TP-M140
X	PRE-MAIN AMP	R 0004	88-108-470-080	0E	C-RES, U 47-1/16W J		YLBCC	TP-M140
X	PRE-MAIN AMP	R 0004	88-108-470-080	0E	C-RES, U 47-1/16W J		YUB3SC	TP-M140
X	PRE-MAIN AMP	R 0004	88-108-470-080	0E	C-RES, U 47-1/16W J		YUBSC	TP-M140
X	PRE-MAIN AMP	R 0005	88-108-152-080	0E	C-RES, U 1.5K-1/16W J		YBC	TP-M140
X	PRE-MAIN AMP	R 0005	88-108-152-080	0E	C-RES, U 1.5K-1/16W J		YLBCC	TP-M140
X	PRE-MAIN AMP	R 0005	88-108-152-080	0E	C-RES, U 1.5K-1/16W J		YUB3SC	TP-M140
X	PRE-MAIN AMP	R 0005	88-108-152-080	0E	C-RES, U 1.5K-1/16W J		YUBSC	TP-M140

PARTS LIST

! = Δ SAFTY PARTS
 C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use Japanese.

! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME
X	PRE-MAIN AMP	R 0006	88-108-561-080	0E	C-RES,U 560-1/16W J	YBC	TP-M140
X	PRE-MAIN AMP	R 0006	88-108-561-080	0E	C-RES,U 560-1/16W J	YLBCC	TP-M140
X	PRE-MAIN AMP	R 0006	88-108-561-080	0E	C-RES,U 560-1/16W J	YUB3SC	TP-M140
X	PRE-MAIN AMP	R 0006	88-108-561-080	0E	C-RES,U 560-1/16W J	YUBSC	TP-M140
X	PRE-MAIN AMP	R 0007	88-108-222-080	0E	C-RES,U 2.2K-1/16W J	YBC	TP-M140
X	PRE-MAIN AMP	R 0007	88-108-222-080	0E	C-RES,U 2.2K-1/16W J	YLBCC	TP-M140
X	PRE-MAIN AMP	R 0007	88-108-222-080	0E	C-RES,U 2.2K-1/16W J	YUB3SC	TP-M140
X	PRE-MAIN AMP	R 0007	88-108-222-080	0E	C-RES,U 2.2K-1/16W J	YUBSC	TP-M140
X	PRE-MAIN AMP	R 0008	88-108-225-080	0E	C-RES,U 2.2M-1/16W J	YBC	TP-M140
X	PRE-MAIN AMP	R 0008	88-108-225-080	0E	C-RES,U 2.2M-1/16W J	YLBCC	TP-M140
X	PRE-MAIN AMP	R 0008	88-108-225-080	0E	C-RES,U 2.2M-1/16W J	YUB3SC	TP-M140
X	PRE-MAIN AMP	R 0008	88-108-225-080	0E	C-RES,U 2.2M-1/16W J	YUBSC	TP-M140
X	PRE-MAIN AMP	R 0009	88-108-681-080	0E	C-RES,U 680-1/16W J	YBC	TP-M140
X	PRE-MAIN AMP	R 0009	88-108-681-080	0E	C-RES,U 680-1/16W J	YLBCC	TP-M140
X	PRE-MAIN AMP	R 0009	88-108-681-080	0E	C-RES,U 680-1/16W J	YUB3SC	TP-M140
X	PRE-MAIN AMP	R 0009	88-108-681-080	0E	C-RES,U 680-1/16W J	YUBSC	TP-M140
X	PRE-MAIN AMP	R 0010	88-108-390-080	0E	C-RES,U 39-1/16W J	YBC	TP-M140
X	PRE-MAIN AMP	R 0010	88-108-390-080	0E	C-RES,U 39-1/16W J	YLBCC	TP-M140
X	PRE-MAIN AMP	R 0010	88-108-390-080	0E	C-RES,U 39-1/16W J	YUB3SC	TP-M140
X	PRE-MAIN AMP	R 0010	88-108-390-080	0E	C-RES,U 39-1/16W J	YUBSC	TP-M140
X	PRE-MAIN AMP	R 0015	88-108-229-080	0E	C-RES,U 2.2-1/16W J	YBC	TP-M140
X	PRE-MAIN AMP	R 0015	88-108-229-080	0E	C-RES,U 2.2-1/16W J	YLBCC	TP-M140
X	PRE-MAIN AMP	R 0015	88-108-229-080	0E	C-RES,U 2.2-1/16W J	YUB3SC	TP-M140
X	PRE-MAIN AMP	R 0015	88-108-229-080	0E	C-RES,U 2.2-1/16W J	YUBSC	TP-M140
X	PRE-MAIN AMP	R 0017	88-108-222-080	0E	C-RES,U 2.2K-1/16W J	YBC	TP-M140
X	PRE-MAIN AMP	R 0017	88-108-222-080	0E	C-RES,U 2.2K-1/16W J	YLBCC	TP-M140
X	PRE-MAIN AMP	R 0017	88-108-222-080	0E	C-RES,U 2.2K-1/16W J	YUB3SC	TP-M140
X	PRE-MAIN AMP	R 0017	88-108-222-080	0E	C-RES,U 2.2K-1/16W J	YUBSC	TP-M140
X	PRE-MAIN AMP	R 0018	88-108-102-080	0E	C-RES,U 1K-1/16W J	YBC	TP-M140
X	PRE-MAIN AMP	R 0018	88-108-102-080	0E	C-RES,U 1K-1/16W J	YLBCC	TP-M140
X	PRE-MAIN AMP	R 0018	88-108-102-080	0E	C-RES,U 1K-1/16W J	YUB3SC	TP-M140
X	PRE-MAIN AMP	R 0018	88-108-102-080	0E	C-RES,U 1K-1/16W J	YUBSC	TP-M140
X	PRE-MAIN AMP	R 0019	88-108-822-080	0E	C-RES,U 8.2K-1/16W J	YBC	TP-M140
X	PRE-MAIN AMP	R 0019	88-108-822-080	0E	C-RES,U 8.2K-1/16W J	YLBCC	TP-M140
X	PRE-MAIN AMP	R 0019	88-108-822-080	0E	C-RES,U 8.2K-1/16W J	YUB3SC	TP-M140
X	PRE-MAIN AMP	R 0019	88-108-822-080	0E	C-RES,U 8.2K-1/16W J	YUBSC	TP-M140
X	PRE-MAIN AMP	R 0020	88-108-392-080	0E	C-RES,U 3.9K-1/16W J	YBC	TP-M140
X	PRE-MAIN AMP	R 0020	88-108-392-080	0E	C-RES,U 3.9K-1/16W J	YLBCC	TP-M140
X	PRE-MAIN AMP	R 0020	88-108-392-080	0E	C-RES,U 3.9K-1/16W J	YUB3SC	TP-M140
X	PRE-MAIN AMP	R 0020	88-108-392-080	0E	C-RES,U 3.9K-1/16W J	YUBSC	TP-M140
X	PRE-MAIN AMP	R 0021	88-108-123-080	0E	C-RES,U 12K-1/16W J	YBC	TP-M140
X	PRE-MAIN AMP	R 0021	88-108-123-080	0E	C-RES,U 12K-1/16W J	YLBCC	TP-M140
X	PRE-MAIN AMP	R 0021	88-108-123-080	0E	C-RES,U 12K-1/16W J	YUB3SC	TP-M140
X	PRE-MAIN AMP	R 0021	88-108-123-080	0E	C-RES,U 12K-1/16W J	YUBSC	TP-M140
X	PRE-MAIN AMP	R 0022	88-108-223-080	0E	C-RES,U 22K-1/16W J	YBC	TP-M140
X	PRE-MAIN AMP	R 0022	88-108-223-080	0E	C-RES,U 22K-1/16W J	YLBCC	TP-M140
X	PRE-MAIN AMP	R 0022	88-108-223-080	0E	C-RES,U 22K-1/16W J	YUB3SC	TP-M140
X	PRE-MAIN AMP	R 0022	88-108-223-080	0E	C-RES,U 22K-1/16W J	YUBSC	TP-M140
X	PRE-MAIN AMP	R 0023	88-108-102-080	0E	C-RES,U 1K-1/16W J	YBC	TP-M140
X	PRE-MAIN AMP	R 0023	88-108-102-080	0E	C-RES,U 1K-1/16W J	YLBCC	TP-M140
X	PRE-MAIN AMP	R 0023	88-108-102-080	0E	C-RES,U 1K-1/16W J	YUB3SC	TP-M140
X	PRE-MAIN AMP	R 0023	88-108-102-080	0E	C-RES,U 1K-1/16W J	YUBSC	TP-M140
X	PRE-MAIN AMP	R 0024	88-108-472-080	0E	C-RES,U 4.7K-1/16W J	YBC	TP-M140
X	PRE-MAIN AMP	R 0024	88-108-472-080	0E	C-RES,U 4.7K-1/16W J	YLBCC	TP-M140
X	PRE-MAIN AMP	R 0024	88-108-472-080	0E	C-RES,U 4.7K-1/16W J	YUB3SC	TP-M140
X	PRE-MAIN AMP	R 0024	88-108-472-080	0E	C-RES,U 4.7K-1/16W J	YUBSC	TP-M140
X	PRE-MAIN AMP	R 0025	88-108-562-080	0E	C-RES,U 5.6K-1/16W J	YBC	TP-M140
X	PRE-MAIN AMP	R 0025	88-108-562-080	0E	C-RES,U 5.6K-1/16W J	YLBCC	TP-M140
X	PRE-MAIN AMP	R 0025	88-108-562-080	0E	C-RES,U 5.6K-1/16W J	YUB3SC	TP-M140
X	PRE-MAIN AMP	R 0025	88-108-562-080	0E	C-RES,U 5.6K-1/16W J	YUBSC	TP-M140
X	PRE-MAIN AMP	R 0026	88-108-561-080	0E	C-RES,U 560-1/16W J	YBC	TP-M140
X	PRE-MAIN AMP	R 0026	88-108-561-080	0E	C-RES,U 560-1/16W J	YLBCC	TP-M140
X	PRE-MAIN AMP	R 0026	88-108-561-080	0E	C-RES,U 560-1/16W J	YUB3SC	TP-M140
X	PRE-MAIN AMP	R 0026	88-108-561-080	0E	C-RES,U 560-1/16W J	YUBSC	TP-M140
X	PRE-MAIN AMP	R 0028	88-108-393-080	0E	C-RES,U 39K-1/16W J	YBC	TP-M140
X	PRE-MAIN AMP	R 0028	88-108-393-080	0E	C-RES,U 39K-1/16W J	YLBCC	TP-M140
X	PRE-MAIN AMP	R 0028	88-108-393-080	0E	C-RES,U 39K-1/16W J	YUB3SC	TP-M140
X	PRE-MAIN AMP	R 0028	88-108-393-080	0E	C-RES,U 39K-1/16W J	YUBSC	TP-M140
X	PRE-MAIN AMP	R 0035	88-108-470-080	0E	C-RES,U 47-1/16W J	YBC	TP-M140
X	PRE-MAIN AMP	R 0035	88-108-470-080	0E	C-RES,U 47-1/16W J	YLBCC	TP-M140

PARTS LIST

! = Δ SAFTY PARTS
 C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use Japanese.

! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME
X	PRE-MAIN AMP	R 0035	88-108-470-080	0E	C-RES,U 47-1/16W J	YUB3SC	TP-M140
X	PRE-MAIN AMP	R 0035	88-108-470-080	0E	C-RES,U 47-1/16W J	YUBSC	TP-M140
X	PRE-MAIN AMP	R 0036	88-108-274-080	0E	C-RES,U 270K-1/16W J	YBC	TP-M140
X	PRE-MAIN AMP	R 0036	88-108-274-080	0E	C-RES,U 270K-1/16W J	YLBCC	TP-M140
X	PRE-MAIN AMP	R 0036	88-108-274-080	0E	C-RES,U 270K-1/16W J	YUB3SC	TP-M140
X	PRE-MAIN AMP	R 0036	88-108-274-080	0E	C-RES,U 270K-1/16W J	YUBSC	TP-M140
X	PRE-MAIN AMP	R 0037	88-108-332-080	0E	C-RES,U 3.3K-1/16W J	YBC	TP-M140
X	PRE-MAIN AMP	R 0037	88-108-332-080	0E	C-RES,U 3.3K-1/16W J	YLBCC	TP-M140
X	PRE-MAIN AMP	R 0037	88-108-332-080	0E	C-RES,U 3.3K-1/16W J	YUB3SC	TP-M140
X	PRE-MAIN AMP	R 0037	88-108-332-080	0E	C-RES,U 3.3K-1/16W J	YUBSC	TP-M140
X	PRE-MAIN AMP	R 0038	88-108-222-080	0E	C-RES,U 2.2K-1/16W J	YBC	TP-M140
X	PRE-MAIN AMP	R 0038	88-108-222-080	0E	C-RES,U 2.2K-1/16W J	YLBCC	TP-M140
X	PRE-MAIN AMP	R 0038	88-108-222-080	0E	C-RES,U 2.2K-1/16W J	YUB3SC	TP-M140
X	PRE-MAIN AMP	R 0038	88-108-222-080	0E	C-RES,U 2.2K-1/16W J	YUBSC	TP-M140
X	PRE-MAIN AMP	R 0039	88-108-102-080	0E	C-RES,U 1K-1/16W J	YBC	TP-M140
X	PRE-MAIN AMP	R 0039	88-108-102-080	0E	C-RES,U 1K-1/16W J	YLBCC	TP-M140
X	PRE-MAIN AMP	R 0039	88-108-102-080	0E	C-RES,U 1K-1/16W J	YUB3SC	TP-M140
X	PRE-MAIN AMP	R 0039	88-108-102-080	0E	C-RES,U 1K-1/16W J	YUBSC	TP-M140
X	PRE-MAIN AMP	R 0040	88-108-223-080	0E	C-RES,U 22K-1/16W J	YBC	TP-M140
X	PRE-MAIN AMP	R 0040	88-108-223-080	0E	C-RES,U 22K-1/16W J	YLBCC	TP-M140
X	PRE-MAIN AMP	R 0040	88-108-223-080	0E	C-RES,U 22K-1/16W J	YUB3SC	TP-M140
X	PRE-MAIN AMP	R 0040	88-108-223-080	0E	C-RES,U 22K-1/16W J	YUBSC	TP-M140
X	PRE-MAIN AMP	R 0041	88-108-331-080	0E	C-RES,U 330-1/16W J	YBC	TP-M140
X	PRE-MAIN AMP	R 0041	88-108-331-080	0E	C-RES,U 330-1/16W J	YLBCC	TP-M140
X	PRE-MAIN AMP	R 0041	88-108-331-080	0E	C-RES,U 330-1/16W J	YUB3SC	TP-M140
X	PRE-MAIN AMP	R 0041	88-108-331-080	0E	C-RES,U 330-1/16W J	YUBSC	TP-M140
O	PRE-MAIN AMP	R 0075	85-TM5-611-010	0E	RES,220-1/8W J 3900P	YBC	TP-M140
O	PRE-MAIN AMP	R 0075	85-TM5-611-010	0E	RES,220-1/8W J 3900P	YLBCC	TP-M140
O	PRE-MAIN AMP	R 0075	85-TM5-611-010	0E	RES,220-1/8W J 3900P	YUB3SC	TP-M140
O	PRE-MAIN AMP	R 0075	85-TM5-611-010	0E	RES,220-1/8W J 3900P	YUBSC	TP-M140
O	PRE-MAIN AMP	R 0076	85-TM5-612-010	0E	RES,33K-1/8W J 800P	YBC	TP-M140
O	PRE-MAIN AMP	R 0076	85-TM5-612-010	0E	RES,33K-1/8W J 800P	YLBCC	TP-M140
O	PRE-MAIN AMP	R 0076	85-TM5-612-010	0E	RES,33K-1/8W J 800P	YUB3SC	TP-M140
O	PRE-MAIN AMP	R 0076	85-TM5-612-010	0E	RES,33K-1/8W J 800P	YUBSC	TP-M140
X	PRE-MAIN AMP	R 0077	88-108-222-080	0E	C-RES,U 2.2K-1/16W J	YBC	TP-M140
X	PRE-MAIN AMP	R 0077	88-108-222-080	0E	C-RES,U 2.2K-1/16W J	YLBCC	TP-M140
X	PRE-MAIN AMP	R 0077	88-108-222-080	0E	C-RES,U 2.2K-1/16W J	YUB3SC	TP-M140
X	PRE-MAIN AMP	R 0077	88-108-222-080	0E	C-RES,U 2.2K-1/16W J	YUBSC	TP-M140
O	PRE-MAIN AMP	SFR0001	85-TM5-615-010	--	SFR,5K V FRB-062	YBC	TP-M140
O	PRE-MAIN AMP	SFR0001	85-TM5-615-010	--	SFR,5K V FRB-062	YLBCC	TP-M140
O	PRE-MAIN AMP	SFR0001	85-TM5-615-010	--	SFR,5K V FRB-062	YUB3SC	TP-M140
O	PRE-MAIN AMP	SFR0001	85-TM5-615-010	--	SFR,5K V FRB-062	YUBSC	TP-M140
O	PRE-MAIN AMP	SFR0002	87-A91-282-080	1A	C-SFR,2.0K H RVG3S08	YBC	TP-M140
O	PRE-MAIN AMP	SFR0002	87-A91-282-080	1A	C-SFR,2.0K H RVG3S08	YLBCC	TP-M140
O	PRE-MAIN AMP	SFR0002	87-A91-282-080	1A	C-SFR,2.0K H RVG3S08	YUB3SC	TP-M140
O	PRE-MAIN AMP	SFR0002	87-A91-282-080	1A	C-SFR,2.0K H RVG3S08	YUBSC	TP-M140
O	PRE-MAIN AMP	SP 0001	87-A91-612-110	1D	SPKR,DIA36 4OHM 0.4W	YBC	TP-M140
O	PRE-MAIN AMP	SP 0001	87-A91-612-110	1D	SPKR,DIA36 4OHM 0.4W	YLBCC	TP-M140
O	PRE-MAIN AMP	SP 0001	87-A91-612-110	1D	SPKR,DIA36 4OHM 0.4W	YUB3SC	TP-M140
O	PRE-MAIN AMP	SP 0001	87-A91-612-110	1D	SPKR,DIA36 4OHM 0.4W	YUBSC	TP-M140
O	PRE-MAIN AMP	SW 0001	8Z-HX5-602-010	--	SW,PUSH PS42D07	YBC	TP-M140
O	PRE-MAIN AMP	SW 0001	8Z-HX5-602-010	--	SW,PUSH PS42D07	YLBCC	TP-M140
O	PRE-MAIN AMP	SW 0001	8Z-HX5-602-010	--	SW,PUSH PS42D07	YUB3SC	TP-M140
O	PRE-MAIN AMP	SW 0001	8Z-HX5-602-010	--	SW,PUSH PS42D07	YUBSC	TP-M140
O	PRE-MAIN AMP	SW 0002	87-031-816-010	1A	SW,SL 1-1-2 SSSS71446A	YBC	TP-M140
O	PRE-MAIN AMP	SW 0002	87-031-816-010	1A	SW,SL 1-1-2 SSSS71446A	YLBCC	TP-M140
O	PRE-MAIN AMP	SW 0002	87-031-816-010	1A	SW,SL 1-1-2 SSSS71446A	YUB3SC	TP-M140
O	PRE-MAIN AMP	SW 0002	87-031-816-010	1A	SW,SL 1-1-2 SSSS71446A	YUBSC	TP-M140
O	PRE-MAIN AMP	SW 0004	87-036-343-010	1A	SW,SL 2-2-2 SSSS22	YBC	TP-M140
O	PRE-MAIN AMP	SW 0004	87-036-343-010	1A	SW,SL 2-2-2 SSSS22	YLBCC	TP-M140
O	PRE-MAIN AMP	SW 0004	87-036-343-010	1A	SW,SL 2-2-2 SSSS22	YUB3SC	TP-M140
O	PRE-MAIN AMP	SW 0004	87-036-343-010	1A	SW,SL 2-2-2 SSSS22	YUBSC	TP-M140
S	PRE-MAIN AMP	SW 0005	85-TM5-608-010	--	SW,LEAF LSA-1114P	YBC	TP-M140
S	PRE-MAIN AMP	SW 0005	85-TM5-608-010	--	SW,LEAF LSA-1114P	YLBCC	TP-M140
S	PRE-MAIN AMP	SW 0005	85-TM5-608-010	--	SW,LEAF LSA-1114P	YUB3SC	TP-M140
S	PRE-MAIN AMP	SW 0005	85-TM5-608-010	--	SW,LEAF LSA-1114P	YUBSC	TP-M140
O	PRE-MAIN AMP	SW 0005	87-031-816-010	1A	SW,SL 1-1-2 SSSS71446A	YBC	TP-M140
O	PRE-MAIN AMP	SW 0005	87-031-816-010	1A	SW,SL 1-1-2 SSSS71446A	YLBCC	TP-M140
O	PRE-MAIN AMP	SW 0005	87-031-816-010	1A	SW,SL 1-1-2 SSSS71446A	YUB3SC	TP-M140
O	PRE-MAIN AMP	SW 0005	87-031-816-010	1A	SW,SL 1-1-2 SSSS71446A	YUBSC	TP-M140

PARTS LIST

! = Δ SAFTY PARTS
 C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use Japanese.

! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME
!	O PRE-MAIN AMP	SW 0006	87-A90-826-010	1A	SW, LEAF LSA-1114P2	YBC	TP-M140
!	O PRE-MAIN AMP	SW 0006	87-A90-826-010	1A	SW, LEAF LSA-1114P2	YLBCC	TP-M140
!	O PRE-MAIN AMP	SW 0006	87-A90-826-010	1A	SW, LEAF LSA-1114P2	YUB3SC	TP-M140
!	O PRE-MAIN AMP	SW 0006	87-A90-826-010	1A	SW, LEAF LSA-1114P2	YUBSC	TP-M140
O	O PRE-MAIN AMP	SW 0009	87-A90-330-080	0E	C-SW, SL 1-1-2 SSSS81 T1.4	YBC	TP-M140
O	O PRE-MAIN AMP	SW 0009	87-A90-330-080	0E	C-SW, SL 1-1-2 SSSS81 T1.4	YLBCC	TP-M140
O	O PRE-MAIN AMP	SW 0009	87-A90-330-080	0E	C-SW, SL 1-1-2 SSSS81 T1.4	YUB3SC	TP-M140
O	O PRE-MAIN AMP	SW 0009	87-A90-330-080	0E	C-SW, SL 1-1-2 SSSS81 T1.4	YUBSC	TP-M140
O	O PRE-MAIN AMP	VR 0001	87-A91-828-010	--	VR, RTRY 10KA V VX010702GYPV1N1	YBC	TP-M140
O	O PRE-MAIN AMP	VR 0001	87-A91-828-010	--	VR, RTRY 10KA V VX010702GYPV1N1	YLBCC	TP-M140
O	O PRE-MAIN AMP	VR 0001	87-A91-828-010	--	VR, RTRY 10KA V VX010702GYPV1N1	YUB3SC	TP-M140
O	O PRE-MAIN AMP	VR 0001	87-A91-828-010	--	VR, RTRY 10KA V VX010702GYPV1N1	YUBSC	TP-M140
X	PRINTED MATTER		87-056-168-010	0E	SH, CAUTION INF-WARR(EC)	YBC	TP-M140
X	PRINTED MATTER		87-B50-078-010	0E	LIST, FACILITY(S)-0007	YBC	TP-M140
X	PRINTED MATTER		87-B50-078-010	0E	LIST, FACILITY(S)-0007	YLBCC	TP-M140
O	PRINTED MATTER		8B-HX7-901-010	--	IB, YU(3L)C	YUB3SC	TP-M140
O	PRINTED MATTER		8B-HX7-901-010	--	IB, YU(3L)C	YUBSC	TP-M140
O	PRINTED MATTER		8B-HX7-904-010	--	IB, YL(3L)C	YLBCC	TP-M140
O	PRINTED MATTER		8B-HX7-905-010	--	IB, Y(EGF)C	YBC	TP-M140
O	PRINTED MATTER		8B-HX7-906-010	--	IB, Y(SID)C	YBC	TP-M140
O	PRINTED MATTER		8B-HX7-907-010	--	IB, Y(PHNCZ)C	YBC	TP-M140
X	PRINTED MATTER		8B-HX7-910-010	--	WARR-CARD, M140	YUB3SC	TP-M140
X	PRINTED MATTER		8B-HX7-910-010	--	WARR-CARD, M140	YUBSC	TP-M140
X	PWB A		8B-HX4-601-010	--	PWB, COMB 3 3M	YBC	TP-M140
X	PWB A		8B-HX4-601-010	--	PWB, COMB 3 3M	YLBCC	TP-M140
X	PWB A		8B-HX4-601-010	--	PWB, COMB 3 3M	YUB3SC	TP-M140
X	PWB A		8B-HX4-601-010	--	PWB, COMB 3 3M	YUBSC	TP-M140
X	PWB A		8B-HX4-602-010	--	PWB, MAIN	YBC	TP-M140
X	PWB A		8B-HX4-602-010	--	PWB, MAIN	YLBCC	TP-M140
X	PWB A		8B-HX4-602-010	--	PWB, MAIN	YUB3SC	TP-M140
X	PWB A		8B-HX4-602-010	--	PWB, MAIN	YUBSC	TP-M140
X	PWB A		8B-HX4-603-010	--	PWB, MIC	YBC	TP-M140
X	PWB A		8B-HX4-603-010	--	PWB, MIC	YLBCC	TP-M140
X	PWB A		8B-HX4-603-010	--	PWB, MIC	YUB3SC	TP-M140
X	PWB A		8B-HX4-603-010	--	PWB, MIC	YUBSC	TP-M140
O	SCREW		8Z-HX5-204-010	--	VT2+2-6 CR S	YBC	TP-M140
O	SCREW		8Z-HX5-204-010	--	VT2+2-6 CR S	YLBCC	TP-M140
O	SCREW		8Z-HX5-204-010	--	VT2+2-6 CR S	YUB3SC	TP-M140
O	SCREW		8Z-HX5-204-010	--	VT2+2-6 CR S	YUBSC	TP-M140
O	SCREW		8Z-HX5-205-010	--	VT2+1.7-6 CR S	YBC	TP-M140
O	SCREW		8Z-HX5-205-010	--	VT2+1.7-6 CR S	YLBCC	TP-M140
O	SCREW		8Z-HX5-205-010	--	VT2+1.7-6 CR S	YUB3SC	TP-M140
O	SCREW		8Z-HX5-205-010	--	VT2+1.7-6 CR S	YUBSC	TP-M140
O	SCREW		8Z-HX5-206-010	--	UT2+2-20 CR S	YUB3SC	TP-M140
O	SCREW		8Z-HX5-206-010	--	UT2+2-20 CR S	YUBSC	TP-M140
O	SCREW		8Z-HX5-207-010	--	VT2+2-6 CR B	YBC	TP-M140
O	SCREW		8Z-HX5-207-010	--	VT2+2-6 CR B	YLBCC	TP-M140
O	SCREW		8Z-HX5-208-010	--	UT2+2-20 CR B	YBC	TP-M140
O	SCREW		8Z-HX5-208-010	--	UT2+2-20 CR B	YLBCC	TP-M140
X	TAPE TRANSPORT		M8-AZK-790-070	--	M-187	YBC	TP-M140
X	TAPE TRANSPORT		M8-AZK-790-070	--	M-187	YLBCC	TP-M140
X	TAPE TRANSPORT		M8-AZK-790-070	--	M-187	YUB3SC	TP-M140
X	TAPE TRANSPORT		M8-AZK-790-070	--	M-187	YUBSC	TP-M140
X	UNIT CODE		PB-HX7-233-070	--	TP-M140 YUBSC	YUBSC	TP-M140
X	UNIT CODE		PB-HX7-243-070	--	TP-M140 YUB3SC	YUB3SC	TP-M140
X	UNIT CODE		PB-HX7-331-070	--	TP-M140 YBC	YBC	TP-M140
X	UNIT CODE		PB-HX7-351-080	--	TP-M140 YLBCC	YLBCC	TP-M140

PARTS LIST

! = Δ SAFTY PARTS
 C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use Japanese.

! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME
O	APPEARANCE		8B-HX6-004-010	--	COVER, MIC	YHSCC	TP-M240
O	APPEARANCE		8B-HX6-004-010	--	COVER, MIC	YHTSC	TP-M240
O	APPEARANCE		8B-HX7-001-010	--	CABI, FRONT	YHSCC	TP-M240
O	APPEARANCE		8B-HX7-001-010	--	CABI, FRONT	YHTSC	TP-M240
O	APPEARANCE		8B-HX7-002-010	--	LID, CASSETTE	YHSCC	TP-M240
O	APPEARANCE		8B-HX7-002-010	--	LID, CASSETTE	YHTSC	TP-M240
O	APPEARANCE		8B-HX7-008-010	--	WINDOW, CASSETTE B	YHSCC	TP-M240
O	APPEARANCE		8B-HX7-008-010	--	WINDOW, CASSETTE B	YHTSC	TP-M240
O	APPEARANCE		8B-HX7-009-010	--	LENS, COUNTER M240 B	YHSCC	TP-M240
O	APPEARANCE		8B-HX7-009-010	--	LENS, COUNTER M240 B	YHTSC	TP-M240
O	APPEARANCE		8Z-HX5-006-010	--	LID, BATT	YHTSC	TP-M240
O	APPEARANCE		8Z-HX5-006-010	1A	LID, BATT	YHSCC	TP-M240
O	APPEARANCE		8Z-HX5-020-010	0E	LENS, LED	YHSCC	TP-M240
O	APPEARANCE		8Z-HX5-020-010	0E	LENS, LED	YHTSC	TP-M240
O	APPEARANCE		8Z-HX7-004-110	--	CABI, REAR Y	YHSCC	TP-M240
O	APPEARANCE		8Z-HX7-004-110	--	CABI, REAR Y	YHTSC	TP-M240
O	KNOB		8B-HX4-007-010	--	KNOB, SL MIC	YHSCC	TP-M240
O	KNOB		8B-HX4-007-010	--	KNOB, SL MIC	YHTSC	TP-M240
O	KNOB		8Z-HX5-015-010	--	KNOB, SL FF/REW	YHSCC	TP-M240
O	KNOB		8Z-HX5-015-010	--	KNOB, SL FF/REW	YHTSC	TP-M240
O	KNOB		8Z-HX5-016-010	--	KNOB, SL PAUSE	YHSCC	TP-M240
O	KNOB		8Z-HX5-016-010	--	KNOB, SL PAUSE	YHTSC	TP-M240
O	KNOB		8Z-HX5-017-010	0E	KNOB, SL 1.2/2.4	YHSCC	TP-M240
O	KNOB		8Z-HX5-017-010	0E	KNOB, SL 1.2/2.4	YHTSC	TP-M240
O	KNOB		8Z-HX5-019-010	0E	KNOB, SL V-SENSOR/ NFR	YHSCC	TP-M240
O	KNOB		8Z-HX5-019-010	0E	KNOB, SL V-SENSOR/ NFR	YHTSC	TP-M240
O	KNOB		8Z-HX7-016-010	--	BTN, CASS REC Y	YHSCC	TP-M240
O	KNOB		8Z-HX7-016-010	--	BTN, CASS REC Y	YHTSC	TP-M240
O	KNOB		8Z-HX7-017-010	--	BTN, CASS PLAY Y	YHSCC	TP-M240
O	KNOB		8Z-HX7-017-010	--	BTN, CASS PLAY Y	YHTSC	TP-M240
O	KNOB		8Z-HX7-018-010	--	BTN, CASS STOP Y	YHSCC	TP-M240
O	KNOB		8Z-HX7-018-010	--	BTN, CASS STOP Y	YHTSC	TP-M240
X	LBL, POP		8B-HX7-972-010	--	LBL, POP YL	YHSCC	TP-M240
X	LBL, POP		8B-HX7-972-010	--	LBL, POP YL	YHTSC	TP-M240
O	OTHERS		85-TM5-203-010	--	SPR, BAT (+/-)	YHSCC	TP-M240
O	OTHERS		85-TM5-203-010	--	SPR, BAT (+/-)	YHTSC	TP-M240
O	OTHERS		85-TM5-204-010	--	SPR, BAT (+)	YHSCC	TP-M240
O	OTHERS		85-TM5-204-010	--	SPR, BAT (+)	YHTSC	TP-M240
O	OTHERS		85-TM5-205-010	--	SPR, BAT (-)	YHSCC	TP-M240
O	OTHERS		85-TM5-205-010	--	SPR, BAT (-)	YHTSC	TP-M240
O	OTHERS		8Z-HX5-200-010	--	HLDR, JACK	YHSCC	TP-M240
O	OTHERS		8Z-HX5-200-010	--	HLDR, JACK	YHTSC	TP-M240
O	OTHERS		8Z-HX5-201-010	0E	SPR, CASS	YHSCC	TP-M240
O	OTHERS		8Z-HX5-201-010	0E	SPR, CASS	YHTSC	TP-M240
X	OTHERS		8Z-HX5-202-010	--	SH, INSULATION	YHSCC	TP-M240
X	OTHERS		8Z-HX5-202-010	--	SH, INSULATION	YHTSC	TP-M240
X	OTHERS 1		8B-HX4-605-010	--	WIRE, B-2-7-2/2 AWG28#1571	YHSCC	TP-M240
X	OTHERS 1		8B-HX4-605-010	--	WIRE, B-2-7-2/2 AWG28#1571	YHTSC	TP-M240
X	OTHERS 1		8B-HX4-606-010	--	WIRE, B+0-7-2/2 AWG28#1571	YHSCC	TP-M240
X	OTHERS 1		8B-HX4-606-010	--	WIRE, B+0-7-2/2 AWG28#1571	YHTSC	TP-M240
X	OTHERS 1		8B-HX4-607-010	--	WIRE, MIC-1-7-2/2 #30	YHSCC	TP-M240
X	OTHERS 1		8B-HX4-607-010	--	WIRE, MIC-1-7-2/2 #30	YHTSC	TP-M240
X	OTHERS 1		8B-HX4-608-010	--	WIRE, MIC+0-7-2/2 #30	YHSCC	TP-M240
X	OTHERS 1		8B-HX4-608-010	--	WIRE, MIC+0-7-2/2 #30	YHTSC	TP-M240
X	OTHERS 1		8B-HX4-609-010	--	WIRE, SP-0-10-2/2 #30	YHSCC	TP-M240
X	OTHERS 1		8B-HX4-609-010	--	WIRE, SP-0-10-2/2 #30	YHTSC	TP-M240
X	OTHERS 1		8B-HX4-610-010	--	WIRE, SP+1-10-2/2 #30	YHSCC	TP-M240
X	OTHERS 1		8B-HX4-610-010	--	WIRE, SP+1-10-2/2 #30	YHTSC	TP-M240
X	OTHERS 1		8B-HX4-611-010	--	WIRE, 140 8 32#UL2851 R/P HEAD	YHSCC	TP-M240
X	OTHERS 1		8B-HX4-611-010	--	WIRE, 140 8 32#UL2851 R/P HEAD	YHTSC	TP-M240
X	OTHERS 1		8B-HX4-612-010	--	TUBE, SPACER 0.86-3 4	YHSCC	TP-M240
X	OTHERS 1		8B-HX4-612-010	--	TUBE, SPACER 0.86-3 4	YHTSC	TP-M240
X	OTHERS 1		8B-HX4-613-010	--	WIRE, MIC-SENS	YHSCC	TP-M240
X	OTHERS 1		8B-HX4-613-010	--	WIRE, MIC-SENS	YHTSC	TP-M240
X	PACKING		84-TM1-868-010	--	P. P SHEET	YHSCC	TP-M240
X	PACKING		84-TM1-868-010	--	P. P SHEET	YHTSC	TP-M240
X	PACKING		8B-HX7-859-010	--	CTN, PRINTED 240	YHSCC	TP-M240
X	PACKING		8B-HX7-859-010	--	CTN, PRINTED 240	YHTSC	TP-M240
X	PACKING		8B-HX7-860-010	--	CTN, INNER 240	YHSCC	TP-M240
X	PACKING		8B-HX7-860-010	--	CTN, INNER 240	YHTSC	TP-M240
X	PACKING		8B-HX7-862-010	--	CTN, INNER 240	YHSCC	TP-M240
X	PACKING		8B-HX7-862-010	--	CTN, INNER 240	YHTSC	TP-M240
X	PACKING		8B-HX7-863-010	--	CTN, INNER 240	YHTSC	TP-M240

PARTS LIST

! = Δ SAFTY PARTS
 C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use Japanese.

! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME
X	PACKING		8B-HX7-865-010	--	CTN, OUTER 240 YHS	YHS	TP-M240
X	PACKING		8B-HX7-866-010	--	CTN, OUTER 240 YHT	YHT	TP-M240
X	PACKING		8Z-HX7-851-010	--	CUSHION, A	YHS	TP-M240
X	PACKING		8Z-HX7-851-010	--	CUSHION, A	YHT	TP-M240
X	PLATE		87-B40-154-010	0E	LBL, BAR-CODE CU	YHS	TP-M240
X	PLATE		87-B40-154-010	0E	LBL, BAR-CODE CU	YHS	TP-M240
X	PLATE		87-B40-154-010	0E	LBL, BAR-CODE CU	YHT	TP-M240
X	PLATE		87-B40-154-010	0E	LBL, BAR-CODE CU	YHT	TP-M240
X	PLATE		87-B40-281-010	0E	LBL, BAR-CODE A 35X8	YHS	TP-M240
X	PLATE		87-B40-281-010	0E	LBL, BAR-CODE A 35X8	YHT	TP-M240
X	PLATE		8B-HX7-018-010	--	LBL, SPEC, M240 YH	YHS	TP-M240
X	PLATE		8B-HX7-020-010	--	LBL, SPEC M240 YHT	YHT	TP-M240
O	PRE-MAIN AMP	C 0001	87-010-788-080	0E	C-CAP, U 0.033-25 Z F	YHS	TP-M240
O	PRE-MAIN AMP	C 0001	87-010-788-080	0E	C-CAP, U 0.033-25 Z F	YHT	TP-M240
O	PRE-MAIN AMP	C 0002	87-012-282-080	0E	C-CAP, U 4700P-50 K B	YHS	TP-M240
O	PRE-MAIN AMP	C 0002	87-012-282-080	0E	C-CAP, U 4700P-50 K B	YHT	TP-M240
O	PRE-MAIN AMP	C 0003	87-012-281-080	0E	C-CAP, U 3900P-50 K B GRM	YHS	TP-M240
O	PRE-MAIN AMP	C 0003	87-012-281-080	0E	C-CAP, U 3900P-50 K B GRM	YHT	TP-M240
O	PRE-MAIN AMP	C 0004	87-010-082-010	0E	CAP, E 220-4 M 5L SRE	YHS	TP-M240
O	PRE-MAIN AMP	C 0004	87-010-082-010	0E	CAP, E 220-4 M 5L SRE	YHT	TP-M240
O	PRE-MAIN AMP	C 0005	87-010-072-010	0E	CAP, E 2.2-50 M 5L SRE	YHS	TP-M240
O	PRE-MAIN AMP	C 0005	87-010-072-010	0E	CAP, E 2.2-50 M 5L SRE	YHT	TP-M240
O	PRE-MAIN AMP	C 0006	87-012-280-080	0E	C-CAP, U 3300P-50 K B	YHS	TP-M240
O	PRE-MAIN AMP	C 0006	87-012-280-080	0E	C-CAP, U 3300P-50 K B	YHT	TP-M240
O	PRE-MAIN AMP	C 0007	87-010-787-080	0E	C-CAP, U 0.022-25 K B	YHS	TP-M240
O	PRE-MAIN AMP	C 0007	87-010-787-080	0E	C-CAP, U 0.022-25 K B	YHT	TP-M240
O	PRE-MAIN AMP	C 0008	87-012-282-080	0E	C-CAP, U 4700P-50 K B	YHS	TP-M240
O	PRE-MAIN AMP	C 0008	87-012-282-080	0E	C-CAP, U 4700P-50 K B	YHT	TP-M240
O	PRE-MAIN AMP	C 0009	87-010-504-080	0E	C-CAP, TN 0.47-25 M ECS	YHS	TP-M240
O	PRE-MAIN AMP	C 0009	87-010-504-080	0E	C-CAP, TN 0.47-25 M ECS	YHT	TP-M240
O	PRE-MAIN AMP	C 0010	87-010-075-010	0E	CAP, E 10-16 M 5L SRE	YHS	TP-M240
O	PRE-MAIN AMP	C 0010	87-010-075-010	0E	CAP, E 10-16 M 5L SRE	YHT	TP-M240
O	PRE-MAIN AMP	C 0011	87-010-490-010	0E	CAP, E 0.1-50 M KS	YHS	TP-M240
O	PRE-MAIN AMP	C 0011	87-010-490-010	0E	CAP, E 0.1-50 M KS	YHT	TP-M240
O	PRE-MAIN AMP	C 0012	87-A10-952-080	0E	C-CAP, TN 22-4 M A MCM	YHS	TP-M240
O	PRE-MAIN AMP	C 0012	87-A10-952-080	0E	C-CAP, TN 22-4 M A MCM	YHT	TP-M240
O	PRE-MAIN AMP	C 0013	87-010-082-010	0E	CAP, E 220-4 M 5L SRE	YHS	TP-M240
O	PRE-MAIN AMP	C 0013	87-010-082-010	0E	CAP, E 220-4 M 5L SRE	YHT	TP-M240
O	PRE-MAIN AMP	C 0014	87-010-082-010	0E	CAP, E 220-4 M 5L SRE	YHS	TP-M240
O	PRE-MAIN AMP	C 0014	87-010-082-010	0E	CAP, E 220-4 M 5L SRE	YHT	TP-M240
O	PRE-MAIN AMP	C 0015	87-010-082-010	0E	CAP, E 220-4 M 5L SRE	YHS	TP-M240
O	PRE-MAIN AMP	C 0015	87-010-082-010	0E	CAP, E 220-4 M 5L SRE	YHT	TP-M240
O	PRE-MAIN AMP	C 0016	87-012-274-080	0E	C-CAP, U 1000P-50 K B	YHS	TP-M240
O	PRE-MAIN AMP	C 0016	87-012-274-080	0E	C-CAP, U 1000P-50 K B	YHT	TP-M240
O	PRE-MAIN AMP	C 0017	87-010-505-080	0E	C-CAP, TN 1-16 M ECS	YHS	TP-M240
O	PRE-MAIN AMP	C 0017	87-010-505-080	0E	C-CAP, TN 1-16 M ECS	YHT	TP-M240
O	PRE-MAIN AMP	C 0018	87-010-504-080	0E	C-CAP, TN 0.47-25 M ECS	YHS	TP-M240
O	PRE-MAIN AMP	C 0018	87-010-504-080	0E	C-CAP, TN 0.47-25 M ECS	YHT	TP-M240
O	PRE-MAIN AMP	C 0019	87-A11-056-080	0E	C-CAP, U 1-10 Z F	YHS	TP-M240
O	PRE-MAIN AMP	C 0019	87-A11-056-080	0E	C-CAP, U 1-10 Z F	YHT	TP-M240
O	PRE-MAIN AMP	C 0020	87-A10-025-080	0E	C-CAP, U 0.22-16 Z F	YHS	TP-M240
O	PRE-MAIN AMP	C 0020	87-A10-025-080	0E	C-CAP, U 0.22-16 Z F	YHT	TP-M240
O	PRE-MAIN AMP	C 0021	87-A10-025-080	0E	C-CAP, U 0.22-16 Z F	YHS	TP-M240
O	PRE-MAIN AMP	C 0021	87-A10-025-080	0E	C-CAP, U 0.22-16 Z F	YHT	TP-M240
O	PRE-MAIN AMP	C 0022	87-A11-791-080	1A	C-CAP, TN 10-4 M F93 A	YHS	TP-M240
O	PRE-MAIN AMP	C 0022	87-A11-791-080	1A	C-CAP, TN 10-4 M F93 A	YHT	TP-M240
O	PRE-MAIN AMP	C 0023	87-010-494-010	0E	CAP, E 1-50 M KS	YHS	TP-M240
O	PRE-MAIN AMP	C 0023	87-010-494-010	0E	CAP, E 1-50 M KS	YHT	TP-M240
O	PRE-MAIN AMP	C 0024	87-010-757-080	0E	C-CAP, U 0.047-25 Z F	YHS	TP-M240
O	PRE-MAIN AMP	C 0024	87-010-757-080	0E	C-CAP, U 0.047-25 Z F	YHT	TP-M240
O	PRE-MAIN AMP	C 0025	87-A11-056-080	0E	C-CAP, U 1-10 Z F	YHS	TP-M240
O	PRE-MAIN AMP	C 0025	87-A11-056-080	0E	C-CAP, U 1-10 Z F	YHT	TP-M240
O	PRE-MAIN AMP	C 0027	87-012-282-080	0E	C-CAP, U 4700P-50 K B	YHS	TP-M240
O	PRE-MAIN AMP	C 0027	87-012-282-080	0E	C-CAP, U 4700P-50 K B	YHT	TP-M240
S	PRE-MAIN AMP	D 0001	87-001-167-080	0E	C-DIODE, 1SS302	YHS	TP-M240
S	PRE-MAIN AMP	D 0001	87-001-167-080	0E	C-DIODE, 1SS302	YHT	TP-M240
S	PRE-MAIN AMP	D 0002	87-A40-822-040	0E	C-DIODE, CRS01	YHS	TP-M240
S	PRE-MAIN AMP	D 0002	87-A40-822-040	0E	C-DIODE, CRS01	YHT	TP-M240
S	PRE-MAIN AMP	IC 0001	85-TM5-604-010	1E	IC, LA4165M	YHS	TP-M240
S	PRE-MAIN AMP	IC 0001	85-TM5-604-010	1E	IC, LA4165M	YHT	TP-M240

PARTS LIST

- ! = Δ SAFTY PARTS
- C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use Japanese.

! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME
O	PRE-MAIN AMP	J 0001	87-A61-294-010	0E	JACK, 3.5 MONO W/SW	YHSCC	TP-M240
O	PRE-MAIN AMP	J 0001	87-A61-294-010	0E	JACK, 3.5 MONO W/SW	YHTSC	TP-M240
O	PRE-MAIN AMP	J 0002	87-A61-124-110	0E	JACK, DC DIA2.75 BLK TC	YHSCC	TP-M240
O	PRE-MAIN AMP	J 0002	87-A61-124-110	0E	JACK, DC DIA2.75 BLK TC	YHTSC	TP-M240
O	PRE-MAIN AMP	J 0002	87-A61-294-010	0E	JACK, 3.5 MONO W/SW	YHSCC	TP-M240
O	PRE-MAIN AMP	J 0002	87-A61-294-010	0E	JACK, 3.5 MONO W/SW	YHTSC	TP-M240
X	PRE-MAIN AMP	JR 0001	88-128-000-080	0E	C-JUMPER, 3216	YHSCC	TP-M240
X	PRE-MAIN AMP	JR 0001	88-128-000-080	0E	C-JUMPER, 3216	YHTSC	TP-M240
X	PRE-MAIN AMP	JR 0002	88-128-000-080	0E	C-JUMPER, 3216	YHSCC	TP-M240
X	PRE-MAIN AMP	JR 0002	88-128-000-080	0E	C-JUMPER, 3216	YHTSC	TP-M240
X	PRE-MAIN AMP	JR 0003	88-128-000-080	0E	C-JUMPER, 3216	YHSCC	TP-M240
X	PRE-MAIN AMP	JR 0003	88-128-000-080	0E	C-JUMPER, 3216	YHTSC	TP-M240
X	PRE-MAIN AMP	JR 0004	88-128-000-080	0E	C-JUMPER, 3216	YHSCC	TP-M240
X	PRE-MAIN AMP	JR 0004	88-128-000-080	0E	C-JUMPER, 3216	YHTSC	TP-M240
X	PRE-MAIN AMP	JR 0005	88-128-000-080	0E	C-JUMPER, 3216	YHSCC	TP-M240
X	PRE-MAIN AMP	JR 0005	88-128-000-080	0E	C-JUMPER, 3216	YHTSC	TP-M240
X	PRE-MAIN AMP	JR 0006	88-128-000-080	0E	C-JUMPER, 3216	YHSCC	TP-M240
X	PRE-MAIN AMP	JR 0006	88-128-000-080	0E	C-JUMPER, 3216	YHTSC	TP-M240
X	PRE-MAIN AMP	JR 0007	88-128-000-080	0E	C-JUMPER, 3216	YHSCC	TP-M240
X	PRE-MAIN AMP	JR 0007	88-128-000-080	0E	C-JUMPER, 3216	YHTSC	TP-M240
X	PRE-MAIN AMP	JR 0008	88-128-000-080	0E	C-JUMPER, 3216	YHSCC	TP-M240
X	PRE-MAIN AMP	JR 0008	88-128-000-080	0E	C-JUMPER, 3216	YHTSC	TP-M240
X	PRE-MAIN AMP	JR 0009	88-128-000-080	0E	C-JUMPER, 3216	YHSCC	TP-M240
X	PRE-MAIN AMP	JR 0009	88-128-000-080	0E	C-JUMPER, 3216	YHTSC	TP-M240
X	PRE-MAIN AMP	JR 0010	88-128-000-080	0E	C-JUMPER, 3216	YHSCC	TP-M240
X	PRE-MAIN AMP	JR 0010	88-128-000-080	0E	C-JUMPER, 3216	YHTSC	TP-M240
X	PRE-MAIN AMP	JR 0011	88-128-000-080	0E	C-JUMPER, 3216	YHSCC	TP-M240
X	PRE-MAIN AMP	JR 0011	88-128-000-080	0E	C-JUMPER, 3216	YHTSC	TP-M240
X	PRE-MAIN AMP	JR 0012	88-128-000-080	0E	C-JUMPER, 3216	YHSCC	TP-M240
X	PRE-MAIN AMP	JR 0012	88-128-000-080	0E	C-JUMPER, 3216	YHTSC	TP-M240
X	PRE-MAIN AMP	JR 0013	88-128-000-080	0E	C-JUMPER, 3216	YHSCC	TP-M240
X	PRE-MAIN AMP	JR 0013	88-128-000-080	0E	C-JUMPER, 3216	YHTSC	TP-M240
X	PRE-MAIN AMP	JR 0014	88-128-000-080	0E	C-JUMPER, 3216	YHSCC	TP-M240
X	PRE-MAIN AMP	JR 0014	88-128-000-080	0E	C-JUMPER, 3216	YHTSC	TP-M240
X	PRE-MAIN AMP	JR 0015	88-128-000-080	0E	C-JUMPER, 3216	YHSCC	TP-M240
X	PRE-MAIN AMP	JR 0015	88-128-000-080	0E	C-JUMPER, 3216	YHTSC	TP-M240
X	PRE-MAIN AMP	JR 0016	88-128-000-080	0E	C-JUMPER, 3216	YHSCC	TP-M240
X	PRE-MAIN AMP	JR 0016	88-128-000-080	0E	C-JUMPER, 3216	YHTSC	TP-M240
X	PRE-MAIN AMP	JR 0017	88-128-000-080	0E	C-JUMPER, 3216	YHSCC	TP-M240
X	PRE-MAIN AMP	JR 0017	88-128-000-080	0E	C-JUMPER, 3216	YHTSC	TP-M240
X	PRE-MAIN AMP	JR 0018	88-128-000-080	0E	C-JUMPER, 3216	YHSCC	TP-M240
X	PRE-MAIN AMP	JR 0018	88-128-000-080	0E	C-JUMPER, 3216	YHTSC	TP-M240
X	PRE-MAIN AMP	JR 0019	88-128-000-080	0E	C-JUMPER, 3216	YHSCC	TP-M240
X	PRE-MAIN AMP	JR 0019	88-128-000-080	0E	C-JUMPER, 3216	YHTSC	TP-M240
X	PRE-MAIN AMP	JR 0020	88-128-000-080	0E	C-JUMPER, 3216	YHSCC	TP-M240
X	PRE-MAIN AMP	JR 0020	88-128-000-080	0E	C-JUMPER, 3216	YHTSC	TP-M240
X	PRE-MAIN AMP	JR 0021	88-128-000-080	0E	C-JUMPER, 3216	YHSCC	TP-M240
X	PRE-MAIN AMP	JR 0021	88-128-000-080	0E	C-JUMPER, 3216	YHTSC	TP-M240
X	PRE-MAIN AMP	JR 0022	88-128-000-080	0E	C-JUMPER, 3216	YHSCC	TP-M240
X	PRE-MAIN AMP	JR 0022	88-128-000-080	0E	C-JUMPER, 3216	YHTSC	TP-M240
X	PRE-MAIN AMP	JR 0023	88-128-000-080	0E	C-JUMPER, 3216	YHSCC	TP-M240
X	PRE-MAIN AMP	JR 0023	88-128-000-080	0E	C-JUMPER, 3216	YHTSC	TP-M240
X	PRE-MAIN AMP	JR 0024	88-128-000-080	0E	C-JUMPER, 3216	YHSCC	TP-M240
X	PRE-MAIN AMP	JR 0024	88-128-000-080	0E	C-JUMPER, 3216	YHTSC	TP-M240
X	PRE-MAIN AMP	JR 0025	88-128-000-080	0E	C-JUMPER, 3216	YHSCC	TP-M240
X	PRE-MAIN AMP	JR 0025	88-128-000-080	0E	C-JUMPER, 3216	YHTSC	TP-M240
X	PRE-MAIN AMP	JR 0026	88-128-000-080	0E	C-JUMPER, 3216	YHSCC	TP-M240
X	PRE-MAIN AMP	JR 0026	88-128-000-080	0E	C-JUMPER, 3216	YHTSC	TP-M240
X	PRE-MAIN AMP	JR 0027	88-128-000-080	0E	C-JUMPER, 3216	YHSCC	TP-M240
X	PRE-MAIN AMP	JR 0027	88-128-000-080	0E	C-JUMPER, 3216	YHTSC	TP-M240
X	PRE-MAIN AMP	JR 0028	88-128-000-080	0E	C-JUMPER, 3216	YHSCC	TP-M240
X	PRE-MAIN AMP	JR 0028	88-128-000-080	0E	C-JUMPER, 3216	YHTSC	TP-M240
X	PRE-MAIN AMP	JR 0029	88-128-000-080	0E	C-JUMPER, 3216	YHSCC	TP-M240
X	PRE-MAIN AMP	JR 0029	88-128-000-080	0E	C-JUMPER, 3216	YHTSC	TP-M240
X	PRE-MAIN AMP	JR 0030	88-128-000-080	0E	C-JUMPER, 3216	YHSCC	TP-M240
X	PRE-MAIN AMP	JR 0030	88-128-000-080	0E	C-JUMPER, 3216	YHTSC	TP-M240
X	PRE-MAIN AMP	JR 0031	88-128-000-080	0E	C-JUMPER, 3216	YHSCC	TP-M240
X	PRE-MAIN AMP	JR 0031	88-128-000-080	0E	C-JUMPER, 3216	YHTSC	TP-M240
X	PRE-MAIN AMP	JR 0032	88-108-000-080	0E	C-JUMPER, U	YHSCC	TP-M240
X	PRE-MAIN AMP	JR 0032	88-108-000-080	0E	C-JUMPER, U	YHTSC	TP-M240

PARTS LIST

! = Δ SAFTY PARTS
 C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use Japanese.

! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME
O	PRE-MAIN AMP	LED0001	8Z-HX5-601-010	--	LED,KM2520A01SRC001	RED	TP-M240
O	PRE-MAIN AMP	LED0001	8Z-HX5-601-010	--	LED,KM2520A01SRC001	RED	TP-M240
O	PRE-MAIN AMP	MIC0001	87-A91-891-010	1A	MIC,ECM OBO-54LN-OB		TP-M240
O	PRE-MAIN AMP	MIC0001	87-A91-891-010	1A	MIC,ECM OBO-54LN-OB		TP-M240
S	PRE-MAIN AMP	Q 0001	87-A30-288-040	OE	C-TR,DTC114YKA		TP-M240
S	PRE-MAIN AMP	Q 0001	87-A30-288-040	OE	C-TR,DTC114YKA		TP-M240
S	PRE-MAIN AMP	Q 0002	87-A30-288-040	OE	C-TR,DTC114YKA		TP-M240
S	PRE-MAIN AMP	Q 0002	87-A30-288-040	OE	C-TR,DTC114YKA		TP-M240
S	PRE-MAIN AMP	Q 0003	87-A30-283-040	OE	C-TR,DTA114YKA		TP-M240
S	PRE-MAIN AMP	Q 0003	87-A30-283-040	OE	C-TR,DTA114YKA		TP-M240
S	PRE-MAIN AMP	Q 0004	89-327-125-080	OE	C-TR,2SC2712GR		TP-M240
S	PRE-MAIN AMP	Q 0004	89-327-125-080	OE	C-TR,2SC2712GR		TP-M240
S	PRE-MAIN AMP	Q 0005	89-327-125-080	OE	C-TR,2SC2712GR		TP-M240
S	PRE-MAIN AMP	Q 0005	89-327-125-080	OE	C-TR,2SC2712GR		TP-M240
S	PRE-MAIN AMP	Q 0006	89-327-125-080	OE	C-TR,2SC2712GR		TP-M240
S	PRE-MAIN AMP	Q 0006	89-327-125-080	OE	C-TR,2SC2712GR		TP-M240
S	PRE-MAIN AMP	Q 0007	87-A30-283-040	OE	C-TR,DTA114YKA		TP-M240
S	PRE-MAIN AMP	Q 0007	87-A30-283-040	OE	C-TR,DTA114YKA		TP-M240
S	PRE-MAIN AMP	Q 0009	89-327-125-080	OE	C-TR,2SC2712GR		TP-M240
S	PRE-MAIN AMP	Q 0009	89-327-125-080	OE	C-TR,2SC2712GR		TP-M240
X	PRE-MAIN AMP	R 0001	88-108-392-080	OE	C-RES,U 3.9K-1/16W J		TP-M240
X	PRE-MAIN AMP	R 0001	88-108-392-080	OE	C-RES,U 3.9K-1/16W J		TP-M240
X	PRE-MAIN AMP	R 0002	88-108-822-080	OE	C-RES,U 8.2K-1/16W J		TP-M240
X	PRE-MAIN AMP	R 0002	88-108-822-080	OE	C-RES,U 8.2K-1/16W J		TP-M240
X	PRE-MAIN AMP	R 0003	88-108-223-080	OE	C-RES,U 22K-1/16W J		TP-M240
X	PRE-MAIN AMP	R 0003	88-108-223-080	OE	C-RES,U 22K-1/16W J		TP-M240
X	PRE-MAIN AMP	R 0004	88-108-470-080	OE	C-RES,U 47-1/16W J		TP-M240
X	PRE-MAIN AMP	R 0004	88-108-470-080	OE	C-RES,U 47-1/16W J		TP-M240
X	PRE-MAIN AMP	R 0005	88-108-152-080	OE	C-RES,U 1.5K-1/16W J		TP-M240
X	PRE-MAIN AMP	R 0005	88-108-152-080	OE	C-RES,U 1.5K-1/16W J		TP-M240
X	PRE-MAIN AMP	R 0006	88-108-561-080	OE	C-RES,U 560-1/16W J		TP-M240
X	PRE-MAIN AMP	R 0006	88-108-561-080	OE	C-RES,U 560-1/16W J		TP-M240
X	PRE-MAIN AMP	R 0007	88-108-222-080	OE	C-RES,U 2.2K-1/16W J		TP-M240
X	PRE-MAIN AMP	R 0007	88-108-222-080	OE	C-RES,U 2.2K-1/16W J		TP-M240
X	PRE-MAIN AMP	R 0008	88-108-225-080	OE	C-RES,U 2.2M-1/16W J		TP-M240
X	PRE-MAIN AMP	R 0008	88-108-225-080	OE	C-RES,U 2.2M-1/16W J		TP-M240
X	PRE-MAIN AMP	R 0009	88-108-681-080	OE	C-RES,U 680-1/16W J		TP-M240
X	PRE-MAIN AMP	R 0009	88-108-681-080	OE	C-RES,U 680-1/16W J		TP-M240
X	PRE-MAIN AMP	R 0010	88-108-390-080	OE	C-RES,U 39-1/16W J		TP-M240
X	PRE-MAIN AMP	R 0010	88-108-390-080	OE	C-RES,U 39-1/16W J		TP-M240
X	PRE-MAIN AMP	R 0015	88-108-229-080	OE	C-RES,U 2.2-1/16W J		TP-M240
X	PRE-MAIN AMP	R 0015	88-108-229-080	OE	C-RES,U 2.2-1/16W J		TP-M240
X	PRE-MAIN AMP	R 0017	88-108-222-080	OE	C-RES,U 2.2K-1/16W J		TP-M240
X	PRE-MAIN AMP	R 0017	88-108-222-080	OE	C-RES,U 2.2K-1/16W J		TP-M240
X	PRE-MAIN AMP	R 0018	88-108-102-080	OE	C-RES,U 1K-1/16W J		TP-M240
X	PRE-MAIN AMP	R 0018	88-108-102-080	OE	C-RES,U 1K-1/16W J		TP-M240
X	PRE-MAIN AMP	R 0019	88-108-822-080	OE	C-RES,U 8.2K-1/16W J		TP-M240
X	PRE-MAIN AMP	R 0019	88-108-822-080	OE	C-RES,U 8.2K-1/16W J		TP-M240
X	PRE-MAIN AMP	R 0020	88-108-392-080	OE	C-RES,U 3.9K-1/16W J		TP-M240
X	PRE-MAIN AMP	R 0020	88-108-392-080	OE	C-RES,U 3.9K-1/16W J		TP-M240
X	PRE-MAIN AMP	R 0021	88-108-123-080	OE	C-RES,U 12K-1/16W J		TP-M240
X	PRE-MAIN AMP	R 0021	88-108-123-080	OE	C-RES,U 12K-1/16W J		TP-M240
X	PRE-MAIN AMP	R 0022	88-108-223-080	OE	C-RES,U 22K-1/16W J		TP-M240
X	PRE-MAIN AMP	R 0022	88-108-223-080	OE	C-RES,U 22K-1/16W J		TP-M240
X	PRE-MAIN AMP	R 0023	88-108-102-080	OE	C-RES,U 1K-1/16W J		TP-M240
X	PRE-MAIN AMP	R 0023	88-108-102-080	OE	C-RES,U 1K-1/16W J		TP-M240
X	PRE-MAIN AMP	R 0024	88-108-472-080	OE	C-RES,U 4.7K-1/16W J		TP-M240
X	PRE-MAIN AMP	R 0024	88-108-472-080	OE	C-RES,U 4.7K-1/16W J		TP-M240
X	PRE-MAIN AMP	R 0025	88-108-562-080	OE	C-RES,U 5.6K-1/16W J		TP-M240
X	PRE-MAIN AMP	R 0025	88-108-562-080	OE	C-RES,U 5.6K-1/16W J		TP-M240
X	PRE-MAIN AMP	R 0026	88-108-561-080	OE	C-RES,U 560-1/16W J		TP-M240
X	PRE-MAIN AMP	R 0026	88-108-561-080	OE	C-RES,U 560-1/16W J		TP-M240
X	PRE-MAIN AMP	R 0028	88-108-393-080	OE	C-RES,U 39K-1/16W J		TP-M240
X	PRE-MAIN AMP	R 0028	88-108-393-080	OE	C-RES,U 39K-1/16W J		TP-M240
X	PRE-MAIN AMP	R 0035	88-108-470-080	OE	C-RES,U 47-1/16W J		TP-M240
X	PRE-MAIN AMP	R 0035	88-108-470-080	OE	C-RES,U 47-1/16W J		TP-M240
X	PRE-MAIN AMP	R 0036	88-108-274-080	OE	C-RES,U 270K-1/16W J		TP-M240
X	PRE-MAIN AMP	R 0036	88-108-274-080	OE	C-RES,U 270K-1/16W J		TP-M240
X	PRE-MAIN AMP	R 0037	88-108-332-080	OE	C-RES,U 3.3K-1/16W J		TP-M240
X	PRE-MAIN AMP	R 0037	88-108-332-080	OE	C-RES,U 3.3K-1/16W J		TP-M240

PARTS LIST

! = Δ SAFTY PARTS
 C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.


Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use Japanese.

! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME
X	PRE-MAIN AMP	R 0038	88-108-222-080	0E	C-RES,U 2.2K-1/16W J	YHSCC	TP-M240
X	PRE-MAIN AMP	R 0038	88-108-222-080	0E	C-RES,U 2.2K-1/16W J	YHTSC	TP-M240
X	PRE-MAIN AMP	R 0039	88-108-102-080	0E	C-RES,U 1K-1/16W J	YHSCC	TP-M240
X	PRE-MAIN AMP	R 0039	88-108-102-080	0E	C-RES,U 1K-1/16W J	YHTSC	TP-M240
X	PRE-MAIN AMP	R 0040	88-108-223-080	0E	C-RES,U 22K-1/16W J	YHSCC	TP-M240
X	PRE-MAIN AMP	R 0040	88-108-223-080	0E	C-RES,U 22K-1/16W J	YHTSC	TP-M240
X	PRE-MAIN AMP	R 0041	88-108-331-080	0E	C-RES,U 330-1/16W J	YHSCC	TP-M240
X	PRE-MAIN AMP	R 0041	88-108-331-080	0E	C-RES,U 330-1/16W J	YHTSC	TP-M240
O	PRE-MAIN AMP	R 0075	85-TM5-611-010	0E	RES,220-1/8W J 3900P	YHSCC	TP-M240
O	PRE-MAIN AMP	R 0075	85-TM5-611-010	0E	RES,220-1/8W J 3900P	YHTSC	TP-M240
O	PRE-MAIN AMP	R 0076	85-TM5-612-010	0E	RES,33K-1/8W J 800P	YHSCC	TP-M240
O	PRE-MAIN AMP	R 0076	85-TM5-612-010	0E	RES,33K-1/8W J 800P	YHTSC	TP-M240
X	PRE-MAIN AMP	R 0077	88-108-222-080	0E	C-RES,U 2.2K-1/16W J	YHSCC	TP-M240
X	PRE-MAIN AMP	R 0077	88-108-222-080	0E	C-RES,U 2.2K-1/16W J	YHTSC	TP-M240
O	PRE-MAIN AMP	SFR0001	85-TM5-615-010	--	SFR,5K V FRB-062	YHSCC	TP-M240
O	PRE-MAIN AMP	SFR0001	85-TM5-615-010	--	SFR,5K V FRB-062	YHTSC	TP-M240
O	PRE-MAIN AMP	SFR0002	87-A91-282-080	1A	C-SFR,2.0K H RVG3S08	YHSCC	TP-M240
O	PRE-MAIN AMP	SFR0002	87-A91-282-080	1A	C-SFR,2.0K H RVG3S08	YHTSC	TP-M240
O	PRE-MAIN AMP	SP 0001	87-A91-612-110	1D	SPKR,DIA36 4OHM 0.4W	YHSCC	TP-M240
O	PRE-MAIN AMP	SP 0001	87-A91-612-110	1D	SPKR,DIA36 4OHM 0.4W	YHTSC	TP-M240
O	PRE-MAIN AMP	SW 0001	8Z-HX5-602-010	--	SW,PUSH PS42D07	YHSCC	TP-M240
O	PRE-MAIN AMP	SW 0001	8Z-HX5-602-010	--	SW,PUSH PS42D07	YHTSC	TP-M240
O	PRE-MAIN AMP	SW 0002	87-031-816-010	1A	SW,SL 1-1-2 SSSS71446A	YHSCC	TP-M240
O	PRE-MAIN AMP	SW 0002	87-031-816-010	1A	SW,SL 1-1-2 SSSS71446A	YHTSC	TP-M240
O	PRE-MAIN AMP	SW 0004	87-036-343-010	1A	SW,SL 2-2-2 SSSS22	YHSCC	TP-M240
O	PRE-MAIN AMP	SW 0004	87-036-343-010	1A	SW,SL 2-2-2 SSSS22	YHTSC	TP-M240
S	PRE-MAIN AMP	SW 0005	85-TM5-608-010	--	SW,LEAF LSA-1114P	YHSCC	TP-M240
S	PRE-MAIN AMP	SW 0005	85-TM5-608-010	--	SW,LEAF LSA-1114P	YHTSC	TP-M240
O	PRE-MAIN AMP	SW 0005	87-031-816-010	1A	SW,SL 1-1-2 SSSS71446A	YHSCC	TP-M240
O	PRE-MAIN AMP	SW 0005	87-031-816-010	1A	SW,SL 1-1-2 SSSS71446A	YHTSC	TP-M240
!	O PRE-MAIN AMP	SW 0006	87-A90-826-010	1A	SW,LEAF LSA-1114P2	YHSCC	TP-M240
!	O PRE-MAIN AMP	SW 0006	87-A90-826-010	1A	SW,LEAF LSA-1114P2	YHTSC	TP-M240
O	PRE-MAIN AMP	SW 0009	87-A90-330-080	0E	C-SW,SL 1-1-2 SSSS81 T1.4	YHSCC	TP-M240
O	PRE-MAIN AMP	SW 0009	87-A90-330-080	0E	C-SW,SL 1-1-2 SSSS81 T1.4	YHTSC	TP-M240
O	PRE-MAIN AMP	VR 0001	87-A91-828-010	--	VR,RTRY 10KA V VX010702GYPV1N1	YHSCC	TP-M240
O	PRE-MAIN AMP	VR 0001	87-A91-828-010	--	VR,RTRY 10KA V VX010702GYPV1N1	YHTSC	TP-M240
X	PRINTED MATTER		87-B50-078-010	0E	LIST,FACILITY(S)-0007	YHSCC	TP-M240
X	PRINTED MATTER		87-B50-078-010	0E	LIST,FACILITY(S)-0007	YHTSC	TP-M240
X	PRINTED MATTER		87-B50-080-010	0E	WARR-CARD,CHINA-0009	YHSCC	TP-M240
O	PRINTED MATTER		8B-HX7-902-010	--	IB,YH(ECC)C	YHSCC	TP-M240
O	PRINTED MATTER		8B-HX7-902-010	--	IB,YH(ECC)C	YHTSC	TP-M240
X	PWB A		8B-HX4-601-010	--	PWB,COMB 3 3M	YHSCC	TP-M240
X	PWB A		8B-HX4-601-010	--	PWB,COMB 3 3M	YHTSC	TP-M240
X	PWB A		8B-HX4-602-010	--	PWB,MAIN	YHSCC	TP-M240
X	PWB A		8B-HX4-602-010	--	PWB,MAIN	YHTSC	TP-M240
X	PWB A		8B-HX4-603-010	--	PWB,MIC	YHSCC	TP-M240
X	PWB A		8B-HX4-603-010	--	PWB,MIC	YHTSC	TP-M240
O	SCREW		8Z-HX5-204-010	--	VT2+2-6 CR S	YHSCC	TP-M240
O	SCREW		8Z-HX5-204-010	--	VT2+2-6 CR S	YHTSC	TP-M240
O	SCREW		8Z-HX5-205-010	--	VT2+1.7-6 CR S	YHSCC	TP-M240
O	SCREW		8Z-HX5-205-010	--	VT2+1.7-6 CR S	YHTSC	TP-M240
O	SCREW		8Z-HX5-206-010	--	UT2+2-20 CR S	YHSCC	TP-M240
O	SCREW		8Z-HX5-206-010	--	UT2+2-20 CR S	YHTSC	TP-M240
X	TAPE TRANSPORT		M8-AZK-790-070	--	M-187	YHSCC	TP-M240
X	TAPE TRANSPORT		M8-AZK-790-070	--	M-187	YHTSC	TP-M240
X	UNIT CODE		PB-HX7-311-080	--	TP-M240 YHSCC	YHSCC	TP-M240
X	UNIT CODE		PB-HX7-343-070	--	TP-M240 YHTSC	YHTSC	TP-M240

SCHEMATIC DIAGRAM - 1 (MAIN)



アイワ株式会社 〒110-8710 東京都台東区池之端1-2-11 ☎03(3827)3111 (代表)
AIWA CO.,LTD. 2-11, IKENOHATA 1-CHOME, TAITO-KU, TOKYO 110, JAPAN TEL:03 (3827) 3111