


M-18

Ampeg



MODEL NO. M-18

Tube Location (from left to right)

SERIAL

V1	V2	V3	V4	V5	V6
6SL7	6SL7	6SL7	6L6	6L6	5U4

CONNECTED TO THE
AUTO-TRANSFORMER
FOR 240V

Ampeg