





A17 Power amplifier







F16 Tuner control and FM. I.F. section

Track side of F16






C:28 Input switching and pre-amplifier






Z:20 Power supply


Bottom View



C:30 Tuner power supply and audio output
Tuners Only



F14 A.M. aerial amplifier L14 Stereo decoder



Drive Cord Replacement
Viewed from front of set (plan view)