


# Bang & Olufsen




## Beocenter 2200

Type 2421/22/25










Voltages in [ ] are measured in AM mode  
 Voltages in ( ) are measured in FM AUTO mode


## DIAGRAM B





MAINS VOLTAGE CONNECTIONS AND FUSES ARE PLACED UNDER COVER AT RIGHT HAND SIDE (FROM BOTTOM)





<math>\wedge</math> = REW  
 <math>\vee</math> = PLAY  
 <math>\nabla</math> = FF

- A25 - A34
- B35 - B42
- B54
- B66 - B67
- B70
- D56 - D59
- D64
- E60 - E63

