


Bang & Olufsen




Beogram 6002

Type 5641/42/43/45/46/47


Beogram TX

Type 5651/52/53/55



MANUEL d'ENTRETIEN

Bang & Olufsen



TYPE	AC SUPPLY	F1
5641	100V	T 0,8A
5643	120V	T 1,2 A
5645	220V	T 0,8A
5646	240V	T 0,8A
5647	240V	T 0,8A
5651	220V	T 0,8A
5652	240V	T 0,8A
5653	120V	T 1,2A
5655	240V	T 0,8A

