


Bang & Olufsen



Beolab 8000


Type 6801, 6802, 6803,
6804, 6805

Indklæbes i serviceanvisningen Beovox 5 (3538717)
Paste into service manual Beovox 5 (3538717)

3538801

01





#=SMD

#=SMD

50V (ICON)