


MODEL 83


BROWNING LABORATORIES, INC.

MODEL BL-FM22
MODEL BL-43-6D

NOTES:

1. BROWNING BL-1 TUNER - INDUCTION OF FOUR SETS OF COILS 11, 12, 13, 14, 15, 16 WITH A TUNED AND TUNED CIRCUIT AND CHANGE OVER SWITCH FOR THE FOUR BANKS ALL INDUCED WITH ONE SET OF COILS.
2. TUNING WHOLE SPOTS ARE INVERTED (BROWNING SAYS ONLY ONE SET OF COILS).
3. RESISTORS ARE 1/4 WATT UNLESS OTHERWISE SPECIFIED.
4. CONNECTIONS TO BROWNING BL-1 TUNER.
5. T.R. PHONOGRAPH JACK CONNECTIONS SHOULD LEAD AT T-2 AND WHILE AS SHOWN, JACK SHOULD BE PLACED IN HOLE NEAR TO TUNER NEED TO VOLUME KNOB LEAD TO JACK WHILST.
6. FOR PHONO JACK CONNECTIONS MEAN LEAD AT T-2 AND WHILE AS SHOWN, PHONE JACK SHOULD BE PLACED IN HOLE NEAR TUNER CAPTION.
7. I.F. FREQUENCY 49.9 K.C.

MODELS BL-FM22 AND BL-43-6D



©John F. Rider