


**SCHEMATIC DIAGRAM (2) CMC-5L (E), (UK), (GE), (FR)**



- 500 FUNCTION SW PHONO AIDE RADIO (RADIO POSITION)
- 501 RECT/F B SW PLAYBACK-REC (PLAYBACK POSITION)
- 502 SP SW (A)
- 503 SW (A)
- 504 DUB SW ON-OFF (OFF POSITION)
- 505 TAPE POSITION SW NORMAL (TAPE) (OFF POSITION)
- 506 CO2 (TURNS) (OFF POSITION)
- 507 METAL (OFF POSITION)
- 508 ADDRESS SW 1-2-3 (1 POSITION)
- 509 MEAT SW
- 510 POWER SW WHISTING SW ON-OFF (OFF POSITION)
- 511 SW (A)
- 512 SW (A)
- 513 MODE FLASHING SW ON-OFF (OFF POSITION)
- 514 PAUSE SW ON-OFF (OFF POSITION)