



Hitachi HA 1100

- NOTES
- 1. S1a,b S2a-d
  - 2. S1a,b S17,b
  - 3. UNITS
- POWER SPEAKERS
- FUNCTION
- TAPE MONITOR
- TAPE COPY
- LOUDNESS
- GAIN SELECTOR
- GAIN SELECTOR
- MODE
- HIGH FILTER
- LOW FILTER
- TONE DEFEAT
- TREBLE TURNOVER
- BASS TURNOVER
- RELAY
- THERMAL PROTECTOR
- PHONO-2 LEVEL
- BALANCE
- LEVEL ATTENUATOR
- B SPEAKERS LEVEL
- BASS CONTROL
- TREBLE CONTROL
- IDLE CURRENT ADJUST
- DISTORTION ADJUST
- RESISTANCE : Ω
- CAPACITANCE : F
- ① ON 2.OFF
  - ① OFF
  - 2.A SPEAKERS
  - 3.B SPEAKERS
  - 4.C SPEAKERS
  - 5.A+B SPEAKERS
  - 6.A+C SPEAKERS
  - ① PHONO-2
  - 2.PHONO-1
  - 3.TUNER
  - 4.AUX-1
  - 5.AUX-2
  - 6.A+C SPEAKERS
  - ① TAPE-1
  - 2.TAPE-2
  - ① TAPE-1-2
  - ② SOURCE
  - 3.TAPE-2-1
  - 1.ON ② OFF
  - 1.-20dB ② OFF
  - 1.-10dB ② OFF
  - 1.-5 dB ② OFF
  - ① REVERSE
  - ② STEREO
  - 3.L+R
  - 4.L
  - 5.R
  - 1.15kHz
  - ② OFF
  - 3.8kHz
  - 1.OFF
  - ② 10Hz
  - 3.30Hz
  - ① DEFEAT
  - 1.6Hz
  - ② 2Hz
  - 3.15Hz
  - ② 300Hz
  - 1.150Hz
  - 3.600Hz
  - ① SP ON 2.SP OFF
  - 1.ON ② OFF

TERMINAL GUIDE OF TRANSISTORS

