



JR-S501 Schematic Diagram



Printed Circuit Board Ass'y Locations

P.C. Board Ass'y	Descriptikon	Page
TFC-23A	FM/AM Tuners and Equalizer Amp. P.C. Board Ass'y	14
TXX-114A	Select Switch P.C. Board Ass'y	22
TXX-115A	Speaker Terminal P.C. Board Ass'y	23
TXX-116A	Pin-jack P.C. Board Ass'y	24
TXX-117C,D(or G) and TXX-130C (or D)	AC Block P.C. Board Ass'y	25
TPS-118A (or B)	DC Power Supply P.C. Board Ass'y	26
TPS-126A (to D)	Fuse P.C. Board Ass'y	28
TAP-273A	Power Amp. P.C. Board Ass'y	29
TAC-488B	S.E.A. (Sound Effect Amp.) P.C. Board Ass'y	34



Notes:

1. Parts in red indicate transistors or ICs.
2.  indicates signal path.
3.  indicates positive B power supply.
Voltage values in  are negative.
4.  indicates negative B power supply.
Voltage values in  are positive.
5. When replacing the parts in the darkened area  and those marked with , be sure to use the designated parts to ensure safety.
6. This is the standard circuit diagram.
The design and contents are subject to change without notice.