

# JVC

# SCHEMATIC DIAGRAMS



## HOME CINEMA CONTROL CENTER

### RX-E5S

CD-ROM No.SML200405

**Area suffix**

US ----- Singapore  
UP ----- Korea  
UT ----- Taiwan




**AV COMPU LINK**

### Contents

Block diagram .....	2-1
Standard schematic diagrams .....	2-2
Printed circuit boards .....	2-8 to 12


# Block diagram



# Standard schematic diagrams

## ■ Primary / Regulator section (US, UT, A)

TO CN711 OF LVA10482-1  
(SHEET 3)



VERSION CODES

E	: CONTINENTAL EUROPE
EN	: NORTHERN EUROPE
B	: U.K.
EV	: EASTERN EUROPE
A	: AUSTRARIA
US	: SINGAPORE
UT	: TAIWAN
UP	: KOREA


SHEET NUMBER	CIRC IT DISCRPTION
1	PRIMARY/REGULATOR (US-UT, A)
2	PRIMARY/REGULATOR (UP)
3	POWER AMP/SPEAKER TERMINAL
4	AUDIO-VIDEO SIGNAL IN/OUT/SOUND IC/SYSTEM CONTROL LSI
5	USER CONTROL KEYS/SYSTEM CONTROL LSI/FL DISPLAY
6	DSP IC/DIGITAL SIGNAL INPUT TERMINAL

▲ Parts are safety assurance parts.  
When replacing those parts make sure to use the specified one.

Primary / Regulator section (UP)

TO CN711 OF LVA10482-1  
(SHEET 3)


UP



VERSION CODES  
 E : CONTINENTAL EUROPE  
 EN : NORTHERN EUROPE  
 B : U. K.  
 EV : EASTERN EUROPE  
 A : AUSTRIA  
 US : SINGAPORE  
 UT : TAIWAN  
 UP : KOREA

⚠ Parts are safety assurance parts.  
 When replacing those parts make  
 sure to use the specified one.

Power amp / Speaker terminal section



Mark

REV	DATE	BY	CHK	DESCRIPTION
1				
2				
3				
4				
5				
6				
7				
8				
9				
10				

Parts are safety assurance parts.  
When replacing those parts make sure to use the specified one.




Audio video signal in / out / system control LSI section

TO CN601 OF LVA10479-3  
(SHEET 6)

TO CN602 OF LVA10479-3  
(SHEET 6)

CONTROL LOGIC				
SOURCE	VIDEO1	VIDEO2	VIDEO3	VIDEO4
DVD MULTI	L	H	H	L
DVD	L	H	H	L
VIDEO1(OBS)	H	H	H	L
VCR	H	L	H	H
TV	H	L	H	H
FM/AM	L	L	L	L



\*MARK  
C6671-C6676 USE ONLY LIP

TO CN600 OF LVA10481-1 (SHEET 1 or SHEET 2) TO CN610 OF LVA10481-1 (SHEET 1 or SHEET 2)

TO CN628 OF LVA10480-8 (SHEET 3)


TO CN631 OF LVA10481-8 (SHEET 5)

TO CN619 OF LVA10481-1 (SHEET 3)



LVA10480-7

Parts are safety assurance parts.  
When replacing those parts make sure to use the specified one.

■ User control keys / system control LSI / FL display section



■ DSP IC / Digital signal input terminal section



Ver.	US-UP-UT-A
Rev.	1.0
Date	01.01

TO CN52 OF LVA10480-4  
(SHEET 4)

TO CN502 OF LVA10480-1  
(SHEET 4)

LVA10480-3