

Supplementary





SERVICE MANUAL

MODEL VL-8

Two of the illustrations shown in the section "VOLTAGE CHANGE" of the SERVICE MANUAL No. 2294 for the VL-8 are incorrect.

When you use this SERVICE MANUAL please see the correct illustrations below.

CORRECTION

ORIGINAL	CORRECTED
<p data-bbox="588 1397 746 1428">220V ZONE</p>  <p data-bbox="531 1907 756 1938">AC 220, 50/60Hz</p> <p data-bbox="316 1938 419 1968">Fig. 7</p>	<p data-bbox="1447 1413 1604 1443">220V ZONE</p>  <p data-bbox="1389 1938 1614 1968">AC 220V, 50/60Hz</p>
<p data-bbox="562 2044 719 2075">240V ZONE</p>  <p data-bbox="500 2548 746 2578">AC 240V, 50/60Hz</p> <p data-bbox="306 2578 408 2609">Fig. 8</p>	<p data-bbox="1430 2044 1588 2075">240V ZONE</p>  <p data-bbox="1379 2563 1624 2594">AC 240V, 50/60Hz</p>