



RESISTOR VALUES GIVEN IN OHMS UNLESS STATED OTHERWISE SHOWN  
 CAPACITOR VALUES GIVEN IN MICRO-MICROGRAMS UNLESS OTHERWISE SHOWN  
 VOLTAGES INDICATED ON A SWITCH OR POTENTIOMETER  
 SWITCHES AND POTENTIOMETERS  
 SW1 INPUT SELECTION SWITCH  
 SW2 FUNCTION SWITCH  
 SW3 FILTER SWITCH  
 SW4 TUNING SWITCH  
 SW5 TUNING POINT OF MIXER  
 SW6 AND SW7 ARE MOUNTED FROM THE HOOD  
 END OF THE SWITCH ON POTENTIOMETER  
 ALL SWITCHES ARE SHOWN FULLY ANTICLOCKWISE

CIRCUIT DIAGRAM

**H. J. LEAK & CO., LTD.**

BRUNEL ROAD • WESTWAY FACTORY ESTATE • LONDON W.3

Telephone :

Shepherds Bush 1173/4/5

Telegrams :

Inland : Sinusoidal, Ealux, London  
 Foreign : Sinusoidal, London