



(OPTION)

- ⊖ AGND (ANALOG)
- ⊖ DGND (DIGITAL)
- ⊕ +5V(DIGITAL)
- ⊕ +5VA(ANALOG)

*OPTION

- 1) When Using IC204
R203: NO NEED
- 2) When NOT Using IC204
R202, IC206, IC207
NO NEED

- * A = 32M ROM ENABLE SIGNAL (EXCEPT PGM ROM)
- * B = PGM ROM ENABLE SIGNAL
- * C = 16M LOW ROM ENABLE SIGNAL
- * D = 16M HIGH ROM ENABLE SIGNAL
- * F = USE TWO 16M ROMS
- * A=USE TWO 16M ROMS AND 1M PGM ROM

1. GND_D2(DIGITAL)
2. GND_CD(ANALOG)
3. +5V_CD(CD ONLY)
4. +12V_CD(DRIVE)

1. MLD1(IC210 #49)
2. RESET(IC210 #17)
3. CMP/VCD(Q301 BASE)
4. MUTE(Q315 EMITTER)



