



	J	U	S	E
F001	3A	3A	1A (T)	3A / 1.5A
F002 a,b	3A	3A	3.15A (F)	3A
F401	0.5A	0.5A	100mA (T)	0.5A

- Note: SW 101 PHONO INPUT SELECTOR  
 SW 102 TUNER INPUT SELECTOR  
 SW 103 AUX INPUT SELECTOR  
 SW 104 MONITOR  
 SW 105 MONITOR 1, 2  
 SW 106 DUBBING 1-2  
 SW 107 DUBBING 2-1  
 SW 108 SUBSONIC  
 SW 109 HIGH CUT  
 SW 110 MODE  
 SW 111 LOUDNESS
- \*----FLEME PROOF TYPE
- SW 001 POWER SW  
 SW 501 SPEAKER A.  
 SW 502 SPEAKER B.