


INSIDE VIEW MANLEY WAVE REMOTE CONTROL



FIXING THE WAVE DAC REMOTE CONTROL
PROBLEM (POOR BATTERY LIFE).

STEP # 1 REMOVE COVER

STEP # 2 IDENTIFY THE CHIP CD4011BCN (THE ONE CLOSEST TO THE BATTERIES)
AND USE A PAIR OF WIRE CUTTERS TO CLIP PIN #11.SO IT NO LONGER
CONNECTS TO THE CIRCUIT BOARD IF IS NOT NEEDED.