

<b>marantz®</b> <b>SERVICE BULLETIN</b>	Date: 9-Dec.-2004	Model: DV4500 / DV6500
	Page: 1 / 1	REF.NBR: MZ04-078
Subject: <p style="text-align: center;"><b>Software Update File Information.</b></p> <p style="text-align: center;"><b>Update the firmware version to Ver: 1.07</b></p>		

Attached Update firmware File name is “90M-DV4500xCR.zip” and “90M-DV6500xCR.zip”

	Disc Part No.	Inside of .zip file
1) Update of the firmware disc for DV4500/N1B/N1S	90M-DV4500NCR	E5N107_GP2S.ab5
2) Update of the firmware disc for DV4500/U1B/U1S	90M-DV4500UCR	E5N107_EP1E.ab5
3) Update of the firmware disc for DV4500/S1G	90M-DV4500SCR	E5N107_GP3A.ab5
-----		
4) Update of the firmware disc for DV6500/N1B/N1S	90M-DV6500NCR	E5N107_WA2S.ab5
5) Update of the firmware disc for DV6500/U1B	90M-DV6500UCR	E5N107_TA1E.ab5
6) Update of the firmware disc for DV6500/S1G	90M-DV6500SCR	E5N107_WA3A.ab5

1. When you received “.zip” file, Please unzip them.
2. Then you can find the following files.

Example: 90M-DV4500NCR.zip folder, file name is E5N107\_GP2S.ab5

3. Please make each CD-ROM with the above each file for DV4500 and for DV6500 separately with The following CD-R writing application setting.

- 3-1. CD-ROM mode 1 (ISO9660)
- 3-2. "Joliet" file mode
- 3-3. Not finalize

**Do not make 1 CD-ROM with 2 file together.**  
Please make CD-ROM with **only 1 file** (ex." E5N107\_GP2S.ab5 ") but **not folder**.

**It can be confirmed on the “FIRMWARE RENEWAL MODE”, please refer to the DV4500/DV6500 Service Manual on page 1-11-1 for the procedure.**

